LUBRICATION CHART

During breaking in period after every 300 900 1500 3000 miles 500 1500 5000 Kilometers	Lubrication point	Picture No.	Lubrican!	Remarks Required characteristics of lubricants	After breaking- in period, every
	Front axle: lubricate torsion bar tubes Lubricate king pins Lubricate tie rod joints	14 16 12,13	Universal grease	low-temperature grease water-repellent	1500 miles 2500 km
	Engine: change oil * Transmission / Differential: check oil level Check oil level in steering gear Lubricate parking brake cables Lubricate distributor cam Lubricate door and hood-locks and hinges	7-9 4 1 11 6	good quality HD-all ** Transmission oil Universal grease	Hypoid SAE 90 low-temperature grease water-repellent	3000 miles 5000 km
	Lubricate carburetor linkage joints Engine: Clean oil strainer and magnetic filter Engine: Replace oil refining filterinsert Transmission / Differential: change oil Repack front wheel bearings Lubricate shift lever	10 7 5 4 <u></u>	Transmission oil Multi-purpose gracse Lithium base Engine oil	together with an oil change In warm season: Hypoid SAE 90 *** Drop point above 1800 C (3560 F) ASTM peneitration: Worked: approx. 270	6000 miles 10000 km
	Lubricate parking brake cable tubes, carburetor linkage, clutch, heater and windshield wiper mechanism		Universal grease	low-temperature grease water-repellent	beginning of the cold season

