

			1		
	2	Ge	nerator		
	3 Re		gulator		
	4 Di		stributor		
ı	6	Igi	nition coil		
l	8	Sp	ark plug		
	9	Sp	ark plug socket		
	13	Ва	ttery		
1	15	H	eadlight		
1	15 a	Se	ealed Beam		ith parking light
1	16		Signal light		. S. AExport
1	18	В	ake tail light	١	
1	19	L	icense plate light	1	17
1	21		ack up light		
1	22	II	nterior light, Coupé 2 ea.,	1	
1			abriolet, Hardtop 1 ea.	ı	
1	23	F	og .lights		ptinal
١	27	C	il pressure warning light		Combination inst.
1	28		Senerator warning light	1 -	Combination inst.
1	29	1 1	Turn signal indicator light	(	on tachometer
1	30	F	ligh beam indicator light		on tachometer
Ì	31	,	Parking light indicator light		on tachometer
╁		_		Τ	
١	37		Ignition-starter switch	1	
- 1	39		Head light switch	1	
1	41		Brake light switch	1	
- }	42		Back-up light switch	1	
١	43		Oil pressure switch	-1	
- 1	44	1	Signal dimmer switch	-	
١	45	- 1	Door contact switches	-	optinal
- 1	46		Fog light switch	١	Optimar
-	48	1	Horn button	- 1	
	50	- 1	Windshield wiper switch	- 1	
	52	1	Horn relay	١	
	53	-	Light signal relay	ļ	
	55	- 1	Turn signal interrupter	- 1	
	56	- {	Fog light relay		optinal
	60		Accessory socket		
	61	ł	Fuse box		İ
	1	1	Forward wire loom		1
	63 64	-	Battery ground strap		
	1	1	Instrument wire loom		1
	65	- 1	Rear wire loom		
	66		Ignition cables		1
	6,7	- }	Plug connector		1
	. 69				<del>                                     </del>
	76		Two tone horn		
	80		Windshield wiper		
	82		Cigarette lighter		<del> </del>
	83		Tachometer		
89		)	Speedometer		
90		)	Combination instrument		
92		2	Electric clock		
	93	3	Fuel gauge sender		
	9.	4	Oil thermometer sender		}