Operations, Descriptions	Page	Remarks
Crankshaft:		
Crankshaft - General	SE 5	
Removing and Installing Main Bearings	SE 5	
Adjusting End Play	SE 6	
Adjusting Crankshaft End Play	SE 49	356 C
Crankshaft and Main Bearing Dimension for		·
1600 S-90 Engine	SE 15	
Crankshaft and Main Bearing Dimension for		
1600 C and 1600 SC Engines	SE 50	356 C
Timing Gear Backlash	SE 26	
Connecting Rod Bearing Inserts	SE 26	
•••••		

Torque Values	SE 17	
Performance and Fuel Consumption Diagram for		
1600 S-90 Engine	SE 19	
Performance and Fuel Consumption Diagram for		
1600 C Engine	SE 56	356 C
Performance and Fuel Consumption Diagram for	ŀ	
1600 SC Engine	SE 57	356 C
Tolerances and Wear Limits	SE 21	s)
Tolerances and Wear Limits for 1600 SC Engine	SE 52	356 C
Tolerances and Wear Limits for 1600 C Engine	SE 54	356 C
Adjusting Ignition Timing	SE 12	
••••••		
•••••••••••••••••••••••••••••••••••••••		
Clutch:		
Diaphragm Clutch (A 12) for 1600 S-90 Engine	SE 27	starting with Engine No. 804 001
•••••••	,	
••••••		
••••••		

		*