SECTION INDEX

Group F: Fuel System

	Pα	ge	9
Description of Fuel System	F		1 3 9
Carburetor Adjustment Data			7
Carburetor:			
Procedures: 1 Fu Removing and Installing Carburetor 2 Fu Cleaning Carburetor 3 Fu Disassembling and Assembling Carburetor 4 Fu Idling Adjustment 5 Fu Adjusting Injection Ratio 6 Fu Checking Fuel Level in Float Housing 7 Fu Checking Float 8 Fu Checking Throttle Valve Assembly 9 Fu Cleaning Air Filter 10 Fu Replacing Micronic Filter Elements 11 Fu Removing and Installing Intake Manifold 12 Fu Removing and Installing Carburetor Linkage 13 Fu Adjusting Carburetor Connecting Rod Assembly Carburetor Troubles and Their Cure	F F F F F F F F F F F	1: 1: 1: 1: 1: 1: 1: 1: 1: 1: 1: 1: 1: 1	2 4 5 6 7 7 8 8 9 9
Fuel Pump: Description of Fuel Pump Fuel Pump Components Procedures: 14 Fu Checking Fuel Pump Pressure 15 Fu Removing and Installing Fuel Pump 16 Fu Reconditioning Fuel Pump Fuel Pump Troubles and Their Cure Fuel Tank: Procedure: 17 Fu Removing and Installing Fuel Thank	F F F	2 2 2 2	24 25 25 26 29
Fuel Cock: Fuel Cock Fuel Cock Procedures: 18 Fu Removing and Installing Fuel Cock 19 Fu Inspection of Fuel System 20 Fu Fuel Mileage Test	. F . F		31 32 33 33