



Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tick

-80 -60 -40 -20 0 20 40 60 80