ETSI TS 129 002 V8.12.0 (2010-02)

Technical Specification

**Digital cellular telecommunications system (Phase 2+);
Universal Mobile Telecommunications System (UMTS);
Mobile Application Part (MAP) specification
(3GPP TS 29.002 version 8.12.0 Release 8)**



Reference
RTS/TSGC-0429002v8c0

Keywords
GSM, UMTS

ETSI

650 Route des Lucioles
F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C
Association à but non lucratif enregistrée à la
Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

Individual copies of the present document can be downloaded from:
http://www.etsi.org

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status. Information on the current status of this and other ETSI documents is available at
http://portal.etsi.org/tb/status/status.asp

If you find errors in the present document, please send your comment to one of the following services:
http://portal.etsi.org/chaircor/ETSI_support.asp

Copyright Notification

No part may be reproduced except as authorized by written permission.
The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2010.
All rights reserved.

DECT™, **PLUGTESTS**™, **UMTS**™, **TIPHON**™, the TIPHON logo and the ETSI logo are Trade Marks of ETSI registered for the benefit of its Members.
3GPP™ is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.
LTE™ is a Trade Mark of ETSI currently being registered
for the benefit of its Members and of the 3GPP Organizational Partners.
GSM® and the GSM logo are Trade Marks registered and owned by the GSM Association.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: *"Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards"*, which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp.

Contents

Intellectual Property Rights 2
Foreword 2
Foreword 26
1 Scope 27
2 References 27
3 Abbreviations 33
4 Void 33
5 Overload and compatibility overview 33
5.1 Overload control 33
5.1.1 Overload control for MSC (outside MAP) 33
5.1.2 Overload control for MAP entities 33
5.1.3 Congestion control for Signalling System No. 7 37
5.2 Compatibility 37
5.2.1 General 37
5.2.2 Strategy for selecting the Application Context (AC) version 37
5.2.2.1 Proposed method 37
5.2.2.2 Managing the version look-up table 38
5.2.2.3 Optimising the method 39
6 Requirements concerning the use of SCCP and TC 39
6.1 Use of SCCP 39
6.1.1 SCCP Class 39
6.1.2 Sub-System Number (SSN) 40
6.1.3 SCCP addressing 40
6.1.3.1 Introduction 40
6.1.3.2 The Mobile-services Switching Centre (MSC) 42
6.1.3.2.1 MSC interaction during handover or relocation 42
6.1.3.2.2 MSC for short message routing 42
6.1.3.2.3 MSC for location request routing 42
6.1.3.2.4 MSC for LMU Control 42
6.1.3.3 The Home Location Register (HLR) 43
6.1.3.3.1 During call set-up 43
6.1.3.3.2 Before location updating completion 43
6.1.3.3.3 After location updating completion 43
6.1.3.3.4 VLR restoration 44
6.1.3.3.5 During Network-Requested PDP Context Activation 44
6.1.3.3.6 Before GPRS location updating completion 44
6.1.3.3.7 After GPRS location updating completion 45
6.1.3.3.8 Query for a Location Request 45
6.1.3.4 The Visitor Location Register (VLR) 45
6.1.3.4.1 Inter-VLR information retrieval 45
6.1.3.4.2 HLR request 45
6.1.3.5 The Interworking MSC (IWMSC) for Short Message Service 45
6.1.3.6 The Equipment Identity Register (EIR) 46
6.1.3.7 Void 46
6.1.3.8 The Serving GPRS Support Node (SGSN) 46
6.1.3.9 The Gateway GPRS Support Node (GGSN) 46
6.1.3.10 The Gateway MSC (GMSC) for Short Message Service 46
6.1.3.10A Void 46
6.1.3.10A.1 Void 46
6.1.3.10A.2 Void 46
6.1.3.10B The Gateway Mobile Location Centre (GMLC) 46
6.1.3.11 Summary table 46

6.2 Use of TC 48
7 General on MAP services 48
7.1 Terminology and definitions 48
7.2 Modelling principles 49
7.3 Common MAP services 49
7.3.1 MAP-OPEN service 50
7.3.2 MAP-CLOSE service 53
7.3.3 MAP-DELIMITER service 53
7.3.4 MAP-U-ABORT service 53
7.3.5 MAP-P-ABORT service 54
7.3.6 MAP-NOTICE service 55
7.3.7 Void 56
7.3.8 Void 56
7.3.9 Void 56
7.3.10 Void 56
7.4 Sequencing of services 56
7.5 General rules for mapping of services onto TC 57
7.5.1 Mapping of common services 57
7.5.2 Mapping of user specific services 58
7.6 Definition of parameters 59
7.6.1 Common parameters 59
7.6.1.1 Invoke Id 59
7.6.1.2 Linked Id 59
7.6.1.3 Provider error 59
7.6.1.4 User error 59
7.6.2 Numbering and identification parameters 63
7.6.2.1 IMSI 63
7.6.2.2 TMSI 63
7.6.2.3 IMEI 63
7.6.2.3a IMEISV 63
7.6.2.4 Previous location area Id 63
7.6.2.5 Stored location area Id 63
7.6.2.6 Current location area Id 63
7.6.2.7 Target location area Id 63
7.6.2.8 Target cell Id 63
7.6.2.8A Target RNC Id 63
7.6.2.9 Void 64
7.6.2.10 Originating entity number 64
7.6.2.11 MSC number 64
7.6.2.12 Target MSC number 64
7.6.2.13 HLR number 64
7.6.2.14 VLR number 64
7.6.2.15 HLR Id 64
7.6.2.16 LMSI 64
7.6.2.17 MS ISDN 64
7.6.2.18 OMC Id 64
7.6.2.19 Roaming number 64
7.6.2.19A Relocation Number List 64
7.6.2.20 Void 64
7.6.2.21 Handover number 64
7.6.2.22 Forwarded-to number 65
7.6.2.22A Long forwarded-to number 65
7.6.2.22B Long FTN Supported 65
7.6.2.23 Forwarded-to subaddress 65
7.6.2.24 Called number 65
7.6.2.25 Calling number 65
7.6.2.26 Originally dialled number 65
7.6.2.27 Service centre address 65
7.6.2.28 Zone Code 65
7.6.2.29 MSIsdn-Alert 65
7.6.2.30 Location Information 65

7.6.2.30a Location Information for GPRS 65
7.6.2.31 GMSC Address 65
7.6.2.32 VMSC Address 66
7.6.2.33 Group Id 66
7.6.2.34 North American Equal Access preferred Carrier Id 66
7.6.2.35 Void 66
7.6.2.36 Void 66
7.6.2.37 Serving cell Id 66
7.6.2.38 SGSN number 66
7.6.2.39 SGSN address 66
7.6.2.40 GGSN address 66
7.6.2.41 GGSN number 66
7.6.2.42 APN 66
7.6.2.43 Network Node number 66
7.6.2.44 PDP-Type 66
7.6.2.45 PDP-Address 67
7.6.2.46 Additional number 67
7.6.2.47 P-TMSI 67
7.6.2.48 B-subscriber number 67
7.6.2.49 B-subscriber subaddress 67
7.6.2.50 LMU Number 67
7.6.2.51 MLC Number 67
7.6.2.52 Multicall Bearer Information 67
7.6.2.53 Multiple Bearer Requested 67
7.6.2.54 Multiple Bearer Not Supported 67
7.6.2.55 PDP-Charging Characteristics 67
7.6.2.56 Selected RAB ID 67
7.6.2.57 RAB ID 67
7.6.2.58 gsmSCF Address 67
7.6.2.59 V-GMLC Address 68
7.6.2.60 Void 68
7.6.2.61 H-GMLC Address 68
7.6.2.62 PPR Address 68
7.6.2.63 Routeing Number 68
7.6.2.64 Additional V-GMLC Address 68
7.6.3 Subscriber management parameters 68
7.6.3.1 Category 68
7.6.3.2 Equipment status 68
7.6.3.2a BMUEF 68
7.6.3.3 Extensible Bearer service 68
7.6.3.4 Extensible Teleservice 68
7.6.3.5 Extensible Basic Service Group 68
7.6.3.6 GSM bearer capability 69
7.6.3.7 Subscriber Status 69
7.6.3.8 CUG Outgoing Access indicator 69
7.6.3.9 Operator Determined Barring General Data 69
7.6.3.10 ODB HPLMN Specific Data 71
7.6.3.11 Regional Subscription Data 71
7.6.3.12 Regional Subscription Response 71
7.6.3.13 Roaming Restriction Due To Unsupported Feature 71
7.6.3.14 Extensible SS-Info 71
7.6.3.15 Extensible forwarding information 72
7.6.3.16 Extensible forwarding feature 72
7.6.3.17 Extensible SS-Status 72
7.6.3.18 Extensible Forwarding Options 72
7.6.3.19 Extensible No reply condition timer 73
7.6.3.20 Extensible Call barring information 73
7.6.3.21 Extensible Call barring feature 73
7.6.3.22 CUG info 73
7.6.3.23 CUG subscription 73
7.6.3.24 CUG interlock 73
7.6.3.25 CUG index 73

7.6.3.26 CUG feature 73
7.6.3.27 Inter CUG options 74
7.6.3.28 Intra CUG restrictions 74
7.6.3.29 Extensible SS-Data 74
7.6.3.30 Subscriber State 74
7.6.3.31 Requested Info 74
7.6.3.31A Requested Domain 74
7.6.3.32 Suppression of Announcement 75
7.6.3.33 Suppress T-CSI 75
7.6.3.34 GMSC CAMEL Subscription Info 75
7.6.3.35 VLR CAMEL Subscription Info 75
7.6.3.36 Supported CAMEL Phases in the VLR 75
7.6.3.36A Supported CAMEL Phases in the SGSN 75
7.6.3.36B Offered CAMEL4 CSIs in the VLR 75
7.6.3.36C Offered CAMEL4 CSIs in the SGSN 75
7.6.3.36D Offered CAMEL4 CSIs 75
7.6.3.36E Offered CAMEL4 CSIs in interrogating node 75
7.6.3.36F Offered CAMEL4 CSIs in VMSC 75
7.6.3.36G Offered CAMEL4 Functionalities 75
7.6.3.36H Supported CAMEL Phases 75
7.6.3.36I Supported CAMEL Phases in interrogating node 75
7.6.3.37 CUG Subscription Flag 76
7.6.3.38 CAMEL Subscription Info Withdraw 76
7.6.3.39 Voice Group Call Service (VGCS) Data 76
7.6.3.40 Voice Broadcast Service (VBS) Data 76
7.6.3.41 ISDN bearer capability 76
7.6.3.42 Lower layer Compatibility 76
7.6.3.43 High Layer Compatibility 76
7.6.3.44 Alerting Pattern 76
7.6.3.45 GPRS Subscription Data Withdraw 76
7.6.3.45A EPS Subscription Data Withdraw 76
7.6.3.46 GPRS Subscription Data 76
7.6.3.46A EPS Subscription Data 76
7.6.3.47 QoS-Subscribed 76
7.6.3.48 VPLMN address allowed 77
7.6.3.49 Roaming Restricted In SGSN/MME Due To Unsupported Feature 77
7.6.3.50 Network Access Mode 77
7.6.3.51 Mobile Not Reachable Reason 77
7.6.3.52 Cancellation Type 77
7.6.3.53 All GPRS Data 77
7.6.3.54 Complete Data List Included 77
7.6.3.55 PDP Context Identifier 77
7.6.3.56 LSA Information 77
7.6.3.57 SoLSA support indicator 77
7.6.3.58 LSA Information Withdraw 77
7.6.3.59 LMU Indicator 77
7.6.3.60 LCS Information 78
7.6.3.61 GMLC List 78
7.6.3.62 LCS Privacy Exception List 78
7.6.3.62A Additional LCS Privacy Exception List 78
7.6.3.63 LCS Privacy Exception Parameters 78
7.6.3.64 External Client List 78
7.6.3.65 Internal Client List 79
7.6.3.65A MO-LR List 79
7.6.3.65B Privacy Notification to MS User 79
7.6.3.65C GMLC List Withdraw 79
7.6.3.65D Service Type List 79
7.6.3.66 IST Alert Timer 79
7.6.3.67 Call Termination Indicator 79
7.6.3.68 IST Information Withdraw 79
7.6.3.69 IST Support Indicator 79
7.6.3.70 Super-Charger Supported In HLR 80

7.6.3.71 Super-Charger Supported In Serving Network Entity....80
7.6.3.72 Age Indicator....80
7.6.3.73 GPRS enhancements support indicator....80
7.6.3.74 Extension QoS-Subscribed....80
7.6.3.75 SGSN CAMEL Subscription Info....80
7.6.3.75A Extension-2 QoS-Subscribed....80
7.6.3.75B Extension-3 QoS-Subscribed....80
7.6.3.76 MO-SMS-CSI....80
7.6.3.76a MT-SMS-CSI....80
7.6.3.77 GPRS-CSI....80
7.6.3.78 CAMEL subscription info....80
7.6.3.83 Call Barring Data....81
7.6.3.84 Call Forwarding Data....81
7.6.3.85 ODB Data....81
7.6.3.86 Requested Subscription Info....81
7.6.3.87 CS Allocation/Retention priority....81
7.6.3.88 ODB Info....82
7.6.3.89 Suppress VT-CSI....82
7.6.3.90 Suppress Incoming Call Barring....82
7.6.3.91 gsmSCF Initiated Call....82
7.6.3.91a SuppressMTSS....82
7.6.3.92 Call barring support indicator....82
7.6.3.93 MNP Info Result....82
7.6.3.94 Allowed Services....82
7.6.3.95 Unavailability Cause....82
7.6.3.96 MNP Requested Info....82
7.6.3.97 Access Restriction Data....82
7.6.3.98 Supported RAT types indicator....83
7.6.4 Supplementary services parameters....83
7.6.4.1 SS-Code....83
7.6.4.1A SS-Code 2....83
7.6.4.2 SS-Status....83
7.6.4.3 SS-Data....83
7.6.4.4 Override Category....84
7.6.4.5 CLI Restriction Option....84
7.6.4.6 Forwarding Options....84
7.6.4.7 No reply condition timer....84
7.6.4.8 - 7.6.4.14 Void....84
7.6.4.15 Forwarding information....84
7.6.4.16 Forwarding feature....84
7.6.4.17 Void....85
7.6.4.18 Call barring information....85
7.6.4.19 Call barring feature....85
7.6.4.20 New password....85
7.6.4.21 Current password....85
7.6.4.22 Guidance information....85
7.6.4.23 Void....86
7.6.4.24 SS-Info....86
7.6.4.25 - 7.6.4.35 Void....86
7.6.4.36 USSD Data Coding Scheme....86
7.6.4.37 USSD String....86
7.6.4.38 Bearer service....86
7,6,4.38A Bearer Service 2....86
7.6.4.39 Teleservice....86
7.6.4.39A Teleservice 2....86
7.6.4.40 Basic Service Group....87
7.6.4.41 eMLPP information....87
7.6.4.42 SS-event....87
7.6.4.43 SS-event data....87
7.6.4.44 LCS Privacy Exceptions....87
7.6.4.45 Mobile Originating Location Request (MO-LR)....87
7.6.4.46 NbrUser....88

7.6.4.47 MC Subscription Data 88
7.6.4.48 MC Information 88
7.6.4.49 CCBS Request State 88
7.6.4.50 Basic Service Group 2 88
7.6.5 Call parameters 88
7.6.5.1 Call reference number 88
7.6.5.2 Interrogation type 89
7.6.5.3 OR interrogation 89
7.6.5.4 OR capability 89
7.6.5.5 Forwarding reason 89
7.6.5.6 Forwarding interrogation required 89
7.6.5.7 O-CSI 89
7.6.5.7A D-CSI 89
7.6.5.7B T-CSI 89
7.6.5.7C VT-CSI 89
7.6.5.7D O-IM-CSI 89
7.6.5.7E D-IM-CSI 90
7.6.5.7F VT-IM-CSI 90
7.6.5.8 Void 90
7.6.5.9 Void 90
7.6.5.10 Void 90
7.6.5.11 CCBS Feature 90
7.6.5.12 UU Data 90
7.6.5.14 Number Portability Status 90
7.6.5.15 Pre-paging supported 90
7.6.5.16 MT Roaming Retry Supported 90
7.6.5.17 MT Roaming Retry 90
7.6.5.18 Paging Area 91
7.6.5.19 Call Priority 91
7.6.6 Radio parameters 91
7.6.6.1 - 7.6.6.3 Void 91
7.6.6.4 GERAN Classmark 91
7.6.6.5 BSSMAP Service Handover 91
7.6.6.5A BSSMAP Service Handover List 91
7.6.6.6 RANAP Service Handover 91
7.6.6.7 HO-Number Not Required 91
7.6.6.8 Integrity Protection Information 91
7.6.6.9 Encryption Information 91
7.6.6.10 Radio Resource Information 91
7.6.6.10A Radio Resource List 91
7.6.6.10B Chosen Radio Resource Information 91
7.6.6.11 Key Status 92
7.6.6.12 Selected UMTS Algorithms 92
7.6.6.13 Allowed GSM Algorithms 92
7.6.6.14 Allowed UMTS Algorithms 92
7.6.6.15 Selected GSM Algorithm 92
7.6.6.16 Iu-Currently Used Codec 92
7.6.6.17 Iu-Supported Codecs List 92
7.6.6.17A Iu-Available Codecs List 92
7.6.6.18 Iu-Selected Codec 92
7.6.6.19 RAB Configuration Indicator 92
7.6.6.20 UESBI-Iu 92
7.6.6.21 Alternative Channel Type 92
7.6.7 Authentication parameters 93
7.6.7.1 Authentication set list 93
7.6.7.2 Rand 93
7.6.7.3 Sres 93
7.6.7.4 Kc 93
7.6.7.5 Xres 93
7.6.7.5A Ck 93
7.6.7.5B Ik 93
7.6.7.5C Autn 93

7.6.7.5D KASME....93
7.6.7.6 Cksn....93
7.6.7.6A Ksi....93
7.6.7.6B Auts....93
7.6.7.7 Ciphering mode....93
7.6.7.8 Current Security Context....94
7.6.7.9 Failure cause....94
7.6.7.10 Re-attempt....94
7.6.7.11 Access Type....94
7.6.8 Short message parameters....94
7.6.8.1 SM-RP-DA....94
7.6.8.2 SM-RP-OA....94
7.6.8.3 MWD status....94
7.6.8.4 SM-RP-UI....95
7.6.8.5 SM-RP-PRI....95
7.6.8.6 SM Delivery Outcome....95
7.6.8.7 More Messages To Send....95
7.6.8.8 Alert Reason....95
7.6.8.9 Absent Subscriber Diagnostic SM....95
7.6.8.10 Alert Reason Indicator....95
7.6.8.10A Additional Alert Reason Indicator....95
7.6.8.11 Additional SM Delivery Outcome....95
7.6.8.12 Additional Absent Subscriber Diagnostic SM....95
7.6.8.13 Delivery Outcome Indicator....95
7.6.8.14 GPRS Node Indicator....95
7.6.8.15 GPRS Support Indicator....96
7.6.8.16 SM-RP-MTI....96
7.6.8.17 SM-RP-SMEA....96
7.6.8.18 IP-SM-GW SM Delivery Outcome....96
7.6.8.19 IP-SM-GW Absent Subscriber Diagnostic SM....96
7.6.8.20 IP-SM-GW Indicator....96
7.6.9 Access and signalling system related parameters....96
7.6.9.1 AN-apdu....96
7.6.9.2 CM service type....96
7.6.9.3 Access connection status....97
7.6.9.4 External Signal Information....97
7.6.9.5 Access signalling information....97
7.6.9.6 Location update type....97
7.6.9.7 Protocol ID....97
7.6.9.8 Network signal information....97
7.6.9.8A Network signal information 2....98
7.6.9.9 Call Info....98
7.6.9.10 Additional signal info....98
7.6.10 System operations parameters....99
7.6.10.1 Network resources....99
7.6.10.2 Trace reference....99
7.6.10.2A Trace reference 2....99
7.6.10.3 Trace type....99
7.6.10.4 Additional network resources....99
7.6.10.5 Trace depth list....99
7.6.10.6 Trace NE type list....99
7.6.10.7 Trace interface list....99
7.6.10.8 Trace event list....100
7.6.10.9 Trace support indicator....100
7.6.10.10 Trace Propagation List....100
7.6.11 Location Service Parameters....100
7.6.11.1 Age of Location Estimate....100
7.6.11.2 Deferred MT-LR Response Indicator....100
7.6.11.3 Deferred MT-LR Data....100
7.6.11.4 LCS Client ID....100
7.6.11.5 LCS Event....100
7.6.11.7 LCS Priority....100

7.6.11.8 LCS QoS 100
7.6.11.9 CS LCS Not Supported by UE 101
7.6.11.10 PS LCS Not Supported by UE 101
7.6.11.11 Location Estimate 101
7.6.11.11A GERAN Positioning Data 101
7.6.11.11B UTRAN Positioning Data 101
7.6.11.12 Location Type 101
7.6.11.13 NA-ESRD 102
7.6.11.14 NA-ESRK 102
7.6.11.15 LCS Service Type Id 102
7.6.11.16 Privacy Override 102
7.6.11.17 Supported LCS Capability Sets 102
7.6.11.18 LCS Codeword 102
7.6.11.19 NA-ESRK Request 102
7.6.11.20 Supported GAD Shapes 102
7.6.11.21 Additional Location Estimate 102
7.6.11.22 Cell Id Or SAI 103
7.6.11.23 LCS-Reference Number 103
7.6.11.24 LCS Privacy Check 103
7.6.11.25 Additional LCS Capability Sets 103
7.6.11.26 Area Event Info 103
7.6.11.27 Velocity Estimate 103
7.6.11.28 Accuracy Fulfilment Indicator 103
7.6.11.29 MO-LR Short Circuit Indicator 103
7.6.11.30 Reporting PLMN List 104
7.6.11.31 Periodic LDR information 104
7.6.11.32 Sequence Number 104
7.6.12 Void 104
7.7 Representation of a list of a basic parameter in service-primitives 104

8 Mobility services 105
8.1 Location management services 105
8.1.1 Void 105
8.1.1.1 Void 105
8.1.1.2 Void 105
8.1.1.3 Void 105
8.1.2 MAP_UPDATE_LOCATION service 105
8.1.2.1 Definition 105
8.1.2.2 Service primitives 105
8.1.2.3 Parameter definitions and use 105
8.1.3 MAP_CANCEL_LOCATION service 108
8.1.3.1 Definition 108
8.1.3.2 Service primitives 108
8.1.3.3 Parameter definitions and use 108
8.1.4 MAP_SEND_IDENTIFICATION service 109
8.1.4.1 Definition 109
8.1.4.2 Service primitives 109
8.1.4.3 Parameter definitions and use 109
8.1.5 Void 110
8.1.5.1 Void 110
8.1.5.2 Void 110
8.1.5.3 Void 110
8.1.6 MAP_PURGE_MS service 110
8.1.6.1 Definition 110
8.1.6.2 Service primitives 111
8.1.6.3 Parameter definitions and use 111
8.1.7 MAP_UPDATE_GPRS_LOCATION service 112
8.1.7.1 Definition 112
8.1.7.2 Service primitives 112
8.1.7.3 Parameter definitions and use 113
8.1.8 MAP-NOTE-MM-EVENT 115
8.1.8.1 Definition 115

8.1.8.2 Service primitives 116
8.1.8.3 Parameter use 116
8.2 Paging and search 117
8.2.1 MAP_PAGE service 117
8.2.1.1 Definition 117
8.2.1.2 Service primitives 117
8.2.1.3 Parameter definitions and use 118
8.2.2 MAP_SEARCH_FOR_MS service 118
8.2.2.1 Definition 118
8.2.2.2 Service primitives 118
8.2.2.3 Parameter definitions and use 119
8.3 Access management services 119
8.3.1 MAP_PROCESS_ACCESS_REQUEST service 119
8.3.1.1 Definition 119
8.3.1.2 Service primitives 119
8.3.1.3 Parameter definitions and use 120
8.4 Handover services 121
8.4.1 MAP_PREPARE_HANDOVER service 121
8.4.1.1 Definition 121
8.4.1.2 Service primitives 121
8.4.1.3 Parameter use 122
8.4.2 MAP_SEND_END_SIGNAL service 125
8.4.2.1 Definition 125
8.4.2.2 Service primitives 125
8.4.2.3 Parameter use 125
8.4.3 MAP_PROCESS_ACCESS_SIGNALLING service 126
8.4.3.1 Definition 126
8.4.3.2 Service primitives 126
8.4.3.3 Parameter use 126
8.4.4 MAP_FORWARD_ACCESS_SIGNALLING service 127
8.4.4.1 Definition 127
8.4.4.2 Service primitives 127
8.4.4.3 Parameter use 128
8.4.5 MAP_PREPARE_SUBSEQUENT_HANDOVER service 129
8.4.5.1 Definition 129
8.4.5.2 Service primitives 130
8.4.5.3 Parameter use 130
8.4.6 MAP_ALLOCATE_HANDOVER_NUMBER service 131
8.4.6.1 Definition 131
8.4.6.2 Service primitives 131
8.4.6.3 Parameter use 131
8.4.7 MAP_SEND_HANDOVER_REPORT service 131
8.4.7.1 Definition 131
8.4.7.2 Service primitives 132
8.4.7.3 Parameter use 132
8.5 Authentication management services 132
8.5.1 MAP_AUTHENTICATE service 132
8.5.1.1 Definition 132
8.5.1.2 Service primitives 132
8.5.1.3 Parameter use 133
8.5.2 MAP_SEND_AUTHENTICATION_INFO service 133
8.5.2.1 Definition 133
8.5.2.2 Service primitives 134
8.5.2.3 Parameter use 134
8.5.3 MAP_AUTHENTICATION_FAILURE_REPORT service 135
8.5.3.1 Definition 135
8.5.3.2 Service primitives 135
8.5.3.3 Parameter use 136
8.6 Security management services 137
8.6.1 MAP_SET_CIPHERING_MODE service 137
8.6.1.1 Definitions 137
8.6.1.2 Service primitives 137

8.6.1.3 Parameter use 137
8.7 International mobile equipment identities management services 137
8.7.1 MAP_CHECK_IMEI service 137
8.7.1.1 Definition 137
8.7.1.2 Service primitives 137
8.7.1.3 Parameter use 138
8.7.2 MAP_OBTAIN_IMEI service 139
8.7.2.1 Definition 139
8.7.2.2 Service primitives 139
8.7.2.3 Parameter use 139
8.8 Subscriber management services 139
8.8.1 MAP-INSERT-SUBSCRIBER-DATA service 139
8.8.1.1 Definition 139
8.8.1.2 Service primitives 140
8.8.1.3 Parameter use 141
8.8.1.4 Basic service information related to supplementary services 151
8.8.2 MAP-DELETE-SUBSCRIBER-DATA service 151
8.8.2.1 Definition 151
8.8.2.2 Service primitives 152
8.8.2.3 Parameter use 152
8.9 Identity management services 155
8.9.1 MAP-PROVIDE-IMSI service 155
8.9.1.1 Definition 155
8.9.1.2 Service primitives 155
8.9.1.3 Parameter use 155
8.9.2 MAP-FORWARD-NEW-TMSI service 155
8.9.2.1 Definition 155
8.9.2.2 Service primitives 156
8.9.2.3 Parameter use 156
8.10 Fault recovery services 156
8.10.1 MAP_RESET service 156
8.10.1.1 Definition 156
8.10.1.2 Service primitives 156
8.10.1.3 Parameter definition and use 156
8.10.2 MAP_FORWARD_CHECK_SS_INDICATION service 157
8.10.2.1 Definition 157
8.10.2.2 Service primitives 157
8.10.2.3 Parameter definition and use 157
8.10.3 MAP_RESTORE_DATA service 157
8.10.3.1 Definition 157
8.10.3.2 Service primitives 157
8.10.3.3 Parameter definitions and use 158
8.11 Subscriber Information services 159
8.11.1 MAP-ANY-TIME-INTERROGATION service 159
8.11.1.1 Definition 159
8.11.1.2 Service primitives 159
8.11.1.3 Parameter definition and use 160
8.11.2 MAP-PROVIDE-SUBSCRIBER-INFO service 160
8.11.2.1 Definition 160
8.11.2.2 Service primitives 161
8.11.2.3 Parameter definition and use 161
8.11.3 MAP-ANY-TIME-SUBSCRIPTION-INTERROGATION service 161
8.11.3.1 Definition 161
8.11.3.2 Service primitives 161
8.11.3.3 Parameter definition and use 162
8.11.4 MAP-ANY-TIME-MODIFICATION service 162
8.11.4.1 Definition 162
8.11.4.2 Service primitives 163
8.11.4.3 Parameter definition and use 163
8.11.5 MAP-NOTE-SUBSCRIBER-DATA-MODIFIED service 164
8.11.5.1 Definition 164
8.11.5.2 Service primitives 164

8.11.5.3 Parameter definition and use 164
9 Operation and maintenance services 165
9.1 Subscriber tracing services 165
9.1.1 MAP-ACTIVATE-TRACE-MODE service 165
9.1.1.1 Definition 165
9.1.1.2 Service primitives 166
9.1.1.3 Parameter use 166
9.1.2 MAP-DEACTIVATE-TRACE-MODE service 167
9.1.2.1 Definition 167
9.1.2.2 Service primitives 167
9.1.2.3 Parameter use 167
9.1.3 MAP-TRACE-SUBSCRIBER-ACTIVITY service 168
9.1.3.1 Definition 168
9.1.3.2 Service primitives 168
9.1.3.3 Parameter use 168
9.2 Other operation and maintenance services 169
9.2.1 MAP-SEND-IMSI service 169
9.2.1.1 Definition 169
9.2.1.2 Service primitives 169
9.2.1.3 Parameter use 169
10 Call handling services 169
10.1 MAP_SEND_ROUTING_INFORMATION service 169
10.1.1 Definition 169
10.1.2 Service primitives 169
10.1.3 Parameter use 170
10.2 MAP_PROVIDE_ROAMING_NUMBER service 176
10.2.1 Definition 176
10.2.2 Service primitives 176
10.2.3 Parameter use 176
10.3 MAP_RESUME_CALL_HANDLING service 179
10.3.1 Definition 179
10.3.2 Service primitives 179
10.3.3 Parameter use 179
10.4 MAP_PREPARE_GROUP_CALL service 181
10.4.1 Definition 181
10.4.2 Service primitives 181
10.4.3 Parameter definitions and use 181
10.5 MAP_PROCESS_GROUP CALL_SIGNALLING service 182
10.5.1 Definitions 182
10.5.2 Service primitives 182
10.5.3 Parameter definitions and use 183
10.6 MAP_FORWARD_GROUP_CALL_SIGNALLING service 183
10.6.1 Definitions 183
10.6.2 Service primitives 183
10.6.3 Parameter definitions and use 184
10.7 MAP_SEND_GROUP_CALL_END_SIGNAL service 185
10.7.1 Definitions 185
10.7.2 Service primitives 185
10.7.3 Parameter definitions and use 185
10.7A MAP_SEND_GROUP_CALL_INFO service 186
10.7A.1 Definitions 186
10.7A.2 Service primitives 186
10.7A.3 Parameter definitions and use 186
10.8 Void 188
10.9 Void 188
10.10 MAP_SET_REPORTING_STATE service 188
10.10.1 Definition 188
10.10.2 Service primitives 188
10.10.3 Parameter use 188
10.11 MAP_STATUS_REPORT service 189

10.11.1 Definition 189
10.11.2 Service primitives 189
10.11.3 Parameter use 189
10.12 MAP_REMOTE_USER_FREE service 190
10.12.1 Definition 190
10.12.2 Service primitives 190
10.12.3 Parameter use 190
10.13 MAP_IST_ALERT service 191
10.13.1 Definition 191
10.13.2 Service primitives 191
10.13.3 Parameter use 191
10.14 MAP_IST_COMMAND service 192
10.14.1 Definition 192
10.14.2 Service primitives 192
10.14.3 Parameter use 192
10.15 MAP_RELEASE_RESOURCES service 192
10.15.1 Definition 192
10.15.2 Service primitives 192
10.15.3 Parameter use 193

11 Supplementary services related services 193
11.1 MAP_REGISTER_SS service 193
11.1.1 Definition 193
11.1.2 Service primitives 193
11.1.3 Parameter use 193
11.2 MAP_ERASE_SS service 195
11.2.1 Definition 195
11.2.2 Service primitives 195
11.2.3 Parameter use 195
11.3 MAP_ACTIVATE_SS service 196
11.3.1 Definition 196
11.3.2 Service primitives 196
11.3.3 Parameter use 196
11.4 MAP_DEACTIVATE_SS service 197
11.4.1 Definitions 197
11.4.2 Service primitives 197
11.4.3 Parameter use 198
11.5 MAP_INTERROGATE_SS service 199
11.5.1 Definitions 199
11.5.2 Service primitives 199
11.5.3 Parameter use 199
11.6 Void 201
11.7 MAP_REGISTER_PASSWORD service 201
11.7.1 Definitions 201
11.7.2 Service primitives 201
11.7.3 Parameter use 201
11.8 MAP_GET_PASSWORD service 202
11.8.1 Definitions 202
11.8.2 Service primitives 202
11.8.3 Parameter use 202
11.9 MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service 202
11.9.1 Definitions 202
11.9.2 Service primitives 202
11.9.3 Parameter use 203
11.10 MAP_UNSTRUCTURED_SS_REQUEST service 203
11.10.1 Definitions 203
11.10.2 Service primitives 204
11.10.3 Parameter use 204
11.11 MAP_UNSTRUCTURED_SS_NOTIFY service 205
11.11.1 Definitions 205
11.11.2 Service primitives 205
11.11.3 Parameter use 205

11.12 MAP_SS_INVOCATION_NOTIFY 206
11.12.1 Definition 206
11.12.2 Service primitives 206
11.12.3 Parameter use 206
11.13 MAP_REGISTER_CC_ENTRY service 206
11.13.1 Definition 206
11.13.2 Service primitives 207
11.13.3 Parameter use 207
11.14 MAP_ERASE_CC_ENTRY service 208
11.14.1 Definition 208
11.14.2 Service primitives 208
11.14.3 Parameter use 208

12 Short message service management services 209
12.1 MAP-SEND-ROUTING-INFO-FOR-SM service 209
12.1.1 Definition 209
12.1.2 Service primitives 209
12.1.3 Parameter use 209
12.2 MAP-MO-FORWARD-SHORT-MESSAGE service 211
12.2.1 Definition 211
12.2.2 Service primitives 211
12.2.3 Parameter use 211
12.3 MAP-REPORT-SM-DELIVERY-STATUS service 212
12.3.1 Definition 212
12.3.2 Service primitives 212
12.3.3 Parameter use 213
12.4 MAP-READY-FOR-SM service 214
12.4.1 Definition 214
12.4.2 Service primitives 214
12.4.3 Parameter use 214
12.5 MAP-ALERT-SERVICE-CENTRE service 215
12.5.1 Definition 215
12.5.2 Service primitives 215
12.5.3 Parameter use 215
12.6 MAP-INFORM-SERVICE-CENTRE service 216
12.6.1 Definition 216
12.6.2 Service primitives 216
12.6.3 Parameter use 216
12.7 MAP-SEND-INFO-FOR-MT-SMS service 217
12.7.1 Definition 217
12.7.2 Service primitives 217
12.7.3 Parameter use 217
12.8 MAP-SEND-INFO-FOR-MO-SMS service 218
12.8.1 Definition 218
12.8.2 Service primitives 218
12.8.3 Parameter use 218
12.9 MAP-MT-FORWARD-SHORT-MESSAGE service 219
12.9.1 Definition 219
12.9.2 Service primitives 219
12.9.3 Parameter use 219
12.10 MAP-MT-FORWARD-SM-FOR-VGCS service 220
12.10.1 Definition 220
12.10.2 Service primitives 220
12.10.3 Parameter use 220

13 Network-Requested PDP Context Activation services 221
13.1 MAP_SEND_ROUTING_INFO_FOR_GPRS service 221
13.1.1 Definition 221
13.1.2 Service primitives 222
13.1.3 Parameter definition and use 222
13.2 MAP_FAILURE_REPORT service 223
13.2.1 Definition 223

13.2.2 Service primitives 223
13.2.3 Parameter definition and use 223
13.3 MAP_NOTE_MS_PRESENT_FOR_GPRS service 223
13.3.1 Definition 223
13.3.2 Service primitives 224
13.3.3 Parameter definition and use 224

13A Location Service Management Services 224
13A.1 MAP-SEND-ROUTING-INFO-FOR-LCS Service 224
13A.1.1 Definition 224
13A.1.2 Service Primitives 225
13A.1.3 Parameter Use 225
13A.2 MAP-PROVIDE-SUBSCRIBER-LOCATION Service 226
13A.2.1 Definition 226
13A.2.2 Service Primitives 226
13A.2.3 Parameter Definition and Use 227
13A.3 MAP-SUBSCRIBER-LOCATION-REPORT Service 230
13A.3.1 Definition 230
13A.3.2 Service Primitives 230
13A.3.3 Parameter Definition and Use 230
13A.4 Void 234
13A.4.1 Void 234
13A.4.2 Void 234
13A.4.3 Void 234
13A.5 Void 234
13A.5.1 Void 234
13A.5.2 Void 234
13A.5.3 Void 234
13A.6 Void 234
13A.6.1 Void 234
13A.6.2 Void 234
13A.6.3 Void 234
13A.7 Void 234
13A.7.1 Void 234
13A.7.2 Void 234
13A.7.3 Void 234
13A.8 Void 234
13A.8.1 Void 234
13A.8.2 Void 234
13A.8.3 Void 234
13A.9 Void 234
13A.9.1 Void 234
13A.9.2 Void 235
13A.9.3 Void 235

14 General 235
14.1 Overview 235
14.2 Underlying services 235
14.3 Model 235
14.4 Conventions 235

15 Elements of procedure 236
15.1 Handling of unknown operations 236
15.2 Dialogue establishment 236
15.2.1 Behaviour at the initiating side 237
15.2.2 Behaviour at the responding side 237
15.3 Dialogue continuation 238
15.4 Load control 238
15.5 Procedures for MAP specific services 238
15.5.1 Service invocation 239
15.5.2 Void 239
15.5.3 Service invocation receipt 239
15.5.4 Void 239

15.5.5 Handling of components received from TC....239
15.6 SDL descriptions....239

16 Mapping on to TC services....272
16.1 Dialogue control....272
16.1.1 Directly mapped parameters....272
16.1.2 Use of other parameters of dialogue handling primitives....272
16.1.2.1 Dialogue Id....272
16.1.2.2 Application-context-name....272
16.1.2.3 User information....272
16.1.2.4 Component present....272
16.1.2.5 Termination....272
16.1.2.6 P-Abort-Cause....272
16.1.2.7 Quality of service....273
16.2 Service specific procedures....273
16.2.1 Directly mapped parameters....273
16.2.2 Use of other parameters of component handling primitives....273
16.2.2.1 Dialogue Id....273
16.2.2.2 Class....273
16.2.2.3 Linked Id....273
16.2.2.4 Operation....274
16.2.2.5 Error....275
16.2.2.6 Parameters....275
16.2.2.7 Time out....275
16.2.2.8 Last component....275
16.2.2.9 Problem code....275
16.2.2.9.1 Mapping to MAP User Error....275
16.2.2.9.2 Mapping to MAP Provider Error parameter....276
16.2.2.9.3 Mapping to diagnostic parameter....276

17 Abstract syntax of the MAP protocol....277
17.1 General....277
17.1.1 Encoding rules....277
17.1.2 Use of TC....277
17.1.2.1 Use of Global Operation and Error codes defined outside MAP....278
17.1.3 Use of information elements defined outside MAP....278
17.1.4 Compatibility considerations....278
17.1.5 Structure of the Abstract Syntax of MAP....279
17.1.6 Application Contexts....281
17.2 Operation packages....283
17.2.1 General aspects....283
17.2.2 Packages specifications....284
17.2.2.1 Location updating....284
17.2.2.2 Location cancellation....284
17.2.2.3 Roaming number enquiry....284
17.2.2.4 Information retrieval....284
17.2.2.5 Inter-VLR information retrieval....285
17.2.2.6 IMSI retrieval....285
17.2.2.7 Call control transfer....285
17.2.2.8 Void....285
17.2.2.9 Void....285
17.2.2.10 Interrogation....285
17.2.2.11 Void....286
17.2.2.12 Handover Control....286
17.2.2.13 Subscriber Data management stand alone....286
17.2.2.14 Equipment management....286
17.2.2.15 Subscriber data management....286
17.2.2.16 Location register restart....287
17.2.2.17 Tracing stand-alone....287
17.2.2.18 Functional SS handling....287
17.2.2.19 Tracing....287
17.2.2.20 Binding....287

17.2.2.21 Unstructured SS handling 288
17.2.2.22 MO Short message relay services 288
17.2.2.23 Short message gateway services 288
17.2.2.24 MT Short message relay services 289
17.2.2.25 Void 289
17.2.2.26 Message waiting data management 289
17.2.2.27 Alerting 289
17.2.2.28 Data restoration 289
17.2.2.29 Purging 290
17.2.2.30 Subscriber information enquiry 290
17.2.2.31 Any time information enquiry 290
17.2.2.32 Group Call Control 290
17.2.2.32A Group Call Info Retrieval 290
17.2.2.33 Void 291
17.2.2.34 Void 291
17.2.2.35 Gprs location updating 291
17.2.2.36 Gprs Interrogation 291
17.2.2.37 Failure reporting 291
17.2.2.38 GPRS notifying 291
17.2.2.39 Supplementary Service invocation notification 292
17.2.2.40 Set Reporting State 292
17.2.2.41 Status Report 292
17.2.2.42 Remote User Free 292
17.2.2.43 Call Completion 292
17.2.2.44 Location service gateway services 292
17.2.2.45 Location service enquiry 293
17.2.2.45A Location service reporting 293
17.2.2.46 Void 293
17.2.2.47 Void 293
17.2.2.48 Void 293
17.2.2.49 IST Alerting 293
17.2.2.50 Service Termination 293
17.2.2.51 Mobility Management event notification 294
17.2.2.53 Subscriber Data modification notification 294
17.2.2.54 Authentication Failure Report 294
17.2.2.55 Resource Management 294
17.2.2.56 MT Short message relay VGCS services 295
17.3 Application contexts 295
17.3.1 General aspects 295
17.3.2 Application context definitions 296
17.3.2.1 Void 296
17.3.2.2 Location Updating 296
17.3.2.3 Location Cancellation 296
17.3.2.4 Roaming number enquiry 296
17.3.2.5 Void 297
17.3.2.6 Location Information Retrieval 297
17.3.2.7 Call control transfer 297
17.3.2.8 Void 297
17.3.2.9 Void 297
17.3.2.10 Void 297
17.3.2.11 Location registers restart 297
17.3.2.12 Handover control 298
17.3.2.13 IMSI Retrieval 298
17.3.2.14 Equipment Management 298
17.3.2.15 Information retrieval 298
17.3.2.16 Inter-VLR information retrieval 299
17.3.2.17 Stand Alone Subscriber Data Management 299
17.3.2.18 Tracing 299
17.3.2.19 Network functional SS handling 300
17.3.2.20 Network unstructured SS handling 300
17.3.2.21 Short Message Gateway 300
17.3.2.22 Mobile originating Short Message Relay 301

17.3.2.23 Void....301
17.3.2.24 Short message alert....301
17.3.2.25 Short message waiting data management....301
17.3.2.26 Mobile terminating Short Message Relay....302
17.3.2.27 MS purging....302
17.3.2.28 Subscriber information enquiry....302
17.3.2.29 Any time information enquiry....302
17.3.2.30 Group Call Control....303
17.3.2.30A Group Call Info Retrieval....303
17.3.2.31 Void....303
17.3.2.32 Gprs Location Updating....303
17.3.2.33 Gprs Location Information Retreival....303
17.3.2.34 Failure Reporting....304
17.3.2.35 GPRS Notifying....304
17.3.2.36 Supplementary Service invocation notification....304
17.3.2.37 Reporting....304
17.3.2.38 Call Completion....304
17.3.2.39 Location Service Gateway....305
17.3.2.40 Location Service Enquiry....305
17.3.2.41 Void....305
17.3.2.42 Void....305
17.3.2.43 Void....305
17.3.2.44 IST Alerting....305
17.3.2.45 Service Termination....305
17.3.2.46 Mobility Management event notification....306
17.3.2.48 Subscriber Data modification notification....306
17.3.2.49 Authentication Failure Report....306
17.3.2.50 Resource Management....306
17.3.2.51 Mobile terminating Short Message Relay VGCS....307
17.3.3 ASN.1 Module for application-context-names....307
17.4 MAP Dialogue Information....309
17.5 MAP operation and error codes....311
17.6 MAP operations and errors....313
17.6.1 Mobile Service Operations....313
17.6.2 Operation and Maintenance Operations....320
17.6.3 Call Handling Operations....321
17.6.4 Supplementary service operations....324
17.6.5 Short message service operations....328
17.6.6 Errors....331
17.6.7 Group Call operations....337
17.6.8 Location service operations....339
17.6.9 Void....340
17.7 MAP constants and data types....340
17.7.1 Mobile Service data types....340
17.7.2 Operation and maintenance data types....380
17.7.3 Call handling data types....384
17.7.4 Supplementary service data types....390
17.7.5 Supplementary service codes....394
17.7.6 Short message data types....397
17.7.7 Error data types....401
17.7.8 Common data types....407
17.7.9 Teleservice Codes....415
17.7.10 Bearer Service Codes....416
17.7.11 Extension data types....418
17.7.12 Group Call data types....419
17.7.13 Location service data types....421
17.7.14 Void....431

18 General on MAP user procedures....432
18.1 Introduction....432
18.2 Common aspects of user procedure descriptions....432
18.2.1 General conventions....432

18.2.2 Naming conventions 432
18.2.3 Convention on primitives parameters 434
18.2.3.1 Open service 434
18.2.3.2 Close service 434
18.2.4 Version handling at dialogue establishment 434
18.2.4.1 Behaviour at the initiating side 434
18.2.4.2 Behaviour at the responding side 434
18.2.5 Abort Handling 434
18.2.6 SDL conventions 434
18.3 Interaction between MAP Provider and MAP Users 435

19 Mobility procedures 436
19.1 Location management Procedures 436
19.1.1 Location updating 437
19.1.1.1 General 437
19.1.1.2 Procedures in the VLR 442
19.1.1.3 Procedure in the PVLR 442
19.1.1.4 Procedure in the SGSN 442
19.1.1.5 Procedures in the HLR 443
19.1.2 Location Cancellation 463
19.1.2.1 General 463
19.1.2.2 Procedure in the HLR 463
19.1.2.3 Procedure in the VLR 464
19.1.2.4 Procedure in the SGSN 464
19.1.3 Void 471
19.1.4 MS Purging 471
19.1.4.1 General 471
19.1.4.2 Procedure in the VLR 471
19.1.4.3 Procedure in the SGSN 471
19.1.4.4 Procedure in the HLR 472
19.2 Handover procedures 477
19.2.1 General 477
19.2.2 Procedure in MSC-A 480
19.2.2.1 Basic handover 480
19.2.2.2 Handling of access signalling 481
19.2.2.3 Subsequent handover 481
19.2.3 Procedure in MSC-B 481
19.2.3.1 Basic handover 482
19.2.3.2 Handling of access signalling 482
19.2.3.3 Subsequent handover 482
19.2.4 Macro Receive_Error_From_HO_CA 482
19.2.5 Procedure in VLR-B 482
19.3 Fault recovery procedures 501
19.3.1 VLR fault recovery procedures 501
19.3.1.1 General 501
19.3.1.2 Procedure in the VLR 502
19.3.1.3 Procedure in the HLR 502
19.3.2 HLR fault recovery procedures 504
19.3.2.1 General 504
19.3.2.2 Procedure in the HLR 505
19.3.2.3 Procedure in the VLR 505
19.3.2.4 Procedure in the SGSN 506
19.4 Mobility Management event notification procedure 512
19.4.1 General 512
19.4.2 Procedure in the VLR or SGSN 512
19.4.3 Procedure in the gsmSCF 512
19.4 HLR Insert Subscriber Data macros 515
19.5.1 Macro Insert_Subs_Data_Framed_HLR 515
19.5.2 Macro Insert_GPRS_Subs_Data_Framed_HLR 515

20 Operation and maintenance procedures 518
20.1 General 518

20.1.1 Tracing Co-ordinator for the VLR 518
20.1.2 Tracing Co-ordinator for the SGSN 518
20.1.3 Subscriber Data Management Co-ordinator for the VLR 518
20.1.4 Subscriber Data Management Co-ordinator for the SGSN 518
20.2 Tracing procedures 523
20.2.1 Subscriber tracing activation procedure 526
20.2.1.1 Procedures in the HLR 526
20.2.1.2 Procedure in the VLR 526
20.2.1.3 Procedure in the SGSN 526
20.2.2 Subscriber tracing deactivation procedure 526
20.2.2.1 Procedures in the HLR 526
20.2.2.2 Procedure in the VLR 527
20.2.2.3 Procedure in the SGSN 527
20.3 Subscriber data management procedures 540
20.3.1 Subscriber deletion procedure 541
20.3.1.1 Procedure in the HLR 541
20.3.1.2 Procedure in the VLR 541
20.3.1.3 Procedure in the SGSN 541
20.3.2 Subscriber data modification procedure 542
20.3.2.1 Procedure in the HLR 542
20.3.2.2 Procedures in the VLR 543
20.3.2.3 Procedures in the SGSN 543
20.4 Subscriber Identity procedure 555
20.4.1 Procedure in the VLR 555
20.4.2 Procedure in the HLR 555

21 Call handling procedures 558
21.1 General 558
21.2 Retrieval of routing information 558
21.2.1 General 558
21.2.2 Procedure in the GMSC 561
21.2.9 Process in the gsmSCF 562
21.2.4 Procedure in the HLR 562
21.2.5 Procedure in the VLR to provide a roaming number 562
21.2.6 Procedure in the VLR to restore subscriber data 562
21.2.7 Procedure in the VLR to provide subscriber information 562
21.3 Transfer of call handling 571
21.3.1 General 571
21.3.2 Process in the VMSC 571
21.3.3 Process in the GMSC 572
21.4 Inter MSC Group Call Procedures 575
21.4.1 General 575
21.4.2 Process in the Anchor MSC 576
21.4.3 Process in the Relay MSC 576
21.4A Inter MSC Group Call Info Retrieval 581
21.4A.1 General 581
21.4A.2 Process in the MSC 581
21.5 Void 584
21.6 CCBS: monitoring and reporting the status of the subscriber 584
21.6.1 Reporting co-ordinator process in the VLR 584
21.6.2 Setting the reporting state – stand-alone 584
21.6.2.1 Process in the HLR 584
21.6.2.2 Process in the VLR 584
21.6.3 Status Reporting 584
21.6.3.1 Process in the VLR 585
21.6.3.2 Process in the HLR 586
21.6.4 CCBS: Remote User Free 586
21.6.4.1 Process in the HLR 587
21.6.3.2 Process in the VLR 587
21.7 Void 600
21.8 Void 600
21.9 Immediate Service Termination (IST) 600

21.9.1 IST Alert 600
21.9.1.1 Procedure in the MSC 600
21.9.1.2 Procedure in the HLR 600
21.9.2 IST Command 600
21.9.2.1 Procedure in the HLR 601
21.9.2.2 Procedure in the MSC 601
21.10 Resource Management 606
21.10.1 General 606
21.3.2 Process in the GMSC 606
21.3.3 Process in the VMSC 606

22 Supplementary services procedures 609
22.1 Supplementary service co-ordinator processes 609
22.1.1 Supplementary service co-ordinator process for the MSC 609
22.1.2 Void 609
22.1.3 Functional supplementary service co-ordinator process for the HLR 609
22.1.4 Call completion supplementary service co-ordinator process for the HLR 609
22.2 Registration procedure 614
22.2.1 General 614
22.2.2 Procedure in the MSC 615
22.2.3 Procedure in the VLR 615
22.2.4 Procedure in the HLR 615
22.3 Erasure procedure 621
22.3.1 General 621
22.3.2 Procedure in the MSC 622
22.3.3 Procedure in the VLR 622
22.3.4 Procedure in the HLR 622
22.4 Activation procedure 622
22.4.1 General 622
22.4.2 Procedure in the MSC 623
22.4.3 Procedure in the VLR 624
22.4.4 Procedure in the HLR 624
22.5 Deactivation procedure 630
22.5.1 General 630
22.5.2 Procedure in the MSC 631
22.5.3 Procedures in the VLR 631
22.5.4 Procedures in the HLR 631
22.6 Interrogation procedure 631
22.6.1 General 631
22.6.2 Procedure in the MSC 632
22.6.3 Procedures in the VLR 632
22.6.4 Procedure in the HLR 633
22.7 Void 637
22.8 Password registration procedure 638
22.8.1 General 638
22.8.2 Procedure in the MSC 640
22.8.3 Procedure in the VLR 640
22.8.4 Procedure in the HLR 640
22.9 Mobile Initiated USSD procedure 643
22.9.1 General 643
22.9.2 Procedure in the MSC 643
22.9.3 Procedure in the VLR 643
22.9.4 Procedure in the HLR 644
22.9.5 Procedures in the gsmSCF/secondary HLR 644
22.10 Network initiated USSD procedure 658
22.10.1 General 658
22.10.2 Procedure in the MSC 658
22.10.3 Procedure in the VLR 658
22.10.4 Procedure in the HLR 659
22.10.5 Procedure in the gsmSCF or secondary HLR 659
22.11 Common macros for clause 22 679
22.11.1 SS Password handling macros 679

22.11.2 Void 679
22.12 Supplementary Service Invocation Notification procedure 683
22.12.1 General 683
22.12.2 Procedure in the MSC 683
22.12.3 Procedure in the gsmSCF 683
22.13 Activation of a CCBS request 686
22.13.1 General 686
22.13.2 Procedure in the VLR 686
22.13.3 Procedure in the HLR 686
22.14 Deactivation of a CCBS request 689
22.14.1 General 689
22.14.2 Procedure in the VLR 689
22.14.3 Procedure in the HLR 689

23 Short message service procedures 692
23.1 General 692
23.1.1 Mobile originated short message service Co-ordinator for the MSC 692
23.1.2 Short message Gateway Co-ordinator for the HLR 692
23.2 The mobile originated short message transfer procedure 696
23.2.1 Procedure in the serving MSC 697
23.2.2 Procedure in the VLR 697
23.2.3 Procedure in the SGSN 697
23.2.4 Procedure in the SMS Interworking MSC (SMS-IWMSC) 698
23.3 The mobile terminated short message transfer procedure 710
23.3.1 Procedure in the SMS-GMSC 717
23.3.2 Procedure in the HLR 718
23.3.3 Procedure in the Serving MSC 719
23.3.4 Procedure in the VLR 719
23.3.5 Procedure in the SGSN 719
23.3.6 Procedure in the SMS Router 720
23.3.7 Procedure in the IP-SM-GW 720
23.4 The Short Message Alert procedure 767
23.4.1 Procedure in the Serving MSC – the MS has memory available 769
23.4.2 Procedures in the VLR 769
23.4.2.1 The Mobile Subscriber is present 769
23.4.2.2 The MS has memory available 769
23.4.3 Procedures in the SGSN 770
23.4.3.1 The Mobile Subscriber is present 770
23.4.3.2 The Mobile Equipment has memory available 770
23.4.4 Procedure in the HLR 770
23.4.5 Procedure in the SMS Interworking MSC 770
23.5 The SM delivery status report procedure 779
23.5.1 Procedure in the SMS-GMSC 779
23.5.2 Procedure in the HLR 780
23.5.3 Procedure in the IP-SM-GW 780
23.6 The macro Report_SM_Delivery_Stat_HLR 785
23.7 The mobile terminated short message transfer procedure for VGCS 788
23.7.1 Procedure in the SMS-GMSC 789
23.7.2 Procedure in the Anchor MSC 789

24 GPRS process description 793
24.1 Procedure for retrieval of routeing information for GPRS 794
24.1.1 Process in the GGSN 794
24.1.2 Process in the HLR 794
24.2 Procedure for reporting failure to establish a network requested PDP context 797
24.2.1 Process in the GGSN 797
24.2.2 Process in the HLR 797
24.3 Procedure for reporting that an MS has become reachable for GPRS 800
24.3.1 Process in the HLR 800
24.3.2 Process in the GGSN for Note Ms Present For Gprs 800

24A CSE interrogation and control of subscriber data 803
24A.1 General 803

24A.2 Any Time Subscription Interrogation procedure 805
24A.2.1 General 805
24A.2.2 Process in the gsmSCF 805
24A.2.3 Process in the HLR 805
24A.3 Any Time Modification procedure 808
24A.3.1 General 808
24A.3.2 Process in the gsmSCF 808
24A.3.3 Process in the HLR 808
24A.4 Subscriber Data Modification Notification procedure 811
24A.4.1 General 811
24A.4.2 Process in the HLR 811
24A.4.3 Process in the gsmSCF 811
24A.5 Any Time Interrogation procedure 816
24A.5.1 General 816
24A.5.2 Procedures in the gsmSCF 817
24A.5.3 Procedure in the HLR 817
24A.5.4 Procedure in the GMLC 817

24B Location Services process description 823
24B.1 Routeing information retrieval procedure for LCS 823
24B.1.1 General 823
24B.1.2 Process in the GMLC 823
24B.1.3 Process in the HLR 823
24B.2 Provide Subscriber Location procedure 826
24B.2.1 General 826
24B.2.2 Process in the GMLC 826
24B.2.3 Process in the MSC 826
24B.2.4 Process in the SGSN 826
24B.3 Subscriber Location Report procedure 830
24B.3.1 General 830
24B.3.2 Process in the MSC 830
24B.3.3 Process in the SGSN 830
24B.3.4 Process in the GMLC 830

25 General macro description 834
25.1 MAP_OPEN handling macros 834
25.1.1 Macro Receive_Open_Ind 834
25.1.2 Macro Receive_Open_Cnf 834
25.2 Macros to check the content of indication and confirmation primitives 839
25.2.1 Macro Check_Indication 839
25.2.2 Macro Check_Confirmation 839
25.3 The page and search macros 842
25.3.1 Macro PAGE_MSC 842
25.3.2 Macro Search_For_MS_MSC 842
25.4 Macros for handling an Access Request 845
25.4.1 Macro Process_Access_Request_MSC 845
25.4.2 Macro Process_Access_Request_VLR 845
25.4.3 Macro Obtain_Identity_VLR 845
25.4.4 Process Update_Location_Child_VLR 845
25.5 Authentication macros and processes 855
25.5.1 Macro Authenticate_MSC 855
25.5.2 Macro Authenticate_VLR 855
25.5.3 Macro Obtain_Authent_Params_VLR 855
25.5.4 Process Obtain_Authentication_Sets_VLR 855
25.5.6 Process Obtain_Authent_Sets_SGSN 855
25.5.6 Process Obtain_Authent_Sets_HLR 855
25.5.7 Authentication Failure Reporting 856
25.5.7.1 General 856
25.5.7.2 Process in the VLR 856
25.5.7.3 Process in the SGSN 856
25.5.7.4 Process in the HLR 856
25.6 IMEI Handling Macros 872

25.6.1 Macro Check_IMEI_MSC 872
25.6.2 Macro Check_IMEI_VLR 872
25.6.3 Process Check_IMEI_SGSN 872
25.6.4 Process Check_IMEI_EIR 872
25.6.5 Macro Obtain_IMEI_MSC 872
25.6.6 Macro Obtain_IMEI_VLR 872
25.7 Insert Subscriber Data macros and processes 881
25.7.1 Macro Insert_Subs_Data_VLR 881
25.7.2 Macro Insert_Subs_Data_SGSN 881
25.7.3 Process Insert_Subs_Data_Stand_Alone_HLR 881
25.7.4 Process Insert_GPRS_Subs_Data_Stand_Alone_HLR 881
25.7.5 Macro Wait_for_Insert_Subs_Data_Cnf 882
25.7.6 Macro Wait_for_Insert_GPRS_Subs_Data_Cnf 882
25.7.7 Process Send_Insert_Subs_Data_HLR 882
25.8 Request IMSI Macros 892
25.8.1 Macro Obtain_IMSI_MSC 892
25.8.2 Macro Obtain_IMSI_VLR 892
25.9 Tracing macros 895
25.9.1 Macro Trace_Subscriber_Activity_MSC 895
25.9.2 Macro Trace_Subscriber_Activity_VLR 895
25.9.3 Macro Trace_Subscriber_Activity_SGSN 895
25.9.4 Macro Activate_Tracing_VLR 895
25.9.5 Macro Activate_Tracing_SGSN 895
25.9.6 Macro Control_Tracing_With_VLR_HLR 895
25.9.7 Macro Control_Tracing_With_SGSN_HLR 895
25.10 Short Message Alert procedures 903
25.10.1 Process Subscriber_Present_VLR 903
25.10.2 Process SubscriberPresent_SGSN 903
25.10.3 Macro Alert_Service_Centre_HLR 903
25.10.4 Process Alert_SC_HLR 903

Annex A (informative): ASN.1 Cross-reference listing and fully expanded sources 908

Annex B (informative): Void 909

Annex C (informative): Message Segmentation Mechanisms 910
C.1 SCCP segmentation 910
C.2 TCAP segmentation 910
C.2.1 Empty Begin 910
C.2.2 Empty Continue 910
C.2.3 TC-Result-NL 910
C.3 MAP Segmentation 911
C.3.1 Invoke without explicit indication 911
C.3.2 Invoke with explicit indication 911
C.3.3 Result 911

Annex D (informative): Void 914

Annex E (informative): Change History 915

History 931

Foreword

This Technical Specification (TS) has been produced by the 3rd Generation Partnership Project (3GPP).

The present document specifies the Mobile Application Part (MAP), the requirements for the signalling system and procedures within the 3GPP system at application level.

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

It is necessary to transfer between entities of a Public Land Mobile Network (PLMN) information specific to the PLMN in order to deal with the specific behaviour of roaming Mobile Stations (MS)s. The Signalling System No. 7 specified by CCITT is used to transfer this information.

The present document describes the requirements for the signalling system and the procedures needed at the application level in order to fulfil these signalling needs.

Clauses 1 to 6 are related to general aspects such as terminology, mobile network configuration and other protocols required by MAP.

MAP consists of a set of MAP services that are provided to MAP service-users by a MAP service-provider.




Figure 1.1/1: Modelling principles

Clauses 7 to 13A of the present document describe the MAP services.

Clauses 14 to 17 define the MAP protocol specification and the behaviour of service provider (protocol elements to be used to provide MAP services, mapping on to TC service primitives, abstract syntaxes, etc.).

Clauses 18 to 25 describe the MAP user procedures that make use of MAP services.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document.*

[1] 3GPP TS 21.905: "3G Vocabulary".

[2] 3GPP TS 22.001: "Digital cellular telecommunications system (Phase 2+); Principles of telecommunication services supported by a Public Land Mobile Network (PLMN)".

[3] 3GPP TS 22.002: "Bearer Services Supported by a Public Land Mobile Network (PLMN)".

[4] 3GPP TS 22.003: "Circuit Teleservices Supported by a Public Land Mobile Network (PLMN)".

[5] 3GPP TS 22.004: "General on Supplementary Services".

[6] 3GPP TS 42.009: "Digital cellular telecommunications system (Phase 2+); Security aspects".

[7] 3GPP TS 22.016: "International Mobile station Equipment Identities (IMEI)".

[8] 3GPP TS 22.041: "Operator Determined Barring".

[9] 3GPP TS 22.081: "Line identification supplementary services - Stage 1".

[10] 3GPP TS 22.082: "Call Forwarding (CF) supplementary services - Stage 1".

[11] 3GPP TS 22.083: "Call Waiting (CW) and Call Hold (HOLD) Supplementary Services - Stage 1".

[12] 3GPP TS 22.084: "Multi Party (MPTY) Supplementary Services - Stage 1".

[13] 3GPP TS 22.085: "Closed User Group (CUG) supplementary services - Stage 1".

[14] 3GPP TS 22.086: "Advice of charge (AoC) Supplementary Services - Stage 1".

[15] 3GPP TS 22.088: "Call Barring (CB) supplementary services - Stage 1".

[16] 3GPP TS 22.090: "Unstructured Supplementary Service Data (USSD); - Stage 1".

[17] 3GPP TS 23.003: "Numbering, addressing and identification".

[18] Void

[19] 3GPP TS 23.007: "Restoration procedures".

[20] 3GPP TS 23.008: "Organisation of subscriber data".

[21] 3GPP TS 23.009: "Handover procedures".

[22] 3GPP TS 23.011: "Technical realization of Supplementary Services - General Aspects".

[23] 3GPP TS 23.012: "Location management procedures".

[24] 3GPP TS 43.020: "Security related network functions".

[25] 3GPP TS 23.038: "Alphabets and language".

[25a] 3GPP TS 23.039: " Interface protocols for the connection of Short Message Service Centres (SMSCs) to Short Message Entities (SMEs)".

[26] 3GPP TS 23.040: "Technical realization of the Short Message Service (SMS) Point to Point (PP)".

[26a] 3GPP TS 23.271: "Functional stage2 description of LCS".

[27] 3GPP TS 23.081: "Line Identification Supplementary Services - Stage 2".

[28] 3GPP TS 23.082: "Call Forwarding (CF) Supplementary Services - Stage 2".

[29] 3GPP TS 23.083: "Call Waiting (CW) and Call Hold (HOLD) Supplementary Services - Stage 2".

[30] 3GPP TS 23.084: "Multi Party (MPTY) Supplementary Services - Stage 2".

[31] 3GPP TS 23.085: "Closed User Group (CUG) Supplementary Services - Stage 2".

[32] 3GPP TS 23.086: "Advice of Charge (AoC) Supplementary Services - Stage 2".

[33] 3GPP TS 23.088: "Call Barring (CB) Supplementary Services - Stage 2".

[34] 3GPP TS 23.090: "Unstructured Supplementary Services Data (USSD) - Stage 2".

[34a] 3GPP TS 33.204: "3G Security; Network domain security; TCAP user security".

[35] 3GPP TS 24.008: "Mobile Radio Interface Layer 3 specification; Core Network Protocols - Stage 3".

[36] 3GPP TS 24.010: "Mobile radio interface layer 3 Supplementary Services specification - General aspects".

[37] 3GPP TS 24.011: "Point-to-Point (PP) Short Message Service (SMS) support on mobile radio interface".

[37a] 3GPP TS 44.071: "Location Services (LCS) – stage 3".

[38] 3GPP TS 24.080: "Mobile radio interface layer 3 supplementary services specification - Formats and coding".

[39] 3GPP TS 24.081: "Line identification supplementary services - Stage 3".

[40] 3GPP TS 24.082: "Call Forwarding (CF) Supplementary Services - Stage 3".

[41] 3GPP TS 24.083: "Call Waiting (CW) and Call Hold (HOLD) supplementary services - Stage 3".

[42] 3GPP TS 24.084: "Multi Party (MPTY) Supplementary Services - Stage 3".

[43] 3GPP TS 24.085: "Closed User Group (CUG) Supplementary Services - Stage 3".

[44] 3GPP TS 24.086: "Advice of Charge (AoC) Supplementary Services - Stage 3".

[45] 3GPP TS 24.088: "Call Barring (CB) Supplementary Services - Stage 3".

[46] 3GPP TS 24.090: "Unstructured Supplementary Services Data - Stage 3".

[47] 3GPP TS 48.002: " Base Station System - Mobile-services Switching Centre (BSS - MSC) interface principles".

[48] 3GPP TS 48.006: "Signalling transport mechanism specification for the Base Station System - Mobile-services Switching Centre (BSS - MSC) interface".

[49] 3GPP TS 48.008: "Mobile Switching Centre - Base Station System (MSC - BSS) interface; Layer 3 specification".

[49a1] 3GPP TS 48.031: "Location Services (LCS); Serving Mobile Location Centre (SMLC) – Serving Mobile Location Centre (SMLC); SMLC Peer Protocol (SMLCPP)".

[49b] 3GPP TS 48.071: "Location Services (LCS); Serving Mobile Location Centre - Base Station System (SMLC - BSS) interface Layer 3 specification".

[50] 3GPP TS 49.001: "General network interworking scenarios".

[51] 3GPP TS 29.002: "Mobile Application Part (MAP) specification".

[52] Void

[53] Void

[54] Void

[55] 3GPP TS 29.006: "Interworking between a Public Land Mobile Network (PLMN) and a Packet Switched Public Data Network/Integrated Services Digital Network (PSPDN/ISDN) for the support of Packet Switched data transmission services".

[56] 3GPP TS 29.007: "General requirements on interworking between the Public Land Mobile Network (PLMN) and the Integrated Services Digital Network (ISDN) or Public Switched Telephone Network (PSTN)".

[57] 3GPP TS 29.008: "Application of the Base Station System Application Part (BSSAP) on the E-interface".

[58] 3GPP TS 29.010: "Information element mapping between Mobile Station - Base Station System and BSS - Mobile-services Switching Centre (MS - BSS - MSC) Signalling procedures and the Mobile Application Part (MAP)".

[59] 3GPP TS 29.011: "Signalling interworking for Supplementary Services".

[59a] 3GPP TS 49.031: "Digital cellular telecommunications system (Phase 2+); Location Services (LCS); Base Station System Application Part LCS Extension (BSSAP-LE)".

[60] Void

[61] 3GPP TS 52.008: " GSM Subscriber and Equipment Trace".

[62] ETS 300 102-1 (1990): "Integrated Services Digital Network (ISDN); User-network interface layer 3 specifications for basic call control".

[63] ETS 300 136 (1992): "Integrated Services Digital Network (ISDN); Closed User Group (CUG) supplementary service description".

[64] ETS 300 138 (1992): "Integrated Services Digital Network (ISDN); Closed User Group (CUG) supplementary service Digital Subscriber Signalling System No.one (DSS1) protocol".

[65] ETS 300 287: "Integrated Services Digital Network (ISDN); Signalling System No.7; Transaction Capabilities (TC) version 2".

[66] ETR 060: "Signalling Protocols and Switching (SPS); Guide-lines for using Abstract Syntax Notation One (ASN.1) in telecommunication application protocols".

[66b] ETR 091: "ETSI object identifier tree; Common domain Mobile domain"

[67] ITU-T Recommendation E.164: " The international public telecommunication numbering plan".

[68] ITU-T Recommendation E.212: " The international identification plan for mobile terminals and mobile users".

[69] ITU-T Recommendation E.213: " Telephone and ISDN numbering plan for land mobile stations in public land mobile networks (PLMN) ".

[70] ITU-T Recommendation E.214: " Structure of the land mobile global title for the signalling connection control part (SCCP) ".

[71] ITU-T Recommendation Q.699: " Interworking between ISDN access and non-ISDN access over ISDN User Part of Signalling System No. 7 ".

[72] ITU-T Recommendation Q.711: "Specifications of Signalling System No.7; Functional description of the Signalling Connection Control Part".

[73] ITU-T Recommendation Q.712: "Definition and function of SCCP messages".

[74] ITU-T Recommendation Q.713: "Specifications of Signalling System No.7; SCCP formats and codes".

[75] ITU-T Recommendation Q.714: "Specifications of Signalling System No.7; Signalling Connection Control Part procedures".

[76] ITU-T Recommendation Q.716: "Specifications of Signalling System No.7; Signalling connection control part (SCCP) performances".

[77] ITU-T Recommendation Q.721 (1988): "Specifications of Signalling System No.7; Functional description of the Signalling System No.7 Telephone user part".

[78] ITU-T Recommendation Q.722 (1988): "Specifications of Signalling System No.7; General function of Telephone messages and signals".

[79] ITU-T Recommendation Q.723 (1988): "Specifications of Signalling System No.7; Formats and codes".

[80] ITU-T Recommendation Q.724 (1988): "Specifications of Signalling System No.7; Signalling procedures".

[81] ITU-T Recommendation Q.725 (1988): "Specifications of Signalling System No.7; Signalling performance in the telephone application".

[82] ITU-T Recommendation Q.761 (1988): "Specifications of Signalling System No.7; Functional description of the ISDN user part of Signalling System No.7".

[83] ITU-T Recommendation Q.762 (1988): "Specifications of Signalling System No.7; General function of messages and signals".

[84] ITU-T Recommendation Q.763 (1988): "Specifications of Signalling System No.7; Formats and codes".

[85] ITU-T Recommendation Q.764 (1988): "Specifications of Signalling System No.7; Signalling procedures".

[86] ITU-T Recommendation Q.767: "Specifications of Signalling System No.7; Application of the ISDN user part of CCITT signalling System No.7 for international ISDN interconnections".

[87] ITU-T Recommendation Q.771: "Specifications of Signalling System No.7; Functional description of transaction capabilities".

[88] ITU-T Recommendation Q.772: "Specifications of Signalling System No.7; Transaction capabilities information element definitions".

[89] ITU-T Recommendation Q.773: "Specifications of Signalling System No.7; Transaction capabilities formats and encoding".

[90] ITU-T Recommendation Q.774: "Specifications of Signalling System No.7; Transaction capabilities procedures".

[91] ITU-T Recommendation Q.775: "Specifications of Signalling System No.7; Guide-lines for using transaction capabilities".

[92] ITU-T Recommendation X.200: "Reference Model of Open systems interconnection for CCITT Applications".

[93] ITU-T Recommendation X.680: "Information technology – Abstract Syntax Notation One (ASN.1): Specification of basic notation".

[93b] ITU-T Recommendation X.681: "Information technology – Abstract Syntax Notation One (ASN.1): Information object specification"

[94] ITU-T Recommendation X.690: "Information technology – ASN.1 encoding rules: Specification of Basic Encoding Rules (BER), Canonical Encoding Rules (CER) and Distinguished Encoding Rules (DER)".

[95] ITU-T Recommendation X.210: "Open systems interconnection layer service definition conventions".

[97] 3GPP TS 23.018: "Basic Call Handling".

[98] 3GPP TS 23.078: "Customised Applications for Mobile network Enhanced Logic (CAMEL) Phase 4 - Stage 2".

[99] 3GPP TS 23.079: "Support of Optimal Routeing (SOR) - Stage 2".

[100] 3GPP TS 43.068: "Voice Group Call Service (VGCS) - Stage 2".

[101] 3GPP TS 43.069: "Voice Broadcast service (VBS) - Stage 2".

[102] ANSI T1.113: "Signaling System No. 7 (SS7) - ISDN User Part".

[103] Void

[104] 3GPP TS 23.060: "General Packet Radio Service (GPRS) Description; Stage 2".

[105] 3GPP TS 29.060: "General Packet Radio Service (GPRS); GPRS Tunnelling Protocol (GTP) across the Gn and Gp Interface".

[106] 3GPP TS 29.018: "General Packet Radio Service (GPRS); Serving GPRS Support Node (SGSN) - Visitors Location Register (VLR); Gs interface layer 3 specification".

[107] 3GPP TS 23.093: "Technical Realization of Completion of Calls to Busy Subscriber (CCBS); Stage 2".

[108] 3GPP TS 23.066: "Support of Mobile Number Portability (MNP); Technical Realisation Stage 2".

[109] ANSI T1.112 (1996): "Telecommunication – Signalling No. 7 - Signaling Connection Control Part (SCCP)".

[110] 3GPP TS 23.116: "Super-Charger Technical Realisation; Stage 2."

[111] Void.

[112] Void

[113] Void

[114] Void

[115] Void

[116] ITU-T Recommendation Q.850 (May 1998): "Usage of cause and location in the Digital Subscriber Signalling System No. 1 and the Signalling System No. 7 ISDN User Part".

[117] 3GPP TS 22.135: "Multicall; Service description; Stage 1".

[118] 3GPP TS 23.135: "Multicall supplementary service; Stage 2".

[119] 3GPP TS 24.135: "Multicall supplementary service; Stage 3".

[120] 3GPP TS 25.413: "UTRAN Iu Interface RANAP Signalling".

[121] 3GPP TS 29.202: "SS7 signalling transport in core network"

[122] 3GPP TS 23.032: "Universal Geographical Area Description (GAD)"

[123] 3GPP TS 22.071: " Location Services (LCS); Service description, Stage 1"

[124] ITU-T Recommendation X.880: "Data networks and open system communication - Open System Interconnection - Service definitions - Remote operations: Concepts, model and notation".

[125] 3GPP TS 23.278: 'Customised Applications for Mobile Network Enhanced Logic (CAMEL) Phase 4 – Stage 2 IM CN Interworking (Rel-5)'

[126] 3GPP TS 23.172: "Technical realization of Circuit Switched (CS) multimedia service; UDI/RDI fallback and service modification"

[127] 3GPP TS 26.103: "Speech codec list for GSM and UMTS".

[128] 3GPP TS 23.141: "Presence Service; Architecture and Functional Description"

[129] 3GPP TS 23.094: "Follow Me (FM) – Stage 2"

[130] 3GPP TS 32.422: "Subscriber and equipment trace; Trace control and Configuration Management (CM)".

[131] 3GPP TS 32.421: "Subscriber and equipment trace: Trace concepts and requirements".

[132] 3GPP TS 32.422: "Subscriber and equipment trace; Trace control and Configuration Management".

[133] 3GPP TS 23.236: " Intra-domain connection of Radio Access Network (RAN) nodes to multiple Core Network (CN) nodes"

[134] 3GPP TS 23.204: "Support of Short Message Service (SMS) over generic 3GPP Internet Protocol (IP) access"

[135] 3GPP TS 23.292: "IP Multimedia Subsystem (IMS) Centralized Services"

[136] 3GPP TS 23.067: "enhanced Multi-Level Precedence and Pre-emption service (eMLPP) - Stage 2"

[137] 3GPP TS 24.067: "Enhanced Multi-Level Precedence and Pre-emption service (eMLPP); Stage 3"

[138] 3GPP TS 22.011: "Service accessibility".

[139] IETF RFC 3588: "Diameter Base Protocol"

[140] 3GPP TS 29.274: " Evolved General Packet Radio Service (GPRS) Tunnelling Protocol for Control plane (GTPv2-C); Stage 3"

3 Abbreviations

ADD Automatic Device Detection

All other abbreviations used in the present document are listed in 3GPP TS 21.905.

4 Void

5 Overload and compatibility overview

5.1 Overload control

There is a requirement for an overload/congestion control for all entities of the Public Land Mobile Network and the underlying Signalling System No. 7.

5.1.1 Overload control for MSC (outside MAP)

For the entity MSC the following two procedures (outside MAP) may be applied to control the processor load:

- ISDN
  CCITT Recommendation Q.764 (Automatic Congestion Control), applicable to reduce the mobile terminating traffic;

- BSSAP
  3GPP TS 48.008 [49] (A-interface Flow Control), applicable to reduce the mobile originating traffic.

5.1.2 Overload control for MAP entities

For all MAP entities, especially the HLR, the following overload control method is applied.

If overload of a MAP entity is detected requests for certain MAP operations (see tables 5.1/1, 5.1/2, 5.1/3 and 5.1/4) may be ignored by the responder. The decision as to which MAP Operations may be ignored is made by the MAP service provider and is based upon the priority of the application context.

Since most of the affected MAP operations are supervised in the originating entity by TC timers (medium) an additional delay effect is achieved for the incoming traffic.

If overload levels are applicable in the Location Registers the MAP operations should be discarded taking into account the priority of their application context (see table 5.1/1 for HLR, table 5.1/2 for MSC/VLR, table 5.1/3 for the SGSN and table 5.1/4 for the SMLC; the lowest priority is discarded first).

The ranking of priorities given in the tables 5.1/1, 5.1/2, 5.1/3 and 5.1/4 is not normative. The tables can only be seen as a proposal that might be changed due to network operator/implementation matters.

Table 5.1/1: Priorities of Application Contexts for HLR as Responder

	Responder = HLR	**Initiating Entity**
Priority high		
	Mobility Management	
	networkLocUp (updateLocation), (restoreData/v2), (sendParameters/v1)	VLR
	gprsLocationUpdate (updateGPRSLocation/v3),	SGSN
	infoRetrieval (sendAuthenticationInfo/v2/v3), (sendParameters/v1)	VLR/SGSN
	istAlerting (istAlert/v3)	MSC
	msPurging (purgeMS/v2/v3)	VLR
	msPurging (purgeMS/v3)	SGSN
	Short Message Service	
	shortMsgGateway (sendRoutingInfoforSM), (reportSM-DeliveryStatus)	GMSC
	mwdMngt (readyForSM/v2/v3), (noteSubscriberPresent/v1)	VLR/SGSN
	Mobile Terminating Traffic	
	locInfoRetrieval (sendRoutingInfo)	GMSC
	anyTimeEnquiry (anyTimeInterrogation/v3)	gsmSCF
	reporting (statusReport)	VLR
	Location Services	
	locationSvcGateway (sendRoutingInfoforLCS/v3)	GMLC
	Subscriber Controlled Inputs (Supplementary Services)	
	networkFunctionalSs (registerSS), (eraseSS), (activateSS), (deactivateSS), (interrogateSS), (registerPassword), (processUnstructuredSS-Data/v1), (beginSubscriberActivity/v1)	VLR
	callCompletion (registerCCEntry), (eraseCCEntry)	VLR
	networkUnstructuredSs (processUnstructuredSS-Request/v2)	VLR
	imsiRetrieval (sendIMSI/v2)	VLR
	gprsLocationInfoRetrieval (sendRoutingInfoForGprs/v3/v4)	GGSN/SGSN
	failureReport (failureReport/v3)	GGSN/SGSN
	authenticationFailureReport (authenticationFailureReport/v3)	VLR/SGSN
Priority low		

NOTE: The application context name is the last component but one of the object identifier.
Operation names are given in brackets for information with "/vn" appended to vn only operations.

Table 5.1/3: Priorities of Application Contexts for SGSN as Responder

Responder = SGSN	Initiating Entity
Priority high	
Mobility and Location Register Management	
locationCancel (cancelLocation v3)	HLR
reset (reset)	HLR
subscriberDataMngt (insertSubscriberData v3), (deleteSubscriberData v3)	HLR
tracing (activateTraceMode), (deactivateTraceMode)	HLR
Short Message Service	
shortMsgMT-Relay (MT-ForwardSM v3), (forwardSM v1/v2)	MSC
Location Services	
locationSvcEnquiry (provideSubscriberLocation v3)	GMLC
Network-Requested PDP context activation	
gprsNotify (noteMsPresentForGprs v3),	HLR
(*Subscriber Location & State retrieval)*	
subscriberInfoEnquiry (provideSubscriberInformation/v3)	HLR
Priority low	

NOTE: The application context name is the last component but one of the object identifier.
Operation names are given in brackets for information with "/vn" appended to vn.

Table 5.1/2: Priorities of Application Contexts for MSC/VLR as Responder

Responder = MSC/VLR	Initiating Entity
Priority high	
Handover	
handoverControl (prepareHandover/v2/v3), (performHandover/v1)	MSC
Group call and Broadcast call	
groupCallControl (prepareGroupCall/v3)	MSC
groupCallInfoRetrieval (sendGroupCallInfo/v3)	MSC
Mobility and Location Register Management	
locationCancel (cancelLocation)	HLR
reset (reset)	HLR
immediateTermination (istCommand/v3)	HLR
interVlrInfoRetrieval (sendIdentification/v2/v3), (sendParameters/v1)	VLR
subscriberDataMngt (insertSubscriberData), (deleteSubscriberData)	HLR
tracing (activateTraceMode), (deactivateTraceMode)	HLR
Short Message Service	
shortMsgMO-Relay (MO-ForwardSM v3), (forwardSM v1/v2)	MSC/SGSN
shortMsgMT-Relay (MT-ForwardSM v3), (forwardSM v1/v2)	MSC
shortMsgAlert (alertServiceCentre/v2), (alertServiceCentreWithoutResult/v1)	HLR
Mobile Terminating Traffic	
resourceMngt (releaseResources)	GMSC
roamingNbEnquiry (provideRoamingNumber)	HLR
callControlTransfer (resumeCallHandling)	MSC
subscriberInfoEnquiry (provideSubscriberInformation/v3)	HLR
reporting (remoteUserFree), (SetReportingState)	HLR
Location Services	
locationSvcEnquiry (provideSubscriberLocation/v3)	GMLC
Network-Initiated USSD	
networkUnstructuredSs (unstructuredSS-Request/v2), (unstructuredSS-Notify/v2)	HLR
Priority low	

NOTE: The application context name is the last component but one of the object identifier.
Operation names are given in brackets for information with "/vn" appended to vn only operations.

5.1.3 Congestion control for Signalling System No. 7

The requirements of SS7 Congestion control have to be taken into account as far as possible.

Means that could be applied to achieve the required traffic reductions are described in clauses 5.1.1 and 5.1.2.

5.2 Compatibility

5.2.1 General

The present document of the Mobile Application Part is designed in such a way that an implementation which conforms to it can also conform to the Mobile Application Part operational version 1 specifications, except on the MSC-VLR interface.

A version negotiation mechanism based on the use of an application-context-name is used to negotiate the protocol version used between two entities for supporting a MAP-user signalling procedure.

When starting a signalling procedure, the MAP-user supplies an application-context-name to the MAP-provider. This name refers to the set of application layer communication capabilities required for this dialogue. This refers to the required TC facilities (e.g. version 1 or 2) and the list of operation packages (i.e. set of operations) from which operations can be invoked during the dialogue.

A version one application-context-name may only be transferred to the peer user in a MAP-U-ABORT to an entity of version two or higher (i.e. to trigger a dialogue which involves only communication capabilities defined for MAP operational version 1).

If the proposed application-context-name can be supported by the responding entity the dialogue continues on this basis otherwise the dialogue is refused and the initiating user needs to start a new dialogue, which involves another application-context-name which requires less communication capabilities but provides similar functionality (if possible).

When a signalling procedure can be supported by several application contexts that differ by their version number, the MAP-User needs to select a name. It can either select the name that corresponds to the highest version it supports or follow a more specific strategy so that the number of protocol fallbacks due to version compatibility problems is minimised.

5.2.2 Strategy for selecting the Application Context (AC) version

A method should be used to minimise the number of protocol fall-backs which would occur sometimes if the highest supported AC-Name were always the one selected by GSM entities when initiating a dialogue. The following method is an example that can be used mainly at transitory phase stage when the network is one of mixed phase entities.

5.2.2.1 Proposed method

A table (table 1) may be set up by administrative action to define the highest application context (AC) version supported by each destination; a destination may be another node within the same or a different PLMN, or another PLMN considered as a single entity. The destination may be defined by an E.164 number or an E.214 number derived from an IMSI or in North America (World Zone 1) by an E.164 number or an IMSI (E.212 number). The table also includes the date when each destination is expected to be able to handle at least one AC of the latest version of the MAP protocol. When this date is reached, the application context supported by the node is marked as "unknown", which will trigger the use of table 2.

A second table (table 2) contains an entry for each destination that has an entry in table 1. For a given entity, the entry in table 2 may be a single application context version or a vector of different versions applying to different application contexts for that entity. Table 2 is managed as described in clause 5.2.2.2.

The data for each destination will go through the following states:

a) the version shown in table 1 is "version n-1", where 'n' is the highest version existing in this specification; table 2 is not used;

b) the version shown in table 1 is "unknown"; table 2 is used, and maintained as described in clause 5.2.2.2;

c) when the PLMN operator declares that an entity (single node or entire PLMN) has been upgraded to support all the MAP version n ACs defined for the relevant interface, the version shown in table 1 is set to "version n" by administrative action; table 2 is no longer used, and the storage space may be recovered.

5.2.2.2 Managing the version look-up table

WHEN it receives a MAP-OPEN ind the MAP-User determines the originating entity number either using the originating address parameter or the originating reference parameter or retrieving it from the subscriber data using the IMSI or the MSISDN.

IF the entity number is known:

THEN

It updates (if required) the associated list of highest supported ACs.

ELSE

It creates an entry for this entity and includes the received AC-name in the list of highest supported ACs.

WHEN starting a procedure, the originating MAP-user looks up its version control table.

IF the destination address is known and not timed-out.

THEN

It retrieves the appropriate AC-name and uses it

IF the dialogue is accepted by the peer

THEN

It does not modify the version control table

ELSE (this should never occur)

It starts a new dialogue with the common highest version supported (based on information implicitly or explicitly provided by the peer).

It replaces the old AC-name by the new one in the list of associated highest AC supported.

ELSE

It uses the AC-name that corresponds to the highest version it supports.

IF the dialogue is accepted by the peer.

THEN

It adds the destination node in its version control table and includes the AC-Name in the list of associated highest AC supported.

ELSE

It starts a new dialogue with the common highest version supported (based on information implicitly or explicitly provided by the peer).

IF the destination node was not known

THEN

It adds the destination node in its version control table and includes the new AC-Name in the list of associated highest AC supported.

ELSE

It replaces the old AC-name by the new one in the list of highest supported AC and reset the timer.

5.2.2.3 Optimising the method

A table look-up may be avoided in some cases if both the HLR and the VLR or both the HLR and the SGSN store for each subscriber the version of the AC-name used at location updating. Then:

- for procedures which make use of the same application-context, the same AC-name (thus the same version) can be selected (without any table look-up) when the procedure is triggered;
- for procedures which make use of a different application-context but which includes one of the packages used by the location updating AC, the same version can be selected (without any table look-up) when the procedure is triggered;

for HLR:

- Subscriber data modification (stand alone);

for VLR:

- Data Restoration.

6 Requirements concerning the use of SCCP and TC

6.1 Use of SCCP

The Mobile Application Part (MAP) makes use of the services offered by the Signalling Connection Control Part (SCCP).

MAP supports the following SCCP versions:

- Signalling Connection Control Part, Signalling System no. 7 CCITT ("Blue Book SCCP");
- Signalling Connection Control Part, Signalling System no. 7 ITU-T Recommendation (07/96) Q.711 to Q.716 ("White Book SCCP"). Support of White Book SCCP at the receiving side shall be mandated from 00:01hrs, 1st July 2002(UTC). However, for signalling over the MAP E-interface to support inter-MSC handover/relocation, the support of White Book SCCP shall be mandated with immediate effect.

A White Book SCCP message will fail if any signalling point used in the transfer of the message does not support White Book SCCP. Therefore it is recommended that the originator of the White Book SCCP message supports a drop back mechanism or route capability determination mechanism to interwork with signalling points that are beyond the control of GSM/UMTS network operators.

In North America (World Zone 1) the national version of SCCP is used as specified in ANSI T1.112. Interworking between a PLMN in North America and a PLMN outside North America will involve an STP to translate between ANSI SCCP and ITU-T/CCITT SCCP.

The SCCP is identified as an MTP3-user and the transport of SCCP messages between two entities shall be accomplished according to the 3GPP TS 29.202 [121].

6.1.1 SCCP Class

MAP will only make use of the connectionless classes (0 or 1) of the SCCP.

6.1.2 Sub-System Number (SSN)

The Application Entities (AEs) defined for MAP consist of several Application Service Elements (ASEs) and are addressed by sub-system numbers (SSNs). The SSNs for MAP are specified in 3GPP TS 23.003 [17].

When the SGSN emulates MSC behaviour for processing messages (MAP-MO-FORWARD-SHORT-MESSAGE, MAP_CHECK_IMEI, MAP_SUBSCRIBER_LOCATION_REPORT) towards entities which do not support interworking to SGSNs, it shall use the MSC SSN in the calling party address instead of the SGSN SSN.

When present in the network, the Presence Network Agent emulates the behaviour of the GSM Service Control Function (gsm SCF) for processing of messages (MAP-NOTE-MM-EVENT, MAP-ANY-TIME-INTERROGATION and MAP-ANY-TIME-MODIFICATION).

When a FFN (Follow Me Functional Node, see TS 23.094 [129]) is implemented in a network entity different from HLR, this network entity shall emulate HLR behaviour, i.e. it shall accept MAP-PROCESS-UNSTRUCTURED-SS-REQUEST messages addressed with SSN for HLR.

In an EPS, an Interworking Function (IWF) may be used to convert Diameter S6a messages to MAP Gr messages and vice versa; also an IWF may be used to convert Diameter S13 messages to MAP Gf messages and vice versa. An SSN value for the IWF does not exist. Instead the IWF shall use the SGSN SSN value when serving an MME and use the HLR SSN when serving an HSS. An IWF is said to serve an MME (or HSS) when Diameter messages are exchanged between the IWF and the MME (or HSS).

6.1.3 SCCP addressing

6.1.3.1 Introduction

Within the GSM System there will be a need to communicate between entities within the same PLMN and in different PLMNs. Using the Mobile Application Part (MAP) for this function implies the use of Transaction Capabilities (TC) and the Signalling Connection Control Part (SCCP) of CCITT Signalling System No. 7.

Only the entities that should be addressed are described below. If the CCITT or ITU-T SCCP is used, the format and coding of address parameters carried by the SCCP for that purpose shall comply with CCITT Recommendation Q.713 with the following restrictions:

1) Intra-PLMN addressing

   For communication between entities within the same PLMN, a MAP SSN shall always be included in the called and calling party addresses. All other aspects of SCCP addressing are network specific.

2) Inter-PLMN addressing

   a) Called Party Address

      - SSN indicator = 1 (MAP SSN always included);
      - Global title indicator = 0100 (Global title includes translation type, numbering plan, encoding scheme and nature of address indicator);
      - the translation type field will be coded "00000000" (Not used). For call related messages for non-optimal routed calls (as described in 3GPP TS 23.066 [108]) directed to another PLMN the translation type field may be coded "10000000" (CRMNP);
      - Routing indicator = 0 (Routing on global title);

   b) Calling Party Address

      - SSN indicator = 1 (MAP SSNs always included);
      - Point code indicator = 0;

- Global title indicator = 0100 (Global title includes translation type, numbering plan, encoding scheme and nature of address indicator);
- Numbering Plan = 0001 (ISDN Numbering Plan, E.164; In Case of Inter-PLMN Signalling, the dialogue initiating entity and dialogue responding entity shall always include its own E.164 Global Title as Calling Party Address);
- the translation type field will be coded "00000000" (Not used);
- Routing indicator = 0 (Routing on Global Title).

If ANSI T1.112 SCCP is used, the format and coding of address parameters carried by the SCCP for that purpose shall comply with ANSI specification T1.112 with the following restrictions:

1) Intra-PLMN addressing

   For communication between entities within the same PLMN, a MAP SSN shall always be included in the called and calling party addresses. All other aspects of SCCP addressing are network specific.

2) Inter-PLMN addressing

   a) Called Party Address

   - SSN indicator = 1 (MAP SSN always included);
   - Global title indicator = 0010 (Global title includes translation type);
   - the Translation Type (TT) field will be coded as follows:

     TT = 9, if IMSI is included;

     TT = 14, if MSISDN is included;

     Or TT = 10, if Network Element is included. (If TT=10, then Number Portability GTT is not invoked, if TT=14, then Number Portability GTT may be invoked).

   - Routing indicator = 0 (Routing on global title);

   b) Calling Party Address

   - SSN indicator = 1 (MAP SSNs always included);
   - Point code indicator = 0;
   - Global Title indicator = 0010 (Global title includes translation type);

     TT = 9, if IMSI is included;

     TT = 14, if MSISDN is included;

     Or TT = 10, if Network Element is included. (If TT=10, then Number Portability GTT is not invoked, if TT=14, then Number Portability GTT may be invoked).

   Routing indicator = 0 (Routing on Global Title).

If a Global Title translation is required for obtaining routeing information, one of the numbering plans E.164, E.212 and E.214 is applicable.

- E.212 numbering plan.

  When CCITT or ITU-T SCCP is used, an E.212 number must not be included as Global Title in an SCCP UNITDATA message. The translation of an E.212 number into a Mobile Global Title is applicable in a dialogue initiating VLR, SGSN or GGSN if the routeing information towards the HLR is derived from the subscriber's IMSI. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used as a Global Title to address the HLR. When an MS moves from one VLR service area to another, the new VLR may derive the address of the previous VLR from the Location Area Identification provided by the MS in the location registration request. The PLMN where the previous VLR is located is identified by the E.212

numbering plan elements of the Location Area Identification, i.e. the Mobile Country Code (MCC) and the Mobile Network Code (MNC).

- E.214 and E.164 numbering plans.

  When CCITT or ITU-T SCCP is used, only address information belonging to either E.214 or E.164 numbering plan is allowed to be included as Global Title in the Called and Calling Party Address. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used as a Global Title to address the HLR.

  If the Calling Party Address associated with the dialogue initiating message contains a Global Title, the sending network entity shall include its E.164 entity number.

  When receiving an SCCP UNITDATA message, SCCP shall accept either of the valid numbering plans in the Called Party Address and in the Calling Party Address.

  When CCITT or ITU-T SCCP is used and an N-UNITDATA-REQUEST primitive from TC is received, SCCP shall accept an E.164 number or an E.214 number in the Called Address and in the Calling Address. In World Zone 1 when ANSI SCCP is used, the IMSI (E.212 number) is used instead of E.214 number.

The following clauses describe the method of SCCP addressing appropriate for each entity both for the simple intra-PLMN case and where an inter-PLMN communication is required. The following entities are considered:

- the Mobile-services Switching Centre (MSC);
- the Home location Register (HLR);
- the Visitor Location Register (VLR);
- the Gateway Mobile-services Switching Centre (GMSC);
- the GSM Service Control Function (gsmSCF);
- the Interworking Mobile-services Switching Centre (IWMSC);
- the Serving GPRS Support Node (SGSN);
- the Gateway GPRS Support Node (GGSN);
- the Gateway Mobile Location Centre (GMLC).

6.1.3.2 The Mobile-services Switching Centre (MSC)

There are several cases where it is necessary to address the MSC.

6.1.3.2.1 MSC interaction during handover or relocation

The address is derived from the target Cell id or from the target RNC id.

6.1.3.2.2 MSC for short message routing

When a short message has to be routed to an MS, the GMSC addresses the VMSC by an MSC identity received from the HLR that complies with E.164 rules.

For MS originating short message, the IWMSC address is derived from the Service Centre address.

6.1.3.2.3 MSC for location request routing

When a location request for a particular MS needs to be sent to the MS"s VMSC, the GMLC addresses the VMSC using an E.164 address received from the MS"s HLR.

6.1.3.2.4 MSC for LMU Control

When a control message has to be routed to an LMU from an SMLC, the SMLC addresses the serving MSC for the LMU using an E.164 address.

6.1.3.3 The Home Location Register (HLR)

There are several cases where the HLR has to be addressed.

6.1.3.3.1 During call set-up

When a call is initiated the HLR of the called mobile subscriber will be interrogated to discover the whereabouts of the MS. The addressing required by the SCCP will be derived from the MSISDN dialled by the calling subscriber. The dialled number will be translated into either an SPC, in the case of communications within a PLMN, or a Global Title if other networks are involved (i.e. if the communication is across a PLMN boundary).

If the calling subscriber is a fixed network subscriber, the interrogation can be initiated from the Gateway MSC of the home PLMN in the general case. If the topology of the network allows it, the interrogation could be initiated from any Signalling Point that has MAP capabilities, e.g. local exchange, outgoing International Switching Centre (ISC), etc.

6.1.3.3.2 Before location updating completion

When an MS registers for the first time in a VLR, the VLR has to initiate the update location dialogue with the MS's HLR and a preceding dialogue for authentication information retrieval if the authentication information must be retrieved from the HLR. When initiating either of these dialogues, the only data for addressing the HLR that the VLR has available is contained in the IMSI, and addressing information for SCCP must be derived from it. When continuing the established update location dialogue (as with any other dialogue), the VLR must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received. This means that the VLR must be able to address the HLR based on:

- an E.214 Mobile Global Title originally derived by the VLR from the IMSI (when CCITT or ITU-T SCCP is used), or an E.212 number originally derived from IMSI (when ANSI SCCP is used, an IMSI); or
- an E.164 HLR address; or
- in the case of intra-PLMN signalling, an SPC.

When answering with Global Title to the VLR, the HLR shall insert its E.164 address in the Calling Party Address of the SCCP message containing the first responding CONTINUE message.

If the HLR is in the same PLMN as the VLR, local translation tables may exist to derive an SPC. For authentication information retrieval and location updating via the international PSTN/ISDN signalling network that requires the use of CCITT or ITU-T SCCP, the Global Title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. In World Zone 1 where the ANSI SCCP is used, IMSI (E.212 number) is used as Global Title. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the VLR. The Mobile Global Title thus derived will be used to address the HLR.

If location updating is triggered by an MS that roams from one MSC Area into a different MSC Area served by the same VLR, the VLR shall address the HLR in the same way as if the MS registers for the first time in the VLR.

6.1.3.3.3 After location updating completion

In this case, the subscriber's basic MSISDN has been received from the HLR during the subscriber data retrieval procedure as well as the HLR number constituting a parameter of the MAP message indicating successful completion of the update location dialogue. From either of these E.164 numbers the address information for initiating dialogues with the roaming subscriber's HLR can be derived. Also the subscriber's IMSI may be used for establishing the routeing

information towards the HLR. This may apply in particular if the dialogue with the HLR is triggered by subscriber controlled input.

Thus the SCCP address of the roaming subscriber's HLR may be an SPC, or it may be a Global title consisting of the E.164 MSISDN or the E.164 number allocated to the HLR or either the E.214 Mobile Global Title derived from the IMSI if CCITT or ITU-T SCCP is used, or the IMSI if ANSI SCCP is used (ANSI SCCP is used in World Zone 1).

6.1.3.3.4 VLR restoration

If a roaming number is requested by the HLR for an IMSI that has no data record in the interrogated VLR, the VLR provides the roaming number in the dialogue terminating message. Subsequently the VLR must retrieve the authentication data from the MS's HLR, if required, and must then trigger the restore data procedure. For this purpose, the VLR has to initiate in succession two independent dialogues with the MS's HLR. The MTP and SCCP address information needed for routeing towards the HLR can be derived from the IMSI received as a parameter of the MAP message requesting the roaming number. In this case, the IMSI received from the HLR in the roaming number request shall be processed in the same way as the IMSI that is received from an MS that registers for the first time within a VLR. Alternatively to the IMSI, the Calling Party Address associated with the roaming number request may be used to obtain the routeing information towards the HLR.

6.1.3.3.5 During Network-Requested PDP Context Activation

When receiving a PDP PDU the GGSN may interrogate the HLR of the MS for information retrieval. When initiating such a dialogue, the only data for addressing the HLR that the GGSN has available is contained in the IMSI, and addressing information must be derived from it. The IMSI is obtained from the IP address or the X.25 address in the incoming IP message by means of a translation table. This means that the GGSN shall be able to address the HLR based on an E.214, (if CCITT or ITU-T SCCP is used), or E.212 (if ANSI SCCP is used), Mobile Global Title originally derived by the GGSN from the IMSI in the case of inter-PLMN signalling. In the case of intra-PLMN signalling, an SPC may also be used.

If the HLR is in the same PLMN as the GGSN, local translation tables may exist to derive an SPC. For information retrieval via the international PSTN/ISDN signalling network, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the GGSN. The Mobile Global Title thus derived will be used to address the HLR.

6.1.3.3.6 Before GPRS location updating completion

When an MS registers for the first time in an SGSN, the SGSN has to initiate the update location dialogue with the MS's HLR and a preceding dialogue for authentication information retrieval if the authentication information must be retrieved from the HLR. When initiating either of these dialogues, the only data for addressing the HLR that the SGSN has available is contained in the IMSI, and addressing information for SCCP must be derived from it. When continuing the established update location dialogue (as with any other dialogue), the SGSN must derive the routeing information towards the HLR from the Calling Party Address received with the first responding CONTINUE message until the dialogue terminating message is received. This means that the SGSN must be able to address the HLR based on:

- an E.214 (if CCITT or ITU-T SCCP is used) or E.212 (if ANSI SCCP is used) Mobile Global Title originally derived by the SGSN from the IMSI; or
- an E.164 HLR address; or
- in the case of intra-PLMN signalling, an SPC.

If the HLR is in the same PLMN as the SGSN, local translation tables may exist to derive an SPC. For authentication information retrieval and location updating via the international PSTN/ISDN signalling network, the Global title must be derived from the IMSI, using the principles contained in CCITT Recommendation E.214 and the Numbering Plan Indicator (NPI) value referenced by the SCCP Specifications. A summary of the translation from the IMSI (CCITT Recommendation E.212) to Mobile Global Title (described in CCITT Recommendation E.214) is shown below:

- E.212 Mobile Country Code translates to E.164 Country Code;
- E.212 Mobile Network Code translates to E.164 National Destination Code;
- E.212 Mobile Subscriber Identification Number (MSIN) is carried unchanged if within the E.164 number maximum length (15 digits). If the Mobile Global Title is more than 15 digits the number is truncated to 15 by deleting the least significant digits.

This translation will be done either at the application or at SCCP level in the SGSN. The Mobile Global Title thus derived will be used to address the HLR.

6.1.3.3.7 After GPRS location updating completion

In this case, the subscriber's Basic MSISDN has been received from the HLR during the subscriber data retrieval procedure as well as the HLR number constituting a parameter of the MAP message indicating successful completion of the update location dialogue. From either of these E.164 numbers the address information for initiating dialogues with the roaming subscriber's HLR can be derived. Also the subscriber's IMSI may be used for establishing the routeing information towards the HLR.

Thus the SCCP address of the roaming subscriber's HLR may be an SPC, or it may be a Global title consisting of the E.164 MSISDN or the E.164 number allocated to the HLR or the E.214 Mobile Global Title derived from the IMSI.

6.1.3.3.8 Query for a Location Request

For a location request from an external client, the GMLC needs to address the home HLR of the target MS to obtain the address of the target MS"s serving MSC. The GMLC uses either the international E.164 MSISDN, the international E.214 number (if CCITT or ITU-T SCCP is used) or the international E.212 number (if ANSI SCCP is used) of the MS as means to route a query to the HLR.

6.1.3.4 The Visitor Location Register (VLR)

There are several cases when the VLR needs to be addressed.

6.1.3.4.1 Inter-VLR information retrieval

When an MS moves from one VLR service area to another, the new VLR may request the IMSI and authentication sets from the previous VLR. The new VLR derives the address of the previous VLR from the Location Area Identification provided by the MS in the location registration request.

6.1.3.4.2 HLR request

The HLR will only request information from a VLR if it is aware that one of its subscribers is in the VLR service area. This means that a location updating dialogue initiated by the VLR has been successfully completed, i.e. the HLR has indicated successful completion of the update location procedure to the VLR.

When initiating dialogues towards the VLR after successful completion of location updating, the routeing information used by the HLR is derived from the E.164 VLR number received as a parameter of the MAP message initiating the update location dialogue. If the VLR is in the same PLMN as the HLR, the VLR may be addressed directly by an SPC derived from the E.164 VLR number. For dialogues via the international PSTN/ISDN signalling network, presence of the E.164 VLR number in the Called Party Address is required.

6.1.3.5 The Interworking MSC (IWMSC) for Short Message Service

The IWMSC is the interface between the mobile network and the network to access to the Short Message Service Centre. This exchange has an E.164 address known in the SGSN or in the MSC.

6.1.3.6 The Equipment Identity Register (EIR)

The EIR address is either unique or could be derived from the IMEI. The type of address is not defined.

6.1.3.7 Void

6.1.3.8 The Serving GPRS Support Node (SGSN)

The HLR will initiate dialogues towards the SGSN if it is aware that one of its subscribers is in the SGSN serving area. This means that a GPRS location updating has been successfully completed, i.e., the HLR has indicated successful completion of the GPRS location update to the SGSN. The routeing information used by the HLR is derived form the E.164 SGSN number received as parameter of the MAP message initiating the GPRS update location procedure. If the SGSN is in the same PLMN as the HLR, the SGSN may be addressed directly by an SPC derived from the E.164 SGSN number. For dialogues via the international PSTN/ISDN signalling network, the presence of the E.164 SGSN number in the Called Party Address is required.

When the GMSC initiates dialogues towards the SGSN the SGSN (MAP) SSN (See 3GPP TS 23.003 [17]) shall be included in the called party address. The routeing information used by the GMSC is derived from the E.164 SGSN number received as a parameter of the MAP message initiating the forward short message procedure. If the GMSC does not support the GPRS functionality the MSC (MAP) SSN value shall be included in the called party address.

NOTE: Every VMSC and SGSN shall have uniquely identifiable application using E.164 numbers, for the purpose of SMS over GPRS when the GMSC does not support the GPRS functionality.

6.1.3.9 The Gateway GPRS Support Node (GGSN)

The GGSN provides interworking with external packet-switched networks, network screens and routing of the Network-Requested PDP Context activation. If a Network-Requested PDP Context activation fails, the HLR will alert the GGSN when the subscriber becomes reachable. The HLR will use the E.164 GGSN number received as parameter of the MAP message reporting the failure.

6.1.3.10 The Gateway MSC (GMSC) for Short Message Service

The GMSC provides interworking with the network to access the Short Message Service Centre, the mobile network and routing of Send Routing Info For SM. The GMSC has on E.164 address known in the HLR, SGSN or MSC.

6.1.3.10A Void

6.1.3.10A.1 Void

6.1.3.10A.2 Void

6.1.3.10B The Gateway Mobile Location Centre (GMLC)

The GMLC initiates location requests on behalf of external clients. The E.164 address of the GMLC is provided to an HLR when the GMLC requests a serving MSC address or SGSN address from the HLR for a target MS. The E.164 address of the GMLC is also provided to a serving MSC or SGSN when the GMLC requests the location of a target MS served by this MSC or SGSN.

6.1.3.11 Summary table

The following tables summarise the SCCP address used for invoke operations. As a principle, within a PLMN either an SPC or a GT may be used (network operation option), whereas when addressing an entity outside the PLMN the GT must be used. The address type mentioned in the table (e.g. MSISDN) is used as GT or to derive the SPC.

For a response, the originating address passed in the invoke is used as SCCP Called Party Address. For extra-PLMN addressing the own E.164 entity address is used as SCCP Calling Party Address; for intra-PLMN addressing an SPC derived from the entity number may be used instead. When using an SPC, the SPC may be taken directly from MTP.

Table 6.1/1

to from	fixed net work	HLR	VLR	MSC	EIR	gsmSCF	SGSN	GGSN
fixed network	---	E:GT T:MSISDN	---	---	---	---	---	---
Home Location Register	---	---	I:SPC/GT E:GT T:VLR NUMBER	---	---	I:SPC/GT E:GT T:gsmSCF NUMBER	I:SPC/GT E:GT T:SGSN NUMBER	I:SPC/GT E:GT T:GGSN NUMBER
Visitor Location Register	---	I:SPC/GT E:GT T:MGT (outside World Zone 1)/MSISDN (World Zone 1)/HLR NUMBER (note)	I:SPC/GT E:GT T:VLR NUMBER	---	---	I:SPC/GT E:GT T:gsmSCF NUMBER	---	---
mobile-services switching centre	---	I:SPC/GT E:GT T:MSISDN	I:SPC/GT E:GT T:VLR NUMBER	I:SPC/GT E:GT T:MSC NUMBER	I:SPC/GT E:GT T:EIR NUMBER	I:SPC/GT E:GT T:gsmSCF NUMBER	I:SPC/GT E:GT T:SGSN NUMBER	---
gsm Service Control Function	---	I:SPC/GT E:GT T:MSISDN	---	---	---	---	---	---
Serving GPRS Support Node	---	I:SPC/GT E:GT T:MGT/ MSISDN/HLR NUMBER	---	I:SPC/GT E:GT T:MSC NUMBER	I:SPC/GT E:GT T:EIR NUMBER	I:SPC/GT E:GT T:gsmSCF NUMBER	---	---
Gateway GPRS Support Node	---	I:SPC/GT E:GT T:MGT	---	---	---	---	---	---
Gateway Mobile Location Centre	---	I:SPC/GT E:GT T:MSISDN, MGT (outside World Zone 1) or IMSI (World Zone 1) (note)	---	I:SPC/GT E:GT T:MSC NUMBER	---	---	I:SPC/GT E:GT T:SGSN NUMBER	---

Table 6.1/2

to from		GMLC
fixed network		---
Home Location Register		---
Visitor Location Register		---
Mobile-services Switching Centre		I:SPC/GT E:GT T:MLC Number
gsm Service Control Function		I:SPC/GT E:GT T:MSISDN
Serving GPRS Support Node		I:SPC/GT E:GT T:MLC Number
Gateway		---

GPRS Support Node		
Gateway Mobile Location Centre		

I: Intra-PLMN.
E: Extra (Inter)-PLMN.
T: Address Type.
GT: Global Title.
MGT: E.214 Mobile Global Title.
SPC: Signalling Point Code.

6.2 Use of TC

The Mobile Application part makes use of the services offered by the Transaction Capabilities (TC) of Signalling System No. 7. ETS 300 287, which is based on CCITT White Book Recommendations Q.771 to Q.775, should be consulted for the full specification of TC.

The MAP uses all the services provided by TC except the ones related to the unstructured dialogue facility.

From a modelling perspective, the MAP is viewed as a single Application Service Element. Further structuring of it is for further study.

Transaction Capabilities refers to a protocol structure above the network layer interface (i.e., the SCCP service interface) up to the application layer including common application service elements but not the specific application service elements using them.

TC is structured as a Component sub-layer above a Transaction sub-layer.

The Component sub-layer provides two types of application services: services for the control of end-to-end dialogues and services for Remote Operation handling. These services are accessed using the TC-Dialogue handling primitives and TC-Component handling primitives respectively.

Services for dialogue control include the ability to exchange information related to application-context negotiation as well as initialisation data.

Services for Remote Operation handling provide for the exchange of protocol data units invoking tasks (operations), and reporting their outcomes (results or errors) plus any non-application-specific protocol errors detected by the component sub-layer. The reporting of application-specific protocol errors by the TC user, as distinct from application process errors, is also provided. The Transaction sub-layer provides a simple end-to-end connection association service over which several related protocol data units (i.e. built by the Component Sub-Layer) can be exchanged. A Transaction termination can be prearranged (no indication provided to the TC user) or basic (indication provided).

7 General on MAP services

7.1 Terminology and definitions

The term service is used in clauses 7 to 12 as defined in CCITT Recommendation X.200. The service definition conventions of CCITT Recommendation X.210 are also used.

MAP services that are defined for use between HLR and SGSN are also used in an Evolved Packet System (EPS) between two IWFs and between HSS and IWF, where the IWF is an Interworking Function that converts MAP messages to Diameter messages and vice versa.

MAP services that are defined for use between SGSN and EIR are also used in an Evolved Packet System (EPS) between IWF and EIR.

IWFs may be connected via Diameter to MMEs and HSSs and they may be connected via MAP to HSSs, IWFs, and EIRs.

7.2 Modelling principles

MAP provides its users with a specified set of services and can be viewed by its users as a "black box" or abstract machine representing the MAP service-provider. The service interface can then be depicted as shown in figure 7.2/1.




Figure 7.2/1: Modelling principles

The MAP service-users interact with the MAP service-provider by issuing or receiving MAP service-primitives at the service interface.

A MAP service-user may receive services from several instances of the MAP service-provider at the same time. In such cases the overall procedure is synchronised by the service-user.

The MAP service-primitives are named using the following notation:

MAP-ServicePrimitiveName **type**

where **type** can be any of: request (req), indication (ind), response (rsp) or confirm (cnf). (In the user arrow diagrams type is not indicated in the case of req/ind and indicated as "ack" in the case of rsp/cnf).

The services are further classified as unconfirmed-service, confirmed-service and provider-initiated-service where the first two categories refer to whether or not the service is confirmed by the service-provider. The confirmation may or may not correspond to a response provided by the other service-user.

MAP services are also classified as common MAP services that are available to all MAP service-users, and MAP service-user specific services, which are services available to one or several, but not all, MAP service-users.

A MAP dialogue is defined as an exchange of information between two MAP users in order to perform a common task. A MAP dialogue will consist of one or several MAP services.

7.3 Common MAP services

All MAP service-users require access to services for performing basic application layer functions:

- for establishing and clearing MAP dialogues between peer MAP service-users;
- for accessing functions supported by layers below the applications layer;
- for reporting abnormal situations;
- for handling of different MAP versions;
- for testing whether or not a persistent MAP dialogue is still active at each side.

For these purposes the following common services are defined:

- MAP-OPEN service;
- MAP-CLOSE service;

- MAP-DELIMITER service;
- MAP-U-ABORT service;
- MAP-P-ABORT service;
- MAP-NOTICE service.

In defining the service-primitives the following convention is used for categorising parameters:

M the inclusion of the parameter is mandatory. The M category can be used for any primitive type and specifies that the corresponding parameter must be present in the indicated primitive type;

O the inclusion of the parameter is a service-provider option. The O category can be used in indication and confirm type primitives and is used for parameters that may optionally be included by the service-provider;

U the inclusion of the parameter is a service-user option. The U category can be used in request and response type primitives. The inclusion of the corresponding parameter is the choice of the service-user;

C the inclusion of the parameter is conditional. The C category can be used for the following purposes:

- to indicate that if the parameter is received from another entity it must be included for the service being considered;
- to indicate that the service user must decide whether to include the parameter, based on the context on which the service is used;
- to indicate that one of a number of mutually exclusive parameters must be included (e.g. parameters indicating a positive result versus parameters indicating a negative result);
- to indicate that a service user optional parameter (marked "U") or a conditional parameter (marked "C") presented by the service user in a request or response type primitive is to be presented to the service user in the corresponding indication or confirm type primitive;

(=) when appended to one of the above, this symbol means that the parameter takes the same value as the parameter appearing immediately to its left;

blank the parameter is not present.

A primitive type may also be without parameters, i.e. no parameter is required with the primitive type; in this case the corresponding column of the table is empty.

7.3.1 MAP-OPEN service

This service is used for establishing a MAP dialogue between two MAP service-users. The service is a confirmed service with service primitives as shown in table 7.3/1.

Table 7.3/1: Service-primitives for the MAP-OPEN service

Parameters	Request	Indication	Response	Confirm
Application context name	M	M(=)	U	C(=)
Destination address	M	M(=)		
Destination reference	U	C(=)		
Originating address	U	O		
Originating reference	U	C(=)		
Specific information	U	C(=)	U	C(=)
Responding address			U	C(=)
Result			M	M(=)
Refuse-reason			C	C(=)
Provider error				O

Application context name:

This parameter identifies the type of application context being established. If the dialogue is accepted the received application context name shall be echoed. In case of refusal of dialogue this parameter shall indicate the highest version supported.

Destination address:

A valid SCCP address identifying the destination peer entity (see also clause 6). As an implementation option, this parameter may also, in the indication, be implicitly associated with the service access point at which the primitive is issued.

Destination-reference:

This parameter is a reference that refines the identification of the called process. It may be identical to Destination address but its value is to be carried at MAP level. Table 7.3/2 describes the MAP services using this parameter. Only these services are allowed to use it.

Table 7.3/2: Use of the destination reference

MAP service	Reference type	Use of the parameter
MAP-REGISTER-SS	IMSI	Subscriber identity
MAP-ERASE-SS	IMSI	Subscriber identity
MAP-ACTIVATE-SS	IMSI	Subscriber identity
MAP-DEACTIVATE-SS	IMSI	Subscriber identity
MAP-INTERROGATE-SS	IMSI	Subscriber identity
MAP-REGISTER-PASSWORD	IMSI	Subscriber identity
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	IMSI (note 1)	Subscriber identity
MAP-UNSTRUCTURED-SS-REQUEST	IMSI (note 2)	Subscriber identity
MAP-UNSTRUCTURED-SS-NOTIFY	IMSI (note 2)	Subscriber identity
MAP-FORWARD-SHORT-MESSAGE	IMSI (note 3)	Subscriber identity
MAP-REGISTER-CC-ENTRY	IMSI	Subscriber identity
MAP-ERASE-CC-ENTRY	IMSI	Subscriber identity

NOTE 1: On the HLR - HLR interface and on the HLR - gsmSCF interface the Destination reference shall be either IMSI or MSISDN.

NOTE 2: On the gsmSCF - HLR interface and on the HLR - HLR interface the Destination reference shall be either IMSI or MSISDN.

NOTE 3: Only when the IMSI and the LMSI are received together from the HLR in the mobile terminated short message transfer.

Originating address:

A valid SCCP address identifying the requestor of a MAP dialogue (see also clause 6). As an implementation option, this parameter may also, in the request, be implicitly associated with the service access point at which the primitive is issued.

Originating-reference:

This parameter is a reference that refines the identification of the calling process. It may be identical to the Originating address but its value is to be carried at MAP level. Table 7.3/3 describes the MAP services using the parameter. Only these services are allowed to use it. Processing of the Originating-reference shall be performed according to the supplementary service descriptions and other service descriptions, e.g. operator determined barring. Furthermore the receiving entity may be able to use the value of the Originating-reference to screen the service indication.

Table 7.3/3: Use of the originating reference

MAP service	Reference type	Use of the parameter
MAP-REGISTER-SS	ISDN-Address-String	Originated entity address
MAP-ERASE-SS	ISDN-Address-String	Originated entity address
MAP-ACTIVATE-SS	ISDN-Address-String	Originated entity address
MAP-DEACTIVATE-SS	ISDN-Address-String	Originated entity address
MAP-INTERROGATE-SS	ISDN-Address-String	Originated entity address
MAP-REGISTER-PASSWORD	ISDN-Address-String	Originated entity address
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	ISDN-Address-String	Originated entity address
MAP-UNSTRUCTURED-SS-REQUEST	ISDN-Address-String (note)	Originated entity address
MAP-UNSTRUCTURED-SS-NOTIFY	ISDN-Address-String (note)	Originated entity address
MAP-REGISTER-CC-ENTRY	ISDN-Address-String	Originated entity address
MAP-ERASE-CC-ENTRY	ISDN-Address-String	Originated entity address

NOTE: The Originating reference may be omitted.

Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

Responding address:

An address identifying the responding entity. The responding address is included if required by the context (e.g. if it is different from the destination address).

Result:

This parameter indicates whether the peer accepts the dialogue.

Refuse reason:

This parameter is present only if the Result parameter indicates that the dialogue is refused. It takes one of the following values:

- Application-context-not-supported;
- Invalid-destination-reference;

- Invalid-originating-reference;
- No-reason-given;
- Remote node not reachable;
- Potential version incompatibility.

7.3.2 MAP-CLOSE service

This service is used for releasing a previously established MAP dialogue. The service may be invoked by either MAP service-user depending on rules defined within the service-user. The service is an unconfirmed service with parameters as shown in table 7.3/4.

Table 7.3/4: Service-primitives for the MAP-CLOSE service

Parameters	Request	Indication
Release method	M	
Specific Information	U	C(=)

Release method:

This parameter can take the following two values:

- normal release; in this case the primitive is mapped onto the protocol and sent to the peer;
- prearranged end; in this case the primitive is not mapped onto the protocol. Prearranged end is managed independently by the two users, i.e. only the request type primitive is required in this case.

Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM GSM and shall be performed according to operator specific requirements.

7.3.3 MAP-DELIMITER service

This service is used to explicitly request the transfer of the MAP protocol data units to the peer entities.

See also clause 7.4 and 7.5 for the detailed use of the MAP-DELIMITER service.

The service is an unconfirmed service with service-primitives as shown in table 7.3/5.

Table 7.3/5: Service-primitives for the MAP-DELIMITER service

Parameters	Request	Indication

7.3.4 MAP-U-ABORT service

This service enables the service-user to request the MAP dialogue to be aborted. The service is an unconfirmed service with service-primitives as shown in table 7.3/6.

Table 7.3/6: Service-primitives for the MAP-U-ABORT service

Parameters	Request	Indication
User reason	M	M(=)
Diagnostic information	U	C(=)
Specific information	U	C(=)

User reason:

This parameter can take the following values:

- resource limitation (congestion);

  the requested user resource is unavailable due to congestion;

- resource unavailable;

  the requested user resource is unavailable for reasons other than congestion;

- application procedure cancellation;

  the procedure is cancelled for reasons detailed in the diagnostic information parameter;

- procedure error;

  processing of the procedure is terminated for procedural reasons.

Diagnostic information:

This parameter may be used to give additional information for some of the values of the user-reason parameter:

Table 7.3/7: User reason and diagnostic information

User reason	Diagnostic information
Resource limitation (congestion)	-
Resource unavailable	Short term/long term problem
Application procedure cancellation	Handover cancellation/ Radio Channel release/ Network path release/ Call release/ Associated procedure failure/ Tandem dialogue released/ Remote operations failure
Procedure error	-

Specific information:

This parameter may be used for passing any user specific information. Establishment and processing of the Specific information is not specified by GSM and shall be performed according to operator specific requirements.

7.3.5 MAP-P-ABORT service

This service enables the MAP service-provider to abort a MAP dialogue. The service is a provider-initiated service with service-primitives as shown in table 7.3/8.

Table 7.3/8: Service-primitives for the MAP-P-ABORT service

Parameters		Indication
Provider reason		M
Source		M

Provider reason:

This parameter indicates the reason for aborting the MAP dialogue:

- provider malfunction;
- supporting dialogue/transaction released;
- resource limitation;
- maintenance activity;
- version incompatibility;

- abnormal MAP dialogue.

Source:

This parameter indicates the source of the abort. For Transaction Capabilities (TC) applications the parameter may take the following values:

- MAP problem;
- TC problem;
- network service problem.

Table 7.3/9: Values of provider reason and source parameters and examples of corresponding events

Provider reason	Source	Corresponding event
Provider	MAP	Malfunction at MAP level at peer entity
malfunction	TC	"Unrecognised message type" or "Badly formatted transaction portion" or "Incorrect transaction portion" received in TC-P-ABORT "Abnormal dialogue"
	Network service	Malfunction at network service level at peer entity
Supporting dialogue/ transaction released	TC	"Unrecognised transaction ID" received in TC-ABORT
Resource	MAP	Congestion towards MAP peer service-user
limitation	TC	"Resource limitation" received in TC-P-ABORT
Maintenance	MAP	Maintenance at MAP peer service-user
activity	Network service	Maintenance at network peer service level
Abnormal MAP dialogue	MAP	MAP dialogue is not in accordance with specified application context
Version incompatibility	TC	A Provider Abort indicating "No common dialogue portion" is received in the dialogue initiated state

7.3.6 MAP-NOTICE service

This service is used to notify the MAP service-user about protocol problems related to a MAP dialogue not affecting the state of the protocol machines.

The service is a provider-initiated service with service-primitive as shown in table 7.3/10.

Table 7.3/10: Service-primitive for the MAP-NOTICE service

Parameters	Indication
Problem diagnostic	M

Problem diagnostic:

This parameter can take one of the following values:

- abnormal event detected by the peer;
- response rejected by the peer;
- abnormal event received from the peer;
- message cannot be delivered to the peer.

7.3.7 Void

7.3.8 Void

7.3.9 Void

7.3.10 Void

7.4 Sequencing of services

The sequencing of services is shown in figure 7.4/1 and is as follows:

Opening:

The MAP-OPEN service is invoked before any user specific service-primitive is accepted. The sequence may contain none, one or several user specific service-primitives. If no user specific service-primitive is contained between the MAP-OPEN and the MAP-DELIMITER primitives, then this will correspond to sending an empty Begin message in TC. If more than one user specific service-primitive is included, all are to be sent in the same Begin message. The sequence ends with a MAP-DELIMITER primitive.

Continuing:

This sequence may not be present in some MAP dialogues. If it is present, it ends with a MAP-DELIMITER primitive. If more than one user specific service-primitive is included, all are to be included in the same Continue message.

Closing:


The sequence can only appear after an opening sequence or a continuing sequence. The sequence may contain none, one or several user specific service-primitives if the MAP-CLOSE primitive specifies normal release. If no user specific service-primitive is included, then this will correspond to sending an empty End message in TC. If more than one user specific service-primitive is included, all are to be sent in the same End message. If prearranged end is specified, the sequence cannot contain any user specific service-primitive. The MAP-CLOSE primitive must be sent after all user specific service-primitives have been delivered to the MAP service-provider.

Aborting:


A MAP service-user can issue a MAP-U-ABORT primitive at any time after the MAP dialogue has been opened or as a response to an attempt to open a MAP dialogue.

The MAP service-provider may issue at any time a MAP-P-ABORT primitive towards a MAP service-user for which a MAP dialogue exists.


MAP-U-ABORT primitives and MAP-P-ABORT primitives terminate the MAP dialogue.



a) Opening



b) Continuing



c) Closing



d) Aborting

Figure 7.4/1: Sequencing of services

If the reason "resource unavailable (short term problem)" is indicated in the MAP-U-ABORT indication primitive, the MAP service-user may decide to attempt a new MAP dialogue establishment immediately.

Sequencing of user specific service-primitives is done by the MAP service-user and based on rules applicable for each MAP service-user instance.

A MAP-NOTICE indication primitive may be received at any time during the active period of a MAP dialogue.

7.5 General rules for mapping of services onto TC

7.5.1 Mapping of common services

Table 7.5/1 gives an overview of the mapping rules for mapping of common services onto TC-services. Table 7.5/2 gives the mapping rules for mapping of TC-services onto common services.

Protocol machine description is given in clauses 14 to 17.

Table 7.5/1: Mapping of common services onto TC services

MAP service-primitive	TC service-primitive
MAP-OPEN request (+ any user specific service primitives) + MAP-DELIMITER request	TC-BEGIN request (+ component handling primitives)
MAP-OPEN response (+ any user specific service primitives) + MAP-DELIMITER request	TC-CONTINUE request (note) (+ component handling primitives)
(any user specific service primitives) + MAP-DELIMITER request	TC-CONTINUE request (+ component handling primitives)
(any user specific service primitives) + MAP-CLOSE request	TC-END request (+ component handling primitives)

MAP-U-ABORT request	TC-U-ABORT request
NOTE: Or TC-END if the MAP-CLOSE request has been received before the MAP-DELIMITER request.	

Table 7.5/2: Mapping of TC services onto common service

TC service-primitive	MAP service-primitive
TC-BEGIN indication (+ component handling primitives)	MAP-OPEN indication (+ user specific service primitives) + MAP-DELIMITER indication (note 1)
TC-CONTINUE indication (+ component handling primitives)	First time: MAP-OPEN confirm (+ user specific service primitives) + MAP-DELIMITER indication (note 1) Subsequent times: (user specific service primitives) + MAP-DELIMITER indication (note 1)
TC-END indication (+ component handling primitives)	MAP-OPEN confirm (note 6) (user specific service primitives) + MAP-CLOSE indication
TC-U-ABORT indication	MAP-U-ABORT indication or MAP-P-ABORT indication (note 2) MAP-OPEN confirmation (note 3)
TC-P-ABORT indication	MAP-P-ABORT indication (note 4) MAP-OPEN confirmation (note 5)
NOTE 1: It may not be necessary to present this primitive to the user for MAP version 2 applications. NOTE 2: The mapping depends on whether the TC-U-ABORT indication primitive contains a MAP-abort-PDU from the remote MAP service-provider or a MAP-user-abort-PDU from the remote MAP service-user. NOTE 3: Only if the opening sequence is pending and if the "Abort Reason" in the TC-U-ABORT indication is set to "Application Context Not Supported". NOTE 4: If the "Abort Reason" in the TC-P-ABORT indication is set to a value different from "Incorrect Transaction Portion". NOTE 5: Only if the opening sequence is pending and if the "Abort Reason" in the TC-P-ABORT indication is set to "Incorrect Transaction Portion". NOTE 6: Only if opening sequence is pending.	

7.5.2 Mapping of user specific services

Table 7.5/3 gives the general mapping rules which apply to mapping of MAP user specific services onto TC services and table 7.5/4 gives the similar rules for mapping of TC services onto MAP user specific services. Detailed mapping is given in clauses 14 to 17.

Table 7.5/3: Mapping of MAP user specific services onto TC services

MAP service-primitive	TC-service-primitive
MAP-xx request	TC-INVOKE request
MAP-xx response (note 1)	TC-RESULT-L request TC-U-ERROR request TC-U-REJECT request TC-INVOKE request (note 2)

Table 7.5/4: Mapping of TC services onto MAP user specific services

TC-service-primitive	MAP service-primitive
TC-INVOKE indication	MAP-xx indication
TC-RESULT-L indication (note 4) TC-U-ERROR indication TC-INVOKE indication (note 2)	MAP-xx confirm

TC-L-CANCEL indication	
TC-U-REJECT indication TC-L-REJECT indication TC-R-REJECT indication	MAP-xx confirm or MAP-NOTICE indication (note 3)

Notes to tables 7.5/3 and 7.5/4:

NOTE 1: The mapping is determined by parameters contained in the MAP-xx response primitive.

NOTE 2: This applies only to TC class 4 operations where the operation is used to pass a result of another class 2 or class 4 operation.

NOTE 3: The detailed mapping rules are given in clause 16.

NOTE 4: If RESULT-NL components are present they are mapped onto the same MAP-xx confirm.

7.6 Definition of parameters

7.6.1 Common parameters

The following set of parameters is used in several MAP service-primitives.

7.6.1.1 Invoke Id

This parameter identifies corresponding service primitives. The parameter is supplied by the MAP service-user and must be unique over each service-user/service-provider interface.

7.6.1.2 Linked Id

This parameter is used for linked services and it takes the value of the invoke Id of the service linked to.

7.6.1.3 Provider error

This parameter is used to indicate a protocol related type of error:

- duplicated invoke Id;
- not supported service;
- mistyped parameter;
- resource limitation;
- initiating release, i.e. the peer has already initiated release of the dialogue and the service has to be released;
- unexpected response from the peer;
- service completion failure;
- no response from the peer;
- invalid response received.

7.6.1.4 User error

This parameter can take values as follows:

NOTE: The values are grouped in order to improve readability; the grouping has no other significance.

a) Generic error:

- system failure, i.e. a task cannot be performed because of a problem in the entity reporting the error or in another entity. The type of entity or network resource may be indicated by use of the network resource parameter or additional network resource parameter. If and only if the problem is in the entity reporting the error, a cause of failure (FailureCauseParam) shall be included;
- data missing, i.e. an optional parameter required by the context is missing;
- unexpected data value, i.e. the data type is formally correct but its value or presence is unexpected in the current context;
- resource limitation;
- initiating release, i.e. the receiving entity has started the release procedure;
- facility not supported, i.e. the requested facility is not supported by the PLMN with detailed reasons as follows:
    - Shape of location estimate not supported;
    - Needed LCS capability not supported in serving node;
- incompatible terminal, i.e. the requested facility is not supported by the terminal.

b) Identification or numbering problem:

- unknown subscriber, i.e. no such subscription exists;
- number changed, i.e. the subscription does not exist for that number any more;
- unknown MSC;
- unidentified subscriber, i.e. if the subscriber is not contained in the database and it has not or cannot be established whether or not a subscription exists;
- unallocated roaming number;
- unknown equipment;
- unknown location area.

c) Subscription problem:

- roaming not allowed, i.e. a location updating attempt is made in an area not covered by the subscription;
- illegal subscriber, i.e. illegality of the access has been established by use of authentication procedure;
- bearer service not provisioned;
- teleservice not provisioned;
- illegal equipment, i.e. the IMEI check procedure has shown that the IMEI is blacklisted or not whitelisted.

d) Handover problem:

- no handover number available, i.e. the VLR cannot allocate a number for handover or cannot allocate the required amount of numbers for relocation;
- subsequent handover failure, i.e. handover to a third MSC failed for some reason;
- target cell outside group call area.

e) Operation and maintenance problem:

- tracing buffer full, i.e. tracing cannot be performed because the tracing capacity is exceeded.

f) Call set-up problem:

- no roaming number available, i.e. a roaming number cannot be allocated because all available numbers are in use;
- absent subscriber, i.e. the subscriber has activated the detach service or the system detects the absence condition. This error may be qualified to indicate whether the subscriber was IMSI detached, in a restricted area or did not respond to paging;
- busy subscriber. This error may be qualified to indicate that the subscriber was busy due to CCBS and that CCBS is possible;
- no subscriber reply;
- forwarding violation, i.e. the call has already been forwarded the maximum number of times that is allowed;
- CUG reject, i.e. the call does not pass a CUG check; additional information may also be given in order to indicate rejection due to e.g. incoming call barred or non-CUG membership;
- call barred. Optionally, additional information may be included for indicating either that the call meets a barring condition set by the subscriber or that the call is barred for operator reasons. In the case of barring of Mobile Terminating Short Message, the additional information may indicate a barring condition due to "Unauthorised Message Originator";
- optimal routeing not allowed, i.e. the entity which sends the error does not support optimal routeing, or the HLR will not accept an optimal routeing interrogation from the GMSC, or the call cannot be optimally routed because it would contravene optimal routeing constraints;
- forwarding failed, i.e. the GMSC interrogated the HLR for forwarding information but the HLR returned an error.

g) Supplementary services problem:

- call barred;
- illegal SS operation;
- SS error status;
- SS not available;
- SS subscription violation;
- SS incompatibility;
- negative password check;
- password registration failure;
- Number of Password Attempts;
- USSD Busy;
- Unknown Alphabet;
- short term denial;
- long term denial.

For definition of these errors see 3GPP TS 24.080 [38].

h) Short message problem:

- SM delivery failure with detailed reason as follows:
  - memory capacity exceeded;
  - MS protocol error;
  - MS not equipped;

- unknown service centre (SC);
- SC congestion;
- invalid SME address;
- subscriber is not an SC subscriber;
- and possibly detailed diagnostic information, coded as specified in 3GPP TS 23.040, under SMS-SUBMIT-REPORT and SMS-DELIVERY-REPORT. If the SM entity that returns the SM Delivery Failure error includes detailed diagnostic information, it shall be forwarded in the MAP_MO_FORWARD_SHORT_MESSAGE and in the MAP_MT_FORWARD_SHORT_MESSAGE response.

- message waiting list full, i.e. no further SC address can be added to the message waiting list.
- Subscriber busy for MT SMS, i.e. the mobile terminated short message transfer cannot be completed because:
  - another mobile terminated short message transfer is going on and the delivery node does not support message buffering; or
  - another mobile terminated short message transfer is going on and it is not possible to buffer the message for later delivery; or
  - the message was buffered but it is not possible to deliver the message before the expiry of the buffering time defined in 3GPP TS 23.040;
- Absent Subscriber SM, i.e. the mobile terminated short message transfer cannot be completed because the network cannot contact the subscriber. Diagnostic information regarding the reason for the subscriber's absence may be included with this error.

i) Location services problem:

- Unauthorised Requesting Network
- Unauthorised LCS Client with detailed reasons as follows:
  - NoAdditional Information
  - Client not in MS Privacy Exception List
  - Call to Client not setup
  - Disallowed by Local Regulatory Requirements
  - Unauthorised Privacy Class
  - Unauthorised Call/Session Unrelated External Client
  - Unauthorised Call/Session Related External Client
  - Privacy override not applicable
- Position method failure with detailed reasons as follows:
  - Congestion
  - Insufficient resources
  - Insufficient Measurement Data
  - Inconsistent Measurement Data
  - Location procedure not completed
  - QoS not attainable

- Position Method Not Available in Network
- Position Method Not Available in Location Area
- Unknown or unreachable LCS Client.

7.6.1.5 All Information Sent

This parameter indicates to the receiving entity when the sending entity has sent all necessary information.

7.6.2 Numbering and identification parameters

7.6.2.1 IMSI

This parameter is the International Mobile Subscriber Identity defined in 3GPP TS 23.003 [17].

7.6.2.2 TMSI

This parameter is the Temporary Mobile Subscriber Identity defined in 3GPP TS 23.003 [17].

7.6.2.3 IMEI

This parameter is the International Mobile Equipment Identity defined in 3GPP TS 23.003 [17].

7.6.2.3a IMEISV

This parameter is the International Mobile Equipment Identity and Software Version Number defined in 3GPP TS 23.003 [17].

7.6.2.4 Previous location area Id

This parameter refers to the identity of the location area from which the subscriber has roamed.

7.6.2.5 Stored location area Id

This parameter refers to the location area where the subscriber is assumed to be located.

7.6.2.6 Current location area Id

This parameter is used to indicate the location area in which the subscriber is currently located.

7.6.2.7 Target location area Id

This parameter refers to the location area into which the subscriber intends to roam.

7.6.2.8 Target cell Id

This parameter refers to the identity of the cell to which a call has to be handed over.

7.6.2.8A Target RNC Id

This parameter refers to the identity of the RNC to which a call has to be relocated.

7.6.2.9 Void

7.6.2.10 Originating entity number

This parameter refers to an application layer identification of a system component in terms of its associated ISDN number.

7.6.2.11 MSC number

This parameter refers to the ISDN number of an MSC.

7.6.2.12 Target MSC number

This parameter refers to the ISDN number of an MSC to which a call has to be handed over.

7.6.2.13 HLR number

This parameter refers to the ISDN number of an HLR.

7.6.2.14 VLR number

This parameter refers to the ISDN number of a VLR.

7.6.2.15 HLR Id

This parameter refers to the identity of an HLR derived from the IMSI defined in CCITT Recommendation E.212.

7.6.2.16 LMSI

This parameter refers to a local identity allocated by the VLR to a given subscriber for internal management of data in the VLR. LMSI shall not be sent to the SGSN.

7.6.2.17 MS ISDN

This parameter refers to one of the ISDN numbers assigned to a mobile subscriber in accordance with CCITT Recommendation E.213.

7.6.2.18 OMC Id

This parameter refers to the identity of an Operation and Maintenance Centre.

7.6.2.19 Roaming number

This parameter refers to the roaming number as defined in CCITT Recommendation E.213.

7.6.2.19A Relocation Number List

This parameter refers to the number(s) used for routing one call or several calls between MSCs during relocation.

7.6.2.20 Void

7.6.2.21 Handover number

This parameter refers to the number used for routing a call between MSCs during handover.

7.6.2.22 Forwarded-to number

This parameter refers to the address to which a call is to be forwarded. A subaddress may be appended. For subscribers having an originating CAMEL Phase 2 or higher subscription, this address need not be in E.164 international format.

7.6.2.22A Long forwarded-to number

This parameter refers to the address to which a call is to be forwarded. A subaddress may be appended. For subscribers having an originating CAMEL Phase 2 or higher subscription this address need not be in international format.

7.6.2.22B Long FTN Supported

This parameter indicates that the sending entity supports Long Forwarded-to Numbers.

7.6.2.23 Forwarded-to subaddress

This parameter refers to the sub-address attached to the address to which a call is to be forwarded.

7.6.2.24 Called number

This parameter refers to a called party number as defined in CCITT Recommendation Q.767.

7.6.2.25 Calling number

This parameter refers to a calling party number as defined in CCITT Recommendation Q.767.

7.6.2.26 Originally dialled number

This parameter refers to the number dialled by the calling party in order to reach a mobile subscriber.

7.6.2.27 Service centre address

This parameter represents the address of a Short Message Service Centre.

7.6.2.28 Zone Code

This parameter is used to define location areas into which the subscriber is allowed or not allowed to roam (regional subscription). With a complete list of Zone Codes the VLR or the SGSN or MME is able to determine for all its location areas, routing areas or tracking areas whether roaming is allowed or not.

7.6.2.29 MSIsdn-Alert

This parameter refers to the MSISDN stored in a Message Waiting Data File in the HLR. It is used to alert the Service Centre when the MS is again attainable.

7.6.2.30 Location Information

This parameter indicates the location of the served subscriber as defined in 3GPP TS 23.018 [97].

7.6.2.30a Location Information for GPRS

This parameter indicates the location of the served subscriber as defined in 3GPP TS 23.078 [98].

7.6.2.31 GMSC Address

This parameter refers to the E.164 address of a GMSC.

7.6.2.32 VMSC Address

This parameter refers to the E.164 address of a VMSC.

7.6.2.33 Group Id

This parameter is used to describe groups a subscriber can be a member of. A subscriber can partake in all group calls (VBS/VGCS) where he subscribed to the respective groups.

7.6.2.34 North American Equal Access preferred Carrier Id

This parameter refers to the carrier identity preferred by the subscriber for calls requiring routing via an inter-exchange carrier. This identity is used at:

- outgoing calls: when the subscriber does not specify at call set-up a carrier identity;
- forwarded calls: when a call is forwarded by the subscriber;
- incoming calls: applicable to the roaming leg of the call.

7.6.2.35 Void

7.6.2.36 Void

7.6.2.37 Serving cell Id

This parameter indicates the cell currently being used by the served subscriber.

7.6.2.38 SGSN number

This parameter refers to the ISDN number of a SGSN.

7.6.2.39 SGSN address

This parameter refers to the IP-address of a SGSN. This parameter is defined in 3GPP TS 23.003 [17].

7.6.2.40 GGSN address

This parameter refers to the IP-address of a GGSN. This parameter is defined in 3GPP TS 23.003 [17].

7.6.2.41 GGSN number

This parameter refers to the ISDN number of a GGSN or the ISDN number of the protocol-converter if a protocol-converting GSN is used between the GGSN and the HLR.

7.6.2.42 APN

This parameter refers to the DNS name of a GGSN. This parameter is defined in 3GPP TS 23.060 [104].

7.6.2.43 Network Node number

This parameter refers either to the ISDN number of SGSN or to the ISDN number of MSC.

7.6.2.44 PDP-Type

This parameter indicates which type of protocol is used by the MS as defined in 3GPP TS 23.060 [104].

7.6.2.45 PDP-Address

This parameter indicates the address of the data protocol as defined in 3GPP TS 23.060 [104].

7.6.2.46 Additional number

This parameter can refer either to the SGSN number or to the MSC number.

7.6.2.47 P-TMSI

This parameter is the Packet Temporary Mobile Subscriber Identity defined in 3GPP TS 23.003 [17].

7.6.2.48 B-subscriber number

This parameter refers to the number of the destination B dialled by the A user. This may include a subaddress.

7.6.2.49 B-subscriber subaddress

This parameter refers to the sub-address attached to the destination B dialled by the A user.

7.6.2.50 LMU Number

This parameter refers to a local number assigned to an LMU by an SMLC.

7.6.2.51 MLC Number

This parameter refers to the ISDN (E.164) number of an MLC.

7.6.2.52 Multicall Bearer Information

This parameter refers to the number of simultaneous bearers supported per user by the serving network.

7.6.2.53 Multiple Bearer Requested

This parameter indicates whether multiple bearers are requested for a relocation.

7.6.2.54 Multiple Bearer Not Supported

This parameter indicates whether multiple bearers are supported.

7.6.2.55 PDP-Charging Characteristics

This parameter indicates the charging characteristics associated with a specific PDP context as defined in 3GPP TS 32.215.

7.6.2.56 Selected RAB ID

The selected radio access bearer to be kept at subsequent inter-MSC handover from UMTS to GSM.

7.6.2.57 RAB ID

This parameter indicates the radio access bearer identifier as defined in 3GPP TS 25.413. This parameter is used to relate the radio resources with the radio access bearers.

7.6.2.58 gsmSCF Address

This parameter refers to the ISDN number assigned to the gsmSCF address. In an IP Multimedia Core Network, the gsmSCF-address shall contain the IM-SSF address when the IM-SSF takes the role of the gsmSCF.

7.6.2.59 V-GMLC Address

This parameter refers to the IP address of a V-GMLC.

7.6.2.60 Void

7.6.2.61 H-GMLC Address

This parameter refers to the IP address of a H-GMLC.

7.6.2.62 PPR Address

This parameter refers to the IP address of a Privacy Profile Register.

7.6.2.63 Routeing Number

This parameter refers to a number used for routeing purpose and identifying a network operator. See 3GPP TS 23.066 [108].

7.6.2.64 Additional V-GMLC Address

This parameter refers to the IP address of a V-GMLC.

7.6.3 Subscriber management parameters

7.6.3.1 Category

This parameter refers to the calling party category as defined in CCITT Recommendation Q.767.

7.6.3.2 Equipment status

This parameter refers to the status of the mobile equipment as defined in 3GPP TS 22.016 [7].

7.6.3.2a BMUEF

This parameter refers to the Bit Map of UE Faults and corresponds to the UESBI-Iu parameter defined in 3GPP TS 25.413 [120].

7.6.3.3 Extensible Bearer service

This parameter may refer to a single bearer service, a set of bearer services or to all bearer services as defined in 3GPP TS 22.002 [3]. This parameter is used only for subscriber profile management. Extensible Bearer service values include all values defined for a Bearer service parameter (7.6.4.38).

7.6.3.4 Extensible Teleservice

This parameter may refer to a single teleservice, a set of teleservices or to all teleservices as defined in 3GPP TS 22.003 [4]. This parameter is used only for subscriber profile management. Extensible Teleservice values include all values defined for a Teleservice parameter (7.6.4.39).

7.6.3.5 Extensible Basic Service Group

This parameter refers to the Basic Service Group either as an extensible bearer service (see clause 7.6.3.3) or an extensible teleservice (see clause 7.6.3.4). This parameter is used only for subscriber profile management. The null value (i.e. neither extensible bearer service nor extensible teleservice) is used to denote the group containing all extensible bearer services and all extensible teleservices.

7.6.3.6 GSM bearer capability

This parameter refers to the GSM bearer capability information element defined in 3GPP TS 24.008 [35].

7.6.3.7 Subscriber Status

This parameter refers to the barring status of the subscriber:

- service granted;
- Operator Determined Barring.

7.6.3.8 CUG Outgoing Access indicator

This parameter represents the Outgoing Access as defined in ETS 300 136.

7.6.3.9 Operator Determined Barring General Data

This parameter refers to the set of subscriber features that the network operator or the service provider can regulate. This set only includes those limitations that can be

a) controlled in the VLR,
b) controlled in the SGSN or MME,
c) controlled in the SGSN applied for short message transfer only,
d) interrogated or modified by the gsmSCF:

ODB category	Controlled in the VLR	Controlled in the SGSN or MME	Controlled in the SGSN applied for short message transfer only	Interrogatable and modifyable by the gsmSCF
All outgoing calls barred	X		X	X
International outgoing calls barred	X		X	X
International outgoing calls except those to the home PLMN country barred	X		X	X
Interzonal outgoing calls barred	X		X	X
Interzonal outgoing calls except those to the home PLMN country barred	X		X	X
Interzonal outgoing calls AND international outgoing calls except those directed to the home PLMN country barred	X		X	X
Premium rate (information) outgoing calls barred	X			X

Premium rate (entertainment) outgoing calls barred	X			X
Supplementary service access barred	X			X
Invocation of call transfer barred	X			X
Invocation of chargeable call transfer barred	X			X
Invocation of internationally chargeable call transfer barred	X			X
Invocation of interzonally chargeable call transfer barred	X			X
Invocation of call transfer where both legs are chargeable barred	X			X
Invocation of call transfer if there is already an ongoing transferred call for the served subscriber in the serving MSC/VLR barred	X			X
All packet Oriented Services barred		X		X
Roamer Access to HPLMN-AP barred		X		X
Roamer Access to VPLMN-AP barred		X		X
Outgoing calls when roaming outside the home PLMN country				X
All incoming calls				X
Incoming calls when roaming outside the home PLMN country				X
Incoming calls when roaming outside the zone of the home PLMN country				X
Roaming outside the home PLMN				X
Roaming outside the home PLMN country				X

Registration of any call forwarded-to number				X
Registration of any international call forwarded-to number				X
Registration of any international call forwarded-to number except to a number within the HPLMN country				X
Registration of any inter-zone call forwarded-to number				X
Registration of any inter-zone call forwarded-to number except to a number within the HPLMN country				X

7.6.3.10 ODB HPLMN Specific Data

This parameter refers to the set of subscriber features that the network operator or the service provider can regulate only when the subscriber is registered in the HPLMN. This set only includes those limitations that can be controlled in the VLR or in the SGSN or MME:

- Operator Determined Barring Type 1;
- Operator Determined Barring Type 2;
- Operator Determined Barring Type 3;
- Operator Determined Barring Type 4.

7.6.3.11 Regional Subscription Data

This parameter defines the regional subscription area in which the subscriber is allowed to roam. It consists of a list of Zone Codes (see clause 7.6.2.28).

7.6.3.12 Regional Subscription Response

This parameter indicates either that the regional subscription data cannot be handled or that the current MSC or SGSN or MME area is entirely restricted because of regional subscription.

7.6.3.13 Roaming Restriction Due To Unsupported Feature

This parameter defines that a subscriber is not allowed to roam in the current MSC area. It may be used by the HLR if a feature or service is indicated as unsupported by the VLR.

7.6.3.14 Extensible SS-Info

This parameter refers to all the information related to a supplementary service and is a choice between:

- extensible forwarding information (see clause 7.6.3.15);
- extensible call barring information (see clause 7.6.3.20);
- CUG info (see clause 7.6.3.22);
- extensible SS-Data (see clause 7.6.3.29).

7.6.3.15 Extensible forwarding information

This parameter represents the information related to each call forwarding service:

- the SS-Code of the relevant call forwarding service (see clause 7.6.4.1);
- if required, a list of extensible forwarding feature parameters (see clause 7.6.3.16).

  The list may contain one item per Basic Service Group.

7.6.3.16 Extensible forwarding feature

This parameter applies to each combination of call forwarding service and Basic Service Group and contains the following information, as required:

- extensible Basic Service Group (see clause 7.6.3.5);
- extensible SS-Status (see clause 7.6.3.17);
- forwarded-to number (see clause 7.6.2.22);
- forwarded-to subaddress (see clause 7.6.2.23);
- extensible forwarding options (see clause 7.6.3.18);
- extensible no reply condition timer (see clause 7.6.4.19);
- long forwarded-to number (see clause 7.6.2.22A).

If a number is required to define the forwarded-to destination then:

- If the VLR supports Long Forwarded-to Numbers then the long forwarded-to number shall be present and the forwarded-to number shall be absent;
- If the VLR does not support Long Forwarded-to Numbers then the forwarded-to number shall be present and the long forwarded-to number shall be absent.

7.6.3.17 Extensible SS-Status

This parameter refers to the state information of individual supplementary services as defined in 3GPP TS 23.011 [22].

7.6.3.18 Extensible Forwarding Options

This parameter refers to a set of forwarding options attached to a supplementary service. It contains the following information:

- notification to forwarding party (see 3GPP TS 22.082 [10] for the meaning of this parameter);
- redirection notification to the forwarded-to party (see 3GPP TS 22.082 [10] for the meaning of this parameter);
- notification to calling party (see 3GPP TS 22.082 [10] for the meaning of this parameter);
- redirecting presentation (see 3GPP TS 22.082 [10] for the meaning of this parameter);

- forwarding reason (see 3GPP TS 22.082 [10] for the meaning of this parameter).

7.6.3.19 Extensible No reply condition timer

This parameter refers to the extensible no reply condition timer for call forwarding on no reply.

7.6.3.20 Extensible Call barring information

This parameter contains for each call barring service:

- SS-Code (see clause 7.6.4.1);
- a list of extensible call barring feature parameters (see clause 7.6.3.21).

  The list may contain one item per Basic Service Group.

7.6.3.21 Extensible Call barring feature

This parameter gives the status of call barring services as applicable to each Basic Service Group. The parameter contains the following information:

- Extensible Basic Service Group (see clause 7.6.3.5);
- provisioned SS-Status (see clause 7.6.3.17).

7.6.3.22 CUG info

This parameter refers to the overall information required for operation for each CUG:

- CUG subscriptionList;
- CUG featureList.

7.6.3.23 CUG subscription

This parameter refers to the set of basic information for each CUG defined in that subscription. The following information is stored:

- CUG index;
- CUG interlock;
- Intra CUG restrictions;
- Basic Service Group List.

7.6.3.24 CUG interlock

This parameter represents the CUG interlock code defined in ETS 300 138.

7.6.3.25 CUG index

This parameter represents the CUG index defined in ETS 300 138.

7.6.3.26 CUG feature

This parameter contains two parameters that are associated with the Basic Service Group. If the Basic Service Group Code is not present the feature applies to all Basic Services. The following parameters are included:

- Preferential CUG indicator:

  - indicates which CUG index is to be used at outgoing call set-up using the associated Basic Service Group;

- Inter CUG Option:

  - describes whether it for the associated Basic Service Group is allowed to make calls outside the CUG and whether incoming calls are allowed;

- Basic Service Group.

See 3GPP TS 22.085 [13] for meaning of this parameter.

7.6.3.27 Inter CUG options

This parameter indicates the subscribers' ability to make and receive calls outside a specific closed user group. It takes any of the following values:

- CUG only facility (only calls within CUG are allowed);
- CUG with outgoing access (calls outside CUG allowed);
- CUG with incoming access (calls from outside CUG into CUG allowed);
- CUG with both incoming and outgoing access (all calls allowed).

7.6.3.28 Intra CUG restrictions

This parameter describes whether or not the subscriber is allowed to originate calls to or to receive calls from within the CUG. It can take any of the following values:

- no CUG restrictions;
- CUG incoming calls barred;
- CUG outgoing calls barred.

7.6.3.29 Extensible SS-Data

This parameter refers to the necessary set of information required in order to characterise one supplementary service:

- SS-Code (see clause 7.6.4.1);
- Extensible SS-Status (if applicable) (see clause 7.6.3.17);
- Extensible Override subscription option (if applicable) (see clause 7.6.3.30);
- Extensible CLI Restriction (if applicable) (see clause 7.6.3.31);
- Extensible Basic Service Group Code (see clause 7.6.3.5).

7.6.3.30 Subscriber State

This parameter indicates the state of the MS as defined in 3GPP TS 23.018 [97].

7.6.3.31 Requested Info

This parameter indicates the subscriber information being requested as defined in 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98].

7.6.3.31A Requested Domain

This parameter indicates the domain (circuit switched, i.e. from the MSC/VLR, or packet switched, i.e. from the SGSN) from which the requested information should be retrieved.

7.6.3.32 Suppression of Announcement

This parameter indicates if the announcement or tones shall be suppressed as defined in 3GPP TS 23.078 [98].

7.6.3.33 Suppress T-CSI

This parameter is used to suppress the invocation of terminating CAMEL services.

7.6.3.34 GMSC CAMEL Subscription Info

This parameter contains CAMEL subscription information, i.e. O-CSI and/or D-CSI and/or T-CSI, which indicates to the GMSC that originating and/or terminating CAMEL services shall be invoked for the incoming call.

7.6.3.35 VLR CAMEL Subscription Info

This parameter identifies the subscriber as having CAMEL services that are invoked in the MSC or VLR.

7.6.3.36 Supported CAMEL Phases in the VLR

This parameter indicates which phases of CAMEL are supported in the VLR.

7.6.3.36A Supported CAMEL Phases in the SGSN

This parameter indicates which phases of CAMEL are supported in the SGSN.

7.6.3.36B Offered CAMEL4 CSIs in the VLR

This parameter indicates which CSIs of CAMEL phase 4 are offered in the VLR as defined in 3GPP TS 23.078.

7.6.3.36C Offered CAMEL4 CSIs in the SGSN

This parameter indicates which CSIs of CAMEL phase 4 are offered in the SGSN as defined in 3GPP TS 23.078.

7.6.3.36D Offered CAMEL4 CSIs

This parameter indicates which CSIs of CAMEL phase 4 are offered as defined in 3GPP TS 23.078.

7.6.3.36E Offered CAMEL4 CSIs in interrogating node

This parameter indicates which CSIs of CAMEL phase 4 are offered in the GMSC or in the gsmSCF as defined in 3GPP TS 23.078.

7.6.3.36F Offered CAMEL4 CSIs in VMSC

This parameter indicates which CSIs of CAMEL phase 4 are offered in the VMSC as defined in 3GPP TS 23.078.

7.6.3.36G Offered CAMEL4 Functionalities

7.6.3.36H Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported as defined in 3GPP TS 23.078.

7.6.3.36I Supported CAMEL Phases in interrogating node

This parameter indicates which phases of CAMEL are supported as defined in 3GPP TS 23.078. The interrogating node may be a GMSC or a gsmSCF.

This parameter indicates which functionalities of CAMEL phase 4 are offered as defined in 3GPP TS 23.078.

7.6.3.37 CUG Subscription Flag

This parameter indicates that a subscriber with a T-CSI also has a CUG subscription. It is defined in 3GPP TS 23.078.

7.6.3.38 CAMEL Subscription Info Withdraw

This parameter indicates that CAMEL Subscription Info shall be deleted from the VLR or SGSN.

7.6.3.39 Voice Group Call Service (VGCS) Data

This parameter refers to one or more groups a subscriber may be a member of for voice group calls.

7.6.3.40 Voice Broadcast Service (VBS) Data

This parameter refers to one or more groups a subscriber may be a member of for the voice broadcast service. Per group it is further indicated whether the subscriber is only allowed to listen to respective group calls or whether he is in addition entitled to initiate respective voice broadcast calls.

7.6.3.41 ISDN bearer capability

This parameter refers to the ISDN bearer capability information element defined in 3GPP TS 29.007 [56].

7.6.3.42 Lower layer Compatibility

This parameter refers to the lower layer compatibility information element defined in 3GPP TS 24.008 [35].

7.6.3.43 High Layer Compatibility

This parameter refers to the high layer compatibility information element defined in 3GPP TS 24.008 [35].

7.6.3.44 Alerting Pattern

This parameter is an indication that can be used by the MS to alert the user in a specific manner in case of mobile terminating traffic (switched call or USSD). That indication can be an alerting level or an alerting category.

7.6.3.45 GPRS Subscription Data Withdraw

This parameter indicates that GPRS Subscription Data shall be deleted from the SGSN.

7.6.3.45A EPS Subscription Data Withdraw

This parameter indicates that EPS Subscription Data shall be deleted from the MME.

7.6.3.46 GPRS Subscription Data

This parameter refers to the list of PDP-Contexts the subscriber has subscribed to.

7.6.3.46A EPS Subscription Data

This parameter refers to the list of APN-Configurations the subscriber has subscribed to.

7.6.3.47 QoS-Subscribed

This parameter indicates the quality of service subscribed for a certain service. It is defined in 3GPP TS 23.060 [104].

7.6.3.48 VPLMN address allowed

This parameter specifies whether the MS is allowed to use a dynamic address allocated in the VPLMN. It is defined in 3GPP TS 23.060 [104].

7.6.3.49 Roaming Restricted In SGSN/MME Due To Unsupported Feature

This parameter defines that a subscriber is not allowed to roam in the current SGSN or MME area. It may be used by the HLR if a feature or service is indicated as unsupported by the SGSN or MME.

7.6.3.50 Network Access Mode

This parameter is defined in 3GPP TS 23.108.

7.6.3.51 Mobile Not Reachable Reason

This parameter stores the reason for the MS being absent when an attempt to deliver a short message to an MS fails at the MSC, SGSN or both. It is defined in 3GPP TS 23.040.

7.6.3.52 Cancellation Type

This parameter indicates the reason of location cancellation. It is defined in 3GPP TS 23.060 [104].

7.6.3.53 All GPRS Data

This parameter indicates to the SGSN that all GPRS Subscription Data shall be deleted for the subscriber.

7.6.3.54 Complete Data List Included

This parameter indicates to the SGSN or MME that the complete GPRS Subscription Data/EPS Subscription Data stored for the Subscriber shall be replaced with the GPRS Subscription Data/EPS Subscription Data received.

7.6.3.55 PDP Context Identifier

This parameter is used to identify a PDP context for the subscriber.

7.6.3.56 LSA Information

This parameter refers to one or more localised service areas a subscriber may be a member of, together with the priority, the preferential access indicator, the active mode support indicator and active mode indication of each localised service area. The access right outside these localised service areas is also indicated.

7.6.3.57 SoLSA support indicator

This parameter indicates that the VLR or the SGSN supports SoLSA subscription.

7.6.3.58 LSA Information Withdraw

This parameter indicates that LSA information shall be deleted from the VLR or the SGSN.

7.6.3.59 LMU Indicator

This parameter indicates the presence of an LMU.

7.6.3.60 LCS Information

This parameter defines the LCS related information for an MS subscriber and contains the following components:

- GMLC List (see clause 7.6.3.61).
- LCS Privacy Exception List (see clause 7.6.3.62).
- MO-LR List (see clause 7.6.3.65A).
- Additional LCS Privacy Exception List (see clause 7.6.3.62A).

7.6.3.61 GMLC List

This parameter contains the addresses of all GMLCs that are permitted to issue a call/session unrelated or call/session related MT-LR location request for this MS. Usage of this parameter is defined in 3GPP TS 23.271.

7.6.3.62 LCS Privacy Exception List

This parameter defines the classes of LCS Client that are allowed to locate any target MS. For each class, the following information is provided:

- SS-Code (see clause 7.6.4.1);
- a list of LCS privacy exception parameters (see clause 7.6.3.63).

7.6.3.62A Additional LCS Privacy Exception List

This parameter defines the classes of LCS Client that are allowed to locate any target MS. For each class, the following information is provided:

- SS-Code (see clause 7.6.4.1);
- a list of LCS privacy exception parameters (see clause 7.6.3.63).

The Additional LCS Privacy Exception List shall be present only if the LCS Privacy Exception List is present and contains LCS privacy exception parameters for 4 privacy exception classes.

7.6.3.63 LCS Privacy Exception Parameters

This parameter gives the status of each LCS privacy exception class and any additional parameters relevant to this class. The parameter contains the following information:

- provisioned SS-Status (see clause 7.6.3.17);
- privacy notification to MS user (see clause 7.6.3.65B);
- external client List (see clause 7.6.3.64);
- internal client List (see clause 7.6.3.65).
- service type List (see clause 7.6.3.65D);

7.6.3.64 External Client List

This parameter is only applicable to the call/session unrelated privacy class and call/session related privacy class, and gives the identities of the external clients that are allowed to locate a target MS for a MT-LR. Each identity is an international (e.g.E.164) address. For each identified external client, GMLC restrictions may be defined. It may also be indicated if the MS shall be notified of a non-restricted MT-LR from each identified LCS client and, if so, whether

notification only or notification with privacy verification shall apply. Usage of this parameter is defined in 3GPP TS 23.271.

7.6.3.65 Internal Client List

This parameter is only applicable to the PLMN operator privacy class and gives the identities of the internal PLMN operator clients that are allowed to locate a target MS for an NI-LR or MT-LR. Usage of this parameter is defined in 3GPP TS 23.271.

7.6.3.65A MO-LR List

This parameter defines the classes of MO-LR for which a subscription exists for a particular MS. For each class, the following information is provided:

- SS-Code (see clause 7.6.4.1).

7.6.3.65B Privacy Notification to MS User

This parameter is applicable to the call/session unrelated privacy class and call/session related privacy class. For non-call/call related privacy class it indicates whether the MS user shall be notified for that class MT-LR from any value added LCS client when the MT-LR is restricted and be enabled to accept or override the restriction. Usage of this parameter is defined in 3GPP TS 23.271.

7.6.3.65C GMLC List Withdraw

This parameter indicates whether the subscriber"s LCS GMLC list shall be deleted from the VLR or SGSN.

7.6.3.65D Service Type List

This parameter is only applicable to the Service type privacy class and gives the identities of the service type of the clients that are allowed to locate a target MS for an MT-LR. Usage of this parameter is defined in 3GPP TS 23.271.

7.6.3.66 IST Alert Timer

This parameter indicates the IST Alert Timer value that must be used in the MSC to inform the HLR about the call activities that the subscriber performs. Units are minutes.

7.6.3.67 Call Termination Indicator

This parameter indicates whether the MSC shall terminate a specific ongoing call, or all the call activities related to a specified subscriber.

7.6.3.68 IST Information Withdraw

This parameter indicates that IST information shall be deleted from the VMSC.

7.6.3.69 IST Support Indicator

This parameter indicates the degree of IST functionality supported by the MSC (Visited MSC or Gateway MSC). It can take one of the following values:

- Basic IST functionality;
- IST command service (in addition to the basic IST functionality and including the ability to terminate all calls being carried for the identified subscriber).

7.6.3.70 Super-Charger Supported In HLR

This parameter is used by the HLR to indicate support of the Super-Charger functionality and an indication of the age of the subscription data stored in the HLR.

7.6.3.71 Super-Charger Supported In Serving Network Entity

This parameter is used to indicate support of the Super-Charger functionality by the originating entity and to indicate either that subscription data is required or the date and time of the last know subscriber data modification.

7.6.3.72 Age Indicator

This parameter is used by the HLR to determine the validity of the subscription data retained by the serving network entity in a Super-Charged network.

7.6.3.73 GPRS enhancements support indicator

This parameter indicates to the HLR that the SGSN supports GPRS enhancements.

7.6.3.74 Extension QoS-Subscribed

This parameter indicates the enhanced QoS subscribed for a certain service. It is defined in 3GPP TS 23.060. This parameter is an extension to QoS-Subscribed.

7.6.3.75 SGSN CAMEL Subscription Info

This parameter identifies the subscriber as having CAMEL services that are invoked in the SGSN.

7.6.3.75A Extension-2 QoS-Subscribed

This parameter indicates the additional QoS information to the Extension QoS-subscribed parameter. It is a further extension to Extension QoS-Subscribed. This parameter shall be used when the maximum bit rate exceeds 8640 kbps. For more details, refer to 3GPP TS 24.008 [35].

7.6.3.75B Extension-3 QoS-Subscribed

This parameter indicates the additional QoS information to the Extension QoS-subscribed parameter. It is a further extension to Extension QoS-Subscribed. This parameter shall be used when the maximum/guaranteed bit rate for uplink exceeds 8640 kbps. For more details, refer to 3GPP TS 24.008 [35].

7.6.3.76 MO-SMS-CSI

This parameter identifies the subscriber as having mobile originating SMS CAMEL services as defined in 3GPP TS 23.078. For the CAMEL phase 3 the MO-SMS-CSI is the same as the SMS-CSI.

7.6.3.76a MT-SMS-CSI

This parameter identifies the subscriber as having mobile terminating SMS CAMEL services as defined in 3GPP TS 23.078.

7.6.3.77 GPRS-CSI

This parameter identifies the subscriber as having GPRS CAMEL services as defined in 3GPP TS 23.078.

7.6.3.78 CAMEL subscription info

This parameter indicates the CSI that can be controlled by CSE.

7.6.3.79 Extensible Call barring information for CSE

This parameter contains for each call barring service for CSE:

- SS-Code;
- a list of extensible call barring feature parameters.

  The list may contain one item per Basic Service Group.
- password;
- wrong password attempt counter;
- notification-to-CSE flag.

7.6.3.80 Extensible Forwarding information for CSE

This parameter represents the information for CSE related to each call forwarding service:

- the SS-Code of the relevant call forwarding service;
- if required, a list of extensible forwarding feature parameters;
- the list may contain one item per Basic Service Group;
- notification-to-CSE flag.

7.6.3.81 Modification Request for CSI

This parameter indicates the CAMEL subscription information to be modified by CSE.

7.6.3.81a Modification Request for ODB data

This parameter indicates the operator determined barring data to be modified by CSE.

7.6.3.82 Modification Request for SS Information

This parameter indicates the call forwarding and call barring supplementary service data to be modified by CSE.

7.6.3.83 Call Barring Data

This parameter contains the extensible call barring feature list (see clause 7.6.3.21) and Notification to CSE flag.

7.6.3.84 Call Forwarding Data

This parameter contains the extensible call forwarding feature list (see clause 7.6.3.16) and Notification to CSE flag.

7.6.3.85 ODB Data

This parameter contains the ODB general data, ODB HPLMN specific data.

7.6.3.86 Requested Subscription Info

This parameter indicates the subscription information being requested.

7.6.3.87 CS Allocation/Retention priority

This parameter indicates the allocation/retention priority for Circuit Switched (CS). It corresponds to the allocation/retention priority that is defined in 3GPP TS 23.107.

7.6.3.88 ODB Info

This parameter contains the ODB data and Notification to CSE flag.

7.6.3.89 Suppress VT-CSI

This parameter is used to suppress the invocation of terminating CAMEL services at the VMSC.

7.6.3.90 Suppress Incoming Call Barring

This parameter is used to suppress the invocation of Incoming Call Barrings.

7.6.3.91 gsmSCF Initiated Call

This parameter is used to indicate that the call was initiated by the gsmSCF.

7.6.3.91a SuppressMTSS

This parameter is used to suppress the invocation of terminating supplementary services

7.6.3.92 Call barring support indicator

This parameter is used to indicate that the SGSN supports the call barring services for SMS.

7.6.3.93 MNP Info Result

This parameter refers to the Mobile Number Portability (MNP) information result (see 3GPP TS 23.078 [98] and 3GPP TS 23.066 [108]). This parameter may contain the following information:

- Routeing Number (see clause 7.6.2.63).
- IMSI (see 3GPP TS 23.078[98], see also clause 7.6.2.1).
- MSISDN (see clause 7.6.2.17).
- Number Portability Status (see clause 7.6.5.14).

7.6.3.94 Allowed Services

This parameter is used by the HLR to indicate which service is available for a call when two services have been requested, for the SCUDIF feature described in 3GPP TS 23.172 [126].

7.6.3.95 Unavailability Cause

This parameter is used to indicate the reason for the unavailability of one of the services as indicated by the Allowed Services IE (see 7.6.3.94) when two services have been requested, for the SCUDIF feature described in 3GPP TS 23.172 [126].

7.6.3.96 MNP Requested Info

This parameter indicates by its presence that Mobile Number Portability (MNP) information is requested for the subscriber, as defined in 3GPP TS 23.078 [98].

7.6.3.97 Access Restriction Data

This parameter refers to the radio access technologies that are possibly restricted to a subscriber via subscription data. For the use of the parameter, see 3GPP TS 23.012[23] for CS domain and 3GPP TS 23.060[104] for PS domain.

7.6.3.98 Supported RAT types indicator

This parameter indicates which RAT types are supported/served by the MSC/VLR or SGSN or MME

7.6.4 Supplementary services parameters

7.6.4.1 SS-Code

This parameter may refer to one supplementary service or a set of supplementary services as defined in 3GPP TS 22.004. For MAP this includes:

- Calling Line Identification Presentation service (CLIP);
- Calling Line Identification Restriction service (CLIR);
- Connected Line Identification Presentation service (COLP);
- Connected Line Identification Restriction service (COLR);
- Calling Name Presentation (CNAP);
- All Call Forwarding services, including Call Deflection;
- Call Waiting (CW);
- Call Hold (HOLD);
- Multi-Party service (MPTY);
- Closed User Group (CUG);
- All Charging services;
- All Call Restriction services;
- Explicit Call Transfer service (ECT);
- enhanced Multi-Level Precedence and Pre-emption service (eMLPP);
- Completion of Calls to Busy Subscriber, originating side (CCBS-A);
- Completion of Calls to Busy Subscriber, destination side (CCBS-B);
- All LCS privacy exceptions (see clause 7.6.4.44);
- Mobile Originating Location Request (MO-LR) (see clause 7.6.4.45);
- Multicall (MC).

7.6.4.1A SS-Code 2

This parameter is used to refer to one or a set of supplementary services (as 7.6.4.1 "SS-Code") related to Network Signal Info 2 for SCUDIF calls (see 3GPP TS 23.172 [126]).

7.6.4.2 SS-Status

This parameter refers to the state information of individual supplementary services as defined in 3GPP TS 23.011.

7.6.4.3 SS-Data

This parameter refers to the necessary set of information required in order to characterise one supplementary service:

- SS-Code (see clause 7.6.4.1);

- SS-Status (if applicable) (see clause 7.6.4.2);
- Override subscription option (see clause 7.6.4.4);
- CLI Restriction (see clause 7.6.4.5);
- Basic Service Group Code (see clause 7.6.4.40).

7.6.4.4 Override Category

This parameter refers to the subscription option Override Category attached to a supplementary service. It can take the following two values:

- Enabled;
- Disabled.

7.6.4.5 CLI Restriction Option

This parameter refers to the subscription option Restriction mode attached to the CLIR supplementary service. It can take the following three values:

- Permanent;
- Temporary (Default Restricted);
- Temporary (Default Allowed).

7.6.4.6 Forwarding Options

This parameter refers to a forwarding option attached to a supplementary service. It can take one of the following values:

- notification to forwarding party (see 3GPP TS 22.082 [10] for the meaning of this parameter);
- notification to calling party (see 3GPP TS 22.082 [10] for the meaning of this parameter);
- redirecting presentation (see 3GPP TS 22.082 [10] for the meaning of this parameter);
- Forwarding reason (see 3GPP TS 22.082 [10] for the meaning of this parameter).

7.6.4.7 No reply condition timer

This parameter refers to the no reply condition timer for call forwarding on no reply.

7.6.4.8 - 7.6.4.14 Void

7.6.4.15 Forwarding information

This parameter represents the information related to each call forwarding service:

- the SS-Code of the relevant call forwarding service (see clause 7.6.4.1);
- if required, a list of forwarding feature parameters (see clause 7.6.4.16).

  the list may contain one item per Basic Service Group.

7.6.4.16 Forwarding feature

This parameter applies to each combination of call forwarding service and Basic Service Group and contains the following information, as required:

- Basic Service Group (see clause 7.6.4.40);

- SS-Status (see clause 7.6.4.2);
- forwarded-to number (see clause 7.6.2.22);
- forwarded-to subaddress (see clause 7.6.2.23);
- forwarding options (see clause 7.6.4.6);
- no reply condition timer (see clause 7.6.4.7);
- long forwarded-to number (see clause 7.6.2.22A).

If a number is required to define the forwarded-to destination then:

- If the VLR supports Long Forwarded-to Numbers then the long forwarded-to number shall be present and the forwarded-to number shall be absent.
- If the VLR does not support Long Forwarded-to Numbers then the forwarded-to number shall be present and the long forwarded-to number shall be absent.

7.6.4.17 Void

7.6.4.18 Call barring information

This parameter contains for each call barring service:

- SS-Code (see clause 7.6.4.1);
- a list of call barring feature parameters (see clause 7.6.4.19).

  The list may contain one item per Basic Service Group.

7.6.4.19 Call barring feature

This parameter gives the status of call barring services as applicable to each Basic Service Group. The parameter contains the following information:

- Basic Service Group (see clause 7.6.4.40);
- SS-Status (see clause 7.6.4.2).

7.6.4.20 New password

This parameter refers to the password which the subscriber just registered in the network.

This parameter refers to a password used by the subscriber for supplementary service control.

7.6.4.21 Current password

This parameter refers to a password used by the subscriber for supplementary service control.

7.6.4.22 Guidance information

This parameter refers to guidance information given to a subscriber who is requested to provide a password. One of the following information may be given:

- "enter password";

  this information is used for checking of the old password;

- "enter new password";

  this information is used during password registration for the request of the first new password;

- "enter new password again";

  this information is used during password registration for the request of the new password again for verification.

7.6.4.23 Void

7.6.4.24 SS-Info

This parameter refers to all the information related to a supplementary service and is a choice between:

- forwarding information (see clause 7.6.4.15);
- call barring information (see clause 7.6.4.18);
- CUG info (see clause 7.6.4.8);
- SS-Data (see clause 7.6.4.3).
- eMLPP information (see clause 7.6.4.41).

7.6.4.25 - 7.6.4.35 Void

7.6.4.36 USSD Data Coding Scheme

This parameter contains the information of the alphabet and the language used for the unstructured information in an Unstructured Supplementary Service Data operation. The coding of this parameter is according to the Cell Broadcast Data Coding Scheme as specified in 3GPP TS 23.038 [25].

7.6.4.37 USSD String

This parameter contains a string of unstructured information in an Unstructured Supplementary Service Data operation. The string is sent either by the mobile user or the network. The contents of a string sent by the MS are interpreted by the network as specified in 3GPP TS 22.090 [16].

7.6.4.38 Bearer service

This parameter may refer to a single bearer service, a set of bearer services or to all bearer services as defined in 3GPP TS 22.002 [3]. This parameter is used only for supplementary service management.

7,6,4.38A Bearer Service 2

This parameter is used to indicate the bearer service or set of bearer services (as 7.6.4.38 "Bearer service") related to Network Signal Info 2 for SCUDIF calls (see 3GPP TS 23.172 [126]).

7.6.4.39 Teleservice

This parameter may refer to a single teleservice, a set of teleservices or to all teleservices as defined in 3GPP TS 22.003 [4]. This parameter is used only for supplementary service management.

7.6.4.39A Teleservice 2

This parameter is used to indicate the teleservice or set of teleservices (as 7.6.4.39 "Teleservice") related to Network Signal Info 2 for SCUDIF calls (see 3GPP TS 23.172 [126]).

7.6.4.40 Basic Service Group

This parameter refers to the Basic Service Group either as a bearer service (see clause 7.6.4.38) or a teleservice (see clause 7.6.4.39). This parameter is used only for supplementary service management. The null value (i.e. neither bearer service nor teleservice) is used to denote the group containing all bearer services and all teleservices.

7.6.4.41 eMLPP information

This parameter contains two parameters which are associated with the eMLPP service. The following two parameters are included:

- maximum entitled priority:
  - indicates the highest priority level the subscriber is allowed to apply for an outgoing call set-up;
- default priority:
  - defines the priority level which shall be assigned to a call if no explicit priority is indicated during call set-up.

7.6.4.42 SS-event

This parameter indicates the Supplementary Service for which an invocation notification is sent towards the gsmSCF. It can indicate one of the following services:

- Explicit Call Transfer (ECT)
- Call Deflection (CD)
- Multi-Party call (MPTY)
- Completion of Calls to Busy Subscriber (CCBS)

7.6.4.43 SS-event data

This parameter contains additional information related to Supplementary Service invocation. Depending on the service invoked it can contain the following information:

ECT A list with all Called Party Numbers involved.

CD The called Party number involved.

7.6.4.44 LCS Privacy Exceptions

Distinct SS codes are assigned to the following classes of LCS client in a target MS subscriber"s privacy exception list.

- Universal Class;
- Call/session related value added class;
- Call/session unrelated value added class;
- PLMN operator class.
- Service type class.

7.6.4.45 Mobile Originating Location Request (MO-LR)

Distinct SS codes are assigned to the following classes of MO-LR:

- Basic Self Location;
- Autonomous Self Location;

- Transfer to Third Party.

7.6.4.46 NbrUser

This parameter indicates the maximum number of parallel bearers that may be used as defined by the user at registration of the MC SS.

7.6.4.47 MC Subscription Data

This parameter contains two parameters which are associated with the MC service. The following two parameters are included:

- NbrUser:

  indicates the maximum number of parallel bearers that may be used as defined by the user at registration of the MC SS

- NbrSB:

  indicates the maximum number of parallel bearers that may be used as defined by the user"s subscription.

7.6.4.48 MC Information

This parameter contains three parameters which are associated with the MC service. The following parameters are included:

- NbrSB;
- NbrUser;
- NbrSN.

Definitions of these parameters are provided in 3GPP TS 23.135.

7.6.4.49 CCBS Request State

This parameter indicates the current state of the CCBS request. It can take one of seven values:

- request;
- recall;
- active;
- completed;
- suspended;
- frozen;
- deleted.

7.6.4.50 Basic Service Group 2

This parameter refers to the Basic Service Group either as a bearer service (see clause 7.6.4.38) or a teleservice (see clause 7.6.4.39). This parameter is used only for supplementary service management.

7.6.5 Call parameters

7.6.5.1 Call reference number

This parameter refers to a call reference number allocated by a call control MSC.

7.6.5.2 Interrogation type

This parameter refers to the type of interrogation for routing information which is sent from a GMSC to an HLR. It can take either of two values:

- basic call (for information to route a call before the call has been extended to the VMSC of the called party);
- forwarding (for information to route the call to the forwarded-to destination after the VMSC of the forwarding party has requested the GMSC to resume handling of the call.

7.6.5.3 OR interrogation

This parameter indicates that the GMSC which interrogated the HLR for routeing information is not in the same PLMN as the HLR, and therefore that the call will potentially be optimally routed.

7.6.5.4 OR capability

This parameter indicates the phase of OR which the GMSC supports.

7.6.5.5 Forwarding reason

This parameter indicates the reason for which the call is to be forwarded. It can take one of three values:

- busy subscriber;
- mobile subscriber not reachable;
- no subscriber reply.

7.6.5.6 Forwarding interrogation required

This parameter indicates that if the VMSC of the forwarding subscriber requests the GMSC to resume handling of the call the GMSC shall interrogate the HLR for forwarding information.

7.6.5.7 O-CSI

This parameter identifies the subscriber as having originating CAMEL services as defined in 3GPP TS 23.078.

7.6.5.7A D-CSI

This parameter identifies the subscriber as having originating CAMEL dialled services as defined in 3GPP TS 23.078.

7.6.5.7B T-CSI

This parameter identifies the subscriber as having terminating CAMEL services in the GMSC, as defined in 3GPP TS 23.078.

7.6.5.7C VT-CSI

This parameter identifies the subscriber as having terminating CAMEL services in the VMSC, as defined in 3GPP TS 23.078.

7.6.5.7D O-IM-CSI

This parameter identifies the subscriber as having originating IP Multimedia Core Network CAMEL services as defined in 3GPP TS 23.278.

7.6.5.7E D-IM-CSI

This parameter identifies the subscriber as having originating IP Multimedia Core Network CAMEL dialled services as defined in 3GPP TS 23.278.

7.6.5.7F VT-IM-CSI

This parameter identifies the subscriber as having terminating IP Multimedia Core Network CAMEL services as defined in 3GPP TS 23.278.

7.6.5.8 Void

7.6.5.9 Void

7.6.5.10 Void

7.6.5.11 CCBS Feature

This parameter corresponds to the 'CCBS Description' parameter in 3GPP TS 23.093. It refers to the necessary set of information required in order to characterise a certain CCBS request. The parameter may contain the following information:

- CCBS Index (see 3GPP TS 23.093 for the use of this parameter);
- B-subscriber number (see clause 7.6.2.48);
- B-subscriber subaddress (see clause 7.6.2.49);
- Basic Service Group Code (see clause 7.6.4.40).

7.6.5.12 UU Data

This parameter includes User-To-User Data. It is defined in 3GPP TS 23.087.

7.6.5.13 UUS CF Interaction

This parameter indicates if the call forwarding or call deflection has been activated after UUS1 request has been accepted . It is defined in 3GPP TS 23.087.

7.6.5.14 Number Portability Status

This parameter indicates the number portability status of subscriber. See 3GPP TS 23.066 [108].

7.6.5.15 Pre-paging supported

This parameter indicates that the entity which sent it supports pre-paging.

7.6.5.16 MT Roaming Retry Supported

The parameter indicates that the entity which sent it supports MT Roaming Retry. When sent by the HLR, it further indicates that the GMSC also supports MT Roaming Retry.

7.6.5.17 MT Roaming Retry

The parameter indicates that the GMSC receiving the IE shall start MT roaming retry (see 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23]).

7.6.5.18 Paging Area

The parameter indicates the paging area where the MS is currently located (see 3GPP TS 23.012 [23] and 3GPP TS 23.018 [97]).

7.6.5.19 Call Priority

The parameter indicates the eMLPP priority of the call (see 3GPP TS 23.067 [136]).

7.6.6 Radio parameters

7.6.6.1 - 7.6.6.3 Void

7.6.6.4 GERAN Classmark

This information element is sent from one MSC to the other MSC in the signalling for inter MSC handover. It is used to convey information related to cell capabilities, as defined in 3GPP TS 48.008.

7.6.6.5 BSSMAP Service Handover

This parameter refers to the Service Handover information element defined in 3GPP TS 48.008

7.6.6.5A BSSMAP Service Handover List

This parameter refers to the list of Service Handover information elements defined in 3GPP TS 48.008. This parameter shall be used when there are multiple bearers and at least one of the bearers has an associated BSSMAP Service Handover parameter.

7.6.6.6 RANAP Service Handover

This parameter refers to the Service Handover information element defined in 3GPP TS 25.413.

7.6.6.7 HO-Number Not Required

This parameter indicates that no handover or relocation number allocation is necessary.

7.6.6.8 Integrity Protection Information

This parameter refers to the Integrity Protection Information element defined in 3GPP TS 25.413.

7.6.6.9 Encryption Information

This parameter refers to the Encryption Information element defined in 3GPP TS 25.413.

7.6.6.10 Radio Resource Information

This parameter refers to the Channel Type information element defined in 3GPP TS 48.008 [49].

7.6.6.10A Radio Resource List

This parameter refers to list of RAB-id's and their associated Channel Type information elements defined in 3GPP TS 48.008. This parameter shall be used when there are multiple bearers and at least one of the bearers has an associated Radio Resource Information parameter.

7.6.6.10B Chosen Radio Resource Information

This parameter refers to the Chosen Channel and Speech Version information elements defined in 3GPP TS 48.008.

7.6.6.11 Key Status

This parameter refers to the Key Status element defined in 3GPP TS 25.413.

7.6.6.12 Selected UMTS Algorithms

This parameters identifies the UMTS integrity and optionally encryption algorithms selected by MSC-B. Coding of this parameter is defined in 3GPP TS 25.413.

7.6.6.13 Allowed GSM Algorithms

This parameters identifies the allowed GSM algorithms in MSC-B. Coding of this parameter is defined in 3GPP TS 48.008.

7.6.6.14 Allowed UMTS Algorithms

This parameters identifies the allowed UMTS algorithms in MSC-B. Coding of this parameter is defined in 3GPP TS 25.413.

7.6.6.15 Selected GSM Algorithm

This parameter identifies the GSM algorithm selected by GSM BSC controlled by MSC-B. Coding of this parameter is defined in 3GPP TS 48.008.

7.6.6.16 Iu-Currently Used Codec

This parameter indicates the codec used at the Iu interface before handover.

7.6.6.17 Iu-Supported Codecs List

This parameter indicates the codecs supported by the UE and by MSC-A and the associated modes in priority order (the first entry being the highest priority codec). MSC-B uses this information to select the associated transcoder resources.

7.6.6.17A Iu-Available Codecs List

This parameter indicates the codecs available at the Iu interface in MSC-B and the associated modes. MSC-A uses this information to decide whether a change to a different codec at the Iu interface is possible.

7.6.6.18 Iu-Selected Codec

When sent by MSC-B, this parameter indicates the codec selected by MSC-B for the Iu interface. When sent by MSC-A, this parameter indicates the codec to be used by MSC-B at the Iu interface.

7.6.6.19 RAB Configuration Indicator

This parameter indicates by its presence that MSC-A (or MSC-B in case of subsequent handover) has generated the RAB parameters according to the preferred codec (first entry in the Iu-Supported Codecs List).

7.6.6.20 UESBI-Iu

This parameter refers to the UESBI-Iu (UE Specific Behaviour Information over the Iu interface) information element defined in 3GPP TS 25.413.

7.6.6.21 Alternative Channel Type

This parameter refers to the Channel Type information element defined in 3GPP TS 48.008 [49] for the alternative radio access bearer. This parameter is used for SCUDIF calls (see 3GPP TS 23.172 [126]).

7.6.7 Authentication parameters

7.6.7.1 Authentication set list

This parameter represents a list of sets of authentication parameters for a given subscriber.

The list either contains Authentication Triplets (Rand, Sres, Kc) or Authentication Quintuplets (Rand, Xres, Ck, Ik, Autn). If the list contains Authentication Quintuplets, the order of sequence in this list is chronological, the first quintuplet in the list is the oldest one.

7.6.7.2 Rand

This parameter represents a random number used for authentication.

7.6.7.3 Sres

This parameter represents the response to an authentication request.

7.6.7.4 Kc

This parameter refers to a key used for ciphering purposes.

7.6.7.5 Xres

This parameter represents the response to an UMTS authentication request.

7.6.7.5A Ck

This parameter refers to a key used for UMTS ciphering purposes.

7.6.7.5B Ik

This parameter refers to the Integrity Key.

7.6.7.5C Autn

This parameter refers to the Authentication Token.

7.6.7.5D KASME

This parameter refers to the Key for the Access Security Management Entity.

7.6.7.6 Cksn

This parameter refers to a ciphering key sequence number.

7.6.7.6A Ksi

This parameter refers to a key set identifier.

7.6.7.6B Auts

This parameter refers to the resynchronisation token.

7.6.7.7 Ciphering mode

This parameter refers to the ciphering mode which is associated with a radio channel. It may take values as follows:

- no encryption;
- identification of specific ciphering algorithm.

7.6.7.8 Current Security Context

This parameter represents a list of security context parameters for a given subscriber.

The list either contains GSM Security Context data (Kc, Cksn) or UMTS Security Context Data (Ck, Ik, Ksi).

7.6.7.9 Failure cause

This parameter refers to an authentication failure which has occurred. It may take values as follows:

- wrong user response;
- wrong network signature.

7.6.7.10 Re-attempt

It indicates whether the failure ocurred in a normal authentication attempt or in an authentication reattempt (there was a previous unsuccessful authentication).

7.6.7.11 Access Type

It indicates whether the authentication procedure was initiated due to a call, an emergency call, a location updating, a supplementary service procedure, a short message transfer, a GPRS attach procedure, a routing area updating, a service request, a MS initiated Detach in GPRS, a PDP context activation or a PDP context deactivation procedure.

7.6.8 Short message parameters

7.6.8.1 SM-RP-DA

This parameter represents the destination address used by the short message service relay sub-layer protocol. It can be either of the following:

- IMSI (see clause 7.6.2.1);
- LMSI (see clause 7.6.2.16);
- MS-ISDN (see clause 7.6.2.17);
- roaming number (see clause 7.6.2.19);
- service centre address (see clause 7.6.2.27).

7.6.8.2 SM-RP-OA

This parameter refers to the originating address used by the short message service relay sub-layer protocol. It can be either of the following:

- MS-ISDN (see clause 7.6.2.17);
- service centre address (see clause 7.6.2.27).

7.6.8.3 MWD status

This parameter indicates whether or not the address of the originator service centre is already contained in the Message Waiting Data file. In addition, it contains the status of the Memory Capacity Exceeded Flag (MCEF), the status of the Mobile subscriber Not Reachable Flag (MNRF) and the status of the Mobile station Not Reachable for GPRS flag (MNRG).

7.6.8.4 SM-RP-UI

This parameter represents the user data field carried by the short message service relay sub-layer protocol.

7.6.8.5 SM-RP-PRI

This parameter is used to indicate whether or not delivery of the short message shall be attempted when a service centre address is already contained in the Message Waiting Data file.

7.6.8.6 SM Delivery Outcome

This parameter indicates the cause for setting the message waiting data. It can take one of the following values:

- Absent subscriber;
- MS memory capacity exceeded;
- Successful transfer.

7.6.8.7 More Messages To Send

This parameter is used to indicate whether or not the service centre has more short messages to send.

7.6.8.8 Alert Reason

This parameter is used to indicate the reason why the service centre is alerted. It can take one of the following values:

- MS present;
- Memory Available.

7.6.8.9 Absent Subscriber Diagnostic SM

This parameter is used to indicate the reason why the subscriber is absent. For the values for this parameter see 3GPP TS 23.040.

7.6.8.10 Alert Reason Indicator

This parameter indicates that the alert reason is sent to the HLR due to GPRS activity.

7.6.8.10A Additional Alert Reason Indicator

This parameter indicates that the alert reason is sent to the HLR due to IMS activity.

7.6.8.11 Additional SM Delivery Outcome

This parameter is used to indicate the GPRS delivery outcome in case a combination between delivery outcome for GPRS and non-GPRS are sent to the HLR.

7.6.8.12 Additional Absent Subscriber Diagnostic SM

This parameter indicates the reason of the additional SM Delivery Outcome.

7.6.8.13 Delivery Outcome Indicator

This parameter indicates that the delivery outcome sent to the HLR is for GPRS.

7.6.8.14 GPRS Node Indicator

This parameter indicates that the Network Node Number sent by the HLR is the SGSN number.

7.6.8.15 GPRS Support Indicator

This parameter indicates that the SMS-GMSC supports GPRS specific procedure of combine delivery of Short Message via MSC and/or via the SGSN.

7.6.8.16 SM-RP-MTI

This parameter represents the RP-Message Type Indicator of the Short Message. It is used to distinguish a SM sent to the mobile station in order to acknowledge an MO-SM initiated by the mobile from a normal MT-SM. This parameter is formatted according to the formatting rules of address fields as described in 3GPP TS 23.040.

7.6.8.17 SM-RP-SMEA

This parameter represents the RP-Originating SME-address of the Short Message Entity that has originated the SM. This parameter is used by the short message service relay sub-layer protocol and is formatted according to the formatting rules of address fields as described in 3GPP TS 23.040.

7.6.8.18 IP-SM-GW SM Delivery Outcome

This parameter is used to indicate the delivery outcome for the IMS domain.

7.6.8.19 IP-SM-GW Absent Subscriber Diagnostic SM

This parameter indicates the reason of the IP-SM-GW SM Delivery Outcome.

7.6.8.20 IP-SM-GW Indicator

This parameter indicates indicates by its presence that sm-deliveryOutcome is for delivery via IMS.

7.6.9 Access and signalling system related parameters

7.6.9.1 AN-apdu

This parameter includes one or two concatenated complete 3GPP TS 25.413 or 3GPP TS 48.006 [48] messages, as described in 3GPP TS 23.009 and 3GPP TS 29.010. The access network protocol ID indicates that the message or messages are according to either 3GPP TS 48.006 [48] or 3GPP TS 25.413. For the coding of the messages see 3GPP TS 25.413, 3GPP TS 48.006 [48] and 3GPP TS 48.008 [49].

7.6.9.2 CM service type

This parameter identifies the service category being requested by the subscriber:

- mobile originating call;
- emergency call establishment;
- short message service;
- mobile originating call re-establishment;
- mobile terminating call;
- SS request;
- Voice group call set-up;
- Voice broadcast set-up.

7.6.9.3 Access connection status

This parameter represents the following access connection status information:

- RR-connection status (established/not established);
- ciphering mode (on/off);
- authentication status (authenticated/not authenticated).

7.6.9.4 External Signal Information

This parameter contains concatenated information elements (including tag and length) which are defined by a common protocol version, preceded by the associated protocol ID. It is used to transport information of the indicated protocol via MAP interfaces.

7.6.9.5 Access signalling information

This parameter refers to any set of information elements imported from 3GPP TS 24.008 [35].

7.6.9.6 Location update type

This parameter refers to the location update type (normal, periodic or IMSI attach) contained in the 3GPP TS 24.008 [35] LOCATION REGISTRATION REQUEST message.

7.6.9.7 Protocol ID

This parameter refers to the protocol to which the coding of the content of the associated External Signal Information conforms.

The following values are defined:

- 04.08;
- 08.06;
- ETS 300 102-1.

This value indicates the protocol defined by ETS 300 102-1 (EDSS1).

7.6.9.8 Network signal information

This parameter is transported as external signal information. The protocol ID shall be set to "ETS 300 102-1".

The network signal information may include the following information elements as defined in 3GPP TS 29.007 [56]:

- ISDN BC; the tag and length are defined by ETS 300 102-1.

  For the content, see 3GPP TS 29.007 [56].

- HLC; the tag and length are defined by ETS 300 102-1.

  For the content, see 3GPP TS 29.007 [56].

- LLC; the tag and length are defined by ETS 300 102-1.

  For the content, see 3GPP TS 29.007 [56].

They are contained in the Signal Information parameter according to figure 7.6/1 (irrespective of the order):




Figure 7.6/1: Network signal information parameter

7.6.9.8A Network signal information 2

This parameter is transported as additional external signal information for SCUDIF calls, described in 3GPP TS 23.172 [126]. The protocol ID and possibly included information elements are identical to Network Signal Information, defined in 7.6.9.8, "Network signal information".

7.6.9.9 Call Info

This parameter is transported as external signal information. The protocol ID shall be set to "3GPP TS 24.008 [35]".

The Call Info includes the set of information elements from the original SETUP message and is imported from 3GPP TS 24.008 [35].

7.6.9.10 Additional signal info

This parameter is transported as external signal information. The protocol ID shall be set to "ETS 300 356".

The additional signal information may include the following information elements:

- Calling Party Number as defined by ETS 300 356.
- Generic Number as defined by ETS 300 356.

They are contained in the Signal Information parameter according to figure 7.6/2 (irrespective of the order):




Figure 7.6/2: Additional signal information parameter

7.6.10 System operations parameters

7.6.10.1 Network resources

This parameter refers to a class or type of network resource:

- PLMN;
- HLR;
- VLR (current or previous);
- MSC (controlling or current);
- EIR;
- radio sub-system.

7.6.10.2 Trace reference

This parameter represents a reference associated with a GSM only tracing request as defined in 3GPP TS 52.008 [61]. The parameter is managed by OMC/EM.

7.6.10.2A Trace reference 2

This parameter represents a reference associated with a tracing request as defined in 3GPP TS 32.421 [131] and 3GPP TS 32.422 [132]. The parameter is managed by EM.

7.6.10.3 Trace type

This parameter identifies the type of trace for GSM only tracing request. Trace types are fully defined in 3GPP TS 52.008 [61]. If the activation of the tracing is requested only for UMTS, then this parameter shall contain value "No MSC Trace" for MSC Record Type and value "No BSS Trace" for BSS Record Type.

7.6.10.4 Additional network resources

This parameter refers to a class or type of network resource:

- SGSN;
- GGSN;
- GMLC;
- gsmSCF;
- NPLR;
- AuC.

7.6.10.5 Trace depth list

This parameter identifies the list of depths of trace per network element. See 3GPP TS 32.422 [132].

7.6.10.6 Trace NE type list

This parameter identifies the list of network elements to be traced. See 3GPP TS 32.422 [132].

7.6.10.7 Trace interface list

This parameter identifies the list of interfaces or protocols per network element to be traced. See 3GPP TS 32.422 [132].

7.6.10.8 Trace event list

This parameter identifies the list of events per network element, which trigger a Trace Recording Session. See 3GPP TS 32.422 [132].

7.6.10.9 Trace support indicator

This parameter indicates that UMTS trace parameters are supported in the VLR or in the SGSN.

7.6.10.10 Trace Propagation List

This parameter indicates UMTS trace propagation parameters sent from one MSC to the other MSC in the signalling for inter MSC handover/relocation. See 3GPP TS 32.422 [132].

7.6.11 Location Service Parameters

7.6.11.1 Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

7.6.11.2 Deferred MT-LR Response Indicator

This parameter shows that this is a response to a deferred mt-lr request.

7.6.11.3 Deferred MT-LR Data

This parameter is used to report the deferred location event type, the location information and reason why the serving node aborted monitoring the event to the GMLC. The termination cause mt-lrRestart shall be used to trigger the GMLC to restart the location procedure in all the cases where the sending node detects that the location procedure cannot be successfully performed anymore by the sending node and that it could be successfully performed by another node (as for example when. Cancel Location or Send Identification has been received). The location information shall be included only if the termination cause is mt-lrRestart. The network node number contained in the location information refers to the node where the MS/UE has moved to and shall be included if available, like in case Send Identification has been received.

7.6.11.4 LCS Client ID

This parameter provides information related to the identity of an LCS client.

7.6.11.5 LCS Event

This parameter identifies an event associated with the triggering of a location estimate.

7.6.11.6 Void

7.6.11.7 LCS Priority

This parameter gives the priority of the location request.

7.6.11.8 LCS QoS

This parameter defines the Quality of Service (QoS) for any location request. It is composed of the following elements.

1) Response Time

   Indicates the category of response time – 'low delay' or 'delay tolerant'.

2) Horizontal Accuracy

Indicates the required horizontal accuracy of the location estimate.

3) Vertical Coordinate

Indicates if a vertical coordinate is required (in addition to horizontal coordinates).

4) Vertical Accuracy

Indicates the required vertical accuracy of the location estimate (inclusion is optional).

5) Velocity Request

Indicates that velocity should be returned if available (inclusion is optional).

7.6.11.9 CS LCS Not Supported by UE

This parameter is used by the VLR to indicate to the HLR that the UE does not support neither UE Based nor UE Assisted positioning metheds for Circuit Switched Location Services. VLR defines the presence of this parameter on the basis of the Classmark 3 information.

7.6.11.10 PS LCS Not Supported by UE

This parameter is used by the SGSN to indicate to the HLR that the UE does not support neither UE Based nor UE Assisted positioning metheds for Packet Switched Location Services. SGSN defines the presence of this parameter on the basis of the UE capability information and the access technology supported by the SGSN.

7.6.11.11 Location Estimate

This parameter gives an estimate of the location of an MS in universal coordinates and the accuracy of the estimate. The estimate is expressed in terms of the geographical shapes defined by 3GPP TS 23.032. and is composed of the type of shape plus the encoding of the shape itself. Any type of shape defined in 3GPP TS 23.032 can be filled in in the Location Estimate parameter, but only the encoding of the following shapes shall be carried by Location Estimate:

- Ellipsoid point with uncertainty circle
- Ellipsoid point with uncertainty ellipse
- Ellipsoid point with altitude and uncertainty ellipsoid
- Ellipsoid arc
- Ellipsoid point

The encoding for the remaining types of shape, defined in the 3GPP TS 23.032, shall be filled in in the Additional Location Estimate parameter.

7.6.11.11A GERAN Positioning Data

This parameter provides positioning data associated with a successful or unsuccessful location attempt for a target MS described in 3GPP TS 49.031 [59a].

7.6.11.11B UTRAN Positioning Data

This parameter provides positioning data associated with a successful location attempt for a target MS as described in 3GPP TS 25.413 [120]. It contains the positioningDataDiscriminator and positioningDataSet parts of the RANAP PositionData element only.

7.6.11.12 Location Type

This parameter indicates the type of location estimate required by the LCS client. Possible location estimate types include:

- current location;

- current or last known location;
- initial location for an emergency services call;
- deferred location event type;
- notification verification only.

7.6.11.13 NA-ESRD

This parameter only applies to location for an emergency services call in North America and gives the North American Emergency Services Routing Digits.

7.6.11.14 NA-ESRK

This parameter only applies to location for an emergency services call in North America and gives the North American Emergency Services Routing Key.

7.6.11.15 LCS Service Type Id

This parameter defines the LCS Service Type of the current positioning request. The possible values are defined in 3GPP TS 22.071 [123]

7.6.11.16 Privacy Override

This parameter indicates if MS privacy is overridden by the LCS client when the GMLC and VMSC/SGSN for an MT-LR are in the same country.

7.6.11.17 Supported LCS Capability Sets

This parameter indicates which capability sets of LCS are supported in the VLR or SGSN.

7.6.11.18 LCS Codeword

This parameter contains the codeword associated to current positioning request as described in 3GPP TS 23.271 [26a].

7.6.11.19 NA-ESRK Request

This parameter allows the MSC to indicate that it requires the GMLC to allocate a NA-ESRK based on the target MS location estimate. This parameter only applies to emergency services calls in North America.

7.6.11.20 Supported GAD Shapes

This parameter indicates which of the shapes defined in 3GPP TS 23.032 are supported. If the parameter is not provided then the receiving node shall assume that the sending entity supports the following shapes:

- Ellipsoid point with uncertainty circle
- Ellipsoid point with uncertainty ellipse
- Ellipsoid point with altitude and uncertainty ellipsoid
- Ellipsoid arc
- Ellipsoid point

7.6.11.21 Additional Location Estimate

This parameter gives an estimate of the location of an MS/UE in universal coordinates and the accuracy of the estimate. This parameter allows the location estimate to be expressed in any of the geographical shapes defined in 3GPP TS 23.032

7.6.11.22 Cell Id Or SAI

For GERAN access, this parameter contains the Global Cell Identifier for the cell that the subscriber is currently attached to. For UTRAN access, this parameter contains the Service Area Identifier for the cell that the subscriber is currently attached to.

7.6.11.23 LCS-Reference Number

This parameter represents a reference between a request and a responce of a deferred mt-lr procedure as deccribed in 3GPP TS 23.271 [26a].

7.6.11.24 LCS Privacy Check

This parameter refers to the requested privacy check related actions (call/session unrelated and/or call/session related) from MSC or SGSN provided by H-GMLC. Possible requested actions are:

- positioning allowed without notifying the UE user;
- positioning allowed with notification to the UE user;
- positioning requires notification and verification by the UE user; positioning is allowed only if granted by the UE user or if there is no response to the notification;
- positioning requires notification and verification by the UE user; positioning is allowed only if granted by the UE user;
- positioning not allowed.

7.6.11.25 Additional LCS Capability Sets

This parameter indicates which capability sets of LCS are supported in the VLR or SGSN.

7.6.11.26 Area Event Info

This parameter defines the requested deferred MT-LR area event information. The parameter consists of area definition, type of area event, occurrence info and minimum interval time.

7.6.11.27 Velocity Estimate

This parameter gives an estimate of the velocity of an MS and the accuracy of the estimate. The estimate is expressed in terms of speed and bearing as defined by 3GPP TS 23.032 [122], and is composed of the velocity terms plus the encoding of the velocity itself. Only the encoding of the following velocity definitions shall be carried by the Velocity Estimate:

- Horizontal Velocity
- Horizontal with Vertical Velocity
- Horizontal Velocity with Uncertainty
- Horizontal with Vertical Velocity and Uncertainty

7.6.11.28 Accuracy Fulfilment Indicator

This parameter indicates the fulfilled accuracy of the positioning procedure. For details see 3GPP TS 23.271 [26a].

7.6.11.29 MO-LR Short Circuit Indicator

This parameter indicates whether MO-LR short circuit feature is permitted. For details see 3GPP TS 23.271 [26a].

7.6.11.30 Reporting PLMN List

This parameter provides a list of PLMNs in which subsequent periodic MO-LR TTTP requests will be made. For details see 3GPP TS 23.271 [26a].

7.6.11.31 Periodic LDR information

This parameter refers to the periodic reporting interval and reporting amount of the deferred periodic location. For details see 3GPP TS 23.271 [26a].

7.6.11.32 Sequence Number

This parameter refers to the number of the periodic location reports completed. The sequence number would be set to 1 in the first location report and increment by 1 for each new report. When the number reaches the reporting amount value, the H-GMLC (for a periodic MT-LR or a periodic MO-LR transfer to third party) will know the procedure is complete. For details see 3GPP TS 23.271 [26a].

7.6.12 Void

7.7 Representation of a list of a basic parameter in service-primitives

In some service-primitives several instances of a basic parameter of clause 7.6 are required. In the service descriptions such cases will be represented as

ParameterNameLIST

in the tables where ParameterName refers to one of the parameters defined in clause 7.6. This corresponds to the following construction rule:




Figure 7.7/1: Construction of Lists

8 Mobility services

8.1 Location management services

8.1.1 Void

8.1.1.1 Void

8.1.1.2 Void

8.1.1.3 Void

8.1.2 MAP_UPDATE_LOCATION service

8.1.2.1 Definition

This service is used by the VLR to update the location information stored in the HLR.

The MAP_UPDATE_LOCATION service is a confirmed service using the service primitives given in table 8.1/2.

8.1.2.2 Service primitives

Table 8.1/2: MAP_UPDATE_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSC Address	M	M(=)		
VLR number	M	M(=)		
LMSI	U	C(=)		
Supported CAMEL Phases	C	C(=)		
SoLSA Support Indicator	C	C(=)		
IST Support Indicator	C	C(=)		
Super-Charger Supported in Serving Network Entity	C	C(=)		
Long FTN Supported	C	C(=)		
Supported LCS Capability Sets	C	C(=)		
Offered CAMEL 4 CSIs	C	C(=)		
Inform Previous Network Entity	C	C(=)		
CS LCS Not Supported by UE	C	C(=)		
V-GMLC Address	U	C(=)		
IMEISV	C	C(=)		
Skip Subscriber Data Update	U	C(=)		
Supported RAT Types Indicator	U	C(=)		
Paging Area	U	C(=)		
ADD Capability			U	C(=)
Paging Area Capability			U	C(=)
HLR number			C	C(=)
User error			C	C(=)
Provider error				O

8.1.2.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

MSC Address

See definition for MSC number in clause 7.6.2. The MSC address is used for short message delivery only and for each incoming call set-up attempt the MSRN will be requested from the VLR.

VLR number

See definition in clause 7.6.2.

LMSI

See definition in clause 7.6.2. It is an operator option to provide the LMSI from the VLR; it is mandatory for the HLR to support the LMSI handling procedures.

Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. Must be present if a CAMEL phase different from phase 1 is supported. Otherwise may be absent.

HLR number

See definition in clause 7.6.2. The presence of this parameter is mandatory in case of successful HLR updating.

SoLSA Support Indicator

This parameter is used by the VLR to indicate to the HLR in the Update Location indication that SoLSA is supported. If this parameter is not included in the Update Location indication and the Subscriber is marked as only allowed to roam in Subscribed LSAs, then the HLR shall reject the roaming and indicate to the VLR that roaming is not allowed to that Subscriber in the VLR.

This SoLSA Support Indicator shall be stored by the HLR per VLR where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a VLR and no SoLSA Support indicator is stored for that VLR, the location status of that Subscriber shall be set to Restricted.

IST Support Indicator

This parameter is used to indicate to the HLR that the VMSC supports basic IST functionality, that is, the VMSC is able to terminate the Subscriber Call Activity that originated the IST Alert when it receives the IST alert response indicating that the call(s) shall be terminated. If this parameter is not included in the Update Location indication and the Subscriber is marked as an IST Subscriber, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Roaming, Incoming or Outgoing calls), or allow service assuming the associated risk of not having the basic IST mechanism available.

This parameter can also indicate that the VMSC supports the IST Command service, including the ability to terminate all calls being carried for the identified subscriber by using the IMSI as a key. If this additional capability is not included in the Update Location indication and the HLR supports the IST Command capability, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Roaming, Incoming or Outgoing calls), or allow service assuming the associated risk of not having the IST Command mechanism available.

Long FTN Supported

This parameter indicates that the VLR supports Long Forwarded-to Numbers.

Super-Charger Supported in Serving Network Entity

This parameter is used by the VLR to indicate to the HLR that the VLR supports the Super-Charger functionality and whether subscription data has been retained by the VLR. If subscription data has been retained by the VLR the age indicator shall be included. Otherwise the VLR shall indicate that subscriber data is required.

If this parameter is absent then the VLR does not support the Super-Charger functionality.

Supported LCS Capability Sets

This parameter indicates, if present, the capability sets of LCS which are supported. If the parameter is sent but no capability set is marked as supported then the VLR does not support LCS at all.

If this parameter is absent then the VLR may support at most LCS capability set 1, that is LCS Release98 or Release99 version.

Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the VMSC/VLR (see clause 7.6.3.36D).

Inform Previous Network Entity

This parameter is used by the VLR to ask the HLR to inform the previous network entity about the update by sending the previous network entity a Cancel Location message. It is used in case Super-Charger is supported in the network and the serving network entity has not been able to inform the previous network entity that MS has moved, that is if it has not sent Send Identification to the previous serving entity.

CS LCS Not Supported by UE

See definition in clause 7.6.11.

V-GMLC address

See definition in clause 7.6.2.

IMEISV

For definition of the parameter see clause 7.6.2. For the use of this parameter see 3GPP TS 23.012. IMEISV shall be present if ADD function is supported and a new IMEISV is to be notified to the HLR (The functional requirements for the presence of IMEISV due to ADD are described in 3GPP TS 22.101 clause 7.4).

Skip Subscriber Data Update

The presence of the parameter is optional and if present it indicates that the service is solely used to inform the HLR about change of IMEISV or Paging Area. The parameter is used to optimise signalling load during Location Update procedure.

Supported RAT Types Indicator

This parameter indicates, if present, which access technologies (e.g. GERAN and / or UTRAN) are served by the MSC/VLR (see clause 7.6.3)

Paging Area

This parameter indicates, if present, the paging area where the MS is currently located (see clause 7.6.5.18)

ADD Capability

This parameter indicates, if present, the support of ADD function by the HLR.

Paging Area Capability

This parameter indicates, if present, the support of Paging Area function by the HLR. The HLR shall report the same capability for all subscribers.

User error

In case of unsuccessful updating, an error cause shall be returned by the HLR. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- roaming not allowed;

  This cause will be sent if the MS is not allowed to roam into the PLMN indicated by the VLR number. The cause is qualified by the roaming restriction reason "PLMN Not Allowed", "Supported RAT Types Not

Allowed" or "Operator Determined Barring". If no qualification is received (HLR with MAP Version 1), "PLMN Not Allowed" is taken as default.

- system failure;
- unexpected data value.

Provider error

For definition of provider errors see clause 7.6.1.

8.1.3 MAP_CANCEL_LOCATION service

8.1.3.1 Definition

This service is used between HLR and VLR to delete a subscriber record from the VLR. It may be invoked automatically when an MS moves from one VLR area to another, to remove the subscriber record from the old VLR, or by the HLR operator to enforce a location updating from the VLR to the HLR, e.g. on withdrawal of a subscription.

Also this service is used between HLR and SGSN to delete a subscriber record from the SGSN. It may be invoked automatically when an MS moves from one SGSN area to another, to remove the subscriber record from the old SGSN, or by the HLR operator to enforce a location updating from the SGSN to the HLR.

In an EPS this service is used between HSS and IWF and between IWF and IWF to delete the subscriber record from the MME or SGSN or to release bearer resources without deleting the subscriber record.

The MAP_CANCEL_LOCATION service is a confirmed service using the primitives defined in table 8.1/3.

8.1.3.2 Service primitives

Table 8.1/3: MAP_CANCEL_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
LMSI	C	C(=)		
Cancellation Type	C	C(=)		
User error			C	C(=)
Provider error				O

8.1.3.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

LMSI

See definition in clause 7.6.2. The LMSI shall be included if it has been received from VLR. LMSI is not applicable between SGSN and HLR.

Value 0000 0000 can be used to indicate that the LMSI is not in use.

Cancellation Type

See definition in clause 7.6.3. The presence of this parameter is mandatory when the Cancel Location is sent to the SGSN or IWF. The parameter may also be sent during an inter-VLR location update If the VLR receives this parameter and does not understand it the VLR shall ignore it and should by default assume an Update procedure. If the SGSN

receives this parameter indicating initial attach procedure, the SGSN shall do as specified in 3GPP TS 23.060 [104], and shall not delete the subscription data.

User error

If the cancellation fails, an error cause is to be returned by the VLR or by the SGSN or IWF. One of the following error causes defined in clause 7.6.1 shall be used:

- unexpected data value;
- data missing.

Provider error

For definition of provider errors see clause 7.6.1.

8.1.4 MAP_SEND_IDENTIFICATION service

8.1.4.1 Definition

The MAP_SEND_IDENTIFICATION service is used between a VLR and a previous VLR to retrieve IMSI and authentication data for a subscriber registering afresh in that VLR.

It may also be used to send the MSC number from a VLR to a previous VLR.

The MAP_SEND_IDENTIFICATION service is a confirmed service using the service primitives defined in table 8.1/4.

8.1.4.2 Service primitives

Table 8.1/4: MAP_SEND_IDENTIFICATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
TMSI	M	M(=)		
Number of requested vectors	M	M(=)		
Segmentation prohibited indicator	C	C(=)		
MSC Number	U	C(=)		
Previous Location Area Id	U	C(=)		
Hop Counter	U	C (=)		
IMSI			C	C(=)
Authentication set			U	C(=)
Current Security Context			U	C(=)
User error			C	C(=)
Provider error				O

8.1.4.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

TMSI

See definition in clause 7.6.2.

If multiple service requests are present in a dialogue then this parameter shall be present in every service request.

Number of requested vectors

A number indicating how many authentication vectors the new VLR is prepared to receive. The previous VLR shall not return more vectors than indicated by this parameter.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one

Segmentation prohibited indicator

This parameter indicates if the new VLR or SGSN allows segmentation of the response at MAP user level.

This parameter may be present only in the first request of the dialogue.

IMSI

See definition in clause 7.6.2. The IMSI is to be returned if the service succeeds.

If multiple service requests are present in a dialogue and the service succeeds then this parameter shall not be present in any service response other than the first one

MSC Number

This is the ISDN number assigned to the MSC currently serving the MS.

Previous Location Area Id

See definition in clause 7.6.2. Together with the TMSI the Previous Location Area Id can be used to derive the IMSI.

Authentication set

See definition in clause 7.6.7. If the service succeeds a list of up to five authentication sets is returned, if there are any available.

Current Security Context

See definition in clause 7.6.7. If the service succeeds, a list of either GSM or UMTS Security Context parameters can be returned.

Hop Counter

For the use of this parameter see 3GPP TS 23.012 [23].

User error

This parameter is mandatory if the service fails. The following error cause defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unidentified subscriber.

Provider error

For definition of provider errors see clause 7.6.1.

8.1.5 Void

8.1.5.1 Void

8.1.5.2 Void

8.1.5.3 Void

8.1.6 MAP_PURGE_MS service

8.1.6.1 Definition

This service is used between the VLR and the HLR to cause the HLR to mark its data for an MS so that any request for routing information for a mobile terminated call or a mobile terminated short message will be treated as if the MS is not

reachable. It is invoked when the subscriber record for the MS is to be deleted in the VLR, either by MMI interaction or automatically, e.g. because the MS has been inactive for several days. This service shall not be used if both the VLR and HLR support the Super-Charger functionality.

Also this service is used between the SGSN and the HLR to cause the HLR to mark its data for an MS so that any request for routing information for a mobile terminated short message or a network requested PDP-context activation will be treated as if the MS is not reachable. It is invoked when the subscriber record for the MS is to be deleted in the SGSN, either by MMI interaction or automatically, e.g. because the MS has been inactive for several days. This service shall not be used if both the SGSN and HLR support the Super-Charger functionality.

In an EPS this service is used between IWF and IWF and between IWF and HSS.

The MAP_PURGE_MS service is a confirmed service using the primitives defined in table 8.1/6.

8.1.6.2 Service primitives

Table 8.1/6: MAP_PURGE_MS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
VLR number	C	C(=)		
Freeze TMSI			C	C(=)
Freeze P-TMSI			C	C(=)
Freeze M-TMSI			C	C(=)
SGSN number	C	C(=)		
User error			C	C(=)
Provider error				O

8.1.6.3 Parameter definitions and use

Invoke ID

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

VLR number

Shall be present if the sender is VLR. See definition in clause 7.6.2.

SGSN number

Shall be present if the sender is SGSN. See definition in clause 7.6.2.

In an EPS, this parameter may contain the IWF number.

Freeze TMSI

This parameter is sent to the VLR to indicate that the TMSI has to be frozen. It shall be present if the received VLR number matches the stored VLR number.

Freeze P-TMSI

This parameter is sent to the SGSN to indicate that the P-TMSI has to be frozen. It shall be present if the received SGSN number matches the stored SGSN number.

Freeze M-TMSI

This parameter is sent to the IWF to indicate that the M-TMSI has to be frozen. It shall be present if the received node number matches the stored IWF number.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

See definition of provider errors in clause 7.6.1.

8.1.7 MAP_UPDATE_GPRS_LOCATION service

8.1.7.1 Definition

This service is used by the SGSN to update the location information stored in the HLR.

In an EPS, this service is used between IWF and IWF and between IWF and HSS.

The MAP_UPDATE_GPRS_LOCATION service is a confirmed service using the service primitives given in table 8.1/7.

8.1.7.2 Service primitives

Table 8.1/7: MAP_UPDATE_GPRS_LOCATION

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
SGSN number	M	M(=)		
SGSN address	M	M(=)		
Supported CAMEL Phases	C	C(=)		
SoLSA Support Indicator	C	C(=)		
Super-Charger Supported in Serving Network Entity	C	C(=)		
GPRS enhancements support indicator	C	C(=)		
Supported LCS Capability Sets	C	C(=)		
Offered CAMEL 4 CSIs	C	C(=)		
Inform Previous Network Entity	C	C(=)		
PS LCS Not Supported by UE	C	C(=)		
V-GMLC Address	U	C(=)		
Call barring support indicator	C	C(=)		
IMEISV	C	C(=)		
Skip Subscriber Data Update	U	C(=)		
Supported RAT Types Indicator	U	C(=)		
EPS Info	C	C(=)		
Serving Node Type Indicator	C	C(=)		
Supported Features	U	C(=)		
Used RAT Type	U	C(=)		
GPRS Subscription Data not needed Indicator	C	C(=)		
Node-Type-Indicator	U	C(=)		
Area Restricted Indicator	C	C(=)		
UE Reachable Indicator	C	C(=)		
ADD Capability			U	C(=)
SGSN-MME Separation Support Indicator			C	C(=)
HLR number			C	C(=)
User error			C	C(=)
Provider error				O

8.1.7.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

SGSN number

See definition in clause 7.6.2.

In an EPS, this parameter is populated with an IWF number if received from an IWF.

SGSN address

See definition in clause 7.6.2.

In an EPS, this parameter is populated with an IWF address if received from an IWF.

Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. The SGSN can only support CAMEL phase 3 or greater.

SoLSA Support Indicator

This parameter is used by the SGSN to indicate to the HLR in the Update GPRS Location indication that SoLSA is supported. If this parameter is not included in the Update GPRS Location indication and the Subscriber is marked as only allowed to roam in Subscribed LSAs, then the HLR shall reject the roaming and indicate to the SGSN that roaming is not allowed to that Subscriber in the SGSN.

This SoLSA Support Indicator shall be stored by the HLR per SGSN where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a SGSN and no SoLSA Support indicator is stored for that SGSN, the location status of that Subscriber has to be set to Restricted.

Super-Charger Supported in Serving Network Entity

This parameter is used by the SGSN to indicate to the HLR that the SGSN supports the Super-Charger functionality and whether subscription data has been retained by the SGSN. If subscription data has been retained by the SGSN the age indicator shall be included. Otherwise the SGSN shall indicate that subscriber data is required.

If this parameter is absent then the SGSN does not support the Super-Charger functionality.

GPRS enhancements support indicator

This parameter is used by the SGSN to indicate to the HLR in the Update GPRS Location indication that GPRS enhancements are supported. If this parameter is included in the Update GPRS Location indication the HLR may send the extension QoS parameter in the PDP contexts to the SGSN. The HLR may send the extension-2 QoS and the extension-3 QoS parameters with the extension QoS parameter.

HLR number

See definition in clause 7.6.2. The presence of this parameter is mandatory in case of successful HLR updating.

Supported LCS Capability Sets

This parameter indicates, if present, the capability sets of LCS which are supported. If the parameter is sent but no capability set is marked as supported then the SGSN does not support LCS at all.

The SGSN is not allowed to indicate support for LCS capability set 1.

If this parameter is absent then the SGSN does not support LCS at all.

Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the SGSN (see clause 7.6.3.36D).

Inform Previous Network Entity

This parameter is used by the SGSN to ask the HLR to inform the previous network entity about the update by sending the previous network entity a Cancel Location message. It is used in case Super-Charger is supported in the network and the serving network entity has not been able to inform the previous network entity that MS has moved, that is if it has not sent SGSN Context Request to the previous serving entity.

PS LCS Not Supported by UE

See definition in clause 7.6.11.

V-GMLC address

See definition in clause 7.6.2.

Call Barring support indicator

See definition in clause 7.6.3.92.

IMEISV

For definition of the parameter see clause 7.6.2. For the use of this parameter see 3GPP TS 23.060. IMEISV shall be present if ADD function is supported and the IMEISV is new in SGSN (The functional requirements for the presence of IMEISV due to ADD are described in 3GPP TS 22.101 clause 7.4).

Skip Subscriber Data Update

The presence of the parameter is optional and if present it indicates that subscriber data download during the updateGprsLocation procedure may be skipped by the HLR e.g. because the service is solely used to inform the HLR about change of IMEISV. The parameter is used to optimise signalling load during Location Update procedure.

Supported RAT Types Indicator

This parameter indicates, if present, which access technologies (e.g. GERAN and/or UTRAN and/or E-UTRAN) are served by the SGSN or MME (see clause 7.6.3)

EPS Info

This parameter may indicate that the MME or SGSN has selected a new PDN GW for an APN. If so, the HSS shall skip subscriber data update (insert subscriber data) and only note the new PDN GW.

Otherwise this parameter may indicate the appropriate ISR instruction to be performed by the HSS which is one or more of

a) Update MME; i.e. send CancelLocation to the old MME and replace the stored MME id;

b) Cancel SGSN; i.e. send CancelLocation to the SGSN and delete the stored SGSN id.

c) Initial Attach; i.e. send CancelLocation to the MME (if Serving Node Type Indicator is absent) or to the SGSN (if Serving Node Type Indicator is present) with cancellation type set to "initial attach procedure"

Serving Node Type Indicator

This parameter indicates by its presence that the subscriber's serving node is an MME (which is either stand alone or combined with an SGSN) and it indicates by its absence that the subscriber's serving node is an SGSN (which is either stand alone or combined with an MME).

Supported Features

This parameter shall be used by an IWF to forward feature support indications as received from the MME or SGSN via S6a/S6d.

Used RAT Type

This parameter may indicate the RAT type currently used by the serving node.

GPRS Subscription Data not needed Indicator

This parameter indicates by its presence that the SGSN (or MME/IWF) does not request GPRS Subscription Data in addition to EPS Subscription Data.

Node-Type Indicator

This parameter indicates by its presence that the requesting node is a combined MME/SGSN. Absence of this Indicator indicates that the requesting node is a single MME or SGSN.

When Node-Type Indicator is absent and Serving Node Type Indicator is present, the HSS may skip checking SMS/LCS supported features and skip the download of SMS/LCS-related subscription data to a standalone MME.

Area Restricted Indicator

This parameter indicates by its presence that the network node area is restricted due to regional subscription. This parameter is used by the IWF only.

UE-Reachable Indicator

This parameter indicates by its presence that the UE is reachable. This parameter is used by the IWF only.

ADD Capability

This parameter indicates, if present, the support of ADD function by the HLR.

SGSN-MME Separation Support Indicator

This parameter indicates by its presence that the HSS separately stores SGSN Id and MME Id. A combined MME/SGSN shall not send Update-GPRS-Location at intra node inter RAT routing area update if a Separation Indicator was not received previously.

User error

In case of unsuccessful updating, an error cause shall be returned by the HLR. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- roaming not allowed.

  This cause will be sent if the MS is not allowed to roam into the PLMN indicated by the SGSN number. The cause is qualified by the roaming restriction reason "PLMN Not Allowed", "Supported RAT Types Not Allowed" or "Operator Determined Barring".
- system failure;
- unexpected data value.

The diagnostic in the Unknown Subscriber may indicate 'Imsi Unknown' or 'Gprs or EPS Subscription Unknown'.

Provider error

For definition of provider errors see clause 7.6.1.

8.1.8 MAP-NOTE-MM-EVENT

8.1.8.1 Definition

This service is used between the VLR and the gsmSCF or between the SGSN and the gsmSCF when a mobility management event for a subscriber has been processed successfully, that subscriber is provisioned with M-CSI or MG-CSI and the relevant mobility management event is marked for reporting.

This service is also used between the VLR and the Presence Network Agent or between the SGSN and the Presence Network Agent to notify the Presence Network Agent when a mobility management event for a subscriber has been processed successfully, that subscriber is provisioned with M-CSI or MG-CSI and the relevant mobility management event is marked for reporting (see 3GPP TS 23.141 [128]).

8.1.8.2 Service primitives

The service primitives are shown in table 8.1/8.

Table 8.1/8: MAP_NOTE_MM_EVENT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Event Met	M	M(=)		
Service Key	M	M(=)		
IMSI	M	M(=)		
Basic MSISDN	M	M(=)		
Location Information for GPRS	C	C(=)		
Location Information	C	C(=)		
LSA Identity	C	C(=)		
Supported CAMEL Phases	M	M(=)		
Offered CAMEL 4 Functionalities	C	C(=)		
User error			C	C(=)
Provider error				O

8.1.8.3 Parameter use

Event Met
This parameter indicates the mobility management event that has lead to the notification. It shall have one of the following values for a mobility management event reported by the VLR:

- Location update in the same VLR service area;
- Location update to another VLR service area;
- IMSI attach;
- MS initiated IMSI detach (explicit detach);
- Network initiated IMSI detach (implicit detach).

It shall have one of the following values for a mobility management event reported by the SGSN:

- Routeing area update in the same SGSN service area;
- Routeing area update to another SGSN service area;
- GPRS attach;
- MS initiated GPRS detach;
- Network initiated GPRS detach;
- Network initiated transfer to the "not reachable for paging" state.

Service Key

See clause 7.6.x.

IMSI

See clause 7.6.x.

Basic MSISDN

See clause 7.6.x.

Location Information

See clause 7.6.2.30. This information shall be sent when the event is reported by a VLR, if available.

Location Information for GPRS

See clause 7.6.2.30a. This information shall be sent when the event is reported by an SGSN, if available.

LSA Identity

See clause 7.6.x. This information shall be sent, if available.

Supported CAMEL Phases

See clause 7.6.x. This information shall always be sent.

Offered CAMEL 4 Functionalities

This parameter indicates the CAMEL phase 4 functionalities offered by the sending entity, VMSC/VLR or SGSN (see clause 7.6.3.36G).

User error

This parameter is sent by the receiving entity when an error is detected. It shall have one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber;
- MM-EventNotSupported.

Provider error

This is defined in clause 7.6.1.

8.2 Paging and search

8.2.1 MAP_PAGE service

8.2.1.1 Definition

This service is used between VLR and MSC to initiate paging of an MS for mobile terminated short message or unstructured SS notification.

The MAP_PAGE service is a confirmed service using the primitives from table 8.2/1.

8.2.1.2 Service primitives

Table 8.2/1: MAP_PAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Stored location area Id	M	M(=)		
TMSI	U	C(=)		
User error			C	C(=)
Provider error				O

8.2.1.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2. The IMSI is used to define the paging subgroup. If the TMSI is not supplied, paging on the radio path uses the IMSI as an identifier.

Stored location area Id

See definition in clause 7.6.2.

TMSI

See definition in clause 7.6.2. The TMSI is included if paging on the radio channel is to use the TMSI as an identifier.

User error

The following error causes defined in clause 7.6.1 may be sent by the user in case of a paging error, depending on the failure reason:

- absent subscriber;
- unknown location area;
- busy subscriber;
- system failure;
- this corresponds to the case where there is no call associated with the MAP_PAGE service, i.e. if the call has been released but the dialogue to the VLR has not been aborted;
- unexpected data value.

Provider error

See definition in clause 7.6.1.

8.2.2 MAP_SEARCH_FOR_MS service

8.2.2.1 Definition

This service is used between VLR and MSC to initiate paging of an MS in all location areas of that VLR. It is used if the VLR does not hold location area information confirmed by radio contact.

The MAP_SEARCH_FOR_MS service is a confirmed service using the primitives from table 8.2/2.

8.2.2.2 Service primitives

Table 8.2/2: MAP_SEARCH_FOR_MS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Current location area Id			C	C(=)
User error			C	C(=)
Provider error				O

8.2.2.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2. The IMSI is used to identify the subscriber when paging on the radio path.

Current location area Id

See definition in clause 7.6.2. In case of successful outcome of the service, i.e. if the MS responds to paging, the Location Area Id of the area in which the MS responded is given in the response.

User error

The following error causes defined in clause 7.6.1 shall be sent by the user if the search procedure fails, depending on the failure reason:

- absent subscriber;

  this error cause is returned by the MSC if the MS does not respond to the paging request;

- system failure;

- this corresponds to the case where there is no call associated with the MAP_SEARCH_FOR_MS service, i.e. if the call has been released but the dialogue to the VLR has not been aborted;

- busy subscriber;

- unexpected data value.

Provider error

See definition in clause 7.6.1.

8.3 Access management services

8.3.1 MAP_PROCESS_ACCESS_REQUEST service

8.3.1.1 Definition

This service is used between MSC and VLR to initiate processing of an MS access to the network, e.g. for mobile originated short message submission or after being paged by the network.

The MAP_PROCESS_ACCESS_REQUEST service is a confirmed service using the primitives from table 8.3/1.

8.3.1.2 Service primitives

Table 8.3/1: MAP_PROCESS_ACCESS_REQUEST

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
CM service type	M	M(=)		
Access connection status	M	M(=)		
Current Location Area Id	M	M(=)		
Serving cell Id	M	M(=)		
TMSI	C	C(=)		
Cksn	C	C(=)		
IMSI	C	C(=)	C	C(=)
IMEI	C	C(=)	C	C(=)
MSISDN			U	C(=)

User error			C	C(=)
Provider error				O

8.3.1.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

CM service type

See definition in clause 7.6.9.

Access connection status

See definition in clause 7.6.9.

Current Location Area Id

See definition in clause 7.6.2. This parameter is used to update the VLR in case of previous VLR failure.

Serving cell Id

See definition in clause 7.6.2.

TMSI

See definition in clause 7.6.2. Either TMSI or IMSI as received from the MS are included in the Request/Indication, but one shall be present. In case of CM Service Type "Emergency Call Establishment", the IMEI may replace IMSI/TMSI.

Cksn

See definition in clause 7.6.7. In case of access with TMSI, the Cksn shall be present.

IMSI

See definition in clause 7.6.2. Either TMSI or IMSI as received from the MS are included in the Request/Indication, but one shall be present. In case of CM Service Type "Emergency Call Establishment", the IMEI may replace IMSI/TMSI.

In the Response/Confirmation, the IMSI is to be sent in case of successful outcome of the service. In case of CM Service Type "Emergency Call Establishment", IMEI may replace IMSI.

IMEI

See definition in clause 7.6.2. The IMEI may replace IMSI/TMSI in the Request/Indication and IMSI in the Response/Confirmation only in case the CM Service Type indicates "Emergency Call Establishment".

MSISDN

See definition in clause 7.6.2. The MSISDN is included in case of successful outcome of the service as an operator option, e.g. if it is needed at the MSC for charging purposes in case of call forwarding.

User error

One of the following error causes defined in clause 7.6.1 shall be sent by the user if the access request fails, depending on the failure reason:

- unidentified subscriber;
- illegal subscriber;

  this error is sent if a correlated authentication procedure has not authenticated the subscriber;

- illegal equipment;

  this error is sent if an IMEI check failed, i.e. the IMEI is blacklisted or not white-listed;

- roaming not allowed;
- this cause is used after VLR restart if the subscriber has no subscription for the current location area, e.g. due to regional subscription. The cause will be qualified by "location area not allowed" or "national roaming not allowed", respectively;
- unknown location area;
- system failure;
- unexpected data value.

Provider error

For definition of provider errors see clause 7.6.1.

8.4 Handover services

It should be noted that the handover services used on the B-interface have not been updated for Release 99. The B-interface is not fully operational specified. It is strongly recommended not to implement the B-interface as an external interface.

8.4.1 MAP_PREPARE_HANDOVER service

8.4.1.1 Definition

This service is used between MSC-A and MSC-B (E-interface) when a call is to be handed over or relocated from MSC-A to MSC-B.

The MAP_PREPARE_HANDOVER service is a confirmed service using the primitives from table 8.4/1.

8.4.1.2 Service primitives

Table 8.4/1: MAP_PREPARE_HANDOVER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Target Cell Id	C	C(=)		
Target RNC Id	C	C(=)		
HO-NumberNotRequired	C	C(=)		
IMSI	C	C(=)		
Integrity Protection Information	C	C(=)		
Encryption Information	C	C(=)		
Radio Resource Information	C	C(=)		
AN-APDU	C	C(=)	C	C(=)
Allowed GSM Algorithms	C	C(=)		
Allowed UMTS Algorithms	C	C(=)		
Radio Resource List	C	C(=)		
RAB ID	C	C(=)		
GERAN Classmark	C	C(=)		
BSSMAP Service Handover	C	C(=)		
BSSMAP Service Handover List	C	C(=)		
RANAP Service Handover	C	C(=)		
Iu-Currently Used Codec	C	C(=)		
Iu-Supported Codecs List	C	C(=)		
RAB Configuration Indicator	C	C(=)		
ASCI Call Reference	C	C(=)		
UESBI-Iu	C	C(=)		
IMEISV	C	C(=)		
Alternative Channel Type	C	C(=)		
Trace_Propagation_List	C	C(=)		

Handover Number			C	C(=)
Relocation Number List			C	C(=)
Multicall Bearer Information			C	C(=)
Multiple Bearer Requested	C	C(=)		
Multiple Bearer Not Supported			C	C(=)
Selected UMTS Algorithms			C	C(=)
Chosen Radio Resource Information			C	C(=)
Iu-Selected Codec			C	C(=)
Iu-Available Codecs List			C	C(=)
User error			C	C(=)
Provider error				O

8.4.1.3 Parameter use

Invoke Id

For definition of this parameter see clause 7.6.1.

Target Cell Id

For definition of this parameter see clause 7.6.2. This parameter is only included if the service is not in an ongoing transaction. This parameter shall also be excluded if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

Target RNC Id

For definition of this parameter see clause 7.6.2. This parameter shall be included if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

HO-Number Not Required

For definition of this parameter see clause 7.6.6.

IMSI

For definition of this parameter see clause 7.6.2. This UMTS parameter shall be included if:

- available and
- if the access network protocol is BSSAP and
- there is an indication that the MS also supports UMTS.

Integrity Protection Information

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the access network protocol is BSSAP.

Encryption Information

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the access network protocol is BSSAP.

Radio Resource Information

For definition of this parameter see clause 7.6.6. This GSM parameter shall be included if the access network protocol is RANAP and there is an indication that the UE also supports GSM. If the parameter Radio Resource List is sent , the parameter Radio Resource Information shall not be sent.

AN-APDU

For definition of this parameter see clause 7.6.9.

Allowed GSM Algorithms

For definition of this parameter see clause 7.6.6. This parameters includes allowed GSM algorithms. This GSM parameter shall be included if:

- the service is a part of the Inter-MSC SRNS Relocation procedure and
- Ciphering or Security Mode Setting procedure has been performed.and
- there is an indication that the UE also supports GSM.

Allowed UMTS Algorithms

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if all of the following conditions apply:

- access network protocol is BSSAP and
- Integrity Protection Information and Encryption Information are not available and

Ciphering or Security Mode Setting procedure has been performed.

Radio Resource List

For definition of this parameter see clause 7.6.6. This parameter shall be included if the access network protocol is RANAP and there is an indication that the UE also supports GSM. This parameter shall be sent when MSC-A requests multiple bearers to MSC-B. If the parameter Radio Resource Information is sent , the parameter Radio Resource List shall not be sent.

RAB ID

For definition of this parameter see subclause 7.6.2. This parameter shall be included when MSC-A supports multiple bearers and access network protocol is BSSAP and the RAB ID has a value other than 1.

GERAN Classmark

For definition of this parameter see subclause 7.6.6 This parameter shall be included if available.

BSSMAP Service Handover

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is RANAP. If the parameter BSSMAP Service Handover List is sent, the parameter BSSMAP Service Handover shall not be sent.

BSSMAP Service Handover List

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is RANAP. This parameter shall be sent when MSC-A requests multiple bearers to MSC-B. If the parameter BSSMAP Service Handover is sent, the parameter BSSMAP Service Handover List shall not be sent.

RANAP Service Handover

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is BSSAP.

Iu-Currently Used Codec

For definition of this parameter see subclause 7.6.6. This parameter shall be included if the handover is requested for a speech bearer and the MS is in UMTS or GERAN Iu-mode access. This parameter shall not be included if the Iu-Supported Codecs List is not included.

Iu-Supported Codecs List

For definition of this parameter see subclause 7.6.6. This parameter shall be included by MSC-A, if the handover is requested for a speech bearer.

RAB Configuration Indicator

For definition of this parameter see subclause 7.6.6. This parameter may be included if the handover is requested for a speech bearer and MSC-A knows by means of configuration information that MSC-B supports the use of the Iu-Supported Codecs List parameter. This parameter shall not be included if the Iu-Supported Codecs List is not included.

ASCI Call Reference

This parameter contains either the broadcast call reference or group call reference. It shall be included if a subscriber is undergoing handover during a VGCS or VBS call, where MSC-B already has a Bearer established, so that MSC-B can determine the Group or Broadcast Call to which it shall attach the subscriber, see 3GPP TS 48.008 [49].

UESBI-Iu

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the access network protocol is BSSAP.

IMEISV

For definition of the parameter see clause 7.6.2. This parameter is used for Management based Trace Activation (see 3GPP TS 32.422) and shall be present, if available.

Alternative Channel Type

For definition of this parameter see clause 7.6.6 It shall be present for a SCUDIF call if the access network protocol is BSSAP.

Trace Propagation List

See definition in clause 7.6.10. This parameter shall be included when MSC-A requests trace invocation.

Handover Number

For definition of this parameter see clause 7.6.2. This parameter shall be returned at handover, unless the parameter HO-NumberNotRequired is sent. If the parameter Handover Number is returned, the parameter Relocation Number List shall not be returned.

Relocation Number List

For definition of this parameter see clause 7.6.2. This parameter shall be returned at relocation, unless the parameter HO-NumberNotRequired is sent. If the parameter Relocation Number List is returned, the parameter Handover Number shall not be returned.

Multicall Bearer Information

For a definition of this parameter see clause 7.6.2. This parameter shall be returned at relocation in the case that MSC-B supports multiple bearers.

Multiple Bearer Requested

For a definition of this parameter see clause 7.6.2. This parameter shall be sent when MSC-A requests multiple bearers to MSC-B.

Multiple Bearer Not Supported

For a definition of this parameter see clause 7.6.2. This parameter shall be returned at relocation when MSC-B receives Multiple Bearer Requested parameter and MSC-B does not support multiple bearers.

Selected UMTS Algorithms

For definition of this parameter see clause 7.6.6. This parameters includes the UMTS integrity and optionally encryption algorithms selected by RNC under the control of MSC-B. This UMTS parameter shall be included if the service is a part of the inter MSC inter system handover from GSM to UMTS.

Chosen Radio Resource Information

For definition of this parameter see clause 7.6.6. This parameter shall be returned at relocation if the encapsulated PDU is RANAP RAB Assignment Response and MS is in GSM access.

Iu-Selected Codec

For definition of this parameter see subclause 7.6.6. This parameter shall be included if an Iu-Supported Codecs List was received in the service request and MSC-B supports the selection of codec based on the Iu-Supported Codecs List and the target radio access network is connected to MSC-B via the Iu interface, even if the Iu-Selected Codec is equal to the Iu-Currently Used Codec received in the service request. This parameter shall not be included if the Iu-Supported Codecs List was not received in the service request.

Iu-Available Codecs List

For definition of this parameter see subclause 7.6.6. This parameter shall be included by an MSC-B supporting TrFO, if the Iu-Supported Codecs List was included by MSC-A and the target radio access is UMTS or GERAN Iu-mode.

User error

For definition of this parameter see clause 7.6.1. The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- No handover number available.
- Target cell outside group call area;
- System failure.
- Unexpected data value.
- Data Missing.

Provider error

See definition of provider errors in clause 7.6.1.

8.4.2 MAP_SEND_END_SIGNAL service

8.4.2.1 Definition

This service is used between MSC-B and MSC-A (E-interface) indicating that the radio path has been established by MSC-B to the MS. MSC-A retains then the main control of the call until it clears.

The response is used by MSC-A to inform MSC-B that all resources for the call can be released in MSC-B, either because the call has been released in MSC-A or because the call has been successfully handed over or relocated from MSC-B to another MSC.

The MAP_SEND_END_SIGNAL service is a confirmed service using the primitives from table 8.4/2.

8.4.2.2 Service primitives

Table 8.4/2: MAP_SEND_END_SIGNAL

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
AN-APDU	M	M(=)		
Provider error				O

8.4.2.3 Parameter use

Invoke Id

For definition of this parameter see clause 7.6.1.

AN-APDU

For definition of this parameter see clause 7.6.9.

Provider error

For definition of this parameter see clause 7.6.1.

8.4.3 MAP_PROCESS_ACCESS_SIGNALLING service

8.4.3.1 Definition

This service is used between MSC-B and MSC-A (E-interface) to pass information received on the A-interface or Iu-interface in MSC-B to MSC-A.

The MAP_PROCESS_ACCESS_SIGNALLING service is a non-confirmed service using the primitives from table 8.4/3.

8.4.3.2 Service primitives

Table 8.4/3: MAP_PROCESS_ACCESS_SIGNALLING

Parameter name	Request	Indication
Invoke Id	M	M(=)
AN-APDU	M	M(=)
Selected GSM Algorithm	C	C(=)
Selected UMTS Algorithms	C	C(=)
Chosen Radio Resource Information	C	C(=)
Selected RAB id	C	C(=)
Iu-Selected Codec	C	C(=)
Iu-Available Codecs List	C	C(=)

8.4.3.3 Parameter use

Invoke Id

For definition of this parameter see clause 7.6.1.

AN-APDU

For definition of this parameter see clause 7.6.9.

Selected GSM algorithm

For definition of this parameter see clause 7.6.6. This parameter shall be present if the encapsulated PDU is Security Mode Complete and MS is in GSM access.

Selected UMTS Algorithms

For definition of this parameter see clause 7.6.6. This parameters includes the UMTS integrity and optionally encryption algorithms selected by RNC under the control of MSC-B. This UMTS parameter shall be included if the encapsulated PDU is BSSMAP Cipher Mode Complete and the MS is in UMTS, or an interystem handover to UMTS is performed in MSC-B, or in the case of intra MSC-B intra UMTS relocation.

Chosen Radio Resource Information

For definition of this parameter see clause 7.6.6. This parameter shall be sent if the encapsulated PDU is RANAP RAB Assignment Response and MS is in GSM access.

Selected RAB ID

The selected radio access bearer that was kept at subsequent intra-MSC handover from UMTS to GSM after multiple bearers were used.

Iu-Selected Codec

For definition of this parameter see subclause 7.6.6. This parameter shall be included

- if MSC-B changes the selected codec and the MS is in UMTS or GERAN Iu-mode access;
- if intersystem handover to UMTS or GERAN Iu-mode is performed in MSC-B; or
- if MSC-B received a Forward Access Signalling service request including an Iu-Supported Codecs List and the MS is in UMTS or GERAN Iu-mode access.

This parameter shall not be included if the Iu-Supported Codecs List was not received either in the Prepare Handover service request or in the Forward Access Signalling service request.

Iu-Available Codecs List

For definition of this parameter see subclause 7.6.6. This parameter shall be included by an MSC-B supporting TrFO

- if the Iu-Available Codecs List has changed in MSC-B;
- if intersystem handover to UMTS or GERAN Iu-mode is performed in MSC-B; or
- if MSC-B received a Forward Access Signalling service request including an Iu-Supported Codecs List and the MS is in UMTS or GERAN Iu-mode access.

8.4.4 MAP_FORWARD_ACCESS_SIGNALLING service

8.4.4.1 Definition

This service is used between MSC-A and MSC-B (E-interface) to pass information to be forwarded to the A-interface or Iu-interface of MSC-B.

The MAP_FORWARD_ACCESS_SIGNALLING service is a non-confirmed service using the primitives from table 8.4/4.

8.4.4.2 Service primitives

Table 8.4/4: MAP_FORWARD_ACCESS_SIGNALLING

Parameter name	Request	Indication
Invoke Id	M	M(=)
Integrity Protection Information	C	C(=)
Encryption Information	C	C(=)
Key Status	C	C(=)
AN-APDU	M	M(=)
Allowed GSM Algorithms	C	C(=)
Allowed UMTS Algorithms	C	C(=)
Radio Resource Information	C	C(=)
Radio Resource List	C	C(=)
BSSMAP Service Handover	C	C(=)
BSSMAP Service Handover List	C	C(=)
RANAP Service Handover	C	C(=)
Iu-Currently Used Codec	C	C(=)
Iu-Supported Codecs List	C	C(=)
RAB Configuration Indicator	C	C(=)
Iu-Selected Codec	C	C(=)
Alternative Channel Type	C	C(=)
Trace Propagation List	C	C(=)

8.4.4.3 Parameter use

For the definition and use of all parameters and errors, see clause 7.6.1.

Invoke Id

For definition of this parameter see clause 7.6.1.

Integrity Protection Information

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the encapsulated PDU is BSSMAP Cipher Mode Command.

Encryption Information

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the encapsulated PDU is BSSMAP Cipher Mode Command.

Key Status

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if available and if the encapsulated PDU is BSSMAP Cipher Mode Command.

AN-APDU

For definition of this parameter see clause 7.6.9.

Allowed GSM Algorithms

This parameters includes allowed GSM algorithms. This GSM parameter shall be included if the encapsulated PDU is RANAP Security Mode Command and there is an indication that the UE also supports GSM.

Allowed UMTS Algorithms

For definition of this parameter see clause 7.6.6. This UMTS parameter shall be included if Integrity Protection Information and Encryption Information are not available and the encapsulated PDU is BSSMAP Cipher Mode Command.

Radio Resource Information

For definition of this parameter see clause 7.6.6. This parameter shall be sent if the encapsulated PDU is RANAP RAB Assignment Request. If the parameter Radio Resource List is sent, the parameter Radio Resource Information shall not be sent.

Radio Resource List

For definition of this parameter see clause 7.6.6. This parameter shall be sent if the encapsulated PDU is RANAP RAB Assignment Request and MSC-A requests modification of multiple bearers. If the parameter Radio Resource Information is sent, the parameter Radio Resource List shall not be sent.

BSSMAP Service Handover

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the encapsulated PDU is RANAP RAB Assignment Request. If the parameter BSSMAP Service Handover List is sent, the parameter BSSMAP Service Handover shall not be sent.

BSSMAP Service Handover List

For definition of this parameter see clause 7.6.6. It shall be present if it is available and the encapsulated PDU is RANAP RAB Assignment Request and MSC-A requests modification of multiple bearers. If the parameter BSSMAP Service Handover is sent, the parameter BSSMAP Service Handover List shall not be sent.

RANAP Service Handover

For definition of this parameter see clause 7.6.6.. It shall be present if it is available and the encapsulated PDU is BSSMAP Assignment Request.

Iu-Currently Used Codec

For definition of this parameter see subclause 7.6.6. This parameter shall be included if the encapsulated PDU is a RANAP RAB Assignment Request or BSSMAP Assignment Request for a speech bearer and the MS is in UMTS or GERAN Iu-mode access. This parameter shall not be included if the Iu-Supported Codecs List is not included.

Iu-Supported Codecs List

For definition of this parameter see subclause 7.6.6. This parameter shall be included if the encapsulated PDU is a RANAP RAB Assignment Request or BSSMAP Assignment Request and

- a new bearer is allocated for speech;
- an existing bearer is modified from data to speech; or
- for an existing speech bearer the order of priority in the Iu-Supported Codecs List needs to be modified.

This parameter shall not be included if the Iu-Selected Codec is included.

RAB Configuration Indicator

For definition of this parameter see subclause 7.6.6. This parameter may be included if the encapsulated PDU is a RANAP RAB Assignment Request for a speech bearer, and MSC-A knows by means of configuration information that MSC-B supports the use of the Iu-Supported Codecs List parameter. This parameter shall not be included if the Iu-Supported Codecs List is not included.

Iu-Selected Codec

For definition of this parameter see subclause 7.6.6. This parameter shall be included if

- the encapsulated PDU is a RANAP RAB Assignment Request or BSSMAP Assignment Request for an existing speech bearer; and
- the MS is in UMTS or GERAN Iu-mode access; and
- an Iu-Available Codecs List was received by MSC-A for this speech bearer before, either in the Prepare Handover service response or in the Process Access Signalling service request.

This parameter shall not be included if the Iu-Supported Codecs List is included.

Alternative Channel Type

For definition of this parameter see clause 7.6.6. This parameter shall be present for a SCUDIF call if the encapsulated PDU is BSSMAP Assignment Request.

Trace Propagation List

See definition in clause 7.6.10. This parameter shall be included when MSC-A requests trace invocation.

8.4.5 MAP_PREPARE_SUBSEQUENT_HANDOVER service

8.4.5.1 Definition

This service is used between MSC-B and MSC-A (E-interface) to inform MSC-A that it has been decided that a handover or relocation to either MSC-A or a third MSC (MSC-B') is required.

The MAP_PREPARE_SUBSEQUENT_HANDOVER service is a confirmed service using the primitives from table 8.4/5.

8.4.5.2 Service primitives

Table 8.4/5: MAP_PREPARE_SUBSEQUENT_HANDOVER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Target Cell Id	C	C(=)		
Target RNC Id	C	C(=)		
Target MSC Number	M	M(=)		
Selected RAB ID	C	C(=)		
GERAN Classmark	C	C(=)		
RAB Configuration Indicator	C	C(=)		
AN-APDU	M	M(=)	C	C(=)
User error			C	C(=)
Provider error				O

8.4.5.3 Parameter use

Invoke Id

For definition of this parameter see clause 7.6.1.

Target Cell Id

For definition of this parameter see clause 7.6.2. This parameter shall be excluded if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

Target RNC Id

For definition of this parameter see clause 7.6.2. This parameter shall be included if the service is a part of the Inter-MSC SRNS Relocation procedure or the inter-system handover GSM to UMTS procedure described in 3GPP TS 23.009.

Target MSC Number

For definition of this parameter see clause 7.6.2.

Selected RAB ID

For definition of this parameter see clause 7.6.2.

GERAN Classmark

For definition of this parameter see subclause 7.6.6 This parameter shall be included if available.

RAB Configuration Indicator

For definition of this parameter see subclause 7.6.6. This parameter may be included if the call is a speech call and MSC-B knows by means of configuration information that MSC-B' (and MSC-A) supports the use of the Iu-Supported Codecs List parameter.

AN-APDU

For definition of this parameter see clause 7.6.9.

User error

For definition of this parameter see clause 7.6.1. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown MSC;
- Subsequent handover failure;

- Unexpected data value;
- Data Missing.

Provider error

For definition of this parameter see clause 7.6.1.

8.4.6 MAP_ALLOCATE_HANDOVER_NUMBER service

8.4.6.1 Definition

This service is used between MSC and VLR (B-interface) to request a handover number.

The MAP_ALLOCATE_HANDOVER_NUMBER service is a confirmed service using the primitives from table 8.4/6.

8.4.6.2 Service primitives

Table 8.4/6: MAP_ALLOCATE_HANDOVER_NUMBER

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
User error			C	C(=)
Provider error				O

8.4.6.3 Parameter use

Invoke Id

For definition of this parameter see clause 7.6.1.

User error

For definition of this parameter see clause 7.6.1. The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- No handover number available.

Provider error

For definition of this parameter see clause 7.6.1.

8.4.7 MAP_SEND_HANDOVER_REPORT service

8.4.7.1 Definition

This service is used between VLR and MSC-B (B-interface) to transfer the handover number to be forwarded to and used by MSC-A.

The MAP_SEND_HANDOVER_REPORT service is a confirmed service using the primitives from table 8.4/7.

8.4.7.2 Service primitives

Table 8.4/7: MAP_SEND_HANDOVER_REPORT

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Handover Number	M	M(=)		
Linked Id	M	M(=)		
Provider error				O

8.4.7.3 Parameter use

Invoke Id

For definition of this parameter see clause 7.6.1.

Handover Number

For definition of this parameter see clause 7.6.2.

Linked Id

For definition of this parameter see clause 7.6.1. This service is linked with MAP_ALLOCATE_HANDOVER_NUMBER.

Provider error

For definition of this parameter see clause 7.6.1.

8.5 Authentication management services

8.5.1 MAP_AUTHENTICATE service

The MAP_AUTHENTICATE service is used on the MAP B interface. This interface is not fully operational specified. It is strongly recommended not to implement the B-interface as an external interface.

8.5.1.1 Definition

This service is used between the VLR and the MSC when the VLR receives a MAP service indication from the MSC concerning a location registration, call set-up, operation on a supplementary service or a request from the MSC to initiate authentication.

The service is a confirmed service and consists of four service primitives.

8.5.1.2 Service primitives

The service primitives are shown in table 8.5/1.

Table 8.5/1: MAP_AUTHENTICATE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
RAND	M	M(=)		
CKSN	M	M(=)		
SRES			M	M(=)
Provider error				O

8.5.1.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

RAND

See clause 7.6.7 for the use of this parameter.

CKSN

See clause 7.6.7 for the use of this parameter.

SRES

See clause 7.6.7 for the use of this parameter.

Provider error

See clause 7.6.1 for the use of this parameter.

8.5.2 MAP_SEND_AUTHENTICATION_INFO service

8.5.2.1 Definition

This service is used between the VLR and the HLR for the VLR to retrieve authentication information from the HLR. The VLR requests up to five authentication vectors.

Also this service is used between the SGSN and the HLR for the SGSN to retrieve authentication information from the HLR. The SGSN requests up to five authentication vectors.

Also this service is used between the BSF and the HLR for the BSF to retrieve authentication information from the HLR. The BSF shall only request one authentication vector at a time.

In an EPS, this service is used between IWF and IWF and between IWF and HSS.

If the requesting node type is different from "MME" and the user is a UMTS subscriber, the HLR shall return authentication quintuplets. If the requesting node type is different from MME and the user is a GSM subscriber, the HLR shall return authentication triplets.

If the requesting node type is "MME", the HSS shall return EPS authentication vectors.

If the requesting node type is a combined MME/SGSN, the HSS shall return requested authentication vectors for the actual RAT and may return additional authentication vectors for the other RAT.

If the HLR cannot provide the VLR, the SGSN or the BSF with triplets, an empty response is returned. The VLR, the SGSN, or the BSF may then re-use old authentication triplets, except where this is forbidden under the conditions specified in 3GPP TS 43.020 [24].

If the HLR cannot provide the VLR, the SGSN or the BSF with quintuplets, an empty response is returned. The VLR, the SGSN or the BSF shall not re-use old authentication quintuplets.

If the HSS cannot provide the IWF with EPS authentication vectors, an empty response is returned.

If the VLR or SGSN or IWF or BSF receives a MAP_SEND_AUTHENTICATION_INFO response containing a User Error parameter as part of the handling of an authentication procedure, the authentication procedure in the VLR or SGSN or MME or BSF shall fail.

Security related network functions are further described in 3GPP TS 43.020 [24] and 3GPP TS 33.200.

The service is a confirmed service and consists of four service primitives.

8.5.2.2 Service primitives

The service primitives are shown in table 8.5/2.

Table 8.5/2: MAP_SEND_AUTHENTICATION_INFO parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Number of requested vectors	C	C(=)		
Requesting node type	C	C(=)		
Re-synchronisation Info	C	C(=)		
Segmentation prohibited indicator	C	C (=)		
Immediate response preferred indicator	U	C (=)		
Requesting PLMN ID	C	C(=)		
Number of additional requested vectors	C	C(=)		
Additional requested Vectors are for EPS	C	C(=)		
AuthenticationSetList			C	C(=)
User error			C	C(=)
Provider error				O

8.5.2.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

IMSI

See clause 7.6.2 for the use of this parameter.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

Number of requested vectors

A number indicating how many authentication vectors the VLR, the SGSN, the MME or the BSF is prepared to receive. The HLR shall not return more vectors than indicated by this parameter.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

Requesting node type

The type of the requesting node (SGSN, MME, combined MME/SGSN, VLR, or BSF).

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

Re-synchronisation Info

For definition and use of this parameter see 3GPP TS 33.200.

If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one..

Segmentation prohibited indicator

This parameter indicates if the VLR, the SGSN or the IWF allows segmentation of the response at MAP user level.

This parameter may be present only in the first request of the dialogue.

Immediate response preferred indicator

This parameter indicates that one of the requested authentication vectors is requested for immediate use in the VLR, the SGSN, the MME or the BSF. It may be used by the HLR together with the number of requested vectors and the number of vectors stored in the HLR to determine the number of vectors to be obtained from the AuC. It shall be ignored if the number of available vectors is greater than the number of requested vectors.

If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

Requesting PLMN ID

The PLMN-ID of the requesting node. See3GPP TS 23.003.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

Number of additional requested vectors

A number indicating how many additional authentication vectors the combined MME/SGSN or IWF is prepared to receive. The HLR shall not return more vectors than indicated by this parameter. This parameter shall be present only if the requesting node type is a combined MME/SGSN. A combined MME/SGSN that wants to request only EPS-Vectors (only non-EPS-Vectors) shall set the requesting node type to "MME" ("SGSN").

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

Additional vectors are for EPS

This parameter shall be absent if Number of additional vectors is absent. The parameter indicates by its presence that additional vectors (i.e. not for immediate use) are for EPS.

This parameter shall be present in the first (or only) request of the dialogue. If multiple service requests are present in a dialogue then this parameter shall not be present in any service request other than the first one.

AuthenticationSetList

A set of one to five authentication vectors are transferred from the HLR to the VLR, from the HLR to the SGSN or IWF or from the HLR to the BSF, if the outcome of the service was successful.

User error

One of the following error causes defined in clause 7.6.1 shall be sent by the user in case of unsuccessful outcome of the service, depending on the respective failure reason:

- unknown subscriber;
- unexpected data value;
- system failure;
- data missing.

Provider error

See clause 7.6.1 for the use of this parameter.

8.5.3 MAP_AUTHENTICATION_FAILURE_REPORT service

8.5.3.1 Definition

This service is used between the VLR and the HLR or between the SGSN or HLR for reporting of authentication failures.

8.5.3.2 Service primitives

The service primitives are shown in table 8.5/3.

Table 8.5/3: MAP_AUTHENTICATION_FAILURE_REPORT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Failure cause	M	M(=)		
Re-attempt	M	M(=)		
Access Type	M	M(=)		
Rand	M	M(=)		
VLR number	C	C(=)		
SGSN number	C	C(=)		
User error			C	C(=)
Provider error				O

8.5.3.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

IMSI

See clause 7.6.2 for the use of this parameter.

Failure Cause

See clause 7.6.7 for use of this parameter.

Re-attempt

See clause 7.6.7 for use of this parameter.

Access Type

See clause 7.6.7 for use of this parameter.

Rand

This parameter identifies the specific AV that failed authentication.

See clause 7.6.7 for use of this parameter.

VLR number

Shall be present if the sender is VLR. See definition in clause 7.6.2.

SGSN number

Shall be present if the sender is SGSN. See definition in clause 7.6.2.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- Unknown Subscriber;
- System Failure;
- Unexpected Data Value.

Provider error

These are defined in clause 7.6.

8.6 Security management services

8.6.1 MAP_SET_CIPHERING_MODE service

8.6.1.1 Definitions

This service is used between the VLR and the MSC to set the ciphering mode and to start ciphering if applicable. It is called when another service requires that information is to be sent on the radio path in encrypted form.

The service is a non-confirmed service and consists of two service primitives.

8.6.1.2 Service primitives

The service primitives are shown in table 8.6/1.

Table 8.6/1: MAP_SET_CIPHERING_MODE parameters

Parameter name	Request	Indication
Invoke id	M	M(=)
Ciphering mode	M	M(=)
Kc	C	C(=)

8.6.1.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

Ciphering mode

See clause 7.6.7 for the use of this parameter.

Kc

The Kc parameter should be included when the ciphering mode parameter indicates that ciphering must be performed.

8.7 International mobile equipment identities management services

8.7.1 MAP_CHECK_IMEI service

8.7.1.1 Definition

This service is used between the VLR and the MSC, between the MSC and the EIR, between the SGSN and EIR, and between IWF and EIR to request check of IMEI. If the IMEI is not available in the MSC or in the SGSN, it is requested from the MS and transferred to the EIR in the service request.

This service may also be used to request the BMUEF from the EIR.

The service is a confirmed service and consists of four service primitives.

8.7.1.2 Service primitives

The service primitives are shown in table 8.7/1.

Table 8.7/1: MAP_CHECK_IMEI parameters

Parameter name	Request	Indication	Response	Confirm

Invoke id	M	M(=)	M(=)	M(=)
IMEI	C	C(=)	C	C(=)
IMEISV	C	C(=)	C(=)	C(=)
Requested Equipment Info	M	M(=)		
Equipment status			C	C(=)
BMUEF			C	C(=)
User error			C	C(=)
Provider error				O

8.7.1.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

Requested Equipment Info

This parameter indicates whether Equipment Status or BMUEF or both is requested.

IMEI

See clause 7.6.2 for the use of this parameter. The parameter shall not be included in the service request between the VLR and the MSC, but one of IMEI and IMEISV is mandatory in the service request from the MSC to the EIR, from the SGSN to the EIR and from the IWF to the EIR. It is not included in the service response from the EIR to the MSC, the SGSN or the IWF, but one of IMEI and IMEISV is mandatory in the service response from the MSC to the VLR on successful outcome.

IMEISV

See clause 7.6.2 for the use of this parameter. IMEISV shall be present if BMUEF is requested.

Equipment status

See clause 7.6.3 for the use of this parameter. This parameter is sent by the responder in case of successful outcome of the service if Equipment status was requested.

BMUEF

See clause 7.6.4 for the use of this parameter. This parameter is sent by the responder in case of successful outcome of the service if BMUEF was requested.

User error

One of the following error causes defined in clause 7.6.1 shall be sent by the user in case of unsuccessful outcome of the service, depending on the respective failure reason:

- unknown equipment;

  this error is returned by the responder when the IMEI is not known in the EIR;

- system failure;

- unexpected data value.

Provider error

See clause 7.6.1 for the use of this parameter.

8.7.2 MAP_OBTAIN_IMEI service

8.7.2.1 Definition

This service is used between the VLR and the MSC to request the IMEI. If the IMEI is not available in the MSC, it is requested from the MS.

The service is a confirmed service and consists of four service primitives.

8.7.2.2 Service primitives

The service primitives are shown in table 8.7/2.

Table 8.7/2: MAP_OBTAIN_IMEI parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMEI			C	C(=)
User error			C	C(=)
Provider error				O

8.7.2.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

IMEI

See clause 7.6.2 for the use of this parameter. The parameter is included in the service response from the MSC to the VLR on successful outcome of the service.

User error

If the service fails, the VLR sends the user error System Failure (see clause 7.6.1) to the MSC.

Provider error

See clause 7.6.1 for the use of this parameter.

8.8 Subscriber management services

8.8.1 MAP-INSERT-SUBSCRIBER-DATA service

8.8.1.1 Definition

This service is used by an HLR to update a VLR with certain subscriber data in the following occasions:

- the operator has changed the subscription of one or more supplementary services, basic services or data of a subscriber. Note that in case of withdrawal of a Basic or Supplementary service this primitive shall not be used;
- the operator has applied, changed or removed Operator Determined Barring;
- the subscriber has changed data concerning one or more supplementary services by using a subscriber procedure;
- the HLR provides the VLR with subscriber parameters at location updating of a subscriber or at restoration. In this case, this service is used to indicate explicitly that a supplementary service is not provisioned, if the supplementary service specification requires it. The only supplementary services which have this requirement are the CLIR and COLR services. Network access mode is provided only in restoration. If the Super-Charger

functionality is supported the HLR may not need to provide the VLR with subscriber parameters at location updating of a subscriber. See TS 23.116.

Also this service is used by an HLR to update an SGSN with certain subscriber data in the following occasions:

- if the GPRS subscription has changed;
- if the network access mode is changed;
- the operator has applied, changed or removed Operator Determined Barring;
- the subscriber has changed data concerning one or more supplementary services by using a subscriber procedure;
- the HLR provides the SGSN with subscriber parameters at GPRS location updating of a subscriber. If the Super-Charger functionality is supported the HLR may not need to provide the SGSN with subscriber parameters. See 3GPP TS 23.116.

In an EPS, this service is used by an HSS to update an MME via IWF with certain subscriber data in the following occasions:

- the EPS subscription has changed;
- the operator has applied, changed or removed Operator Determined Barring;
- the HSS provides the MME via IWF(MME) with subscriber parameters at EPS location updating of a subscriber unless an explicit indication to skip subscriber data update has been received.

In an EPS, this service is used by an IWF to indicate to the MME via IWF that the HSS has requested to be notified when the UE has become reachable.

It is a confirmed service and consists of the primitives shown in table 8.8/1.

8.8.1.2 Service primitives

Table 8.8/1: MAP-INSERT-SUBSCRIBER-DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
MSISDN	C	C(=)		
Category	C	C(=)		
Subscriber Status	C	C(=)		
Bearer service List	C	C(=)	C	C(=)
Teleservice List	C	C(=)	C	C(=)
Forwarding information List	C	C(=)		
Call barring information List	C	C(=)		
CUG information List	C	C(=)		
SS-Data List	C	C(=)		
eMLPP Subscription Data	C	C(=)		
MC-Subscription Data	C	C(=)		
Operator Determined Barring General data	C	C(=)	C	C(=)
Operator Determined Barring HPLMN data	C	C(=)		
Roaming Restriction Due To Unsupported Feature	C	C(=)		
Regional Subscription Data	C	C(=)		
VLR CAMEL Subscription Info	C	C(=)		
Voice Broadcast Data	C	C(=)		
Voice Group Call Data	C	C(=)		
Network access mode	C	C(=)		
GPRS Subscription Data	C	C(=)		
EPS Subscription Data	C	C(=)		
Roaming Restricted In SGSN/MME Due To Unsupported Feature	C	C(=)		
North American Equal Access preferred Carrier Id List	U	C(=)		
SGSN CAMEL Subscription Info	C	C(=)		

Parameter name	Request	Indication	Response	Confirm
LSA Information	C	C(=)		
IST Alert Timer	C	C(=)		
SS-Code List			C	C(=)
LMU Identifier	C	C(=)		
LCS Information	C	C(=)		
CS Allocation/Retention priority	C	C(=)		
Super-Charger Supported In HLR	C	C(=)		
Subscribed Charging Characteristics	C	C(=)		
Access Restriction Data	C	C(=)		
ICS Indicator	U	C(=)		
CSG Subscription Data	C	C(=)		
UE Reachability Request Indicator	C	C(=)		
Regional Subscription Response			C	C(=)
Supported CAMEL Phases			C	C (=)
Offered CAMEL 4 CSIs			C	C (=)
Supported Features			U	C (=)
User error			U	C(=)
Provider error				O

8.8.1.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

Network access mode

This parameter defines if the subscriber has access to MSC/VLR and/or to SGSN/MME. This parameter is used by SGSN/MME and MSC/VLR. In VLR, the parameter is used only as part of Restore Data Procedure and the parameter is not stored in the VLR. This parameter shall always be sent to the SGSN and viaIWF to the MME as part of the GPRS subscriber data at GPRS/MME location updating. It shall be sent to the SGSN and via IWF to the MME if it is changed as a result of administrative action.

IMSI

It is only included if the service is not used in an ongoing transaction (e.g. location updating). This parameter is used by the VLR and the SGSN and IWF.

MSISDN

It is included either at location updating or when it is changed. The MSISDN sent shall be the basic MSISDN. This parameter is used by the VLR and the SGSN and IWF.

Category

It is included either at location updating or when it is changed. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

Subscriber Status

It is included either at location updating or when it is changed.

To apply, remove or update Operator Determined Barring Categories the Subscriber Status is set to Operator Determined Barring. In this case ODB General Data shall also be present. If the Operator Determined Barring applies and the subscriber is registered in the HPLMN and HPLMN specific Operator Determined Barring applies then ODB HPLMN Specific Data shall also be present.

To remove all Operator Determined Barring Categories the Subscriber Status shall be set to "Service Granted". This parameter is used by the VLR and the SGSN and IWF.

Bearer service List

A list of Extensible Bearer service parameters (Extensible Bearer service is defined in clause 7.6). An Extensible Bearer service parameter must be the code for an individual Bearer service, except in the cases described below.

The codes for the Bearer service groups "allAlternateSpeech-DataCDA" and "allAlternateSpeech-DataCDS" shall, if applicable, be sent from the HLR to the VLR as a pair. The codes for the Bearer service groups "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS" shall, if applicable, be sent from the HLR to the VLR as a pair.

If it is included in the Request/Indication, it includes either all Extensible Bearer services subscribed (at location updating or at restoration) or only the ones added (at subscriber data modification).

If the VLR receives an Indication containing any Extensible Bearer service parameters which it does not support/allocate it returns them in the response to the HLR and discards the unsupported Extensible Bearer services (no error is sent back), except in the cases described below.

If the VLR receives the codes for the Bearer service groups "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS" and supports one or more of the circuit-switched synchronous or asynchronous data rates specified for simple data bearer services, it shall accept the bearer service codes, and not return them in the response to the HLR. If the VLR does not support any of the circuit-switched synchronous or asynchronous data rates specified for simple data bearer services, and receives the pair of codes for "allAlternateSpeech-DataCDA" and "allAlternateSpeech-DataCDS" or the pair of codes for "allSpeechFollowedByDataCDA" and "allSpeechFollowedByDataCDS", it shall reject the pair of codes by returning them in the response to the HLR. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

Teleservice List

A list of Extensible Teleservice parameters (Extensible Teleservice is defined in clause 7.6). An Extensible Teleservice parameter must be the code for an individual Teleservice.

If it is included in the Request/Indication, it contains either all Extensible Teleservices subscribed (at location updating or at restoration) or the ones added (at subscriber data modification). Only the Extensible Teleservices that are relevant to the node at which the message is received should be included in the Teleservice List.

If the VLR or the SGSN or the IWF receives an Indication containing any Extensible Teleservice parameters which it does not support/allocate it returns them in the response to the HLR and discards the unsupported Extensible Teleservices (no error is sent back). This parameter is used by the VLR and the SGSN and the IWF.

Forwarding information List

A list of Extensible Forwarding information parameters (Extensible Forwarding information is defined in clause 7.6). It includes Call Forwarding services either at location updating or at restoration or when they are changed. Each Extensible Forwarding information parameter shall be treated independently of all other parameters in the primitive.

The Extensible Forwarding information shall include the SS-Code for an individual call forwarding supplementary service. The Extensible Forwarding information shall contain one or more Extensible Forwarding Features (Extensible Forwarding Feature is defined in clause 7.6).

The Extensible Forwarding Feature may include an Extensible Basic Service Group. This shall be interpreted according to the rules in clause 8.8.1.4.

The Extensible Forwarding Feature shall contain an Extensible SS-Status parameter.

If the Extensible SS-Status indicates that call forwarding is registered then (except for call forwarding unconditional) the Extensible Forwarding Feature shall contain a number to define the forwarded-to destination and, if available, the forwarded-to subaddress. In other states the forwarded-to number and, if applicable, the forwarded-to subaddress shall not be included. For call forwarding unconditional the forwarded-to number and, if applicable, the forwarded-to subaddress shall not be included. If the VLR does not receive a forwarded-to subaddress then it shall assume that a forwarded-to subaddress has not been registered.

The Extensible Forwarding Feature shall contain the extensible forwarding options (except for call forwarding unconditional where the extensible forwarding options shall not be included). Bits 3 and 4 of the extensible forwarding options shall be ignored by the VLR, and may be set to any value by the HLR.

For call forwarding on no reply: If the extensible SS-Status indicates that call forwarding is registered then the Extensible Forwarding Feature shall contain an extensible no reply condition timer. In other states the no reply condition timer shall not be included.

For call forwarding services other than call forwarding on no reply: The Extensible Forwarding Feature shall not contain a no reply condition timer.

If the VLR receives an Indication containing any Call Forwarding service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and discards the unsupported Call Forwarding service codes (no error is sent back). This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

Call barring information List

A list of Extensible Call barring information parameters (Extensible Call barring information is defined in clause 7.6). It includes Call Barring services either at location updating or at restoration or when they are changed. Each Extensible Call barring information parameter shall be treated independently of all other parameters in the primitive.

The Extensible Call barring information shall include the SS-Code for an individual call barring supplementary service. The Extensible Call barring information shall contain one or more Extensible Call Barring Features (Extensible Call Barring Feature is defined in clause 7.6).

The Extensible Call Barring Feature may include an Extensible Basic Service Group. This shall be interpreted according to the rules in clause 8.8.1.4.

The Extensible Call Barring Feature shall contain an extensible SS-Status parameter.

If the VLR or the SGSN or the IWF receives an Indication containing any Extensible Call Barring service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and discards the unsupported Extensible Call Barring service codes (no error is sent back).

CUG information List

A list of CUG information list parameters (CUG information is defined in clause 7.6). It includes CUG information either at location updating or at restoration or when it is changed.

At location updating, restoration or when there is a change in CUG data, the HLR shall include the complete CUG-SubscriptionList and, if there are options per basic group, it shall also include the complete CUG-FeatureList. If there are not options per extensible basic service group the CUG-FeatureList shall not be included.

In any dialogue, the first insertSubscriberData message which contains CUG information shall include a non-empty CUG-SubscriptionList.

When the VLR receives CUG data it shall replace the stored CUG data with the received data set.

If CUG-FeatureList is omitted in the Insert Subscriber Data operation VLR shall interpret that no options per extensible basic service group exist, and then it shall apply the default values i.e. no outgoing access, no incoming access, no preferential CUG exists.

If CUG-Feature is received without preferential CUG, the VLR shall interpret that no preferential CUG applies.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value.

Note that data consistency between CUG subscription data and CUG feature data is the responsibility of the HLR.

If the VLR does not support the CUG service it returns its code to the HLR in the parameter SS-Code List and discards the received information (no error is sent back). This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

SS-Data List

A list of Extensible SS-Data parameters (Extensible SS-Data is defined in clause 7.6). It is sent for any other supplementary service than Call Forwarding, Call Barring, CUG and eMLPP either at location updating or at restoration or when they are changed. Each SS-Data parameter shall be treated independently of all other parameters in the primitive.

The Extensible SS-Data shall include the SS-Code for an individual supplementary service.

The Extensible SS-Data shall contain an Extensible SS-Status parameter and any subscription options that are applicable to the service defined by the SS-Code.

The SS-Data may include a Basic Service Group List. This shall be interpreted according to the rules in clause 8.8.1.4.

If the VLR receives an Indication containing any supplementary service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and therefore discards the unsupported service codes received (no error is sent back).

This parameter is used by the SGSN only for LCS. If the SGSN receives an Indication containing any LCS related supplementary service codes which it does not support/allocate it returns them to the HLR in the parameter SS-Code List and therefore discards the unsupported service codes received (no error is sent back). SS-codes not related to the supported LCS capability set shall be discarded.

If the IWF receives an Indication containing any LCS related supplementary service codes, it returns them to the HSS in the parameter SS-Code List and therefore discards the service codes received (no error is sent back). SS-codes not related to the supported LCS capability set shall be discarded.

Operator Determined Barring General data

If it is included in a Request/Indication, it includes all the Operator Determined Barring categories that may be applied to a subscriber registered in any PLMN. This parameter is only included in a Request/Indication when the parameter Subscriber Status is set to the value Operator Determined Barring. Note that all General Operator Determined Barring Categories shall be set to their actual status.

If the VLR or the SGSN or IWF receives an Indication containing Operator Determined Barring General Data which shows that the subscriber is subject to barring not supported / not allocated by the VLR or by the SGSN, it returns Operator Determined Barring General Data in the response to the HLR to show the barring categories which are not supported / not allocated by the VLR or by the SGSN. This parameter is used by the VLR and the SGSN and IWF.

Operator Determined Barring HPLMN data

It includes all the Operator Determined Barring categories that may be applied only to a subscriber registered in the HPLMN. Therefore, it shall only be transferred to the VLR or to the SGSN or IWF when the subscriber is roaming into the HPLMN and when the parameter Subscriber Status is set to the value Operator Determined Barring. Note that all HPLMN Operator Determined Barring Categories shall be set to their actual status.

If Subscriber Status is set to the value Operator Determined Barring and no Operator Determined Barring HPLMN data is present then the VLR or the SGSN or IWF shall not apply any HPLMN specific ODB services to the subscriber. This parameter is used by the VLR and the SGSN and IWF.

eMLPP Subscription Data

If included in the Insert Subscriber Data request this parameter defines the priorities the subscriber might apply for a call (as defined in clause 7.6). It contains both subparameters of eMLPP.

If the VLR does not support the eMLPP service it returns its code to the HLR in the parameter SS-Code List and therefore discards the received information (no error is sent back).

eMLPP subscription data that have been stored previously in a subscriber data record in the VLR are completely replaced by the new eMLPP subscription data received in a MAP_INSERT_SUBSCRIBER_DATA during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

MC Subscription Data

If included in the Insert Subscriber Data request, this parameter provides the MC Subscription Data as defined in clause 7.6.

If the VLR does not support the MC service, it returns its code to the HLR in the parameter SS-Code List and therefore discards the received information (no error is sent back).

MC subscription data that have been stored previously in a subscriber data record in the VLR are completely replaced by the new MC subscription data received in a MAP_INSERT_SUBSCRIBER_DATA during either an Update

Location or Restore Data procedure or a stand alone Insert Subscriber data procedure. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

Roaming Restriction Due To Unsupported Feature

The HLR may decide to include this parameter in the request if certain services or features are indicated as not supported by the MSC/VLR (e.g. Advice of Charge Charging Level).

If this parameter is sent to the VLR the MSC area is restricted by the HLR and the VLR. This parameter is used only by the VLR and if the SGSN or the IWF receives this parameter it shall ignore it.

Regional Subscription Data

If included in the Insert Subscriber Data request this parameter defines the subscriber's subscription area for the addressed VLR, for the addressed SGSN or for the addressed MME (as defined in clause 7.6). It contains the complete list of up to 10 Zone Codes that apply to a subscriber in the currently visited PLMN. The HLR shall send only those Zone Codes which are stored against the CC and NDC of the VLR, the SGSN or the MME to be updated.

NOTE: Support of this parameter is a network operator option and it will not be sent to networks which do not support Regional Subscription.

Regional subscription data that have been stored previously in a subscriber data record in the VLR, in the SGSN or in the MME are completely replaced by the regional subscription data received in an Insert Subscriber Data indication during either an Update Location or Restore Data procedure or a stand alone Insert Subscriber data procedure.

After the regional subscription data are inserted the VLR or the SGSN shall derive whether its location areas are allowed or not. If the whole MSC or SGSN area is restricted it will be reported to HLR by returning the Regional Subscription Response.

The VLR or the SGSN returns a Regional Subscription Response indicating that a problem with the Zone Code has been detected in one of the following cases:

- Too Many Zone Codes: more than 10 Zone Codes are to be stored in the VLR or in the SGSN.
- Regional Subscription Not Supported by the VLR or the SGSN.
- Zone Codes Conflict: the VLR or the SGSN detects that the zone codes indicate conflicting service permission for a location area.

Zone codes which have no mapping to location areas shall be ignored.

If a sequence of MAP_INSERT_SUBSCRIBER_DATA services is used during a dialogue, Regional Subscription Data shall be accepted only in one service. Regional Subscription Data received in a subsequent service shall be rejected with the error Unexpected Data Value.

If Regional Subscription Data are not included in any MAP_INSERT_SUBSCRIBER_DATA service, there is no restriction of roaming due to Regional Subscription. This parameter is used by the VLR, the SGSN and the IWF.

Voice Broadcast Data

This parameter contains a list of group id's a user might have subscribed to; (VBS-Data is defined in clause 7.6). It includes VBS information either at location updating or at restoration or when it is changed.

At location updating, restoration or when there is a change in VBS data, the HLR shall include the complete VBS-Data.

When the VLR receives VBS-Data within a dialogue it shall replace the stored VBS-data with the received data set. All subsequent VBS-data received within this dialogue shall be interpreted as add-on data.

If VBS-data is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VBS data.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN or the IWF receives this parameter it shall ignore it.

Voice Group Call Data

This parameter contains a list of group id's a user might have subscribed to; see clause 7.6.

At location updating, restoration or when there is a change in VGCS data, the HLR shall include the complete VGCS-Data.

When the VLR receives VGCS-Data within a dialogue it shall replace the stored VGCS-Data with the received data set. All VGCS-Data received within this dialogue shall be interpreted as add-on data.

If VBCS-Data is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VGCS-Data.

If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN or the IWF receives this parameter it shall ignore it.

North American Equal Access preferred Carrier Id List

A list of the preferred carrier identity codes that are subscribed to.

When the VLR receives this parameter from the HLR, it shall replace the previously stored preferred carrier identity codes with the received ones. It is not possible to delete all the preferred carrier identity codes from the VLR using this service. To delete all the preferred carrier identity codes from the VLR, the HLR shall use the MAP_CANCEL_LOCATION service.

LSA Information

If included in the ISD request, this parameter contains a list of localised service area identities a user might have subscribed to together with the priority, the preferential access indicator, the active mode support indicator and active mode indication of each localised service area; see clause 7.6. The access right outside these localised service areas is also indicated. In all cases mentioned below, the LSA information shall only include LSA Data applicable to the VPLMN where the Subscriber is located. The VLR number, received in the MAP-UPDATE_LOCATION primitive, or the SGSN number, received in the MAP_UPDATE_GPRS_LOCATION primitive, can be used, alongside data stored in the HLR, to determine the LSA Data applicable to the VPLMN.

At restoration, location updating or GPRS location updating the HLR shall include the complete set of applicable LSA Information.

When there is a change in LSA data the HLR shall include at least the new and/or modified LSA data.

When there is a change in the access right outside the localised service areas the HLR shall include the LSA only access indicator.

When the SGSN or the VLR receives LSA information within a dialogue it shall check if the received data has to be considered as the entire LSA information. If so, it shall replace the stored LSA information with the received data set, otherwise it shall replace the data only for the modified LSA data (if any) and/or access right, and add the new LSA data (if any) to the stored LSA Information.

If the entire LSA information is received, it shall always include the LSA only access indicator value together with the LSA data applicable for the PLMN (if any).

If LSA Information is omitted in the Insert Subscriber Data operation the SGSN or the VLR shall keep the previously stored LSA Information.

If the SGSN or the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used by the VLR and the SGSN, and if the IWF receives this parameter it shall ignore it.

IST Alert Timer

This parameter contains the IST Alert timer value that must be used to inform the HLR about the call activities that the subscriber performs.

At Location Updating, restoration, or when there is a change in the IST data defined for the Subscriber, the HLR shall include the IST Alert timer.

LMU Identifier

This parameter indicates the presence of an LMU. This parameter is used only by the VLR and shall be ignored if received by an SGSN or an IWF.

LCS Information

This parameter provides the following LCS related information for an MS subscriber:

- list of GMLCs in the HPLMN;
- privacy exception list;
- MO-LR list.

At restoration and location updating, the HLR shall include the complete LCS data of the subscriber.

When there is a change in LCS subscriber data the HLR shall include at least the new and/or modified LCS data. LCS data that is not modified need not be included.

The VLR/SGSN shall keep any previously stored LCS Information that is not included in an Insert Subscriber Data operation.

If the VLR/SGSN detects that there is overlapping in the LCS information received within a dialogue, it shall send the error Unexpected Data Value. However, if the VLR receives the LCS code in both the LCS Information and the SS-Data List, then the VLR shall not interpret this as overlapping data. This parameter is used by the VLR and the SGSN and the IWF.

Super-Charger Supported In HLR

This parameter is used by the HLR to indicate support for the Super-Charger functionality. If this parameter is present it shall include an indication of the age of the subscription data stored in the HLR.

If this parameter is absent then the HLR does not support the Super-Charger functionality.

SS-Code List

The list of SS-Code parameters for the services that are provided to a subscriber but are not supported/allocated by the VLR/SGSN/IWF (SS-Code is defined in clause 7.6). The list can only include individual SS-Codes that were sent in the service request. For the VLR, this list can also include SS-Codes for the eMLPP and/or CUG services if the above mentioned conditions, as described in eMLPP Subscription Data and/or CUG information List, are met (that is, eMLPP Subscription Data and/or CUG information List are received).

ICS-Indicator

This optional flag indicates to the MSC Server enhanced for ICS (see 3GPP TS 23.292 [135]) whether the MSC Server shall attempt the IMS registration.

This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

CSG-Subscription Data

This parameter contains a list of CSG-Ids and the associated expiration dates (see 3GPP TS 22.011 [138]). When the VLR or SGSN or MME receives CSG-Subscription Data it shall replace the stored CSG-Subscription Data (if any) with the received data. This parameter is used by the VLR and the SGSN and IWF.

UE Reachability Request Indicator

This parameter indicates by its presence that the HSS is awaiting a Notification of UE Reachability. This parameter is used by the IWF only.

Regional Subscription Response

If included in the response this parameter indicates one of:

- Network Node Area Restricted entirely because of regional subscription;

- Too Many Zone Codes to be inserted;
- Zone Codes Conflict;
- Regional Subscription not Supported by the VLR or by the SGSN or MME.

If the VLR determines after insertion of Regional Subscription Data that the entire MSC area is restricted, the VLR shall respond with a Regional Subscription Response indicating MSC Area Restricted. Otherwise MSC Area Restricted is not sent. The HLR shall check whether the current MSC area is no longer restricted.

If the SGSN determines after insertion of Regional Subscription Data that the entire SGSN area is restricted, the SGSN shall respond with a Regional Subscription Response indicating SGSN Area Restricted. Otherwise SGSN Area Restricted is not sent. The HLR shall check whether the current SGSN area is no longer restricted. This parameter is used by the VLR, the SGSN and the IWF.

VLR CAMEL Subscription Info

This parameter is sent for subscribers who have CAMEL services which are invoked in the MSC.

- In CAMEL phase 1, this parameter contains only the O-CSI.
- In CAMEL Phase 2, this parameter may contain O-CSI, SS-CSI and TIF-CSI. In CAMEL Phase 2 and onwards, TDP-Criteria for O-CSI may be associated with O-CSI.
- In CAMEL Phase 3, this parameter may contain O-CSI, D-CSI, SS-CSI, VT-CSI, MO-SMS-CSI, M-CSI and TIF-CSI. In CAMEL Phase 3 and onwards, TDP-Criteria for VT-CSI may be associated with VT-CSI.
- In CAMEL Phase 4, this parameter may contain O-CSI, D-CSI, SS-CSI, VT-CSI, MO-SMS-CSI, MT-SMS-CSI, M-CSI and TIF-CSI. In CAMEL Phase 4, TDP-Criteria for MT-SMS-CSI may be associated with MT-SMS-CSI.

The VLR CAMEL Subscription Info is sent at location updating or when any information in the applicable CAMEL Subscription Info in the HLR has been changed.

At location updating, the complete set of VLR CAMEL Subscription Info is sent in one dialogue.

When CAMEL Subscription Information is changed in the HLR and changed data have to be sent to the VLR, then:

- for CAMEL Phase 1 and CAMEL Phase 2, the complete set of VLR CAMEL Subscription Info is sent in one dialogue;
- for CAMEL Phase 3 or higher, one or more specific elements of VLR CAMEL Subscription Info are sent in one dialogue.

When the VLR receives a specific element of VLR CAMEL Subscription Info, it shall overwrite the corresponding specific element of VLR CAMEL Subscription Info (if any) which it has stored for that subscriber.

For CAMEL Phase 1 and CAMEL Phase 2 , the VLR CAMEL Subscription Info consists of any one or more of:

- O-CSI (irrespective of the value of the 'CAMEL Capability Handling' inside O-CSI),TDP-Criteria for O-CSI,SS-CSI and TIF-CSI.

  (The complete set of above shall be sent even if only one CSI has changed in case of stand alone ISD. The omitted elements of above list will be withdrawn in the VLR.)

From CAMEL phase 3 onwards, the specific elements of VLR CAMEL Subscription Info which may be sent are:

- O-CSI (irrespective of the value of the 'CAMEL Capability Handling' inside O-CSI), TDP criteria for O-CSI, SS-CSI and TIF-CSI;

  (The complete set of above shall be sent even if only one CSI has changed in case of stand alone ISD. The omitted elements of above list will be withdrawn in the VLR.)

- D-CSI;
- VT-CSI;

- TDP-Criteria for VT-CSI;
- MO-SMS-CSI;
- MT-SMS-CSI;
- TDP-Criteria for MT-SMS-CSI;
- M-CSI.

If the VLR CAMEL Subscription Info is omitted in the Insert Subscriber Data operation the VLR shall keep the previously stored VLR CAMEL Subscription Info. Within one dialogue subsequent received data are interpreted as add-on data. If the VLR detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

The VLR CAMEL Subscription Info may contain the TIF-CSI (Translation Information Flag) for CAMEL Phase 2 and higher. See 3GPP TS 23.072 for the use of this parameter and the conditions for its presence.

Supported CAMEL Phases

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078. This parameter is used by the VLR and SGSN.

A VLR or SGSN not supporting any CAMEL Phase may omit this parameter. An IWF shall omit this parameter.

GPRS Subscription Data

This parameter contains a list of PDP-contexts a user has subscribed to; see clause 7.6.

At GPRS location updating the HLR shall include the complete GPRS Subscription Data.

When there is a change in GPRS subscriber data the HLR shall include only the new and/or modified PDP contexts.

When the SGSN receives GPRS Subscription Data within a dialogue it shall check if the received data has to be considered as the entire GPRS subscription data. If so, it shall replace the stored GPRS Subscription Data with the received data set, otherwise it shall replace the data only for the modified PDP contexts (if any) and add the new PDP contexts (if any) to the stored GPRS Subscription Data.

If GPRS Subscription Data is omitted in the Insert Subscriber Data operation the SGSN shall keep the previously stored GPRS Subscription Data.

If the SGSN detects that there is overlapping in the information received within a dialogue, it shall send the error Unexpected Data Value. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

EPS Subscription Data

This parameter contains:

- the APN-OI Replacement (see 3GPP TS 23.401), and
- the Subscriber Profile ID for RAT/Frequency Priority (RFSP-ID) (see 3GPP TS 23.401 and 3GPP TS 36.413), and
- the AMBR (see 3GPPTS 23.401), and
- a list of APN Configurations,
- a session transfer number for SRVCC (STN-SR) (see 3GPP TS 23.003).

This parameter is used only by the IWF and SGSN supporting S4. If the Gn/Gp-SGSN or VLR receives this parameter it shall ignore it.

SGSN CAMEL Subscription Info

The SGSN CAMEL Subscription Info is sent at GPRS location updating or when any information in the applicable SGSN CAMEL Subscription Info in the HLR has been changed.

- In CAMEL Phase 3, this parameter may contain one or both of GPRS-CSI and MO-SMS-CSI.
- In CAMEL Phase 4, this parameter may contain GPRS-CSI, MO-SMS-CSI and MT-SMS-CSI and TDP-Criteria for MT-SMS-CSI.

At GPRS location updating the complete set of SGSN CAMEL Subscription Info is sent.

When CAMEL Subscription Information is changed in the HLR and changed data have to be sent to the SGSN, then one or more specific elements of SGSN CAMEL Subscription Info are sent in one dialogue.

When the SGSN receives a specific element of SGSN CAMEL Subscription Info, it shall overwrite the corresponding specific element of SGSN CAMEL Subscription Info (if any) which it has stored for that subscriber.

The specific elements of SGSN CAMEL Subscription Info which may be sent are:

- MO-SMS-CSI;
- MT-SMS-CSI;
- TDP-Criteria for MT-SMS-CSI;
- GPRS-CSI;
- MC-CSI.

This parameter is used only by the SGSN and if the VLR or IWF receives this parameter it shall ignore it.

Roaming Restricted In SGSN/MME Due To Unsupported Feature

The HSS/HLR may decide to include this parameter in the request if certain services or features are indicated as not supported by the SGSN/IWF. This parameter is used only by the SGSN and IWFand if the VLR receives this parameter it shall ignore it.

CS Allocation/Retention priority

The CS Allocation/Retention priority is used only for Circuit Switched (CS). This parameter specifies relative importance to compare with other bearers about allocation and retention of bearer. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the VMSC/VLR or SGSN (see clause 7.6.3.36D). An IWF shall omit this parameter.

Subscribed Charging Characteristics

This parameter refers to the Subscribed Charging Characteristics as defined in 3GPP TS 32.251.

For a detailed description of the use of the parameter, see 3GPP TS 32.251.

This parameter is used only by the SGSN and IWF and if the VLR receives this parameter it shall ignore it.

Access Restriction Data

This parameter indicates the allowed RAT according to subscription data. (see clause 7.6.3.96)

If the VLR/SGSN/MME supports the Access Restriction feature but does not receive the Access Restriction Data parameter from the HSS/HLR at location updating or restoration, the VLR/SGSN/MME shall assume that the subscriber's profile does not have any restrictions enabled.

For a detailed description of the use of the parameter, see 3GPP TS 23.012[23] for CS domain and 3GPP TS 23.060[104] for PS domain.

Supported Features

This parameter shall be used by an IWF to forward feature support indications as received from the MME or SGSN via S6a/S6d.

User error

Only one of the following values is applicable:

- Unidentified subscriber;
- Data missing;
- Unexpected data value.

8.8.1.4 Basic service information related to supplementary services

A number of parameters that relate to supplementary services can be qualified by a Basic Service Group (or a Basic Service Group List). This clause explains how this information is to be interpreted. Supplementary service parameters to which this clause is applicable only apply to the basic service groups described in this clause, and only those basic service groups shall be overwritten at the VLR or the SGSN.

The Basic Service Group (or Basic Service Group List) is optional.

If present the Basic Service Group (or each element of the Basic Service Group List) shall be one of:

- an Elementary Basic Service Group for which the supplementary service is applicable to at least one basic service in the group and for which the subscriber has a subscription to at least one basic service in the group;
- the group "All Teleservices" provided that the service is applicable to at least one teleservice and that the subscriber has a subscription to at least one teleservice which is in the same Elementary Basic Service Group as a teleservice to which the service is applicable;
- the group "All Bearer Services" provided that the service is applicable to at least one bearer service and that the subscriber has a subscription to at least one bearer service which is in the same Elementary Basic Service Group as a basic service to which the service is applicable.

If the Basic Service Group (or Basic Service Group List) is not present then the parameter shall apply to all Basic Service Groups.

If the basic service information is not a single Elementary Basic Service Group then the parameter shall be taken as applying individually to all the Elementary Basic Service Groups for which:

- the supplementary service is applicable to at least one basic service in the Basic Service Group; and
- the subscriber has a subscription to at least one basic service in the Basic Service Group.

The VLR and the SGSN are not required to store supplementary services data for Basic Service Groups which are not supported at the VLR or the SGSN respectively.

8.8.2 MAP-DELETE-SUBSCRIBER-DATA service

8.8.2.1 Definition

This service is used by an HLR to remove certain subscriber data from a VLR or SGSN if the subscription of one or more supplementary services or basic services is withdrawn. Note that this service is not used in case of erasure or deactivation of supplementary services.

This service is also used by an HLR to remove GPRS subscription data from an SGSN.

This service is also used by an HSS via IWF to remove EPS subscription data from an MME.

It is a confirmed service and consists of the primitives shown in table 8.8/2.

8.8.2.2 Service primitives

Table 8.8/2: MAP-DELETE-SUBSCRIBER-DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Basic service List	C	C(=)		
SS-Code List	C	C(=)		
Roaming Restriction Due To				
Unsupported Feature	C	C(=)		
Camel Subscription Info Withdraw	C	C(=)		
Specific CSI Withdraw	C	C(=)		
Regional Subscription Data	C	C(=)		
VBS Group Indication	C	C(=)		
VGCS Group Indication	C	C(=)		
GPRS Subscription Data Withdraw	C	C(=)		
EPS Subscription Data Withdraw	C	C(=)		
Roaming Restricted In SGSN Due To Unsupported Feature	C	C(=)		
LSA Information Withdraw	C	C(=)		
IST Information Withdraw	C	C(=)		
Regional Subscription Response			C	C(=)
GMLC List Withdraw	C	C(=)		
Subscribed Charging Characteristics Withdraw	C	C(=)		
CSG Information Deleted	C	C(=)		
User error			C	C(=)
Provider error				O

8.8.2.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

Basic service List

A list of Extensible Basic service parameters (Extensible Basic service is defined in clause 7.6). It is used when one, several or all basic services are to be withdrawn from the subscriber. If the VLR or the SGSN receives a value for an Extensible Basic Service which it does not support, it shall ignore that value. This parameter is used by the VLR and by the SGSN; if the IWF receives this parameter it shall ignore it.

SS-Code List

A list of SS-Code parameters (SS-Code is defined in clause 7.6). It is used when several or all supplementary services are to be withdrawn from the subscriber.

There are three possible options:

- deletion of basic service(s);

  The parameter Basic service List is only included.

- deletion of supplementary service(s);

  The parameter SS-Code List is only included.

- deletion of basic and supplementary services;

  Both Basic service List and SS-Code List are included.

This parameter is used by the VLR and SGSN and IWF for Call Barring and LCS. Otherwise, this parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

Roaming Restriction Due To Unsupported Feature

This parameter is used if Roaming Restriction Due To Unsupported Feature is deleted from the subscriber data. This may occur if unsupported features or services are removed from the subscriber data in the HLR.

If this parameter is sent the VLR shall check if the current Location Area is possibly allowed now. This parameter is used only by the VLR and if the SGSN or IWF receives this parameter it shall ignore it.

CAMEL Subscription Info Withdraw

This parameter is used to indicate that CAMEL Subscription Info shall be deleted from the VLR or from the SGSN. All CAMEL Subscription Info for the subscriber shall be deleted. This parameter is used by the VLR and by the SGSN. This parameter should not be sent in the same message as the Specific CSI Withdraw parameter; if the IWF receives this parameter it shall ignore it.

Specific CSI Withdraw

This parameter is used to indicate that one or more specific elements of CAMEL Subscription Info shall be deleted from the VLR or from the SGSN.

The specific elements of CAMEL Subscription Info which may be withdrawn are:

- O-CSI with TDP criteria for O-CSI;
- SS-CSI;
- TIF-CSI;
- D-CSI;
- VT-CSI with TDP criteria for VT-CSI;
- MO-SMS-CSI;
- MT-SMS-CSI with TDP-Criteria for MT-SMS-CSI;
- M-CSI;
- MG-CSI;
- GPRS-CSI.

This parameter is used by the VLR and by the SGSN; if the IWF receices this parameter it shall ignore it. It shall not be sent to VLRs that do not support CAMEL phase 3 or higher. This parameter should not be sent in the same message as the CAMEL Subscription Info Withdraw parameter.

Regional Subscription Identifier

Contains one single Zone Code (as defined in clause 7.6) and is used if all Zone Codes shall be deleted from the subscriber data. When all the Zone Codes are deleted, the VLR, the SGSN or the MME shall check for its location areas whether they are allowed or not. If the whole Network Node area is restricted, the VLR, the SGSN or the MME (via the IWF) will report it to HLR by returning the Regional Subscription Response "Network Node Area Restricted".

The binary coding of the Zone Code value received in a Delete Subscriber Data request shall not be checked by the VLR, the SGSN or the MME.

Note that support of this parameter is a network operator option and it shall not be sent to networks which do not support Regional Subscription.

If Regional Subscription is not supported by the VLR, the SGSN or the MME, the request for deletion of Zone Codes is refused by sending the Regional Subscription Response "Regional Subscription Not Supported" to the HLR.

If no Zone Codes are stored in the respective subscriber data record, the request for deleting all Zone Code information shall be ignored and no Regional Subscription Response shall be returned. This parameter is used by the VLR, the SGSN and the MME.

VBS Group Indication

Contains an indication (flag) which is used if all Group Ids shall be deleted from the subscriber data for the Voice Broadcast teleservice.

If VBS is not supported in the VLR or no Group Ids are stored for VBS in the respective subscriber record, the request for deletion of all Group Ids shall be ignored. This parameter is used only by the VLR and if the SGSN or the IWF receives this parameter it shall ignore it.

VGCS Group Indication

Contains an indication (flag) which is used if all Group Id's shall be deleted from the subscriber data for the Voice Group Call teleservice. This parameter is used only by the VLR and if the SGSN receives this parameter it shall ignore it.

If VGCS is not supported in the VLR or no Group Ids are stored for VGCS in the respective subscriber record, the request for deletion of all Group Ids shall be ignored.

GPRS Subscription Data Withdraw

This parameter is used to indicate whether all GPRS Subscription Data for the subscriber shall be deleted or if only a subset of the stored GPRS Subscription Data for the subscriber shall be deleted. In the latter case only those PDP contexts whose identifiers are included in the subsequent identifier list will be deleted. This parameter is used only by the SGSN and if the VLR receives this parameter it shall ignore it.

EPS Subscription Data Withdraw

This parameter is used to indicate whether all EPS Subscription Data for the subscriber shall be deleted or if only a subset of the stored EPS Subscription Data for the subscriber shall be deleted. In the latter case, only those APN Configurations whose identifiers are included in the subsequent identifier list will be deleted. This parameter is used only by the SGSN and the MME and if the VLR receives this parameter it shall ignore it.

Roaming Restricted In SGSN/MME Due To Unsupported Feature

This parameter is used if Roaming Restricted In SGSN/MME Due To Unsupported Feature is deleted from the GPRS/EPS subscriber data. This may occur if unsupported features or services are removed from the GPRS/EPS subscriber data in the HLR.

If this parameter is sent the SGSN shall check if the current Location Area is possibly allowed now. This parameter is used only by the SGSN and the IWF and if the VLR receives this parameter it shall ignore it.

LSA Information Withdraw

This parameter is used to indicate whether all LSA Information for the subscriber shall be deleted or if only a subset of the stored LSA Information for the subscriber shall be deleted. In the latter case only the LSA data whose LSA identities are included in the subsequent LSA data list will be deleted. This parameter is used by the VLR and the SGSN.

IST Information Withdraw

This parameter is used to indicate that the IST condition has been removed for the subscriber. See 3GPP TS 43.035 for the use of this parameter.

Regional Subscription Response

If included in the Delete Subscriber Data response this parameter indicates one of:

- Network Node Area Restricted;
- Regional Subscription Not Supported.

This parameter is used by the VLR, the SGSN and the IWF.

GMLC List Withdraw

This parameter indicates that the subscriber's LCS GMLC List shall be deleted from the VLR or SGSN. This parameter is used by the VLR and the SGSN and IWF.

Subscribed Charging Characteristics Withdraw

This parameter indicates that the Subscribed Charging Characteristics shall be replaced with a local default value in the SGSN or in the MME (see 3GPP TS 32.251).
This parameter is used only by the SGSN and the IWF and if the VLR receives this parameter it shall ignore it.

CSG Information Deleted

This parameter indicates that CSG Subscription Information shall be deleted from VLR, SGSN, or MME.
This parameter is used by the VLR, SGSN and the IWF.

User error

Only one of the following values is applicable:

- Unidentified subscriber;
- Data missing;
- Unexpected data value.

8.9 Identity management services

8.9.1 MAP-PROVIDE-IMSI service

8.9.1.1 Definition

This service is used by a VLR in order to get, via the MSC, the IMSI of a subscriber (e.g. when a subscriber has identified itself with a TMSI not allocated to any subscriber in the VLR).

It is a confirmed service and consists of the primitives shown in table 8.9/1.

8.9.1.2 Service primitives

Table 8.9/1: MAP-PROVIDE-IMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI			C	C(=)
User error			C	C(=)
Provider error				O

8.9.1.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

IMSI

This parameter is received when the request is successfully carried out. It contains the requested IMSI.

User error

Only one of the following values is applicable:

- Absent subscriber.

8.9.2 MAP-FORWARD-NEW-TMSI service

8.9.2.1 Definition

This service is used by a VLR to allocate, via MSC, a new TMSI to a subscriber during an ongoing transaction (e.g. call set-up, location updating or supplementary services operation).

It is a confirmed service and consists of the primitives shown in table 8.9/2.

8.9.2.2 Service primitives

Table 8.9/2: MAP-FORWARD-NEW-TMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
TMSI	M	M(=)		
Provider error				O

8.9.2.3 Parameter use

The parameter TMSI is described in clause 7.6.

8.10 Fault recovery services

8.10.1 MAP_RESET service

8.10.1.1 Definition

This service is used by the HSS/HLR, after a restart, to indicate to a list of VLRs, SGSNs or MMEs (via IWF) that a failure occurred.

The MAP_RESET service is a non-confirmed service using the service primitives defined in table 8.10/1.

8.10.1.2 Service primitives

Table 8.10/1: MAP_RESET

Parameter name	Request	Indication
Invoke Id	M	M(=)
HLR number	M	M(=)
HLR Id LIST	U	C(=)

8.10.1.3 Parameter definition and use

Invoke Id

See definition in clause 7.6.1.

HLR number

See definition in clause 7.6.2.

HLR Id LIST

The HLR Id List is a list of HLR Ids. If the parameter is present in the indication, the VLR, the SGSN or the MME may base the retrieval of subscribers to be restored on their IMSI: the subscribers affected by the reset are those whose IMSI leading digits are equal to one of these numbers. If the parameter is absent, subscribers to be restored are those for which the OriginatingEntityNumber received at location updating time matches the equivalent parameter of the Reset Indication.

8.10.2 MAP_FORWARD_CHECK_SS_INDICATION service

8.10.2.1 Definition

This service may be used by an HLR as an implementation option, to indicate to a mobile subscriber that supplementary services parameters may have been altered, e.g. due to a restart. If received from the HLR, the VLR shall forward this indication to the MSC, which in turn forwards it to the MS. The HLR only sends this indication after successful completion of the subscriber data retrieval from HLR to VLR that ran embedded in a MAP_UPDATE_LOCATION procedure.

The MAP_FORWARD_CHECK_SS_INDICATION service is a non-confirmed service using the service primitives defined in table 8.10/2.

8.10.2.2 Service primitives

Table 8.10/2: MAP_FORWARD_CHECK_SS_INDICATION

Parameter name	Request	Indication
Invoke Id	M	M(=)

8.10.2.3 Parameter definition and use

Invoke Id

See definition in clause 7.6.1.

8.10.3 MAP_RESTORE_DATA service

8.10.3.1 Definition

This service is invoked by the VLR on receipt of a MAP_PROVIDE_ROAMING_NUMBER indication for an unknown IMSI, or for a known IMSI with the indicator " Subscriber Data Confirmed by HLR" set to "Not confirmed". The service is used to update the LMSI in the HLR, if provided, and to request the HLR to send all data to the VLR that are to be stored in the subscriber's IMSI record.

The MAP_RESTORE_DATA service is a confirmed service using the service primitives defined in table 8.10/3.

8.10.3.2 Service primitives

Table 8.10/3: MAP_RESTORE_DATA

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
LMSI	U	C(=)		
Supported CAMEL phases	C	C(=)		
SoLSA Support Indicator	C	C(=)		
IST Support Indicator	C	C(=)		
Super-Charger Supported in Serving Network Entity	C	C(=)		
Long FTN Supported	C	C(=)		

Supported LCS Capability Sets	C	C(=)		
Offered CAMEL 4 CSIs	C	C(=)		
HLR number			C	C(=)
MS Not Reachable Flag			C	C(=)
User error			C	C(=)
Provider error				O

8.10.3.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

LMSI

See definition in clause 7.6.2. It is an operator option to provide the LMSI from the VLR; it is mandatory for the HLR to support the LMSI handling procedures.

Supported CAMEL Phases

This parameter indicates which phases of CAMEL are supported. Must be present if a CAMEL phase different from phase 1 is supported. Otherwise may be absent.

SoLSA Support Indicator

This parameter is used by the VLR to indicate to the HLR in the Restore Data indication that SoLSA is supported. If this parameter is not included in the Restore Data indication then the HLR shall not perform any specific error handling.

This SoLSA Support Indicator shall be stored by the HLR per VLR where there are Subscribers roaming. If a Subscriber is marked as only allowed to roam in Subscribed LSAs while roaming in a VLR and no SoLSA Support indicator is stored for that VLR, the location status of that Subscriber shall be set to Restricted.

IST Support Indicator

This parameter is used to indicate to the HLR that the VMSC supports basic IST functionality, that is, the VMSC is able to terminate the Subscriber Call Activity that originated the IST Alert when it receives the IST alert response indicating that the call(s) shall be terminated. If this parameter is not included in the Restore Data indication and the Subscriber is marked as an IST Subscriber, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Outgoing calls), or allow service assuming the associated risk of not having the basic IST mechanism available.

This parameter can also indicate that the VMSC supports the IST Command service, including the ability to terminate all calls being carried for the identified subscriber by using the IMSI as a key. If this additional capability is not included in the Restore Data indication and the HLR supports the IST Command capability, then the HLR may limit the service for the subscriber (by inducing an Operator Determined barring of Outgoing calls), or allow service assuming the associated risk of not having the IST Command mechanism available.

Long FTN Supported

This parameter indicates that the VLR supports Long Forwarded-to Numbers.

Super-Charger Supported in Serving Network Entity

This parameter is used by the VLR to indicate to the HLR that the VLR supports the Super-Charger functionality and that subscriber data is required.

If this parameter is absent then the VLR does not support the Super-Charger functionality.

Supported LCS Capability Sets

This parameter indicates, if present, the capability sets of LCS which are supported. If the parameter is sent but no capability set is marked as supported then the VLR does not support LCS at all.

If this parameter is absent then the VLR may support at most LCS capability set 1, that is LCS Release98 or Release99 version.

Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the VMSC/VLR (see clause 7.6.3.36D).

HLR number

See definition in clause 7.6.2. The presence of this parameter is mandatory in case of successful outcome of the service.

MS Not Reachable Flag

See definition in clause 7.6.8. This parameter shall be present in case of successful outcome of the service, if the "MS Not Reachable flag" was set in the HLR.

User error

In case of unsuccessful outcome of the service, an error cause shall be returned by the HLR. The following error causes defined in clause 7.6.1 may be used, depending on the nature of the fault:

- unknown subscriber;
- system failure;
- unexpected data value;
- data missing.

Provider error

For definition of provider errors see clause 7.6.1.

8.11 Subscriber Information services

8.11.1 MAP-ANY-TIME-INTERROGATION service

8.11.1.1 Definition

This service is used by the gsmSCF, to request information (e.g. subscriber state and location) from the HLR or the GMLC at any time. This service may also be used by the gsmSCF to request the Mobile Number Portability (MNP) information from the NPLR.

This service is also used by the Presence Network Agent to request information, (e.g. subscriber state and location) about the subscriber (associated with a presentity) from the HLR at any time (see 3GPP TS 23.141 [128]).

When this service is used to the HLR, the subscriber state or location may be requested.

When this service is used to the GMLC, only the location may be requested.

When this service is used to the NPLR, only the MNP information may be requested.

The MAP-ANY-TIME-INTERROGATION service is a confirmed service using the service primitives defined in table 8.11/1.

8.11.1.2 Service primitives

Table 8.11/1: Any_Time_Interrogation

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)

Requested Info	M	M(=)		
Requested domain	C	C(=)		
MNP Requested Info	C	C(=)		
gsmSCF-Address	M	M(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
Location Information			C	C(=)
Location Information for GPRS			C	C(=)
Subscriber State			C	C(=)
PS Subscriber State			C	C(=)
IMEI			C	C(=)
MS Classmark 2			C	C(=)
GPRS MS Class			C	C(=)
MNP info Result			C	C(=)
User error			C	C(=)
Provider error				O

8.11.1.3 Parameter definition and use

All parameters are described in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98].

The HLR or GMLC may be able to use the value of the parameter gsmSCF-address to screen a MAP_Any_Time_Interrogation indication.

The use of the parameters and the requirements for their presence are specified in 3GPP TS 23.078.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Any Time Interrogation Not Allowed;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

These are defined in clause 7.6.1.

8.11.2 MAP-PROVIDE-SUBSCRIBER-INFO service

8.11.2.1 Definition

This service is used to request information (e.g. subscriber state and location) from the VLR or SGSN at any time.

The MAP-PROVIDE-SUBSCRIBER-INFO service is a confirmed service using the primitives defined in table 8.11/2.

8.11.2.2 Service primitives

Table 8.11/2: Provide_Subscriber_Information

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Requested Info	M	M(=)		
IMSI	M	M(=)		
LMSI	U	O		
Call Priority	U	O		
Location Information			C	C(=)
Location Information for GPRS			C	C(=)
Subscriber State			C	C(=)
PS Subscriber State			C	C(=)
IMEI			C	C(=)
MS Classmark 2			C	C(=)
GPRS MS Class			C	C(=)
User error			C	C(=)
Provider error				O

8.11.2.3 Parameter definition and use

All parameters are defined in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98].

Call Priority

This parameter indicates the eMLPP priority of the call (see 3GPP TS 24.067 [137]). This parameter should be present if the HLR supports this parameter and if the Call Priority was received in the MAP_SEND_ROUTING_INFORMATION request.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value.

Provider error

These are defined in clause 7.6.1.

8.11.3 MAP-ANY-TIME-SUBSCRIPTION-INTERROGATION service

8.11.3.1 Definition

This service is used by the gsmSCF, to request subscription information (e.g. call forwarding supplementary service data or CSI) from the HLR at any time. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this service.

8.11.3.2 Service primitives

Table 8.11/3: Any_Time_Subscription_Interrogation

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Requested Subscription Info	M	M(=)		
GsmSCF-Address	M	M(=)		

IMSI	C	C(=)		
MSISDN	C	C(=)		
Long FTN Supported	C	C(=)		
Call Forwarding Data			C	C(=)
Call Barring Data			C	C(=)
ODB Info			C	C(=)
CAMEL Subscription Info			C	C(=)
Supported CAMEL phases in VLR			C	C(=)
Supported CAMEL phases in SGSN			C	C(=)
Offered CAMEL 4 CSIs in VLR			C	C(=)
Offered CAMEL 4 CSIs in SGSN			C	C(=)
MSISDN-BS-List			C	C(=)
User error			C	C(=)
Provider error				O

8.11.3.3 Parameter definition and use

All parameters are described in clause 7.6.

The HLR may be able to use the value of the parameter gsmSCF-address to screen a MAP_Any_Time_Subscription_Interrogation indication. The gsmSCF-address shall contain the IM-SSF address when the IM-SSF takes the role of the gsmSCF.

The use of the parameters and the requirements for their presence are specified in 3GPP TS 23.078 and 3GPP TS 23.278.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Unexpected Data Value;
- Unknown Subscriber;
- BearerServiceNotProvisioned;
- TeleserviceNotProvisioned;
- CallBarred;
- IllegalSS-Operation;
- SS-NotAvailable;
- InformationNotAvailable;
- Any Time Subscription Interrogation Not Allowed;
- Data Missing.

Provider error

These are defined in clause 7.6.1.

8.11.4 MAP-ANY-TIME-MODIFICATION service

8.11.4.1 Definition

This service is used by the gsmSCF, to modify information of the HLR at any time.

This service is also used by the Presence Network Agent to activate or deactivate reporting of mobility management events (associated with a presentity) from the VLR or SGSN (see 3GPP TS 23.141 [128]).

This service is also used by a Service Related Entity (e.g. the IP-SM-GW) to activate a one-time subscription of UE-reachability in the MME (see 3GPP TS 23.204 [134]).

This service is also used by external Short Message Gateway (IP-SM-GW) for updating the IP-SM-GW Number stored in the HLR.

8.11.4.2 Service primitives

Table 8.11/4: Any_Time_Modification

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
gsmSCF-Address	M	M(=)		
Subscriber Identity	M	M(=)		
Modification request for ODB data	C	C(=)		
Modification request for SS information	C	C(=)		
Modification request for CSI	C	C(=)		
Long FTN Supported	C	C(=)		
Modification request for IP-SM-GW data	C	C(=)		
Activation request for UE-Reachability	C	C(=)		
Ext Forwarding information-for-CSE			C	C(=)
Ext Call barring information-for-CSE			C	C(=)
ODB Info			C	C(=)
CAMEL subscription info			C	C(=)
User error			C	C(=)
Provider error				O

8.11.4.3 Parameter definition and use

All parameters are described in clause 7.6.

The HLR may be able to use the value of the parameter gsmSCF-address to screen a MAP_Any_Time_Modification indication.

The use of parameters other than described below and the requirements for their presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.278 [125].

gsmSCF-Address

This parameter indicates the address of the interrogating gsmSCF. The gsmSCF Address shall be in international E.164 format. If the service is used by IP-SM-GW, the parameter contains the address of the IP-SM-GW. See also 3GPP TS 23.078 [98] and 3GPP TS 23.278 [125].

Modification request for IP-SM-GW data

This parameter is used by the external IP-SM-GW for updating the IP-SM-GW Number stored in the HLR. If this parameter is present then other modification requests shall not be present.

Activation request for UE Reachability

This parameter is used by the Service Related Entity (e.g. IP-SM-GW) to activate the one-time subscription for UE-Reachability. If this parameter is present then other modification requests shall not be present.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Any Time Modification Not Allowed;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber;

- Bearer service not provisioned;

  This error is returned only if not even a subset of the requested bearer service group has been subscribed to;

- Teleservice not provisioned;

  This error is returned only if not even a subset of the requested teleservice group has been subscribed to;

- Call Barred;
- Illegal SS operation;
- SS error status;
- SS incompatibility;
- SS subscription violation;
- Information Not Available.

Provider error

These are defined in clause 7.6.1.

8.11.5 MAP-NOTE-SUBSCRIBER-DATA-MODIFIED service

8.11.5.1 Definition

This service is used by the HLR to inform the gsmSCF that subscriber data have been modified. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this service.

This service is also used by the HLR to inform the Service Related Entity (e.g. IP-SM-GW) that the UE has become reachable (see 3GPP TS 23.204 [134]).

8.11.5.2 Service primitives

Table 8.11/5: Note_Subscriber_Data_Modified

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSISDN	M	M(=)		
Ext Forwarding information-for-CSE	C	C(=)		
Ext Call barring information-for-CSE	C	C(=)		
ODB Info	C	C(=)		
CAMEL subscription info	C	C(=)		
All Information Sent	C	C(=)		
UE reachable	C	C(=)		
User error			C	C(=)
Provider error				O

8.11.5.3 Parameter definition and use

Invoke id

See clause 7.6.1 for the use of this parameter.

IMSI

See clause 7.6.2 for the use of this parameter.

MSISDN

See clause 7.6.2 for the use of this parameter. In an IP Multimedia Core Network, if no MSISDN is available, the HLR shall populate this parameter with a dummy MSISDN.

Ext Forwarding information-for-CSE

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078.

Ext Call barring information-for-CSE

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078.

ODB Info

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078.

CAMEL subscription info

See clause 7.6.3 for the use of this parameter. The use of this parameter and the requirements for their presence are specified in 3GPP TS 23.078 and 3GPP TS 23.278.

All Information Sent

This parameter is set when the HLR has sent all information to gsmSCF.

UE Reachable

This parameter is used when the HLR indicates to the Service related entity (e.g. IP-SM-GW) that the UE is reachable again.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

These are defined in clause 7.6.1.

The use of the parameters and the requirements for their presence are specified in 3GPP TS 23.078 and 3GPP TS 23.278.

9 Operation and maintenance services

9.1 Subscriber tracing services

9.1.1 MAP-ACTIVATE-TRACE-MODE service

9.1.1.1 Definition

This service is used between the HLR and the VLR to activate subscriber tracing in the VLR.

Also this service is used between the HLR and the SGSN to activate subscriber tracing in the SGSN.

The MAP-ACTIVATE-TRACE-MODE service is a confirmed service using the primitives from table 9.1/1.

9.1.1.2 Service primitives

Table 9.1/1: MAP-ACTIVATE-TRACE-MODE

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Trace reference	M	M(=)		
Trace type	M	M(=)		
Trace reference 2	C	C(=)		
Trace depth list	C	C(=)		
Trace NE type list	C	C(=)		
Trace interface list	C	C(=)		
Trace event list	C	C(=)		
Trace support indicator			C	C(=)
OMC Id	U	C(=)		
User error			C	C(=)
Provider error				O

9.1.1.3 Parameter use

Invoke id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2. The IMSI is a mandatory parameter in a stand-alone operation.

Trace reference

See definition in clause 7.6.10. This parameter contains trace reference for GSM only tracing request.

Trace type

See definition in clause 7.6.10. This parameter contains trace type for GSM only tracing request.

OMC Id

See definition in clause 7.6.2. The use of this parameter is an operator option.

Trace reference 2

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

Trace depth list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

Trace NE type list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

Trace interface list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

Trace event list

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

Trace support indicator

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified Subscriber;
- Facility Not Supported;
- Tracing Buffer Full;
- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see clause 7.6.1.

9.1.2 MAP-DEACTIVATE-TRACE-MODE service

9.1.2.1 Definition

This service is used between the VLR and the HLR for deactivating subscriber tracing in the VLR.

Also this service is used between the SGSN and the HLR for deactivating subscriber tracing in the SGSN.

The MAP-DEACTIVATE-TRACE-MODE service is a confirmed service using the primitives from table 9.1/2.

9.1.2.2 Service primitives

Table 9.1/2: MAP-DEACTIVATE-TRACE-MODE

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Trace reference	M	M(=)		
Trace reference 2	C	C(=)		
User error			C	C(=)
Provider error				O

9.1.2.3 Parameter use

Invoke id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2. The IMSI is a mandatory parameter in a stand-alone operation.

Trace reference

See definition in clause 7.6.10.

Trace reference 2

See definition in clause 7.6.10. This parameter shall be used for UMTS trace activation.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified Subscriber;
- Facility Not Supported;
- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see clause 7.6.1.

9.1.3 MAP-TRACE-SUBSCRIBER-ACTIVITY service

9.1.3.1 Definition

This service is used between the VLR and the MSC to activate the subscriber tracing in the MSC.

The MAP-TRACE-SUBSCRIBER-ACTIVITY service is a non-confirmed service using the primitives from table 9.1/3.

9.1.3.2 Service primitives

Table 9.1/3: MAP-TRACE-SUBSCRIBER-ACTIVITY

Parameter name	Request	Indication
Invoke id	M	M(=)
IMSI	C	C(=)
Trace reference	M	M(=)
Trace type	M	M(=)
OMC Id	U	C(=)

9.1.3.3 Parameter use

Invoke id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2. The controlling MSC shall provide either the IMSI or the IMEI to the servicing MSC.

Trace reference

See definition in clause 7.6.10.

Trace type

See definition in clause 7.6.10.

OMC Id

See definition in clause 7.6.2. The use of this parameter is an operator option.

9.2 Other operation and maintenance services

9.2.1 MAP-SEND-IMSI service

9.2.1.1 Definition

This service is used by a VLR in order to fetch the IMSI of a subscriber in case of some Operation & Maintenance procedure where subscriber data are needed in the Visited PLMN and MSISDN is the only subscriber's identity known.

It is a confirmed service and consists of the primitives shown in table 9.2/1.

9.2.1.2 Service primitives

Table 9.2/1: MAP-SEND-IMSI

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
IMSI			C	C(=)
User error			C	C(=)
Provider error				O

9.2.1.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable.

User error

Only one of the following values is applicable:

- Unknown subscriber;
- Unexpected data value;
- Data missing.

10 Call handling services

10.1 MAP_SEND_ROUTING_INFORMATION service

10.1.1 Definition

This service is used between the Gateway MSC and the HLR. The service is invoked by the Gateway MSC to perform the interrogation of the HLR in order to route a call towards the called MS.

This is a confirmed service using the primitives listed in table 10.1/1.

This service is also used between the GMSC and the NPLR and between the gsmSCF and the HLR.

10.1.2 Service primitives

Table 10.1/1: MAP_SEND_ROUTING_INFORMATION parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Interrogation Type	M	M(=)		
GMSC or gsmSCF Address	M	M(=)		

Parameter name	Request	Indication	Response	Confirm
MSISDN	M	M(=)	C	C(=)
OR Interrogation	C	C(=)		
OR Capability	C	C(=)		
CUG Interlock	C	C(=)	C	C(=)
CUG Outgoing Access	C	C(=)	C	C(=)
Number of Forwarding	C	C(=)		
Network Signal Info	C	C(=)		
Supported CAMEL Phases	C	C(=)	C	C(=)
Suppress T-CSI	C	C(=)		
Offered CAMEL 4 CSIs	C	C(=)		
Suppression of Announcement	C	C(=)		
Call Reference Number	C	C(=)		
Forwarding Reason	C	C(=)		
Basic Service Group	C	C(=)		
Basic Service Group 2	C	C(=)		
Alerting Pattern	C	C(=)		
CCBS Call	C	C(=)		
Supported CCBS Phase	C	C(=)		
Additional Signal Info	C	C(=)		
IST Support Indicator	C	C(=)		
Pre-paging supported	C	C(=)		
Call Diversion Treatment Indicator	C	C(=)		
Long FTN Supported	C	C(=)		
Suppress VT-CSI	C	C(=)		
Suppress Incoming Call Barring	C	C(=)		
SuppressMTSS	C	C(=)		
gsmSCF Initiated Call	C	C(=)		
Network Signal Info 2	C	C(=)		
MT Roaming Retry Supported	U	C(=)		
Call Priority	U	C(=)		
IMSI			C	C(=)
MSRN			C	C(=)
Forwarding Data			C	C(=)
Forwarding Interrogation Required			C	C(=)
VMSC address			C	C(=)
ReleaseResourcesSupported			C	C(=)
GMSC Camel Subscription Info			C	C(=)
Location Information			C	C(=)
Subscriber State			C	C(=)
Basic Service Code			C	C(=)
CUG Subscription Flag			C	C(=)
North American Equal Access preferred Carrier Id			U	C(=)
User error			C	C(=)
SS-List			U	C(=)
CCBS Target			C	C(=)
Keep CCBS Call Indicator			C	C(=)
IST Alert Timer			C	C(=)
Number Portability Status			U	C(=)
Supported CAMEL Phases in VMSC			C	
Offered CAMEL 4 CSIs in VMSC			C	C(=)
MSRN 2			C	C(=)
Forwarding Data 2			C	C(=)
SS-List 2			C	C(=)
Basic Service Code 2			C	C(=)
Allowed Services			C	C(=)
Unavailability Cause			C	C(=)
Provider error				O
GSM Bearer Capability			U	C (=)

10.1.3 Parameter use

See clause 7.6 for a definition of the parameters used in addition to the following. Note that:

- a conditional parameter whose use is defined only in 3GPP TS 23.078 shall be absent if the sending entity does not support CAMEL;
- a conditional parameter whose use is defined only in 3GPP TS 23.079 [99] shall be absent if the sending entity does not support optimal routeing;
- a conditional parameter whose use is defined only in 3GPP TS 23.078 & 3GPP TS 23.079 [99] shall be absent if the sending entity supports neither CAMEL nor optimal routeing.

Interrogation Type

See 3GPP TS 23.079 [99] for the use of this parameter.

GMSC or gsmSCF address

The E.164 address of the GMSC or the gsmSCF. This parameter contains the gsmSCF address if the gsmSCF iniated call parameter is present, otherwise it is the GMSC address.

MSISDN

This is the Mobile Subscriber ISDN number assigned to the called subscriber. In the Request & Indication it is the number received by the GMSC in the ISUP IAM. If the call is to be forwarded and the HLR supports determination of the redirecting number, the HLR inserts the basic MSISDN in the Response.

See 3GPP TS 23.066 [108] for the use of this parameter and the conditions for its presence in the response.

OR Interrogation

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

OR Capability

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

CUG Interlock

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

CUG Outgoing Access

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

Number of Forwarding

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

Network Signal Info

See 3GPP TS 23.018 [97] for the conditions for the presence of the components of this parameter.

Supported CAMEL Phases

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

T-CSI Suppression

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

Offered CAMEL 4 CSIs

This parameter indicates the CAMEL phase 4 CSIs offered in the GMSC/VLR (see clause 7.6.3.36D).

Suppression Of Announcement

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

Call Reference Number

The use of this parameter and the conditions for its presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.079 [99].

Forwarding Reason

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

Basic Service Group

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

Basic Service Group 2

See 3GPP TS 23.079[99] for the use of this parameter and the conditions for its presence.

Alerting Pattern

See 3GPP TS 23.018 [97] and 3GPP TS 23.078 [98] for the use of this parameter and the conditions for its presence.

CCBS Call

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Supported CCBS Phase

This parameter indicates by its presence that CCBS is supported and the phase of CCBS which is supported.

Additional Signal Info

See 3GPP TS 23.081 [27] for the conditions for the presence of the components of this parameter.

IST Support Indicator

This parameter is used to indicate to the HLR that the GMSC supports basic IST functionality, that is, the GMSC is able to terminate the subscriber call activity that originated the IST Alert when it receives the IST Alert response indicating that the call(s) shall be terminated. If this parameter is not included in the Send Routing Information indication and the subscriber is marked as an IST subscriber, then the HLR may limit the service for the call (by barring the incoming call if it is not subject to forwarding, or suppressing Call Forwarding from the GMSC), or allow the call assuming the associated risk of not having the basic IST mechanism available.

This parameter can also indicate that the GMSC supports the IST Command, including the ability to terminate all calls being carried for the identified subscriber by using the IMSI as a key. If this additional capability is not included in the Send Routing Information indication and the subscriber is marked as an IST subscriber, then the HLR may limit the service for the subscriber (by barring the incoming calls if they are not subject to forwarding, or suppressing Call Forwarding from the GMSC), or allow the incoming calls assuming the associated risk of not having the IST Command mechanism available.

Pre-paging supported

See 3GPP TS 23.018 for the use of this parameter and the conditions for its presence.

Call Diversion Treatment Indicator

This parameter indicates whether or not call diversion is allowed.

Network Signal Info 2

See 3GPP TS 23.172 [126] for the conditions for the presence of the components of this parameter.

MT Roaming Retry Supported

See 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23] for the use of this parameter and the conditions for its presence.

Call Priority

This parameter indicates the eMLPP priority of the call (see 3GPP TS 24.067 [137]). This parameter should be present if the GMSC supports the eMLPP feature and if the call is an eMLPP call. The eMLPP priority levels A and B shall be mapped to the Call Priority level 0.

IMSI

See 3GPP TS 23.018 [97] and 3GPP TS 23.066 [108] for the use of this parameter and the conditions for its presence.

MSRN

See 3GPP TS 23.018 [97], 3GPP TS 23.066 [108] and 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence. If the NPLR returns only the MSISDN-number without Routeing Number to the GMSC, the MSISDN-number shall be returned as MSRN.

Forwarding Data

This parameter includes a number to define the forwarded-to destination, the forwarding reason and the forwarding options Notification to calling party and Redirecting presentation, and can include the forwarded-to subaddress. See 3GPP TS 23.018 [97] and 3GPP TS 23.079 [99] for the conditions for the presence of its components.

Forwarding Interrogation Required

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

Long FTN Supported

This parameter indicates that the GMSC supports Long Forwarded-to Numbers.

Suppress VT-CSI

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

Suppress Incoming Call Barring

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

gsmSCF Initiated Call

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

SuppressMTSS

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

VMSC address

See 3GPP TS 23.079 [99] and 3GPP TS 23.078 [98] for the use of this parameter and the conditions for its presence. In addition this parameter shall be present if the ReleaseResourcesSupported parameter is present.

Release Resources Supported

This parameter indicates by its presence that the MAP_RELEASE_RESOURCES service is supported at the VMSC. It shall be present if so indicated by the VMSC with MAP_PROVIDE_ROAMING_NUMBER confirm.

GMSC CAMEL Subscription Info

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

Location Information

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

Subscriber State

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

CUG Subscription Flag

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

North American Equal Access preferred Carrier Id

This parameter is returned to indicate the preferred carrier identity to be used to set-up the call (i.e. forwarding the call or establishing the roaming leg).

SS-List

This parameter includes SS-codes and will be returned as an operator option. The HLR shall not send PLMN-specific SS-codes across PLMN boundaries. However if the GMSC receives PLMN-specific SS-codes from a foreign PLMN's HLR the GMSC may ignore it. If the GMSC attempts to process the PLMN- specific SS- codes, this may lead to unpredictable behaviour but the GMSC shall continue call processing.

Basic Service Code

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

If the CAMEL service is not involved, this parameter includes the basic service code and will be returned as an operator option. The HLR shall not send a PLMN-specific Basic Service Code across PLMN boundaries. However if the GMSC receives a PLMN-specific Basic Service Code from a foreign PLMN's HLR the GMSC may ignore it. If the GMSC attempts to process the PLMN specific Basic Service codes, this may lead to unpredictable behaviour but the GMSC shall continue call processing.

CCBS Target

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Keep CCBS Call Indicator

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

IST Alert Timer

It includes the IST Alert timer value that must be used to inform the HLR about the call activities that the subscriber performs. This parameter is only sent to the GMSC in response to a Send Routing Information request which indicates the the GMSC supports IST.

Number Portability Status

This parameter indicates the number portability status of the subscriber. This parameter may be present if the sender of SRIack is NPLR.

Supported CAMEL Phases in VMSC

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078.

Offered CAMEL 4 CSIs in VMSC

This parameter is defined in clause 7.6.3.36F.

MSRN 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

Forwarding Data 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

SS-List 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

Basic Service Code 2

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

Allowed Services

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

Unavailability Cause

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.172 [126].

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Unknown Subscriber;

  The diagnostic for the Unknown Subscriber error may indicate 'NPDB Mismatch'.

- Number changed;

- Call Barred;

  This error will indicate that either incoming calls are barred for this MS or that calls are barred due to Operator Determined Barring (see 3GPP TS 22.041 [8] for a definition of this network feature);

- CUG Reject;

  The value of this error cause will indicate the reason for CUG Reject;

- Bearer Service Not Provisioned;

- Teleservice Not Provisioned;

  A subscription check has been performed and the call has not passed the check due to incompatibility with regard to the requested service. Depending on the nature of the incompatibility, either of these messages will be returned;

- Facility Not Supported;

- Absent Subscriber;

  This indicates that the location of the MS is not known (either the station is not registered and there is no location information available or the Provide Roaming Number procedure fails due to IMSI detached flag being set), or the GMSC requested forwarding information with a forwarding reason of not reachable, and the call forwarding on MS not reachable service is not active;

- Busy Subscriber;

  This indicates that Call Forwarding on Busy was not active for the specified basic service group when the GMSC requested forwarding information with a forwarding reason of busy;

  The error may also indicate that the subscriber is busy due to an outstanding CCBS recall. In the error data it may then be specified that CCBS is possible for the busy encountered call;

- No Subscriber Reply;

  This indicates that Call Forwarding on No Reply was not active for the specified basic service group when the GMSC requested forwarding information with a forwarding reason of no reply;

- OR Not Allowed;

  This indicates that the HLR is not prepared to accept an OR interrogation from the GMSC, or that calls to the specified subscriber are not allowed to be optimally routed;

- Forwarding Violation;

- System Failure;

- Data Missing;

- Unexpected Data Value.

See clause 7.6 for a definition of these errors.

Provider error

These are defined in clause 7.6.

GSM Bearer Capability

This information is passed according to the rules specified in 3GPP TS 29.007 [56]. There may be two GSM Bearer Capabilities supplied.

10.2 MAP_PROVIDE_ROAMING_NUMBER service

10.2.1 Definition

This service is used between the HLR and VLR. The service is invoked by the HLR to request a VLR to send back a roaming number to enable the HLR to instruct the GMSC to route an incoming call to the called MS.

This is a confirmed service which uses the primitives described in table 10.2/1.

10.2.2 Service primitives

Table 10.2/1: MAP_PROVIDE_ROAMING_NUMBER parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
MSC Number	M	M(=)		
MSISDN	U	C(=)		
LMSI	C	C(=)		
GSM Bearer Capability	C	C(=)		
Network Signal Info	C	C(=)		
Suppression Of Announcement	C	C(=)		
Call Reference Number	C	C(=)		
GMSC Address	C	C(=)		
OR Interrogation	C	C(=)		
OR Not Supported in GMSC	C	C(=)		
Alerting Pattern	C	C(=)		
CCBS Call	C	C(=)		
Supported CAMEL Phases in interrogating node	C	C(=)		
Additional Signal Info	C	C(=)		
Pre-paging supported	C	C(=)		
Long FTN Supported	C	C(=)		
Suppress VT-CSI	C	C(=)		
Offered CAMEL 4 CSIs in interrogating node	C	C(=)		
MT Roaming Retry Supported	U	C(=)		
Paging Area	U	C(=)		
Call Priority	U	C(=)		
Roaming Number			C	C(=)
ReleaseResourcesSupported			U	C(=)
User error			C	C(=)
Provider error				O

10.2.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following. Note that:

- a conditional parameter whose use is defined only in 3GPP TS 23.078 [98] shall be absent if the sending entity does not support CAMEL;

- a conditional parameter whose use is defined only in 3GPP TS 23.079 [99] shall be absent if the sending entity does not support optimal routeing;
- a conditional parameter whose use is defined only in 3GPP TS 23.078 [98] & 3GPP TS 23.079 [99] shall be absent if the sending entity supports neither CAMEL nor optimal routeing.

IMSI

This is the IMSI of the called Subscriber.

MSC Number

This is the ISDN number assigned to the MSC currently serving the MS. The MSC number will have been stored in the HLR as provided at location updating.

MSISDN

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

LMSI

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

GSM Bearer Capability

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

This information is passed according to the rules specified in TS 3GPP TS 29.007 [56].

There may be two GSM Bearer Capabilities supplied.

Network Signal Info

See 3GPP TS 23.018 [97] for the conditions for the presence of the components of this parameter.

Suppression Of Announcement

The use of this parameter and the requirements for its presence are specified in 3GPP TS 23.078 [98].

Call Reference Number

The use of this parameter and the conditions for its presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.079 [99].

GMSC Address

The use of this parameter and the conditions for its presence are specified in 3GPP TS 23.078 [98] and 3GPP TS 23.079 [99].

OR Interrogation

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

OR Not Supported in GMSC

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

Supported CAMEL Phases in interrogating node

This parameter is defined in clause 7.6.3.36I.Alerting Pattern

See 3GPP TS 23.078 [98] for the use of this parameter and the conditions for its presence.

CCBS Call

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Additional Signal Info

See 3GPP TS 23.081 [27] for the conditions for the presence of the components of this parameter.

Pre-paging supported

See 3GPP TS 23.018 for the use of this parameter and the conditions for its presence.

Long FTN supported

See 3GPP TS 23.082 for the use of this parameter and the conditions for its presence.

Suppress VT-CSI

See 3GPP TS 23.078 for the use of this parameter and the conditions for its presence.

Offered CAMEL 4 CSIs in interrogating node

This parameter is defined in clause 7.6.3.36E.

MT Roaming Retry Supported

See 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23] for the use of this parameter and the conditions for its presence.

Paging Area

See 3GPP TS 23.018 [97] and 3GPP TS 23.012 [23] for the use of this parameter and the conditions for its presence.

Call Priority

This parameter indicates the eMLPP priority of the call (see 3GPP TS 24.067 [137]). This parameter should be present if the HLR supports this parameter and if the Call Priority was received in the MAP_SEND_ROUTING_INFORMATION request.

Roaming Number

See 3GPP TS 23.018 [97] for the use of this parameter and the conditions for its presence.

ReleaseResourcesSupported

This parameter indicates by its presence that the MAP_RELEASE_RESOURCES service is supported at the VMSC.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Absent Subscriber;

  This error will be returned if the IMSI detach flag is set.

- No Roaming Number Available;

- OR Not Allowed;

  This indicates that the MAP_PROVIDE_ROAMING_NUMBER indication included the OR interrogation indicator, but the VLR does not support optimal routeing.

- Facility Not Supported;

- System Failure;

- Data Missing;

- Unexpected Data Value.

See clause 7.6 for a definition of these reasons.

Provider error

These are defined in clause 7.6.

10.3 MAP_RESUME_CALL_HANDLING service

10.3.1 Definition

This service is used between the terminating VMSC and the GMSC. The service is invoked by the terminating VMSC to request the GMSC to resume handling the call and forward it to the specified destination.

This is a confirmed service which uses the Primitives listed in table 10.3/1.

10.3.2 Service primitives

Table 10.3/1: MAP_RESUME_CALL_HANDLING parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Call Reference Number	C	C(=)		
Basic Service Group	C	C(=)		
Basic Service Group 2	C	C(=)		
IMSI	C	C(=)		
Forwarding Data	C	C(=)		
CUG Interlock	C	C(=)		
CUG Outgoing Access	C	C(=)		
O-CSI	C	C(=)		
D-CSI	C	C(=)		
CCBS Target	C	C(=)		
UU Data	C	C(=)		
UUS CF Interaction	C	C(=)		
All Information Sent	C	C(=)		
MSISDN	C	C(=)		
MT Roaming Retry	U	C(=)		
User error			C	C(=)
Provider error				O

10.3.3 Parameter use

Information received in subsequent segment of a segmented dialogue shall not overwrite information received in an earlier segment.

See clause 7.6 for a definition of the parameters used, in addition to the following.

Call Reference Number

See 3GPP TS 23.079 [99] for the use of this parameter. This parameter shall be present in the first segment of the dialogue.

Basic Service Group

See 3GPP TS 23.079 [99] for the use of this parameter. This parameter shall be present in the first segment of the dialogue.

Basic Service Group 2

See 3GPP TS 23.079[99] for the use of this parameter. If this parameter is present, it shall be in the first segment of the dialogue.

IMSI

This is the IMSI of the forwarding Subscriber. This parameter shall be present in the first segment of the dialogue.

Forwarding Data

This parameter includes a number to define the forwarded-to destination, the forwarding reason and the forwarding options Notification to calling party and Redirecting presentation, and can include the forwarded-to subaddress. See 3GPP TS 23.079 [99] for the conditions for the presence of its components. This parameter shall be present in a first segment of the dialogue.

CUG Interlock

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

CUG Outgoing Access

See 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence.

O-CSI

See 3GPP TS 23.078 for the use of this parameter and the conditions for its presence.

For CAMEL phases 1 & 2, the O-CSI shall contain only one set of O-BCSM TDP data.

D-CSI

The Dialled Services-CSI.

See 3GPP TS 23.078 for the use of this parameter and the conditions for its presence.

CCBS Target

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

UU Data

See 3GPP TS 23.087 for the use of this parameter and the conditions for its presence.

UUS CF Interaction

See 3GPP TS 23.087 for the use of this parameter and the conditions for its presence.

All Information Sent

This parameter is set when the VMSC has sent all information to GMSC.

MT Roaming Retry

See 3GPP TS 23.018 [97], 3GPP TS 23.012 [23] and 3GPP TS 23.079 [99] for the use of this parameter and the conditions for its presence. When this parameter is present, only the Call Reference Number and All Information Sent IEs shall be present; the other IEs shall be ignored by the GMSC if received.

MSISDN

This parameter is the basic MSISDN of the forwarding subscriber. It shall be present if the VMSC supports determination of the redirecting number.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Optimal Routeing not allowed;
- Forwarding failed;
- Unexpected Data Value;
- Data Missing.

Provider error

These are defined in clause 7.6.

10.4 MAP_PREPARE_GROUP_CALL service

10.4.1 Definition

This service is used by the Anchor_MSC to inform the Relay_MSC about a group call set-up.

The MAP_PREPARE_GROUP_CALL service is a confirmed service using the service primitives given in table 10.4/1.

10.4.2 Service primitives

Table 10.4/1: MAP_PREPARE_GROUP_CALL service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Teleservice	M	M(=)		
ASCI Call Reference	M	M(=)		
Ciphering Algorithm	M	M(=)		
Group Key Number VK-Id	C	C(=)		
VSTK Key	C	C(=)		
VSTK-RAND	C	C(=)		
Priority	C	C(=)		
CODEC-Information	M	M(=)		
Uplink Free Indicator	M	M(=)		
Talker Channel Parameter	C	C(=)		
Group Call Number			M	M(=)
User Error			C	C(=)
Provider Error				O

10.4.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1.

Teleservice

Voice Broadcast Service or Voice Group Call Service.

ASCI Call Reference

Broadcast call reference or group call reference. This item is used to access the VBS-GCR or VGCS-GCR within the Relay_MSC.

Ciphering Algorithm

The ciphering algorithm to be used for the group call.

Group Key Number VK-Id

This Group Key Number has to be broadcast and is used by the mobile station to derive the key for ciphering on the radio interface (see 3GPP TS 43.020 [24]). Values 2 to 15 are reserved for future use.

Shall be present if the ciphering applies.

VSTK

The VGCS/VBS Short Term Key is used to derive the key for ciphering on the radio interface (see 3GPP TS 43.020 [24]).

Shall be present if the ciphering applies.

VSTK-RAND

This random number has to be broadcast and is used by the mobile station to derive the group key for ciphering on the radio interface (see 3GPP TS 43.020 [24]).

Shall be present if the ciphering applies.

Priority

Default priority level related to the call if eMLPP applies.

CODEC-Information

Information on the codecs allowed for this call.

Uplink Free Indicator

A flag indicating whether the call is initiated from a dispatcher.

Talker Channel Parameter

A flag indicating by its presence that a dedicated channel shall be established and maintained for the talking service subscriber.

Group Call Number

This temporary allocated E.164 number is used for routing the call from the Anchor MSC to the Relay MSC.

User Error

For definition of this parameter see clause 7.6.1 The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- No Group Call Number available;
- System Failure;
- Unexpected Data Value.

Provider Error

See definition of provider error in clause 7.6.1.

10.5 MAP_PROCESS_GROUP CALL_SIGNALLING service

10.5.1 Definitions

This service is used between Relay MSC and Anchor MSC for transmission of Group Call notifications.

The MAP_PROCESS_GROUP_CALL_SIGNALLING service is a non-confirmed service using the service primitives given in table 10.5/1.

10.5.2 Service primitives

Table 10.5/1: MAP_PROCESS_GROUP_CALL_SIGNALLING service

Parameter name	Request	Indication
Invoke Id	M	M(=)
Uplink Request	C	C(=)
Uplink Release Indication	C	C(=)
AN-APDU	C	C(=)
Release Group Call	C	C(=)

Talker Priority	C	C(=)
Additional Info	C	C(=)
Emergency Mode Reset Command Flag	C	C(=)

10.5.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1

Uplink Request

This information element indicates to the anchor MSC that a service subscriber roaming in the relay MSC area requests access to the uplink.

Uplink Release Indication

This information element if included by the Relay MSC indicates to the Anchor MSC that the uplink has become free.

AN-APDU

This parameter contains the Notification Data message as defined in3GPP TS 48.008 [49].

Release Group Call

This information element if included by the Relay MSC indicates to the Anchor MSC that the service subscriber who has initiated the call and who currently has access to the uplink terminates the call.

Talker Priority

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Emergency Mode Reset Command Flag

For the definition and use of this parameter see 3GPP TS 43.068 [100]

10.6 MAP_FORWARD_GROUP_CALL_SIGNALLING service

10.6.1 Definitions

This service is used between Anchor MSC and Relay MSC for transmission of Group Call notifications.

The MAP_FORWARD_GROUP_CALL_SIGNALLING service is a non-confirmed service using the service primitives given in table 10.6/1.

10.6.2 Service primitives

Table 10.6/1: MAP_FORWARD_GROUP_CALL_SIGNALLING service

Parameter name	Request	Indication
Invoke Id	M	M(=)
IMSI	C	C(=)
Uplink Request Acknowledgement	C	C(=)
Uplink Release Indication	C	C(=)
Uplink Reject Command	C	C(=)
Uplink Seized Command	C	C(=)

Uplink Release Command	C	C(=)
AN-APDU	C	C(=)
State Attributes	C	C(=)
Talker Priority	C	C(=)
Additional Info	C	C(=)
Emergency Mode Reset Command Flag	C	C(=)
SM RP UI	C	C(=)

10.6.3 Parameter definitions and use

IMSI

Identity of the service subscriber who has established the call and who is allowed to terminate the call.

Invoke Id

See definition in clause 7.6.1.

Uplink Request Acknowledgement

This information element is used for positive acknowledgement of an uplink request.

Uplink Release Indication

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink has become free.

Uplink Reject Command

This information element is used for negative acknowledgement of an uplink request.

Uplink Seized Command

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink is no longer free.

Uplink Release Command

This information element if included by the Anchor MSC indicates to the Relay MSC that the uplink which is granted to a MS in the relay MSC area shall be released.

AN-APDU

This parameter contains the Notification Data message as defined in 3GPP TS 48.008 [49]

State Attributes

This information element is used to allow service logic running in an Anchor MSC to mute a VGCS talker even when the talker is served on a Relay MSC. The IE is used to build a GCC message that provides a mechanism to induce the VGCS talker terminal to mute/unmute the downlink at the Anchor MSC, as defined in 3GPP TS 44.068.

Talker Priority

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Emergency Mode Reset Command Flag

For the definition and use of this parameter see 3GPP TS 43.068 [100]

SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter.

10.7 MAP_SEND_GROUP_CALL_END_SIGNAL service

10.7.1 Definitions

This service is used between the Relay MSC and the Anchor MSC. When the VGCS/ VBS calling service subscriber is in the Relay MSC area the MAP_SEND_GROUP_CALL_END_SIGNAL indicates that at least the downlink channel in the originating cell is established. For all other VGCS/ VBS call set-up scenarios (i.e. calling service subscriber in Anchor MSC area, calling service subscriber in other Relay MSC area, dispatcher originated call) the MAP_SEND_GROUP_CALL_END_SIGNAL indicates that at least the downlink channel in any one cell within the VGCS/ VBS call area in the Relay MSC is established. The response is used by the Anchor MSC to inform the Relay MSC that all resources for the call can be released in the Relay MSC because the call has been released in the Anchor MSC.

The MAP_SEND_GROUP_CALL_END_SIGNAL service is a confirmed service using the service primitives given in table 10.7/1.

10.7.2 Service primitives

Table 10.7/1: MAP_SEND_GROUP_CALL_END_SIGNAL service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
Talker Priority	C	C(=)		
Additional Info	C	C(=)		
Provider Error				O

10.7.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1

IMSI

Identity of the service subscriber who has established the call and who is allowed to terminate the call.

Shall be present if the call was established by a service subscriber roaming in the relay MSC area.

Talker Priority

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Provider Error

See definition of provider error in clause 7.6.1.

10.7A MAP_SEND_GROUP_CALL_INFO service

10.7A.1 Definitions

This service is used in a RANflex configuration (see 3GPP TS 23.236 [133]) between the subscriber's visited MSC and group call serving MSC of the subscriber's location area.

The MAP_SEND_GROUP_CALL_INFO service is a confirmed service using the service primitives given in table 10.7A/1.

10.7A.2 Service primitives

Table 10.7A/1: MAP_SEND_GROUP_CALL_INFO service

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Requested Info	M	M(=)		
Teleservice	M	M(=)		
Cell Id	C	C(=)		
Group Id	M	M(=)		
IMSI	C	C(=)	C	C(=)
Talker Priority	C	C(=)		
Additional Info	C	C(=)	C	C(=)
TMSI	C	C(=)		
CKSN	C	C(=)		
Anchor MSC Address			C	C(=)
ASCI Call Reference			C	C(=)
Additional Subscriptions			C	C(=)
Kc			C	C(=)
User Error			C	C(=)
Provider Error				O

10.7A.3 Parameter definitions and use

Invoke Id

See definition in clause 7.6.1

Requested Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Teleservice

Voice Broadcast Service or Voice Group Call Service.

Cell Id

Identity of the initiating service subscriber's current cell.

Group Id

For the definition and use of this parameter see 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]

IMSI

If sent in the request: Identity of the service subscriber who has established the call and who is allowed to terminate the call.
If sent in the response: Identity of the uplink requesting service subscriber.

Talker Priority

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Additional Info

For the definition and use of this parameter see 3GPP TS 43.068 [100]

TMSI

See definition in clause 7.6.2.

CKSN

See clause 7.6.7 for the use of this parameter.

Anchor MSC Address

For the definition and use of this parameter see 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]

ASCI Call Reference

For the definition and use of this parameter see 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]

Additional Subscriptions

For the definition and use of this parameter see 3GPP TS 43.068 [100]

Kc

See clause 7.6.7 for the use of this parameter.

User Error

For definition of this parameter see clause 7.6.1 The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value;
- Data Missing
- TeleserviceNotProvisioned;
- Unknown Subscriber;
- Ongoing Call.

Provider Error

See definition of provider error in clause 7.6.1.

10.8 Void

10.9 Void

10.10 MAP_SET_REPORTING_STATE service

10.10.1 Definition

This service is used between the HLR and the VLR to set the reporting state for a requested service. It is a confirmed service using the service primitives shown in table 10.10/1.

10.10.2 Service primitives

Table 10.10/1: MAP_SET_REPORTING_STATE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
LMSI	C	C(=)		
CCBS Monitoring	C	C(=)		
CCBS Subscriber Status			C	C(=)
User error			C	C(=)
Provider error				O

10.10.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

IMSI

The IMSI is a mandatory parameter if the service is used as the only one in a dialogue.

CCBS Monitoring

This parameter indicates whether monitoring for CCBS shall be started or stopped. If it indicates that monitoring shall be started this service corresponds to the message 'Start Reporting' in 3GPP TS 23.093 [107]; if it indicates that monitoring shall be stopped this service corresponds to the message 'Stop Reporting' in 3GPP TS 23.093 [107].

CCBS Subscriber Status

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System Failure;
- Unidentified Subscriber;
- Unexpected Data Value;
- Data Missing;
- Resource Limitation;
- Facility Not Supported.

NOTE: This error is reserved for future use.

Provider error

These are defined in clause 7.6.

10.11 MAP_STATUS_REPORT service

10.11.1 Definition

This service is used by the VLR to report an event or call outcome to the HLR. It is a confirmed service using the service primitives shown in table 10.11/1.

10.11.2 Service primitives

Table 10.11/1: MAP_STATUS_REPORT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
CCBS Subscriber Status	C	C(=)		
Monitoring Mode	C	C(=)		
Call Outcome	C	C(=)		
User error			C	C(=)
Provider error				O

10.11.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

CCBS Subscriber Status

If this parameter is present without Monitoring Mode and Call Outcome this service corresponds to the message 'Event Report' in 3GPP TS 23.093 [107]. See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Monitoring Mode

If this parameter is present with CCBS Call Outcome this service corresponds to the message 'CCBS Call Report' in 3GPP TS 23.093 [107]. See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Call Outcome

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- Unknown Subscriber;
- System Failure;
- Unexpected Data Value;
- Data Missing.

Provider error

These are defined in clause 7.6.

10.12 MAP_REMOTE_USER_FREE service

10.12.1 Definition

This service is used between the HLR and the VLR to report that the B subscriber is now idle and that the A subscriber can be notified. It is a confirmed service using the service primitives shown in table 10.12/1.

10.12.2 Service primitives

Table 10.12/1: MAP_REMOTE_USER_FREE parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
Call Info	M	M(=)		
CCBS Feature	M	M(=)		
Translated B Number	M	M(=)		
Replace B Number	C	C(=)		
Alerting Pattern	C	C(=)		
RUF Outcome			C	C(=)
User error			C	C(=)
Provider error				O

10.12.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

Call Info

See 3GPP TS 23.093 [107] for the use of this parameter.

CCBS Feature

See 3GPP TS 23.093 [107] for the conditions for the presence of the parameters included in the CCBS feature.

Translated B Number

See 3GPP TS 23.093 [107] for the use of this parameter.

Replace B Number

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Alerting Pattern

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

RUF Outcome

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- Unexpected Data Value;
- Data Missing;
- Incompatible Terminal;

- This error is returned by the responder when the terminal used for CCBS activation is not compatible with the terminal used for the CCBS recall. For details refer to 3GPP TS 24.008 [35];
- Absent Subscriber (IMSI Detach; Restricted Area; No Page Response);
- System Failure;
- Busy Subscriber (CCBS Busy).

Provider error

These are defined in clause 7.6.

10.13 MAP_IST_ALERT service

10.13.1 Definition

This service is used between the MSC (Visited MSC or Gateway MSC) and the HLR, to report that the IST timer running for a call for the Subscriber has expired. It is a confirmed service using the service primitives shown in table 10.13/1.

10.13.2 Service primitives

Table 10.13/1: MAP_IST_ALERT parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
IST Alert Timer			C	C(=)
IST Information Withdraw			C	C(=)
Call termination Indicator			C	C(=)
User error			C	C(=)
Provider error				O

10.13.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

IST Alert Timer

If included in the IST Alert response, it includes the new IST Alert timer value that must be used to inform the HLR about the call activities that the subscriber performs.

IST Information Withdraw

If included in the IST Alert response, this parameter is used to indicate that the IST condition has been removed for the subscriber. When the MSC receives this parameter, IST control for that call shall be terminated.

Call termination Indicator

If included in the IST Alert response, this parameter is used to indicate whether the MSC shall terminate the call activity that had previously triggered the IST Alert procedure, or it shall also release all other call activities for the specified subscriber (outgoing call activities if the IST Alert is initiated by the VMSC, or incoming call activities if the IST Alert is initiated by the GMSC). Release of all other call activities is possible only if the MSC has the capability to link the call activities for the Subscriber by using the IMSI as key.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;

- Unexpected Data Value;
- Resource Limitation;
- Facility Not Supported;
- Unknown Subscriber.

10.14 MAP_IST_COMMAND service

10.14.1 Definition

This service is used by the HLR to instruct the MSC (Visited MSC or Gateway MSC) to terminate ongoing call activities for a specific subscriber. It is a confirmed service using the service primitives shown in table 10.14/1.

10.14.2 Service primitives

Table 10.14/1: MAP_IST_COMMAND parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
User error			C	C(=)
Provider error				O

10.14.3 Parameter use

All parameters are described in clause 7.6. The following clarifications are applicable:

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Unexpected Data Value;
- Resource Limitation;
- Facility Not Supported;
- Unknown Subscriber.

10.15 MAP_RELEASE_RESOURCES service

10.15.1 Definition

This service is used between the GMSC and the terminating VMSC. The service is invoked by the GMSC to request the VMSC to release the resources associated with the specified MSRN.

This is a confirmed service which uses the Primitives listed in table 10.15/1.

10.15.2 Service primitives

Table 10.15/1: MAP_RELEASE_RESOURCES parameters

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSRN	M	M(=)		

User error			C	C(=)
Provider error				O

10.15.3 Parameter use

MSRN

See 3GPP TS 23.018 [97] for the use of this parameter.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Unexpected Data Value;

Provider error

These are defined in clause 7.6.

11 Supplementary services related services

11.1 MAP_REGISTER_SS service

11.1.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to register data related to a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.1./1.

11.1.2 Service primitives

Table 11.1/1: MAP_REGISTER_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarded-to number with subaddress	C	C(=)		
No reply condition time	C	C(=)		
EMLPP default priority	C	C(=)	C	C(=)
Long FTN Supported	C	C(=)		
NbrUser	C	C(=)	C	C(=)
Forwarding information			C	C(=)
User error			C	C(=)
Provider error				O

11.1.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to register.

Basic service

This parameter indicates for which basic service group the supplementary service is to be registered. If it is not included, the registration request applies to all basic services.

Forwarded-to number with subaddress

This parameter is obligatory if the registration applies to one or more call forwarding supplementary services. It can optionally include a sub-address.

No reply condition time

This parameter is included if the registration applies to the Call Forwarding on No Reply supplementary service (or a superset of this service) and the mobile subscriber supplies a value for this time.

EMLPP default priority

This parameter is sent by the initiator to register the eMLPP default priority level and is returned by the responder at successful outcome of the service.

Long FTN Supported

This parameter indicates that the mobile station supports Long Forwarded-to Numbers.

NbrUser

This parameter is sent by the initiator to register the MC maximum number of user defined circuit switched bearers to be used.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the registration request concerned one or a group of Call Forwarding supplementary services.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;
- Call Barred;
- Bearer service not provisioned;
- This error is returned only if not even a subset of the requested bearer service group has been subscribed to;
- Teleservice not provisioned;

  This error is returned only if not even a subset of the requested teleservice group has been subscribed to;
- Illegal SS operation;
- SS error status;
- SS incompatibility.

Provider error

See clause 7.6.1 for the use of this parameter.

11.2 MAP_ERASE_SS service

11.2.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to erase data related to a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.2/1.

11.2.2 Service primitives

Table 11.2/1: MAP_ERASE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarding information			C	C(=)
User error			C	C(=)
Provider error				O

11.2.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to erase.

Basic service

This parameter indicates for which basic service group the supplementary service should be erased. If it is not included, the erasure request applies to all basic services.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the erasure request concerned one or a group of Call Forwarding supplementary services.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

  This error is returned only if not even a subset of the requested bearer service group has been subscribed to;
- Teleservice not provisioned;

  This error is returned only if not even a subset of the requested teleservice group has been subscribed to;
- Call Barred;
- Illegal SS operation;

- SS error status.

Provider error

See clause 7.6.1 for the use of this parameter.

11.3 MAP_ACTIVATE_SS service

11.3.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to activate a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.3/1.

11.3.2 Service primitives

Table 11.3/1: MAP_ACTIVATE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Long FTN Supported	C	C(=)		
Basic service	C	C(=)		
Forwarding information			C	C(=)
Call barring information			C	C(=)
SS-Data			C	C(=)
User error			C	C(=)
Provider error				O

11.3.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to activate.

Basic service

This parameter indicates for which basic service groups the requested supplementary service(s) should be activated. If it is not included, the activation request applies to all basic services.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned Call Forwarding.

Long FTN Supported

This parameter indicates that the mobile station supports Long Forwarded-to Numbers.

Call barring information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned Call Barring.

SS-Data

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned for example Call Waiting.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;
- This error is returned only if not even a subset of the requested bearer service group has been subscribed to.
- Teleservice not provisioned;
- This error is returned only if not even a subset of the requested teleservice group has been subscribed to.
- Call Barred;
- Illegal SS operation;
- SS error status;
- SS subscription violation;
- SS incompatibility;
- Negative PW check;
- Number Of PW Attempts Violation.

Provider error

See clause 7.6.1 for the use of this parameter.

11.4 MAP_DEACTIVATE_SS service

11.4.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR to deactivate a supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.4/1.

11.4.2 Service primitives

Table 11.4/1: MAP_DEACTIVATE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Forwarding information			C	C(=)
Call barring information			C	C(=)
SS-Data			C	C(=)
User error			C	C(=)
Provider error				O

11.4.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates the supplementary service which the mobile subscriber wants to deactivate.

Basic service

This parameter indicates for which basic service group the requested supplementary service(s) should be deactivated. If it is not included the deactivation request applies to all basic services.

Forwarding information

This parameter is returned by the responder at successful outcome of the service, if the deactivation request concerned one or a group of Call Forwarding supplementary services.

Call barring information

This parameter is returned by the responder at successful outcome of the service, if the activation request concerned one or a group of Call Barring supplementary services.

SS-Data

This parameter is returned by the responder at successful outcome of the service, for example if the deactivation request concerned the Call Waiting supplementary service.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer service not provisioned;

  This error is returned only if not even a subset of the requested bearer service group has been subscribed to;
- Teleservice not provisioned;

  This error is returned only if not even a subset of the requested teleservice group has been subscribed to;
- Call Barred;
- Illegal SS operation;
- SS error status;
- SS subscription violation;
- Negative PW check;
- Number Of PW Attempts Violation.

Provider error

See clause 7.6.1 for the use of this parameter.

11.5 MAP_INTERROGATE_SS service

11.5.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR to retrieve information related to a supplementary service. The VLR will relay the message to the HLR if necessary.

The service is a confirmed service and consists of four service primitives.

11.5.2 Service primitives

The service primitives are shown in table 11.5/1.

Table 11.5/1: MAP_INTERROGATE_SS parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
Basic service	C	C(=)		
Long FTN Supported	C	C(=)		
SS-Status			C	C(=)
Basic service Group LIST			C	C(=)
Forwarding feature LIST			C	C(=)
CLI restriction Info			C	C(=)
EMLPP Info			C	C(=)
MC Information			C	C(=)
CCBS Feature LIST			C	C(=)
User error			C	C(=)
Provider error				O

11.5.3 Parameter use

For additional information on parameter use refer to the GSM 04.8x and 04.9x-series of technical specifications.

Invoke id

See clause 7.6.1 for the use of this parameter.

SS-Code

The mobile subscriber can only interrogate a single supplementary service per service request.

Basic service

This parameter indicates for which basic service group the given supplementary service is interrogated. If it is not included, the interrogation request applies to all basic services.

SS-Status

This parameter is included by the responder if:

- the interrogated supplementary service can only be subscribed for all applicable basic services simultaneously; or
- the interrogated supplementary service is not active for any of the interrogated basic services, or
- the interrogation was for the CCBS supplementary service and no CCBS request is active or the service is not provisioned.

Basic service group LIST

This parameter LIST is used to include one or a series of basic service groups for which the interrogated supplementary service is active. If the interrogated supplementary service is not active for any of the interrogated (and provisioned) basic service groups, the SS-Status parameter is returned.

Long FTN Supported

This parameter indicates that the mobile station supports Long Forwarded-to Numbers.

Forwarding feature LIST

The forwarding feature parameter is described in clause 7.6.4. A list of one or more forwarding features is returned by the responder when the interrogation request applied to Call Forwarding supplementary service.

If no basic service code parameter is provided within this sequence, the forwarding feature parameter applies to all provisioned basic services.

CLI restriction Info

The CLI-RestrictionInfo parameter is returned by the responder when the interrogation request applies to the CLIR supplementary service.

EMLPP Info

The eMLPP info (maximum entitled priority and default priority) is returned by the responder if the interrogation request applies to the eMLPP supplementary service.

MC Information

The MC information (NbrSB, NbrUser and NbrSN) is returned by the responder if the interrogation request applies to the MC supplementary service. For a definition of these 3 components, refer to 3GPP TS 23.135 and 3GPP TS 24.135.

CCBS Feature LIST

The CCBS feature parameter is described in clause 7.6. A list of one or more CCBS features is returned by the responder when the interrogation request applied to the CCBS supplementary service. See 3GPP TS 23.093 [107] for the conditions for the presence of the parameters included in the CCBS feature.

User error

This error is sent by the responder upon unsuccessful outcome of the interrogation service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Bearer Service not provisioned;

  This error is returned only if not even a subset of the interrogated bearer services are provided;
- Teleservice not provisioned;

  This error is returned only if not even a subset of the interrogated teleservices are provided;
- Call Barred;
- Illegal SS operation;
- SS not available.

Provider error

See clause 7.6.1 for the use of this parameter.

11.6 Void

11.7 MAP_REGISTER_PASSWORD service

11.7.1 Definitions

This service is used between the MSC and the VLR and between the VLR and the HLR if the mobile subscriber requests to register a new password. The VLR will relay the message to the HLR.

The service is a confirmed service and consists of four service primitives.

11.7.2 Service primitives

The service primitives are shown in table 11.7/1.

Table 11.7/1: MAP_REGISTER_PASSWORD parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)		
New password			C	C(=)
User error			C	C(=)
Provider error				O

11.7.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

SS-Code

This parameter indicates for which supplementary service(s) the password should be registered.

New Password

See clause 7.6.4 for the use of this parameter.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;
- Unexpected data value;
- Call Barred;
- SS subscription violation;
- Password registration failure;
- Negative PW check;
- Number Of PW Attempts Violation.

Provider error

See clause 7.6.1 for the use of this parameter.

11.8 MAP_GET_PASSWORD service

11.8.1 Definitions

This service is used between the HLR and the VLR and between the VLR and the MSC when the HLR receives a request from the mobile subscriber for an operation on a supplementary service which requires a password from the subscriber. The VLR will relay the message to the MSC.

The service is a confirmed service and uses the service primitives shown in table 11.8/1.

11.8.2 Service primitives

Table 11.8/1: MAP_GET_PASSWORD parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Linked id	C	C(=)		
Guidance info	M	M(=)		
Current password			M	M(=)
Provider error				O

11.8.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

Linked Id

See clause 7.6.1 for the use of this parameter. If the MAP_GET_PASSWORD service is used in conjunction with the MAP_REGISTER_PASSWORD service, this parameter must be present; otherwise it must be absent.

Guidance info

See clause 7.6.4 for the use of this parameter.

Current password

See clause 7.6.4 for the use of this parameter.

Provider error

See clause 7.6.1 for the use of this parameter.

11.9 MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service

11.9.1 Definitions

This service is used between the MSC and the VLR, between the VLR and the HLR, between the HLR and gsmSCF and between the HLR and HLR to relay information in order to allow unstructured supplementary service operation.

The MAP_PROCESS_UNSTRUCTURED_SS_REQUEST service is a confirmed service using the primitives from table 11.9/1.

11.9.2 Service primitives

Table 11.9/1: MAP_PROCESS_UNSTRUCTURED_SS_REQUEST parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)	C	C(=)
USSD String	M	M(=)	C	C(=)
MSISDN	C	C(=)		
User error			C	C(=)
Provider error				O

11.9.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

USSD Data Coding Scheme

See clause 7.6.4 for the use of this parameter. The presence of the parameter in the response is dependent on the unstructured supplementary service application. If this parameter is present, then the USSD String parameter has to be present.

USSD String

See clause 7.6.1 for the use of this parameter. The presence of the parameter in the response is dependent on the unstructured supplementary service application. If this parameter is present, then the USSD Data Coding Scheme parameter has to be present.

MSISDN

The subscriber"s basic MSISDN.

See definition in clause 7.6.2. For Follow Me when the service request is sent from the HLR of the A subscriber, the parameter shall contain the MSISDN of the A subscriber, see 3GPP TS 23.094 [129]. For other purposes the MSISDN may be included as an operator option, e.g. to allow addressing the subscriber"s data in the gsmSCF with the MSISDN.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

  This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Call Barred;
- Unknown Alphabet.

Provider error

See clause 7.6.1 for the use of this parameter.

11.10 MAP_UNSTRUCTURED_SS_REQUEST service

11.10.1 Definitions

This service is used between the gsmSCF and the HLR, the HLR and the VLR and between the VLR and the MSC when the invoking entity requires information from the mobile user, in connection with unstructured supplementary service handling.

The MAP_UNSTRUCTURED_SS_REQUEST service is a confirmed service using the primitives from table 11.10/1.

11.10.2 Service primitives

Table 11.10/1: MAP_UNSTRUCTURED_SS_REQUEST parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)	C	C(=)
USSD String	M	M(=)	C	C(=)
Alerting Pattern	C	C(=)		
User error			C	C(=)
Provider error				O

11.10.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

USSD Data Coding Scheme

See clause 7.6.4 for the use of this parameter. The presence of the parameter in the response is dependent on the mobile user's MMI input. If this parameter is present, then the USSD String parameter has to be present.

USSD String

See clause 7.6.1 for the use of this parameter. The presence of the parameter in the response is dependent on the mobile user's MMI input. If this parameter is present, then the USSD Data Coding Scheme parameter has to be present.

Alerting Pattern

See clause 7.6.3 for the use of this parameter.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

  This error is returned by the responder if it is not able to deal with the contents of the USSD string;

- Absent Subscriber;
- Illegal Subscriber;

  This error indicates that delivery of the unstructured supplementary service data failed because the MS failed authentication;

- Illegal Equipment;
- USSD Busy;
- Unknown Alphabet.

Provider error

See clause 7.6.1 for the use of this parameter.

11.11 MAP_UNSTRUCTURED_SS_NOTIFY service

11.11.1 Definitions

This service is used between the gsmSCF and the HLR, the HLR and the VLR and between the VLR and the MSC when the invoking entity requires a notification to be sent to the mobile user, in connection with unstructured supplementary services handling.

The MAP_UNSTRUCTURED_SS_NOTIFY service is a confirmed service using the primitives from table 11.11/1.

11.11.2 Service primitives

Table 11.11/1: MAP_UNSTRUCTURED_SS_NOTIFY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
USSD Data Coding Scheme	M	M(=)		
USSD String	M	M(=)		
Alerting Pattern	C	C(=)		
User error			C	C(=)
Provider error				O

11.11.3 Parameter use

Invoke id

See clause 7.6.1 for the use of this parameter.

USSD Data Coding Scheme:

See clause 7.6.4 for the use of this parameter.

USSD String:

See clause 7.6.1 for the use of this parameter.

Alerting Pattern

See clause 7.6.3 for the use of this parameter.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;

  This error is returned by the responder if it is not able to deal with the contents of the USSD string.

- Absent Subscriber;
- Illegal Subscriber;

  This error indicates that delivery of the unstructured supplementary service data failed because the MS failed authentication.

- Illegal Equipment;
- USSD Busy;

- Unknown Alphabet.

Provider error

See clause 7.6.1 for the use of this parameter.

11.12 MAP_SS_INVOCATION_NOTIFY

11.12.1 Definition

This service is used between the MSC and the gsmSCF when the subscriber invokes one of the following supplementary services; Call Deflection (CD), Explicit Call Transfer (ECT) or Multi Party (MPTY).

This service is used between the HLR and the gsmSCF when the subscriber invokes the CCBS supplementary service.

11.12.2 Service primitives

The service primitives are shown in table 11.12/1.

Table 11.12/1: SS_INVOCATION_NOTIFY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
IMSI	M	M(=)		
SS- event	M	M(=)		
SS- event data	C	C(=)		
B-subscriber Number	C	C(=)		
CCBS Request State	C	C(=)		
User error			C	C(=)
Provider error				O

11.12.3 Parameter use

All parameters are described in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.078.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

This is defined in clause 7.6.1.

11.13 MAP_REGISTER_CC_ENTRY service

11.13.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to register data for a requested call completion supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.13/1.

11.13.2 Service primitives

Table 11.13/1: MAP_REGISTER_CC_ENTRY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS Code	M	M(=)		
CCBS Feature	C	C(=)	C	C(=)
Translated B number	C	C(=)		
Service Indicator	C	C(=)		
Call Info	C	C(=)		
Network Signal Info	C	C(=)		
User error			C	C(=)
Provider error				O

11.13.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

SS-Code

This parameter indicates the call completion supplementary service for which the mobile subscriber wants to register an entry.

CCBS Feature

See 3GPP TS 23.093 [107] for the conditions for the presence of the parameters included in the CCBS feature.

Translated B Number

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Service Indicator

This parameter corresponds to the parameters 'Presentation Indicator' and 'CAMEL Invoked' in 3GPP TS 23.093 [107]. It indicates which services have been invoked for the original call (e.g. CLIR, CAMEL). See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Call Info

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

Network Signal Info

See 3GPP TS 23.093 [107] for the use of this parameter and the conditions for its presence.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data missing;
- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status;
- SS incompatibility.

- Short Term Denial;
- Long Term Denial;
- Facility Not Supported;

NOTE: This error is reserved for future use.

Private Extensions shall not be sent with these user errors for this operation.

Provider error

See clause 7.6.1 for the use of this parameter.

11.14 MAP_ERASE_CC_ENTRY service

11.14.1 Definition

This service is used between the MSC and the VLR and between the VLR and the HLR to erase data related to a call completion supplementary service. The VLR will relay the message to the HLR.

The service is a confirmed service and uses the service primitives shown in table 11.14/1.

11.14.2 Service primitives

Table 11.14/1: MAP_ERASE_CC_ENTRY parameters

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
SS-Code	M	M(=)	C(=)	C(=)
CCBS Index	C	C(=)		
SS-Status			C	C(=)
User error			C	C(=)
Provider error				O

11.14.3 Parameter use

See clause 7.6 for a definition of the parameters used, in addition to the following.

SS-Code

This parameter indicates the call completion supplementary service for which the mobile subscriber wants to erase an entry/entries.

CCBS Index

See 3GPP TS 23.093 [107] for the use of this parameter and the condition for its presence.

SS-Status

Depending on the outcome of the service request this parameter may indicate either provisioned and active or not provisioned.

User error

This parameter is sent by the responder upon unsuccessful outcome of the service, and then takes one of the following values, defined in clause 7.6.1:

- System failure;
- Data Missing;

- Unexpected data value;
- Call Barred;
- Illegal SS operation;
- SS error status.

Private Extensions shall not be sent with these user errors for this operation.

Provider error

See clause 7.6.1 for the use of this parameter.

12 Short message service management services

12.1 MAP-SEND-ROUTING-INFO-FOR-SM service

12.1.1 Definition

This service is used between the gateway MSC and the HLR to retrieve the routing information needed for routing the short message to the servicing MSC or SGSN. This service is also used between the gateway MSC and SMS Router, and SMS Router and HLR in order to enforce routing of the SM delivery via the HPLMN of the receiving MS. This service is also used between HLR and IP-SM-GW, and between IP-SM-GW and HLR in order to allow MT-SM delivery via the IMS.

The MAP-SEND-ROUTING-INFO-FOR-SM is a confirmed service using the primitives from table 12.1/1.

12.1.2 Service primitives

Table 12.1/1: MAP-SEND-ROUTING-INFO-FOR-SM

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
SM-RP-PRI	M	M(=)		
Service Centre Address	M	M(=)		
SM-RP-MTI	C	C(=)		
SM-RP-SMEA	C	C(=)		
GPRS Support Indicator	C	C(=)		
SM-Delivery Not Intended	U	C(=)		
IMSI			C	C(=)
Network Node Number			C	C(=)
LMSI			C	C(=)
GPRS Node Indicator			C	C(=)
Additional Number			C	C(=)
User error			C	C(=)
Provider error				O

12.1.3 Parameter use

Invoke id

See definition in clause 7.6.1.

MSISDN

See definition in clause 7.6.2.

SM-RP-PRI

See definition in clause 7.6.8.

Service Centre Address

See definition in clause 7.6.2.

SM-RP-MTI

See definition in clause 7.6.8. This parameter shall be present when the feature « SM filtering by the HPLMN » is supported by the SMS-GMSC and when the equivalent parameter is received from the short message service relay sub-layer protocol.

SM-RP-SMEA

See definition in clause 7.6.8. This parameter shall be present when the feature « SM filtering by the HPLMN » is supported by the SMS-GMSC and when the equivalent parameter is received from the short message service relay sub-layer protocol.

GPRS Support Indicator

See definition in clause 7.6.8. The presence of this parameter is mandatory if the SMS-GMSC supports receiving of the two numbers from the HLR.

SM-Delivery Not Intended

This parameter indicates by its presence that delivery of a short message is not intended. It further indicates whether only IMSI or only MCC+MNC are requested.

This parameter may be set by entities that request the service without intending to deliver a short message (e.g. MMS Relay/Server), and shall be evaluated by the SMS Router and may be evaluated by the HLR.

IMSI

See definition in clause 7.6.2. If enforcement of routing an SM via the HPLMN of the receiving MS is deployed, this parameter contains an MT Correlation ID instead of an IMSI when the service is used between SMS-GMSC and SMS Router (see 3GPP TS 23.040 [26] for more information). If the "SM-Delivery Not Intended" parameter was present in the Indication with a value of "only MCC+MNC requested", then this parameter may contain MCC+MNC+dummy MSIN.

The presence of this parameter is mandatory in a successful case.

Network Node Number

See definition in clause 7.6.2. This parameter is provided in a successful response. If the "SM-Delivery Not Intended" parameter was present in the Indication a dummy address may be provided.

LMSI

See definition in clause 7.6.2. It is an operator option to provide this parameter from the VLR; it is mandatory for the HLR to include the LMSI in a successful response, if the VLR has used the LMSI.

GPRS Node Indicator

See definition in clause 7.6.8. The presence of this parameter is mandatory if only the SGSN number is sent in the Network Node Number.

Additional Number

See definition in clause 7.6.2. This parameter is provided in a successful response.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;

- Call Barred;
- Teleservice Not Provisioned;
- Absent Subscriber_SM;
- Facility Not Supported;
- System failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see clause 7.6.1.

12.2 MAP-MO-FORWARD-SHORT-MESSAGE service

12.2.1 Definition

This service is used between the serving MSC or the SGSN and the SMS Interworking MSC to forward mobile originated short messages.

The MAP-MO-FORWARD-SHORT-MESSAGE service is a confirmed service using the service primitives given in table 12.2/1.

12.2.2 Service primitives

Table 12.2/1: MAP-MO-FORWARD-SHORT-MESSAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	C	C(=)
IMSI	C	C(=)		
User error			C	C(=)
Provider error				O

12.2.3 Parameter use

Invoke id

See definition in clause 7.6.1.

SM RP DA

See definition in clause 7.6.8.

In the mobile originated SM transfer this parameter contains the Service Centre address received from the mobile station.

SM RP OA

See definition in clause 7.6.8.

The MSISDN received from the VLR or from the SGSN is inserted in this parameter in the mobile originated SM transfer.

SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter.

IMSI

See definition in clause 7.6.2.1. The IMSI of the originating subscriber is inserted in this parameter in the mobile originated SM transfer.

This parameter shall be included if the sending entity, whether MSC or SGSN, supports mobile number portability.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Facility Not Supported;
- System Failure;
- SM Delivery Failure;
  - The reason of the SM Delivery Failure can be one of the following in the mobile originated SM:
    - unknown Service Centre address;
    - Service Centre congestion;
    - invalid Short Message Entity address;
    - subscriber not Service Centre subscriber;
    - protocol error.
- Unexpected Data Value

Provider error

For definition of provider errors see clause 7.6.1.

12.3 MAP-REPORT-SM-DELIVERY-STATUS service

12.3.1 Definition

This service is used between the gateway MSC and the HLR or the external Short Message Gateway (IP-SM-GW) and the HLR. The MAP-REPORT-SM-DELIVERY-STATUS service is used to set the Message Waiting Data into the HLR or to inform the HLR of successful SM transfer after polling. This service is invoked by the gateway MSC or the external Short Message Gateway (IP-SM-GW).

The MAP-REPORT-SM-DELIVERY-STATUS service is a confirmed service using the service primitives given in table 12.3/1.

12.3.2 Service primitives

Table 12.3/1: MAP-REPORT-SM-DELIVERY-STATUS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSISDN	M	M(=)		
Service Centre Address	M	M(=)		
SM Delivery Outcome	M	M(=)		
Absent Subscriber Diagnostic SM	C	C(=)		
GPRS Support Indicator	C	C(=)		
Delivery Outcome Indicator	C	C(=)		
Additional SM Delivery Outcome	C	C(=)		
Additional Absent Subscriber Diagnostic SM	C	C(=)		

IP-SM-GW-Indicator	C	C(=)		
IP-SM-GW SM Delivery Outcome	C	C(=)		
IP-SM-GW Absent Subscriber Diagnostic SM	C	C(=)		
MSIsdn-Alert			C	C(=)
User error			C	C(=)
Provider error				O

12.3.3 Parameter use

Invoke id

See definition in clause 7.6.1.

MSISDN

See definition in clause 7.6.2.

Service Centre Address

See definition in clause 7.6.2.

SM Delivery Outcome

See definition in clause 7.6.8. This parameter indicates the status of the mobile terminated SM delivery.

Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

GPRS Support Indicator

See definition in clause 7.6.8. The presence of this parameter is mandatory if the SMS-GMSC supports handling of two delivery outcomes.

Delivery Outcome Indicator

See definition in clause 7.6.8.

Additional SM Delivery Outcome

See definition in clause 7.6.8.

Additional Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

IP-SM-GW Indicator

See definition in clause 7.6.8.

IP-SM-GW SM Delivery Outcome

See definition in clause 7.6.8.

IP-SM-GW Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

MSIsdn-Alert

See definition in clause 7.6.2. This parameter shall be present in case of unsuccessful delivery, when the MSISDN received in the operation is different from the stored MSIsdn-Alert; the stored MSIsdn-Alert is the value that is returned to the gateway MSC.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown Subscriber;
- Message Waiting List Full;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see clause 7.6.1.

12.4 MAP-READY-FOR-SM service

12.4.1 Definition

This service is used between the MSC and VLR as well as between the VLR and the HLR. The MSC initiates this service if a subscriber indicates memory available situation. The VLR uses the service to indicate this to the HLR.

The VLR initiates this service if a subscriber, whose message waiting flag is active in the VLR, has radio contact in the MSC.

Also this service is used between the SGSN and the HLR. The SGSN initiates this service if a subscriber indicates memory available situation. The SGSN uses the service to indicate this to the HLR.

Also this service is used between the HSS and the IWF.

The SGSN initiates this service if a subscriber, whose message waiting flag is active in the SGSN, has radio contact in the GPRS.

The MAP-READY-FOR-SM service is a confirmed service using the primitives from table 12.4/1.

12.4.2 Service primitives

Table 12.4/1: MAP-READY-FOR-SM

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
IMSI	C	C(=)		
TMSI	C	C(=)		
Alert Reason	M	M(=)		
Alert Reason Indicator	C	C(=)		
Additional Alert Reason Indicator	C	C(=)		
User error			C	C(=)
Provider error				O

12.4.3 Parameter use

Invoke id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2. The IMSI is used always between the VLR and the HLR and between the SGSN and the HLR and between the HSS and the IWF. Between the MSC and the VLR the identification can be either IMSI or TMSI.

TMSI

See definition in clause 7.6.2. The identification can be either IMSI or TMSI between MSC and VLR.

Alert Reason

See definition in clause 7.6.8. This parameter indicates if the mobile subscriber is present or the MS has memory available.

Alert Reason Indicator

See definition in clause 7.6.8.

Additional Alert Reason Indicator

See definition in clause 7.6.8.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown Subscriber;
- Facility Not Supported;
- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see clause 7.6.1.

12.5 MAP-ALERT-SERVICE-CENTRE service

12.5.1 Definition

This service is used between the HLR and the interworking MSC. The HLR initiates this service, if the HLR detects that a subscriber, whose MSISDN is in the Message Waiting Data file, is active or the MS has memory available.

The MAP-ALERT-SERVICE-CENTRE service is a confirmed service using the primitives from table 12.5/1.

12.5.2 Service primitives

Table 12.5/1: MAP-ALERT-SERVICE-CENTRE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MSIsdn-Alert	M	M(=)		
Service Centre Address	M	M(=)		
User error			C	C(=)
Provider error				O

12.5.3 Parameter use

Invoke id

See definition in clause 7.6.1.

MSIsdn-Alert

See definition in clause 7.6.2. The provided MSISDN shall be the one which is stored in the Message Waiting Data file.

Service Centre Address

See definition in clause 7.6.2.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value;
- Data missing.

Provider error

For definition of provider errors see clause 7.6.1.

12.6 MAP-INFORM-SERVICE-CENTRE service

12.6.1 Definition

This service is used between the HLR and the gateway MSC (transiting an SMS Router, if present) to inform the Service Centre which MSISDN number is stored in the Message Waiting Data file. If the stored MSISDN number is not the same as the one received from the gateway MSC in the MAP-SEND-ROUTING-INFO-FOR-SM service primitive the stored MSISDN number is included in the message.

Additionally the status of MCEF, MNRF and MNRG flags and the inclusion of the particular Service Centre address in the Message Waiting Data list is informed to the gateway MSC when appropriate.

If the HLR has stored a single MNRR, the value is included in the Absent Subscriber Diagnostic SM parameter.

If the HLR has stored a second MNRR, the value of the MNRR for the MSC is included in the Absent Subscriber Diagnostic SM parameter and the value of the MNRR for the SGSN is included in the Additional Absent Subscriber Diagnostic SM parameter.

The MAP-INFORM-SERVICE-CENTRE service is a non-confirmed service using the primitives from table 12.6/1.

12.6.2 Service primitives

Table 12.6/1: MAP-INFORM-SERVICE-CENTRE

Parameter name	Request	Indication
Invoke Id	M	M(=)
MSIsdn-Alert	C	C(=)
MWD Status	C	C(=)
Absent Subscriber Diagnostic SM	C	C(=)
Additional Absent Subscriber Diagnostic SM	C	C(=)

12.6.3 Parameter use

Invoke id

See definition in clause 7.6.1.

MSIsdn-Alert

See definition in clause 7.6.2. This parameter refers to the MSISDN stored in a Message Waiting Data file in the HLR.

MWD Status

See definition in clause 7.6.8. This parameter indicates the status of the MCEF, MNRF and MNRG flags and the status of the particular SC address presence in the Message Waiting Data list.

Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

Additional Absent Subscriber Diagnostic SM

See definition in clause 7.6.8.

12.7 MAP-SEND-INFO-FOR-MT-SMS service

12.7.1 Definition

This service is used between the MSC and the VLR. The service is invoked by the MSC receiving a mobile terminated short message to request subscriber related information from the VLR.

The MAP-SEND-INFO-FOR-MT-SMS service is a confirmed service using the primitives from table 12.7/1.

12.7.2 Service primitives

Table 12.7/1: MAP-SEND-INFO-FOR-MT-SMS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
IMSI	C	C(=)		
MSISDN			C	C(=)
User error			C	C(=)
Provider error				O

12.7.3 Parameter use

Invoke id

See definition in clause 7.6.1.

SM RP DA

See definition in clause 7.6.8. This parameter shall contain either an IMSI or an LMSI.

IMSI

See definition in clause 7.6.2. This parameter shall be present if the SM RP DA parameter contains an LMSI; otherwise it shall be absent.

MSISDN

See definition in clause 7.6.2.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Unidentified Subscriber;
- Absent subscriber;

- Unexpected Data Value;
- Data Missing;
- Illegal subscriber;
- Illegal equipment;
- Subscriber busy for MT SMS;
- System Failure.

Provider error

For definition of provider errors see clause 7.6.1.

12.8 MAP-SEND-INFO-FOR-MO-SMS service

12.8.1 Definition

This service is used between the MSC and the VLR. The service is invoked by the MSC which has to handle a mobile originated short message request to request the subscriber related information from the VLR.

The MAP-SEND-INFO-FOR-MO-SMS service is a confirmed service using the primitives from table 12.8/1.

12.8.2 Service primitives

Table 12.8/1: MAP-SEND-INFO-FOR-MO-SMS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
Service Centre Address	M	M(=)		
MSISDN			C	C(=)
User error			C	C(=)
Provider error				O

12.8.3 Parameter use

Invoke id

See definition in clause 7.6.1.

Service Centre Address

See definition in clause 7.6.2.

MSISDN

See definition in clause 7.6.2.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Teleservice Not Provisioned;
- Call Barred;
- Unexpected Data Value;
- Data Missing.

Provider error

For definition of provider errors see clause 7.6.1.

12.9 MAP-MT-FORWARD-SHORT-MESSAGE service

12.9.1 Definition

This service is used between the gateway MSC and the serving MSC or the SGSN (transiting an SMS Router, if present) to forward mobile terminated short messages.

The MAP-MT-FORWARD-SHORT-MESSAGE service is a confirmed service using the service primitives given in table 12.9/1.

12.9.2 Service primitives

Table 12.9/1: MAP-MT-FORWARD-SHORT-MESSAGE

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
SM RP DA	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	C	C(=)
More Messages To Send	C	C(=)		
User error			C	C(=)
Provider error				O

12.9.3 Parameter use

Invoke id

See definition in clause 7.6.1.

SM RP DA

See definition in clause 7.6.8. This parameter can contain either an IMSI or a LMSI. The use of the LMSI is an operator option. The LMSI can be provided if it is received from the HLR. The IMSI is used if the use of the LMSI is not available.

This parameter is omitted in the mobile terminated subsequent SM transfers.

SM RP OA

See definition in clause 7.6.8. The Service Centre address received from the originating Service Centre is inserted in this parameter.

This parameter is omitted in the mobile terminated subsequent SM transfers.

SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter. A short message transfer protocol data unit may also be inserted in this parameter in the message delivery acknowledgement from the MSC or from the SGSN to the Service Centre.

More Messages To Send

See definition in clause 7.6.8. The information from the MMS indication received from the Service Centre is inserted in this parameter.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unidentified subscriber;

- Absent Subscriber_SM;
- Subscriber busy for MT SMS;
- Facility Not Supported;
- Illegal Subscriber indicates that delivery of the mobile terminated short message failed because the mobile station failed authentication;
- Illegal equipment indicates that delivery of the mobile terminated short message failed because an IMEI check failed, i.e. the IMEI was blacklisted or not white-listed;
- System Failure;
- SM Delivery Failure:
  - The reason of the SM Delivery Failure can be one of the following in the mobile terminated SM:
    - memory capacity exceeded in the mobile equipment;
    - protocol error;
    - mobile equipment does not support the mobile terminated short message service.
- Unexpected Data Value;
- Data Missing.

Provider error

For definition of provider errors see clause 7.6.1.

12.10 MAP-MT-FORWARD-SM-FOR-VGCS service

12.10.1 Definition

This service is used between the SMS gateway MSC and the Group Call Anchor MSC to forward mobile terminated short messages into an ongoing voice group call.

The MAP-MT-FORWARD-SM-FOR-VGCS service is a confirmed service using the service primitives given in table 12.10/1.

12.10.2 Service primitives

Table 12.10/1: MAP-MT-FORWARD-SM-VGCS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
ASCI Call Reference	M	M(=)		
SM RP OA	M	M(=)		
SM RP UI	M	M(=)	C	C(=)
Dispatcher List			C	C(=)
Ongoing Call Indicator			C	C(=)
User error			C	C(=)
Provider error				O

12.10.3 Parameter use

Invoke id

See definition in clause 7.6.1.

ASCI Call Reference

Group call reference. This item is used to access the VGCS-GCR within the Anchor_MSC.

SM RP OA

See definition in clause 7.6.8. The Service Centre address received from the originating Service Centre is inserted in this parameter.

SM RP UI

See definition in clause 7.6.8. The short message transfer protocol data unit received from the Service Centre is inserted in this parameter. A short message transfer protocol data unit may also be inserted in this parameter in the message delivery acknowledgement from the MSC to the Service Centre.

Dispatcher List

A list of identities (international E.164 phone numbers) identifying the dispatchers of the VGCS call. It shall be present if received from the GCR; otherwise shall be absent.

Ongoing Call Indicator

Indicates by its presence that the VGCS call is ongoing.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- System Failure;
- Unexpected Data Value.

Provider error

For definition of provider errors see clause 7.6.1.

13 Network-Requested PDP Context Activation services

13.1 MAP_SEND_ROUTING_INFO_FOR_GPRS service

13.1.1 Definition

This service is used by the GGSN to request GPRS routing information from the HLR.

13.1.2 Service primitives

Table 13.1/1: MAP_SEND_ROUTING_INFO_FOR_GPRS

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	C	C(=)	C	C(=)
GGSN number	M	M(=)		
SGSN address			C	C(=)
Mobile Not Reachable Reason			C	C(=)
User error			C	C(=)
Provider error				O

13.1.3 Parameter definition and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

GGSN number

See definition in clause 7.6.2.

SGSN address

This parameter shall be present if the outcome of the Send Routing Info For GPRS request to the GPRS application process in the HLR is positive.

Mobile Not Reachable Reason

This parameter shall be present if the outcome of the Send Routing Info For GPRS request to the GPRS application process in the HLR is positive and the MNRG flag in the HLR is set. See definition in clause 7.6.3.51.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- Absent Subscriber;
- System Failure;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

The diagnostic in the Unknown Subscriber may indicate 'Imsi Unknown' or 'Gprs Subscription Unknown'.

- Call Barred;

  This error will indicate that the received PDP PDUs in the GGSN shall be barred for this MS due to Operator Determined Barring. (The CallBarringCause must be the operatorBarring.)

Provider error

These are defined in clause 7.6.1.

13.2 MAP_FAILURE_REPORT service

13.2.1 Definition

This service is used by the GGSN to inform the HLR that network requested PDP-context activation has failed.

13.2.2 Service primitives

Table 13.2/1: MAP_FAILURE_REPORT

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	C	C(=)	C	C(=)
GGSN number	M	M(=)		
User error			C	C(=)
Provider error				O

13.2.3 Parameter definition and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

GGSN number

See definition in clause 7.6.2.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

These are defined in clause 7.6.1.

13.3 MAP_NOTE_MS_PRESENT_FOR_GPRS service

13.3.1 Definition

This service is used by the HLR to inform the GGSN that the MS is present for GPRS again.

13.3.2 Service primitives

Table 13.3/1: MAP_NOTE_MS_PRESENT_FOR_GPRS

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
IMSI	M	M(=)		
GGSN address	C	C(=)		
SGSN address	M	M(=)		
User error			C	C(=)
Provider error				O

13.3.3 Parameter definition and use

Invoke Id

See definition in clause 7.6.1.

IMSI

See definition in clause 7.6.2.

GGSN address

This parameter shall be present if the protocol-converting GSN is used between the GGSN and the HLR.

SGSN address

See definition in clause 7.6.2.

User error

This parameter is sent by the responder when an error is detected and if present, takes one of the following values:

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Unknown Subscriber.

Provider error

These are defined in clause 7.6.1.

13A Location Service Management Services

13A.1 MAP-SEND-ROUTING-INFO-FOR-LCS Service

13A.1.1 Definition

This service is used between the GMLC and the HLR to retrieve the routing information needed for routing a location service request to the servicing VMSC or SGSN. The MAP-SEND-ROUTING-INFO-FOR-LCS is a confirmed service using the primitives from table 13A.1/1.

13A.1.2 Service Primitives

Table 13A.1/1: MAP-SEND-ROUTING-INFO-FOR-LCS

Parameter name	Request	Indication	Response	Confirm
Invoke Id	M	M(=)	M(=)	M(=)
MLC Number	M	M(=)		
MSISDN	C	C(=)	C	C(=)
IMSI	C	C(=)	C	C(=)
LMSI			C	C(=)
Network Node Number			C	C(=)
GPRS Node Indicator			C	C(=)
Additional Number			C	C(=)
Supported LCS Capability Sets			C	C(=)
Additional LCS Capability Sets			C	C(=)
V-GMLC Address			U	C(=)
Additional V-GMLC Address			U	C(=)
H-GMLC Address			C	C(=)
PPR Address			U	C(=)
User error			C	C(=)
Provider error				O

13A.1.3 Parameter Use

Invoke id

See definition in clause 7.6.1.

MLC Number

See definition in clause 7.6.2.

MSISDN

See definition in clause 7.6.2. The request shall carry either the IMSI or MSISDN. The response shall carry whichever of these was not included in the request (see 3GPP TS 23.271 for details).

IMSI

See definition in clause 7.6.2.

LMSI

See definition in clause 7.6.2. It is an operator option to provide this parameter from the VLR; it is mandatory for the HLR to include the LMSI in a successful response, if the VLR has used the LMSI.

Network Node Number

See definition in clause 7.6.2. This parameter is provided in a successful response. If the Network Node Number and Additional Number are received in the GMLC, the Network Node Number is used in preference to the Additional Number.

GPRS Node Indicator

See definition in clause 7.6.8. The presence of this parameter is mandatory only if the SGSN number is sent in the Network Node Number.

Additional Number

See definition in clause 7.6.2. This parameter is provided in a successful response. If the Network Node Number and Additional Number are received in the GMLC, the Network Node Number is used in preference to the Additional Number.

Supported LCS Capability Sets

See definition in clause 7.6.11. This parameter indicates the LCS capability of the serving node that is indicated by the Network Node Number. This parameter is provided only if LCS capability sets are available in HLR and Network Node Number is present in this message.

Additional LCS Capability Sets

See definition in clause 7.6.11. This parameter indicates the LCS capability of the serving node that is indicated by the Additional Number. This parameter is provided only if LCS capability sets are available in HLR and Additional Number is present in this message.

V-GMLC address

See definition in clause 7.6.2. . This parameter indicates the V-GMLC address of the serving node that is indicated by the Network Node Number.

Additional V-GMLC address

See definition in clause 7.6.2. This parameter indicates the V-GMLC address of the serving node that is indicated by the Additional Number. This parameter is provided only if additional LCS capability sets are available in HLR and Additional Number is present in this message.

H-GMLC address

See definition in clause 7.6.2. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

PPR address

See definition in clause 7.6.2.

User error

The following errors defined in clause 7.6.1 may be used, depending on the nature of the fault:

- Unknown subscriber;
- Absent Subscriber;
- Facility Not Supported;
- System failure;
- Unexpected Data Value;
- Data missing;
- Unauthorised requesting network.

Provider error

For definition of provider errors see clause 7.6.1.

13A.2 MAP-PROVIDE-SUBSCRIBER-LOCATION Service

13A.2.1 Definition

This service is used by a GMLC to request the location of a target MS from the visited MSC or SGSN at any time. This is a confirmed service using the primitives from table 13A.2/1.

13A.2.2 Service Primitives

Table 13A.2/1: Provide_Subscriber_Location

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
Location Type	M	M(=)		
MLC Number	M	M(=)		
LCS Client ID	M	M(=)		
Privacy Override	U	C(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
LMSI	C	C(=)		
LCS Priority	C	C(=)		
LCS QoS	C	C(=)		
IMEI	U	C(=)		
Supported GAD Shapes	C	C(=)		
LCS-Reference Number	C	C(=)		
LCS Codeword	C	C(=)		
LCS Service Type Id	C	C(=)		
LCS Privacy Check	C	C(=)		
Area Event Info	C	C(=)		
H-GMLC Address	C	C(=)		
Reporting PLMN List	C	C(=)		
PeriodicLDRInfo	C	C(=)		
MO-LR Short Circuit Indicator	C	C(=)	C	C(=)
Location Estimate			M	M(=)
GERAN Positioning Data			C	C(=)
UTRAN Positioning Data			C	C(=)
Age of Location Estimate			C	C(=)
Additional Location Estimate			C	C(=)
Deferred MT-LR Response Indicator			C	C(=)
Cell Id Or SAI			C	C(=)
Accuracy Fulfilment Indicator			C	C(=)
User error			C	C(=)
Provider error				O

13A.2.3 Parameter Definition and Use

All parameters are defined in clause 7.6. The use of these parameters and the requirements for their presence are specified in 3GPP TS 23.271 [26a].

Location Type

This parameter identifies the type of location information requested.

MLC Number

This is the E.164 number of the requesting GMLC.

LCS Client ID

This parameter provides information related to the identity of an LCS client.

Privacy Override

This parameter indicates if MS privacy is overridden by the LCS client when the GMLC and VMSC or SGSN for an MT-LR are in the same country.

IMSI

The IMSI is provided to identify the target MS. At least one of the IMSI or MSISDN is mandatory.

MSISDN

The MSISDN is provided to identify the target MS. At least one of the IMSI or MSISDN is mandatory.

LMSI

The LMSI shall be provided if previously supplied by the HLR. This parameter is only used in the case of the MT-LR for CS domain.

LCS Priority

This parameter indicates the priority of the location request.

LCS QoS

This parameter indicates the required quality of service in terms of response time and accuracy.

IMEI

The requirements for its presence are specified in 3GPP TS 23.271 [26a].

Supported GAD Shapes

This parameter indicates which of the shapes defined in 3GPP TS 23.032 [122] are supported.

LCS-Reference Number

This parameter shall be included if a deferred MT-LR procedure is performed for a UE available event, an area event or a periodic positioning event.

LCS Codeword

See definition in clause 7.6.11.18. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

LCS Service Type Id

See definition in clause 7.6.11.15. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

LCS Privacy Check

See definition in clause 7.6.11. The requirements for its and its components presence are specified in 3GPP TS 23.271 [26a].

Area Event Info

See definition in clause 7.6.11. The parameter shall be included if a deferred MT-LR procedure is performed for an area event.

H-GMLC address

See definition in clause 7.6.2. The parameter shall be included if a deferred MT-LR procedure is performed for a UE available event, an area event or a periodic positioning event.

Location Estimate

This parameter provides the location estimate if this is encoded in one of the supported geographical shapes. Otherwise this parameter shall consist of one octet, which shall be discarded by the receiving node.

GERAN Positioning Data

This parameter indicates the usage of each positioning method that was attempted to determine the location estimate either successfully or unsuccessfully. If Positioning Data received from the RAN contains no Positioning Methods, Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is GERAN, see 3GPP TS 23.271 [26a].

UTRAN Positioning Data

This parameter indicates the usage of each positioning method that was successfully attempted to determine the location estimate. If Position Data received from the RAN contains no Positioning Methods, UTRAN Positioning Data is

excluded from the MAP message. It may be included in the message only if the access network is UTRAN, see 3GPP TS 23.271 [26a].

Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

Additional Location Estimate

This parameter provides the location estimate when not provided by the Location Estimate parameter. It may be sent only if the parameter Supported GAD Shapes has been received in the Provide Subscriber Location indication and the shape to be included is supported by the GMLC.

Deferred MT-LR Response Indicator

See definition in clause 7.6.11.2.

Cell Id Or SAI

For GERAN access, this parameter indicates Global Cell Identifier of the cell that the served subscriber is currently attached to. For UTRAN access, this parameter contains the Service Area Identifier for the cell that the subscriber is currently attached to. This parameter is included only for North American Emergency Calls as described in 3GPP TS 23.271 [26a].

Accuracy Fulfilment Indicator

See definition in clause 7.6.11.28.

MO-LR Short Circuit Indicator

This parameter indicates whether MO-LR Short Circuit is permitted for periodic location.

Reporting PLMN List

This parameter indicates a list of PLMNs in which subsequent periodic MO-LR TTTP requests will be made.

Periodic LDR information

This parameter indicates the reporting amount and reporting interval of deferred periodic location.

User error

This parameter is sent by the responder when the location request has failed or cannot proceed and if present, takes one of the following values defined in clause 7.6.1.

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Facility Not Supported;
- Unidentified Subscriber;
- Illegal Subscriber;
- Illegal Equipment;
- Absent Subscriber (diagnostic information may also be provided);
- Unauthorised requesting network;
- Unauthorised LCS Client with detailed reason;
- Position method failure with detailed reason.

Provider error

These are defined in clause 7.6.1.

13A.3 MAP-SUBSCRIBER-LOCATION-REPORT Service

13A.3.1 Definition

This service is used by a VMSC or SGSN to provide the location of a target MS to a GMLC when a request for location is either implicitly administered or made at some earlier time. This is a confirmed service using the primitives from table 13A.3/1.

13A.3.2 Service Primitives

Table 13A.3/1: Subscriber_Location_Report

Parameter name	Request	Indication	Response	Confirm
Invoke id	M	M(=)	M(=)	M(=)
LCS Event	M	M(=)		
LCS Client ID	M	M(=)		
Network Node Number	M	M(=)		
IMSI	C	C(=)		
MSISDN	C	C(=)		
NA-ESRD	C	C(=)	C	C(=)
NA-ESRK	C	C(=)	C	C(=)
IMEI	U	C(=)		
Location Estimate	C	C(=)		
GERAN Positioning Data	C	C(=)		
UTRAN Positioning Data	C	C(=)		
Age of Location Estimate	C	C(=)		
LMSI	U	C(=)		
GPRS Node Indicator	C	C(=)		
Additional Location Estimate	C	C(=)		
Deferred MT-LR Data	C	C(=)		
LCS-Reference Number	C	C(=)	C	C(=)
NA-ESRK Request	C	C(=)		
Cell Id Or SAI	C	C(=)		
H-GMLC Address	C	C(=)	C	C(=)
LCS Service Type Id	C	C(=)		
Pseudonym Indicator	C	C(=)		
Accuracy Fulfilment Indicator	C	C(=)		
Sequence Number	C	C(=)		
Periodic LDR Info	C	C(=)		
MO-LR Short Circuit Indicator	C	C(=)	C	C(=)
Reporting PLMN List			C	C(=)
User error			C	C(=)
Provider error				O

13A.3.3 Parameter Definition and Use

All parameters are defined in clause 7.6. The use of these parameters and the requirements for their presence are specified in. 3GPP TS 23.271 [26a].

LCS Event

This parameter indicates the event that triggered the Subscriber Location Report.

LCS Client ID

This parameter provides information related to the identity of the recipient LCS client.

Network Node Number

See definition in clause 7.6.2. This parameter provides the address of the sending node.

IMSI

The IMSI shall be provided if available to the VMSC or SGSN.

MSISDN

The MSISDN shall be provided if available to the VMSC or SGSN.

NA-ESRD

If the target MS has originated an emergency service call in North America, the NA-ESRD shall be provided by the VMSC if available.

If the target MS has originated an emergency service call in North America and NA-ESRK Request is included in Subscriber_Location_Report-Arg, an NA-ESRK or NA-ESRD, but not both, may also be included in the response to the MSC, see 3GPP TS 23.271 [26a].

NA-ESRK

If the target MS has originated an emergency service call in North America, the NA-ESRK shall be provided by the VMSC if assigned.

If the target MS has originated an emergency service call in North America and NA-ESRK Request is included in Subscriber_Location_Report-Arg, an NA-ESRK or NA-ESRD, but not both, may also be included in the response to the MSC, see 3GPP TS 23.271 [26a].

IMEI

The requirements for its presence are specified in 3GPP TS 23.271 [26a].

Location Estimate

This parameter provides the location estimate. The absence of this parameter implies that a location estimate was not available or could not be successfully obtained. If the obtained location estimate is not encoded in one of the supported geographical shapes then this parameter shall consist of one octet, which shall be discarded by the receiving node.

GERAN Positioning Data

This parameter indicates the usage of each positioning method that was attempted to determine the location estimate either successfully or unsuccessfully. If Positioning Data received from the RAN contains no Positioning Methods, Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is GERAN, see 3GPP TS 23.271 [26a].

UTRAN Positioning Data

This parameter indicates the usage of each positioning method that was successfullyattempted to determine the location estimate. If Position Data received from the RAN contains no Positioning Methods, UTRAN Positioning Data is excluded from the MAP message. It may be included in the message only if the access network is UTRAN, see 3GPP TS 23.271 [26a].

Age of Location Estimate

This parameter indicates how long ago the location estimate was obtained.

LMSI

The LMSI may be provided if assigned by the VLR.

GPRS Node Indicator

See definition in clause 7.6.8. This presence of this parameter is mandatory only if the SGSN number is sent in the Network Node Number.

Additional Location Estimate

This parameter provides the location estimate when not provided by the Location Estimate parameter..

Deferred MT-LR Data

See definition in clause 7.6.11.3.

LCS-Reference Number

This parameter shall be included if the Subscriber Location Report is the response to a deferred MT location request.

NA-ESRK Request

If the target MS has originated an emergency service call in North America, NA-ESRK Request may be included to indicate that the MSC is able to accept NA-ESRK in the Response message, see section 7.6.11.19.

Cell Id Or SAI

For GERAN access, this parameter indicates Global Cell Identifier of the cell that the served subscriber is currently attached to. For UTRAN access, this parameter contains the Service Area Identifier for the cell that the subscriber is currently attached to. This parameter is included only for Emergency Calls as described in 3GPP TS 23.271 [26a].

H-GMLC address

See definition in clause 7.6.2. The parameter shall be included if the Subscriber Location Report is the response to a deferred MT location request for a UE available event, an area event or a periodic positioning event. This parameter shall be included in a Subscriber Location Report response if a deferred MO-LR TTTP procedure is initiated for a periodic positioning event.

LCS Service Type Id

See definition in clause 7.6.11.15. The requirements for its presence are specified in 3GPP TS 23.271 [26a].

Pseudonym Indicator

This parameter indicates by its presence that the pseudonym is required. Refer to 3GPP TS 23.271 [26a].

Accuracy Fulfilment Indicator

For a mobile terminated periodic LDR, this parameter indicates whether the obtained location estimate satisfies the requested accuracy or not, provided that this indication is obtained from RAN or the UE with the location estimate.

Periodic LDR Information

This parameter refers to the periodic reporting interval and reporting amount of the deferred periodic location.

MO-LR Short Circuit Indicator

This parameter indicates whether MO-LR Short Circuit is permitted for periodic location.

Reporting PLMN List

This parameter indicates a list of PLMNs in which subsequent periodic MO-LR TTTP requests will be made.

Sequence Number

This parameter refers to the number of the periodic location reports completed. The sequence number would be set to 1 in the first location report and increment by 1 for each new report. When the number reaches the reporting amount value, the H-GMLC (for a periodic MT-LR or a periodic MO-LR transfer to third party) will know the procedure is complete. For details see 3GPP TS 23.271 [26a].

User error

This parameter is sent by the responder when the received message contains an error, cannot be forwarded or stored for an LCS client or cannot be accepted for some other reason and if present, takes one of the following values defined in clause 7.6.1.

- System Failure;
- Data Missing;
- Unexpected Data Value;
- Resource Limitation;
- Unknown Subscriber;
- Unauthorised requesting network;
- Unknown or unreachable LCS Client.

Provider error

These are defined in clause 7.6.1.

13A.4 Void

13A.4.1 Void

13A.4.2 Void

13A.4.3 Void

13A.5 Void

13A.5.1 Void

13A.5.2 Void

13A.5.3 Void

13A.6 Void

13A.6.1 Void

13A.6.2 Void

13A.6.3 Void

13A.7 Void

13A.7.1 Void

13A.7.2 Void

13A.7.3 Void

13A.8 Void

13A.8.1 Void

13A.8.2 Void

13A.8.3 Void

13A.9 Void

13A.9.1 Void

13A.9.2 Void

13A.9.3 Void

14 General

14.1 Overview

Clauses 14 to 17 specify the protocol elements to be used to provide the MAP services described in clause 7.

Clause 15 specifies the elements of procedures for the MAP protocol. Clause 16 specifies the mapping onto TC service primitives. Clause 17 specifies the application contexts, operation packages and abstract syntaxes for the MAP protocol as well as the encoding rules to be applied.

14.2 Underlying services

The MAP protocol relies on the services provided by the Transaction Capabilities (TC) of Signalling System Number No. 7, as referenced in clause 6.

14.3 Model

The MAP Protocol Machine (MAP PM) can be modelled as a collection of service state machines (SSMs) - one per MAP specific service invoked - coordinated by a MAP dialogue control function with its one state machine: MAP dialogue state machine (DSM). There are two types of Service State Machines: Requesting Service State Machines (RSM) and Performing Service State Machines (PSM).

A new invocation of a MAP PM is employed on the receipt of a MAP-OPEN request primitive or a TC-BEGIN indication primitive. Each invocation controls exactly one MAP dialogue. For each MAP specific service invoked during a dialogue, a MAP RSM is created at the requestor's side and a MAP PSM is created at the performer's side.

This modelling is used only to facilitate understanding and the MAP behaviour descriptions and is not intended to suggest any implementation. SDL descriptions are organised according to this model.

How the MAP-service-user and the MAP refer to a MAP dialogue (i.e. a MAP PM invocation) is a local implementation matter.

How TC dialogue identifiers are assigned to a MAP PM invocation is also a local implementation matter.

14.4 Conventions

The behaviour of the MAP PM depends on the application-context-name associated with the dialogue. One major difference is that the MAP requests the transfer of the application-context-name by TC only for those contexts which do not belong to the so-called "version one context set".

The "version one context set" is a set of application-contexts which model the behaviour of a MAP V1 implementation according to the latest phase 1 version of GSM 09.02. This set is defined in clause 15.

The procedures described in clause 15 are used when the application-context-name does not refer to a dialogue between an MSC and its VLR. When the application-context-name refers to a dialogue between an MSC and its VLR the MAP PM procedures are a local implementation matter.

15 Elements of procedure

15.1 Handling of unknown operations

Unknown operations (i.e. a standard operation introduced in a later version of the MAP specification, or a private operation) can be introduced into MAP in a backwards compatible way. This means that the receiver of an unknown operation shall, if the dialogue state allows it, send a TC-REJECT component to the sender of the operation indicating 'unrecognised operation' and continue with the processing of further components or messages exchanged within the dialogue as if the unknown operation had not been received.

The standardised structure of a MAP dialogue shall not be affected by the invocation of unknown operations, i.e. if a dialogue uses only a TC-BEGIN message which is acknowledged by a TC-END message, a TC-CONTINUE message shall not be used to invoke an unknown operation. However the standardised structure of a MAP dialogue may be affected by the rejection of unknown operations, i.e. if a dialogue uses only a TC-BEGIN message which is acknowledged by a TC-END message, a TC-CONTINUE message followed by a TC-END message may be used to carry the rejection of an unknown operation and the response to the standardised operation. The entity which initiated a dialogue whose standardised structure is a TC-BEGIN message which is acknowledged by a TC-END message shall not send any messages in that dialogue after the TC-BEGIN. Note that if the dialogue structure is affected as described in this paragraph the TC-CONTINUE shall include the dialogue portion required to confirm the acceptance of the dialogue.

Unknown operations may be invoked in the following types of message (there is no restriction as to how many unknown operations can be invoked in a message):

- TC-BEGIN: the component to invoke the unknown operation shall follow the component of the standard operation which is included in this message.
- TC-CONTINUE: the component to invoke the unknown operation may be transported as the only component in a stand-alone message or may be grouped with existing operations. In the latter case a specific sequencing of components is not required.
- TC-END: if the component to invoke the unknown operation is grouped with an existing operation a specific sequencing of components is not required

The TC-REJECT component may be sent in the following messages:

- TC-CONTINUE or TC-END: either as the only component of the message or grouped with an existing component. The choice is up to the MAP-Service User.

  If the received message contains only unknown operations the MAP-Service User shall send the TC-REJECT components in a TC-CONTINUE message to the peer entity, if the dialogue state allows it.

  If the received message contains unknown operations and standard operations and the standardised structure of the dialogue requires the response to the standard operation to be sent within a TC-END message, then the MAP-Service User may send the response to the standard operations and the TC-REJECT components for the unknown operations in a TC-CONTINUE message followed by a TC-END message. Neither a specific distribution of the components to the TC messages nor a specific sequencing of components is required.

Note that the SDL diagrams of clauses 19 - 25 do not show the report to the MAP-Service User about the reception of the unknown operation. This has been done for simplicity of description; the MAP PM may inform the MAP-Service User.

The sender of the unknown operation shall ensure that there is enough room in the used message for the unknown operation.

15.2 Dialogue establishment

The establishment of a MAP dialogue involves two MAP-service-users: the dialogue-initiator and the dialogue-responder.

This procedure is driven by the following signals:

- a MAP-OPEN request primitive from the dialogue-initiator;
- a TC-BEGIN indication primitive occurring at the responding side;
- a MAP-OPEN response primitive from the dialogue-responder;
- the first TC-CONTINUE indication primitive occurring at the initiating side;

and under specific conditions:

- a TC-END indication primitive occurring at the initiating side;
- a TC-U-ABORT indication primitive occurring at the initiating side;
- a TC-P-ABORT indication primitive occurring at the initiating side.

One instance of the MAP dialogue state machine runs at the initiating side, and one at the responding side.

15.2.1 Behaviour at the initiating side

The behaviour of the MAP dialogue state machine at the initiating side is defined in sheets 1 – 8 of the process MAP_DSM (figure 15.6/3).

Sheet 3: When the MAP dialogue state machine at the initiating side is waiting for a response from the responding side, a TC-END indication which echoes the AC name which was sent in the TC-BEGIN indicates acceptance of the dialogue.

Sheet 3: If the dialogue opening is accepted, any components included in the TC-END are processed and passed to the MAP-Service User. The dialogue is closed by sending a MAP-CLOSE to the MAP-Service User.

Sheet 3, sheet 4, sheet 5, sheet 6, sheet 7, sheet 8: when a dialogue is terminated, the MAP dialogue state machine terminates all instances of the Requesting_MAP_SSM which are active for this dialogue.

Sheet 4: A TC-P-ABORT with an abort parameter Incorrect_Transaction_Portion indicates that the responding side does not support a MAP version higher than 1. This triggers a MAP-OPEN confirm indicating that the dialogue is refused, with a refuse reason potential version incompatibility. The MAP-Service User may then decide to retry the dialogue at MAP version 1.

Sheet 8: When the MAP dialogue state machine at the initiating side is waiting for a response from the responding side, a TC-CONTINUE indication which echoes the AC name which was sent in the TC-BEGIN indicates acceptance of the dialogue.

Sheet 8: If the dialogue opening is accepted, any components included in the TC-CONTINUE are processed and passed to the MAP-Service User. The dialogue has then reached the established state.

15.2.2 Behaviour at the responding side

The behaviour of the MAP dialogue state machine at the responding side is defined in sheets 0 – 14 of the process MAP_DSM (figure 15.6/3).

Sheet 9: If no application context information is included in the TC-BEGIN indication, this implies a MAP version 1 dialogue. An explicit application context indicating version 1 is treated as abnormal behaviour.

Sheet 11: The v1 application context name which corresponds to a v1 operation is derived using the information in table 15.2/1.

Table 15.2/1: Mapping of V1 operation codes on to application-context-names

Operation	Application-context-name (note 1)
updateLocation	networkLocUpContext-v1
cancelLocation	locationCancellationContext-v1
provideRoamingNumber	roamingNumberEnquiryContext-v1
insertSubscriberData	subscriberDataMngtContext-v1
deleteSubscriberData	subscriberDataMngtContext-v1
sendParameters	infoRetrievalContext-v1
	networkLocUpContext-v1 (note 2)
beginSubscriberActivity	networkFunctionalSsContext-v1
sendRoutingInfo	locationInfoRetrievalContext-v1
performHandover	handoverControlContext-v1
reset	resetContext-v1
activateTraceMode	tracingContext-v1
deactivateTraceMode	tracingContext-v1
sendRoutingInfoForSM	shortMsgGatewayContext-v1
forwardSM	shortMsgRelayContext-v1
reportSM-deliveryStatus	shortMsgGatewayContext-v1
noteSubscriberPresent	mwdMngtContext-v1
alertServiceCentreWithoutResult	shortMsgAlertContext-v1
checkIMEI	EquipmentMngtContext-v1

NOTE 1: These symbolic names refer to the object identifier value defined in clause 17 and allocated to each application-context used for the MAP.
NOTE 2: The choice between the application contexts is based on the parameters received in the operation.

Sheet 12: If the dialogue is accepted, each component present in the TC-BEGIN is forwarded to an instance of a Performing_MAP_SSM, by executing the procedure Process_Components.

Sheet 13: If the MAP dialogue state machine receives a MAP-OPEN response with a result accepted, it waits for any MAP specific service request or response primitives or a MAP-DELIMITER request.

Sheet 13, sheet 14: When a dialogue is terminated, the MAP dialogue state machine terminates all instances of the Requesting_MAP_SSM or Performing_MAP_SSM which are active for this dialogue.

Sheet 14: A MAP-DELIMITER request triggers a TC-CONTINUE request to accept the dialogue. The dialogue has then reached the established state.

15.3 Dialogue continuation

Once established the dialogue is said to be in a continuation phase. The behaviour of the MAP dialogue state machine in this phase is defined in sheets 15 – 17 of the process MAP_DSM (figure 15.6/3).

Both MAP users can request the transfer of MAP APDUs until one of them requests the termination of the dialogue.

Normal closure of an established dialogue is shown on sheet 16; abnormal termination is shown on sheet 17.

15.4 Load control

If an entity which should respond to a MAP dialogue opening request is overloaded, it uses the AC of the request to determine whether to discard the request.

The priority level allocated to each application-context is described in clause 5, tables 5.1/1, 5.1/2, and 5.1/3.

15.5 Procedures for MAP specific services

This clause describes the MAP procedures for MAP specific services. These procedures are driven by the following types of event:

- a MAP specific request or a MAP specific response primitive;

- a component handling primitive from TC.

A Service State Machine is activated when of one of the following signals is received:

- a MAP request primitive, which activates a requesting SSM;
- a TC-INVOKE indication primitive without a linked identifier, which activates a performing SSM.

For component handling primitives there are two types of event:

- events which activate a Service State Machine or which can be related to an existing one;
- events which cannot be related to a Service State Machine.

15.5.1 Service invocation

The behaviour of the requesting SSM which handles a service is defined by the SDL for the process Requesting_MAP_SSM. The requesting SSM receives a MAP service request from the MAP-Service User via the MAP dialogue state machine and sends a TC-INVOKE request to TCAP. When a confirm is received from TCAP via the MAP dialogue state machine, the requesting SSM forwards a MAP service confirm to the MAP-Service User.

The response to a MAP service invocation may come in the form of a linked request. If the linked request corresponds to a class 4 operation, this is handled by the requesting SSM. If the linked request corresponds to a class 1, 2 or 3 operation, the MAP dialogue state machine sends a notification to the requesting SSM and creates an instance of a performing SSM to handle the linked request. The test "Linked_Operation_Allowed" on sheet 3 of the process Requesting_MAP_SSM takes the (TRUE) exit if the definition of the parent operation includes the received linked operation as a permitted linked operation; otherwise the test takes the (FALSE) exit.

The mapping of MAP specific services on to remote operations is given in table 16.2/1.

15.5.2 Void

15.5.3 Service invocation receipt

The behaviour of the performing SSM which handles a service is defined by the SDL for the process Performing_MAP_SSM. The performing SSM receives a TC-INVOKE component from TCAP via the MAP dialogue state machine and sends a MAP service indication to the MAP-Service User. When a MAP service response is received from the MAP-Service User via the MAP dialogue state machine, the performing SSM forwards a TC-RESULT or TC-U-ERROR component to TCAP.

15.5.4 Void

15.5.5 Handling of components received from TC

The procedure Process_Components shows the handling of components received in a TC-BEGIN, TC-CONTINUE or TC-END message.

Sheet 2: If a linked invoke component corresponds to a class 4 operation, the MAP dialogue state machine sends it to the requesting SSM instance identified by the linked invoke ID. If a linked invoke component corresponds to any other class of operation, the MAP dialogue state machine sends a notification to the requesting SSM instance identified by the linked invoke ID, creates an instance of a performing SSM and sends the invoke component to it.

15.6 SDL descriptions

The following SDL specification describes a system which includes three blocks: MAP-user, MAP-provider and TC.

Such a system resides in each network component supporting MAP and communicates with its peers via the lower layers of the signalling network which are part of the environment.

Only the MAP-provider is fully described in this clause. The various types of processes which form the MAP-User block and the TC block are described respectively in clauses 18 to 25 of the present document and in CCITT Recommendation Q.774.

The MAP-Provider block communicates with the MAP_USER via two channels U1 and U2. Via U1 the MAP-provider receives the MAP request and response primitives. Via U2 it sends the MAP indication and confirm primitives.

The MAP-Provider block communicates with TC via two channels P1 and P2. Via P1 the MAP-Provider sends all the TC request primitives. Via P2 it receives all the TC indication primitives.

The MAP-Provider block is composed of the four following types of process:

a) MAP_DSM: This type of process handles a dialogue for transport of MAP messages. There exists one process instance per MAP dialogue.

b) Load_Ctrl: This type of process is in charge of load control. There is only one instance of this process in each system.

c) Requesting_MAP_SSM: This type of process handles a MAP service requested during a dialogue. An instance of this process is created by the instance of the MAP_DSM process for each requested MAP service.

d) Performing_MAP_SSM: This type of process handles a MAP service performed during a dialogue. An instance of this process is created by the instance of the MAP_DSM process for each MAP service to be performed.

A process MAP_DSM exchanges external signals with other blocks as well as internal signals with the other processes of the MAP-Provider block. The external signals are either MAP service primitives or TC service primitives.

The signal routes used by the various processes are organised as follows:

a) A process MAP_DSM receives and sends events from/to the MAP_user via signal route User1/User2. These routes use channels U1 and U2 respectively.

b) A process MAP_DSM receives and sends events from/to the TCAP via signal route TC1/TC2. These routes use channels P1 and P2 respectively.

c) A process MAP_DSM receives and sends events from/to the LOAD_CTRL process via signal route Load1/Load2. These routes are internal.

d) A process MAP_DSM sends events to the Performing_MAP_SSM processes via signal route Intern1. This route is internal.

e) A process MAP_DSM sends events to the Requesting_MAP_SSM processes via signal route Intern2. This route is internal.

f) A process Performing_MAP_SSM sends events to the MAP_USER via signal route User3. This route uses channel U2.

g) A process Performing_MAP_SSM sends events to the TCAP via signal route TC3. This route uses channel P1.

h) A process Requesting_MAP_SSM sends events to the MAP_USER via signal route User4. This route uses channel U2.

i) A process Requesting_MAP_SSM sends events to the TCAP via signal route TC4. This route uses channel P1.




Figure 15.6/1: System MAP_Stack




Figure 15.6/2: Block MAP_Provider




Figure 15.6/3a: Process MAP_DSM (sheet 1)




Figure 15.6/3b: Process MAP_DSM (sheet 2)




Figure 15.6/3c: Process MAP_DSM (sheet 3)




Figure 15.6/3d: Process MAP_DSM (sheet 4)




Figure 15.6/3e: Process MAP_DSM (sheet 5)




Figure 15.6/3f: Process MAP_DSM (sheet 6)




Figure 15.6/3g: Process MAP_DSM (sheet 7)




Figure 15.6/3h: Process MAP_DSM (sheet 8)




Figure 15.6/3i: Process MAP_DSM (sheet 9)




Figure 15.6/3j: Process MAP_DSM (sheet 10)




Figure 15.6/3k: Process MAP_DSM (sheet 11)




Figure 15.6/3l: Process MAP_DSM (sheet 12)




Figure 15.6/3m: Process MAP_DSM (sheet 13)




Figure 15.6/3n: Process MAP_DSM (sheet 14)




Figure 15.6/30: Process MAP_DSM (sheet 15)




Figure 15.6/3p: Process MAP_DSM (sheet 16)




Figure 15.6/3q: Process MAP_DSM (sheet 17)




Figure 15.6/4a: Procedure Process_Components (sheet 1)




Figure 15.6/4b: Procedure Process_Components (sheet 2)




Figure 15.6/4c: Procedure Process_Components (sheet 3)




Figure 15.6/4d: Procedure Process_Components (sheet 4)

Procedure Process_Components Proc_Comp5(5)




Figure 15.6/4e: Procedure Process_Components (sheet 5)




Figure 15.6/5: Process Load_Ctrl




Figure 15.6/6a: Process Requesting_MAP_SSM (sheet 1)




Figure 15.6/6b: Process Requesting_MAP_SSM (sheet 2)




Figure 15.6/6c: Process Requesting_MAP_SSM (sheet 3)




Figure 15.6/6d: Process Requesting_MAP_SSM (sheet 4)



Process Performing_MAP_SSM
MAP_PSSM1(2)
Process to handle an invoke component received from the peer and the response from the user
Comment 'Performing MAP Service State Machine':
DCL
Argument_Correct, Service_Identifiable, Service_Parameters_Available, Unexpected_Data,
Length_OK, User_Error_Present, Linked_Request, Specific_Error, More_Data,
Cnf_Required BOOLEAN,
Operation_Class INTEGER,
TIMER Guard_Timer COMMENT 'expires if MAP user does not respond';
IDLE
Service_ Invocation_ Received
Is the syntax correct ?
Argument_ Correct
(FALSE)
(TRUE)
Service_ Identifiable
(TRUE)
(FALSE)
Discard_ Invocation
Service_ Parameters_ Available
(FALSE)
(TRUE)
Discard_ Invocation
Operation_ Class
Associated with the service
(1,2)
(3,4)
Operation_ Class
Associated with the service
1
(3,4)
(1,2)
Set_Error: Data_Missing
Set_Error: Unexpected_ Data_Value
Unexpected_ Data
(TRUE)
(FALSE)
MAP_ind_ VIA_User3
Discard_ Invocation
Set_Problem_ Code: Mistyped_ Parameter
Cnf_ Required
(FALSE)
(TRUE)
Operation_ Class
Associated with the service
TC_U_ERROR_ req_VIA_TC3
TC_U_REJECT_ req_VIA_TC3
Set_ (Guard_Timer)
(1,2)
(3,4)
MAP_NOTICE_ ind_VIA_User3
MAP_NOTICE_ ind_VIA_User3
WAIT_FOR_ RESPONSE
1

Figure 15.6/8a: Process Performing_MAP_SSM (sheet 1)




Figure 15.6/8b: Process Performing_MAP_SSM (sheet 2)

16 Mapping on to TC services

16.1 Dialogue control

Dialogue control services are mapped to TC dialogue handling services. The TC-UNI service is not used by the MAP PM.

16.1.1 Directly mapped parameters

The following parameters of the MAP-OPEN request and indication primitives are directly mapped on to the corresponding parameters of the TC-BEGIN primitives:

- destination address;
- originating address.

16.1.2 Use of other parameters of dialogue handling primitives

16.1.2.1 Dialogue Id

The value of this parameter is associated with the MAP PM invocation in an implementation dependent manner.

16.1.2.2 Application-context-name

The application-context-name parameter of a MAP primitive is mapped to the application-context-name parameter of TC dialogue handling primitives according to the rules described in clause 15.1.

16.1.2.3 User information

The user information parameter of TC dialogue primitives is used to carry the MAP dialogue APDUs.

16.1.2.4 Component present

This parameter is used by the MAP PM as described in CCITT Recommendation Q.771. It is not visible to the MAP user.

16.1.2.5 Termination

The value of this parameter of the TC-END request primitive is set by the MAP PM on the basis of the release method parameter of the MAP-CLOSE request primitive, except when the dialogue state machine is in the state DIALOGUE INITIATED, in which case the Termination parameter shall always indicate "pre-arranged end".

16.1.2.6 P-Abort-Cause

Values of the P-abort-cause parameter are mapped to the values of the provider-reason parameter of the MAP-P-ABORT indication primitive according to table 16.1/1, except in the dialogue initiated phase for the "incorrectTransactionPortion" and "noCommonDialoguePortion" values which are mapped to the "potential incompatibility problem" value of the refuse-reason parameter of the MAP-OPEN cnf primitive. The source parameter in the MAP-P-ABORT ind takes the value "TC problem".

16.1.2.7 Quality of service

The quality of service of TC request primitives is set by the MAP as shown below.

- Return option: "Return message on error" or "Discard message on error" as required by the network operator;
- Sequence control: "Sequence guaranteed" or "Sequence result not guaranteed" as required by the network operator;
- "Sequence guaranteed" shall be used when a segmented result is to be transferred (e.g. subscriber data in response to SendParameters). It may also be appropriate to use Sequence guaranteed when a series of InsertSubscriberData, ProcessAccessSignalling or ForwardAccessSignalling operations is used.

It is essential that the TC message which indicates acceptance of a dialogue opening request is received by the dialogue initiator before any subsequent message in that dialogue; otherwise the dialogue opening will fail. The dialogue responder shall ensure that this requirement is met by:

- Sending the dialogue acceptance message in a TC-END, if the dialogue structure requires it; or
- Using "Sequence guaranteed", if the dialogue acceptance message is sent in a TC-CONTINUE; or
- Waiting until the dialogue acceptance message has been acknowledged by the dialogue initiator before sending a subsequent message, if the dialogue acceptance message is sent in a TC-CONTINUE.

Table 16.1/1: Mapping of P-Abort cause in TC-P-ABORT indication on to provider-reason in MAP-P-ABORT indication

TC P-Abort cause	MAP provider-reason
unrecognised message type	provider malfunction
unrecognised transaction Id	supporting dialogue released
badlyFormattedTransactionPortion	provider malfunction
incorrectTransactionPortion	provider malfunction (note)
resourceLimitation	resource limitation
abnormalDialogue	provider malfunction
noCommonDialoguePortion	version incompatibility
NOTE: Or version incompatibility in the dialogue initiated phase.	

16.2 Service specific procedures

Specific services are mapped to TC component handling services.

16.2.1 Directly mapped parameters

The Invoke Id parameter of the MAP request and indication primitive is directly mapped on to the Invoke Id parameter of the component handling primitives.

16.2.2 Use of other parameters of component handling primitives

16.2.2.1 Dialogue Id

The value of this parameter is associated with the MAP PM invocation in an implementation dependent manner.

16.2.2.2 Class

The value of this parameter is set by the MAP PM according to the type of the operation to be invoked.

16.2.2.3 Linked Id

When a service response is mapped to a class 4 operation, the value of this parameter is set by the MAP PM and corresponds to the value assigned by the user to the initial service request (i.e. the value of the invoke ID parameter of

the request primitive). Otherwise if such a parameter is included in MAP request/indication primitives it is directly mapped to the linked ID parameter of the associated TC-INVOKE request/indication primitives.

16.2.2.4 Operation

When mapping a request primitive on to a Remote Operations PDU (invoke), the MAP PM shall set the operation code according to the mapping described in table 16.2/1.

When mapping a response primitive on to a Remote Operations service, the MAP PM shall set the operation code of the TC-RESULT-L/NL primitive (if required) to the same value as the one received at invocation time.

Table 16.2/1: Mapping of MAP specific services on to MAP operations

MAP-SERVICE	operation
MAP-ACTIVATE-SS	activateSS
MAP-ACTIVATE-TRACE-MODE	activateTraceMode
MAP-ALERT-SERVICE-CENTRE	alertServiceCentre
MAP-ANY-TIME-INTERROGATION	anyTimeInterrogaton
MAP_AUTHENTICATION_FAILURE_REPORT	authenticationFailureReport
MAP-ANY-TIME-MODIFICATION	anyTimeModification
MAP-ANY-TIME-SUBSCRIPTION-INTERROGATION	anyTimeSubscriptionInterrogation
MAP-CANCEL-LOCATION	cancelLocation
MAP-CHECK-IMEI	checkIMEI
MAP-DEACTIVATE-SS	deactivateSS
MAP-DEACTIVATE-TRACE-MODE	deactivateTraceMode
MAP-DELETE-SUBSCRIBER-DATA	deleteSubscriberData
MAP-ERASE-CC-ENTRY	eraseCC-Entry
MAP-ERASE-SS	eraseSS
MAP-FAILURE-REPORT	failureReport
MAP-FORWARD-ACCESS-SIGNALLING	forwardAccessSignalling
MAP-FORWARD-CHECK-SS-INDICATION	forwardCheckSsIndication
MAP-FORWARD-GROUP-CALL-SIGNALLING	forwardGroupCallSignalling
MAP-MT-FORWARD-SHORT-MESSAGE	mt-forwardSM
MAP-MO-FORWARD-SHORT-MESSAGE	mo-forwardSM
MAP-GET-PASSWORD	getPassword
MAP-INFORM-SERVICE-CENTRE	informServiceCentre
MAP-INSERT-SUBSCRIBER-DATA	insertSubscriberData
MAP-INTERROGATE-SS	interrogateSs
MAP-IST-ALERT	istAlert
MAP-IST-COMMAND	istCommand
MAP-NOTE-MS-PRESENT-FOR-GPRS	noteMsPresentForGprs
MAP-NOTE-SUBSCRIBER-DATA-MODIFIED	noteSubscriberDataModified
MAP-PREPARE-GROUP-CALL	prepareGroupCall
MAP-PREPARE-HANDOVER	prepareHandover
MAP-PREPARE-SUBSEQUENT-HANDOVER	prepareSubsequentHandover
MAP-PROCESS-ACCESS-SIGNALLING	processAccessSignalling
MAP-PROCESS-GROUP-CALL-SIGNALLING	processGroupCallSignalling
MAP-PROCESS-UNSTRUCTURED-SS-REQUEST	processUnstructuredSS-Request
MAP-PROVIDE-ROAMING-NUMBER	provideRoamingNumber
MAP-PROVIDE-SUBSCRIBER-LOCATION	provideSubscriberLocation
MAP-PROVIDE-SUBSCRIBER-INFO	provideSubscriberInfo
MAP-PURGE-MS	purgeMS
MAP-READY-FOR-SM	readyForSM
MAP-REGISTER-CC-ENTRY	registerCC-Entry
MAP-REGISTER-PASSWORD	registerPassword
MAP-REGISTER-SS	registerSS
MAP-REMOTE-USER-FREE	remoteUserFree
MAP-REPORT-SM-DELIVERY-STATUS	reportSmDeliveryStatus
MAP-RESET	reset
MAP-RESTORE-DATA	restoreData
MAP-SEND_GROUP-CALL_END_SIGNAL	sendGroupCallEndSignal
MAP-SEND-GROUP-CALL-INFO	sendGroupCallInfo
MAP-SEND-END-SIGNAL	sendEndSignal

MAP-SEND-AUTHENTICATION-INFO	sendAuthenticationInfo
MAP-SEND-IMSI	sendIMSI
MAP-SEND-IDENTIFICATION	sendIdentification
MAP-SEND-ROUTING-INFO-FOR-SM	sendRoutingInfoForSM
MAP-SEND-ROUTING-INFO-FOR-GPRS	sendRoutingInfoForGprs
MAP-SEND-ROUTING-INFO-FOR-LCS	sendRoutingInfoForLCS
MAP-SEND-ROUTING-INFORMATION	sendRoutingInfo
MAP-SET-REPORTING-STATE	setReportingState
MAP-STATUS-REPORT	statusReport
MAP-SUBSCRIBER-LOCATION-REPORT	subscriberLocationReport
MAP-SUPPLEMENTARY-SERVICE-INVOCATION-NOTIFICATION	ss-Invocation-Notification
MAP-UNSTRUCTURED-SS-NOTIFY	unstructuredSS-Notify
MAP-UNSTRUCTURED-SS-REQUEST	unstructuredSS-Request
MAP-UPDATE-GPRS-LOCATION	updateGprsLocation
MAP-UPDATE-LOCATION	updateLocation
MAP-NOTE-MM-EVENT	NoteMM-Event

16.2.2.5 Error

The error parameter in a TC-U-ERROR indication primitive is mapped to the user error parameter in the MAP confirm primitive of the service associated with the operation to which the error is attached.

The user error parameter in MAP response primitives is mapped to the error parameter of the TC-U-ERROR request primitive, except for "initiating-release" and "resource-limitation" which are mapped to the problem code parameter of the TC-U-REJECT request primitive.

16.2.2.6 Parameters

The parameters of MAP specific request and indication primitives are mapped to the argument parameter of TC-INVOKE primitives.

The parameters of MAP specific response and confirm primitives are mapped to the result parameter of TC-RESULT-L primitives, the parameter of TC-U-ERROR primitives or the argument of TC-INVOKE primitives when mapping on linked class 4 operations is used.

16.2.2.7 Time out

The value of this parameter is set by the MAP PM according to the type of operation invoked.

16.2.2.8 Last component

This parameter is used by the MAP PM as described in CCITT Recommendation Q.711. It is not visible from the MAP user.

16.2.2.9 Problem code

16.2.2.9.1 Mapping to MAP User Error

The following values of the user error parameter are mapped as follows to values of the TC problem code parameter. These values are generated by the MAP user. This mapping is valid from the TC-U-REJECT indication primitive to the MAP confirm service primitive and from the MAP response service primitive to the TC-U-REJECT request primitive.

Table 16.2/2: Mapping of MAP User Error parameter on to TC problem code in TC-U-REJECT primitives

MAP User Error	TC problem code
resource limitation	resource limitation
initiating release	initiating release

16.2.2.9.2 Mapping to MAP Provider Error parameter

The following values of the TC problem code parameter of the TC-U-REJECT indication primitive are mapped as follows to values of the MAP Provider Error parameter of the MAP confirm primitive.

Table 16.2/3: Mapping of TC problem code in TC-U-REJECT on to MAP Provider Error parameter

TC problem code	MAP Provider Error
duplicated invoke Id	duplicated invoke id
unrecognised operation	service not supported
mistyped parameter	mistyped parameter

The following values of the problem code parameters of the TC-L-REJECT primitive are mapped to values of the provider error parameter of the MAP confirm primitive as follows.

Table 16.2/4: Mapping of TC problem code in TC-L-REJECT on to MAP Provider Error parameter

TC problem code	MAP Provider Error
return result unexpected	unexpected response from the peer
return error unexpected	unexpected response from the peer

16.2.2.9.3 Mapping to diagnostic parameter

The following values of the problem code parameter of the TC-R-REJECT and TC-U-REJECT primitive are mapped to values of the diagnostic parameter of the MAP-NOTICE indication primitive as follows:

Table 16.2/5: Mapping of TC problem code of TC-R-REJECT and TC-U-REJECT on to diagnostic parameter

TC problem code	MAP diagnostic
General problem	- abnormal event detected by the peer
Invoke problem	
- unrecognised linked ID	- abnormal event detected by the peer
- linked response unexpected	- response rejected by the peer
- unexpected linked operation	- response rejected by the peer
Return result problem	
- unrecognised invoke ID	- response rejected by the peer
- return result unexpected	- response rejected by the peer
- mistyped parameter	- response rejected by the peer
Return error problem	
- unrecognised invoke ID	- response rejected by the peer
- return error unexpected	- response rejected by the peer
- unrecognised error	- response rejected by the peer
- unexpected error	- response rejected by the peer
- mistyped parameter	- response rejected by the peer

The following values of the problem code parameter of the TC-L-REJECT primitive are mapped to values of the diagnostic parameter of the MAP-NOTICE indication primitive as follows.

Table 16.2/6: Mapping of TC problem code of TC-L-REJECT on to diagnostic parameter

TC problem code	MAP diagnostic
General problems	- abnormal event received from the peer
Invoke problem	
- unrecognised linked ID	- abnormal event received from the peer
Return result problem	
- unrecognised invoke ID	- abnormal event received from the peer
Return error problem	
- unrecognised invoke ID	- abnormal event received from the peer

17 Abstract syntax of the MAP protocol

17.1 General

This clause specifies the Abstract Syntaxes for the Mobile Application Part as well as the associated set of Operations and Errors, using the Abstract Syntax Notation One (ASN.1), defined in ITU-T Recommendations X.680 and X.681 with additions as defined in clause 17.1.4 on Compatibility Considerations and the OPERATION and ERROR external information object classes, defined in ITU-T Recommendation X.880.

The Abstract Syntax is defined for all interfaces specified in clause 4.4 except for the A- and B-interfaces.

The Mobile Application Part protocol is defined by two Abstract Syntaxes:

- one Abstract Syntax which encompass all Operations and Errors identified by the various MAP subsystem numbers.

This Abstract Syntax represents the set of values each of which is a value of the ASN.1 type TCAPMessages. TCMessage as defined in ITU-T Recommendation Q.773 with the component relationconstraint sections resolved by the operation and error codes included in the ASN.1 modules MAP-*Operations and MAP-Errors. However, only the subset of this abstract syntax which is required by the procedures defined for an entity needs to be supported.

- one Abstract Syntax identified by the OBJECT IDENTIFIER value MAP-DialogueInformation.map-DialogueAS.

This Abstract Syntax represents the set of values each of which is a value of the ASN.1 type MAP-DialogueInformation.MAP-DialoguePDU. Such a value of the ASN.1 single-ASN.1-type element is contained within the user-information element of the TCAPMessages.DialoguePortion ASN.1 type. This Abstract Syntax name is to be used as a direct reference.

17.1.1 Encoding rules

The encoding rules which are applicable to the defined Abstract Syntaxes are the Basic Encoding Rules for Abstract Syntax Notation One, defined in ITU-T Recommendation X.690 with the same exceptions as in ITU-T Recommendation Q.773, clause 4 Message Representation.

When the definite form is used for length encoding, a data value of length less than 128 octets must have the length encoded in the short form.

When the long form is employed to code a length, the minimum number of octets shall be used to code the length field.

OCTET STRING values and BIT STRING values must be encoded in a primitive form.

There is no restriction to the use of empty constructors (e.g. an empty SEQUENCE type). That is, the encoding of the content of any data value shall consist of zero, one or more octets.

17.1.2 Use of TC

The mapping of OPERATION and ERROR to TC components is defined in ETS 300 287 (version 2) which is based on ITU-T Recommendation Q.773.

NOTE 1: The class of an operation is not stated explicitly but is specified as well in the ASN.1 operation definition.

Class 1: RESULT and ERROR appear in ASN.1 operation definition.

Class 2: only ERROR appears in ASN.1 operation definition.

Class 3: only RESULT appears in ASN.1 operation definition.

Class 4: both RESULT and ERROR do not appear in ASN.1 operation definition.

The field "ARGUMENT", "PARAMETER" or "RESULT" (for information objects of class OPERATION and ERROR) is always optional from a syntactic point of view. However, except when specifically mentioned with the

ASN.1 comment "-- optional" , the "parameter" part of a component has to be considered as mandatory from a semantic point of view.

When an optional element is missing in an invoke component or in an inner data structure while it is required by the context, an error component is returned if specified in the information object associated with the operation ; the associated type of error is "DataMissing". This holds also when the entire parameter of an invoke component is missing while it is required by the context.

NOTE 2: When a mandatory element is missing in the parameter or inner data structure of any component, a reject component is returned (if the dialogue still exists). The problem code to be used is "Mistyped parameter".

The Timer Values used in the operation definitions are indicated as ASN.1 comments. The Timer Value Ranges are:

s = from 3 seconds to 10 seconds;

m = from 15 seconds to 30 seconds;

ml = from 1 minute to 10 minutes;

l = from 28 hours to 38 hours.

17.1.2.1 Use of Global Operation and Error codes defined outside MAP

An entity supporting an application context greater than 2 shall be capable of receiving an operation or error code, within an application context defined in GSM 29.002, encoded as either an Object Identifier (as defined in ITU-T Recommendation X.690) or an integer value (as defined in clause 17.5). Related restrictions regarding the use of Object Identifiers are as follows:

- The length of the Object Identifier shall not exceed 16 octets and the number of components of the Object Identifier shall not exceed 16.
- Object Identifiers shall be used only for operations or errors defined outside of GSM 29.002.
- Global error codes may be sent only in response to a global operation. If a standard operation is received then a global error code shall not be sent in response.

Handling of an unknown operation codes by the receiving entity is defined in clause 15.1.1.

17.1.3 Use of information elements defined outside MAP

An information element or a set of information elements (messages) transparently carried in the Mobile Application Part but defined in other recommendations/technical specifications are handled in one of the following ways:

i) The contents of each information element (without the octets encoding the identifier and the length in the recommendation/technical specification where it is defined unless explicitly stated otherwise) is carried as the value of an ASN.1 type derived from the OCTET STRING data type. Additionally, the internal structure may be explained by means of comments. In case of misalignment the referred to recommendation/technical specification takes precedence.

ii) The complete information element (including the octets encoding the identifier and the length in the recommendation/technical specification where it is defined) or set of information elements and the identity of the associated protocol are carried as the value of the ExternalSignalInfo data type defined in the present document. Where more than one information element is carried, the information elements are sent contiguously with no filler octets between them.

17.1.4 Compatibility considerations

The following ASN.1 modules conform to ITU-T Recommendation X.680 and X.681 . An extension marker ("...") is used wherever future protocol extensions are foreseen.

The "..." construct applies only to SEQUENCE and ENUMERATED data types. An entity supporting a version greater than 1 shall not reject an unsupported extension following "..." of that SEQUENCE or ENUMERATED data type. The

Encoding Rules from clause 17.1.1 apply to every element of the whole Transfer Syntax especially to the ASN.1 type EXTERNAL.

The extension container "privateExtensionList" is defined in this specification in order to carry extensions which are defined outside this specification. Private extensions can be defined by, for example, network operators, manufacturers, and regional standardisation bodies.

Private extensions shall:

1) if included in operations of an AC of V2, follow the extension marker and be tagged using PRIVATE tags up to and including 29.

NOTE: This type of extension is in most cases used only within a PLMN.

2) if included in operations of an AC of V3 or higher: be included only in the Private Extension Container that is defined in the specification.

NOTE: This type of extension can be used between PLMNs.

Private extensions shall not be included in v2 supplementary service operations.

Private extensions shall not be included within user error for RegisterCCEntry and EraseCCEntry operations.

PCS extensions shall be included in the PCS Extension Container that is defined in this specification.

In order to improve extensibility, a few error parameters have been defined as a CHOICE between the version 2 description and a SEQUENCE including the version 2 description and an extension container. Operations used in a v2-application-context must consider only the first alternative while operations used in a vn-application-context (n>2) must consider only the second alternative.

17.1.5 Structure of the Abstract Syntax of MAP

For each MAP parameter which has to be transferred by a MAP Protocol Data Unit (MAP message), there is a PDU field (an ASN.1 type) which has the same name as the corresponding parameter, except for the differences required by the ASN.1 notation (blanks between words are removed or replaced by hyphen, the first letter of the first word is capital and the first letter of each of the following words ise capitalised, e.g. "no reply condition time" is mapped to "NoReplyConditionTime"). Additionally some words may be abbreviated as follows:

bs basic service

ch call handling

cug closed user group

ho handover

ic incoming call

id identity

info information

mm mobility management

lcs location services

ms mobile service

oc outgoing call

om operation & maintenance

pw Password

sm short message service

ss supplementary service

The MAP protocol is composed of several ASN.1 modules dealing with either operations, errors, data types, and, if applicable, split into those dealing with mobile services, call handling services, supplementary services and short message services. For operations and errors the code values are given as parameters, in order to allow use of the defined information objects also by other protocols (e.g. 3GPP TS 24.080 [38]). The ASN.1 source lines are preceded by line-numbers at the left margin in order to enable the usage of the cross-reference in annex A.

The module containing the definition of the operation packages for MAP is:

1. MAP-OperationPackages.

The module containing the definition of the application contexts for MAP is:

2. MAP-ApplicationContexts.

The module containing the data types for the Abstract Syntax to be used for TCAPMessages.DialoguePortion for MAP is:

3. MAP-DialogueInformation.

The module containing the supported operations is:

4. MAP-Protocol.

The modules containing all operation definitions for MAP are:

5. MAP-MobileServiceOperations;
6. MAP-OperationAndMaintenanceOperations;
7. MAP-CallHandlingOperations;
8. MAP-SupplementaryServiceOperations;
9. MAP-ShortMessageServiceOperations;
10. MAP-Group-Call-Operations;
11. MAP-LocationServiceOperations.

The module containing all error definitions for MAP is:

12. MAP-Errors.

Modules containing all data type definitions for MAP are:

13. MAP-MS-DataTypes;
14. MAP-OM-DataTypes;
15. MAP-CH-DataTypes;
16. MAP-SS-DataTypes;
17. MAP-SS-Code;
18. MAP-SM-DataTypes;
19. MAP-ER-DataTypes;
20. MAP-CommonDataTypes;
21. MAP-TS-Code;
22. MAP-BS-Code;
23. MAP-ExtensionDataTypes;
24. MAP-GR-DataTypes;

25. MAP-LCS-DataTypes.

References are made also to modules defined outside of the present document. They are defined in the technical specification Mobile Services Domain, technical specification Transaction Capability and ITU-T Recommendation X.880 respectively:

MobileDomainDefinitions;

TCAPMessages, DialoguePDUs ;

Remote-Operations-Information-Objects.

17.1.6 Application Contexts

The following informative table lists the latest versions of the Application Contexts used in this specification, with the operations used by them and, where applicable, whether or not the operation description is exactly the same as for previous versions. Information in 17.6 & 17.7 relates only to the ACs in this table.

AC Name	AC Version	Operations Used	Comments
locationCancellationContext	v3	cancelLocation	
equipmentMngtContext	V3	checkIMEI	
imsiRetrievalContext	v2	sendIMSI	
infoRetrievalContext	v3	sendAuthenticationInfo	
interVlrInfoRetrievalContext	v3	sendIdentification	
handoverControlContext	v3	prepareHandover forwardAccessSignalling sendEndSignal processAccessSignalling prepareSubsequentHandover	the syntax of this operation has been extended in comparison with release 98 version
mwdMngtContext	v3	readyForSM	
msPurgingContext	v3	purgeMS	
shortMsgAlertContext	v2	alertServiceCentre	
resetContext	v2	reset	
networkUnstructuredSsContext	v2	processUnstructuredSS-Request unstructuredSS-Request unstructuredSS-Notify	
tracingContext	v3	activateTraceMode deactivateTraceMode	
networkFunctionalSsContext	v2	registerSS eraseSS activateSS deactivateSS registerPassword interrogateSS getPassword	
shortMsgMO-RelayContext	v3	mo-forwardSM	
shortMsgMT-RelayContext	v3	mt-forwardSM	
shortMsgMT-VGCS-RelayContext	v3	mt-forwardSM-VGCS	
shortMsgGatewayContext	v3	sendRoutingInfoForSM reportSM-DeliveryStatus InformServiceCentre	the syntax of this operation has been extended in comparison with release 96 version
networkLocUpContext	v3	updateLocation forwardCheckSs-Indication restoreData insertSubscriberData activateTraceMode	the syntax is the same in v1 & v2
gprsLocationUpdateContext	v3	updateGprsLocation insertSubscriberData activateTraceMode	
subscriberDataMngtContext	v3	insertSubscriberData	

AC Name	AC Version	Operations Used	Comments
		deleteSubscriberData	
roamingNumberEnquiryContext	v3	provideRoamingNumber	
locationInfoRetrievalContext	v3	sendRoutingInfo	
gprsNotifyContext	v3	noteMsPresentForGprs	
gprsLocationInfoRetrievalContext	v4	sendRoutingInfoForGprs	
failureReportContext	v3	failureReport	
callControlTransferContext	v4	resumeCallHandling	
subscriberInfoEnquiryContext	v3	provideSubscriberInfo	
anyTimeEnquiryContext	v3	anyTimeInterrogation	
anyTimeInfoHandlingContext	v3	anyTimeSubscriptionInterrogation anyTimeModification	
ss-InvocationNotificationContext	v3	ss-InvocationNotification	
groupCallControlContext	v3	prepareGroupCall processGroupCallSignalling forwardGroupCallSignalling sendGroupCallEndSignal	
reportingContext	v3	setReportingState statusReport remoteUserFree	
callCompletionContext	v3	registerCC-Entry eraseCC-Entry	
istAlertingContext	v3	istAlert	
ServiceTerminationContext	v3	istCommand	
locationSvcEnquiryContext	v3	provideSubscriberLocation subscriberLocationReport	
locationSvcGatewayContext	v3	sendRoutingInfoForLCS	
mm-EventReportingContext	v3	noteMM-Event	
subscriberDataModificationNotificationContext	v3	noteSubscriberDataModified	
authenticationFailureReportContext	v3	authenticationFailureReport	
resourceManagementContext	v3	releaseResources	
groupCallInfoRetievalContext	V3	sendGroupCallInfo	

NOTE (*): The syntax of the operations is not the same as in previous versions unless explicitly stated

17.2 Operation packages

17.2.1 General aspects

This clause describes the operation-packages which are used to build the application-contexts defined in clause 17.3.

Each operation-package is a specification of the roles of a pair of communicating objects (i.e. a pair of MAP-Providers), in terms of operations which they can invoke of each other.

The grouping of operations into one or several packages does not necessarily imply any grouping in terms of Application Service Elements.

The following ASN.1 information object class is used to describe operation-packages in this clause:

```
OPERATION-PACKAGE ::= CLASS {
     &Both     OPERATION                 OPTIONAL,
     &Consumer OPERATION                 OPTIONAL,
     &Supplier OPERATION                 OPTIONAL,
     &id       OBJECT IDENTIFIER         UNIQUE OPTIONAL }
WITH SYNTAX {
     [ OPERATIONS       &Both ]
     [ CONSUMER INVOKES &Supplier ]
     [ SUPPLIER INVOKES &Consumer ]
     [ ID               &id ] }
```

Since the application-context definitions provided in clause 17.3 use only an informal description technique, only the type notation is used in the following clauses to define operation-packages.

The following definitions are used throughout this clause (n>=2):

- v1-only operation: An operation which shall be used only in v1 application-contexts;
- vn-only operation: An operation which shall be used only in vn application-contexts;
- v(n-1)-operation: An operation whose specification has not been modified since the MAP v(n-1) specifications or if the modifications are considered as not affecting v(n-1) implementations;
- v(n-1)-equivalent operation: The version of an operation which excludes all the information elements and errors which have been added since the MAP v(n-1) specification;
- vn-only package: An operation package which contains only vn-only operations;
- v(n-1)-package: An operation package which contains only v(n-1)- operations.

The names of vn-packages are suffixed by "-vn" where n>=2.

For each operation package which is not vn-only (n>=2) and which does not include only v(n-1)-operations, there is a v(n-1)-equivalent package. Except when a definition is explicitly provided in the following clauses, the v(n-1)-equivalent package includes the v(n-1)-equivalent operations of the operations which belong to this package.

17.2.2 Packages specifications

17.2.2.1 Location updating

This operation package includes the operations required for location management procedures between HLR and VLR.

```
locationUpdatingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          updateLocation}
     SUPPLIER INVOKES {
          forwardCheckSs-Indication} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.2 Location cancellation

This operation package includes the operations required for location cancellation and MS purging procedures between HLR and VLR and between HLR and SGSN.

```
locationCancellationPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          cancelLocation} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.3 Roaming number enquiry

This operation package includes the operations required for roaming number enquiry procedures between HLR and VLR.

```
roamingNumberEnquiryPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR if Consumer is HLR
     CONSUMER INVOKES {
          provideRoamingNumber} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.4 Information retrieval

This operation package includes the operation required for the authentication information retrieval procedure between HLR and VLR and between HLR and SGSN.

```
infoRetrievalPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is HLR if Consumer is SGSN
     CONSUMER INVOKES {
          sendAuthenticationInfo} }
```

The v2-equivalent package is defined as follows:

```
infoRetrievalPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is HLR if Consumer is SGSN
     CONSUMER INVOKES {
          sendAuthenticationInfo} }
```

The v1-equivalent package is defined as follows:

```
infoRetrievalPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is HLR or VLR if Consumer is VLR
     -- Supplier is HLR if Consumer is SGSN
     CONSUMER INVOKES {
          sendParameters} }
```

17.2.2.5 Inter-VLR information retrieval

This operation package includes the operations required for inter VLR information retrieval procedures.

```
interVlrInfoRetrievalPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR if Consumer is VLR
     CONSUMER INVOKES {
          sendIdentification} }
```

The v2-equivalent package is defined as follows:

```
interVlrInfoRetrievalPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is VLR if Consumer is VLR
     CONSUMER INVOKES {
          sendIdentification} }
```

The v1-equivalent package is : infoRetrievalPackage-v1.

17.2.2.6 IMSI retrieval

This operation package includes the operation required for the IMSI retrieval procedure between HLR and VLR.

```
imsiRetrievalPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          sendIMSI} }
```

This package is v2 only.

17.2.2.7 Call control transfer

This operation package includes the operation required for the call control transfer procedure between VMSC and GMSC.

```
callControlTransferPackage-v4  OPERATION-PACKAGE ::= {
     -- Supplier is GMSC if Consumer is VMSC
     CONSUMER INVOKES {
          resumeCallHandling} }
```

The v3-equivalent package can be determined according to the rules described in clause 17.2.1.

17.2.2.8 Void

17.2.2.9 Void

17.2.2.10 Interrogation

This operation package includes the operations required for interrogation procedures between MSC and HLR or NPLR or between HLR and gsmSCF.

```
interrogationPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR or NPLR if Consumer is MSC
     -- Supplier is HLR if Consumer is gsmSCF
     CONSUMER INVOKES {
          sendRoutingInfo} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.11 Void

17.2.2.12 Handover Control

This operation package includes the operations required for handover procedures between MSCs.

```
handoverControlPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is MSCB if Consumer is MSCA
     CONSUMER INVOKES {
          prepareHandover |
          forwardAccessSignalling}
     SUPPLIER INVOKES {
          sendEndSignal |
          processAccessSignalling |
          prepareSubsequentHandover} }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is defined as follows.

```
handoverControlPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is MSCB if Consumer is MSCA
     CONSUMER INVOKES {
          performHandover |
          forwardAccessSignalling |
          traceSubscriberActivity}
     SUPPLIER INVOKES {
          sendEndSignal |
          noteInternalHandover |
          processAccessSignalling |
          performSubsequentHandover} }
```

17.2.2.13 Subscriber Data management stand alone

This operation package includes the operations required for stand alone subscriber data management procedures between HLR and VLR or between HLR and SGSN.

```
subscriberDataMngtStandAlonePackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          insertSubscriberData |
          deleteSubscriberData} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.14 Equipment management

This operation package includes the operations required for equipment management procedures between EIR and MSC or between EIR and SGSN.

```
equipmentMngtPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is EIR if Consumer is MSC
     -- Supplier is EIR if Consumer is SGSN
     CONSUMER INVOKES {
          checkIMEI} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.15 Subscriber data management

This operation package includes the operations required for subscriber data management procedures between HLR and VLR or between HLR and SGSN.

```
subscriberDataMngtPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          insertSubscriberData} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.16 Location register restart

This operation package includes the operations required for location register restart procedures between HLR and VLR or between HLR and SGSN.

```
resetPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          reset} }
```

The v1-equivalent package can be determined according to the rules described in clause 17.2.1.

17.2.2.17 Tracing stand-alone

This operation package includes the operations required for stand alone tracing procedures between HLR and VLR or between HLR and SGSN.

```
tracingStandAlonePackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          activateTraceMode |
          deactivateTraceMode} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.18 Functional SS handling

This operation package includes the operations required for functional supplementary services procedures between VLR and HLR.

```
functionalSsPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          registerSS |
          eraseSS |
          activateSS |
          deactivateSS |
          registerPassword |
          interrogateSS}
     SUPPLIER INVOKES {
          getPassword} }
```

The v1-equivalent package can be determined according to the rules described in clause 17.2.1.

17.2.2.19 Tracing

This operation package includes the operations required for tracing procedures between HLR and VLR or between HLR and SGSN.

```
tracingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          activateTraceMode} }
```

The v1-equivalent and v2-equivalent packages can be determined according to the rules described in clause 17.2.1.

17.2.2.20 Binding

This operation package includes the operation required to initialise a supplementary service procedure between VLR and HLR or between gsmSCF and HLR.

```
bindingPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is gsmSCF if Consumer is HLR
     CONSUMER INVOKES {
          beginSubscriberActivity} }
```

This package is v1 only.

17.2.2.21 Unstructured SS handling

This operation package includes the operations required for unstructured supplementary services procedures between VLR and HLR, between the HLR and the gsmSCF, and between HLR and HLR.

```
unstructuredSsPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is gsmSCF or HLR if Consumer is HLR
     CONSUMER INVOKES {
          processUnstructuredSS-Request}
     SUPPLIER INVOKES {
          unstructuredSS-Request |
          unstructuredSS-Notify} }
```

The v1-equivalent package is defined as follows:

```
unstructuredSsPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is gsmSCF if Consumer is HLR
     CONSUMER INVOKES {
          processUnstructuredSS-Data} }
```

17.2.2.22 MO Short message relay services

This operation package includes the operations required for short message relay service procedures between IWMSC and VMSC or between GMSC and MSC or between SGSN and IWMSC.

```
mo-ShortMsgRelayPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is IWMSC if Consumer is MSC
     -- Supplier is IWMSC if Consumer is SGSN
     CONSUMER INVOKES {
          mo-forwardSM} }
```

The v2-equivalent package is defined as follows:

```
shortMsgRelayPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is IWMSC if Consumer is MSC
     -- Supplier is MSC or SGSN if Consumer is GMSC
     -- Supplier is IWMSC if Consumer is SGSN
     CONSUMER INVOKES {
          forwardSM} }
```

The v1-equivalent package can be determined according to the rules described in clause 17.2.1.

17.2.2.23 Short message gateway services

This operation package includes the operations required for short message service gateway procedures between MSC and HLR.

```
shortMsgGatewayPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GMSC
     CONSUMER INVOKES {
          sendRoutingInfoForSM |
          reportSM-DeliveryStatus}
     SUPPLIER INVOKES {
          informServiceCentre} }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is defined as follows:

```
shortMsgGatewayPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GMSC
     CONSUMER INVOKES {
          sendRoutingInfoForSM |
          reportSMDeliveryStatus} }
```

17.2.2.24 MT Short message relay services

This operation package includes the operations required for short message relay service procedures between GMSC and MSC or between GMSC and SGSN.

```
mt-ShortMsgRelayPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is MSC or SGSN if Consumer is GMSC
     CONSUMER INVOKES {
          mt-forwardSM} }
```

The v2-equivalent package is: s**hortMsgRelayPackage-v2**

17.2.2.25 Void

17.2.2.26 Message waiting data management

This operation package includes the operations required for short message waiting data procedures between HLR and VLR, between HLR and SGSN.

```
mwdMngtPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is SGSN
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          readyForSM} }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is defined as follows:

```
mwdMngtPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          noteSubscriberPresent} }
```

17.2.2.27 Alerting

This operation package includes the operations required for alerting between HLR and IWMSC.

```
alertingPackage-v2  OPERATION-PACKAGE ::= {
     -- Supplier is IWMSC if Consumer is HLR
     CONSUMER INVOKES {
          alertServiceCentre} }
```

The v1-equivalent package is defined as follows.

```
alertingPackage-v1  OPERATION-PACKAGE ::= {
     -- Supplier is IWMSC if Consumer is HLR
     CONSUMER INVOKES {
          alertServiceCentreWithoutResult} }
```

17.2.2.28 Data restoration

This operation package includes the operations required for VLR data restoration between HLR and VLR.

```
dataRestorationPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          restoreData} }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

The v1-equivalent package is: infoRetrievalPackage-v1

17.2.2.29 Purging

This operation package includes the operations required for purging between HLR and VLR or between HLR and SGSN.

```
purgingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is HLR if Consumer is SGSN
     CONSUMER INVOKES {
          purgeMS} }
```

The v2-equivalent package can be determined according to the rules described in clause 17.2.1.

17.2.2.30 Subscriber information enquiry

This operation package includes the operations required for subscriber information enquiry procedures between HLR and VLR or between HLR and SGSN.

```
subscriberInformationEnquiryPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR or SGSN if Consumer is HLR
     CONSUMER INVOKES {
          provideSubscriberInfo} }
```

This package is v3 only.

17.2.2.31 Any time information enquiry

This operation package includes the operations required for any time information enquiry procedures between gsmSCF and HLR or between gsmSCF and GMLC or between gsmSCF and NPLR.

```
anyTimeInformationEnquiryPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR or GMLC or NPLR if Consumer is gsmSCF
     CONSUMER INVOKES {
          anyTimeInterrogation} }
```

This package is v3 only.

17.2.2.32 Group Call Control

This operation package includes the operations required for group call and broadcast call procedures between MSCs.

```
groupCallControlPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is relay MSC if Consumer is anchor MSC
     CONSUMER INVOKES {
          prepareGroupCall |
          forwardGroupCallSignalling}
     SUPPLIER INVOKES {
          sendGroupCallEndSignal |
          processGroupCallSignalling} }
```

This package is v3 only.

17.2.2.32A Group Call Info Retrieval

This operation package includes the operations required for group call and broadcast call info retrieval between MSCs.

```
groupCallInfoRetrievalPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is group call serving MSC if Consumer is visited MSC
     -- Supplier is visited MSC if Consumer is group call serving MSC
     CONSUMER INVOKES {
          sendGroupCallInfo} }
```

This package is v3 only.

17.2.2.33 Void

17.2.2.34 Void

17.2.2.35 Gprs location updating

This operation package includes the operations required for the gprs location management procedures between HLR and SGSN.

```
gprsLocationUpdatingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is SGSN
     CONSUMER INVOKES {
          updateGprsLocation} }
```

This package is v3 only.

17.2.2.36 Gprs Interrogation

This operation package includes the operations required for interrogation procedures between HLR and GGSN.

```
gprsInterrogationPackage-v4  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GGSN
     CONSUMER INVOKES {
          sendRoutingInfoForGprs} }
```

The v3-equivalent package is defined as follows.

```
gprsInterrogationPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GGSN
     CONSUMER INVOKES {
          sendRoutingInfoForGprs} }
```

17.2.2.37 Failure reporting

This operation package includes the operations required for failure reporting between HLR and GGSN.

```
failureReportingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GGSN
     CONSUMER INVOKES {
          failureReport} }
```

This package is v3 only.

17.2.2.38 GPRS notifying

This operation package includes the operations required for notifying that GPRS subscriber is present between HLR and GGSN.

```
gprsNotifyingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is GGSN if Consumer is HLR
     CONSUMER INVOKES {
          noteMsPresentForGprs} }
```

This package is v3 only.

17.2.2.39 Supplementary Service invocation notification

This operation package includes the operations required for Supplementary Service invocation notification procedures between the MSC and the gsmSCF and between the HLR and the gsmSCF.

```
ss-InvocationNotificationPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is gsmSCF if Consumer is MSC
     -- Supplier is gsmSCF if Consumer is HLR
     CONSUMER INVOKES {
          ss-InvocationNotification} }
```

This package is v3 only.

17.2.2.40 Set Reporting State

This operation package includes the operation required for procedures between HLR and VLR to set the reporting state.

```
setReportingStatePackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR if Consumer is HLR
     CONSUMER INVOKES {
          setReportingState} }
```

This package is v3 only.

17.2.2.41 Status Report

This operation package includes the operation required for procedures between VLR and HLR to report call results and events.

```
statusReportPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          statusReport} }
```

This package is v3 only.

17.2.2.42 Remote User Free

This operation package includes the operation required by the HLR to indicate to the VLR that the remote user is free.

```
remoteUserFreePackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VLR if Consumer is HLR
     CONSUMER INVOKES {
          remoteUserFree} }
```

This package is v3 only.

17.2.2.43 Call Completion

This operation package includes the operations required for procedures between VLR and HLR for subscriber control of call completion services.

```
callCompletionPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     CONSUMER INVOKES {
          registerCC-Entry |
          eraseCC-Entry} }
```

This package is v3 only.

17.2.2.44 Location service gateway services

This operation package includes the operations required for location service gateway procedures between GMLC and HLR.

```
locationSvcGatewayPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is GMLC
     CONSUMER INVOKES {
          sendRoutingInfoForLCS} }
```

This package is v3 only.

17.2.2.45 Location service enquiry

This operation package includes the operations required for the location service enquiry procedures between GMLC and MSC and between GMLC and SGSN.

```
locationSvcEnquiryPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is MSC or SGSN if Consumer is GMLC
     CONSUMER INVOKES {
          provideSubscriberLocation} }
```

This package is v3 only.

17.2.2.45A Location service reporting

This operation package includes the operations required for the location service enquiry procedures between MSC and GMLC and between SGSN and GMLC.

```
locationSvcReportingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is GMLC if Consumer is MSC
     -- Supplier is GMLC if Consumer is SGSN
     CONSUMER INVOKES {
          subscriberLocationReport} }
```

17.2.2.46 Void

17.2.2.47 Void

17.2.2.48 Void

17.2.2.49 IST Alerting

This operation package includes the operation required for alerting procedures between the MSC (Visited MSC or Gateway MSC) and HLR.

```
ist-AlertingPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VMSC
     -- Supplier is HLR if Consumer is GMSC
     CONSUMER INVOKES {
          istAlert} }
```

This package is v3 only.

17.2.2.50 Service Termination

This operation package includes the operation required for immediate service termination procedures between the HLR and the Visited MSC or between the HLR and the Gateway MSC.

```
serviceTerminationPackage-v3  OPERATION-PACKAGE ::= {
     -- Supplier is VMSC or GMSC if Consumer is HLR
     CONSUMER INVOKES {
          istCommand} }
```

This package is v3 only.

17.2.2.51 Mobility Management event notification

This operation package includes the operations required for Mobility Management event notification procedures between VLR and gsmSCF.

```
mm-EventReportingPackage-v3 OPERATION-PACKAGE ::= {
     -- Supplier is gsmSCF if Consumer is VLR
     CONSUMER INVOKES {
          noteMM-Event} }
```

This package is v3 only.

17.2.2.52 Any time information handling

This operation package includes the operations required for any time information handling procedures between gsmSCF and HLR.

```
anyTimeInformationHandlingPackage-v3 OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is gsmSCF
     CONSUMER INVOKES {
          anyTimeSubscriptionInterrogation |
          anyTimeModification} }
```

This package is v3 only.

17.2.2.53 Subscriber Data modification notification

This operation package includes the operations required for Subscriber Data modification notification procedures between HLR and gsmSCF.

```
subscriberDataModificationNotificationPackage-v3 OPERATION-PACKAGE ::= {
     -- Supplier is gsmSCF if Consumer is HLR
     CONSUMER INVOKES {
          noteSubscriberDataModified} }
```

This package is v3 only.

17.2.2.54 Authentication Failure Report

This operation package includes the operation required for procedures between VLR and HLR or the SGSN and the HLR for reporting of authentication failures.

```
authenticationFailureReportPackage-v3 OPERATION-PACKAGE ::= {
     -- Supplier is HLR if Consumer is VLR
     -- Supplier is HLR if Consumer is SGSN
     CONSUMER INVOKES {
          authenticationFailureReport} }
```

This package is v3 only.

17.2.2.55 Resource Management

This operation package includes the operation required for procedures between GMSC and VMSC for resource management purpose.

```
resourceManagementPackage-v3 OPERATION-PACKAGE ::= {
     -- Supplier is VMSC if Consumer is GMSC
     CONSUMER INVOKES {
          releaseResources} }
```

This package is v3 only.

17.2.2.56 MT Short message relay VGCS services

This operation package includes the operations required for short message relay service procedures between SMS GMSC and MSC.

```
mt-ShortMsgRelay-VGCS-Package-v3  OPERATION-PACKAGE ::= {
     -- Supplier is MSC if Consumer is GMSC
     CONSUMER INVOKES {
          mt-forwardSM-VGCS} }
```

This package is v3 only.

17.3 Application contexts

17.3.1 General aspects

An application-context is assigned for each dialogue established by a MAP-user. In the present document each application-context is assigned a name which is supplied in the MAP-OPEN Req primitive by the MAP-User and transmitted to the peer under certain circumstances.

The following ASN.1 information object class is used to describe the main aspects of application-contexts in the following clauses:

```
APPLICATION-CONTEXT ::= CLASS {
     &Symmetric           OPERATION-PACKAGE OPTIONAL,
     &InitiatorConsumerOf OPERATION-PACKAGE OPTIONAL,
     &ResponderConsumerOf OPERATION-PACKAGE OPTIONAL,
     &code                OBJECT IDENTIFIER }
WITH SYNTAX {
     [ OPERATIONS OF         &Symmetric ]
     [ INITIATOR CONSUMER OF &InitiatorConsumerOf
       RESPONDER CONSUMER OF &ResponderConsumerOf ]
     ID &code }
```

The following definitions are used throughout this clause:

- v1-application-context: An application-context which contains only v1-packages and uses only TC v1 facilities;
- v1 context set: the set of v1-application-contexts defined in the present document.
- vn-application-context (n>=2): An application-context which contains only vn-packages;

The names of v1-application-contexts are suffixed by "-v1" while other names are suffixed by "-vn" where n>=2.

Application-contexts which do not belong to the v1 context set use v2 TC facilities.

The last component of each application-context-name (i.e. the last component of the object identifier value) assigned to an application-context which belongs to the v1 context set indicates explicitly "version1".

For each application-context which does not belong to the "v1 context set" there is a v1-equivalent application context. This is a v1-application-context which includes the v1-equivalents of the packages included in the original context.

Each application-context uses the abstract-syntax associated with the operation-packages it includes and uses the transfer-syntax derived from it by applying the encoding rules defined in clause 17.1.1.

ACs which do not belong to the v1 context set require the support of the abstract-syntax identified by the object identifier value: MAP-DialogueInformation.map-Dialogue-AS defined in clause 17.4.

17.3.2 Application context definitions

17.3.2.1 Void

17.3.2.2 Location Updating

This application context is used between HLR and VLR for location updating procedures.

```
networkLocUpContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          locationUpdatingPackage-v3 |
          dataRestorationPackage-v3}
     RESPONDER CONSUMER OF {
          subscriberDataMngtPackage-v3 |
          tracingPackage-v3}
     ID   {map-ac networkLocUp(1) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac networkLocUp(1) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac networkLocUp(1) version1(1)}
```

17.3.2.3 Location Cancellation

This application context is used between HLR and VLR or between HLR and SGSN for location cancellation procedures. For the HLR - SGSN interface only version 3 of this application context is applicable.

```
locationCancellationContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR or SGSN if Initiator is HLR
     INITIATOR CONSUMER OF {
          locationCancellationPackage-v3}
     ID    {map-ac locationCancel(2) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   map-ac locationCancel(2) version2(2)
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   map-ac locationCancel(2) version1(1)
```

17.3.2.4 Roaming number enquiry

This application context is used between HLR and VLR for roaming number enquiry procedures.

```
roamingNumberEnquiryContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR if Initiator is HLR
     INITIATOR CONSUMER OF {
          roamingNumberEnquiryPackage-v3}
     ID   {map-ac roamingNbEnquiry(3) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac roamingNbEnquiry(3) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac roamingNbEnquiry(3) version1(1)}
```

17.3.2.5 Void

17.3.2.6 Location Information Retrieval

This application-context is used between GMSC and HLR or between GMSC and NPLR or between gsmSCF and HLR when retrieving location information. For the GMSC - NPLR interface version 1, version 2 and version 3 of this application context are applicable.

```
locationInfoRetrievalContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR or NPLR if Initiator is GMSC
     -- Responder is HLR if Initiator is gsmSCF
     INITIATOR CONSUMER OF {
          interrogationPackage-v3}
     ID   {map-ac locInfoRetrieval(5) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac locInfoRetrieval(5) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac locInfoRetrieval(5) version1(1)}
```

17.3.2.7 Call control transfer

This application context is used for the call control transfer procedure between the VMSC and the GMSC.

```
callControlTransferContext-v4 APPLICATION-CONTEXT ::= {
     -- Responder is GMSC if Initiator is VMSC
     INITIATOR CONSUMER OF {
          callControlTransferPackage-v4}
     ID   {map-ac callControlTransfer(6) version4(4)} }
```

The following application-context-name is assigned to the v3-equivalent application-context:

```
     ID   {map-ac callControlTransfer(6) version3(3)}
```

17.3.2.8 Void

17.3.2.9 Void

17.3.2.10 Void

17.3.2.11 Location registers restart

This application context is used between HLR and VLR or between HLR and SGSN for location register restart procedures. For the HLR - SGSN interface version 1 and version 2 of this application context are applicable.

```
resetContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is VLR or SGSN if Initiator is HLR
     INITIATOR CONSUMER OF {
          resetPackage-v2}
     ID   {map-ac reset(10) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac reset(10) version1(1)}
```

17.3.2.12 Handover control

This application context is used for handover procedures between MSCs.

```
handoverControlContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is MSCB if Initiator is MSCA
     INITIATOR CONSUMER OF {
          handoverControlPackage-v3}
     ID   {map-ac handoverControl(11) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac handoverControl(11) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac handoverControl(11) version1(1)}
```

17.3.2.13 IMSI Retrieval

This application context is used for IMSI retrieval between HLR and VLR.

```
imsiRetrievalContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          imsi-RetrievalPackage-v2}
     ID   {map-ac imsiRetrieval(26) version2(2)} }
```

This application-context is v2 only.

17.3.2.14 Equipment Management

This application context is used for equipment checking between MSC and EIR or between SGSN and EIR. For the SGSN - EIR interface version 1 and version 2 and version 3 of this application context are applicable:

```
equipmentMngtContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is EIR if Initiator is MSC
     -- Responder is EIR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          equipmentMngtPackage-v3}
     ID   {map-ac equipmentMngt(13) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
equipmentMngtContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is EIR if Initiator is MSC
     -- Responder is EIR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          equipmentMngtPackage-v2}
     ID   {map-ac equipmentMngt(13) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac equipmentMngt(13) version1(1)}
```

17.3.2.15 Information retrieval

This application context is used for authentication information retrieval between HLR and VLR or between HLR and SGSN. For the HLR - SGSN interface version 1 and version 2 and version 3 of this application context are applicable.

```
infoRetrievalContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     -- Responder is HLR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          infoRetrievalPackage-v3}
     ID   {map-ac infoRetrieval(14) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
infoRetrievalContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     -- Responder is HLR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          infoRetrievalPackage-v2}
     ID   {map-ac infoRetrieval(14) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac infoRetrieval(14) version1(1)}
```

17.3.2.16 Inter-VLR information retrieval

This application context is used for information retrieval between VLRs.

```
interVlrInfoRetrievalContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          interVlrInfoRetrievalPackage-v3}
     ID   {map-ac interVlrInfoRetrieval(15) version3(3)} }
```

The v2-equivalent application-context is:

```
interVlrInfoRetrievalContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is VLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          interVlrInfoRetrievalPackage-v2}
     ID   {map-ac interVlrInfoRetrieval(15) version2(2)} }
```

The v1-equivalent application-context is:

```
     ID   {map-ac infoRetrieval(14) version1(1)}
```

17.3.2.17 Stand Alone Subscriber Data Management

This application context is used for stand alone subscriber data management between HLR and VLR or between HLR and SGSN. For the HLR - SGSN interface only version 3 of this application context is applicable:

```
subscriberDataMngtContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR or SGSN if Initiator is HLR
     INITIATOR CONSUMER OF {
          subscriberDataMngtStandAlonePackage-v3}
     ID   {map-ac subscriberDataMngt(16) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac subscriberDataMngt(16) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac subscriberDataMngt(16) version1(1)}
```

17.3.2.18 Tracing

This application context is used between HLR and VLR or between HLR and SGSN for stand alone tracing control procedures. For the HLR - SGSN interface version 1, version 2 and version 3 of this application context are applicable.

```
tracingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR or SGSN if Initiator is HLR
     INITIATOR CONSUMER OF {
          tracingStandAlonePackage-v3}
     ID   {map-ac tracing(17) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac tracing(17) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac tracing(17) version1(1)}
```

17.3.2.19 Network functional SS handling

This application context is used for functional-like SS handling procedures between VLR and HLR.

```
networkFunctionalSsContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is HLR, Initiator is VLR
     INITIATOR CONSUMER OF {
          functionalSsPackage-v2}
     ID   {map-ac networkFunctionalSs(18) version2(2)} }
```

The v1-equivalent application-context is defined as follows:

```
networkFunctionalSsContext-v1 APPLICATION-CONTEXT ::= {
     -- Responder is HLR, Initiator is VLR
     INITIATOR CONSUMER OF {
          functionalSsPackage-v1 |
          unstructuredSsPackage-v1 |
          bindingPackage-v1}
     ID   {map-ac networkFunctionalSs(18) version1(1)} }
```

17.3.2.20 Network unstructured SS handling

This application context is used for handling stimuli-like procedures between HLR and VLR, between the HLR and gsmSCF, and between HLR and HLR.

```
networkUnstructuredSsContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is HLR, Initiator is VLR
     -- Responder is VLR, Initiator is HLR
     -- Responder is gsmSCF, Initiator is HLR
     -- Responder is HLR, Initiator is gsmSCF
     -- Responder is HLR, Initiator is HLR
     OPERATIONS OF {
          unstructuredSsPackage-v2}
     ID   {map-ac networkUnstructuredSs(19) version2(2)} }
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac networkFunctionalSs(18) version1(1)}
```

17.3.2.21 Short Message Gateway

This application context is used for short message gateway procedures.

```
shortMsgGatewayContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is GMSC
     INITIATOR CONSUMER OF {
          shortMsgGatewayPackage-v3}
     ID   {map-ac shortMsgGateway(20) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac shortMsgGateway(20) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac shortMsgGateway(20) version1(1)}
```

17.3.2.22 Mobile originating Short Message Relay

This application context is used between MSC and IWMSC or between SGSN and IWMSC for mobile originating short message relay procedures. For the SGSN - IWMSC interface version 1, version 2 and version 3 of this application context are applicable.

```
shortMsgMO-RelayContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is IWMSC if Initiator is MSC
     -- Responder is IWMSC if Initiator is SGSN
     INITIATOR CONSUMER OF {
          mo-ShortMsgRelayPackage-v3}
     ID   {map-ac shortMsgMO-Relay(21) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac shortMsgMO-Relay(21) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac shortMsg-Relay(21) version1(1)}
```

17.3.2.23 Void

17.3.2.24 Short message alert

This application context is used for short message alerting procedures.

```
shortMsgAlertContext-v2 APPLICATION-CONTEXT ::= {
     -- Responder is IWMSC if Initiator is HLR
     INITIATOR CONSUMER OF {
          alertingPackage-v2}
     ID   {map-ac shortMsgAlert(23) version2(2)} }
```

The following application-context-name is symbolically assigned to the v1-equivalent application-context:

```
     ID   {map-ac shortMsgAlert(23) version1(1)}
```

17.3.2.25 Short message waiting data management

This application context is used between VLR and HLR or between SGSN and HLR for short message waiting data management procedures. For the SGSN - HLR interface only version 3 of this application context is applicable.

```
mwdMngtContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is SGSN
     -- Responder is HLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          mwdMngtPackage-v3}
     ID   {map-ac mwdMngt(24) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac mwdMngt(24) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac mwdMngt(24) version1(1)}
```

17.3.2.26 Mobile terminating Short Message Relay

This application context is used between GMSC and MSC or between GMSC and SGSN for mobile terminating short message relay procedures. For the GMSC - SGSN interface version 2 and version 3 of this application context and the equivalent version 1 application context are applicable.

```
shortMsgMT-RelayContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is MSC or SGSN if Initiator is GMSC
     INITIATOR CONSUMER OF {
          mt-ShortMsgRelayPackage-v3}
     ID   {map-ac shortMsgMT-Relay(25) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac shortMsgMT-Relay(25) version2(2)}
```

The following application-context-name is assigned to the v1-equivalent application-context:

```
     ID   {map-ac shortMsg-Relay(21) version1(1)}
```

17.3.2.27 MS purging

This application context is used between HLR and VLR or between HLR and SGSN for MS purging procedures. For the SGSN - HLR interface only version 3 of this application context is applicable.

```
msPurgingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     -- Responder is HLR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          purgingPackage-v3}
     ID   {map-ac msPurging(27) version3(3)} }
```

The following application-context-name is assigned to the v2-equivalent application-context:

```
     ID   {map-ac msPurging(27) version2(2)}
```

17.3.2.28 Subscriber information enquiry

This application context is used between HLR and VLR or between HLR and SGSN for subscriber information enquiry procedures.

```
subscriberInfoEnquiryContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR or SGSN if Initiator is HLR
     INITIATOR CONSUMER OF {
          subscriberInformationEnquiryPackage-v3}
     ID   {map-ac subscriberInfoEnquiry(28) version3(3)} }
```

This application-context is v3 only.

17.3.2.29 Any time information enquiry

This application context is used between gsmSCF and HLR or between gsmSCF and GMLC or between gsmSCF and NPLR for any time information enquiry procedures.

```
anyTimeInfoEnquiryContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR or GMLC or NPLR if Initiator is gsmSCF
     INITIATOR CONSUMER OF {
          anyTimeInformationEnquiryPackage-v3}
     ID   {map-ac anyTimeInfoEnquiry(29) version3(3)} }
```

This application-context is v3 only.

17.3.2.30 Group Call Control

This application context is used between anchor MSC and relay MSC for group call and broadcast call procedures.

```
groupCallControlContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is relay MSC if Initiator is anchor MSC
     INITIATOR CONSUMER OF {
          groupCallControlPackage-v3}
     ID   {map-ac groupCallControl(31) version3(3)} }
```

This application-context is v3 only.

17.3.2.30A Group Call Info Retrieval

This application context is used between group call serving MSC and visited MSC for group call and broadcast call procedures.

```
groupCallInfoRetControlContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is group call serving MSC if Initiator is visited MSC
     -- Responder is visited MSC if Initiator is group call serving MSC
     INITIATOR CONSUMER OF {
          groupCallInfoRetrievalPackage-v3}
     ID   {map-ac groupCallInfoRetrieval(45) version3(3)} }
```

This application-context is v3 only.

17.3.2.31 Void

17.3.2.32 Gprs Location Updating

This application context is used between HLR and SGSN for gprs location updating procedures.

```
gprsLocationUpdateContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          gprsLocationUpdatingPackage-v3}
     RESPONDER CONSUMER OF {
          subscriberDataMngtPackage-v3 |
          tracingPackage-v3}
     ID   {map-ac gprsLocationUpdate(32) version3(3)} }
```

This application-context is v3 only.

17.3.2.33 Gprs Location Information Retreival

This application context is used between HLR and GGSN when retrieving gprs location information.

```
gprsLocationInfoRetrievalContext-v4 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is GGSN
     INITIATOR CONSUMER OF {
          gprsInterrogationPackage-v4}
     ID   {map-ac gprsLocationInfoRetrieval(33) version4(4)} }
```

The following application-context-name is assigned to the v3-equivalent application-context:

```
     ID   {map-ac gprsLocationInfoRetrieval(33) version3(3)}
```

17.3.2.34 Failure Reporting

This application context is used between HLR and GGSN to inform that network requested PDP-context activation has failed.

```
failureReportContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is GGSN
     INITIATOR CONSUMER OF {
          failureReportingPackage-v3}
     ID   {map-ac failureReport(34) version3(3)} }
```

This application-context is v3 only.

17.3.2.35 GPRS Notifying

This application context is used between HLR and GGSN for notifying that GPRS subscriber is present again.

```
gprsNotifyContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is GGSN if Initiator is HLR
     INITIATOR CONSUMER OF {
          gprsNotifyingPackage-v3}
     ID   {map-ac gprsNotify(35) version3(3)} }
```

This application-context is v3 only.

17.3.2.36 Supplementary Service invocation notification

This application context is used between the MSC and the gsmSCF and between the HLR and the gsmSCF for Supplementary Service invocation notification procedures.

```
ss-InvocationNotificationContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is gsmSCF, Initiator is MSC
     -- Responder is gsmSCF, Initiator is HLR
     INITIATOR CONSUMER OF {
          ss-InvocationNotificationPackage-v3}
     ID   {map-ac ss-InvocationNotification(36) version3(3)} }
```

This application-context is v3 only.

17.3.2.37 Reporting

This application context is used between HLR and VLR for reporting procedures.

```
reportingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VLR if Initiator is HLR
     -- Responder is HLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          setReportingStatePackage-v3 |
          statusReportPackage-v3 |
          remoteUserFreePackage-v3}
     RESPONDER CONSUMER OF {
          setReportingStatePackage-v3 |
          statusReportPackage-v3}
     ID   {map-ac reporting(7) version3(3)} }
```

This application-context is v3 only.

17.3.2.38 Call Completion

This application context is used between VLR and the HLR for subscriber control of call completion services.

```
callCompletionContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     INITIATOR CONSUMER OF {
          callCompletionPackage-v3}
     ID   {map-ac callCompletion(8) version3(3)} }
```

This application-context is v3 only.

17.3.2.39 Location Service Gateway

This application context is used for location service gateway procedures.

```
locationSvcGatewayContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is GMLC
     INITIATOR CONSUMER OF {
          locationSvcGatewayPackage-v3}
     ID   {map-ac locationSvcGateway(37) version3(3)} }
```

17.3.2.40 Location Service Enquiry

This application context is used for location service enquiry procedures.

```
locationSvcEnquiryContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is MSC or SGSN if Initiator is GMLC
     -- Responder is GMLC if Initiator is MSC
     -- Responder is GMLC if Initiator is SGSN
     INITIATOR CONSUMER OF {
          locationSvcEnquiryPackage-v3 |
          locationSvcReportingPackage-v3}
     ID   {map-ac locationSvcEnquiry(38) version3 (3)} }
```

17.3.2.41 Void

17.3.2.42 Void

17.3.2.43 Void

17.3.2.44 IST Alerting

This application context is used between MSC (Visited MSC or Gateway MSC) and HLR for alerting services within IST procedures.

```
istAlertingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VMSC
     -- Responder is HLR if Initiator is GMSC
     INITIATOR CONSUMER OF {
          ist-AlertingPackage-v3}
     ID   {map-ac alerting(4) version3(3)} }
```

This application-context is v3 only.

17.3.2.45 Service Termination

This application context is used between HLR and MSC (Visited MSC or Gateway MSC) for service termination services within IST procedures.

```
serviceTerminationContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VMSC or GMSC if Initiator is HLR
     INITIATOR CONSUMER OF {
          serviceTerminationPackage-v3}
     ID   {map-ac serviceTermination(9) version3(3)} }
```

This application-context is v3 only.

17.3.2.46 Mobility Management event notification

This application context is used between VLR and gsmSCF for Mobility Management event notification procedures.

```
mm-EventReportingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is gsmSCF, Initiator is VLR
     INITIATOR CONSUMER OF {
          mm-EventReportingPackage-v3}
     ID   {map-ac mm-EventReporting(42) version3(3)} }
```

This application-context is v3 only.

17.3.2.47 Any time information handling

This application context is used between gsmSCF and HLR for any time information handling procedures.

```
anyTimeInfohandlingContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is gsmSCF
     INITIATOR CONSUMER OF {
          anyTimeInformationHandlingPackage-v3}
     ID   {map-ac anyTimeInfoHandling(43) version3(3)} }
```

This application-context is v3 only.

17.3.2.48 Subscriber Data modification notification

This application context is used between HLR and gsmSCF for Subscriber Data modification notification procedures.

```
subscriberDataModificationNotificationContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is gsmSCF, Initiator is HLR
     INITIATOR CONSUMER OF {
          subscriberDataModificationNotificationPackage-v3}
     ID   {map-ac subscriberDataModificationNotification(22) version3(3)} }
```

This application-context is v3 only.

17.3.2.49 Authentication Failure Report

This application context is used between VLR and HLR or SGSN and HLR for reporting of authentication failures.

```
authenticationFailureReportContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is HLR if Initiator is VLR
     -- Responder is HLR if Initiator is SGSN
     INITIATOR CONSUMER OF {
          authenticationFailureReportPackage-v3 }
     ID   {map-ac authenticationFailureReport(39) version3(3)} }
```

This application-context is v3 only.

17.3.2.50 Resource Management

This application context is used between GMSC and VMSC for resource management purpose.

```
resourceManagementContext-v3 APPLICATION-CONTEXT ::= {
     -- Responder is VMSC if Initiator is GMSC
     INITIATOR CONSUMER OF {
          resourceManagementPackage-v3 }
     ID   {map-ac resourceManagement(44) version3(3)} }
```

This application-context is v3 only.

17.3.2.51 Mobile terminating Short Message Relay VGCS

This application context is used between SMS-GMSC and MSC for mobile terminating short message relay procedures for VGCS.

```
shortMsgMT-Relay-VGCS-Context-v3 APPLICATION-CONTEXT ::= {
     -- Responder is MSC if Initiator is SMS-GMSC
     INITIATOR CONSUMER OF {
          mt-ShortMsgRelay-VGCS-Package-v3}
     ID   {map-ac shortMsgMT-Relay-VGCS(41) version3(3)} }
```

This application-context is v3 only.

17.3.3 ASN.1 Module for application-context-names

The following ASN.1 module summarises the application-context-name assigned to MAP application-contexts.

```
MAP-ApplicationContexts {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ApplicationContexts (2) version11 (11)}

DEFINITIONS

::=

BEGIN


-- EXPORTS everything


IMPORTS
   gsm-NetworkId,
   ac-Id
FROM MobileDomainDefinitions {
   itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
   mobileDomainDefinitions (0) version1 (1)}
;

-- application-context-names

map-ac  OBJECT IDENTIFIER ::= {gsm-NetworkId ac-Id}

networkLocUpContext-v3  OBJECT IDENTIFIER ::=
     {map-ac networkLocUp(1) version3(3)}

locationCancellationContext-v3  OBJECT IDENTIFIER ::=
     {map-ac locationCancel(2) version3(3)}

roamingNumberEnquiryContext-v3  OBJECT IDENTIFIER ::=
     {map-ac roamingNbEnquiry(3) version3(3)}

authenticationFailureReportContext-v3  OBJECT IDENTIFIER ::=
     {map-ac authenticationFailureReport(39) version3(3)}

locationInfoRetrievalContext-v3  OBJECT IDENTIFIER ::=
     {map-ac locInfoRetrieval(5) version3(3)}

resetContext-v2  OBJECT IDENTIFIER ::=
     {map-ac reset(10) version2(2)}

handoverControlContext-v3  OBJECT IDENTIFIER ::=
     {map-ac handoverControl(11) version3(3)}

equipmentMngtContext-v3  OBJECT IDENTIFIER ::=
     {map-ac equipmentMngt(13) version3(3)}

infoRetrievalContext-v3  OBJECT IDENTIFIER ::=
     {map-ac infoRetrieval(14) version3(3)}

interVlrInfoRetrievalContext-v3  OBJECT IDENTIFIER ::=
     {map-ac interVlrInfoRetrieval(15) version3(3)}
```

```
subscriberDataMngtContext-v3  OBJECT IDENTIFIER ::=
     {map-ac subscriberDataMngt(16) version3(3)}

tracingContext-v3  OBJECT IDENTIFIER ::=
     {map-ac tracing(17) version3(3)}

networkFunctionalSsContext-v2  OBJECT IDENTIFIER ::=
     {map-ac networkFunctionalSs(18) version2(2)}

networkUnstructuredSsContext-v2  OBJECT IDENTIFIER ::=
     {map-ac networkUnstructuredSs(19) version2(2)}

shortMsgGatewayContext-v3  OBJECT IDENTIFIER ::=
     {map-ac shortMsgGateway(20) version3(3)}

shortMsgMO-RelayContext-v3  OBJECT IDENTIFIER ::=
     {map-ac shortMsgMO-Relay(21) version3(3)}

shortMsgAlertContext-v2  OBJECT IDENTIFIER ::=
     {map-ac shortMsgAlert(23) version2(2)}

mwdMngtContext-v3  OBJECT IDENTIFIER ::=
     {map-ac mwdMngt(24) version3(3)}

shortMsgMT-RelayContext-v3  OBJECT IDENTIFIER ::=
     {map-ac shortMsgMT-Relay(25) version3(3)}

shortMsgMT-Relay-VGCS-Context-v3  OBJECT IDENTIFIER ::=
     {map-ac shortMsgMT-Relay-VGCS(41) version3(3)}

imsiRetrievalContext-v2  OBJECT IDENTIFIER ::=
     {map-ac imsiRetrieval(26) version2(2)}

msPurgingContext-v3  OBJECT IDENTIFIER ::=
     {map-ac msPurging(27) version3(3)}

subscriberInfoEnquiryContext-v3  OBJECT IDENTIFIER ::=
     {map-ac subscriberInfoEnquiry(28) version3(3)}

anyTimeInfoEnquiryContext-v3  OBJECT IDENTIFIER ::=
     {map-ac anyTimeInfoEnquiry(29) version3(3)}

callControlTransferContext-v4  OBJECT IDENTIFIER ::=
     {map-ac callControlTransfer(6) version4(4)}

ss-InvocationNotificationContext-v3  OBJECT IDENTIFIER ::=
     {map-ac ss-InvocationNotification(36) version3(3)}

groupCallControlContext-v3  OBJECT IDENTIFIER ::=
     {map-ac groupCallControl(31) version3(3)}

groupCallInfoRetrievalContext-v3  OBJECT IDENTIFIER ::=
     {map-ac groupCallInfoRetrieval(45) version3(3)}

gprsLocationUpdateContext-v3  OBJECT IDENTIFIER ::=
     {map-ac gprsLocationUpdate(32) version3(3)}

gprsLocationInfoRetrievalContext-v4  OBJECT IDENTIFIER ::=
     {map-ac gprsLocationInfoRetrieval(33) version4(4)}

failureReportContext-v3  OBJECT IDENTIFIER ::=
     {map-ac failureReport(34) version3(3)}

gprsNotifyContext-v3  OBJECT IDENTIFIER ::=
     {map-ac gprsNotify(35) version3(3)}

reportingContext-v3  OBJECT IDENTIFIER ::=
     {map-ac reporting(7) version3(3)}

callCompletionContext-v3  OBJECT IDENTIFIER ::=
     {map-ac callCompletion(8) version3(3)}

istAlertingContext-v3  OBJECT IDENTIFIER ::=
     {map-ac istAlerting(4) version3(3)}
```

```
serviceTerminationContext-v3  OBJECT IDENTIFIER ::=
     {map-ac immediateTermination(9) version3(3)}

locationSvcGatewayContext-v3  OBJECT IDENTIFIER ::=
     {map-ac locationSvcGateway(37) version3(3)}

locationSvcEnquiryContext-v3  OBJECT IDENTIFIER ::=
     {map-ac locationSvcEnquiry(38) version3(3)}

mm-EventReportingContext-v3  OBJECT IDENTIFIER ::=
     {map-ac mm-EventReporting(42) version3(3)}

anyTimeInfoHandlingContext-v3  OBJECT IDENTIFIER ::=
     {map-ac anyTimeInfoHandling(43) version3(3)}

subscriberDataModificationNotificationContext-v3  OBJECT IDENTIFIER ::=
     {map-ac subscriberDataModificationNotification(22) version3(3)}

resourceManagementContext-v3  OBJECT IDENTIFIER ::=
     {map-ac resourceManagement(44) version3(3)}

-- The following Object Identifiers are reserved for application-contexts
--  existing in previous versions of the protocol
```

-- AC Name & Version	Object Identifier	
--		
-- networkLocUpContext-v1	map-ac networkLocUp (1)	version1 (1)
-- networkLocUpContext-v2	map-ac networkLocUp (1)	version2 (2)
-- locationCancellationContext-v1	map-ac locationCancellation (2)	version1 (1)
-- locationCancellationContext-v2	map-ac locationCancellation (2)	version2 (2)
-- roamingNumberEnquiryContext-v1	map-ac roamingNumberEnquiry (3)	version1 (1)
-- roamingNumberEnquiryContext-v2	map-ac roamingNumberEnquiry (3)	version2 (2)
-- locationInfoRetrievalContext-v1	map-ac locationInfoRetrieval (5)	version1 (1)
-- locationInfoRetrievalContext-v2	map-ac locationInfoRetrieval (5)	version2 (2)
-- resetContext-v1	map-ac reset (10)	version1 (1)
-- handoverControlContext-v1	map-ac handoverControl (11)	version1 (1)
-- handoverControlContext-v2	map-ac handoverControl (11)	version2 (2)
-- sIWFSAllocationContext-v3	map-ac sIWFSAllocation (12)	version3 (3)
-- equipmentMngtContext-v1	map-ac equipmentMngt (13)	version1 (1)
-- equipmentMngtContext-v2	map-ac equipmentMngt (13)	version2 (2)
-- infoRetrievalContext-v1	map-ac infoRetrieval (14)	version1 (1)
-- infoRetrievalContext-v2	map-ac infoRetrieval (14)	version2 (2)
-- interVlrInfoRetrievalContext-v2	map-ac interVlrInfoRetrieval (15)	version2 (2)
-- subscriberDataMngtContext-v1	map-ac subscriberDataMngt (16)	version1 (1)
-- subscriberDataMngtContext-v2	map-ac subscriberDataMngt (16)	version2 (2)
-- tracingContext-v1	map-ac tracing (17)	version1 (1)
-- tracingContext-v2	map-ac tracing (17)	version2 (2)
-- networkFunctionalSsContext-v1	*map-ac networkFunctionalSs (18)*	*version1 (1)*
-- shortMsgGatewayContext-v1	map-ac shortMsgGateway (20)	version1 (1)
-- shortMsgGatewayContext-v2	map-ac shortMsgGateway (20)	version2 (2)
-- shortMsgRelayContext-v1	map-ac shortMsgRelay (21)	version1 (1)
-- shortMsgAlertContext-v1	map-ac shortMsgAlert (23)	version1 (1)
-- mwdMngtContext-v1	*map-ac mwdMngt (24)*	*version1 (1)*
-- mwdMngtContext-v2	map-ac mwdMngt (24)	version2 (2)
-- shortMsgMT-RelayContext-v2	map-ac shortMsgMT-Relay (25)	version2 (2)
-- msPurgingContext-v2	map-ac msPurging (27)	version2 (2)
-- callControlTransferContext-v3	map-ac callControlTransferContext (6)	version3 (3)
-- gprsLocationInfoRetrievalContext-v3	map-ac gprsLocationInfoRetrievalContext (33)	version3 (3)

```
END
```

17.4 MAP Dialogue Information

```
MAP-DialogueInformation {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-DialogueInformation (3) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN
```

```
EXPORTS
   map-DialogueAS,
   MAP-DialoguePDU

;

IMPORTS
   gsm-NetworkId,
   as-Id
FROM MobileDomainDefinitions {
   itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
   mobileDomainDefinitions (0) version1 (1)}

   AddressString
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network(1) modules (3) map-CommonDataTypes (18) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}


;


-- abstract syntax name for MAP-DialoguePDU
```

```
map-DialogueAS  OBJECT IDENTIFIER ::=
    {gsm-NetworkId as-Id map-DialoguePDU (1) version1 (1)}
```

```
MAP-DialoguePDU ::= CHOICE {
    map-open                        [0] MAP-OpenInfo,
    map-accept                      [1] MAP-AcceptInfo,
    map-close                       [2] MAP-CloseInfo,
    map-refuse                      [3] MAP-RefuseInfo,
    map-userAbort                   [4] MAP-UserAbortInfo,
    map-providerAbort               [5] MAP-ProviderAbortInfo}
```

```
MAP-OpenInfo ::= SEQUENCE {
    destinationReference            [0] AddressString           OPTIONAL,
    originationReference            [1] AddressString           OPTIONAL,
    ...,
    extensionContainer              ExtensionContainer          OPTIONAL
    -- extensionContainer must not be used in version 2
    }
```

```
MAP-AcceptInfo ::= SEQUENCE {
    ...,
    extensionContainer              ExtensionContainer          OPTIONAL
    -- extensionContainer must not be used in version 2
    }
```

```
MAP-CloseInfo ::= SEQUENCE {
    ...,
    extensionContainer              ExtensionContainer          OPTIONAL
    -- extensionContainer must not be used in version 2
    }
```

```
MAP-RefuseInfo ::= SEQUENCE {
    reason    Reason,
    ...,
    extensionContainer              ExtensionContainer          OPTIONAL,
    -- extensionContainer must not be used in version 2
    alternativeApplicationContext   OBJECT IDENTIFIER           OPTIONAL
    -- alternativeApplicationContext must not be used in version 2
    }
```

```
Reason ::= ENUMERATED {
    noReasonGiven                   (0),
    invalidDestinationReference     (1),
    invalidOriginatingReference     (2)}
```

```
MAP-UserAbortInfo ::= SEQUENCE {
     map-UserAbortChoice                MAP-UserAbortChoice,
     ...,
     extensionContainer                 ExtensionContainer              OPTIONAL
     -- extensionContainer must not be used in version 2
     }
```

```
MAP-UserAbortChoice ::= CHOICE {
     userSpecificReason                 [0] NULL,
     userResourceLimitation             [1] NULL,
     resourceUnavailable                [2] ResourceUnavailableReason,
     applicationProcedureCancellation   [3] ProcedureCancellationReason}
```

```
ResourceUnavailableReason ::= ENUMERATED {
     shortTermResourceLimitation  (0),
     longTermResourceLimitation  (1)}
```

```
ProcedureCancellationReason ::= ENUMERATED {
     handoverCancellation  (0),
     radioChannelRelease  (1),
     networkPathRelease  (2),
     callRelease  (3),
     associatedProcedureFailure  (4),
     tandemDialogueRelease  (5),
     remoteOperationsFailure  (6)}
```

```
MAP-ProviderAbortInfo ::= SEQUENCE {
     map-ProviderAbortReason            MAP-ProviderAbortReason,
     ...,
     extensionContainer                 ExtensionContainer              OPTIONAL
     -- extensionContainer must not be used in version 2
     }
```

```
MAP-ProviderAbortReason ::= ENUMERATED {
     abnormalDialogue  (0),
     invalidPDU  (1)}
```

```
END
```

17.5 MAP operation and error codes

```
MAP-Protocol {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Protocol (4) version11 (11)}

DEFINITIONS

::=

BEGIN

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}

   updateLocation,
   cancelLocation,
   purgeMS,
   sendIdentification,
   updateGprsLocation,
   prepareHandover,
   sendEndSignal,
   processAccessSignalling,
   forwardAccessSignalling,
   prepareSubsequentHandover,
   sendAuthenticationInfo,
   authenticationFailureReport,
   checkIMEI,
   insertSubscriberData,
   deleteSubscriberData,
   reset,
   forwardCheckSS-Indication,
   restoreData,
   provideSubscriberInfo,
   anyTimeInterrogation,
   anyTimeSubscriptionInterrogation,
```

```
   anyTimeModification,
   sendRoutingInfoForGprs,
   failureReport,
   noteMsPresentForGprs,
   noteMM-Event,
   noteSubscriberDataModified


FROM MAP-MobileServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MobileServiceOperations (5)
   version11 (11)}

   activateTraceMode,
   deactivateTraceMode,
   sendIMSI
FROM MAP-OperationAndMaintenanceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OperationAndMaintenanceOperations (6)
   version11 (11)}

   sendRoutingInfo,
   provideRoamingNumber,
   resumeCallHandling,
   setReportingState,
   statusReport,
   remoteUserFree,
   ist-Alert,
   ist-Command,
   releaseResources
FROM MAP-CallHandlingOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CallHandlingOperations (7)
   version11 (11)}

   registerSS,
   eraseSS,
   activateSS,
   deactivateSS,
   interrogateSS,
   processUnstructuredSS-Request,
   unstructuredSS-Request,
   unstructuredSS-Notify,
   registerPassword,
   getPassword,
   ss-InvocationNotification,
   registerCC-Entry,
   eraseCC-Entry
FROM MAP-SupplementaryServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SupplementaryServiceOperations (8)
   version11 (11)}

   sendRoutingInfoForSM,
   mo-ForwardSM,
   mt-ForwardSM,
   reportSM-DeliveryStatus,
   alertServiceCentre,
   informServiceCentre,
   readyForSM,
   mt-ForwardSM-VGCS
FROM MAP-ShortMessageServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ShortMessageServiceOperations (9)
   version11 (11)}

   prepareGroupCall,
   processGroupCallSignalling,
   forwardGroupCallSignalling,
   sendGroupCallEndSignal,
   sendGroupCallInfo
FROM MAP-Group-Call-Operations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Group-Call-Operations (22)
   version11 (11)}
```

```
   provideSubscriberLocation,
   sendRoutingInfoForLCS,
   subscriberLocationReport
FROM MAP-LocationServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-LocationServiceOperations (24)
   version11 (11)}


;
Supported-MAP-Operations OPERATION ::= {updateLocation | cancelLocation | purgeMS |
   sendIdentification | updateGprsLocation | prepareHandover | sendEndSignal |
   processAccessSignalling | forwardAccessSignalling | prepareSubsequentHandover |
   sendAuthenticationInfo | authenticationFailureReport | checkIMEI | insertSubscriberData |
   deleteSubscriberData | reset | forwardCheckSS-Indication | restoreData | provideSubscriberInfo |
   anyTimeInterrogation | anyTimeSubscriptionInterrogation | anyTimeModification |
   sendRoutingInfoForGprs | failureReport |noteMsPresentForGprs | noteMM-Event |
   noteSubscriberDataModified | activateTraceMode | deactivateTraceMode | sendIMSI |
   sendRoutingInfo | provideRoamingNumber | resumeCallHandling | setReportingState | statusReport |
remoteUserFree | ist-Alert |
   ist-Command | registerSS | eraseSS | activateSS | deactivateSS | interrogateSS |
   processUnstructuredSS-Request | unstructuredSS-Request | unstructuredSS-Notify |
   registerPassword | getPassword | ss-InvocationNotification | registerCC-Entry | eraseCC-Entry |
   sendRoutingInfoForSM | mo-ForwardSM | mt-ForwardSM | reportSM-DeliveryStatus |
   alertServiceCentre | informServiceCentre | readyForSM | prepareGroupCall |
   processGroupCallSignalling | forwardGroupCallSignalling | sendGroupCallEndSignal |
   provideSubscriberLocation | sendRoutingInfoForLCS | subscriberLocationReport |
   releaseResources | mt-ForwardSM-VGCS | sendGroupCallInfo }



-- The following operation codes are reserved for operations
-- existing in previous versions of the protocol
```

-- Operation Name	AC used	Oper. Code
--		
-- sendParameters	map-ac infoRetrieval (14) version1 (1)	local:9
-- processUnstructuredSS-Data	map-ac networkFunctionalSs (18) version1 (1)	local:19
-- performHandover	map-ac handoverControl (11) version1 (1)	local:28
-- performSubsequentHandover	map-ac handoverControl (11) version1 (1)	local:30
-- provideSIWFSNumber	map-ac sIWFSAllocation (12) version3 (3)	local:31
-- siwfs-SignallingModify	map-ac sIWFSAllocation (12) version3 (3)	local:32
-- noteInternalHandover	map-ac handoverControl (11) version1 (1)	local:35
-- noteSubscriberPresent	map-ac mwdMngt (24) version1 (1)	local:48
-- alertServiceCentreWithoutResult	map-ac shortMsgAlert (23) version1 (1)	local:49
-- traceSubscriberActivity	map-ac handoverControl (11) version1 (1)	local:52
-- beginSubscriberActivity	map-ac networkFunctionalSs (18) version1 (1)	local:54

```
-- The following error codes are reserved for errors
-- existing in previous versions of the protocol
```

-- Error Name	AC used	Error Code
--		
-- unknownBaseStation	map-ac handoverControl (11) version1 (1)	local:2
-- invalidTargetBaseStation	map-ac handoverControl (11) version1 (1)	local:23
-- noRadioResourceAvailable	map-ac handoverControl (11) version1 (1)	local:24

```
END
```

17.6 MAP operations and errors

17.6.1 Mobile Service Operations

```
MAP-MobileServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MobileServiceOperations (5)
   version11 (11)}

DEFINITIONS

::=

BEGIN
```

```
EXPORTS

   -- location registration operations
   updateLocation,
   cancelLocation,
   purgeMS,
   sendIdentification,

   -- gprs location registration operations
   updateGprsLocation,

   -- subscriber information enquiry operations
   provideSubscriberInfo,

   -- any time information enquiry operations
   anyTimeInterrogation,

   -- any time information handling operations
   anyTimeSubscriptionInterrogation,
   anyTimeModification,

   -- subscriber data modification notification operations
   noteSubscriberDataModified,


   -- handover operations
   prepareHandover,
   sendEndSignal,
   processAccessSignalling,
   forwardAccessSignalling,
   prepareSubsequentHandover,

   -- authentication management operations
   sendAuthenticationInfo,
   authenticationFailureReport,

   -- IMEI management operations
   checkIMEI,

   -- subscriber management operations
   insertSubscriberData,
   deleteSubscriberData,

   -- fault recovery operations
   reset,
   forwardCheckSS-Indication,
   restoreData,

-- gprs location information retrieval operations
   sendRoutingInfoForGprs,

   -- failure reporting operations
   failureReport,

   -- gprs notification operations
   noteMsPresentForGprs,

   -- Mobility Management operations
   noteMM-Event

;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   dataMissing,
   unexpectedDataValue,
   unknownSubscriber,
   unknownMSC,
   unidentifiedSubscriber,
   unknownEquipment,
   roamingNotAllowed,
   ati-NotAllowed,
   noHandoverNumberAvailable,
   subsequentHandoverFailure,
```

```
   absentSubscriber,
   mm-EventNotSupported,
   atsi-NotAllowed,
   atm-NotAllowed,
   bearerServiceNotProvisioned,
   teleserviceNotProvisioned,
   callBarred,
   illegalSS-Operation,
   ss-ErrorStatus,
   ss-NotAvailable,
   ss-Incompatibility,
   ss-SubscriptionViolation,
   informationNotAvailable,
   targetCellOutsideGroupCallArea


FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}

   UpdateLocationArg,
   UpdateLocationRes,
   CancelLocationArg,
   CancelLocationRes,
   PurgeMS-Arg,
   PurgeMS-Res,
   SendIdentificationArg,
   SendIdentificationRes,
   UpdateGprsLocationArg,
   UpdateGprsLocationRes,
   PrepareHO-Arg,
   PrepareHO-Res,
   ForwardAccessSignalling-Arg,
   ProcessAccessSignalling-Arg,
   SendEndSignal-Arg,
   SendEndSignal-Res,
   PrepareSubsequentHO-Res,
   PrepareSubsequentHO-Arg,
   SendAuthenticationInfoArg,
   SendAuthenticationInfoRes,
   AuthenticationFailureReportArg,
   AuthenticationFailureReportRes,
   CheckIMEI-Arg,
   CheckIMEI-Res,
   InsertSubscriberDataArg,
   InsertSubscriberDataRes,
   DeleteSubscriberDataArg,
   DeleteSubscriberDataRes,
   ResetArg,
   RestoreDataArg,
   RestoreDataRes,
   ProvideSubscriberInfoArg,
   ProvideSubscriberInfoRes,
   AnyTimeSubscriptionInterrogationArg,
   AnyTimeSubscriptionInterrogationRes,
   AnyTimeModificationArg,
   AnyTimeModificationRes,
   NoteSubscriberDataModifiedArg,
   NoteSubscriberDataModifiedRes,
   AnyTimeInterrogationArg,
   AnyTimeInterrogationRes,
   SendRoutingInfoForGprsArg,
   SendRoutingInfoForGprsRes,
   FailureReportArg,
   FailureReportRes,
   NoteMsPresentForGprsArg,
   NoteMsPresentForGprsRes,
   NoteMM-EventArg,
   NoteMM-EventRes


FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version11 (11)}

;
```

```
-- location registration operations

updateLocation  OPERATION ::= {                                          --Timer m
     ARGUMENT
          UpdateLocationArg
     RESULT
          UpdateLocationRes
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber |
          roamingNotAllowed}
     CODE local:2 }

cancelLocation  OPERATION ::= {                                          --Timer m
     ARGUMENT
          CancelLocationArg
     RESULT
          CancelLocationRes
               -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue}
     CODE local:3 }

purgeMS  OPERATION ::= {                                                 --Timer m
     ARGUMENT
          PurgeMS-Arg
     RESULT
          PurgeMS-Res
               -- optional
     ERRORS{
          dataMissing |
          unexpectedDataValue|
          unknownSubscriber}
     CODE local:67 }

sendIdentification  OPERATION ::= {                                      --Timer s
     ARGUMENT
          SendIdentificationArg
     RESULT
          SendIdentificationRes
     ERRORS {
          dataMissing |
          unidentifiedSubscriber}
     CODE local:55 }

-- gprs location registration operations

updateGprsLocation  OPERATION ::= {                                      --Timer m
     ARGUMENT
          UpdateGprsLocationArg
     RESULT
          UpdateGprsLocationRes
     ERRORS {
          systemFailure |
          unexpectedDataValue |
          unknownSubscriber |
          roamingNotAllowed}
     CODE local:23 }

-- subscriber information enquiry operations

provideSubscriberInfo  OPERATION ::= {                                   --Timer m
     ARGUMENT
          ProvideSubscriberInfoArg
     RESULT
          ProvideSubscriberInfoRes
     ERRORS {
          dataMissing |
          unexpectedDataValue}
     CODE local:70 }

-- any time information enquiry operations
```

```
anyTimeInterrogation  OPERATION ::= {                                    --Timer m
     ARGUMENT
          AnyTimeInterrogationArg
     RESULT
          AnyTimeInterrogationRes
     ERRORS {
          systemFailure |
          ati-NotAllowed |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:71 }
```

-- any time information handling operations

```
anyTimeSubscriptionInterrogation  OPERATION ::= {                        --Timer m
     ARGUMENT
          AnyTimeSubscriptionInterrogationArg
     RESULT
          AnyTimeSubscriptionInterrogationRes
     ERRORS {
          atsi-NotAllowed |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-NotAvailable |
          informationNotAvailable}
     CODE local:62 }
```

```
anyTimeModification  OPERATION ::= {                                     --Timer m
     ARGUMENT
          AnyTimeModificationArg
     RESULT
          AnyTimeModificationRes
     ERRORS {
          atm-NotAllowed |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-SubscriptionViolation |
          ss-ErrorStatus |
          ss-Incompatibility |
          informationNotAvailable}
     CODE local:65 }
```

-- subscriber data modification notification operations

```
noteSubscriberDataModified  OPERATION ::= {                              --Timer m
     ARGUMENT
          NoteSubscriberDataModifiedArg
     RESULT
          NoteSubscriberDataModifiedRes
               -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:5 }
```

-- handover operations

```
prepareHandover  OPERATION ::= {                                    --Timer m
     ARGUMENT
          PrepareHO-Arg
     RESULT
          PrepareHO-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          noHandoverNumberAvailable |
          targetCellOutsideGroupCallArea }
     CODE local:68 }
```

```
sendEndSignal  OPERATION ::= {                                      --Timer l
     ARGUMENT
          SendEndSignal-Arg
     RESULT
          SendEndSignal-Res
     CODE local:29 }
```

```
processAccessSignalling  OPERATION ::= {                            --Timer s
     ARGUMENT
          ProcessAccessSignalling-Arg
     CODE local:33 }
```

```
forwardAccessSignalling  OPERATION ::= {                            --Timer s
     ARGUMENT
          ForwardAccessSignalling-Arg
     CODE local:34 }
```

```
prepareSubsequentHandover  OPERATION ::= {                           --Timer m
     ARGUMENT
          PrepareSubsequentHO-Arg
     RESULT
          PrepareSubsequentHO-Res
     ERRORS {
          unexpectedDataValue |
          dataMissing |
          unknownMSC |
          subsequentHandoverFailure}
     CODE local:69 }
```

```
-- authentication management operations
```

```
sendAuthenticationInfo  OPERATION ::= {                             --Timer m
     ARGUMENT
          SendAuthenticationInfoArg
          -- optional
          -- within a dialogue sendAuthenticationInfoArg shall not be present in
          -- subsequent invoke components. If received in a subsequent invoke component
          -- it shall be discarded.

     RESULT
          SendAuthenticationInfoRes
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:56 }
```

```
authenticationFailureReport  OPERATION ::= {                        --Timer m
     ARGUMENT
          AuthenticationFailureReportArg
     RESULT
          AuthenticationFailureReportRes
          -- optional
     ERRORS {
          systemFailure |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:15 }
```

```
-- IMEI management operations
```

```
checkIMEI  OPERATION ::= {                                          --Timer m
     ARGUMENT
          CheckIMEI-Arg
     RESULT
          CheckIMEI-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unknownEquipment}
     CODE local:43 }
```

-- subscriber management operations

```
insertSubscriberData  OPERATION ::= {                               --Timer m
     ARGUMENT
          InsertSubscriberDataArg
     RESULT
          InsertSubscriberDataRes
          -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unidentifiedSubscriber}
     CODE local:7 }
```

```
deleteSubscriberData  OPERATION ::= {                               --Timer m
     ARGUMENT
          DeleteSubscriberDataArg
     RESULT
          DeleteSubscriberDataRes
          -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unidentifiedSubscriber}
     CODE local:8 }
```

-- fault recovery operations

```
reset  OPERATION ::= {                                              --Timer m
     ARGUMENT
          ResetArg
     CODE local:37 }
```

```
forwardCheckSS-Indication  OPERATION ::= {                          --Timer s
     CODE local:38 }
```

```
restoreData  OPERATION ::= {                                        --Timer m
     ARGUMENT
          RestoreDataArg
     RESULT
          RestoreDataRes
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:57 }
```

-- gprs location information retrieval operations

```
sendRoutingInfoForGprs  OPERATION ::= {                             --Timer m
     ARGUMENT
          SendRoutingInfoForGprsArg
     RESULT
          SendRoutingInfoForGprsRes
     ERRORS {
          absentSubscriber |
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber |
          callBarred }
     CODE local:24 }
```

-- failure reporting operations

```
failureReport  OPERATION ::= {                                          --Timer m
     ARGUMENT
          FailureReportArg
     RESULT
          FailureReportRes
               -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:25 }
```

-- gprs notification operations

```
noteMsPresentForGprs  OPERATION ::= {                                   --Timer m
     ARGUMENT
          NoteMsPresentForGprsArg
     RESULT
          NoteMsPresentForGprsRes
               -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:26 }
```

```
noteMM-Event  OPERATION ::= {                                           --Timer m
     ARGUMENT
          NoteMM-EventArg
     RESULT
          NoteMM-EventRes
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber |
          mm-EventNotSupported}
     CODE local:89 }
```

```
END
```

17.6.2 Operation and Maintenance Operations

```
MAP-OperationAndMaintenanceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OperationAndMaintenanceOperations (6)
   version11 (11)}

DEFINITIONS

::=

BEGIN

EXPORTS
   activateTraceMode,
   deactivateTraceMode,
   sendIMSI
;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   dataMissing,
   unexpectedDataValue,
   facilityNotSupported,
   unknownSubscriber,
   unidentifiedSubscriber,
   tracingBufferFull
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}
```

```
   ActivateTraceModeArg,
   ActivateTraceModeRes,
   DeactivateTraceModeArg,
   DeactivateTraceModeRes
FROM MAP-OM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OM-DataTypes (12) version11 (11)}

   ISDN-AddressString,
   IMSI
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}
;
```

```
activateTraceMode  OPERATION ::= {                                    --Timer m
     ARGUMENT
          ActivateTraceModeArg
     RESULT
          ActivateTraceModeRes
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unidentifiedSubscriber |
          tracingBufferFull}
     CODE local:50 }
```

```
deactivateTraceMode  OPERATION ::= {                                  --Timer m
     ARGUMENT
          DeactivateTraceModeArg
     RESULT
          DeactivateTraceModeRes
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unidentifiedSubscriber}
     CODE local:51 }
```

```
sendIMSI  OPERATION ::= {                                             --Timer m
     ARGUMENT
          ISDN-AddressString
     RESULT
          IMSI
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:58 }
```

```
END
```

17.6.3 Call Handling Operations

```
MAP-CallHandlingOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CallHandlingOperations (7)
   version11 (11)}

DEFINITIONS

::=

BEGIN

EXPORTS
   sendRoutingInfo,
   provideRoamingNumber,
   resumeCallHandling,
   setReportingState,
   statusReport,
   remoteUserFree,
```

```
   ist-Alert,
   ist-Command,
   releaseResources
;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   dataMissing,
   unexpectedDataValue,
   facilityNotSupported,
   or-NotAllowed,
   unknownSubscriber,
   numberChanged,
   bearerServiceNotProvisioned,
   teleserviceNotProvisioned,
   noRoamingNumberAvailable,
   absentSubscriber,
   busySubscriber,
   noSubscriberReply,
   callBarred,
   forwardingViolation,
   forwardingFailed,
   cug-Reject,
   resourceLimitation,
   incompatibleTerminal,
   unidentifiedSubscriber

FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}
   SendRoutingInfoArg,
   SendRoutingInfoRes,
   ProvideRoamingNumberArg,
   ProvideRoamingNumberRes,
   ResumeCallHandlingArg,
   ResumeCallHandlingRes,
   SetReportingStateArg,
   SetReportingStateRes,
   StatusReportArg,
   StatusReportRes,
   RemoteUserFreeArg,
   RemoteUserFreeRes,
   IST-AlertArg,
   IST-AlertRes,
   IST-CommandArg,
   IST-CommandRes,
   ReleaseResourcesArg,
   ReleaseResourcesRes
FROM MAP-CH-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CH-DataTypes (13) version11 (11)}

;
```

```
sendRoutingInfo  OPERATION ::= {                                    --Timer m
-- The timer is set to the upper limit of the range if the GMSC supports pre-paging.
     ARGUMENT
          SendRoutingInfoArg
     RESULT
          SendRoutingInfoRes
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          or-NotAllowed |
          unknownSubscriber |
          numberChanged |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          absentSubscriber |
          busySubscriber |
          noSubscriberReply |
          callBarred |
          cug-Reject |
          forwardingViolation}
     CODE local:22 }
```

```
provideRoamingNumber  OPERATION ::= {                               --Timer m
-- The timer is set to the upper limit of the range if the HLR supports pre-paging.
     ARGUMENT
          ProvideRoamingNumberArg
     RESULT
          ProvideRoamingNumberRes
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          or-NotAllowed |
          absentSubscriber |
          noRoamingNumberAvailable}
     CODE local:4 }
```

```
resumeCallHandling  OPERATION ::= {                                 --Timer m
     ARGUMENT
          ResumeCallHandlingArg
     RESULT
          ResumeCallHandlingRes
          -- optional
     ERRORS {
          forwardingFailed |
          or-NotAllowed |
          unexpectedDataValue |
          dataMissing }
     CODE local:6 }
```

```
setReportingState  OPERATION ::= {                                  --Timer m
     ARGUMENT
          SetReportingStateArg
     RESULT
          SetReportingStateRes
          -- optional
     ERRORS {
          systemFailure |
          unidentifiedSubscriber |
          unexpectedDataValue |
          dataMissing |
          resourceLimitation |
          facilityNotSupported}
     CODE local:73 }
```

```
statusReport  OPERATION ::= {                                          --Timer m
     ARGUMENT
          StatusReportArg
     RESULT
          StatusReportRes
          -- optional
     ERRORS {
          unknownSubscriber |
          systemFailure |
          unexpectedDataValue |
          dataMissing}
     CODE local:74 }
```

```
remoteUserFree  OPERATION ::= {                                        --Timer ml
     ARGUMENT
          RemoteUserFreeArg
     RESULT
          RemoteUserFreeRes
     ERRORS {
          unexpectedDataValue |
          dataMissing |
          incompatibleTerminal |
          absentSubscriber |
          systemFailure |
          busySubscriber}
     CODE local:75 }
```

```
ist-Alert  OPERATION ::= {                                             --Timer m
     ARGUMENT
          IST-AlertArg
     RESULT
          IST-AlertRes
          -- optional
     ERRORS {
          unexpectedDataValue |
          resourceLimitation |
          unknownSubscriber |
          systemFailure |
          facilityNotSupported}
     CODE local:87 }
```

```
ist-Command  OPERATION::= {                                            --Timer m
     ARGUMENT
          IST-CommandArg
     RESULT
          IST-CommandRes
          -- optional
     ERRORS {
          unexpectedDataValue |
          resourceLimitation |
          unknownSubscriber |
          systemFailure |
          facilityNotSupported}
     CODE local:88 }
```

```
releaseResources  OPERATION::= {                                       --Timer m
     ARGUMENT
          ReleaseResourcesArg
     RESULT
          ReleaseResourcesRes
          -- optional
     ERRORS {
          unexpectedDataValue |
          systemFailure }
     CODE local:20 }
```

```
END
```

17.6.4 Supplementary service operations

```
MAP-SupplementaryServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SupplementaryServiceOperations (8)
   version11 (11)}

DEFINITIONS

::=
```

```
BEGIN

EXPORTS
   registerSS,
   eraseSS,
   activateSS,
   deactivateSS,
   interrogateSS,
   processUnstructuredSS-Request,
   unstructuredSS-Request,
   unstructuredSS-Notify,
   registerPassword,
   getPassword,
   ss-InvocationNotification,
   registerCC-Entry,
   eraseCC-Entry
;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   dataMissing,
   unexpectedDataValue,
   unknownSubscriber,
   bearerServiceNotProvisioned,
   teleserviceNotProvisioned,
   callBarred,
   illegalSS-Operation,
   ss-ErrorStatus,
   ss-NotAvailable,
   ss-SubscriptionViolation,
   ss-Incompatibility,
   pw-RegistrationFailure,
   negativePW-Check,
   numberOfPW-AttemptsViolation,
   unknownAlphabet,
   ussd-Busy,
   absentSubscriber,
   illegalSubscriber,
   illegalEquipment,
   shortTermDenial,
   longTermDenial,
   facilityNotSupported
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}

   RegisterSS-Arg,
   SS-Info,
   SS-ForBS-Code,
   InterrogateSS-Res,
   USSD-Arg,
   USSD-Res,
   Password,
   GuidanceInfo,
   SS-InvocationNotificationArg,
   SS-InvocationNotificationRes,
   RegisterCC-EntryArg,
   RegisterCC-EntryRes,
   EraseCC-EntryArg,
   EraseCC-EntryRes
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version11 (11)}

   SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version11 (11)}
;


-- supplementary service handling operations
```

```
registerSS  OPERATION ::= {                                          --Timer m
     ARGUMENT
          RegisterSS-Arg
     RESULT
          SS-Info
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-ErrorStatus |
          ss-Incompatibility}
     CODE local:10 }
```

```
eraseSS  OPERATION ::= {                                             --Timer m
     ARGUMENT
          SS-ForBS-Code
     RESULT
          SS-Info
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-ErrorStatus
          }
     CODE local:11 }
```

```
activateSS  OPERATION ::= {                                          --Timer m
     ARGUMENT
          SS-ForBS-Code
     RESULT
          SS-Info
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-ErrorStatus |
          ss-SubscriptionViolation |
          ss-Incompatibility |
          negativePW-Check |
          numberOfPW-AttemptsViolation}
     CODE local:12 }
```

```
deactivateSS  OPERATION ::= {                                        --Timer m
     ARGUMENT
          SS-ForBS-Code
     RESULT
          SS-Info
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-ErrorStatus |
          ss-SubscriptionViolation |
          negativePW-Check |
          numberOfPW-AttemptsViolation}
     CODE local:13 }
```

```
interrogateSS  OPERATION ::= {                                          --Timer m
     ARGUMENT
          SS-ForBS-Code
     RESULT
          InterrogateSS-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          bearerServiceNotProvisioned |
          teleserviceNotProvisioned |
          callBarred |
          illegalSS-Operation |
          ss-NotAvailable}
     CODE local:14 }
```

```
processUnstructuredSS-Request  OPERATION ::= {                           --Timer 10
minutes
     ARGUMENT
          USSD-Arg
     RESULT
          USSD-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          unknownAlphabet |
          callBarred}
     CODE local:59 }
```

```
unstructuredSS-Request  OPERATION ::= {                                  --Timer ml
     ARGUMENT
          USSD-Arg
     RESULT
          USSD-Res
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          absentSubscriber |
          illegalSubscriber |
          illegalEquipment |
          unknownAlphabet |
          ussd-Busy}
     CODE local:60 }
```

```
unstructuredSS-Notify  OPERATION ::= {                                   --Timer ml
     ARGUMENT
          USSD-Arg
     RETURN RESULT TRUE
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          absentSubscriber |
          illegalSubscriber |
          illegalEquipment |
          unknownAlphabet |
          ussd-Busy}
     CODE local:61 }
```

```
registerPassword  OPERATION ::= {                                    --Timer ml
     ARGUMENT
          SS-Code
     RESULT
          Password
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          callBarred |
          ss-SubscriptionViolation |
          pw-RegistrationFailure |
          negativePW-Check |
          numberOfPW-AttemptsViolation}
     LINKED {
          getPassword}
     CODE local:17 }
```

```
getPassword  OPERATION ::= {                                         --Timer m
     ARGUMENT
          GuidanceInfo
     RESULT
          Password
     CODE local:18 }
```

```
ss-InvocationNotification  OPERATION ::= {                            --Timer m
     ARGUMENT
          SS-InvocationNotificationArg
     RESULT
          SS-InvocationNotificationRes
          -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber}
     CODE local:72 }
```

```
registerCC-Entry  OPERATION ::= {                                    --Timer m
     ARGUMENT
          RegisterCC-EntryArg
     RESULT
          RegisterCC-EntryRes
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          callBarred |
          illegalSS-Operation |
          ss-ErrorStatus |
          ss-Incompatibility |
          shortTermDenial |
          longTermDenial |
          facilityNotSupported}
     CODE local:76 }
```

```
eraseCC-Entry  OPERATION ::= {                                       --Timer m
     ARGUMENT
          EraseCC-EntryArg
     RESULT
          EraseCC-EntryRes
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          callBarred |
          illegalSS-Operation |
          ss-ErrorStatus}
     CODE local:77 }
```

```
END
```

17.6.5 Short message service operations

```
MAP-ShortMessageServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ShortMessageServiceOperations (9)
   version11 (11)}
```

```
DEFINITIONS

::=

BEGIN

EXPORTS
   sendRoutingInfoForSM,
   mo-ForwardSM,
   mt-ForwardSM,
   reportSM-DeliveryStatus,
   alertServiceCentre,
   informServiceCentre,
   readyForSM,
   mt-ForwardSM-VGCS
;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   dataMissing,
   unexpectedDataValue,
   facilityNotSupported,
   unknownSubscriber,
   unidentifiedSubscriber,
   illegalSubscriber,
   illegalEquipment,
   teleserviceNotProvisioned,
   callBarred,
   subscriberBusyForMT-SMS,
   sm-DeliveryFailure,
   messageWaitingListFull,
   absentSubscriberSM
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}

   RoutingInfoForSM-Arg,
   RoutingInfoForSM-Res,
   MO-ForwardSM-Arg,
   MO-ForwardSM-Res,
   MT-ForwardSM-Arg,
   MT-ForwardSM-Res,
   ReportSM-DeliveryStatusArg,
   ReportSM-DeliveryStatusRes,
   AlertServiceCentreArg,
   InformServiceCentreArg,
   ReadyForSM-Arg,
   ReadyForSM-Res,
   MT-ForwardSM-VGCS-Arg,
   MT-ForwardSM-VGCS-Res
FROM MAP-SM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SM-DataTypes (16) version11 (11)}

;
```

```
sendRoutingInfoForSM  OPERATION ::= {                                    --Timer m
     ARGUMENT
          RoutingInfoForSM-Arg
     RESULT
          RoutingInfoForSM-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unknownSubscriber |
          teleserviceNotProvisioned |
          callBarred |
          absentSubscriberSM}
     CODE local:45 }
```

```
mo-ForwardSM  OPERATION ::= {                                          --Timer ml
     ARGUMENT
          MO-ForwardSM-Arg
     RESULT
          MO-ForwardSM-Res
          -- optional
     ERRORS {
          systemFailure |
          unexpectedDataValue |
          facilityNotSupported |
          sm-DeliveryFailure}
     CODE local:46 }
```

```
mt-ForwardSM  OPERATION ::= {                                          --Timer ml
     ARGUMENT
          MT-ForwardSM-Arg
     RESULT
          MT-ForwardSM-Res
          -- optional
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unidentifiedSubscriber |
          illegalSubscriber |
          illegalEquipment |
          subscriberBusyForMT-SMS |
          sm-DeliveryFailure |
          absentSubscriberSM}
     CODE local:44 }
```

```
reportSM-DeliveryStatus  OPERATION ::= {          --Timer s
     ARGUMENT
          ReportSM-DeliveryStatusArg
     RESULT
          ReportSM-DeliveryStatusRes
          -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          unknownSubscriber |
          messageWaitingListFull}
     CODE local:47 }
```

```
alertServiceCentre  OPERATION ::= {                                    --Timer s
     ARGUMENT
          AlertServiceCentreArg
     RETURN RESULT TRUE
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue}
     CODE local:64 }
```

```
informServiceCentre  OPERATION ::= {                                   --Timer s
     ARGUMENT
          InformServiceCentreArg
     CODE local:63 }
```

```
readyForSM  OPERATION ::= {                                            --Timer m
     ARGUMENT
          ReadyForSM-Arg
     RESULT
          ReadyForSM-Res
          -- optional
     ERRORS {
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unknownSubscriber}
     CODE local:66 }
```

```
mt-ForwardSM-VGCS  OPERATION ::= {                                    --Timer ml
     ARGUMENT
          MT-ForwardSM-VGCS-Arg
     RESULT
          MT-ForwardSM-VGCS-Res
          -- optional
     ERRORS {
          systemFailure |
          unexpectedDataValue }
     CODE local:21 }
```

```
END
```

17.6.6 Errors

```
MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}

DEFINITIONS

::=

BEGIN

EXPORTS

   -- generic errors
   systemFailure,
   dataMissing,
   unexpectedDataValue,
   facilityNotSupported,
   incompatibleTerminal,
   resourceLimitation,

   -- identification and numbering errors
   unknownSubscriber,
   numberChanged,
   unknownMSC,
   unidentifiedSubscriber,
   unknownEquipment,

   -- subscription errors
   roamingNotAllowed,
   illegalSubscriber,
   illegalEquipment,
   bearerServiceNotProvisioned,
   teleserviceNotProvisioned,

   -- handover errors
   noHandoverNumberAvailable,
   subsequentHandoverFailure,
   targetCellOutsideGroupCallArea,

   -- operation and maintenance errors
   tracingBufferFull,

   -- call handling errors
   or-NotAllowed,
   noRoamingNumberAvailable,
   busySubscriber,
   noSubscriberReply,
   absentSubscriber,
   callBarred,
   forwardingViolation,
   forwardingFailed,
   cug-Reject,

   -- any time interrogation errors
   ati-NotAllowed,

   -- any time information handling errors
   atsi-NotAllowed,
   atm-NotAllowed,
   informationNotAvailable,
```

```
   -- supplementary service errors
   illegalSS-Operation,
   ss-ErrorStatus,
   ss-NotAvailable,
   ss-SubscriptionViolation,
   ss-Incompatibility,
   unknownAlphabet,
   ussd-Busy,
   pw-RegistrationFailure,
   negativePW-Check,
   numberOfPW-AttemptsViolation,
   shortTermDenial,
   longTermDenial,

   -- short message service errors
   subscriberBusyForMT-SMS,
   sm-DeliveryFailure,
   messageWaitingListFull,
   absentSubscriberSM,

   -- Group Call errors
   noGroupCallNumberAvailable,
   ongoingGroupCall,

   -- location service errors
   unauthorizedRequestingNetwork,
   unauthorizedLCSClient,
   positionMethodFailure,
   unknownOrUnreachableLCSClient,

   -- Mobility Management errors
   mm-EventNotSupported


;

IMPORTS
   ERROR
FROM Remote-Operations-Information-Objects {joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0) }

   SS-Status
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version11 (11)}

   SS-IncompatibilityCause,
   PW-RegistrationFailureCause,
   SM-DeliveryFailureCause,
   SystemFailureParam,
   DataMissingParam,
   UnexpectedDataParam,
   FacilityNotSupParam,
   UnknownSubscriberParam,
   NumberChangedParam,
   UnidentifiedSubParam,
   RoamingNotAllowedParam,
   IllegalSubscriberParam,
   IllegalEquipmentParam,
   BearerServNotProvParam,
   TeleservNotProvParam,
   TracingBufferFullParam,
   NoRoamingNbParam,
   OR-NotAllowedParam,
   AbsentSubscriberParam,
   BusySubscriberParam,
   NoSubscriberReplyParam,
   CallBarredParam,
   ForwardingViolationParam,
   ForwardingFailedParam,
   CUG-RejectParam,
   ATI-NotAllowedParam,
   SubBusyForMT-SMS-Param,
   MessageWaitListFullParam,
   AbsentSubscriberSM-Param,
   ResourceLimitationParam,
   NoGroupCallNbParam,
   IncompatibleTerminalParam,
   ShortTermDenialParam,
```

```
   LongTermDenialParam,
   UnauthorizedRequestingNetwork-Param,
   UnauthorizedLCSClient-Param,
   PositionMethodFailure-Param,
   UnknownOrUnreachableLCSClient-Param,
   MM-EventNotSupported-Param,
   ATSI-NotAllowedParam,
   ATM-NotAllowedParam,
   IllegalSS-OperationParam,
   SS-NotAvailableParam,
   SS-SubscriptionViolationParam,
   InformationNotAvailableParam,
   TargetCellOutsideGCA-Param,
   OngoingGroupCallParam
FROM MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version11 (11)}
;

-- generic errors

systemFailure  ERROR ::= {
     PARAMETER
          SystemFailureParam
          -- optional
     CODE local:34 }

dataMissing  ERROR ::= {
     PARAMETER
          DataMissingParam
          -- optional
          -- DataMissingParam must not be used in version <3
     CODE local:35 }

unexpectedDataValue  ERROR ::= {
     PARAMETER
          UnexpectedDataParam
          -- optional
          -- UnexpectedDataParam must not be used in version <3
     CODE local:36 }

facilityNotSupported  ERROR ::= {
     PARAMETER
          FacilityNotSupParam
          -- optional
          -- FacilityNotSupParam must not be used in version <3
     CODE local:21 }

incompatibleTerminal  ERROR ::= {
     PARAMETER
          IncompatibleTerminalParam
          -- optional
     CODE local:28 }

resourceLimitation  ERROR ::= {
     PARAMETER
          ResourceLimitationParam
          -- optional
     CODE local:51 }

-- identification and numbering errors

unknownSubscriber  ERROR ::= {
     PARAMETER
          UnknownSubscriberParam
          -- optional
          -- UnknownSubscriberParam must not be used in version <3
     CODE local:1 }

numberChanged  ERROR ::= {
     PARAMETER
          NumberChangedParam
          -- optional
     CODE local:44 }

unknownMSC  ERROR ::= {
     CODE local:3 }
```

```
unidentifiedSubscriber  ERROR ::= {
     PARAMETER
          UnidentifiedSubParam
          -- optional
          -- UunidentifiedSubParam must not be used in version <3
     CODE local:5 }
```

```
unknownEquipment  ERROR ::= {
     CODE local:7 }
```

-- subscription errors

```
roamingNotAllowed  ERROR ::= {
     PARAMETER
          RoamingNotAllowedParam
     CODE local:8 }
```

```
illegalSubscriber  ERROR ::= {
     PARAMETER
          IllegalSubscriberParam
          -- optional
          -- IllegalSubscriberParam must not be used in version <3
     CODE local:9 }
```

```
illegalEquipment  ERROR ::= {
     PARAMETER
          IllegalEquipmentParam
          -- optional
          -- IllegalEquipmentParam must not be used in version <3
     CODE local:12 }
```

```
bearerServiceNotProvisioned  ERROR ::= {
     PARAMETER
          BearerServNotProvParam
          -- optional
          -- BearerServNotProvParam must not be used in version <3
     CODE local:10 }
```

```
teleserviceNotProvisioned  ERROR ::= {
     PARAMETER
          TeleservNotProvParam
          -- optional
          -- TeleservNotProvParam must not be used in version <3
     CODE local:11 }
```

-- handover errors

```
noHandoverNumberAvailable  ERROR ::= {
     CODE local:25 }
```

```
subsequentHandoverFailure  ERROR ::= {
     CODE local:26 }
```

```
targetCellOutsideGroupCallArea  ERROR ::= {
     PARAMETER
          TargetCellOutsideGCA-Param
          -- optional
     CODE local:42 }
```

-- operation and maintenance errors

```
tracingBufferFull  ERROR ::= {
     PARAMETER
          TracingBufferFullParam
          -- optional
     CODE local: 40 }
```

-- call handling errors

```
noRoamingNumberAvailable  ERROR ::= {
     PARAMETER
          NoRoamingNbParam
          -- optional
     CODE local:39 }
```

```
absentSubscriber  ERROR ::= {
     PARAMETER
          AbsentSubscriberParam
          -- optional
          -- AbsentSubscriberParam must not be used in version <3
     CODE local:27 }
```

```
busySubscriber  ERROR ::= {
     PARAMETER
          BusySubscriberParam
          -- optional
     CODE local:45 }
```

```
noSubscriberReply  ERROR ::= {
     PARAMETER
          NoSubscriberReplyParam
          -- optional
     CODE local:46 }
```

```
callBarred  ERROR ::= {
     PARAMETER
          CallBarredParam
          -- optional
     CODE local:13 }
```

```
forwardingViolation  ERROR ::= {
     PARAMETER
          ForwardingViolationParam
          -- optional
     CODE local:14 }
```

```
forwardingFailed  ERROR ::= {
     PARAMETER
          ForwardingFailedParam
          -- optional
     CODE local:47 }
```

```
cug-Reject  ERROR ::= {
     PARAMETER
          CUG-RejectParam
          -- optional
     CODE local:15 }
```

```
or-NotAllowed  ERROR ::= {
     PARAMETER
          OR-NotAllowedParam
          -- optional
     CODE local:48 }
```

```
-- any time interrogation errors
ati-NotAllowed  ERROR ::= {
     PARAMETER
          ATI-NotAllowedParam
          -- optional
     CODE local:49 }
```

```
-- any time information handling errors
atsi-NotAllowed  ERROR ::= {
     PARAMETER
          ATSI-NotAllowedParam
          -- optional
     CODE local:60 }
```

```
atm-NotAllowed  ERROR ::= {
     PARAMETER
          ATM-NotAllowedParam
          -- optional
     CODE local:61 }
```

```
informationNotAvailable  ERROR ::= {
     PARAMETER
          InformationNotAvailableParam
          -- optional
     CODE local:62 }
```

```
-- supplementary service errors
```

```
illegalSS-Operation  ERROR ::= {
     PARAMETER
          IllegalSS-OperationParam
          -- optional
          -- IllegalSS-OperationParam must not be used in version <3
     CODE local:16 }

ss-ErrorStatus  ERROR ::= {
     PARAMETER
          SS-Status
          -- optional
     CODE local:17 }

ss-NotAvailable  ERROR ::= {
     PARAMETER
          SS-NotAvailableParam
          -- optional
          -- SS-NotAvailableParam must not be used in version <3
     CODE local:18 }

ss-SubscriptionViolation  ERROR ::= {
     PARAMETER
          SS-SubscriptionViolationParam
          -- optional
          -- SS-SubscriptionViolationParam must not be used in version <3
     CODE local:19 }

ss-Incompatibility  ERROR ::= {
     PARAMETER
          SS-IncompatibilityCause
          -- optional
     CODE local:20 }

unknownAlphabet  ERROR ::= {
     CODE local:71 }

ussd-Busy  ERROR ::= {
     CODE local:72 }

pw-RegistrationFailure  ERROR ::= {
     PARAMETER
          PW-RegistrationFailureCause
     CODE local:37 }

negativePW-Check  ERROR ::= {
     CODE local:38 }

numberOfPW-AttemptsViolation  ERROR ::= {
     CODE local:43 }

shortTermDenial  ERROR ::= {
     PARAMETER
          ShortTermDenialParam
          -- optional
     CODE local:29 }

longTermDenial  ERROR ::= {
     PARAMETER
          LongTermDenialParam
          -- optional
     CODE local:30 }

-- short message service errors

subscriberBusyForMT-SMS  ERROR ::= {
     PARAMETER
          SubBusyForMT-SMS-Param
          -- optional
     CODE local:31 }

sm-DeliveryFailure  ERROR ::= {
     PARAMETER
          SM-DeliveryFailureCause
     CODE local:32 }
```

```
messageWaitingListFull  ERROR ::= {
     PARAMETER
          MessageWaitListFullParam
          -- optional
     CODE local:33 }
```

```
absentSubscriberSM  ERROR ::= {
     PARAMETER
          AbsentSubscriberSM-Param
          -- optional
     CODE local:6 }
```

```
-- Group Call errors
```

```
noGroupCallNumberAvailable  ERROR ::= {
     PARAMETER
          NoGroupCallNbParam
          -- optional
     CODE local:50 }
```

```
ongoingGroupCall  ERROR ::= {
     PARAMETER
          OngoingGroupCallParam
          -- optional
     CODE local:22 }
```

```
-- location service errors
```

```
unauthorizedRequestingNetwork  ERROR ::= {
     PARAMETER
          UnauthorizedRequestingNetwork-Param
          -- optional
     CODE local:52 }
```

```
unauthorizedLCSClient  ERROR ::= {
     PARAMETER
          UnauthorizedLCSClient-Param
          -- optional
     CODE local:53 }
```

```
positionMethodFailure  ERROR ::= {
     PARAMETER
          PositionMethodFailure-Param
          -- optional
     CODE local:54 }
```

```
unknownOrUnreachableLCSClient  ERROR ::= {
     PARAMETER
          UnknownOrUnreachableLCSClient-Param
          -- optional
     CODE local:58 }
```

```
mm-EventNotSupported  ERROR ::= {
     PARAMETER
          MM-EventNotSupported-Param
          -- optional
     CODE local:59 }
```

```
END
```

17.6.7 Group Call operations

```
MAP-Group-Call-Operations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Group-Call-Operations (22)
   version11 (11)}

DEFINITIONS

::=

BEGIN

EXPORTS
   prepareGroupCall,
   sendGroupCallEndSignal,
```

```
   forwardGroupCallSignalling,
   processGroupCallSignalling,
   sendGroupCallInfo
;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   unexpectedDataValue,
   noGroupCallNumberAvailable,
   ongoingGroupCall,
   unknownSubscriber,
   teleserviceNotProvisioned,
   dataMissing
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}

   PrepareGroupCallArg,
   PrepareGroupCallRes,
   SendGroupCallEndSignalArg,
   SendGroupCallEndSignalRes,
   ForwardGroupCallSignallingArg,
   ProcessGroupCallSignallingArg,
   SendGroupCallInfoArg,
   SendGroupCallInfoRes
FROM MAP-GR-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-GR-DataTypes (23) version11 (11)}

;
```

```
prepareGroupCall  OPERATION ::= {                                    --Timer m
     ARGUMENT
          PrepareGroupCallArg
     RESULT
     PrepareGroupCallRes
     ERRORS {
          systemFailure |
          noGroupCallNumberAvailable |
          unexpectedDataValue}
     CODE local:39 }
```

```
sendGroupCallEndSignal  OPERATION ::= {                              --Timer l
     ARGUMENT
          SendGroupCallEndSignalArg
     RESULT
          SendGroupCallEndSignalRes
     CODE local:40 }
```

```
processGroupCallSignalling  OPERATION ::= {                           --Timer s
     ARGUMENT
          ProcessGroupCallSignallingArg
     CODE local:41 }
```

```
forwardGroupCallSignalling  OPERATION ::= {                           --Timer s
     ARGUMENT
          ForwardGroupCallSignallingArg
     CODE local:42 }
```

```
sendGroupCallInfo  OPERATION ::= {                                   --Timer m
     ARGUMENT
          SendGroupCallInfoArg
     RESULT
          SendGroupCallInfoRes
     ERRORS {
          systemFailure |
          ongoingGroupCall |
          unexpectedDataValue |
          dataMissing |
          teleserviceNotProvisioned |
          unknownSubscriber}
     CODE local:84 }
```

```
END
```

17.6.8 Location service operations

```
MAP-LocationServiceOperations {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-LocationServiceOperations (24)
   version11 (11)}

DEFINITIONS

::=

BEGIN

EXPORTS
   provideSubscriberLocation,
   sendRoutingInfoForLCS,
   subscriberLocationReport
;

IMPORTS
   OPERATION
FROM Remote-Operations-Information-Objects {
   joint-iso-itu-t remote-operations(4)
  informationObjects(5) version1(0)}

   systemFailure,
   dataMissing,
   unexpectedDataValue,
   facilityNotSupported,
   unknownSubscriber,
   absentSubscriber,
   unauthorizedRequestingNetwork,
   unauthorizedLCSClient,
   positionMethodFailure,
   resourceLimitation,
   unknownOrUnreachableLCSClient,
   unidentifiedSubscriber,
   illegalEquipment,
   illegalSubscriber
FROM MAP-Errors {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-Errors (10) version11 (11)}

   RoutingInfoForLCS-Arg,
   RoutingInfoForLCS-Res,
   ProvideSubscriberLocation-Arg,
   ProvideSubscriberLocation-Res,
   SubscriberLocationReport-Arg,
   SubscriberLocationReport-Res
FROM MAP-LCS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-LCS-DataTypes (25) version11 (11)}
;

sendRoutingInfoForLCS  OPERATION ::= {                                    --Timer m
     ARGUMENT
          RoutingInfoForLCS-Arg
     RESULT
          RoutingInfoForLCS-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unknownSubscriber |
          absentSubscriber |
          unauthorizedRequestingNetwork }
     CODE local:85 }
```

```
provideSubscriberLocation  OPERATION ::= {                                  --Timer ml
     ARGUMENT
          ProvideSubscriberLocation-Arg
     RESULT
          ProvideSubscriberLocation-Res
     ERRORS {
          systemFailure |
          dataMissing |
          unexpectedDataValue |
          facilityNotSupported |
          unidentifiedSubscriber |
          illegalSubscriber |
          illegalEquipment |
          absentSubscriber |
          unauthorizedRequestingNetwork |
          unauthorizedLCSClient |
          positionMethodFailure }
     CODE local:83 }

subscriberLocationReport  OPERATION ::= {                                   --Timer m
     ARGUMENT
          SubscriberLocationReport-Arg
     RESULT
          SubscriberLocationReport-Res
     ERRORS {
          systemFailure |
          dataMissing |
          resourceLimitation |
          unexpectedDataValue |
          unknownSubscriber |
          unauthorizedRequestingNetwork |
          unknownOrUnreachableLCSClient}
     CODE local:86 }


END
```

17.6.9 Void

17.7 MAP constants and data types

17.7.1 Mobile Service data types

```
MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS

   -- location registration types
   UpdateLocationArg,
   UpdateLocationRes,
   CancelLocationArg,
   CancelLocationRes,
   PurgeMS-Arg,
   PurgeMS-Res,
   SendIdentificationArg,
   SendIdentificationRes,
   UpdateGprsLocationArg,
   UpdateGprsLocationRes,
   IST-SupportIndicator,
   SupportedLCS-CapabilitySets,
```

```
    -- handover types
    ForwardAccessSignalling-Arg,
    PrepareHO-Arg,
    PrepareHO-Res,
    PrepareSubsequentHO-Arg,
    PrepareSubsequentHO-Res,
    ProcessAccessSignalling-Arg,
    SendEndSignal-Arg,
    SendEndSignal-Res,

    -- authentication management types
    SendAuthenticationInfoArg,
    SendAuthenticationInfoRes,
    AuthenticationFailureReportArg,
    AuthenticationFailureReportRes,

    -- security management types
    Kc,
    Cksn,

    -- equipment management types
    CheckIMEI-Arg,
    CheckIMEI-Res,

    -- subscriber management types
    InsertSubscriberDataArg,
    InsertSubscriberDataRes,
    LSAIdentity,
    DeleteSubscriberDataArg,
    DeleteSubscriberDataRes,
    Ext-QoS-Subscribed,
    Ext2-QoS-Subscribed,
    Ext3-QoS-Subscribed,
    SubscriberData,
    ODB-Data,
    SubscriberStatus,
    ZoneCodeList,
    maxNumOfZoneCodes,
    O-CSI,
    D-CSI,
    O-BcsmCamelTDPCriteriaList,
    T-BCSM-CAMEL-TDP-CriteriaList,
    SS-CSI,
    ServiceKey,
    DefaultCallHandling,
    CamelCapabilityHandling,
    BasicServiceCriteria,
    SupportedCamelPhases,
    OfferedCamel4CSIs,
    OfferedCamel4Functionalities,
    maxNumOfCamelTDPData,
    CUG-Index,
    CUG-Info,
    CUG-Interlock,
    InterCUG-Restrictions,
    IntraCUG-Options,
    NotificationToMSUser,
    QoS-Subscribed,
    IST-AlertTimerValue,
    T-CSI,
    T-BcsmTriggerDetectionPoint,
    APN,
    AdditionalInfo,

    -- fault recovery types
    ResetArg,
    RestoreDataArg,
    RestoreDataRes,

-- provide subscriber info types
    GeographicalInformation,
    MS-Classmark2,
    GPRSMSClass,

    -- subscriber information enquiry types
    ProvideSubscriberInfoArg,
    ProvideSubscriberInfoRes,
    SubscriberInfo,
```

```
   LocationInformation,
   LocationInformationGPRS,
   RAIdentity,
   SubscriberState,
   GPRSChargingID,
   MNPInfoRes,
   RouteingNumber,

   -- any time information enquiry types
   AnyTimeInterrogationArg,
   AnyTimeInterrogationRes,

   -- any time information handling types
   AnyTimeSubscriptionInterrogationArg,
   AnyTimeSubscriptionInterrogationRes,
   AnyTimeModificationArg,
   AnyTimeModificationRes,

   -- subscriber data modification notification types
   NoteSubscriberDataModifiedArg,
   NoteSubscriberDataModifiedRes,

   -- gprs location information retrieval types
   SendRoutingInfoForGprsArg,
   SendRoutingInfoForGprsRes,

   -- failure reporting types
   FailureReportArg,
   FailureReportRes,

   -- gprs notification types
   NoteMsPresentForGprsArg,
   NoteMsPresentForGprsRes,

   -- Mobility Management types
   NoteMM-EventArg,
   NoteMM-EventRes,
   NumberPortabilityStatus,
   PagingArea,

   -- VGCS / VBS types types
   GroupId,
   Long-GroupId,
   AdditionalSubscriptions

;

IMPORTS
   maxNumOfSS,
   SS-SubscriptionOption,
   SS-List,
   SS-ForBS-Code,
   Password
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version11 (11)}

   SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version11 (11)}

   Ext-BearerServiceCode
FROM MAP-BS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-BS-Code (20) version11 (11)}

   Ext-TeleserviceCode
FROM MAP-TS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version11 (11)}

   AddressString,
   ISDN-AddressString,
   ISDN-SubaddressString,
   FTN-AddressString,
   AccessNetworkSignalInfo,
   IMSI,
   IMEI,
```

```
   TMSI,
   HLR-List,
   LMSI,
   Identity,
   GlobalCellId,
   CellGlobalIdOrServiceAreaIdOrLAI,
   Ext-BasicServiceCode,
   NAEA-PreferredCI,
   EMLPP-Info,
   MC-SS-Info,
   SubscriberIdentity,
   AgeOfLocationInformation,
   LCSClientExternalID,
   LCSClientInternalID,
   Ext-SS-Status,
   LCSServiceTypeID,
   ASCI-CallReference,
   TBCD-STRING,
   LAIFixedLength,
   PLMN-Id,
   EMLPP-Priority,
   GSN-Address
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}

   AbsentSubscriberDiagnosticSM
FROM MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version11 (11)}

   TracePropagationList
FROM MAP-OM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OM-DataTypes (12) version11 (11)}

;

-- location registration types
```

```
UpdateLocationArg ::= SEQUENCE {
     imsi                              IMSI,
     msc-Number                        [1] ISDN-AddressString,
     vlr-Number                        ISDN-AddressString,
     lmsi                              [10] LMSI                          OPTIONAL,
     extensionContainer                ExtensionContainer                 OPTIONAL,
     ... ,
     vlr-Capability                    [6] VLR-Capability                 OPTIONAL,
     informPreviousNetworkEntity       [11] NULL                          OPTIONAL,
     cs-LCS-NotSupportedByUE           [12] NULL                          OPTIONAL,
     v-gmlc-Address                    [2]  GSN-Address                   OPTIONAL,
     add-info                          [13] ADD-Info                      OPTIONAL,
     pagingArea                        [14] PagingArea                    OPTIONAL,
     skipSubscriberDataUpdate          [15] NULL                          OPTIONAL
     -- The skipSubscriberDataUpdate parameter in the UpdateLocationArg and the ADD-Info
     -- structures carry the same semantic.
      }
```

```
VLR-Capability ::= SEQUENCE{
     supportedCamelPhases              [0] SupportedCamelPhases           OPTIONAL,
     extensionContainer                ExtensionContainer                 OPTIONAL,
     ... ,
     solsaSupportIndicator             [2] NULL                           OPTIONAL,
     istSupportIndicator               [1] IST-SupportIndicator           OPTIONAL,
     superChargerSupportedInServingNetworkEntity   [3] SuperChargerInfo   OPTIONAL,
     longFTN-Supported                 [4]  NULL                          OPTIONAL,
     supportedLCS-CapabilitySets       [5]  SupportedLCS-CapabilitySets   OPTIONAL,
     offeredCamel4CSIs                 [6] OfferedCamel4CSIs              OPTIONAL,
     supportedRAT-TypesIndicator       [7]  SupportedRAT-Types            OPTIONAL,
     longGroupID-Supported             [8]  NULL                          OPTIONAL }
```

```
SupportedRAT-Types::= BIT STRING {
     utran  (0),
     geran  (1),
     gan    (2),
     i-hspa-evolution (3),
     e-utran   (4)} (SIZE (2..8))
     -- exception handling: bits 5 to 7 shall be ignored if received and not understood
```

```
SuperChargerInfo ::= CHOICE {
     sendSubscriberData                  [0] NULL,
     subscriberDataStored                [1] AgeIndicator }
```

```
AgeIndicator ::= OCTET STRING (SIZE (1..6))
     -- The internal structure of this parameter is implementation specific.
```

```
IST-SupportIndicator ::=  ENUMERATED {
     basicISTSupported                   (0),
     istCommandSupported                 (1),
     ...}
-- exception handling:
-- reception of values > 1 shall be mapped to ' istCommandSupported '
```

```
SupportedLCS-CapabilitySets ::= BIT STRING {
     lcsCapabilitySet1 (0),
     lcsCapabilitySet2 (1),
     lcsCapabilitySet3 (2),
     lcsCapabilitySet4 (3) ,
     lcsCapabilitySet5 (4) } (SIZE (2..16))
-- Core network signalling capability set1 indicates LCS Release98 or Release99 version.
-- Core network signalling capability set2 indicates LCS Release4.
-- Core network signalling capability set3 indicates LCS Release5.
-- Core network signalling capability set4 indicates LCS Release6.
-- Core network signalling capability set5 indicates LCS Release7 or later version.
-- A node shall mark in the BIT STRING all LCS capability sets it supports.
-- If no bit is set then the sending node does not support LCS.
-- If the parameter is not sent by an VLR then the VLR may support at most capability set1.
-- If the parameter is not sent by an SGSN then no support for LCS is assumed.
-- An SGSN is not allowed to indicate support of capability set1.
-- Other bits than listed above shall be discarded.
```

```
UpdateLocationRes ::= SEQUENCE {
     hlr-Number                          ISDN-AddressString,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     add-Capability                      NULL                              OPTIONAL,
     pagingArea-Capability               [0]NULL                            OPTIONAL }
```

```
ADD-Info ::= SEQUENCE {
     imeisv                              [0] IMEI,
     skipSubscriberDataUpdate            [1] NULL                          OPTIONAL,
     -- The skipSubscriberDataUpdate parameter in the UpdateLocationArg and the ADD-Info
     -- structures carry the same semantic.
     ...}
```

```
PagingArea ::= SEQUENCE SIZE (1..5) OF LocationArea
```

```
LocationArea ::= CHOICE {
     laiFixedLength                      [0] LAIFixedLength,
     lac                                 [1] LAC}
```

```
LAC ::= OCTET STRING (SIZE (2))
     -- Refers to Location Area Code of the Location Area Identification defined in
     -- 3GPP TS 23.003 [17].
     -- Location Area Code according to 3GPP TS 24.008 [35]
```

```
CancelLocationArg ::= [3] SEQUENCE {
     identity                          Identity,
     cancellationType                  CancellationType                OPTIONAL,
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...,
     typeOfUpdate                      [0] TypeOfUpdate                OPTIONAL }
```

```
TypeOfUpdate ::= ENUMERATED {
     sgsn-change (0),
     mme-change (1),
     ...}
     -- TypeOfUpdate shall be absent if CancellationType is different from updateProcedure
```

```
CancellationType ::= ENUMERATED {
     updateProcedure                   (0),
     subscriptionWithdraw              (1),
     ...,
     initialAttachProcedure            (2)}
     -- The HLR shall not send values other than listed above
```

```
CancelLocationRes ::= SEQUENCE {
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...}
```

```
PurgeMS-Arg ::= [3] SEQUENCE {
     imsi                              IMSI,
     vlr-Number                        [0] ISDN-AddressString          OPTIONAL,
     sgsn-Number                       [1]  ISDN-AddressString         OPTIONAL,
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...}
```

```
PurgeMS-Res ::= SEQUENCE {
     freezeTMSI                        [0]  NULL                       OPTIONAL,
     freezeP-TMSI                      [1]  NULL                       OPTIONAL,
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...,
     freezeM-TMSI                      [2]  NULL                       OPTIONAL }
```

```
SendIdentificationArg ::= SEQUENCE {
     tmsi                              TMSI,
     numberOfRequestedVectors          NumberOfRequestedVectors        OPTIONAL,
     -- within a dialogue numberOfRequestedVectors shall be present in
     -- the first service request and shall not be present in subsequent service requests.
     -- If received in a subsequent service request it shall be discarded.
     segmentationProhibited            NULL                            OPTIONAL,
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...,
     msc-Number                        ISDN-AddressString              OPTIONAL,
     previous-LAI                      [0] LAIFixedLength              OPTIONAL,
     hopCounter                        [1] HopCounter                  OPTIONAL }
```

```
HopCounter ::= INTEGER (0..3)
```

```
SendIdentificationRes ::= [3] SEQUENCE {
     imsi                              IMSI                            OPTIONAL,
     -- IMSI shall be present in the first (or only) service response of a dialogue.
     -- If multiple service requests are present in a dialogue then IMSI
     -- shall not be present in any service response other than the first one.
     authenticationSetList             AuthenticationSetList           OPTIONAL,
     currentSecurityContext            [2]CurrentSecurityContext       OPTIONAL,
     extensionContainer                [3] ExtensionContainer          OPTIONAL,
     ...}
```

-- authentication management types

```
AuthenticationSetList ::= CHOICE {
     tripletList                       [0] TripletList,
     quintupletList                    [1] QuintupletList }
```

```
TripletList ::= SEQUENCE SIZE (1..5) OF
                                       AuthenticationTriplet
```

```
QuintupletList ::= SEQUENCE SIZE (1..5) OF
                                       AuthenticationQuintuplet
```

```
AuthenticationTriplet ::= SEQUENCE {
     rand                                RAND,
     sres                                SRES,
     kc                                  Kc,
     ...}
```

```
AuthenticationQuintuplet ::= SEQUENCE {
     rand                                RAND,
     xres                                XRES,
     ck                                  CK,
     ik                                  IK,
     autn                                AUTN,
     ...}
```

```
CurrentSecurityContext ::= CHOICE {
     gsm-SecurityContextData             [0] GSM-SecurityContextData,
     umts-SecurityContextData            [1] UMTS-SecurityContextData }
```

```
GSM-SecurityContextData ::= SEQUENCE {
     kc                                  Kc,
     cksn                                Cksn,
     ... }
```

```
UMTS-SecurityContextData ::= SEQUENCE {
     ck                                  CK,
     ik                                  IK,
     ksi                                 KSI,
     ... }
```

```
RAND ::= OCTET STRING (SIZE (16))
```

```
SRES ::= OCTET STRING (SIZE (4))
```

```
Kc ::= OCTET STRING (SIZE (8))
```

```
XRES ::= OCTET STRING (SIZE (4..16))
```

```
CK ::= OCTET STRING (SIZE (16))
```

```
IK ::= OCTET STRING (SIZE (16))
```

```
AUTN ::= OCTET STRING (SIZE (16))
```

```
AUTS ::= OCTET STRING (SIZE (14))
```

```
Cksn ::= OCTET STRING (SIZE (1))
     -- The internal structure is defined in 3GPP TS 24.008
```

```
KSI ::= OCTET STRING (SIZE (1))
     -- The internal structure is defined in 3GPP TS 24.008
```

```
AuthenticationFailureReportArg ::= SEQUENCE {
     imsi                                IMSI,
     failureCause                        FailureCause,
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ... ,
     re-attempt                          BOOLEAN                             OPTIONAL,
     accessType                          AccessType                          OPTIONAL,
     rand                                RAND                                OPTIONAL,
     vlr-Number                          [0] ISDN-AddressString              OPTIONAL,
     sgsn-Number                         [1] ISDN-AddressString              OPTIONAL }
```

```
AccessType ::= ENUMERATED {
     call (0),
     emergencyCall (1),
     locationUpdating (2),
     supplementaryService (3),
     shortMessage (4),
     gprsAttach (5),
     routingAreaUpdating (6),
     serviceRequest (7),
     pdpContextActivation (8),
     pdpContextDeactivation (9),
     ...,
     gprsDetach (10)}
     -- exception handling:
     -- received values greater than 10 shall be ignored.
```

```
AuthenticationFailureReportRes ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
FailureCause ::= ENUMERATED {
     wrongUserResponse  (0),
     wrongNetworkSignature  (1)}
```

-- gprs location registration types

```
UpdateGprsLocationArg ::= SEQUENCE {
     imsi                                IMSI,
     sgsn-Number                         ISDN-AddressString,
     sgsn-Address                        GSN-Address,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ... ,
     sgsn-Capability                     [0] SGSN-Capability               OPTIONAL,
     informPreviousNetworkEntity         [1]  NULL                         OPTIONAL,
     ps-LCS-NotSupportedByUE             [2]  NULL                         OPTIONAL,
     v-gmlc-Address                      [3]  GSN-Address                  OPTIONAL,
     add-info                            [4]  ADD-Info                     OPTIONAL,
     eps-info                            [5]  EPS-Info                     OPTIONAL,
     servingNodeTypeIndicator            [6]  NULL                         OPTIONAL,
     skipSubscriberDataUpdate            [7] NULL                          OPTIONAL,
     usedRAT-Type                        [8] Used-RAT-Type                 OPTIONAL,
     gprsSubscriptionDataNotNeeded       [9] NULL                          OPTIONAL,
     nodeTypeIndicator                   [10] NULL                         OPTIONAL,
     areaRestricted                      [11] NULL                         OPTIONAL,
     ue-reachableIndicator               [12] NULL                         OPTIONAL
      }
```

```
Used-RAT-Type::= ENUMERATED {
     utran  (0),
     geran  (1),
     gan    (2),
     i-hspa-evolution (3),
     e-utran   (4),
     ...}
```

```
EPS-Info ::= CHOICE{
     pdn-gw-update                       [0] PDN-GW-Update,
     isr-Information                     [1] ISR-Information }
```

```
PDN-GW-Update ::= SEQUENCE{
     apn                                 [0] APN                           OPTIONAL,
     pdn-gw-Identity                     [1] PDN-GW-Identity               OPTIONAL,
     contextId                           [2] ContextId                     OPTIONAL,
     extensionContainer                  [3] ExtensionContainer            OPTIONAL,
     ... }
```

```
ISR-Information::= BIT STRING {
     updateMME  (0),
     cancelSGSN  (1),
     initialAttachIndicator  (2)} (SIZE (3..8))
     -- exception handling: reception of unknown bit assignments in the
     -- ISR-Information data type shall be discarded by the receiver
```

```
SGSN-Capability ::= SEQUENCE{
     solsaSupportIndicator                NULL                                OPTIONAL,
     extensionContainer                   [1] ExtensionContainer              OPTIONAL,
     ... ,
     superChargerSupportedInServingNetworkEntity   [2] SuperChargerInfo       OPTIONAL ,
     gprsEnhancementsSupportIndicator     [3] NULL                            OPTIONAL,
     supportedCamelPhases                 [4] SupportedCamelPhases            OPTIONAL,
     supportedLCS-CapabilitySets          [5]  SupportedLCS-CapabilitySets    OPTIONAL,
     offeredCamel4CSIs                    [6] OfferedCamel4CSIs               OPTIONAL,
     smsCallBarringSupportIndicator       [7]  NULL                           OPTIONAL,
     supportedRAT-TypesIndicator          [8]  SupportedRAT-Types             OPTIONAL,
     supportedFeatures                    [9] SupportedFeatures               OPTIONAL }
```

```
SupportedFeatures::= BIT STRING {
     odb-all-apn (0),
     odb-HPLMN-APN (1),
     odb-VPLMN-APN (2),
     odb-all-og (3),
     odb-all-international-og (4),
     odb-all-int-og-not-to-HPLMN-country (5),
     odb-all-interzonal-og (6),
     odb-all-interzonal-og-not-to-HPLMN-country (7),
     odb-all-interzonal-og-and-internat-og-not-to-HPLMN-country (8),
     regSub (9),
     trace (10),
     lcs-all-PrivExcep (11),
     lcs-universal (12),
     lcs-CallSessionRelated (13),
     lcs-CallSessionUnrelated (14),
     lcs-PLMN-operator (15),
     lcs-ServiceType (16),
     lcs-all-MOLR-SS (17),
     lcs-basicSelfLocation (18),
     lcs-autonomousSelfLocation (19),
     lcs-transferToThirdParty (20),
     sm-mo-pp (21),
     barring-OutgoingCalls (22),
     baoc (23),
     boic (24),
     boicExHC (25)} (SIZE (26..40))
```

```
UpdateGprsLocationRes ::= SEQUENCE {
     hlr-Number                           ISDN-AddressString,
     extensionContainer                   ExtensionContainer                  OPTIONAL,
     ...,
     add-Capability                       NULL                                OPTIONAL,
     sgsn-mmeSeparationSupported          [0] NULL                            OPTIONAL }
```

-- handover types

```
ForwardAccessSignalling-Arg ::= [3] SEQUENCE {
     an-APDU                              AccessNetworkSignalInfo,
     integrityProtectionInfo              [0] IntegrityProtectionInformation  OPTIONAL,
     encryptionInfo                       [1] EncryptionInformation           OPTIONAL,
     keyStatus                            [2]  KeyStatus                      OPTIONAL,
     allowedGSM-Algorithms                [4]  AllowedGSM-Algorithms          OPTIONAL,
     allowedUMTS-Algorithms               [5]  AllowedUMTS-Algorithms         OPTIONAL,
     radioResourceInformation             [6] RadioResourceInformation        OPTIONAL,
     extensionContainer                   [3]  ExtensionContainer             OPTIONAL,
     ...,
     radioResourceList                    [7]  RadioResourceList              OPTIONAL,
     bssmap-ServiceHandover               [9]  BSSMAP-ServiceHandover         OPTIONAL,
     ranap-ServiceHandover                [8]  RANAP-ServiceHandover          OPTIONAL,
     bssmap-ServiceHandoverList           [10] BSSMAP-ServiceHandoverList     OPTIONAL,
     currentlyUsedCodec                   [11] Codec                          OPTIONAL,
     iuSupportedCodecsList                [12] SupportedCodecsList            OPTIONAL,
     rab-ConfigurationIndicator           [13] NULL                           OPTIONAL,
     iuSelectedCodec                      [14] Codec                          OPTIONAL,
     alternativeChannelType               [15] RadioResourceInformation       OPTIONAL,
     tracePropagationList                 [17] TracePropagationList           OPTIONAL }
```

```
AllowedGSM-Algorithms ::= OCTET STRING (SIZE (1))
     -- internal structure is coded as Algorithm identifier octet from
     -- Permitted Algorithms defined in 3GPP TS 48.008
     -- A node shall mark all GSM algorithms that are allowed in MSC-B
```

```
AllowedUMTS-Algorithms ::= SEQUENCE {
     integrityProtectionAlgorithms        [0]  PermittedIntegrityProtectionAlgorithms
     OPTIONAL,
     encryptionAlgorithms                 [1]  PermittedEncryptionAlgorithms  OPTIONAL,
     extensionContainer                   [2]  ExtensionContainer             OPTIONAL,
     ...}
```

```
PermittedIntegrityProtectionAlgorithms ::=
          OCTET STRING (SIZE (1..maxPermittedIntegrityProtectionAlgorithmsLength))
     -- Octets contain a complete PermittedIntegrityProtectionAlgorithms data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413.
     -- Padding bits are included, if needed, in the least significant bits of the
     -- last octet of the octet string.
```

```
maxPermittedIntegrityProtectionAlgorithmsLength INTEGER ::= 9
```

```
PermittedEncryptionAlgorithms ::=
          OCTET STRING (SIZE (1..maxPermittedEncryptionAlgorithmsLength))
     -- Octets contain a complete PermittedEncryptionAlgorithms data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included, if needed, in the least significant bits of the
     -- last octet of the octet string.
```

```
maxPermittedEncryptionAlgorithmsLength INTEGER ::= 9
```

```
KeyStatus ::= ENUMERATED {
     old  (0),
     new  (1),
     ...}
     -- exception handling:
     -- received values in range 2-31 shall be treated as "old"
     -- received values greater than 31 shall be treated as "new"
```

```
PrepareHO-Arg ::= [3] SEQUENCE {
     targetCellId                         [0] GlobalCellId                   OPTIONAL,
     ho-NumberNotRequired                 NULL                               OPTIONAL,
     targetRNCId                          [1] RNCId                          OPTIONAL,
     an-APDU                              [2] AccessNetworkSignalInfo        OPTIONAL,
     multipleBearerRequested              [3] NULL                           OPTIONAL,
     imsi                                 [4] IMSI                           OPTIONAL,
     integrityProtectionInfo              [5] IntegrityProtectionInformation  OPTIONAL,
     encryptionInfo                       [6] EncryptionInformation           OPTIONAL,
     radioResourceInformation             [7] RadioResourceInformation       OPTIONAL,
     allowedGSM-Algorithms                [9]  AllowedGSM-Algorithms         OPTIONAL,
     allowedUMTS-Algorithms               [10] AllowedUMTS-Algorithms        OPTIONAL,
     radioResourceList                    [11] RadioResourceList             OPTIONAL,
     extensionContainer                   [8] ExtensionContainer             OPTIONAL,
     ... ,
     rab-Id                               [12] RAB-Id                        OPTIONAL,
     bssmap-ServiceHandover               [13] BSSMAP-ServiceHandover        OPTIONAL,
     ranap-ServiceHandover                [14] RANAP-ServiceHandover         OPTIONAL,
     bssmap-ServiceHandoverList           [15] BSSMAP-ServiceHandoverList    OPTIONAL,
     asciCallReference                    [20] ASCI-CallReference            OPTIONAL,
     geran-classmark                      [16] GERAN-Classmark               OPTIONAL,
     iuCurrentlyUsedCodec                 [17] Codec                         OPTIONAL,
     iuSupportedCodecsList                [18] SupportedCodecsList           OPTIONAL,
     rab-ConfigurationIndicator           [19] NULL                          OPTIONAL,
     uesbi-Iu                             [21] UESBI-Iu                      OPTIONAL,
     imeisv                               [22] IMEI                          OPTIONAL,
     alternativeChannelType               [23] RadioResourceInformation      OPTIONAL,
     tracePropagationList                 [25] TracePropagationList          OPTIONAL   }
```

```
BSSMAP-ServiceHandoverList ::= SEQUENCE SIZE (1.. maxNumOfServiceHandovers) OF
                                BSSMAP-ServiceHandoverInfo
```

```
BSSMAP-ServiceHandoverInfo ::= SEQUENCE {
     bssmap-ServiceHandover               BSSMAP-ServiceHandover,
     rab-Id                               RAB-Id,
     -- RAB Identity is needed to relate the service handovers with the radio access bearers.
     ...}
```

```
maxNumOfServiceHandovers  INTEGER ::= 7
```

```
BSSMAP-ServiceHandover ::= OCTET STRING (SIZE (1))
     -- Octets are coded according the Service Handover information element in
     -- 3GPP TS 48.008.
```

```
RANAP-ServiceHandover ::= OCTET STRING (SIZE (1))
     -- Octet contains a complete Service-Handover data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included in the least significant bits.
```

```
RadioResourceList ::= SEQUENCE SIZE (1.. maxNumOfRadioResources) OF
                                    RadioResource
```

```
RadioResource ::= SEQUENCE {
     radioResourceInformation            RadioResourceInformation,
     rab-Id                              RAB-Id,
     -- RAB Identity is needed to relate the radio resources with the radio access bearers.
     ...}
```

```
maxNumOfRadioResources  INTEGER ::= 7
```

```
PrepareHO-Res ::= [3] SEQUENCE {
     handoverNumber                      [0] ISDN-AddressString              OPTIONAL,
     relocationNumberList                [1]  RelocationNumberList           OPTIONAL,
     an-APDU                             [2]  AccessNetworkSignalInfo        OPTIONAL,
     multicallBearerInfo                 [3]  MulticallBearerInfo            OPTIONAL,
     multipleBearerNotSupported          NULL                                OPTIONAL,
     selectedUMTS-Algorithms             [5]  SelectedUMTS-Algorithms        OPTIONAL,
     chosenRadioResourceInformation      [6] ChosenRadioResourceInformation OPTIONAL,
     extensionContainer                  [4]  ExtensionContainer             OPTIONAL,
     ...,
     iuSelectedCodec                     [7] Codec                           OPTIONAL,
     iuAvailableCodecsList               [8] CodecList                       OPTIONAL }
```

```
SelectedUMTS-Algorithms ::= SEQUENCE {
     integrityProtectionAlgorithm        [0]  ChosenIntegrityProtectionAlgorithm   OPTIONAL,
     encryptionAlgorithm                 [1]  ChosenEncryptionAlgorithm      OPTIONAL,
     extensionContainer                  [2]  ExtensionContainer             OPTIONAL,
     ...}
```

```
ChosenIntegrityProtectionAlgorithm ::= OCTET STRING (SIZE (1))
     -- Octet contains a complete IntegrityProtectionAlgorithm data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included in the least significant bits.
```

```
ChosenEncryptionAlgorithm ::= OCTET STRING (SIZE (1))
     -- Octet contains a complete EncryptionAlgorithm data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included in the least significant bits.
```

```
ChosenRadioResourceInformation ::= SEQUENCE {
     chosenChannelInfo                   [0] ChosenChannelInfo               OPTIONAL,
     chosenSpeechVersion                 [1] ChosenSpeechVersion             OPTIONAL,
     ...}
```

```
ChosenChannelInfo ::= OCTET STRING (SIZE (1))
     -- Octets are coded according the Chosen Channel information element in 3GPP TS 48.008
```

```
ChosenSpeechVersion ::= OCTET STRING (SIZE (1))
     -- Octets are coded according the Speech Version (chosen) information element in 3GPP TS
     -- 48.008
```

```
PrepareSubsequentHO-Arg ::= [3] SEQUENCE {
     targetCellId                        [0] GlobalCellId                    OPTIONAL,
     targetMSC-Number                    [1] ISDN-AddressString,
     targetRNCId                         [2] RNCId                           OPTIONAL,
     an-APDU                             [3]  AccessNetworkSignalInfo        OPTIONAL,
     selectedRab-Id                      [4]  RAB-Id                         OPTIONAL,
     extensionContainer                  [5]  ExtensionContainer             OPTIONAL,
     ...,
     geran-classmark                     [6] GERAN-Classmark                 OPTIONAL,
     rab-ConfigurationIndicator          [7] NULL                            OPTIONAL }
```

```
PrepareSubsequentHO-Res ::= [3] SEQUENCE {
    an-APDU                          AccessNetworkSignalInfo,
    extensionContainer               [0]  ExtensionContainer          OPTIONAL,
    ...}
```

```
ProcessAccessSignalling-Arg ::= [3] SEQUENCE {
    an-APDU                          AccessNetworkSignalInfo,
    selectedUMTS-Algorithms          [1]  SelectedUMTS-Algorithms     OPTIONAL,
    selectedGSM-Algorithm            [2]  SelectedGSM-Algorithm       OPTIONAL,
    chosenRadioResourceInformation   [3] ChosenRadioResourceInformation OPTIONAL,
    selectedRab-Id                   [4] RAB-Id                       OPTIONAL,
    extensionContainer               [0]  ExtensionContainer          OPTIONAL,
    ...,
    iUSelectedCodec                  [5] Codec                        OPTIONAL,
    iuAvailableCodecsList            [6] CodecList                    OPTIONAL }
```

```
SupportedCodecsList ::= SEQUENCE {
    utranCodecList                   [0] CodecList                    OPTIONAL,
    geranCodecList                   [1] CodecList                    OPTIONAL,
    extensionContainer               [2] ExtensionContainer           OPTIONAL,
    ...}
```

```
CodecList ::= SEQUENCE {
    codec1                           [1] Codec,
    codec2                           [2] Codec                        OPTIONAL,
    codec3                           [3] Codec                        OPTIONAL,
    codec4                           [4] Codec                        OPTIONAL,
    codec5                           [5] Codec                        OPTIONAL,
    codec6                           [6] Codec                        OPTIONAL,
    codec7                           [7] Codec                        OPTIONAL,
    codec8                           [8] Codec                        OPTIONAL,
    extensionContainer               [9] ExtensionContainer           OPTIONAL,
    ...}
    -- Codecs are sent in priority order where codec1 has highest priority
```

```
Codec ::= OCTET STRING (SIZE (1..4))

    -- The internal structure is defined as follows:
    -- octet 1                       Coded as Codec Identification code in 3GPP TS 26.103
    -- octets 2,3,4                  Parameters for the Codec as defined in 3GPP TS
    --                               26.103, if available, length depending on the codec
```

```
GERAN-Classmark ::= OCTET STRING (SIZE (2..87))
    -- Octets are coded according the GERAN Classmark information element in 3GPP TS 48.008
```

```
SelectedGSM-Algorithm ::= OCTET STRING (SIZE (1))
    -- internal structure is coded as Algorithm identifier octet from Chosen Encryption
    -- Algorithm defined in 3GPP TS 48.008
    -- A node shall mark only the selected GSM algorithm
```

```
SendEndSignal-Arg ::= [3] SEQUENCE {
    an-APDU                          AccessNetworkSignalInfo,
    extensionContainer               [0]  ExtensionContainer          OPTIONAL,
    ...}
```

```
SendEndSignal-Res ::= SEQUENCE {
    extensionContainer               [0]  ExtensionContainer          OPTIONAL,
    ...}
```

```
RNCId ::= OCTET STRING (SIZE (7))
    -- The internal structure is defined as follows:
    -- octet 1 bits 4321             Mobile Country Code 1st digit
    --         bits 8765             Mobile Country Code 2nd digit
    -- octet 2 bits 4321             Mobile Country Code 3rd digit
    --         bits 8765             Mobile Network Code 3rd digit
    --                               or filler (1111) for 2 digit MNCs
    -- octet 3 bits 4321             Mobile Network Code 1st digit
    --         bits 8765             Mobile Network Code 2nd digit
    -- octets 4 and 5                Location Area Code according to 3GPP TS 24.008
    -- octets 6 and 7                RNC Id value according to 3GPP TS 25.413
```

```
RelocationNumberList ::= SEQUENCE SIZE (1..maxNumOfRelocationNumber) OF
                                     RelocationNumber
```

```
MulticallBearerInfo ::= INTEGER (1..maxNumOfRelocationNumber)
```

```
RelocationNumber ::= SEQUENCE {
     handoverNumber                         ISDN-AddressString,
     rab-Id                                 RAB-Id,
     -- RAB Identity is needed to relate the calls with the radio access bearers.
     ...}
```

```
RAB-Id ::= INTEGER (1..maxNrOfRABs)
```

```
maxNrOfRABs INTEGER ::= 255
```

```
maxNumOfRelocationNumber  INTEGER ::= 7
```

```
RadioResourceInformation ::= OCTET STRING (SIZE (3..13))
     -- Octets are coded according the Channel Type information element in 3GPP TS 48.008
```

```
IntegrityProtectionInformation ::= OCTET STRING (SIZE (18..maxNumOfIntegrityInfo))
     -- Octets contain a complete IntegrityProtectionInformation data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included, if needed, in the least significant bits of the
     -- last octet of the octet string.
```

```
maxNumOfIntegrityInfo INTEGER ::= 100
```

```
EncryptionInformation ::= OCTET STRING (SIZE (18..maxNumOfEncryptionInfo))
     -- Octets contain a complete EncryptionInformation data type
     -- as defined in 3GPP TS 25.413, encoded according to the encoding scheme
     -- mandated by 3GPP TS 25.413
     -- Padding bits are included, if needed, in the least significant bits of the
     -- last octet of the octet string.
```

```
maxNumOfEncryptionInfo INTEGER ::= 100
```

```
-- authentication management types
```

```
SendAuthenticationInfoArg ::= SEQUENCE {
     imsi                                   [0] IMSI,
     numberOfRequestedVectors               NumberOfRequestedVectors,
     segmentationProhibited                 NULL                                OPTIONAL,
     immediateResponsePreferred             [1] NULL                             OPTIONAL,
     re-synchronisationInfo                 Re-synchronisationInfo              OPTIONAL,
     extensionContainer                     [2] ExtensionContainer              OPTIONAL,
     ...,
     requestingNodeType                     [3] RequestingNodeType              OPTIONAL,
     requestingPLMN-Id                      [4] PLMN-Id                         OPTIONAL,
     numberOfRequestedAdditional-Vectors    [5] NumberOfRequestedVectors        OPTIONAL,
     additionalVectorsAreForEPS             [6] NULL                            OPTIONAL }
```

```
NumberOfRequestedVectors ::= INTEGER (1..5)
```

```
Re-synchronisationInfo ::= SEQUENCE {
     rand                                   RAND,
     auts                                   AUTS,
     ...}
```

```
SendAuthenticationInfoRes ::= [3] SEQUENCE {
     authenticationSetList                  AuthenticationSetList               OPTIONAL,
     extensionContainer                     ExtensionContainer                  OPTIONAL,
     ...,
     eps-AuthenticationSetList              [2] EPS-AuthenticationSetList       OPTIONAL }
```

```
EPS-AuthenticationSetList ::= SEQUENCE SIZE (1..5) OF
                                            EPC-AV
```

```
EPC-AV ::= SEQUENCE {
     rand                                   RAND,
     xres                                   XRES,
     autn                                   AUTN,
     kasme                                  KASME,
     extensionContainer                     ExtensionContainer                  OPTIONAL,
     ...}
```

```
KASME ::= OCTET STRING (SIZE (16))
```

```
RequestingNodeType ::= ENUMERATED {
     vlr  (0),
     sgsn  (1),
     ...,
     s-cscf  (2),
     bsf  (3),
     gan-aaa-server  (4),
     wlan-aaa-server  (5),
     mme       (16),
     mme-sgsn  (17)
     }
     -- the values 2, 3, 4 and 5 shall not be used on the MAP-D or Gr interfaces
     -- exception handling:
     -- received values in the range (6-15) shall be treated as "vlr"
     -- received values greater than 17 shall be treated as "sgsn"
```

-- equipment management types

```
CheckIMEI-Arg ::= SEQUENCE {
     imei                              IMEI,
     requestedEquipmentInfo            RequestedEquipmentInfo,
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...}
```

```
CheckIMEI-Res ::= SEQUENCE {
     equipmentStatus                   EquipmentStatus                 OPTIONAL,
     bmuef                             UESBI-Iu                        OPTIONAL,
     extensionContainer                [0] ExtensionContainer          OPTIONAL,
     ...}
```

```
RequestedEquipmentInfo::= BIT STRING {
     equipmentStatus  (0),
     bmuef  (1)} (SIZE (2..8))
     -- exception handling: reception of unknown bit assignments in the
     -- RequestedEquipmentInfo data type shall be discarded by the receiver
```

```
UESBI-Iu ::= SEQUENCE {
     uesbi-IuA [0] UESBI-IuA                                           OPTIONAL,
     uesbi-IuB [1] UESBI-IuB                                           OPTIONAL,
     ...}
```

```
UESBI-IuA                                  ::= BIT STRING (SIZE(1..128))
-- See 3GPP TS 25.413
```

```
UESBI-IuB                                  ::= BIT STRING (SIZE(1..128))
-- See 3GPP TS 25.413
```

```
EquipmentStatus ::= ENUMERATED {
     whiteListed  (0),
     blackListed  (1),
     greyListed  (2)}
```

-- subscriber management types

```
InsertSubscriberDataArg ::= SEQUENCE {
    imsi                                [0] IMSI                                OPTIONAL,
    COMPONENTS OF                       SubscriberData,
    extensionContainer                  [14] ExtensionContainer                 OPTIONAL,
    ... ,
    naea-PreferredCI                    [15] NAEA-PreferredCI                   OPTIONAL,
    -- naea-PreferredCI is included at the discretion of the HLR operator.
    gprsSubscriptionData                [16] GPRSSubscriptionData               OPTIONAL,
    roamingRestrictedInSgsnDueToUnsupportedFeature [23]                         NULL
                                                                                OPTIONAL,
    networkAccessMode                   [24] NetworkAccessMode                  OPTIONAL,
    lsaInformation                      [25] LSAInformation                     OPTIONAL,
    lmu-Indicator                       [21] NULL                               OPTIONAL,
    lcsInformation                      [22] LCSInformation                     OPTIONAL,
    istAlertTimer                       [26] IST-AlertTimerValue                OPTIONAL,
    superChargerSupportedInHLR          [27] AgeIndicator                       OPTIONAL,
    mc-SS-Info                          [28] MC-SS-Info                         OPTIONAL,
    cs-AllocationRetentionPriority      [29] CS-AllocationRetentionPriority     OPTIONAL,
    sgsn-CAMEL-SubscriptionInfo         [17] SGSN-CAMEL-SubscriptionInfo        OPTIONAL,
    chargingCharacteristics             [18] ChargingCharacteristics            OPTIONAL,
    accessRestrictionData               [19] AccessRestrictionData              OPTIONAL,
    ics-Indicator                       [20] BOOLEAN                            OPTIONAL,
    eps-SubscriptionData                [31] EPS-SubscriptionData               OPTIONAL,
    csg-SubscriptionDataList            [32] CSG-SubscriptionDataList           OPTIONAL,
    ue-ReachabilityRequestIndicator     [33] NULL                               OPTIONAL }
    -- If the Network Access Mode parameter is sent, it shall be present only in
    -- the first sequence if segmentation is used
```

```
CSG-SubscriptionDataList ::= SEQUENCE SIZE (1..50) OF
                                    CSG-SubscriptionData
```

```
CSG-SubscriptionData ::= SEQUENCE {
    csg-Id                              CSG-Id,
    expirationDate                      Time                                    OPTIONAL,
    extensionContainer                  ExtensionContainer                      OPTIONAL,
    ...}
```

```
CSG-Id ::= BIT STRING (SIZE (27))
    -- coded according to 3GPP TS 23.003 [17].
```

```
Time ::= OCTET STRING (SIZE (4))
    -- Octets are coded according to IETF RFC 3588 [139]
```

```
EPS-SubscriptionData ::= SEQUENCE {
    apn-oi-Replacement                  [0]  APN-OI-Replacement                 OPTIONAL,
    rfsp-id                             [2]  RFSP-ID                             OPTIONAL,
    ambr                                [3]  AMBR                               OPTIONAL,
    apn-ConfigurationProfile            [4]  APN-ConfigurationProfile           OPTIONAL,
    stn-sr                              [6]  ISDN-AddressString                 OPTIONAL,
    extensionContainer                  [5]  ExtensionContainer                 OPTIONAL,
    ... }
```

```
APN-OI-Replacement ::=  OCTET STRING (SIZE (9..100))
    -- Octets are coded as APN Operator Identifier according to TS 3GPP TS 23.003 [17]
```

```
RFSP-ID ::=  INTEGER (1..256)
```

```
APN-ConfigurationProfile ::= SEQUENCE {
    defaultContext                      ContextId,
    completeDataListIncluded            NULL                                    OPTIONAL,
        -- If segmentation is used, completeDataListIncluded may only be present in the
        -- first segment of APN-ConfigurationProfile.
    epsDataList                         [1]  EPS-DataList,
    extensionContainer                  [2] ExtensionContainer                  OPTIONAL,
    ... }
```

```
EPS-DataList ::= SEQUENCE SIZE (1..maxNumOfAPN-Configurations) OF
                                    APN-Configuration
```

```
maxNumOfAPN-Configurations  INTEGER ::= 50
```

```
APN-Configuration ::= SEQUENCE {
     contextId                          [0] ContextId,
     pdn-Type                           [1] PDN-Type,
     servedPartyIP-IPv4-Address         [2] PDP-Address                 OPTIONAL,
     apn                                [3] APN,
     eps-qos-Subscribed                 [4] EPS-QoS-Subscribed,
     pdn-gw-Identity                    [5] PDN-GW-Identity             OPTIONAL,
     pdn-gw-AllocationType              [6] PDN-GW-AllocationType       OPTIONAL,
     vplmnAddressAllowed                [7] NULL                        OPTIONAL,
     chargingCharacteristics            [8] ChargingCharacteristics     OPTIONAL,
     ambr                               [9] AMBR                        OPTIONAL,
     specificAPNInfoList                [10] SpecificAPNInfoList        OPTIONAL,
     extensionContainer                 [11] ExtensionContainer         OPTIONAL,
     servedPartyIP-IPv6-Address         [12] PDP-Address                OPTIONAL,
     ... }
```

```
PDN-Type ::= OCTET STRING (SIZE (1))
     -- Octet is coded according to TS 3GPP TS 29.274 [140]
```

```
EPS-QoS-Subscribed ::= SEQUENCE {
     qos-Class-Identifier               [0] QoS-Class-Identifier,
     allocation-Retention-Priority      [1] Allocation-Retention-Priority,
     extensionContainer                 [2] ExtensionContainer          OPTIONAL,
     ... }
```

```
AMBR ::= SEQUENCE {
     max-RequestedBandwidth-UL          [0] Bandwidth,
     max-RequestedBandwidth-DL          [1] Bandwidth,
     extensionContainer                 [2] ExtensionContainer          OPTIONAL,
     ... }
```

```
SpecificAPNInfoList ::= SEQUENCE SIZE (1..maxNumOfSpecificAPNInfos) OF
                                    SpecificAPNInfo
```

```
maxNumOfSpecificAPNInfos  INTEGER ::= 50
```

```
SpecificAPNInfo ::= SEQUENCE {
     apn                                [0] APN,
     pdn-gw-Identity                    [1] PDN-GW-Identity,
     extensionContainer                 [2] ExtensionContainer          OPTIONAL,
     ... }
```

```
Bandwidth ::= INTEGER
     -- bits per second
```

```
QoS-Class-Identifier ::= INTEGER (1..9)
     -- values are defined in  3GPP TS 29.212
```

```
Allocation-Retention-Priority ::= SEQUENCE {
     priority-level                     [0] INTEGER,
     pre-emption-capability             [1] BOOLEAN                     OPTIONAL,
     pre-emption-vulnerability          [2] BOOLEAN                     OPTIONAL,
     extensionContainer                 [3] ExtensionContainer          OPTIONAL,
     ... }
```

```
PDN-GW-Identity ::= SEQUENCE {
     pdn-gw-ipv4-Address                [0] PDP-Address             OPTIONAL,
     pdn-gw-ipv6-Address                [1] PDP-Address             OPTIONAL,
     pdn-gw-name                        [2] FQDN                    OPTIONAL,
     extensionContainer                 [3] ExtensionContainer      OPTIONAL,
     ... }
```

```
FQDN ::=  OCTET STRING (SIZE (9..100))
```

```
PDN-GW-AllocationType ::= ENUMERATED {
     static    (0),
     dynamic   (1)}
```

```
AccessRestrictionData ::= BIT STRING {
     utranNotAllowed (0),
     geranNotAllowed (1),
     ganNotAllowed   (2),
     i-hspa-evolutionNotAllowed (3),
     e-utranNotAllowed (4),
     ho-toNon3GPP-AccessNotAllowed (5) } (SIZE (2..8))
     -- exception handling:
     -- access restriction data related to an access type not supported by a node
     -- shall be ignored
     -- bits 6 to 7 shall be ignored if received and not understood
```

```
CS-AllocationRetentionPriority ::= OCTET STRING (SIZE (1))
     -- This data type encodes each priority level defined in TS 23.107 as the binary value
     -- of the priority level.
```

```
IST-AlertTimerValue ::= INTEGER (15..255)
```

```
LCSInformation ::= SEQUENCE {
     gmlc-List [0]                          GMLC-List OPTIONAL,
     lcs-PrivacyExceptionList               [1]  LCS-PrivacyExceptionList      OPTIONAL,
     molr-List                              [2]  MOLR-List                     OPTIONAL,
     ...,
     add-lcs-PrivacyExceptionList           [3]  LCS-PrivacyExceptionList      OPTIONAL }
     -- add-lcs-PrivacyExceptionList may be sent only if lcs-PrivacyExceptionList is
     -- present and contains four instances of LCS-PrivacyClass. If the mentioned condition
     -- is not satisfied the receiving node shall discard add-lcs-PrivacyExceptionList.
     -- If an LCS-PrivacyClass is received both in lcs-PrivacyExceptionList and in
     -- add-lcs-PrivacyExceptionList with the same SS-Code, then the error unexpected
     -- data value shall be returned.
```

```
GMLC-List ::= SEQUENCE SIZE (1..maxNumOfGMLC) OF
                                        ISDN-AddressString
     -- if segmentation is used, the complete GMLC-List shall be sent in one segment
```

```
maxNumOfGMLC  INTEGER ::= 5
```

```
NetworkAccessMode ::= ENUMERATED {
     packetAndCircuit                   (0),
     onlyCircuit                             (1),
     onlyPacket                              (2),
     ...}
     -- if unknown values are received in NetworkAccessMode
     -- they shall be discarded.
```

```
GPRSDataList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF
                                        PDP-Context
```

```
maxNumOfPDP-Contexts  INTEGER ::= 50
```

```
PDP-Context ::= SEQUENCE {
     pdp-ContextId                      ContextId,
     pdp-Type                           [16] PDP-Type,
     pdp-Address                        [17] PDP-Address                   OPTIONAL,
     qos-Subscribed                     [18] QoS-Subscribed,
     vplmnAddressAllowed                [19] NULL OPTIONAL,
     apn                                [20] APN,
     extensionContainer                 [21] ExtensionContainer            OPTIONAL,
     ... ,
     ext-QoS-Subscribed                 [0] Ext-QoS-Subscribed             OPTIONAL,
     pdp-ChargingCharacteristics        [1] ChargingCharacteristics        OPTIONAL,
     ext2-QoS-Subscribed                [2] Ext2-QoS-Subscribed            OPTIONAL,
     -- ext2-QoS-Subscribed may be present only if ext-QoS-Subscribed is present.
     ext3-QoS-Subscribed                [3] Ext3-QoS-Subscribed            OPTIONAL
     -- ext3-QoS-Subscribed may be present only if ext2-QoS-Subscribed is present.
      }
```

```
ContextId ::= INTEGER (1..maxNumOfPDP-Contexts)
```

```
GPRSSubscriptionData ::= SEQUENCE {
     completeDataListIncluded            NULL                                OPTIONAL,
          -- If segmentation is used, completeDataListIncluded may only be present in the
          -- first segment of GPRSSubscriptionData.
     gprsDataList                        [1]  GPRSDataList,
     extensionContainer                  [2] ExtensionContainer              OPTIONAL,
     ... }
```

```
SGSN-CAMEL-SubscriptionInfo ::= SEQUENCE {
     gprs-CSI                            [0]  GPRS-CSI                       OPTIONAL,
     mo-sms-CSI                          [1]  SMS-CSI                        OPTIONAL,
     extensionContainer                  [2]  ExtensionContainer             OPTIONAL,
     ...,
     mt-sms-CSI                          [3]  SMS-CSI                        OPTIONAL,
     mt-smsCAMELTDP-CriteriaList         [4]  MT-smsCAMELTDP-CriteriaList    OPTIONAL,
     mg-csi                              [5]  MG-CSI                         OPTIONAL
     }
```

```
GPRS-CSI ::= SEQUENCE {
     gprs-CamelTDPDataList               [0] GPRS-CamelTDPDataList           OPTIONAL,
     camelCapabilityHandling             [1] CamelCapabilityHandling         OPTIONAL,
     extensionContainer                  [2] ExtensionContainer              OPTIONAL,
     notificationToCSE                   [3]  NULL                           OPTIONAL,
     csi-Active                          [4]  NULL                           OPTIONAL,
     ...}
--   notificationToCSE and csi-Active shall not be present when GPRS-CSI is sent to SGSN.
--   They may only be included in ATSI/ATM ack/NSDC message.
--   GPRS-CamelTDPData and  camelCapabilityHandling shall be present in
--   the GPRS-CSI sequence.
--   If GPRS-CSI is segmented, gprs-CamelTDPDataList and camelCapabilityHandling shall be
--   present in the first segment
```

```
GPRS-CamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     GPRS-CamelTDPData
--   GPRS-CamelTDPDataList shall not contain more than one instance of
--   GPRS-CamelTDPData containing the same value for gprs-TriggerDetectionPoint.
```

```
GPRS-CamelTDPData ::= SEQUENCE {
     gprs-TriggerDetectionPoint          [0] GPRS-TriggerDetectionPoint,
     serviceKey                          [1] ServiceKey,
     gsmSCF-Address                      [2] ISDN-AddressString,
     defaultSessionHandling              [3] DefaultGPRS-Handling,
     extensionContainer                  [4] ExtensionContainer              OPTIONAL,
     ...
     }
```

```
DefaultGPRS-Handling ::= ENUMERATED {
     continueTransaction (0) ,
     releaseTransaction (1) ,
     ...}
-- exception handling:
-- reception of values in range 2-31 shall be treated as "continueTransaction"
-- reception of values greater than 31 shall be treated as "releaseTransaction"
```

```
GPRS-TriggerDetectionPoint ::= ENUMERATED {
     attach                                  (1),
     attachChangeOfPosition                  (2),
     pdp-ContextEstablishment                (11),
     pdp-ContextEstablishmentAcknowledgement (12),
     pdp-ContextChangeOfPosition             (14),
     ... }
-- exception handling:
-- For GPRS-CamelTDPData sequences containing this parameter with any
-- other value than the ones listed the receiver shall ignore the whole
-- GPRS-CamelTDPDatasequence.
```

```
APN ::=  OCTET STRING (SIZE (2..63))
     -- Octets are coded according to TS 3GPP TS 23.003 [17]
```

```
PDP-Type ::= OCTET STRING (SIZE (2))
     -- Octets are coded according to TS 3GPP TS 29.060 [105]
```

```
PDP-Address ::= OCTET STRING (SIZE (1..16))
     -- Octets are coded according to TS 3GPP TS 29.060 [105]

     -- The possible size values are:
     -- 1-7 octets  X.25 address type
     --  4  octets  IPv4 address type
     -- 16  octets  Ipv6 address type
```

```
QoS-Subscribed ::= OCTET STRING (SIZE (3))
     -- Octets are coded according to TS 3GPP TS 24.008 [35] Quality of Service Octets
     -- 3-5.
```

```
Ext-QoS-Subscribed ::= OCTET STRING (SIZE (1..9))
     -- OCTET 1:
     --  Allocation/Retention Priority (This octet encodes each priority level defined in
     --     23.107 as the binary value of the priority level, declaration in 29.060)
     -- Octets 2-9 are coded according to 3GPP TS 24.008 [35] Quality of Service Octets
     -- 6-13.
```

```
Ext2-QoS-Subscribed ::= OCTET STRING (SIZE (1..3))
     -- Octets 1-3 are coded according to 3GPP TS 24.008 [35] Quality of Service Octets 14-16.
     -- If Quality of Service information is structured with 14 octet length, then
     -- Octet 1 is coded according to 3GPP TS 24.008 [35] Quality of Service Octet 14.
```

```
Ext3-QoS-Subscribed ::= OCTET STRING (SIZE (1..2))
     -- Octets 1-2 are coded according to 3GPP TS 24.008 [35] Quality of Service Octets 17-18.
```

```
ChargingCharacteristics ::= OCTET STRING (SIZE (2))
     -- Octets are coded according to 3GPP TS 32.215.
```

```
LSAOnlyAccessIndicator ::= ENUMERATED {
     accessOutsideLSAsAllowed  (0),
     accessOutsideLSAsRestricted (1)}
```

```
LSADataList ::= SEQUENCE SIZE (1..maxNumOfLSAs) OF
                                        LSAData
```

```
maxNumOfLSAs  INTEGER ::= 20
```

```
LSAData ::= SEQUENCE {
     lsaIdentity                    [0] LSAIdentity,
     lsaAttributes                  [1] LSAAttributes,
     lsaActiveModeIndicator         [2] NULL                    OPTIONAL,
     extensionContainer             [3] ExtensionContainer      OPTIONAL,
     ...}
```

```
LSAInformation ::= SEQUENCE {
     completeDataListIncluded       NULL                        OPTIONAL,

          -- If segmentation is used, completeDataListIncluded may only be present in the
          -- first segment.
     lsaOnlyAccessIndicator         [1]  LSAOnlyAccessIndicator  OPTIONAL,
     lsaDataList                    [2]  LSADataList             OPTIONAL,
     extensionContainer             [3] ExtensionContainer       OPTIONAL,
     ...}
```

```
LSAIdentity ::= OCTET STRING (SIZE (3))
     -- Octets are coded according to TS 3GPP TS 23.003 [17]
```

```
LSAAttributes ::= OCTET STRING (SIZE (1))
     -- Octets are coded according to TS 3GPP TS 48.008 [49]
```

```
SubscriberData ::= SEQUENCE {
    msisdn                                  [1] ISDN-AddressString            OPTIONAL,
    category                                [2] Category                      OPTIONAL,
    subscriberStatus                        [3] SubscriberStatus              OPTIONAL,
    bearerServiceList                       [4] BearerServiceList             OPTIONAL,
    -- The exception handling for reception of unsupported / not allocated
    -- bearerServiceCodes is defined in section 8.8.1
    teleserviceList                         [6] TeleserviceList               OPTIONAL,
    -- The exception handling for reception of unsupported / not allocated
    -- teleserviceCodes is defined in section 8.8.1
    provisionedSS                           [7] Ext-SS-InfoList               OPTIONAL,
    odb-Data                                [8] ODB-Data                      OPTIONAL,
    roamingRestrictionDueToUnsupportedFeature  [9] NULL                       OPTIONAL,
    regionalSubscriptionData                [10] ZoneCodeList                 OPTIONAL,
    vbsSubscriptionData                     [11] VBSDataList                  OPTIONAL,
    vgcsSubscriptionData                    [12] VGCSDataList                 OPTIONAL,
    vlrCamelSubscriptionInfo                [13] VlrCamelSubscriptionInfo     OPTIONAL
    }
```

```
Category ::= OCTET STRING (SIZE (1))
    -- The internal structure is defined in ITU-T Rec Q.763.
```

```
SubscriberStatus ::= ENUMERATED {
    serviceGranted  (0),
    operatorDeterminedBarring  (1)}
```

```
BearerServiceList ::= SEQUENCE SIZE (1..maxNumOfBearerServices) OF
                                    Ext-BearerServiceCode
```

```
maxNumOfBearerServices  INTEGER ::= 50
```

```
TeleserviceList ::= SEQUENCE SIZE (1..maxNumOfTeleservices) OF
                                    Ext-TeleserviceCode
```

```
maxNumOfTeleservices  INTEGER ::= 20
```

```
ODB-Data ::= SEQUENCE {
    odb-GeneralData                     ODB-GeneralData,
    odb-HPLMN-Data                      ODB-HPLMN-Data                    OPTIONAL,
    extensionContainer                  ExtensionContainer                OPTIONAL,
    ...}
```

```
ODB-GeneralData ::= BIT STRING {
     allOG-CallsBarred  (0),
     internationalOGCallsBarred  (1),
     internationalOGCallsNotToHPLMN-CountryBarred  (2),
     interzonalOGCallsBarred (6),
     interzonalOGCallsNotToHPLMN-CountryBarred (7),
     interzonalOGCallsAndInternationalOGCallsNotToHPLMN-CountryBarred (8),
     premiumRateInformationOGCallsBarred  (3),
     premiumRateEntertainementOGCallsBarred  (4),
     ss-AccessBarred  (5),
     allECT-Barred (9),
     chargeableECT-Barred (10),
     internationalECT-Barred (11),
     interzonalECT-Barred (12),
     doublyChargeableECT-Barred (13),
     multipleECT-Barred (14),
     allPacketOrientedServicesBarred (15),
     roamerAccessToHPLMN-AP-Barred  (16),
     roamerAccessToVPLMN-AP-Barred  (17),
     roamingOutsidePLMNOG-CallsBarred  (18),
     allIC-CallsBarred  (19),
     roamingOutsidePLMNIC-CallsBarred  (20),
     roamingOutsidePLMNICountryIC-CallsBarred  (21),
     roamingOutsidePLMN-Barred  (22),
     roamingOutsidePLMN-CountryBarred  (23),
     registrationAllCF-Barred  (24),
     registrationCFNotToHPLMN-Barred  (25),
     registrationInterzonalCF-Barred  (26),
     registrationInterzonalCFNotToHPLMN-Barred  (27),
     registrationInternationalCF-Barred  (28)} (SIZE (15..32))
     -- exception handling: reception of unknown bit assignments in the
     -- ODB-GeneralData type shall be treated like unsupported ODB-GeneralData
     -- When the ODB-GeneralData type is removed from the HLR for a given subscriber,
     -- in NoteSubscriberDataModified operation sent toward the gsmSCF
     -- all bits shall be set to '0'.
```

```
ODB-HPLMN-Data ::= BIT STRING {
     plmn-SpecificBarringType1  (0),
     plmn-SpecificBarringType2  (1),
     plmn-SpecificBarringType3  (2),
     plmn-SpecificBarringType4  (3)} (SIZE (4..32))
     -- exception handling: reception of unknown bit assignments in the
     -- ODB-HPLMN-Data type shall be treated like unsupported ODB-HPLMN-Data
     -- When the ODB-HPLMN-Data type is removed from the HLR for a given subscriber,
     -- in NoteSubscriberDataModified operation sent toward the gsmSCF
     -- all bits shall be set to '0'.
```

```
Ext-SS-InfoList ::= SEQUENCE SIZE (1..maxNumOfSS) OF
                                    Ext-SS-Info
```

```
Ext-SS-Info ::= CHOICE {
     forwardingInfo                  [0] Ext-ForwInfo,
     callBarringInfo                 [1] Ext-CallBarInfo,
     cug-Info                        [2] CUG-Info,
     ss-Data                         [3] Ext-SS-Data,
     emlpp-Info                      [4] EMLPP-Info}
```

```
Ext-ForwInfo ::= SEQUENCE {
     ss-Code                         SS-Code,
     forwardingFeatureList           Ext-ForwFeatureList,
     extensionContainer              [0] ExtensionContainer          OPTIONAL,
     ...}
```

```
Ext-ForwFeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
                                    Ext-ForwFeature
```

```
Ext-ForwFeature ::= SEQUENCE {
    basicService                    Ext-BasicServiceCode            OPTIONAL,
    ss-Status                       [4] Ext-SS-Status,
    forwardedToNumber               [5] ISDN-AddressString          OPTIONAL,
    -- When this data type is sent from an HLR which supports CAMEL Phase 2
    -- to a VLR that supports CAMEL Phase 2 the VLR shall not check the
    -- format of the number
    forwardedToSubaddress           [8] ISDN-SubaddressString       OPTIONAL,
    forwardingOptions               [6] Ext-ForwOptions             OPTIONAL,
    noReplyConditionTime            [7] Ext-NoRepCondTime           OPTIONAL,
    extensionContainer              [9] ExtensionContainer          OPTIONAL,
    ...,
    longForwardedToNumber           [10] FTN-AddressString          OPTIONAL }
```

```
Ext-ForwOptions ::= OCTET STRING (SIZE (1..5))

    -- OCTET 1:

    --  bit 8: notification to forwarding party
    --   0  no notification
    --   1  notification

    --  bit 7: redirecting presentation
    --   0 no presentation
    --   1  presentation

    --  bit 6: notification to calling party
    --   0  no notification
    --   1  notification

    --  bit 5: 0 (unused)

    --  bits 43: forwarding reason
    --   00  ms not reachable
    --   01  ms busy
    --   10  no reply
    --   11  unconditional

    -- bits 21: 00 (unused)

    -- OCTETS 2-5: reserved for future use. They shall be discarded if
    -- received and not understood.
```

```
Ext-NoRepCondTime ::= INTEGER (1..100)
    -- Only values 5-30 are used.
    -- Values in the ranges 1-4 and 31-100 are reserved for future use
    -- If received:
    --       values 1-4 shall be mapped on to value 5
    --       values 31-100 shall be mapped on to value 30
```

```
Ext-CallBarInfo ::= SEQUENCE {
    ss-Code                         SS-Code,
    callBarringFeatureList          Ext-CallBarFeatureList,
    extensionContainer              ExtensionContainer              OPTIONAL,
    ...}
```

```
Ext-CallBarFeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
                                    Ext-CallBarringFeature
```

```
Ext-CallBarringFeature ::= SEQUENCE {
    basicService                    Ext-BasicServiceCode            OPTIONAL,
    ss-Status                       [4] Ext-SS-Status,
    extensionContainer              ExtensionContainer              OPTIONAL,
    ...}
```

```
CUG-Info ::= SEQUENCE {
    cug-SubscriptionList            CUG-SubscriptionList,
    cug-FeatureList                 CUG-FeatureList                 OPTIONAL,
    extensionContainer              [0] ExtensionContainer          OPTIONAL,
    ...}
```

```
CUG-SubscriptionList ::= SEQUENCE SIZE (0..maxNumOfCUG) OF
                                    CUG-Subscription
```

```
CUG-Subscription ::= SEQUENCE {
     cug-Index CUG-Index,
     cug-Interlock                    CUG-Interlock,
     intraCUG-Options                 IntraCUG-Options,
     basicServiceGroupList            Ext-BasicServiceGroupList         OPTIONAL,
     extensionContainer               [0] ExtensionContainer            OPTIONAL,
     ...}
```

```
CUG-Index ::= INTEGER (0..32767)
     -- The internal structure is defined in ETS 300 138.
```

```
CUG-Interlock ::= OCTET STRING (SIZE (4))
```

```
IntraCUG-Options ::= ENUMERATED {
     noCUG-Restrictions  (0),
     cugIC-CallBarred  (1),
     cugOG-CallBarred  (2)}
```

```
maxNumOfCUG  INTEGER ::= 10
```

```
CUG-FeatureList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
                                      CUG-Feature
```

```
Ext-BasicServiceGroupList ::= SEQUENCE SIZE (1..maxNumOfExt-BasicServiceGroups) OF
                                      Ext-BasicServiceCode
```

```
maxNumOfExt-BasicServiceGroups  INTEGER ::= 32
```

```
CUG-Feature ::= SEQUENCE {
     basicService                     Ext-BasicServiceCode              OPTIONAL,
     preferentialCUG-Indicator        CUG-Index OPTIONAL,
     interCUG-Restrictions            InterCUG-Restrictions,
     extensionContainer               ExtensionContainer                OPTIONAL,
     ...}
```

```
InterCUG-Restrictions ::= OCTET STRING (SIZE (1))

     -- bits 876543: 000000 (unused)
     -- Exception handling:
     -- bits 876543 shall be ignored if received and not understood

     -- bits 21
     --   00  CUG only facilities
     --   01  CUG with outgoing access
     --   10  CUG with incoming access
     --   11  CUG with both outgoing and incoming access
```

```
Ext-SS-Data ::= SEQUENCE {
     ss-Code                          SS-Code,
     ss-Status [4] Ext-SS-Status,
     ss-SubscriptionOption            SS-SubscriptionOption             OPTIONAL,
     basicServiceGroupList            Ext-BasicServiceGroupList         OPTIONAL,
     extensionContainer               [5] ExtensionContainer            OPTIONAL,
     ...}
```

```
LCS-PrivacyExceptionList ::= SEQUENCE SIZE (1..maxNumOfPrivacyClass) OF
                                      LCS-PrivacyClass
```

```
maxNumOfPrivacyClass  INTEGER ::= 4
```

```
LCS-PrivacyClass ::= SEQUENCE {
     ss-Code                              SS-Code,
     ss-Status                            Ext-SS-Status,
     notificationToMSUser                 [0] NotificationToMSUser          OPTIONAL,
     -- notificationToMSUser may be sent only for SS-codes callSessionRelated
     -- and callSessionUnrelated. If not received for SS-codes callSessionRelated
     -- and callSessionUnrelated,
     -- the default values according to 3GPP TS 23.271 shall be assumed.
     externalClientList                   [1] ExternalClientList            OPTIONAL,
     -- externalClientList may be sent only for SS-code callSessionUnrelated to a
     -- visited node that does not support LCS Release 4 or later versions.
     -- externalClientList may be sent only for SS-codes callSessionUnrelated and
     -- callSessionRelated to a visited node that supports LCS Release 4 or later versions.
     plmnClientList                       [2] PLMNClientList                OPTIONAL,
     -- plmnClientList may be sent only for SS-code plmnoperator.
     extensionContainer                   [3] ExtensionContainer            OPTIONAL,
     ...,
     ext-externalClientList               [4] Ext-ExternalClientList        OPTIONAL,
     -- Ext-externalClientList may be sent only if the visited node supports LCS Release 4 or
     -- later versions, the user did specify more than 5 clients, and White Book SCCP is used.
     serviceTypeList                      [5]  ServiceTypeList              OPTIONAL
     -- serviceTypeList may be sent only for SS-code serviceType and if the visited node
     -- supports LCS Release 5 or later versions.
     --
     -- if segmentation is used, the complete LCS-PrivacyClass shall be sent in one segment
}
```

```
ExternalClientList ::= SEQUENCE SIZE (0..maxNumOfExternalClient) OF
                                     ExternalClient
```

```
maxNumOfExternalClient  INTEGER ::= 5
```

```
PLMNClientList ::= SEQUENCE SIZE (1..maxNumOfPLMNClient) OF
                                     LCSClientInternalID
```

```
maxNumOfPLMNClient  INTEGER ::= 5
```

```
Ext-ExternalClientList ::= SEQUENCE SIZE (1..maxNumOfExt-ExternalClient) OF
                                     ExternalClient
```

```
maxNumOfExt-ExternalClient  INTEGER ::= 35
```

```
ExternalClient ::= SEQUENCE {
     clientIdentity                       LCSClientExternalID,
     gmlc-Restriction                     [0] GMLC-Restriction              OPTIONAL,
     notificationToMSUser                 [1] NotificationToMSUser          OPTIONAL,
     -- If notificationToMSUser is not received, the default value according to
     -- 3GPP TS 23.271 shall be assumed.
     extensionContainer                   [2] ExtensionContainer            OPTIONAL,
     ... }
```

```
GMLC-Restriction ::= ENUMERATED {
     gmlc-List                            (0),
     home-Country                         (1) ,
     ... }
-- exception handling:
-- At reception of any other value than the ones listed the receiver shall ignore
-- GMLC-Restriction.
```

```
NotificationToMSUser ::= ENUMERATED {
     notifyLocationAllowed                (0),
     notifyAndVerify-LocationAllowedIfNoResponse   (1),
     notifyAndVerify-LocationNotAllowedIfNoResponse(2),
     ...,
     locationNotAllowed (3) }
-- exception handling:
-- At reception of any other value than the ones listed the receiver shall ignore
-- NotificationToMSUser.
```

```
ServiceTypeList ::= SEQUENCE SIZE (1..maxNumOfServiceType) OF
                                     ServiceType
```

```
maxNumOfServiceType  INTEGER ::= 32
```

```
ServiceType ::= SEQUENCE {
     serviceTypeIdentity                LCSServiceTypeID,
     gmlc-Restriction                   [0] GMLC-Restriction              OPTIONAL,
     notificationToMSUser               [1] NotificationToMSUser          OPTIONAL,
     -- If notificationToMSUser is not received, the default value according to
     -- 3GPP TS 23.271 shall be assumed.
     extensionContainer                 [2] ExtensionContainer            OPTIONAL,
     ... }
```

```
MOLR-List ::= SEQUENCE SIZE (1..maxNumOfMOLR-Class) OF
                                        MOLR-Class
```

```
maxNumOfMOLR-Class  INTEGER ::= 3
```

```
MOLR-Class ::= SEQUENCE {
     ss-Code                            SS-Code,
     ss-Status                          Ext-SS-Status,
     extensionContainer                 [0] ExtensionContainer            OPTIONAL,
     ...}
```

```
ZoneCodeList ::= SEQUENCE SIZE (1..maxNumOfZoneCodes)
                                        OF ZoneCode
```

```
ZoneCode ::= OCTET STRING (SIZE (2))
     -- internal structure is defined in TS 3GPP TS 23.003 [17]
```

```
maxNumOfZoneCodes  INTEGER ::= 10
```

```
InsertSubscriberDataRes ::= SEQUENCE {
     teleserviceList                    [1] TeleserviceList               OPTIONAL,
     bearerServiceList                  [2] BearerServiceList             OPTIONAL,
     ss-List                            [3] SS-List                       OPTIONAL,
     odb-GeneralData                    [4] ODB-GeneralData               OPTIONAL,
     regionalSubscriptionResponse       [5] RegionalSubscriptionResponse  OPTIONAL,
     supportedCamelPhases               [6] SupportedCamelPhases          OPTIONAL,
     extensionContainer                 [7] ExtensionContainer            OPTIONAL,
     ... ,
     offeredCamel4CSIs                  [8] OfferedCamel4CSIs             OPTIONAL,
     supportedFeatures                  [9] SupportedFeatures             OPTIONAL }
```

```
RegionalSubscriptionResponse ::= ENUMERATED {
     networkNode-AreaRestricted         (0),
     tooManyZoneCodes                   (1),
     zoneCodesConflict                  (2),
     regionalSubscNotSupported          (3)}
```

```
DeleteSubscriberDataArg ::= SEQUENCE {
     imsi                               [0] IMSI,
     basicServiceList                   [1] BasicServiceList              OPTIONAL,
     -- The exception handling for reception of unsupported/not allocated
     -- basicServiceCodes is defined in section 6.8.2
     ss-List                            [2] SS-List                       OPTIONAL,
     roamingRestrictionDueToUnsupportedFeature [4] NULL                   OPTIONAL,
     regionalSubscriptionIdentifier     [5] ZoneCode                      OPTIONAL,
     vbsGroupIndication                 [7] NULL                          OPTIONAL,
     vgcsGroupIndication                [8] NULL                          OPTIONAL,
     camelSubscriptionInfoWithdraw      [9] NULL                          OPTIONAL,
     extensionContainer                 [6] ExtensionContainer            OPTIONAL,
     ...,
     gprsSubscriptionDataWithdraw       [10] GPRSSubscriptionDataWithdraw OPTIONAL,
     roamingRestrictedInSgsnDueToUnsuppportedFeature [11] NULL            OPTIONAL,
     lsaInformationWithdraw             [12] LSAInformationWithdraw       OPTIONAL,
     gmlc-ListWithdraw                  [13] NULL                         OPTIONAL,
     istInformationWithdraw             [14] NULL                         OPTIONAL,
     specificCSI-Withdraw               [15] SpecificCSI-Withdraw         OPTIONAL,
     chargingCharacteristicsWithdraw    [16] NULL                         OPTIONAL,
     stn-srWithdraw                     [17] NULL                         OPTIONAL,
     epsSubscriptionDataWithdraw        [18] EPS-SubscriptionDataWithdraw  OPTIONAL,
     apn-oi-replacementWithdraw         [19] NULL                         OPTIONAL,
     csg-SubscriptionDeleted            [20] NULL                         OPTIONAL }
```

```
SpecificCSI-Withdraw ::= BIT STRING {
     o-csi (0),
     ss-csi (1),
     tif-csi (2),
     d-csi (3),
     vt-csi (4),
     mo-sms-csi (5),
     m-csi (6),
     gprs-csi (7),
     t-csi (8),
     mt-sms-csi (9),
     mg-csi (10),
     o-IM-CSI (11),
     d-IM-CSI (12),
     vt-IM-CSI (13) } (SIZE(8..32))
-- exception handling:
-- bits 11 to 31 shall be ignored if received by a non-IP Multimedia Core Network entity.
-- bits 0-10 and 14-31 shall be ignored if received by an IP Multimedia Core Network entity.
-- bits 11-13 are only applicable in an IP Multimedia Core Network.
-- Bit 8 and bits 11-13 are only applicable for the NoteSubscriberDataModified operation.
```

```
GPRSSubscriptionDataWithdraw ::= CHOICE {
     allGPRSData                         NULL,
     contextIdList                       ContextIdList}
```

```
EPS-SubscriptionDataWithdraw ::= CHOICE {
     allEPS-Data                         NULL,
     contextIdList                       ContextIdList}
```

```
ContextIdList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF
                                         ContextId
```

```
LSAInformationWithdraw ::= CHOICE {
     allLSAData                          NULL,
     lsaIdentityList                     LSAIdentityList }
```

```
LSAIdentityList ::= SEQUENCE SIZE (1..maxNumOfLSAs) OF
                                         LSAIdentity
```

```
BasicServiceList ::= SEQUENCE SIZE (1..maxNumOfBasicServices) OF
                                         Ext-BasicServiceCode
```

```
maxNumOfBasicServices  INTEGER ::= 70
```

```
DeleteSubscriberDataRes ::= SEQUENCE {
     regionalSubscriptionResponse        [0] RegionalSubscriptionResponse  OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
VlrCamelSubscriptionInfo ::= SEQUENCE {
     o-CSI                               [0] O-CSI                         OPTIONAL,
     extensionContainer                  [1] ExtensionContainer            OPTIONAL,
     ...,
     ss-CSI                              [2] SS-CSI                        OPTIONAL,
     o-BcsmCamelTDP-CriteriaList         [4] O-BcsmCamelTDPCriteriaList    OPTIONAL,
     tif-CSI                             [3] NULL                          OPTIONAL,
     m-CSI                               [5] M-CSI                         OPTIONAL,
     mo-sms-CSI                          [6] SMS-CSI                       OPTIONAL,
     vt-CSI                              [7] T-CSI                         OPTIONAL,
     t-BCSM-CAMEL-TDP-CriteriaList       [8] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
     d-CSI                               [9] D-CSI                         OPTIONAL,
     mt-sms-CSI                          [10] SMS-CSI                      OPTIONAL,
     mt-smsCAMELTDP-CriteriaList         [11] MT-smsCAMELTDP-CriteriaList  OPTIONAL
     }
```

```
MT-smsCAMELTDP-CriteriaList ::= SEQUENCE SIZE (1.. maxNumOfCamelTDPData) OF
     MT-smsCAMELTDP-Criteria
```

```
MT-smsCAMELTDP-Criteria ::= SEQUENCE {
     sms-TriggerDetectionPoint           SMS-TriggerDetectionPoint,
     tpdu-TypeCriterion                  [0]  TPDU-TypeCriterion           OPTIONAL,
     ... }
```

```
TPDU-TypeCriterion ::= SEQUENCE SIZE (1..maxNumOfTPDUTypes) OF
     MT-SMS-TPDU-Type
```

```
maxNumOfTPDUTypes INTEGER ::= 5
```

```
MT-SMS-TPDU-Type ::= ENUMERATED {
     sms-DELIVER                          (0),
     sms-SUBMIT-REPORT                    (1),
     sms-STATUS-REPORT                    (2),
     ... }

--   exception handling:
--   For TPDU-TypeCriterion sequences containing this parameter with any
--   other value than the ones listed above the receiver shall ignore
--   the whole TPDU-TypeCriterion sequence.
--   In CAMEL phase 4, sms-SUBMIT-REPORT shall not be used and a received TPDU-TypeCriterion
--   sequence containing sms-SUBMIT-REPORT shall be wholly ignored.
```

```
D-CSI ::= SEQUENCE {
     dp-AnalysedInfoCriteriaList          [0] DP-AnalysedInfoCriteriaList   OPTIONAL,
     camelCapabilityHandling              [1] CamelCapabilityHandling       OPTIONAL,
     extensionContainer                   [2] ExtensionContainer            OPTIONAL,
     notificationToCSE                    [3]  NULL                         OPTIONAL,
     csi-Active                           [4]  NULL                         OPTIONAL,
     ...}
--   notificationToCSE and csi-Active shall not be present when D-CSI is sent to VLR/GMSC.
--   They may only be included in ATSI/ATM ack/NSDC message.
--   DP-AnalysedInfoCriteria and  camelCapabilityHandling shall be present in
--   the D-CSI sequence.
--   If D-CSI is segmented, then the first segment shall contain dp-AnalysedInfoCriteriaList
--   and camelCapabilityHandling. Subsequent segments shall not contain
--   camelCapabilityHandling, but may contain dp-AnalysedInfoCriteriaList.
```

```
DP-AnalysedInfoCriteriaList  ::= SEQUENCE SIZE (1..maxNumOfDP-AnalysedInfoCriteria) OF
                                 DP-AnalysedInfoCriterium
```

```
maxNumOfDP-AnalysedInfoCriteria INTEGER ::= 10
```

```
DP-AnalysedInfoCriterium ::= SEQUENCE {
     dialledNumber                        ISDN-AddressString,
     serviceKey                           ServiceKey,
     gsmSCF-Address                       ISDN-AddressString,
     defaultCallHandling                  DefaultCallHandling,
     extensionContainer                   ExtensionContainer                OPTIONAL,
     ...}
```

```
SS-CSI ::= SEQUENCE {
     ss-CamelData                         SS-CamelData,
     extensionContainer                   ExtensionContainer                OPTIONAL,
     ...,
     notificationToCSE                    [0]  NULL                         OPTIONAL,
     csi-Active                           [1]  NULL                         OPTIONAL
--   notificationToCSE and csi-Active shall not be present when SS-CSI is sent to VLR.
--   They may only be included in ATSI/ATM ack/NSDC message.
}
```

```
SS-CamelData  ::= SEQUENCE {
     ss-EventList                         SS-EventList,
     gsmSCF-Address                       ISDN-AddressString,
     extensionContainer                   [0] ExtensionContainer            OPTIONAL,
     ...}
```

```
SS-EventList  ::= SEQUENCE SIZE (1..maxNumOfCamelSSEvents) OF SS-Code
     -- Actions for the following SS-Code values are defined in CAMEL Phase 3:
     -- ect                               SS-Code ::= '00110001'B
     -- multiPTY                          SS-Code ::= '01010001'B
     -- cd                                SS-Code ::= '00100100'B
     -- ccbs                              SS-Code ::= '01000100'B
     -- all other SS codes shall be ignored
     -- When SS-CSI is sent to the VLR, it shall not contain a marking for ccbs.
     -- If the VLR receives SS-CSI containing a marking for ccbs, the VLR shall discard the
     -- ccbs marking in SS-CSI.
```

```
maxNumOfCamelSSEvents INTEGER ::= 10
```

```
O-CSI ::= SEQUENCE {
     o-BcsmCamelTDPDataList              O-BcsmCamelTDPDataList,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     camelCapabilityHandling             [0] CamelCapabilityHandling       OPTIONAL,
     notificationToCSE                   [1]  NULL                         OPTIONAL,
     csiActive                           [2]  NULL                         OPTIONAL}
--   notificationtoCSE and csiActive shall not be present when O-CSI is sent to VLR/GMSC.
--   They may only be included in ATSI/ATM ack/NSDC message.
--   O-CSI shall not be segmented.
```

```
O-BcsmCamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     O-BcsmCamelTDPData
     -- O-BcsmCamelTDPDataList shall not contain more than one instance of
     -- O-BcsmCamelTDPData containing the same value for o-BcsmTriggerDetectionPoint.
     -- For CAMEL Phase 2, this means that only one instance of O-BcsmCamelTDPData is allowed
     -- with o-BcsmTriggerDetectionPoint being equal to DP2.
```

```
maxNumOfCamelTDPData  INTEGER ::= 10
```

```
O-BcsmCamelTDPData ::= SEQUENCE {
     o-BcsmTriggerDetectionPoint         O-BcsmTriggerDetectionPoint,
     serviceKey                          ServiceKey,
     gsmSCF-Address                      [0] ISDN-AddressString,
     defaultCallHandling                 [1] DefaultCallHandling,
     extensionContainer                  [2] ExtensionContainer            OPTIONAL,
     ...
     }
```

```
ServiceKey ::= INTEGER (0..2147483647)
```

```
O-BcsmTriggerDetectionPoint ::= ENUMERATED {
     collectedInfo (2),
     ...,
     routeSelectFailure (4) }
     -- exception handling:
     -- For O-BcsmCamelTDPData sequences containing this parameter with any
     -- other value than the ones listed the receiver shall ignore the whole
     -- O-BcsmCamelTDPDatasequence.
     -- For O-BcsmCamelTDP-Criteria sequences containing this parameter with any
     -- other value than the ones listed the receiver shall ignore the whole
     -- O-BcsmCamelTDP-Criteria sequence.
```

```
O-BcsmCamelTDPCriteriaList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     O-BcsmCamelTDP-Criteria
```

```
T-BCSM-CAMEL-TDP-CriteriaList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     T-BCSM-CAMEL-TDP-Criteria
```

```
O-BcsmCamelTDP-Criteria ::= SEQUENCE {
     o-BcsmTriggerDetectionPoint         O-BcsmTriggerDetectionPoint,
     destinationNumberCriteria           [0] DestinationNumberCriteria     OPTIONAL,
     basicServiceCriteria                [1] BasicServiceCriteria          OPTIONAL,
     callTypeCriteria                    [2] CallTypeCriteria              OPTIONAL,
     ...,
     o-CauseValueCriteria                [3] O-CauseValueCriteria          OPTIONAL,
     extensionContainer                  [4] ExtensionContainer            OPTIONAL }
```

```
T-BCSM-CAMEL-TDP-Criteria ::= SEQUENCE {
     t-BCSM-TriggerDetectionPoint       T-BcsmTriggerDetectionPoint,
     basicServiceCriteria                [0] BasicServiceCriteria          OPTIONAL,
     t-CauseValueCriteria                [1] T-CauseValueCriteria          OPTIONAL,
     ... }
```

```
DestinationNumberCriteria  ::= SEQUENCE {
     matchType                           [0] MatchType,
     destinationNumberList               [1] DestinationNumberList         OPTIONAL,
     destinationNumberLengthList         [2] DestinationNumberLengthList   OPTIONAL,
     -- one or both of destinationNumberList and destinationNumberLengthList
     -- shall be present
     ...}
```

```
DestinationNumberList  ::= SEQUENCE SIZE (1..maxNumOfCamelDestinationNumbers) OF
                                    ISDN-AddressString
     -- The receiving entity shall not check the format of a number in
     -- the dialled number list
```

```
DestinationNumberLengthList  ::= SEQUENCE SIZE (1..maxNumOfCamelDestinationNumberLengths) OF
                                        INTEGER(1..maxNumOfISDN-AddressDigits)
```

```
BasicServiceCriteria   ::= SEQUENCE SIZE(1..maxNumOfCamelBasicServiceCriteria) OF
     Ext-BasicServiceCode
```

```
maxNumOfISDN-AddressDigits  INTEGER ::= 15
```

```
maxNumOfCamelDestinationNumbers  INTEGER ::= 10
```

```
maxNumOfCamelDestinationNumberLengths  INTEGER ::= 3
```

```
maxNumOfCamelBasicServiceCriteria  INTEGER ::= 5
```

```
CallTypeCriteria       ::= ENUMERATED {
     forwarded                          (0),
     notForwarded                       (1)}
```

```
MatchType       ::= ENUMERATED {
     inhibiting                         (0),
     enabling                           (1)}
```

```
O-CauseValueCriteria   ::= SEQUENCE SIZE(1..maxNumOfCAMEL-O-CauseValueCriteria) OF
     CauseValue
```

```
T-CauseValueCriteria   ::= SEQUENCE SIZE(1..maxNumOfCAMEL-T-CauseValueCriteria) OF
     CauseValue
```

```
maxNumOfCAMEL-O-CauseValueCriteria  INTEGER ::= 5
```

```
maxNumOfCAMEL-T-CauseValueCriteria  INTEGER ::= 5
```

```
CauseValue ::= OCTET STRING (SIZE(1))
-- Type extracted from Cause parameter in ITU-T Recommendation Q.763.
-- For the use of cause value refer to ITU-T Recommendation Q.850.
```

```
DefaultCallHandling ::= ENUMERATED {
     continueCall (0) ,
     releaseCall (1) ,
     ...}
     -- exception handling:
     -- reception of values in range 2-31 shall be treated as "continueCall"
     -- reception of values greater than 31 shall be treated as "releaseCall"
```

```
CamelCapabilityHandling ::= INTEGER(1..16)
     -- value 1 = CAMEL phase 1,
     -- value 2 = CAMEL phase 2,
     -- value 3 = CAMEL Phase 3,
     -- value 4 = CAMEL phase 4:
     -- reception of values greater than 4 shall be treated as CAMEL phase 4.
```

```
SupportedCamelPhases ::= BIT STRING {
     phase1 (0),
     phase2 (1),
     phase3 (2),
     phase4 (3)} (SIZE (1..16))
-- A node shall mark in the BIT STRING all CAMEL Phases it supports.
-- Other values than listed above shall be discarded.
```

```
OfferedCamel4CSIs ::= BIT STRING {
     o-csi                              (0),
     d-csi                              (1),
     vt-csi                             (2),
     t-csi                              (3),
     mt-sms-csi                         (4),
     mg-csi                             (5),
     psi-enhancements                   (6)
} (SIZE (7..16))
-- A node supporting Camel phase 4 shall mark in the BIT STRING all Camel4 CSIs
-- it offers.
-- Other values than listed above shall be discarded.
```

```
OfferedCamel4Functionalities ::= BIT STRING {
     initiateCallAttempt                 (0),
     splitLeg                            (1),
     moveLeg                             (2),
     disconnectLeg                       (3),
     entityReleased                      (4),
     dfc-WithArgument                    (5),
     playTone                            (6),
     dtmf-MidCall                        (7),
     chargingIndicator                   (8),
     alertingDP                          (9),
     locationAtAlerting                  (10),
     changeOfPositionDP                  (11),
     or-Interactions                     (12),
     warningToneEnhancements             (13),
     cf-Enhancements                     (14),
     subscribedEnhancedDialledServices   (15),
     servingNetworkEnhancedDialledServices (16),
     criteriaForChangeOfPositionDP       (17),
     serviceChangeDP                     (18),
     collectInformation                  (19)
} (SIZE (15..64))
-- A node supporting Camel phase 4 shall mark in the BIT STRING all CAMEL4
-- functionalities it offers.
-- Other values than listed above shall be discarded.
```

```
SMS-CSI ::= SEQUENCE {
     sms-CAMEL-TDP-DataList              [0] SMS-CAMEL-TDP-DataList        OPTIONAL,
     camelCapabilityHandling             [1] CamelCapabilityHandling       OPTIONAL,
     extensionContainer                  [2] ExtensionContainer            OPTIONAL,
     notificationToCSE                   [3] NULL                          OPTIONAL,
     csi-Active                          [4] NULL                          OPTIONAL,
     ...}
--   notificationToCSE and csi-Active shall not be present
--   when MO-SMS-CSI or MT-SMS-CSI is sent to VLR or SGSN.
--   They may only be included in ATSI/ATM ack/NSDC message.
--   SMS-CAMEL-TDP-Data and  camelCapabilityHandling shall be present in
--   the SMS-CSI sequence.
--   If SMS-CSI is segmented, sms-CAMEL-TDP-DataList and camelCapabilityHandling shall be
--   present in the first segment
```

```
SMS-CAMEL-TDP-DataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     SMS-CAMEL-TDP-Data
--   SMS-CAMEL-TDP-DataList shall not contain more than one instance of
--   SMS-CAMEL-TDP-Data containing the same value for sms-TriggerDetectionPoint.
```

```
SMS-CAMEL-TDP-Data ::= SEQUENCE {
     sms-TriggerDetectionPoint           [0] SMS-TriggerDetectionPoint,
     serviceKey                          [1] ServiceKey,
     gsmSCF-Address                      [2] ISDN-AddressString,
     defaultSMS-Handling                 [3] DefaultSMS-Handling,
     extensionContainer                  [4] ExtensionContainer            OPTIONAL,
     ...
     }
```

```
SMS-TriggerDetectionPoint ::= ENUMERATED {
     sms-CollectedInfo (1),
     ...,
     sms-DeliveryRequest (2)
     }
--   exception handling:
--   For SMS-CAMEL-TDP-Data and MT-smsCAMELTDP-Criteria sequences containing this
--   parameter with any other value than the ones listed the receiver shall ignore
--   the whole sequence.
--
--   If this parameter is received with any other value than sms-CollectedInfo
--   in an SMS-CAMEL-TDP-Data sequence contained in mo-sms-CSI, then the receiver shall
--   ignore the whole SMS-CAMEL-TDP-Data sequence.
--
--   If this parameter is received with any other value than sms-DeliveryRequest
--   in an SMS-CAMEL-TDP-Data sequence contained in mt-sms-CSI then the receiver shall
--   ignore the whole SMS-CAMEL-TDP-Data sequence.
--
--   If this parameter is received with any other value than sms-DeliveryRequest
--   in an MT-smsCAMELTDP-Criteria sequence then the receiver shall
--   ignore the whole MT-smsCAMELTDP-Criteria sequence.
```

```
DefaultSMS-Handling ::= ENUMERATED {
     continueTransaction (0) ,
     releaseTransaction (1) ,
     ...}
--   exception handling:
--   reception of values in range 2-31 shall be treated as "continueTransaction"
--   reception of values greater than 31 shall be treated as "releaseTransaction"
```

```
M-CSI ::= SEQUENCE {
     mobilityTriggers                    MobilityTriggers,
     serviceKey                          ServiceKey,
     gsmSCF-Address                      [0]  ISDN-AddressString,
     extensionContainer                  [1]  ExtensionContainer          OPTIONAL,
     notificationToCSE                   [2] NULL                         OPTIONAL,
     csi-Active                          [3] NULL                         OPTIONAL,
     ...}
--   notificationToCSE and csi-Active shall not be present when M-CSI is sent to VLR.
--   They may only be included in ATSI/ATM ack/NSDC message.
```

```
MG-CSI ::= SEQUENCE {
     mobilityTriggers                    MobilityTriggers,
     serviceKey                          ServiceKey,
     gsmSCF-Address                      [0]  ISDN-AddressString,
     extensionContainer                  [1]  ExtensionContainer          OPTIONAL,
     notificationToCSE                   [2] NULL                         OPTIONAL,
     csi-Active                          [3] NULL                         OPTIONAL,
     ...}
--   notificationToCSE and csi-Active shall not be present when MG-CSI is sent to SGSN.
--   They may only be included in ATSI/ATM ack/NSDC message.
```

```
MobilityTriggers  ::= SEQUENCE SIZE (1..maxNumOfMobilityTriggers) OF
     MM-Code
```

```
maxNumOfMobilityTriggers INTEGER ::= 10
```

```
MM-Code ::= OCTET STRING (SIZE (1))
--   This type is used to indicate a Mobility Management event.
--   Actions for the following MM-Code values are defined in CAMEL Phase 4:
--
--   CS domain MM events:
--   Location-update-in-same-VLR          MM-Code ::= '00000000'B
--   Location-update-to-other-VLR         MM-Code ::= '00000001'B
--   IMSI-Attach                          MM-Code ::= '00000010'B
--   MS-initiated-IMSI-Detach             MM-Code ::= '00000011'B
--   Network-initiated-IMSI-Detach        MM-Code ::= '00000100'B
--
--   PS domain MM events:
--   Routeing-Area-update-in-same-SGSN    MM-Code ::= '10000000'B
--   Routeing-Area-update-to-other-SGSN-update-from-new-SGSN
--                                        MM-Code ::= '10000001'B
--   Routeing-Area-update-to-other-SGSN-disconnect-by-detach
--                                        MM-Code ::= '10000010'B
--   GPRS-Attach                          MM-Code ::= '10000011'B
--   MS-initiated-GPRS-Detach             MM-Code ::= '10000100'B
--   Network-initiated-GPRS-Detach        MM-Code ::= '10000101'B
--   Network-initiated-transfer-to-MS-not-reachable-for-paging
--                                        MM-Code ::= '10000110'B
--
--   If the MSC receives any other MM-code than the ones listed above for the
--   CS domain, then the MSC shall ignore that MM-code.
--   If the SGSN receives any other MM-code than the ones listed above for the
--   PS domain, then the SGSN shall ignore that MM-code.
```

```
T-CSI ::= SEQUENCE {
     t-BcsmCamelTDPDataList              T-BcsmCamelTDPDataList,
     extensionContainer                  ExtensionContainer               OPTIONAL,
     ...,
     camelCapabilityHandling             [0] CamelCapabilityHandling      OPTIONAL,
     notificationToCSE                   [1] NULL                         OPTIONAL,
     csi-Active                          [2] NULL                         OPTIONAL}
--   notificationToCSE and csi-Active shall not be present when VT-CSI/T-CSI is sent
--   to VLR/GMSC.
--   They may only be included in ATSI/ATM ack/NSDC message.
--   T-CSI shall not be segmented.
```

```
T-BcsmCamelTDPDataList ::= SEQUENCE SIZE (1..maxNumOfCamelTDPData) OF
     T-BcsmCamelTDPData
     --- T-BcsmCamelTDPDataList shall not contain more than one instance of
     --- T-BcsmCamelTDPData containing the same value for t-BcsmTriggerDetectionPoint.
     --- For CAMEL Phase 2, this means that only one instance of T-BcsmCamelTDPData is allowed
     --- with t-BcsmTriggerDetectionPoint being equal to DP12.
     --- For CAMEL Phase 3, more TDP"s are allowed.
```

```
T-BcsmCamelTDPData ::= SEQUENCE {
     t-BcsmTriggerDetectionPoint          T-BcsmTriggerDetectionPoint,
     serviceKey                           ServiceKey,
     gsmSCF-Address                       [0] ISDN-AddressString,
     defaultCallHandling                  [1] DefaultCallHandling,
     extensionContainer                   [2] ExtensionContainer          OPTIONAL,
     ...}
```

```
T-BcsmTriggerDetectionPoint ::= ENUMERATED {
     termAttemptAuthorized (12),
     ... ,
     tBusy (13),
     tNoAnswer (14)}
     -- exception handling:
     -- For T-BcsmCamelTDPData sequences containing this parameter with any other
     -- value than the ones listed above, the receiver shall ignore the whole
     -- T-BcsmCamelTDPData sequence.
```

-- gprs location information retrieval types

```
SendRoutingInfoForGprsArg ::= SEQUENCE {
     imsi                                 [0] IMSI,
     ggsn-Address                         [1] GSN-Address             OPTIONAL,
     ggsn-Number                          [2]  ISDN-AddressString,
     extensionContainer                   [3] ExtensionContainer      OPTIONAL,
     ...}
```

```
SendRoutingInfoForGprsRes ::= SEQUENCE {
     sgsn-Address                         [0] GSN-Address,
     ggsn-Address                         [1]  GSN-Address            OPTIONAL,
     mobileNotReachableReason             [2]  AbsentSubscriberDiagnosticSM    OPTIONAL,
     extensionContainer                   [3] ExtensionContainer      OPTIONAL,
     ...}
```

-- failure report types

```
FailureReportArg ::= SEQUENCE {
     imsi                                 [0] IMSI,
     ggsn-Number                          [1] ISDN-AddressString      ,
     ggsn-Address                         [2] GSN-Address             OPTIONAL,
     extensionContainer                   [3] ExtensionContainer      OPTIONAL,
     ...}
```

```
FailureReportRes ::= SEQUENCE {
     ggsn-Address                         [0] GSN-Address             OPTIONAL,
     extensionContainer                   [1] ExtensionContainer      OPTIONAL,
     ...}
```

-- gprs notification types

```
NoteMsPresentForGprsArg ::= SEQUENCE {
     imsi                                 [0] IMSI,
     sgsn-Address                         [1] GSN-Address,
     ggsn-Address                         [2] GSN-Address             OPTIONAL,
     extensionContainer                   [3] ExtensionContainer      OPTIONAL,
     ...}
```

```
NoteMsPresentForGprsRes ::= SEQUENCE {
     extensionContainer                   [0] ExtensionContainer      OPTIONAL,
     ...}
```

-- fault recovery types

```
ResetArg ::= SEQUENCE {
     hlr-Number                           ISDN-AddressString,
     hlr-List                             HLR-List                    OPTIONAL,
     ...}
```

```
RestoreDataArg ::= SEQUENCE {
     imsi                                IMSI,
     lmsi                                LMSI                                OPTIONAL,
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ... ,
     vlr-Capability                      [6] VLR-Capability                  OPTIONAL }
```

```
RestoreDataRes ::= SEQUENCE {
     hlr-Number                          ISDN-AddressString,
     msNotReachable                      NULL                                OPTIONAL,
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...}
```

```
-- VBS/VGCS types
VBSDataList ::= SEQUENCE SIZE (1..maxNumOfVBSGroupIds) OF
                                         VoiceBroadcastData
```

```
VGCSDataList ::= SEQUENCE SIZE (1..maxNumOfVGCSGroupIds) OF
                                         VoiceGroupCallData
```

```
maxNumOfVBSGroupIds  INTEGER ::= 50
```

```
maxNumOfVGCSGroupIds  INTEGER ::= 50
```

```
VoiceGroupCallData  ::= SEQUENCE {
     groupId                             GroupId,
     -- groupId shall be filled with six TBCD fillers (1111)if the longGroupId is present
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...,
     additionalSubscriptions             AdditionalSubscriptions             OPTIONAL,
     additionalInfo                      [0] AdditionalInfo                  OPTIONAL,
     longGroupId                         [1] Long-GroupId                    OPTIONAL }

     -- VoiceGroupCallData containing a longGroupId shall not be sent to VLRs that did not
     -- indicate support of long Group IDs within the Update Location or Restore Data
     -- request message
```

```
AdditionalInfo ::= BIT STRING (SIZE (1..136))
--    Refers to Additional Info as specified in 3GPP TS 43.068
```

```
AdditionalSubscriptions ::= BIT STRING {
     privilegedUplinkRequest (0),
     emergencyUplinkRequest (1),
     emergencyReset (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
VoiceBroadcastData ::= SEQUENCE {
     groupid                             GroupId,
     -- groupId shall be filled with six TBCD fillers (1111)if the longGroupId is present
     broadcastInitEntitlement            NULL                                OPTIONAL,
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...,
     longGroupId                         [0] Long-GroupId                    OPTIONAL }

     -- VoiceBroadcastData containing a longGroupId shall not be sent to VLRs that did not
     -- indicate support of long Group IDs within the Update Location or Restore Data
     -- request message
```

```
GroupId  ::= TBCD-STRING (SIZE (3))
     -- When Group-Id is less than six characters in length, the TBCD filler (1111)
     -- is used to fill unused half octets.
     -- Refers to the Group Identification as specified in 3GPP TS 23.003
     -- and 3GPP TS 43.068/ 43.069
```

```
Long-GroupId  ::= TBCD-STRING (SIZE (4))
     -- When Long-Group-Id is less than eight characters in length, the TBCD filler (1111)
     -- is used to fill unused half octets.
     -- Refers to the Group Identification as specified in 3GPP TS 23.003
     -- and 3GPP TS 43.068/ 43.069
```

```
-- provide subscriber info types
```

```
ProvideSubscriberInfoArg ::= SEQUENCE {
     imsi      [0] IMSI,
     lmsi      [1] LMSI                    OPTIONAL,
     requestedInfo                         [2] RequestedInfo,
     extensionContainer                    [3] ExtensionContainer          OPTIONAL,
     ...,
     callPriority                          [4]  EMLPP-Priority             OPTIONAL
     }
```

```
ProvideSubscriberInfoRes ::= SEQUENCE {
     subscriberInfo                        SubscriberInfo,
     extensionContainer                    ExtensionContainer              OPTIONAL,
     ...}
```

```
SubscriberInfo ::= SEQUENCE {
     locationInformation                   [0] LocationInformation         OPTIONAL,
     subscriberState                       [1] SubscriberState             OPTIONAL,
     extensionContainer                    [2] ExtensionContainer          OPTIONAL,
     ... ,
     locationInformationGPRS               [3] LocationInformationGPRS     OPTIONAL,
     ps-SubscriberState                    [4] PS-SubscriberState          OPTIONAL,
     imei                                  [5] IMEI                        OPTIONAL,
     ms-Classmark2                         [6] MS-Classmark2               OPTIONAL,
     gprs-MS-Class                         [7] GPRSMSClass                 OPTIONAL,
     mnpInfoRes                            [8] MNPInfoRes                  OPTIONAL }

--   If the HLR receives locationInformation, subscriberState or ms-Classmark2 from an SGSN
--   it shall discard them.
--   If the HLR receives locationInformationGPRS, ps-SubscriberState or gprs-MS-Class from
--   a VLR it shall discard them.
--   If the HLR receives parameters which it has not requested, it shall discard them.
```

```
MNPInfoRes ::= SEQUENCE {
     routeingNumber                        [0] RouteingNumber              OPTIONAL,
     imsi                                  [1] IMSI                        OPTIONAL,
     msisdn                                [2] ISDN-AddressString          OPTIONAL,
     numberPortabilityStatus               [3] NumberPortabilityStatus     OPTIONAL,
     extensionContainer                    [4] ExtensionContainer          OPTIONAL,
     ... }
--   The IMSI parameter contains a generic IMSI, i.e. it is not tied necessarily to the
--   Subscriber. MCC and MNC values in this IMSI shall point to the Subscription Network of
--   the Subscriber. See 3GPP TS 23.066 [108].
```

```
RouteingNumber ::= TBCD-STRING (SIZE (1..5))
```

```
NumberPortabilityStatus ::= ENUMERATED {
     notKnownToBePorted                    (0),
     ownNumberPortedOut                    (1),
     foreignNumberPortedToForeignNetwork   (2),
     ...,
     ownNumberNotPortedOut                 (4),
     foreignNumberPortedIn                 (5)
     }
     --   exception handling:
     --   reception of other values than the ones listed the receiver shall ignore the
     --   whole NumberPortabilityStatus;
     --   ownNumberNotPortedOut or foreignNumberPortedIn may only be included in Any Time
     --   Interrogation message.
```

```
MS-Classmark2 ::= OCTET STRING (SIZE (3))
     -- This parameter carries the value part of the MS Classmark 2 IE defined in
     -- 3GPP TS 24.008 [35].
```

```
GPRSMSClass ::= SEQUENCE {
     mSNetworkCapability                   [0] MSNetworkCapability,
     mSRadioAccessCapability               [1] MSRadioAccessCapability     OPTIONAL
     }
```

```
MSNetworkCapability ::= OCTET STRING (SIZE (1..8))
     -- This parameter carries the value part of the MS Network Capability IE defined in
     -- 3GPP TS 24.008 [35].
```

```
MSRadioAccessCapability ::= OCTET STRING (SIZE (1..50))
     -- This parameter carries the value part of the MS Radio Access Capability IE defined in
     -- 3GPP TS 24.008 [35].
```

```
RequestedInfo ::= SEQUENCE {
     locationInformation                [0] NULL                              OPTIONAL,
     subscriberState                    [1] NULL                              OPTIONAL,
     extensionContainer                 [2] ExtensionContainer                OPTIONAL,
     ...,
     currentLocation                    [3] NULL                              OPTIONAL,
     requestedDomain                    [4] DomainType                        OPTIONAL,
     imei                               [6] NULL                              OPTIONAL,
     ms-classmark                       [5] NULL                              OPTIONAL,
     mnpRequestedInfo                   [7] NULL                              OPTIONAL }

--   currentLocation shall be absent if locationInformation is absent
```

```
DomainType ::=  ENUMERATED {
     cs-Domain                          (0),
     ps-Domain                          (1),
     ...}
-- exception handling:
-- reception of values > 1 shall be mapped to 'cs-Domain'
```

```
LocationInformation ::= SEQUENCE {
     ageOfLocationInformation          AgeOfLocationInformation          OPTIONAL,
     geographicalInformation            [0] GeographicalInformation       OPTIONAL,
     vlr-number                         [1] ISDN-AddressString            OPTIONAL,
     locationNumber                     [2] LocationNumber                OPTIONAL,
     cellGlobalIdOrServiceAreaIdOrLAI   [3] CellGlobalIdOrServiceAreaIdOrLAI   OPTIONAL,
     extensionContainer                 [4] ExtensionContainer            OPTIONAL,
     ... ,
     selectedLSA-Id                     [5] LSAIdentity                   OPTIONAL,
     msc-Number                         [6] ISDN-AddressString            OPTIONAL,
     geodeticInformation                [7] GeodeticInformation           OPTIONAL,
     currentLocationRetrieved           [8] NULL                          OPTIONAL,
     sai-Present                        [9] NULL                          OPTIONAL,
     locationInformationEPS             [10]LocationInformationEPS        OPTIONAL }
-- sai-Present indicates that the cellGlobalIdOrServiceAreaIdOrLAI parameter contains
-- a Service Area Identity.
-- currentLocationRetrieved shall be present
-- if the location information were retrieved after a successfull paging.
```

```
LocationInformationEPS ::= SEQUENCE {
     e-utranCellGlobalIdentity          [0] OCTET STRING (SIZE(7))         OPTIONAL,
-- Octets are coded as described in 3GPP TS 29.118.
     trackingAreaIdentity               [1] OCTET STRING (SIZE(6))         OPTIONAL,
-- Octets are coded as described in 3GPP TS 29.118.
     extensionContainer                 [2] ExtensionContainer             OPTIONAL,
     ...}
```

```
LocationInformationGPRS ::= SEQUENCE {
     cellGlobalIdOrServiceAreaIdOrLAI   [0] CellGlobalIdOrServiceAreaIdOrLAI OPTIONAL,
     routeingAreaIdentity               [1] RAIdentity                    OPTIONAL,
     geographicalInformation            [2] GeographicalInformation       OPTIONAL,
     sgsn-Number                        [3] ISDN-AddressString            OPTIONAL,
     selectedLSAIdentity                [4] LSAIdentity                   OPTIONAL,
     extensionContainer                 [5] ExtensionContainer            OPTIONAL,
     ...,
     sai-Present                        [6] NULL                          OPTIONAL,
     geodeticInformation                [7] GeodeticInformation           OPTIONAL,
     currentLocationRetrieved           [8] NULL                          OPTIONAL,
     ageOfLocationInformation           [9] AgeOfLocationInformation      OPTIONAL }
-- sai-Present indicates that the cellGlobalIdOrServiceAreaIdOrLAI parameter contains
-- a Service Area Identity.
-- currentLocationRetrieved shall be present if the location information
-- was retrieved after successful paging.
```

```
RAIdentity ::= OCTET STRING (SIZE (6))
-- Routing Area Identity is coded in accordance with 3GPP TS 29.060 [105].
-- It shall contain the value part defined in 3GPP TS 29.060 only. I.e. the 3GPP TS 29.060
-- type identifier octet shall not be included.
```

```
GeographicalInformation ::= OCTET STRING (SIZE (8))
--   Refers to geographical Information defined in 3GPP TS 23.032.
--   Only the description of an ellipsoid point with uncertainty circle
--   as specified in 3GPP TS 23.032 is allowed to be used
--   The internal structure according to 3GPP TS 23.032 is as follows:
--        Type of shape (ellipsoid point with uncertainty circle)          1 octet
--        Degrees of Latitude                                              3 octets
--        Degrees of Longitude                                             3 octets
--        Uncertainty code                                                 1 octet
```

```
GeodeticInformation ::= OCTET STRING (SIZE (10))
--   Refers to Calling Geodetic Location defined in Q.763 (1999).
--   Only the description of an ellipsoid point with uncertainty circle
--   as specified in Q.763 (1999) is allowed to be used
--   The internal structure according to Q.763 (1999) is as follows:
--        Screening and presentation indicators                            1 octet
--        Type of shape (ellipsoid point with uncertainty circle)          1 octet
--        Degrees of Latitude                                              3 octets
--        Degrees of Longitude                                             3 octets
--        Uncertainty code                                                 1 octet
--        Confidence                                                       1 octet
```

```
LocationNumber ::= OCTET STRING (SIZE (2..10))
     -- the internal structure is defined in ITU-T Rec Q.763
```

```
SubscriberState ::= CHOICE {
     assumedIdle                    [0] NULL,
     camelBusy                      [1] NULL,
     netDetNotReachable             NotReachableReason,
     notProvidedFromVLR             [2] NULL}
```

```
PS-SubscriberState ::= CHOICE {
     notProvidedFromSGSN            [0] NULL,
     ps-Detached                    [1] NULL,
     ps-AttachedNotReachableForPaging   [2] NULL,
     ps-AttachedReachableForPaging      [3] NULL,
     ps-PDP-ActiveNotReachableForPaging [4] PDP-ContextInfoList,
     ps-PDP-ActiveReachableForPaging    [5] PDP-ContextInfoList,
     netDetNotReachable             NotReachableReason }
```

```
PDP-ContextInfoList ::= SEQUENCE SIZE (1..maxNumOfPDP-Contexts) OF
                                    PDP-ContextInfo
```

```
PDP-ContextInfo ::= SEQUENCE {
     pdp-ContextIdentifier          [0] ContextId,
     pdp-ContextActive              [1] NULL                        OPTIONAL,
     pdp-Type                       [2] PDP-Type,
     pdp-Address                    [3] PDP-Address                 OPTIONAL,
     apn-Subscribed                 [4] APN                         OPTIONAL,
     apn-InUse                      [5] APN                         OPTIONAL,
     nsapi                          [6] NSAPI                       OPTIONAL,
     transactionId                  [7] TransactionId               OPTIONAL,
     teid-ForGnAndGp                [8] TEID                        OPTIONAL,
     teid-ForIu                     [9] TEID                        OPTIONAL,
     ggsn-Address                   [10] GSN-Address                OPTIONAL,
     qos-Subscribed                 [11] Ext-QoS-Subscribed         OPTIONAL,
     qos-Requested                  [12] Ext-QoS-Subscribed         OPTIONAL,
     qos-Negotiated                 [13] Ext-QoS-Subscribed         OPTIONAL,
     chargingId                     [14] GPRSChargingID             OPTIONAL,
     chargingCharacteristics        [15] ChargingCharacteristics    OPTIONAL,
     rnc-Address                    [16] GSN-Address                OPTIONAL,
     extensionContainer             [17] ExtensionContainer         OPTIONAL,
     ...,
     qos2-Subscribed                [18] Ext2-QoS-Subscribed        OPTIONAL,
     -- qos2-Subscribed may be present only if qos-Subscribed is present.
     qos2-Requested                 [19] Ext2-QoS-Subscribed        OPTIONAL,
     -- qos2-Requested may be present only if qos-Requested is present.
     qos2-Negotiated                [20] Ext2-QoS-Subscribed        OPTIONAL,
     -- qos2-Negotiated may be present only if qos-Negotiated is present.
          qos3-Subscribed           [21] Ext3-QoS-Subscribed        OPTIONAL,
     -- qos3-Subscribed may be present only if qos2-Subscribed is present.
     qos3-Requested                 [22] Ext3-QoS-Subscribed        OPTIONAL,
     -- qos3-Requested may be present only if qos2-Requested is present.
     qos3-Negotiated                [23] Ext3-QoS-Subscribed        OPTIONAL
     -- qos3-Negotiated may be present only if qos2-Negotiated is present.
}
```

```
NSAPI ::= INTEGER (0..15)
--   This type is used to indicate the Network layer Service Access Point
```

```
TransactionId ::= OCTET STRING (SIZE (1..2))
--   This type carries the value part of the transaction identifier which is used in the
--   session management messages on the access interface. The encoding is defined in
--   3GPP TS 24.008
```

```
TEID ::= OCTET STRING (SIZE (4))
--   This type carries the value part of the Tunnel Endpoint Identifier which is used to
--   distinguish between different tunnels between the same pair of entities which communicate
--   using the GPRS Tunnelling Protocol The encoding is defined in 3GPP TS 29.060.
```

```
GPRSChargingID ::= OCTET STRING (SIZE (4))
--   The Charging ID is a unique four octet value generated by the GGSN when
--   a PDP Context is activated. A Charging ID is generated for each activated context.
--   The encoding is defined in 3GPP TS 29.060.
```

```
NotReachableReason ::= ENUMERATED {
     msPurged (0),
     imsiDetached (1),
     restrictedArea (2),
     notRegistered (3)}
```

-- any time interrogation info types

```
AnyTimeInterrogationArg ::= SEQUENCE {
     subscriberIdentity                  [0] SubscriberIdentity,
     requestedInfo                       [1] RequestedInfo,
     gsmSCF-Address                      [3] ISDN-AddressString,
     extensionContainer                  [2] ExtensionContainer          OPTIONAL,
     ...}
```

```
AnyTimeInterrogationRes ::= SEQUENCE {
     subscriberInfo                    SubscriberInfo,
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...}
```

-- any time information handling types

```
AnyTimeSubscriptionInterrogationArg ::= SEQUENCE {
     subscriberIdentity                  [0] SubscriberIdentity,
     requestedSubscriptionInfo           [1] RequestedSubscriptionInfo,
     gsmSCF-Address                      [2] ISDN-AddressString,
     extensionContainer                  [3] ExtensionContainer          OPTIONAL,
     longFTN-Supported                   [4]  NULL                       OPTIONAL,
     ...}
```

```
AnyTimeSubscriptionInterrogationRes ::= SEQUENCE {
     callForwardingData                  [1] CallForwardingData          OPTIONAL,
     callBarringData                     [2] CallBarringData             OPTIONAL,
     odb-Info                            [3] ODB-Info                    OPTIONAL,
     camel-SubscriptionInfo              [4] CAMEL-SubscriptionInfo      OPTIONAL,
     supportedVLR-CAMEL-Phases           [5] SupportedCamelPhases        OPTIONAL,
     supportedSGSN-CAMEL-Phases          [6] SupportedCamelPhases        OPTIONAL,
     extensionContainer                  [7] ExtensionContainer          OPTIONAL,
     ... ,
     offeredCamel4CSIsInVLR              [8] OfferedCamel4CSIs           OPTIONAL,
     offeredCamel4CSIsInSGSN             [9] OfferedCamel4CSIs           OPTIONAL,
     msisdn-BS-List                      [10] MSISDN-BS-List             OPTIONAL }
```

```
RequestedSubscriptionInfo ::= SEQUENCE {
     requestedSS-Info                    [1] SS-ForBS-Code               OPTIONAL,
     odb                                 [2] NULL                        OPTIONAL,
     requestedCAMEL-SubscriptionInfo     [3] RequestedCAMEL-SubscriptionInfo   OPTIONAL,
     supportedVLR-CAMEL-Phases           [4] NULL                        OPTIONAL,
     supportedSGSN-CAMEL-Phases          [5] NULL                        OPTIONAL,
     extensionContainer                  [6] ExtensionContainer          OPTIONAL,
     ...,
     additionalRequestedCAMEL-SubscriptionInfo
                                         [7] AdditionalRequestedCAMEL-SubscriptionInfo
                                                                         OPTIONAL,
     msisdn-BS-List                      [8] NULL                        OPTIONAL }
```

```
MSISDN-BS-List ::= SEQUENCE SIZE (1..maxNumOfMSISDN) OF
                                        MSISDN-BS
```

```
maxNumOfMSISDN  INTEGER ::= 50
```

```
MSISDN-BS ::= SEQUENCE {
     msisdn                                  ISDN-AddressString,
     basicServiceList                  [0]   BasicServiceList              OPTIONAL,
     extensionContainer                [1]   ExtensionContainer            OPTIONAL,
     ...}
```

```
RequestedCAMEL-SubscriptionInfo ::= ENUMERATED {
     o-CSI                             (0),
     t-CSI                             (1),
     vt-CSI                            (2),
     tif-CSI                           (3),
     gprs-CSI                          (4),
     mo-sms-CSI                        (5),
     ss-CSI                            (6),
     m-CSI                             (7),
     d-csi                             (8)}
```

```
AdditionalRequestedCAMEL-SubscriptionInfo ::= ENUMERATED {
     mt-sms-CSI                        (0),
     mg-csi                            (1),
     o-IM-CSI                          (2),
     d-IM-CSI                          (3),
     vt-IM-CSI                         (4),
     ...}
--   exception handling: unknown values shall be discarded by the receiver.
```

```
CallForwardingData ::= SEQUENCE {
     forwardingFeatureList             Ext-ForwFeatureList,
     notificationToCSE                 NULL                              OPTIONAL,
     extensionContainer                [0] ExtensionContainer            OPTIONAL,
     ...}
```

```
CallBarringData ::= SEQUENCE {
     callBarringFeatureList            Ext-CallBarFeatureList,
     password                          Password                          OPTIONAL,
     wrongPasswordAttemptsCounter      WrongPasswordAttemptsCounter      OPTIONAL,
     notificationToCSE                 NULL                              OPTIONAL,
     extensionContainer                ExtensionContainer                OPTIONAL,
     ...}
```

```
WrongPasswordAttemptsCounter ::= INTEGER (0..4)
```

```
ODB-Info ::= SEQUENCE {
     odb-Data                          ODB-Data,
     notificationToCSE                 NULL                              OPTIONAL,
     extensionContainer                ExtensionContainer                OPTIONAL,
     ...}
```

```
CAMEL-SubscriptionInfo ::= SEQUENCE {
     o-CSI                                [0]  O-CSI                          OPTIONAL,
     o-BcsmCamelTDP-CriteriaList          [1]  O-BcsmCamelTDPCriteriaList     OPTIONAL,
     d-CSI                                [2]  D-CSI                          OPTIONAL,
     t-CSI                                [3]  T-CSI                          OPTIONAL,
     t-BCSM-CAMEL-TDP-CriteriaList        [4]  T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
     vt-CSI                               [5]  T-CSI                          OPTIONAL,
     vt-BCSM-CAMEL-TDP-CriteriaList       [6]  T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
     tif-CSI                              [7]  NULL                           OPTIONAL,
     tif-CSI-NotificationToCSE            [8]  NULL                           OPTIONAL,
     gprs-CSI                             [9]  GPRS-CSI                       OPTIONAL,
     mo-sms-CSI                           [10] SMS-CSI                        OPTIONAL,
     ss-CSI                               [11] SS-CSI                         OPTIONAL,
     m-CSI                                [12] M-CSI                          OPTIONAL,
     extensionContainer                   [13] ExtensionContainer             OPTIONAL,
     ...,
     specificCSIDeletedList               [14] SpecificCSI-Withdraw           OPTIONAL,
     mt-sms-CSI                           [15] SMS-CSI                        OPTIONAL,
     mt-smsCAMELTDP-CriteriaList          [16] MT-smsCAMELTDP-CriteriaList    OPTIONAL,
     mg-csi                               [17] MG-CSI                         OPTIONAL,
     o-IM-CSI                             [18] O-CSI                          OPTIONAL,
     o-IM-BcsmCamelTDP-CriteriaList       [19] O-BcsmCamelTDPCriteriaList     OPTIONAL,
     d-IM-CSI                             [20] D-CSI                          OPTIONAL,
     vt-IM-CSI                            [21] T-CSI                          OPTIONAL,
     vt-IM-BCSM-CAMEL-TDP-CriteriaList    [22] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL
     }
```

```
AnyTimeModificationArg ::= SEQUENCE {
     subscriberIdentity                   [0]  SubscriberIdentity,
     gsmSCF-Address                       [1]  ISDN-AddressString,
     modificationRequestFor-CF-Info       [2]  ModificationRequestFor-CF-Info OPTIONAL,
     modificationRequestFor-CB-Info       [3]  ModificationRequestFor-CB-Info OPTIONAL,
     modificationRequestFor-CSI           [4]  ModificationRequestFor-CSI     OPTIONAL,
     extensionContainer                   [5]  ExtensionContainer             OPTIONAL,
     longFTN-Supported                    [6]  NULL                           OPTIONAL,
     ...,
     modificationRequestFor-ODB-data      [7]  ModificationRequestFor-ODB-data OPTIONAL,
     modificationRequestFor-IP-SM-GW-Data [8]  ModificationRequestFor-IP-SM-GW-Data OPTIONAL,
     activationRequestForUE-reachability  [9]  ServingNode                    OPTIONAL }
```

```
ServingNode ::= BIT STRING {
     mme (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
AnyTimeModificationRes ::= SEQUENCE {
     ss-InfoFor-CSE                       [0]  Ext-SS-InfoFor-CSE             OPTIONAL,
     camel-SubscriptionInfo               [1]  CAMEL-SubscriptionInfo         OPTIONAL,
     extensionContainer                   [2]  ExtensionContainer             OPTIONAL,
     ...,
     odb-Info                             [3]  ODB-Info                       OPTIONAL }
```

```
ModificationRequestFor-CF-Info ::= SEQUENCE {
     ss-Code                              [0]  SS-Code,
     basicService                         [1]  Ext-BasicServiceCode           OPTIONAL,
     ss-Status                            [2]  Ext-SS-Status                  OPTIONAL,
     forwardedToNumber                    [3]  AddressString                  OPTIONAL,
     forwardedToSubaddress                [4]  ISDN-SubaddressString          OPTIONAL,
     noReplyConditionTime                 [5]  Ext-NoRepCondTime              OPTIONAL,
     modifyNotificationToCSE              [6]  ModificationInstruction        OPTIONAL,
     extensionContainer                   [7]  ExtensionContainer             OPTIONAL,
     ...}
```

```
ModificationRequestFor-CB-Info ::= SEQUENCE {
     ss-Code                              [0]  SS-Code,
     basicService                         [1]  Ext-BasicServiceCode           OPTIONAL,
     ss-Status                            [2]  Ext-SS-Status                  OPTIONAL,
     password                             [3]  Password                       OPTIONAL,
     wrongPasswordAttemptsCounter         [4]  WrongPasswordAttemptsCounter   OPTIONAL,
     modifyNotificationToCSE              [5]  ModificationInstruction        OPTIONAL,
     extensionContainer                   [6]  ExtensionContainer             OPTIONAL,
     ...}
```

```
ModificationRequestFor-ODB-data ::= SEQUENCE {
     odb-data                             [0]  ODB-Data                       OPTIONAL,
     modifyNotificationToCSE              [1]  ModificationInstruction        OPTIONAL,
     extensionContainer                   [2]  ExtensionContainer             OPTIONAL,
     ...}
```

```
ModificationRequestFor-CSI ::= SEQUENCE {
     requestedCamel-SubscriptionInfo      [0]  RequestedCAMEL-SubscriptionInfo,
     modifyNotificationToCSE              [1]  ModificationInstruction       OPTIONAL,
     modifyCSI-State                      [2]  ModificationInstruction       OPTIONAL,
     extensionContainer                   [3]  ExtensionContainer            OPTIONAL,
     ...,
     additionalRequestedCAMEL-SubscriptionInfo
                                          [4] AdditionalRequestedCAMEL-SubscriptionInfo
                                                                             OPTIONAL }
-- requestedCamel-SubscriptionInfo shall be discarded if
-- additionalRequestedCAMEL-SubscriptionInfo is received
```

```
ModificationRequestFor-IP-SM-GW-Data ::= SEQUENCE {
     modifyRegistrationStatus             [0]  ModificationInstruction       OPTIONAL,
     extensionContainer                   [1]  ExtensionContainer            OPTIONAL,
     ...}
```

```
ModificationInstruction ::= ENUMERATED {
     deactivate                           (0),
     activate                             (1)}
```

-- subscriber data modification notification types

```
NoteSubscriberDataModifiedArg ::= SEQUENCE {
     imsi                                 IMSI,
     msisdn                               ISDN-AddressString,
     forwardingInfoFor-CSE                [0] Ext-ForwardingInfoFor-CSE      OPTIONAL,
     callBarringInfoFor-CSE               [1] Ext-CallBarringInfoFor-CSE     OPTIONAL,
     odb-Info                             [2] ODB-Info                       OPTIONAL,
     camel-SubscriptionInfo               [3] CAMEL-SubscriptionInfo         OPTIONAL,
     allInformationSent                   [4] NULL                           OPTIONAL,
     extensionContainer                   ExtensionContainer                 OPTIONAL,
     ...,
     ue-reachable                         [5] ServingNode                    OPTIONAL }
```

```
NoteSubscriberDataModifiedRes ::= SEQUENCE {
     extensionContainer                   ExtensionContainer                 OPTIONAL,
     ...}
```

-- mobility management event notificatioon info types

```
NoteMM-EventArg::= SEQUENCE {
     serviceKey                           ServiceKey,
     eventMet                             [0]  MM-Code,
     imsi                                 [1]  IMSI,
     msisdn                               [2]  ISDN-AddressString,
     locationInformation                  [3]  LocationInformation           OPTIONAL,
     supportedCAMELPhases                 [5]  SupportedCamelPhases          OPTIONAL,
     extensionContainer                   [6]  ExtensionContainer            OPTIONAL,
     ...,
     locationInformationGPRS              [7]  LocationInformationGPRS       OPTIONAL,
     offeredCamel4Functionalities         [8] OfferedCamel4Functionalities   OPTIONAL
}
```

```
NoteMM-EventRes ::= SEQUENCE {
     extensionContainer                   ExtensionContainer                 OPTIONAL,
     ...}
```

```
Ext-SS-InfoFor-CSE ::= CHOICE {
     forwardingInfoFor-CSE                [0] Ext-ForwardingInfoFor-CSE,
     callBarringInfoFor-CSE               [1] Ext-CallBarringInfoFor-CSE
     }
```

```
Ext-ForwardingInfoFor-CSE ::= SEQUENCE {
     ss-Code                              [0]  SS-Code,
     forwardingFeatureList                [1]  Ext-ForwFeatureList,
     notificationToCSE                    [2]  NULL                          OPTIONAL,
     extensionContainer                   [3]  ExtensionContainer            OPTIONAL,
     ...}
```

```
Ext-CallBarringInfoFor-CSE ::= SEQUENCE {
     ss-Code                              [0]  SS-Code,
     callBarringFeatureList               [1]  Ext-CallBarFeatureList,
     password                             [2]  Password                        OPTIONAL,
     wrongPasswordAttemptsCounter         [3]  WrongPasswordAttemptsCounter    OPTIONAL,
     notificationToCSE                    [4]  NULL                            OPTIONAL,
     extensionContainer                   [5]  ExtensionContainer              OPTIONAL,
     ...}
```

END

17.7.2 Operation and maintenance data types

```
MAP-OM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-OM-DataTypes (12) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   ActivateTraceModeArg,
   ActivateTraceModeRes,
   DeactivateTraceModeArg,
   DeactivateTraceModeRes,
   TracePropagationList
;

IMPORTS
   AddressString,
   IMSI,
   GSN-Address
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}

;
```

```
ActivateTraceModeArg ::= SEQUENCE {
     imsi                                 [0] IMSI                             OPTIONAL,
     traceReference                       [1] TraceReference,
     traceType                            [2] TraceType,
     omc-Id                               [3] AddressString                    OPTIONAL,
     extensionContainer                   [4] ExtensionContainer               OPTIONAL,
     ...,
     traceReference2                      [5] TraceReference2                  OPTIONAL,
     traceDepthList                       [6] TraceDepthList                   OPTIONAL,
     traceNE-TypeList                     [7] TraceNE-TypeList                 OPTIONAL,
     traceInterfaceList                   [8] TraceInterfaceList               OPTIONAL,
     traceEventList                       [9] TraceEventList                   OPTIONAL,
     traceCollectionEntity                [10] GSN-Address                     OPTIONAL
     }
```

```
TraceReference ::= OCTET STRING (SIZE (1..2))
```

```
TraceReference2 ::= OCTET STRING (SIZE (3))
```

```
TraceRecordingSessionReference ::= OCTET STRING (SIZE (2))
```

```
TraceType ::= INTEGER
     (0..255)
     -- Trace types are fully defined in  3GPP TS 52.008. [61]
```

```
TraceDepthList ::= SEQUENCE {
     msc-s-TraceDepth                    [0] TraceDepth                  OPTIONAL,
     mgw-TraceDepth                      [1] TraceDepth                  OPTIONAL,
     sgsn-TraceDepth                     [2] TraceDepth                  OPTIONAL,
     ggsn-TraceDepth                     [3] TraceDepth                  OPTIONAL,
     rnc-TraceDepth                      [4] TraceDepth                  OPTIONAL,
     bmsc-TraceDepth                     [5] TraceDepth                  OPTIONAL,
     ... ,
     mme-TraceDepth                      [6] TraceDepth                  OPTIONAL,
     sgw-TraceDepth                      [7] TraceDepth                  OPTIONAL,
     pgw-TraceDepth                      [8] TraceDepth                  OPTIONAL,
     eNB-TraceDepth                      [9] TraceDepth                  OPTIONAL }
```

```
TraceDepth ::= ENUMERATED {
     minimum (0),
     medium (1),
     maximum (2),
     ...}
-- The value medium is applicable only for RNC. For other network elements, if value medium
-- is received, value minimum shall be applied.
```

```
TraceNE-TypeList ::= BIT STRING {
     msc-s (0),
     mgw (1),
     sgsn (2),
     ggsn (3),
     rnc (4),
     bm-sc (5) ,
     mme (6),
     sgw (7),
     pgw (8),
     eNB (9)} (SIZE (6..16))
-- Other bits than listed above shall be discarded.
```

```
TraceInterfaceList ::= SEQUENCE {
     msc-s-List                          [0] MSC-S-InterfaceList         OPTIONAL,
     mgw-List                            [1] MGW-InterfaceList           OPTIONAL,
     sgsn-List                           [2] SGSN-InterfaceList          OPTIONAL,
     ggsn-List                           [3] GGSN-InterfaceList          OPTIONAL,
     rnc-List                            [4] RNC-InterfaceList           OPTIONAL,
     bmsc-List                           [5] BMSC-InterfaceList          OPTIONAL,
     ...,
     mme-List                            [6] MME-InterfaceList           OPTIONAL,
     sgw-List                            [7] SGW-InterfaceList           OPTIONAL,
     pgw-List                            [8] PGW-InterfaceList           OPTIONAL,
     eNB-List                            [9] ENB-InterfaceList           OPTIONAL}
```

```
MSC-S-InterfaceList ::= BIT STRING {
     a (0),
     iu (1),
     mc (2),
     map-g (3),
     map-b (4),
     map-e (5),
     map-f (6),
     cap (7),
     map-d (8),
     map-c (9)} (SIZE (10..16))
-- Other bits than listed above shall be discarded.
```

```
MGW-InterfaceList ::= BIT STRING {
     mc (0),
     nb-up (1),
     iu-up (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
SGSN-InterfaceList ::= BIT STRING {
     gb (0),
     iu (1),
     gn (2),
     map-gr (3),
     map-gd (4),
     map-gf (5),
     gs (6),
     ge (7),
     s3 (8),
     s4 (9),
     s6d (10)} (SIZE (8..16))
-- Other bits than listed above shall be discarded.
```

```
GGSN-InterfaceList ::= BIT STRING {
     gn (0),
     gi (1),
     gmb (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
RNC-InterfaceList ::= BIT STRING {
     iu (0),
     iur (1),
     iub (2),
     uu (3)} (SIZE (4..8))
-- Other bits than listed above shall be discarded.
```

```
BMSC-InterfaceList ::= BIT STRING {
     gmb (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
MME-InterfaceList ::= BIT STRING {
     s1-mme (0),
     s3 (1),
     s6a (2),
     s10 (3),
     s11 (4)} (SIZE (5..8))
-- Other bits than listed above shall be discarded.
```

```
SGW-InterfaceList ::= BIT STRING {
     s4 (0),
     s5 (1),
     s8b (2),
     s11 (3),
     gxc (4)} (SIZE (5..8))
-- Other bits than listed above shall be discarded.
```

```
PGW-InterfaceList ::= BIT STRING {
     s2a (0),
     s2b (1),
     s2c (2),
     s5 (3),
     s6b (4),
     gx (5),
     s8b (6),
     sgi (7)} (SIZE (8..16))
-- Other bits than listed above shall be discarded.
```

```
ENB-InterfaceList ::= BIT STRING {
     s1-mme (0),
     x2 (1),
     uu (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
TraceEventList ::= SEQUENCE {
     msc-s-List                    [0] MSC-S-EventList          OPTIONAL,
     mgw-List                      [1] MGW-EventList            OPTIONAL,
     sgsn-List                     [2] SGSN-EventList           OPTIONAL,
     ggsn-List                     [3] GGSN-EventList           OPTIONAL,
     bmsc-List                     [4] BMSC-EventList           OPTIONAL,
     ...,
     mme-List                      [5] MME-EventList            OPTIONAL,
     sgw-List                      [6] SGW-EventList            OPTIONAL,
     pgw-List                      [7] PGW-EventList            OPTIONAL}
```

```
MSC-S-EventList ::= BIT STRING {
     mo-mtCall (0),
     mo-mt-sms (1),
     lu-imsiAttach-imsiDetach (2),
     handovers (3),
     ss (4)} (SIZE (5..16))
-- Other bits than listed above shall be discarded.
```

```
MGW-EventList ::= BIT STRING {
     context (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
SGSN-EventList ::= BIT STRING {
     pdpContext (0),
     mo-mt-sms (1),
     rau-gprsAttach-gprsDetach (2),
     mbmsContext (3)} (SIZE (4..16))
-- Other bits than listed above shall be discarded.
```

```
GGSN-EventList ::= BIT STRING {
     pdpContext (0),
     mbmsContext (1)} (SIZE (2..8))
-- Other bits than listed above shall be discarded.
```

```
BMSC-EventList ::= BIT STRING {
     mbmsMulticastServiceActivation (0)} (SIZE (1..8))
-- Other bits than listed above shall be discarded.
```

```
MME-EventList ::= BIT STRING {
     ue-initiatedPDNconectivityRequest (0),
     serviceRequestts (1),
     initialAttachTrackingAreaUpdateDetach (2),
     ue-initiatedPDNdisconnection (3),
     bearerActivationModificationDeletion (4),
     handover (5)} (SIZE (6..8))
-- Other bits than listed above shall be discarded.
```

```
SGW-EventList ::= BIT STRING {
     pdn-connectionCreation (0),
     pdn-connectionTermination (1),
     bearerActivationModificationDeletion (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
PGW-EventList ::= BIT STRING {
     pdn-connectionCreation (0),
     pdn-connectionTermination (1),
     bearerActivationModificationDeletion (2)} (SIZE (3..8))
-- Other bits than listed above shall be discarded.
```

```
TracePropagationList ::= SEQUENCE {
     traceReference                      [0] TraceReference                OPTIONAL,
     traceType                           [1] TraceType                     OPTIONAL,
     traceReference2                     [2] TraceReference2               OPTIONAL,
     traceRecordingSessionReference      [3] TraceRecordingSessionReference OPTIONAL,
     rnc-TraceDepth                      [4] TraceDepth                    OPTIONAL,
     rnc-InterfaceList                   [5] RNC-InterfaceList             OPTIONAL,
     msc-s-TraceDepth                    [6] TraceDepth                    OPTIONAL,
     msc-s-InterfaceList                 [7] MSC-S-InterfaceList           OPTIONAL,
     msc-s-EventList                     [8] MSC-S-EventList               OPTIONAL,
     mgw-TraceDepth                      [9] TraceDepth                    OPTIONAL,
     mgw-InterfaceList                  [10] MGW-InterfaceList             OPTIONAL,
     mgw-EventList                      [11] MGW-EventList                 OPTIONAL,
     ...}
```

```
ActivateTraceModeRes ::= SEQUENCE {
     extensionContainer                  [0] ExtensionContainer            OPTIONAL,
     ...,
     traceSupportIndicator               [1]  NULL                         OPTIONAL
     }
```

```
DeactivateTraceModeArg ::= SEQUENCE {
     imsi                                [0] IMSI                          OPTIONAL,
     traceReference                      [1] TraceReference,
     extensionContainer                  [2] ExtensionContainer            OPTIONAL,
     ...,
     traceReference2                     [3] TraceReference2               OPTIONAL
     }
```

```
DeactivateTraceModeRes ::= SEQUENCE {
     extensionContainer                  [0] ExtensionContainer            OPTIONAL,
     ...}
```

```
END
```

17.7.3 Call handling data types

```
MAP-CH-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CH-DataTypes (13) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   SendRoutingInfoArg,
   SendRoutingInfoRes,
   ProvideRoamingNumberArg,
   ProvideRoamingNumberRes,
   ResumeCallHandlingArg,
   ResumeCallHandlingRes,
   NumberOfForwarding,
   SuppressionOfAnnouncement,
   CallReferenceNumber,
   SetReportingStateArg,
   SetReportingStateRes,
   StatusReportArg,
   StatusReportRes,
   RemoteUserFreeArg,
   RemoteUserFreeRes,
   IST-AlertArg,
   IST-AlertRes,
   IST-CommandArg,
   IST-CommandRes,
   UU-Data,
   ReleaseResourcesArg,
   ReleaseResourcesRes
;

IMPORTS
   SubscriberInfo,
   SupportedCamelPhases,
   OfferedCamel4CSIs,
   CUG-Interlock,
   O-CSI,
   D-CSI,
   O-BcsmCamelTDPCriteriaList,
   T-BCSM-CAMEL-TDP-CriteriaList,
   IST-SupportIndicator,
   IST-AlertTimerValue,
   T-CSI,
   NumberPortabilityStatus,
   PagingArea
FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version11 (11)}

   ForwardingOptions,
   SS-List,
   CCBS-Feature
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version11 (11)}
```

```
   ISDN-AddressString,
   ISDN-SubaddressString,
   FTN-AddressString,
   ExternalSignalInfo,
   Ext-ExternalSignalInfo,
   IMSI,
   LMSI,
   Ext-BasicServiceCode,
   AlertingPattern,
   NAEA-PreferredCI,
   EMLPP-Priority
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}
;
```

```
CUG-CheckInfo ::= SEQUENCE {
     cug-Interlock                    CUG-Interlock,
     cug-OutgoingAccess               NULL                              OPTIONAL,
     extensionContainer               ExtensionContainer                OPTIONAL,
     ...}
```

```
NumberOfForwarding ::= INTEGER (1..5)
```

```
SendRoutingInfoArg ::= SEQUENCE {
     msisdn                           [0] ISDN-AddressString,
     cug-CheckInfo                    [1] CUG-CheckInfo                 OPTIONAL,
     numberOfForwarding               [2] NumberOfForwarding            OPTIONAL,
     interrogationType                [3] InterrogationType,
     or-Interrogation                 [4] NULL                          OPTIONAL,
     or-Capability                    [5] OR-Phase                      OPTIONAL,
     gmsc-OrGsmSCF-Address            [6] ISDN-AddressString,
     callReferenceNumber              [7] CallReferenceNumber           OPTIONAL,
     forwardingReason                 [8] ForwardingReason              OPTIONAL,
     basicServiceGroup                [9] Ext-BasicServiceCode          OPTIONAL,
     networkSignalInfo                [10] ExternalSignalInfo           OPTIONAL,
     camelInfo                        [11] CamelInfo                    OPTIONAL,
     suppressionOfAnnouncement        [12] SuppressionOfAnnouncement    OPTIONAL,
     extensionContainer               [13] ExtensionContainer           OPTIONAL,
     ...,
     alertingPattern                  [14] AlertingPattern              OPTIONAL,
     ccbs-Call                        [15] NULL                          OPTIONAL,
     supportedCCBS-Phase              [16]  SupportedCCBS-Phase         OPTIONAL,
     additionalSignalInfo             [17] Ext-ExternalSignalInfo       OPTIONAL,
     istSupportIndicator              [18] IST-SupportIndicator         OPTIONAL,
     pre-pagingSupported              [19] NULL                         OPTIONAL,
     callDiversionTreatmentIndicator  [20] CallDiversionTreatmentIndicator   OPTIONAL,
     longFTN-Supported                [21] NULL                         OPTIONAL,
     suppress-VT-CSI                  [22] NULL                         OPTIONAL,
     suppressIncomingCallBarring      [23] NULL                         OPTIONAL,
     gsmSCF-InitiatedCall             [24] NULL                         OPTIONAL,
     basicServiceGroup2               [25] Ext-BasicServiceCode         OPTIONAL,
     networkSignalInfo2               [26] ExternalSignalInfo           OPTIONAL,
     suppressMTSS                     [27] SuppressMTSS                 OPTIONAL,
     mtRoamingRetrySupported          [28] NULL                         OPTIONAL,
     callPriority                     [29] EMLPP-Priority               OPTIONAL
      }
```

```
SuppressionOfAnnouncement ::= NULL
```

```
SuppressMTSS ::= BIT STRING {
     suppressCUG                      (0),
     suppressCCBS                     (1) } (SIZE (2..16))
     --   Other bits than listed above shall be discarded
```

```
InterrogationType ::= ENUMERATED {
     basicCall  (0),
     forwarding  (1)}
```

```
OR-Phase ::= INTEGER (1..127)
```

```
CallReferenceNumber ::= OCTET STRING (SIZE (1..8))
```

```
ForwardingReason ::= ENUMERATED {
     notReachable  (0),
     busy  (1),
     noReply  (2)}
```

```
SupportedCCBS-Phase ::= INTEGER (1..127)
-- exception handling:
-- Only value 1 is used.
-- Values in the ranges 2-127 are reserved for future use.
-- If received values 2-127 shall be mapped on to value 1.
```

```
CallDiversionTreatmentIndicator ::= OCTET STRING (SIZE(1))
--   callDiversionAllowed (xxxx xx01)
--   callDiversionNotAllowed (xxxx xx10)
--   network default is call diversion allowed
```

```
SendRoutingInfoRes ::= [3] SEQUENCE {
     imsi                                [9] IMSI                          OPTIONAL,
     -- IMSI must be present if SendRoutingInfoRes is not segmented.
     -- If the TC-Result-NL segmentation option is taken the IMSI must be
     -- present in one segmented transmission of SendRoutingInfoRes.
     extendedRoutingInfo                ExtendedRoutingInfo               OPTIONAL,
     cug-CheckInfo                       [3] CUG-CheckInfo                OPTIONAL,
     cugSubscriptionFlag                 [6] NULL                         OPTIONAL,
     subscriberInfo                      [7] SubscriberInfo               OPTIONAL,
     ss-List                             [1] SS-List                      OPTIONAL,
     basicService                        [5] Ext-BasicServiceCode         OPTIONAL,
     forwardingInterrogationRequired     [4] NULL                         OPTIONAL,
     vmsc-Address                        [2] ISDN-AddressString           OPTIONAL,
     extensionContainer                  [0] ExtensionContainer           OPTIONAL,
     ... ,
     naea-PreferredCI                    [10] NAEA-PreferredCI            OPTIONAL,
     -- naea-PreferredCI is included at the discretion of the HLR operator.
     ccbs-Indicators                     [11] CCBS-Indicators             OPTIONAL,
     msisdn                              [12] ISDN-AddressString          OPTIONAL,
     numberPortabilityStatus             [13] NumberPortabilityStatus     OPTIONAL,
     istAlertTimer                       [14] IST-AlertTimerValue         OPTIONAL,
     supportedCamelPhasesInVMSC          [15] SupportedCamelPhases        OPTIONAL,
     offeredCamel4CSIsInVMSC             [16] OfferedCamel4CSIs           OPTIONAL,
     routingInfo2                        [17] RoutingInfo                 OPTIONAL,
     ss-List2                            [18] SS-List                     OPTIONAL,
     basicService2                       [19] Ext-BasicServiceCode        OPTIONAL,
     allowedServices                     [20] AllowedServices             OPTIONAL,
     unavailabilityCause                 [21] UnavailabilityCause         OPTIONAL,
     releaseResourcesSupported           [22] NULL                        OPTIONAL,
     gsm-BearerCapability                [23] ExternalSignalInfo          OPTIONAL
     }
```

```
AllowedServices ::= BIT STRING {
     firstServiceAllowed                 (0),
     secondServiceAllowed                (1) } (SIZE (2..8))
     --   firstService is the service indicated in the networkSignalInfo
     --   secondService is the service indicated in the networkSignalInfo2
     --   Other bits than listed above shall be discarded
```

```
UnavailabilityCause ::= ENUMERATED {
     bearerServiceNotProvisioned         (1),
     teleserviceNotProvisioned           (2),
     absentSubscriber                    (3),
     busySubscriber                      (4),
     callBarred                          (5),
     cug-Reject                          (6),
     ...}
     --   exception handling:
     --   Reception of other values than the ones listed shall result in the service
     --   being unavailable for that call.
```

```
CCBS-Indicators ::= SEQUENCE {
     ccbs-Possible                       [0]  NULL                        OPTIONAL,
     keepCCBS-CallIndicator              [1]  NULL                        OPTIONAL,
     extensionContainer                  [2]  ExtensionContainer          OPTIONAL,
     ...}
```

```
RoutingInfo ::= CHOICE {
     roamingNumber                       ISDN-AddressString,
     forwardingData                      ForwardingData}
```

```
ForwardingData ::= SEQUENCE {
     forwardedToNumber                  [5] ISDN-AddressString            OPTIONAL,
     -- When this datatype is sent from an HLR which supports CAMEL Phase 2
     -- to a GMSC which supports CAMEL Phase 2 the GMSC shall not check the
     -- format of the number
     forwardedToSubaddress              [4] ISDN-SubaddressString         OPTIONAL,
     forwardingOptions                  [6] ForwardingOptions             OPTIONAL,
     extensionContainer                 [7] ExtensionContainer            OPTIONAL,
     ...,
     longForwardedToNumber              [8] FTN-AddressString             OPTIONAL}
```

```
ProvideRoamingNumberArg ::= SEQUENCE {
     imsi                                [0] IMSI,
     msc-Number                          [1] ISDN-AddressString,
     msisdn                              [2] ISDN-AddressString            OPTIONAL,
     lmsi                                [4] LMSI                          OPTIONAL,
     gsm-BearerCapability                [5] ExternalSignalInfo            OPTIONAL,
     networkSignalInfo                   [6] ExternalSignalInfo            OPTIONAL,
     suppressionOfAnnouncement           [7] SuppressionOfAnnouncement     OPTIONAL,
     gmsc-Address                        [8] ISDN-AddressString            OPTIONAL,
     callReferenceNumber                 [9] CallReferenceNumber           OPTIONAL,
     or-Interrogation                    [10] NULL                         OPTIONAL,
     extensionContainer                  [11] ExtensionContainer           OPTIONAL,
     ... ,
     alertingPattern                     [12] AlertingPattern              OPTIONAL,
     ccbs-Call                           [13] NULL                         OPTIONAL,
     supportedCamelPhasesInInterrogatingNode   [15] SupportedCamelPhases   OPTIONAL,
     additionalSignalInfo                [14] Ext-ExternalSignalInfo       OPTIONAL,
     orNotSupportedInGMSC                [16] NULL                         OPTIONAL,
     pre-pagingSupported                 [17] NULL                         OPTIONAL,
     longFTN-Supported                   [18] NULL                         OPTIONAL,
     suppress-VT-CSI                     [19] NULL                         OPTIONAL,
     offeredCamel4CSIsInInterrogatingNode [20] OfferedCamel4CSIs           OPTIONAL,
     mtRoamingRetrySupported             [21] NULL                         OPTIONAL,
     pagingArea                          [22] PagingArea                   OPTIONAL,
     callPriority                        [23] EMLPP-Priority               OPTIONAL
      }
```

```
ProvideRoamingNumberRes ::= SEQUENCE {
     roamingNumber                      ISDN-AddressString,
     extensionContainer                 ExtensionContainer                OPTIONAL,
     ...,
     releaseResourcesSupported          NULL                              OPTIONAL }
```

```
ResumeCallHandlingArg ::= SEQUENCE {
     callReferenceNumber                [0] CallReferenceNumber           OPTIONAL,
     basicServiceGroup                  [1] Ext-BasicServiceCode          OPTIONAL,
     forwardingData                     [2] ForwardingData                OPTIONAL,
     imsi                               [3] IMSI                          OPTIONAL,
     cug-CheckInfo                      [4] CUG-CheckInfo                 OPTIONAL,
     o-CSI                              [5] O-CSI                         OPTIONAL,
     extensionContainer                 [7] ExtensionContainer            OPTIONAL,
     ccbs-Possible                      [8]  NULL                         OPTIONAL,
     msisdn                             [9]  ISDN-AddressString           OPTIONAL,
     uu-Data                            [10] UU-Data                      OPTIONAL,
     allInformationSent                 [11] NULL                         OPTIONAL,
     ...,
     d-csi                              [12] D-CSI                        OPTIONAL,
     o-BcsmCamelTDPCriteriaList         [13] O-BcsmCamelTDPCriteriaList   OPTIONAL,
     basicServiceGroup2                 [14] Ext-BasicServiceCode         OPTIONAL,
     mtRoamingRetry                     [15] NULL                         OPTIONAL
      }
```

```
UU-Data ::= SEQUENCE {
     uuIndicator                        [0] UUIndicator                   OPTIONAL,
     uui                                [1] UUI                           OPTIONAL,
     uusCFInteraction                   [2] NULL                          OPTIONAL,
     extensionContainer                 [3] ExtensionContainer            OPTIONAL,
     ...}
```

```
UUIndicator ::= OCTET STRING (SIZE (1))
     -- Octets are coded according to ETS 300 356
```

```
UUI  ::= OCTET STRING (SIZE (1..131))
     -- Octets are coded according to ETS 300 356
```

```
ResumeCallHandlingRes ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...}
```

```
CamelInfo ::= SEQUENCE {
     supportedCamelPhases                SupportedCamelPhases,
     suppress-T-CSI                      NULL                                OPTIONAL,
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ... ,
     offeredCamel4CSIs                   [0] OfferedCamel4CSIs               OPTIONAL }
```

```
ExtendedRoutingInfo ::= CHOICE {
     routingInfo                         RoutingInfo,
     camelRoutingInfo                    [8] CamelRoutingInfo}
```

```
CamelRoutingInfo ::= SEQUENCE {
     forwardingData                      ForwardingData                      OPTIONAL,
     gmscCamelSubscriptionInfo           [0] GmscCamelSubscriptionInfo,
     extensionContainer                  [1] ExtensionContainer              OPTIONAL,
     ...}
```

```
GmscCamelSubscriptionInfo ::= SEQUENCE {
     t-CSI                               [0] T-CSI OPTIONAL,
     o-CSI                               [1] O-CSI OPTIONAL,
     extensionContainer                  [2] ExtensionContainer              OPTIONAL,
     ...,
     o-BcsmCamelTDP-CriteriaList         [3] O-BcsmCamelTDPCriteriaList      OPTIONAL,
     t-BCSM-CAMEL-TDP-CriteriaList       [4] T-BCSM-CAMEL-TDP-CriteriaList OPTIONAL,
     d-csi                               [5] D-CSI                           OPTIONAL}
```

```
SetReportingStateArg ::= SEQUENCE {
     imsi                                [0] IMSI                            OPTIONAL,
     lmsi                                [1] LMSI                            OPTIONAL,
     ccbs-Monitoring                     [2] ReportingState                  OPTIONAL,
     extensionContainer                  [3] ExtensionContainer              OPTIONAL,
     ...}
```

```
ReportingState ::= ENUMERATED {
     stopMonitoring                      (0),
     startMonitoring                     (1),
     ...}
     -- exception handling:
     -- reception of values 2-10 shall be mapped to 'stopMonitoring'
     -- reception of values > 10 shall be mapped to 'startMonitoring'
```

```
SetReportingStateRes ::= SEQUENCE{
     ccbs-SubscriberStatus               [0] CCBS-SubscriberStatus           OPTIONAL,
     extensionContainer                  [1] ExtensionContainer              OPTIONAL,
     ...}
```

```
CCBS-SubscriberStatus ::= ENUMERATED {
     ccbsNotIdle                         (0),
     ccbsIdle                            (1),
     ccbsNotReachable                    (2),
     ...}
     --  exception handling:
     --  reception of values 3-10 shall be mapped to 'ccbsNotIdle'
     --  reception of values 11-20 shall be mapped to 'ccbsIdle'
     --  reception of values > 20 shall be mapped to 'ccbsNotReachable'
```

```
StatusReportArg ::= SEQUENCE{
     imsi                                [0] IMSI,
     eventReportData                     [1] EventReportData                 OPTIONAL,
     callReportdata                      [2] CallReportData                  OPTIONAL,
     extensionContainer                  [3] ExtensionContainer              OPTIONAL,
     ...}
```

```
EventReportData ::= SEQUENCE{
     ccbs-SubscriberStatus               [0] CCBS-SubscriberStatus           OPTIONAL,
     extensionContainer                  [1] ExtensionContainer              OPTIONAL,
     ...}
```

```
CallReportData ::= SEQUENCE{
     monitoringMode                  [0]  MonitoringMode              OPTIONAL,
     callOutcome                     [1]  CallOutcome                 OPTIONAL,
     extensionContainer              [2]  ExtensionContainer          OPTIONAL,
     ...}
```

```
MonitoringMode ::= ENUMERATED {
     a-side                          (0),
     b-side                          (1),
     ...}
     --   exception handling:
     --  reception of values 2-10 shall be mapped 'a-side'
     --  reception of values > 10 shall be mapped to 'b-side'
```

```
CallOutcome ::= ENUMERATED {
     success                         (0),
     failure                         (1),
     busy                            (2),
     ...}
     --   exception handling:
     --  reception of values 3-10 shall be mapped to 'success'
     --  reception of values 11-20 shall be mapped to 'failure'
     --  reception of values > 20 shall be mapped to 'busy'
```

```
StatusReportRes ::= SEQUENCE {
     extensionContainer              [0]  ExtensionContainer          OPTIONAL,
     ...}
```

```
RemoteUserFreeArg ::= SEQUENCE{
     imsi                            [0]  IMSI,
     callInfo                        [1]  ExternalSignalInfo,
     ccbs-Feature                    [2]  CCBS-Feature,
     translatedB-Number              [3]  ISDN-AddressString,
     replaceB-Number                 [4]  NULL                        OPTIONAL,
     alertingPattern                 [5]  AlertingPattern             OPTIONAL,
     extensionContainer              [6]  ExtensionContainer          OPTIONAL,
     ...}
```

```
RemoteUserFreeRes ::= SEQUENCE{
     ruf-Outcome                     [0]  RUF-Outcome,
     extensionContainer              [1]  ExtensionContainer          OPTIONAL,
     ...}
```

```
RUF-Outcome ::= ENUMERATED{
     accepted (0),
     rejected (1),
     noResponseFromFreeMS (2), -- T4 Expiry
     noResponseFromBusyMS (3), -- T10 Expiry
     udubFromFreeMS (4),
     udubFromBusyMS (5),
     ...}
     -- exception handling:
     -- reception of values 6-20 shall be mapped to 'accepted'
     -- reception of values 21-30 shall be mapped to 'rejected'
     -- reception of values 31-40 shall be mapped to 'noResponseFromFreeMS'
     -- reception of values 41-50 shall be mapped to 'noResponseFromBusyMS'
     -- reception of values 51-60 shall be mapped to 'udubFromFreeMS'
     -- reception of values > 60 shall be mapped to 'udubFromBusyMS'
```

```
IST-AlertArg ::= SEQUENCE{
     imsi                            [0]  IMSI,
     extensionContainer              [1]  ExtensionContainer          OPTIONAL,
     ...}
```

```
IST-AlertRes ::= SEQUENCE{
     istAlertTimer                   [0]  IST-AlertTimerValue         OPTIONAL,
     istInformationWithdraw          [1]  NULL                        OPTIONAL,
     callTerminationIndicator        [2]  CallTerminationIndicator    OPTIONAL,
     extensionContainer              [3]  ExtensionContainer          OPTIONAL,
     ...}
```

```
IST-CommandArg ::= SEQUENCE{
     imsi                            [0]  IMSI,
     extensionContainer              [1]  ExtensionContainer          OPTIONAL,
     ...}
```

```
IST-CommandRes ::= SEQUENCE{
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
CallTerminationIndicator ::= ENUMERATED {
     terminateCallActivityReferred       (0),
     terminateAllCallActivities          (1),
     ...}
     -- exception handling:
     -- reception of values 2-10 shall be mapped to ' terminateCallActivityReferred '
     -- reception of values > 10 shall be mapped to ' terminateAllCallActivities '

     -- In MSCs not supporting linkage of all call activities, any value received shall
     -- be interpreted as ' terminateCallActivityReferred '
```

```
ReleaseResourcesArg ::= SEQUENCE{
     msrn                                ISDN-AddressString,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ReleaseResourcesRes ::= SEQUENCE{
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
END
```

17.7.4 Supplementary service data types

```
MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   RegisterSS-Arg,
   SS-Info,
   SS-Status,
   SS-SubscriptionOption,
   SS-ForBS-Code,
   InterrogateSS-Res,
   USSD-Arg,
   USSD-Res,
   USSD-DataCodingScheme,
   USSD-String,
   Password,
   GuidanceInfo,
   SS-List,
   SS-InfoList,
   OverrideCategory,
   CliRestrictionOption,
   NoReplyConditionTime,
   ForwardingOptions,
   maxNumOfSS,
   SS-Data,
   SS-InvocationNotificationArg,
   SS-InvocationNotificationRes,
   CCBS-Feature,
   RegisterCC-EntryArg,
   RegisterCC-EntryRes,
   EraseCC-EntryArg,
   EraseCC-EntryRes
;

IMPORTS
   AddressString,
   ISDN-AddressString,
   ISDN-SubaddressString,
   FTN-AddressString,
   IMSI,
   BasicServiceCode,
```

```
   AlertingPattern,
   EMLPP-Priority,
   MaxMC-Bearers,
   MC-Bearers,
   ExternalSignalInfo
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}

   SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version11 (11)}
;
```

```
RegisterSS-Arg ::= SEQUENCE {
     ss-Code                          SS-Code,
     basicService                     BasicServiceCode                 OPTIONAL,
     forwardedToNumber                [4] AddressString                OPTIONAL,
     forwardedToSubaddress            [6] ISDN-SubaddressString        OPTIONAL,
     noReplyConditionTime             [5] NoReplyConditionTime         OPTIONAL,
     ...,
     defaultPriority                  [7] EMLPP-Priority               OPTIONAL,
     nbrUser                          [8] MC-Bearers                   OPTIONAL,
     longFTN-Supported                [9]  NULL                        OPTIONAL }
```

```
NoReplyConditionTime ::= INTEGER (5..30)
```

```
SS-Info ::= CHOICE {
     forwardingInfo                   [0] ForwardingInfo,
     callBarringInfo                  [1] CallBarringInfo,
     ss-Data                          [3] SS-Data}
```

```
ForwardingInfo ::= SEQUENCE {
     ss-Code                          SS-Code                          OPTIONAL,
     forwardingFeatureList            ForwardingFeatureList,
     ...}
```

```
ForwardingFeatureList ::=
     SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
                                      ForwardingFeature
```

```
ForwardingFeature ::= SEQUENCE {
     basicService                     BasicServiceCode                 OPTIONAL,
     ss-Status                        [4] SS-Status                    OPTIONAL,
     forwardedToNumber                [5] ISDN-AddressString           OPTIONAL,
     forwardedToSubaddress            [8] ISDN-SubaddressString        OPTIONAL,
     forwardingOptions                [6] ForwardingOptions            OPTIONAL,
     noReplyConditionTime             [7] NoReplyConditionTime         OPTIONAL,
     ...,
     longForwardedToNumber            [9] FTN-AddressString            OPTIONAL }
```

```
SS-Status ::= OCTET STRING (SIZE (1))

     -- bits 8765: 0000 (unused)
     -- bits 4321: Used to convey the "P bit","R bit","A bit" and "Q bit",
     --            representing supplementary service state information
     --            as defined in TS 3GPP TS 23.011 [22]

     -- bit 4: "Q bit"

     -- bit 3: "P bit"

     -- bit 2: "R bit"

     -- bit 1: "A bit"
```

```
ForwardingOptions ::= OCTET STRING (SIZE (1))

     -- bit 8: notification to forwarding party
     --   0  no notification
     --   1  notification

     -- bit 7: redirecting presentation
     --   0 no presentation
     --   1  presentation

     -- bit 6: notification to calling party
     --   0  no notification
     --   1  notification

     -- bit 5: 0 (unused)

     -- bits 43: forwarding reason
     --   00  ms not reachable
     --   01  ms busy
     --   10  no reply
     --   11  unconditional when used in a SRI Result,
     --       or call deflection when used in a RCH Argument
     -- bits 21: 00 (unused)
```

```
CallBarringInfo ::= SEQUENCE {
     ss-Code                         SS-Code                         OPTIONAL,
     callBarringFeatureList          CallBarringFeatureList,
     ...}
```

```
CallBarringFeatureList ::= SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
                                     CallBarringFeature
```

```
CallBarringFeature ::= SEQUENCE {
     basicService                    BasicServiceCode                OPTIONAL,
     ss-Status [4] SS-Status         OPTIONAL,
     ...}
```

```
SS-Data ::= SEQUENCE {
     ss-Code                         SS-Code                         OPTIONAL,
     ss-Status                       [4] SS-Status                   OPTIONAL,
     ss-SubscriptionOption           SS-SubscriptionOption           OPTIONAL,
     basicServiceGroupList           BasicServiceGroupList           OPTIONAL,
     ...,
     defaultPriority                 EMLPP-Priority                  OPTIONAL,
     nbrUser                         [5] MC-Bearers                  OPTIONAL
     }
```

```
SS-SubscriptionOption ::= CHOICE {
     cliRestrictionOption            [2] CliRestrictionOption,
     overrideCategory                [1] OverrideCategory}
```

```
CliRestrictionOption ::= ENUMERATED {
     permanent  (0),
     temporaryDefaultRestricted  (1),
     temporaryDefaultAllowed  (2)}
```

```
OverrideCategory ::= ENUMERATED {
     overrideEnabled  (0),
     overrideDisabled  (1)}
```

```
SS-ForBS-Code ::= SEQUENCE {
     ss-Code                         SS-Code,
     basicService                    BasicServiceCode                OPTIONAL,
     ...,
     longFTN-Supported               [4]  NULL                       OPTIONAL }
```

```
GenericServiceInfo ::= SEQUENCE {
     ss-Status SS-Status,
     cliRestrictionOption            CliRestrictionOption            OPTIONAL,
     ...,
     maximumEntitledPriority         [0] EMLPP-Priority              OPTIONAL,
     defaultPriority                 [1] EMLPP-Priority              OPTIONAL,
     ccbs-FeatureList                [2] CCBS-FeatureList            OPTIONAL,
     nbrSB                           [3] MaxMC-Bearers               OPTIONAL,
     nbrUser                         [4] MC-Bearers                  OPTIONAL,
     nbrSN                           [5] MC-Bearers                  OPTIONAL }
```

```
CCBS-FeatureList ::= SEQUENCE SIZE (1..maxNumOfCCBS-Requests) OF
                                        CCBS-Feature
```

```
maxNumOfCCBS-Requests  INTEGER ::= 5
```

```
CCBS-Feature ::= SEQUENCE {
     ccbs-Index                         [0] CCBS-Index                  OPTIONAL,
     b-subscriberNumber                 [1] ISDN-AddressString          OPTIONAL,
     b-subscriberSubaddress             [2] ISDN-SubaddressString       OPTIONAL,
     basicServiceGroup                  [3] BasicServiceCode            OPTIONAL,
     ...}
```

```
CCBS-Index  ::= INTEGER (1..maxNumOfCCBS-Requests)
```

```
InterrogateSS-Res ::= CHOICE {
     ss-Status                          [0] SS-Status,
     basicServiceGroupList              [2] BasicServiceGroupList,
     forwardingFeatureList              [3] ForwardingFeatureList,
     genericServiceInfo                 [4]  GenericServiceInfo }
```

```
USSD-Arg ::= SEQUENCE {
     ussd-DataCodingScheme              USSD-DataCodingScheme,
     ussd-String                        USSD-String,
     ... ,
     alertingPattern                    AlertingPattern                 OPTIONAL,
     msisdn                             [0] ISDN-AddressString          OPTIONAL }
```

```
USSD-Res ::= SEQUENCE {
     ussd-DataCodingScheme              USSD-DataCodingScheme,
     ussd-String                        USSD-String,
     ...}
```

```
USSD-DataCodingScheme ::= OCTET STRING (SIZE (1))
     -- The structure of the USSD-DataCodingScheme is defined by
     -- the Cell Broadcast Data Coding Scheme as described in
     -- TS 3GPP TS 23.038 [25]
```

```
USSD-String ::= OCTET STRING (SIZE (1..maxUSSD-StringLength))
     -- The structure of the contents of the USSD-String is dependent
     -- on the USSD-DataCodingScheme as described in TS 3GPP TS 23.038 [25].
```

```
maxUSSD-StringLength  INTEGER ::= 160
```

```
Password ::= NumericString
     (FROM ("0"|"1"|"2"|"3"|"4"|"5"|"6"|"7"|"8"|"9"))
     (SIZE (4))
```

```
GuidanceInfo ::= ENUMERATED {
     enterPW  (0),
     enterNewPW  (1),
     enterNewPW-Again  (2)}
     -- How this information is really delivered to the subscriber
     -- (display, announcement, ...) is not part of this
     -- specification.
```

```
SS-List ::= SEQUENCE SIZE (1..maxNumOfSS) OF
                                        SS-Code
```

```
maxNumOfSS  INTEGER ::= 30
```

```
SS-InfoList ::= SEQUENCE SIZE (1..maxNumOfSS) OF
                                        SS-Info
```

```
BasicServiceGroupList ::= SEQUENCE SIZE (1..maxNumOfBasicServiceGroups) OF
                                        BasicServiceCode
```

```
maxNumOfBasicServiceGroups  INTEGER ::= 13
```

```
SS-InvocationNotificationArg ::= SEQUENCE {
     imsi                                [0] IMSI,
     msisdn                              [1] ISDN-AddressString,
     ss-Event                            [2] SS-Code,
     -- The following SS-Code values are allowed :
     -- ect                              SS-Code ::= '00110001'B
     -- multiPTY                         SS-Code ::= '01010001'B
     -- cd                               SS-Code ::= '00100100'B
     -- ccbs                             SS-Code ::= '01000100'B
     ss-EventSpecification               [3] SS-EventSpecification         OPTIONAL,
     extensionContainer                  [4] ExtensionContainer            OPTIONAL,
     ...,
     b-subscriberNumber                  [5]  ISDN-AddressString           OPTIONAL,
     ccbs-RequestState                   [6]  CCBS-RequestState            OPTIONAL
     }
```

```
CCBS-RequestState ::= ENUMERATED {
     request   (0),
     recall    (1),
     active    (2),
     completed (3),
     suspended (4),
     frozen    (5),
     deleted   (6)
     }
```

```
SS-InvocationNotificationRes ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...
     }
```

```
SS-EventSpecification ::= SEQUENCE SIZE (1..maxEventSpecification) OF
                                         AddressString
```

```
maxEventSpecification  INTEGER ::= 2
```

```
RegisterCC-EntryArg ::= SEQUENCE {
     ss-Code                             [0]  SS-Code,
     ccbs-Data                           [1]  CCBS-Data                    OPTIONAL,
     ...}
```

```
CCBS-Data ::= SEQUENCE {
     ccbs-Feature                        [0]  CCBS-Feature,
     translatedB-Number                  [1]  ISDN-AddressString,
     serviceIndicator                    [2]  ServiceIndicator             OPTIONAL,
     callInfo                            [3]  ExternalSignalInfo,
     networkSignalInfo                   [4]  ExternalSignalInfo,
     ...}
```

```
ServiceIndicator ::= BIT STRING {
     clir-invoked (0),
     camel-invoked (1)} (SIZE(2..32))
     -- exception handling:
     -- bits 2 to 31 shall be ignored if received and not understood
```

```
RegisterCC-EntryRes ::= SEQUENCE {
     ccbs-Feature                        [0] CCBS-Feature                  OPTIONAL,
     ...}
```

```
EraseCC-EntryArg ::= SEQUENCE {
     ss-Code                             [0]  SS-Code,
     ccbs-Index                          [1]  CCBS-Index                   OPTIONAL,
     ...}
```

```
EraseCC-EntryRes ::= SEQUENCE {
     ss-Code                             [0]  SS-Code,
     ss-Status                           [1] SS-Status                     OPTIONAL,
     ...}
```

```
END
```

17.7.5 Supplementary service codes

```
MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version11 (11)}
```

```
DEFINITIONS

::=

BEGIN
```

```
SS-Code ::= OCTET STRING (SIZE (1))
     -- This type is used to represent the code identifying a single
     -- supplementary service, a group of supplementary services, or
     -- all supplementary services. The services and abbreviations
     -- used are defined in TS 3GPP TS 22.004 [5]. The internal structure is
     -- defined as follows:
     --
     -- bits 87654321: group (bits 8765), and specific service
     -- (bits 4321)
```

```
allSS                                   SS-Code ::= '00000000'B
     -- reserved for possible future use
     -- all SS
```

```
allLineIdentificationSS                 SS-Code ::= '00010000'B
     -- reserved for possible future use
     -- all line identification SS
clip                                    SS-Code ::= '00010001'B
     -- calling line identification presentation
clir                                    SS-Code ::= '00010010'B
     -- calling line identification restriction
colp                                    SS-Code ::= '00010011'B
     -- connected line identification presentation
colr                                    SS-Code ::= '00010100'B
     -- connected line identification restriction
mci                                     SS-Code ::= '00010101'B
     -- reserved for possible future use
     -- malicious call identification

allNameIdentificationSS                 SS-Code ::= '00011000'B
     -- all name identification SS
cnap                                    SS-Code ::= '00011001'B
     -- calling name presentation

     -- SS-Codes '00011010'B to '00011111'B are reserved for future
     -- NameIdentification Supplementary Service use.
```

```
allForwardingSS                         SS-Code ::= '00100000'B
     -- all forwarding SS
cfu                                     SS-Code ::= '00100001'B
     -- call forwarding unconditional
allCondForwardingSS                     SS-Code ::= '00101000'B
     -- all conditional forwarding SS
cfb                                     SS-Code ::= '00101001'B
     -- call forwarding on mobile subscriber busy
cfnry                                   SS-Code ::= '00101010'B
     -- call forwarding on no reply
cfnrc                                   SS-Code ::= '00101011'B
     -- call forwarding on mobile subscriber not reachable
cd                                      SS-Code ::= '00100100'B
     -- call deflection
```

```
allCallOfferingSS                       SS-Code ::= '00110000'B
     -- reserved for possible future use
     -- all call offering SS includes also all forwarding SS
ect                                     SS-Code ::= '00110001'B
        -- explicit call transfer
mah                                     SS-Code ::= '00110010'B
     -- reserved for possible future use
     -- mobile access hunting
```

```
allCallCompletionSS                     SS-Code ::= '01000000'B
     -- reserved for possible future use
     -- all Call completion SS
cw                                      SS-Code ::= '01000001'B
     -- call waiting
hold                                    SS-Code ::= '01000010'B
     -- call hold
ccbs-A                                  SS-Code ::= '01000011'B
     -- completion of call to busy subscribers, originating side
     -- this SS-Code is used only in InsertSubscriberData, DeleteSubscriberData
     -- and InterrogateSS
ccbs-B                                  SS-Code ::= '01000100'B
     -- completion of call to busy subscribers, destination side
     -- this SS-Code is used only in InsertSubscriberData and DeleteSubscriberData
mc                                      SS-Code ::= '01000101'B
     -- multicall
```

```
allMultiPartySS                         SS-Code ::= '01010000'B
     -- reserved for possible future use
     -- all multiparty SS
multiPTY                                SS-Code ::= '01010001'B
     -- multiparty
```

```
allCommunityOfInterest-SS               SS-Code ::= '01100000'B
     -- reserved for possible future use
     -- all community of interest SS
cug                                     SS-Code ::= '01100001'B
     -- closed user group
```

```
allChargingSS                           SS-Code ::= '01110000'B
     -- reserved for possible future use
     -- all charging SS
aoci                                    SS-Code ::= '01110001'B
     -- advice of charge information
aocc                                    SS-Code ::= '01110010'B
     -- advice of charge charging
```

```
allAdditionalInfoTransferSS             SS-Code ::= '10000000'B
     -- reserved for possible future use
     -- all additional information transfer SS
uus1                                    SS-Code ::= '10000001'B
     -- UUS1 user-to-user signalling
uus2                                    SS-Code ::= '10000010'B
     -- UUS2 user-to-user signalling
uus3                                    SS-Code ::= '10000011'B
     -- UUS3 user-to-user signalling
```

```
allBarringSS                            SS-Code ::= '10010000'B
     -- all barring SS
barringOfOutgoingCalls                  SS-Code ::= '10010001'B
     -- barring of outgoing calls
baoc                                    SS-Code ::= '10010010'B
     -- barring of all outgoing calls
boic                                    SS-Code ::= '10010011'B
     -- barring of outgoing international calls
boicExHC                                SS-Code ::= '10010100'B
     -- barring of outgoing international calls except those directed
     -- to the home PLMN Country
barringOfIncomingCalls                  SS-Code ::= '10011001'B
     -- barring of incoming calls
baic                                    SS-Code ::= '10011010'B
     -- barring of all incoming calls
bicRoam                                 SS-Code ::= '10011011'B
     -- barring of incoming calls when roaming outside home PLMN
     -- Country
```

```
allPLMN-specificSS                      SS-Code ::= '11110000'B
plmn-specificSS-1                       SS-Code ::= '11110001'B
plmn-specificSS-2                       SS-Code ::= '11110010'B
plmn-specificSS-3                       SS-Code ::= '11110011'B
plmn-specificSS-4                       SS-Code ::= '11110100'B
plmn-specificSS-5                       SS-Code ::= '11110101'B
plmn-specificSS-6                       SS-Code ::= '11110110'B
plmn-specificSS-7                       SS-Code ::= '11110111'B
plmn-specificSS-8                       SS-Code ::= '11111000'B
plmn-specificSS-9                       SS-Code ::= '11111001'B
plmn-specificSS-A                       SS-Code ::= '11111010'B
plmn-specificSS-B                       SS-Code ::= '11111011'B
plmn-specificSS-C                       SS-Code ::= '11111100'B
plmn-specificSS-D                       SS-Code ::= '11111101'B
plmn-specificSS-E                       SS-Code ::= '11111110'B
plmn-specificSS-F                       SS-Code ::= '11111111'B
```

```
allCallPrioritySS                       SS-Code ::= '10100000'B
     -- reserved for possible future use
     -- all call priority SS
emlpp                                   SS-Code ::= '10100001'B
     -- enhanced Multilevel Precedence Pre-emption (EMLPP) service
```

```
allLCSPrivacyException                  SS-Code ::= '10110000'B
     -- all LCS Privacy Exception Classes
universal                               SS-Code ::= '10110001'B
     -- allow location by any LCS client
callSessionRelated                      SS-Code ::= '10110010'B
     -- allow location by any value added LCS client to which a call/session
     -- is established from the target MS
callSessionUnrelated                    SS-Code ::= '10110011'B
     -- allow location by designated external value added LCS clients
plmnoperator                            SS-Code ::= '10110100'B
     -- allow location by designated PLMN operator LCS clients
serviceType                             SS-Code ::= '10110101'B
     -- allow location by LCS clients of a designated LCS service type
```

```
allMOLR-SS                              SS-Code ::= '11000000'B
     -- all Mobile Originating Location Request Classes
basicSelfLocation                       SS-Code ::= '11000001'B
     -- allow an MS to request its own location
autonomousSelfLocation                  SS-Code ::= '11000010'B
     -- allow an MS to perform self location without interaction
     -- with the PLMN for a predetermined period of time
transferToThirdParty                    SS-Code ::= '11000011'B
     -- allow an MS to request transfer of its location to another LCS client
```

```
END
```

17.7.6 Short message data types

```
MAP-SM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SM-DataTypes (16) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   RoutingInfoForSM-Arg,
   RoutingInfoForSM-Res,
   MO-ForwardSM-Arg,
   MO-ForwardSM-Res,
   MT-ForwardSM-Arg,
   MT-ForwardSM-Res,
   ReportSM-DeliveryStatusArg,
   ReportSM-DeliveryStatusRes,
   AlertServiceCentreArg,
   InformServiceCentreArg,
   ReadyForSM-Arg,
   ReadyForSM-Res,
   SM-DeliveryOutcome,
   AlertReason,
```

```
   Additional-Number,
   MT-ForwardSM-VGCS-Arg,
   MT-ForwardSM-VGCS-Res
;

IMPORTS
   AddressString,
   ISDN-AddressString,
   SignalInfo,
   IMSI,
   LMSI,
   ASCI-CallReference

FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   AbsentSubscriberDiagnosticSM
FROM MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}
;
```

```
RoutingInfoForSM-Arg ::= SEQUENCE {
     msisdn                              [0] ISDN-AddressString,
     sm-RP-PRI                           [1] BOOLEAN,
     serviceCentreAddress                [2] AddressString,
     extensionContainer                  [6] ExtensionContainer            OPTIONAL,
     ... ,
     gprsSupportIndicator                [7]  NULL                         OPTIONAL,
     -- gprsSupportIndicator is set only if the SMS-GMSC supports
     -- receiving of two numbers from the HLR
     sm-RP-MTI                           [8] SM-RP-MTI                     OPTIONAL,
     sm-RP-SMEA                          [9] SM-RP-SMEA              OPTIONAL,
     sm-deliveryNotIntended              [10] SM-DeliveryNotIntended       OPTIONAL }
```

```
SM-DeliveryNotIntended ::= ENUMERATED {
     onlyIMSI-requested  (0),
     onlyMCC-MNC-requested  (1),
     ...}
```

```
SM-RP-MTI ::= INTEGER (0..10)
     -- 0 SMS Deliver
     -- 1 SMS Status Report
     -- other values are reserved for future use and shall be discarded if
     -- received
```

```
SM-RP-SMEA ::= OCTET STRING (SIZE (1..12))
     -- this parameter contains an address field which is encoded
     -- as defined in 3GPP TS 23.040. An address field contains 3 elements :
     --       address-length
     --       type-of-address
     --       address-value
```

```
RoutingInfoForSM-Res ::= SEQUENCE {
     imsi                                IMSI,
     locationInfoWithLMSI                [0] LocationInfoWithLMSI,
     extensionContainer                  [4] ExtensionContainer            OPTIONAL,
     ...}
```

```
LocationInfoWithLMSI ::= SEQUENCE {
     networkNode-Number                  [1] ISDN-AddressString,
     lmsi                                LMSI                              OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     gprsNodeIndicator                   [5]  NULL                         OPTIONAL,
     -- gprsNodeIndicator is set only if the SGSN number is sent as the
     -- Network Node Number
     additional-Number                   [6] Additional-Number             OPTIONAL
     -- NetworkNode-number can be either msc-number or sgsn-number or IP-SM-GW
     -- number or SMS Router number
     }
```

```
Additional-Number ::= CHOICE {
     msc-Number                          [0] ISDN-AddressString,
     sgsn-Number                         [1] ISDN-AddressString}
     -- additional-number can be either msc-number or sgsn-number
     -- if received networkNode-number is msc-number then the
     -- additional number is sgsn-number
     -- if received networkNode-number is sgsn-number then the
     -- additional number is msc-number
```

```
MO-ForwardSM-Arg ::= SEQUENCE {
     sm-RP-DA                            SM-RP-DA,
     sm-RP-OA                            SM-RP-OA,
     sm-RP-UI                            SignalInfo,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ... ,
     imsi                                IMSI                              OPTIONAL }
```

```
MO-ForwardSM-Res ::= SEQUENCE {
     sm-RP-UI                            SignalInfo                        OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
MT-ForwardSM-Arg ::= SEQUENCE {
     sm-RP-DA                            SM-RP-DA,
     sm-RP-OA                            SM-RP-OA,
     sm-RP-UI                            SignalInfo,
     moreMessagesToSend                  NULL                              OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
MT-ForwardSM-Res ::= SEQUENCE {
     sm-RP-UI                            SignalInfo                        OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
SM-RP-DA ::= CHOICE {
     imsi                                [0] IMSI,
     lmsi                                [1] LMSI,
     serviceCentreAddressDA              [4] AddressString,
     noSM-RP-DA                          [5] NULL}
```

```
SM-RP-OA ::= CHOICE {
     msisdn                              [2] ISDN-AddressString,
     serviceCentreAddressOA              [4] AddressString,
     noSM-RP-OA                          [5] NULL}
```

```
ReportSM-DeliveryStatusArg ::= SEQUENCE {
     msisdn                              ISDN-AddressString,
     serviceCentreAddress                AddressString,
     sm-DeliveryOutcome                  SM-DeliveryOutcome,
     absentSubscriberDiagnosticSM        [0] AbsentSubscriberDiagnosticSM
                                                                    OPTIONAL,
     extensionContainer                  [1] ExtensionContainer     OPTIONAL,
     ...,
     gprsSupportIndicator                [2]  NULL                  OPTIONAL,
     -- gprsSupportIndicator is set only if the SMS-GMSC supports
     -- handling of two delivery outcomes
     deliveryOutcomeIndicator            [3]  NULL                  OPTIONAL,
     -- DeliveryOutcomeIndicator is set when the SM-DeliveryOutcome
     -- is for GPRS
     additionalSM-DeliveryOutcome        [4]  SM-DeliveryOutcome    OPTIONAL,
     -- If received, additionalSM-DeliveryOutcome is for GPRS
     -- If DeliveryOutcomeIndicator is set, then AdditionalSM-DeliveryOutcome shall be absent
     additionalAbsentSubscriberDiagnosticSM   [5]  AbsentSubscriberDiagnosticSM OPTIONAL,
     -- If received additionalAbsentSubscriberDiagnosticSM is for GPRS
     -- If DeliveryOutcomeIndicator is set, then AdditionalAbsentSubscriberDiagnosticSM
     -- shall be absent
     ip-sm-gw-Indicator                  [6]  NULL                  OPTIONAL,
     -- the ip-sm-gw indicator indicates by its presence that sm-deliveryOutcome
     -- is for delivery via IMS
     -- If present, deliveryOutcomeIndicator shall be absent.
     ip-sm-gw-sm-deliveryOutcome         [7]  SM-DeliveryOutcome    OPTIONAL,
     -- If received ip-sm-gw-sm-deliveryOutcome is for delivery via IMS
     -- If ip-sm-gw-Indicator is set, then ip-sm-gw-sm-deliveryOutcome shall be absent
     ip-sm-gw-absentSubscriberDiagnosticSM    [8]  AbsentSubscriberDiagnosticSM OPTIONAL
     -- If received ip-sm-gw-sm-absentSubscriberDiagnosticSM is for delivery via IMS
     -- If ip-sm-gw-Indicator is set, then ip-sm-gw-sm-absentSubscriberDiagnosticSM
     -- shall be absent
}
```

```
SM-DeliveryOutcome ::= ENUMERATED {
     memoryCapacityExceeded  (0),
     absentSubscriber  (1),
     successfulTransfer  (2)}
```

```
ReportSM-DeliveryStatusRes ::= SEQUENCE {
     storedMSISDN                        ISDN-AddressString         OPTIONAL,
     extensionContainer                  ExtensionContainer         OPTIONAL,
     ...}
```

```
AlertServiceCentreArg ::= SEQUENCE {
     msisdn                              ISDN-AddressString,
     serviceCentreAddress                AddressString,
     ...}
```

```
InformServiceCentreArg ::= SEQUENCE {
     storedMSISDN                        ISDN-AddressString         OPTIONAL,
     mw-Status MW-Status                 OPTIONAL,
     extensionContainer                  ExtensionContainer         OPTIONAL,
     ... ,
     absentSubscriberDiagnosticSM        AbsentSubscriberDiagnosticSM      OPTIONAL,
     additionalAbsentSubscriberDiagnosticSM   [0]  AbsentSubscriberDiagnosticSM OPTIONAL }
     -- additionalAbsentSubscriberDiagnosticSM may be present only if
     -- absentSubscriberDiagnosticSM is present.
     -- if included, additionalAbsentSubscriberDiagnosticSM is for GPRS and
     -- absentSubscriberDiagnosticSM is for non-GPRS
```

```
MW-Status ::= BIT STRING {
     sc-AddressNotIncluded  (0),
     mnrf-Set  (1),
     mcef-Set  (2) ,
     mnrg-Set    (3)} (SIZE (6..16))
     -- exception handling:
     -- bits 4 to 15 shall be ignored if received and not understood
```

```
ReadyForSM-Arg ::= SEQUENCE {
     imsi                                [0] IMSI,
     alertReason                         AlertReason,
     alertReasonIndicator                NULL                                OPTIONAL,
     -- alertReasonIndicator is set only when the alertReason
     -- sent to HLR is for GPRS
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...,
     additionalAlertReasonIndicator      [1] NULL                            OPTIONAL
     -- additionalAlertReasonIndicator is set only when the alertReason
     -- sent to HLR is for IP-SM-GW
     }
```

```
ReadyForSM-Res ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...}
```

```
AlertReason ::= ENUMERATED {
     ms-Present  (0),
     memoryAvailable  (1)}
```

```
MT-ForwardSM-VGCS-Arg ::= SEQUENCE {
     asciCallReference                   ASCI-CallReference,
     sm-RP-OA                            SM-RP-OA,
     sm-RP-UI                            SignalInfo,
     extensionContainer                  ExtensionContainer                  OPTIONAL,
     ...}
```

```
MT-ForwardSM-VGCS-Res ::= SEQUENCE {
     sm-RP-UI                            [0] SignalInfo                      OPTIONAL,
     dispatcherList                      [1] DispatcherList                  OPTIONAL,
     ongoingCall                         NULL                                OPTIONAL,
     extensionContainer                  [2] ExtensionContainer              OPTIONAL,
     ...}
```

```
DispatcherList ::=
     SEQUENCE SIZE (1..maxNumOfDispatchers) OF
                                         ISDN-AddressString
```

```
maxNumOfDispatchers  INTEGER ::= 5
```

```
END
```

17.7.7 Error data types

```
MAP-ER-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ER-DataTypes (17) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   RoamingNotAllowedParam,
   CallBarredParam,
   CUG-RejectParam,
   SS-IncompatibilityCause,
   PW-RegistrationFailureCause,
   SM-DeliveryFailureCause,
   SystemFailureParam,
   DataMissingParam,
   UnexpectedDataParam,
   FacilityNotSupParam,
   OR-NotAllowedParam,
   UnknownSubscriberParam,
   NumberChangedParam,
   UnidentifiedSubParam,
   IllegalSubscriberParam,
   IllegalEquipmentParam,
   BearerServNotProvParam,
```

```
   TeleservNotProvParam,
   TracingBufferFullParam,
   NoRoamingNbParam,
   AbsentSubscriberParam,
   BusySubscriberParam,
   NoSubscriberReplyParam,
   ForwardingViolationParam,
   ForwardingFailedParam,
   ATI-NotAllowedParam,
   SubBusyForMT-SMS-Param,
   MessageWaitListFullParam,
   AbsentSubscriberSM-Param,
   AbsentSubscriberDiagnosticSM,
   ResourceLimitationParam,
   NoGroupCallNbParam,
   IncompatibleTerminalParam,
   ShortTermDenialParam,
   LongTermDenialParam,
   UnauthorizedRequestingNetwork-Param,
   UnauthorizedLCSClient-Param,
   PositionMethodFailure-Param,
   UnknownOrUnreachableLCSClient-Param,
   MM-EventNotSupported-Param,
   ATSI-NotAllowedParam,
   ATM-NotAllowedParam,
   IllegalSS-OperationParam,
   SS-NotAvailableParam,
   SS-SubscriptionViolationParam,
   InformationNotAvailableParam,
   TargetCellOutsideGCA-Param,
   OngoingGroupCallParam

;

IMPORTS
   SS-Status
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-DataTypes (14) version11 (11)}

   SignalInfo,
   BasicServiceCode,
   NetworkResource,
   AdditionalNetworkResource
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}


   SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}
;
```

```
RoamingNotAllowedParam ::= SEQUENCE {
     roamingNotAllowedCause               RoamingNotAllowedCause,
     extensionContainer                   ExtensionContainer                OPTIONAL,
     ...,
     additionalRoamingNotAllowedCause     [0] AdditionalRoamingNotAllowedCause OPTIONAL }

--   if the additionalRoamingNotallowedCause is received by the MSC/VLR or SGSN then the
--   roamingNotAllowedCause shall be discarded.
```

```
AdditionalRoamingNotAllowedCause ::= ENUMERATED {
     supportedRAT-TypesNotAllowed (0),
     ...}
```

```
RoamingNotAllowedCause ::= ENUMERATED {
     plmnRoamingNotAllowed  (0),
     operatorDeterminedBarring  (3)}
```

```
CallBarredParam ::= CHOICE {
     callBarringCause                    CallBarringCause,
     -- call BarringCause must not be used in version 3 and higher
     extensibleCallBarredParam           ExtensibleCallBarredParam
     -- extensibleCallBarredParam must not be used in version <3
     }
```

```
CallBarringCause ::= ENUMERATED {
     barringServiceActive  (0),
     operatorBarring  (1)}
```

```
ExtensibleCallBarredParam ::= SEQUENCE {
     callBarringCause                    CallBarringCause                  OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ... ,
     unauthorisedMessageOriginator       [1] NULL                          OPTIONAL }
```

```
CUG-RejectParam ::= SEQUENCE {
     cug-RejectCause                     CUG-RejectCause                   OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
CUG-RejectCause ::= ENUMERATED {
     incomingCallsBarredWithinCUG  (0),
     subscriberNotMemberOfCUG  (1),
     requestedBasicServiceViolatesCUG-Constraints  (5),
     calledPartySS-InteractionViolation  (7)}
```

```
SS-IncompatibilityCause ::= SEQUENCE {
     ss-Code                             [1] SS-Code                       OPTIONAL,
     basicService                        BasicServiceCode                  OPTIONAL,
     ss-Status                           [4] SS-Status                     OPTIONAL,
     ...}
```

```
PW-RegistrationFailureCause ::= ENUMERATED {
     undetermined  (0),
     invalidFormat  (1),
     newPasswordsMismatch  (2)}
```

```
SM-EnumeratedDeliveryFailureCause ::= ENUMERATED {
     memoryCapacityExceeded  (0),
     equipmentProtocolError  (1),
     equipmentNotSM-Equipped  (2),
     unknownServiceCentre  (3),
     sc-Congestion  (4),
     invalidSME-Address  (5),
     subscriberNotSC-Subscriber  (6)}
```

```
SM-DeliveryFailureCause ::= SEQUENCE {
     sm-EnumeratedDeliveryFailureCause   SM-EnumeratedDeliveryFailureCause,
     diagnosticInfo                      SignalInfo                        OPTIONAL,
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
AbsentSubscriberSM-Param ::= SEQUENCE {
     absentSubscriberDiagnosticSM        AbsentSubscriberDiagnosticSM      OPTIONAL,
     -- AbsentSubscriberDiagnosticSM can be either for non-GPRS
     -- or for GPRS
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     additionalAbsentSubscriberDiagnosticSM    [0]  AbsentSubscriberDiagnosticSM OPTIONAL }
     -- if received, additionalAbsentSubscriberDiagnosticSM
     -- is for GPRS and absentSubscriberDiagnosticSM is
     -- for non-GPRS
```

```
AbsentSubscriberDiagnosticSM ::= INTEGER (0..255)
     -- AbsentSubscriberDiagnosticSM values are defined in 3GPP TS 23.040
```

```
SystemFailureParam ::= CHOICE {
     networkResource                     NetworkResource,
     -- networkResource must not be used in version 3
     extensibleSystemFailureParam        ExtensibleSystemFailureParam
     -- extensibleSystemFailureParam must not be used in version <3
     }
```

```
ExtensibleSystemFailureParam ::= SEQUENCE {
     networkResource                    NetworkResource                  OPTIONAL,
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...,
     additionalNetworkResource          [0] AdditionalNetworkResource    OPTIONAL,
     failureCauseParam                  [1] FailureCauseParam            OPTIONAL }
```

```
FailureCauseParam ::= ENUMERATED {
     limitReachedOnNumberOfConcurrentLocationRequests (0),
     ... }
     -- if unknown value is received in FailureCauseParam it shall be ignored
```

```
DataMissingParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
UnexpectedDataParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
FacilityNotSupParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...,
     shapeOfLocationEstimateNotSupported [0]   NULL                      OPTIONAL,
     neededLcsCapabilityNotSupportedInServingNode [1] NULL               OPTIONAL }
```

```
OR-NotAllowedParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
UnknownSubscriberParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...,
     unknownSubscriberDiagnostic        UnknownSubscriberDiagnostic      OPTIONAL}
```

```
UnknownSubscriberDiagnostic ::= ENUMERATED {
     imsiUnknown  (0),
     gprs-eps-SubscriptionUnknown  (1),
     ...,
     npdbMismatch  (2)}
     -- if unknown values are received in
     -- UnknownSubscriberDiagnostic they shall be discarded
```

```
NumberChangedParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
UnidentifiedSubParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
IllegalSubscriberParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
IllegalEquipmentParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
BearerServNotProvParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
TeleservNotProvParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
TracingBufferFullParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
NoRoamingNbParam ::= SEQUENCE {
     extensionContainer                 ExtensionContainer               OPTIONAL,
     ...}
```

```
AbsentSubscriberParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     absentSubscriberReason              [0] AbsentSubscriberReason        OPTIONAL}
```

```
AbsentSubscriberReason ::= ENUMERATED {
     imsiDetach (0),
     restrictedArea (1),
     noPageResponse (2),
     ... ,
     purgedMS (3)}
-- exception handling: at reception of other values than the ones listed the
-- AbsentSubscriberReason shall be ignored.
-- The AbsentSubscriberReason: purgedMS is defined for the Super-Charger feature
-- (see TS 23.116). If this value is received in a Provide Roaming Number response
-- it shall be mapped to the AbsentSubscriberReason: imsiDetach in the Send Routeing
-- Information response
```

```
BusySubscriberParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     ccbs-Possible                       [0] NULL                          OPTIONAL,
     ccbs-Busy                           [1] NULL                          OPTIONAL}
```

```
NoSubscriberReplyParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ForwardingViolationParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ForwardingFailedParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ATI-NotAllowedParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ATSI-NotAllowedParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ATM-NotAllowedParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
IllegalSS-OperationParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
SS-NotAvailableParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
SS-SubscriptionViolationParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
InformationNotAvailableParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
SubBusyForMT-SMS-Param ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ... ,
     gprsConnectionSuspended             NULL                              OPTIONAL }
     -- If GprsConnectionSuspended is not understood it shall
     -- be discarded
```

```
MessageWaitListFullParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ResourceLimitationParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
NoGroupCallNbParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
IncompatibleTerminalParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
ShortTermDenialParam ::= SEQUENCE {
     ...}
```

```
LongTermDenialParam ::= SEQUENCE {
     ...}
```

```
UnauthorizedRequestingNetwork-Param ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
UnauthorizedLCSClient-Param ::= SEQUENCE {
     unauthorizedLCSClient-Diagnostic     [0] UnauthorizedLCSClient-Diagnostic   OPTIONAL,
     extensionContainer                   [1] ExtensionContainer                 OPTIONAL,
     ... }
```

```
UnauthorizedLCSClient-Diagnostic ::= ENUMERATED {
     noAdditionalInformation (0),
     clientNotInMSPrivacyExceptionList (1),
     callToClientNotSetup (2),
     privacyOverrideNotApplicable (3),
     disallowedByLocalRegulatoryRequirements (4),
     ...,
     unauthorizedPrivacyClass (5),
     unauthorizedCallSessionUnrelatedExternalClient (6),
     unauthorizedCallSessionRelatedExternalClient (7) }
--   exception handling:
--   any unrecognized value shall be ignored
```

```
PositionMethodFailure-Param ::= SEQUENCE {
     positionMethodFailure-Diagnostic     [0] PositionMethodFailure-Diagnostic   OPTIONAL,
     extensionContainer                   [1] ExtensionContainer                 OPTIONAL,
     ... }
```

```
PositionMethodFailure-Diagnostic ::= ENUMERATED {
     congestion  (0),
     insufficientResources  (1),
     insufficientMeasurementData  (2),
     inconsistentMeasurementData  (3),
     locationProcedureNotCompleted  (4),
     locationProcedureNotSupportedByTargetMS  (5),
     qoSNotAttainable  (6),
     positionMethodNotAvailableInNetwork  (7),
     positionMethodNotAvailableInLocationArea  (8),
     ... }
--   exception handling:
--   any unrecognized value shall be ignored
```

```
UnknownOrUnreachableLCSClient-Param ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
MM-EventNotSupported-Param ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
TargetCellOutsideGCA-Param ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
OngoingGroupCallParam ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...}
```

```
END
```

17.7.8 Common data types

```
MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS

   -- general data types and values
   AddressString,
   ISDN-AddressString,
   maxISDN-AddressLength,
   FTN-AddressString,
   ISDN-SubaddressString,
   ExternalSignalInfo,
   Ext-ExternalSignalInfo,
   AccessNetworkSignalInfo,
   SignalInfo,
   maxSignalInfoLength,
   AlertingPattern,
   TBCD-STRING,

   -- data types for numbering and identification
   IMSI,
   TMSI,
   Identity,
   SubscriberId,
   IMEI,
   HLR-List,
   LMSI,
   GlobalCellId,
   NetworkResource,
   AdditionalNetworkResource,
   NAEA-PreferredCI,
   NAEA-CIC,
   ASCI-CallReference,
   SubscriberIdentity,
   PLMN-Id,

   -- data types for CAMEL
   CellGlobalIdOrServiceAreaIdOrLAI,
   CellGlobalIdOrServiceAreaIdFixedLength,
   LAIFixedLength,

   -- data types for subscriber management
   BasicServiceCode,
   Ext-BasicServiceCode,
   EMLPP-Info,
   EMLPP-Priority,
   MC-SS-Info,
   MaxMC-Bearers,
   MC-Bearers,
   Ext-SS-Status,

   -- data types for geographic location
   AgeOfLocationInformation,
   LCSClientExternalID,
   LCSClientInternalID,
   LCSServiceTypeID,

   -- gprs location registration types
   GSN-Address

;

IMPORTS
   TeleserviceCode,
   Ext-TeleserviceCode
```

```
FROM MAP-TS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version11 (11)}

   BearerServiceCode,
   Ext-BearerServiceCode
FROM MAP-BS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-BS-Code (20) version11 (11)}

   SS-Code
FROM MAP-SS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SS-Code (15) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}
;


-- general data types
```

```
TBCD-STRING ::= OCTET STRING
     -- This type (Telephony Binary Coded Decimal String) is used to
     -- represent several digits from 0 through 9, *, #, a, b, c, two
     -- digits per octet, each digit encoded 0000 to 1001 (0 to 9),
     -- 1010 (*), 1011 (#), 1100 (a), 1101 (b) or 1110 (c); 1111 used
     -- as filler when there is an odd number of digits.

     -- bits 8765 of octet n encoding digit 2n
     -- bits 4321 of octet n encoding digit 2(n-1) +1
```

```
AddressString ::= OCTET STRING (SIZE (1..maxAddressLength))
     -- This type is used to represent a number for addressing
     -- purposes. It is composed of
     --   a)   one octet for nature of address, and numbering plan
     --        indicator.
     --   b)   digits of an address encoded as TBCD-String.

     -- a)     The first octet includes a one bit extension indicator, a
     --        3 bits nature of address indicator and a 4 bits numbering
     --        plan indicator, encoded as follows:

     -- bit 8: 1  (no extension)

     -- bits 765: nature of address indicator
     --   000  unknown
     --   001  international number
     --   010  national significant number
     --   011  network specific number
     --   100  subscriber number
     --   101  reserved
     --   110  abbreviated number
     --   111  reserved for extension

     -- bits 4321: numbering plan indicator
     --   0000  unknown
     --   0001  ISDN/Telephony Numbering Plan (Rec ITU-T E.164)
     --   0010  spare
     --   0011  data numbering plan (ITU-T Rec X.121)
     --   0100  telex numbering plan (ITU-T Rec F.69)
     --   0101  spare
     --   0110  land mobile numbering plan (ITU-T Rec E.212)
     --   0111  spare
     --   1000  national numbering plan
     --   1001  private numbering plan
     --   1111  reserved for extension

     --   all other values are reserved.

     -- b)     The following octets representing digits of an address
     --        encoded as a TBCD-STRING.
```

```
maxAddressLength  INTEGER ::= 20
```

```
ISDN-AddressString ::=
              AddressString (SIZE (1..maxISDN-AddressLength))
     -- This type is used to represent ISDN numbers.
```

```
maxISDN-AddressLength  INTEGER ::= 9
```

```
FTN-AddressString ::=
              AddressString (SIZE (1..maxFTN-AddressLength))
     -- This type is used to represent forwarded-to numbers.
     -- If NAI = international the first digits represent the country code (CC)
     -- and the network destination code (NDC) as for E.164.
```

```
maxFTN-AddressLength  INTEGER ::= 15
```

```
ISDN-SubaddressString ::=
              OCTET STRING (SIZE (1..maxISDN-SubaddressLength))
     -- This type is used to represent ISDN subaddresses.
     -- It is composed of
     --   a)   one octet for type of subaddress and odd/even indicator.
     --   b)   20 octets for subaddress information.

     --   a)   The first octet includes a one bit extension indicator, a
     --        3 bits type of subaddress and a one bit odd/even indicator,
     --        encoded as follows:

     --   bit 8: 1  (no extension)

     --   bits 765: type of subaddress
     --        000  NSAP (X.213/ISO 8348 AD2)
     --        010  User Specified
     --        All other values are reserved

     --   bit 4: odd/even indicator
     --        0  even number of address signals
     --        1  odd number of address signals
     --        The odd/even indicator is used when the type of subaddress
     --        is "user specified" and the coding is BCD.

     --   bits 321: 000 (unused)

     --   b) Subaddress information.
     --   The NSAP X.213/ISO8348AD2 address shall be formatted as specified
     --   by octet 4 which contains the Authority and Format Identifier
     --   (AFI). The encoding is made according to the "preferred binary
     --   encoding" as defined in X.213/ISO834AD2. For the definition
     --   of this type of subaddress, see ITU-T Rec I.334.

     --   For User-specific subaddress, this field is encoded according
     --   to the user specification, subject to a maximum length of 20
     --   octets. When interworking with X.25 networks BCD coding should
     --   be applied.
```

```
maxISDN-SubaddressLength  INTEGER ::= 21
```

```
ExternalSignalInfo ::= SEQUENCE {
     protocolId                          ProtocolId,
     signalInfo                          SignalInfo,
     -- Information about the internal structure is given in
     -- clause 7.6.9.
     extensionContainer                  ExtensionContainer                OPTIONAL,
     -- extensionContainer must not be used in version 2
     ...}
```

```
SignalInfo ::= OCTET STRING (SIZE (1..maxSignalInfoLength))
```

```
maxSignalInfoLength  INTEGER ::= 200
     -- This NamedValue represents the theoretical maximum number of octets which is
     -- available to carry a single instance of the SignalInfo data type,
     -- without requiring segmentation to cope with the network layer service.
     -- However, the actual maximum size available for an instance of the data
     -- type may be lower, especially when other information elements
     -- have to be included in the same component.
```

```
ProtocolId ::= ENUMERATED {
     gsm-0408  (1),
     gsm-0806  (2),
     gsm-BSSMAP  (3),
     -- Value 3 is reserved and must not be used
     ets-300102-1  (4)}
```

```
Ext-ExternalSignalInfo ::= SEQUENCE {
     ext-ProtocolId                    Ext-ProtocolId,
     signalInfo                        SignalInfo,
     -- Information about the internal structure is given in
     -- clause 7.6.9.10
     extensionContainer                ExtensionContainer              OPTIONAL,
     ...}
```

```
Ext-ProtocolId ::= ENUMERATED {
     ets-300356  (1),
     ...
      }
-- exception handling:
-- For Ext-ExternalSignalInfo sequences containing this parameter with any
-- other value than the ones listed the receiver shall ignore the whole
-- Ext-ExternalSignalInfo sequence.
```

```
AccessNetworkSignalInfo ::= SEQUENCE {
     accessNetworkProtocolId           AccessNetworkProtocolId,
     signalInfo                        LongSignalInfo,
     -- Information about the internal structure is given in clause 7.6.9.1

     extensionContainer                ExtensionContainer              OPTIONAL,
     ...}
```

```
LongSignalInfo ::= OCTET STRING (SIZE (1..maxLongSignalInfoLength))
```

```
maxLongSignalInfoLength  INTEGER ::= 2560
     -- This Named Value represents the maximum number of octets which is available
     -- to carry a single instance of the LongSignalInfo data type using
     -- White Book SCCP with the maximum number of segments.
     -- It takes account of the octets used by the lower layers of the protocol, and
     -- other information elements which may be included in the same component.
```

```
AccessNetworkProtocolId ::= ENUMERATED {
     ts3G-48006   (1),
     ts3G-25413 (2),
     ...}
     -- exception handling:
     -- For AccessNetworkSignalInfo sequences containing this parameter with any
     -- other value than the ones listed the receiver shall ignore the whole
     -- AccessNetworkSignalInfo sequence.
```

```
AlertingPattern ::= OCTET STRING (SIZE (1) )
     -- This type is used to represent Alerting Pattern

     --   bits 8765 : 0000 (unused)

     --   bits 43 : type of Pattern
     --        00 level
     --        01 category
     --        10 category
     --        all other values are reserved.

     --   bits 21 : type of alerting

alertingLevel-0   AlertingPattern ::= '00000000'B
alertingLevel-1   AlertingPattern ::= '00000001'B
alertingLevel-2   AlertingPattern ::= '00000010'B
     -- all other values of Alerting level are reserved
     -- Alerting Levels are defined in GSM 02.07

alertingCategory-1   AlertingPattern ::= '00000100'B
alertingCategory-2   AlertingPattern ::= '00000101'B
alertingCategory-3   AlertingPattern ::= '00000110'B
alertingCategory-4   AlertingPattern ::= '00000111'B
alertingCategory-5   AlertingPattern ::= '00001000'B
     -- all other values of Alerting Category are reserved
     -- Alerting categories are defined in GSM 02.07
```

```
GSN-Address ::= OCTET STRING (SIZE (5..17))
     -- Octets are coded according to TS 3GPP TS 23.003 [17]
```

```
-- data types for numbering and identification
```

```
IMSI ::= TBCD-STRING (SIZE (3..8))
     -- digits of MCC, MNC, MSIN are concatenated in this order.
```

```
Identity ::= CHOICE {
     imsi                                IMSI,
     imsi-WithLMSI                       IMSI-WithLMSI}
```

```
IMSI-WithLMSI ::= SEQUENCE {
     imsi                                IMSI,
     lmsi                                LMSI,
     -- a special value 00000000 indicates that the LMSI is not in use
     ...}
```

```
ASCI-CallReference ::= TBCD-STRING (SIZE (1..8))
     -- digits of VGCS/VBS-area,Group-ID are concatenated in this order if there is a
     -- VGCS/VBS-area.
```

```
TMSI ::= OCTET STRING (SIZE (1..4))
```

```
SubscriberId ::= CHOICE {
     imsi                                [0] IMSI,
     tmsi                                [1] TMSI}
```

```
IMEI ::= TBCD-STRING (SIZE (8))
     --   Refers to International Mobile Station Equipment Identity
     --   and Software Version Number (SVN) defined in TS 3GPP TS 23.003 [17].
     --   If the SVN is not present the last octet shall contain the
     --   digit 0 and a filler.
     --   If present the SVN shall be included in the last octet.
```

```
HLR-Id ::= IMSI
     -- leading digits of IMSI, i.e. (MCC, MNC, leading digits of
     -- MSIN) forming HLR Id defined in TS 3GPP TS 23.003 [17].
```

```
HLR-List ::= SEQUENCE SIZE (1..maxNumOfHLR-Id) OF
                                         HLR-Id
```

```
maxNumOfHLR-Id  INTEGER ::= 50
```

```
LMSI ::= OCTET STRING (SIZE (4))
```

```
GlobalCellId ::= OCTET STRING (SIZE (5..7))
     -- Refers to Cell Global Identification defined in TS 3GPP TS 23.003 [17].
     -- The internal structure is defined as follows:
     -- octet 1 bits 4321                Mobile Country Code 1st digit
     --         bits 8765                Mobile Country Code 2nd digit
     -- octet 2 bits 4321                Mobile Country Code 3rd digit
     --         bits 8765                Mobile Network Code 3rd digit
     --                                  or filler (1111) for 2 digit MNCs
     -- octet 3 bits 4321                Mobile Network Code 1st digit
     --         bits 8765                Mobile Network Code 2nd digit
     -- octets 4 and 5                   Location Area Code according to TS 3GPP TS 24.008
[35]
     -- octets 6 and 7                   Cell Identity (CI) according to TS 3GPP TS 24.008
[35]
```

```
NetworkResource ::= ENUMERATED {
     plmn  (0),
     hlr  (1),
     vlr  (2),
     pvlr  (3),
     controllingMSC  (4),
     vmsc  (5),
     eir  (6),
     rss  (7)}
```

```
AdditionalNetworkResource ::= ENUMERATED {
     sgsn (0),
     ggsn (1),
     gmlc (2),
     gsmSCF (3),
     nplr (4),
     auc (5),
     ... ,
     ue (6),
     mme (7)}
     -- if unknown value is received in AdditionalNetworkResource
     -- it shall be ignored.
```

```
NAEA-PreferredCI ::= SEQUENCE {
     naea-PreferredCIC                  [0] NAEA-CIC,
     extensionContainer                 [1] ExtensionContainer          OPTIONAL,
     ...}
```

```
NAEA-CIC ::= OCTET STRING (SIZE (3))
     -- The internal structure is defined by the Carrier Identification
     -- parameter in ANSI T1.113.3. Carrier codes between '000' and '999' may
     -- be encoded as 3 digits using '000' to '999' or as 4 digits using
     -- '0000' to '0999'. Carrier codes between '1000' and '9999' are encoded
     -- using 4 digits.
```

```
SubscriberIdentity ::= CHOICE {
     imsi                               [0] IMSI,
     msisdn                             [1] ISDN-AddressString
     }
```

```
LCSClientExternalID ::= SEQUENCE {
     externalAddress                    [0] ISDN-AddressString          OPTIONAL,
     extensionContainer                 [1] ExtensionContainer          OPTIONAL,
     ... }
```

```
LCSClientInternalID ::= ENUMERATED {
     broadcastService                   (0),
     o-andM-HPLMN                       (1),
     o-andM-VPLMN                       (2),
     anonymousLocation                  (3),
     targetMSsubscribedService          (4),
     ... }
-- for a CAMEL phase 3 PLMN operator client, the value targetMSsubscribedService shall be used
```

```
LCSServiceTypeID ::= INTEGER (0..127)
     -- the integer values 0-63 are reserved for Standard LCS service types
     -- the integer values 64-127 are reserved for Non Standard LCS service types
```

```
-- Standard LCS Service Types
emergencyServices                           LCSServiceTypeID ::= 0
emergencyAlertServices                      LCSServiceTypeID ::= 1
personTracking                              LCSServiceTypeID ::= 2
fleetManagement                             LCSServiceTypeID ::= 3
assetManagement                             LCSServiceTypeID ::= 4
trafficCongestionReporting                  LCSServiceTypeID ::= 5
roadsideAssistance                          LCSServiceTypeID ::= 6
routingToNearestCommercialEnterprise        LCSServiceTypeID ::= 7
navigation                                  LCSServiceTypeID ::= 8
     --this service type is reserved for use in previous releases
citySightseeing                             LCSServiceTypeID ::= 9
localizedAdvertising                        LCSServiceTypeID ::= 10
mobileYellowPages                           LCSServiceTypeID ::= 11
trafficAndPublicTransportationInfo          LCSServiceTypeID ::= 12
weather                                     LCSServiceTypeID ::= 13
assetAndServiceFinding                      LCSServiceTypeID ::= 14
gaming                                      LCSServiceTypeID ::= 15
findYourFriend                              LCSServiceTypeID ::= 16
dating                                      LCSServiceTypeID ::= 17
chatting                                    LCSServiceTypeID ::= 18
routeFinding                                LCSServiceTypeID ::= 19
whereAmI                                    LCSServiceTypeID ::= 20

-- The values of LCSServiceTypeID are defined according to 3GPP TS 22.071.
```

```
-- Non Standard LCS Service Types
serv64                                          LCSServiceTypeID ::= 64
serv65                                          LCSServiceTypeID ::= 65
serv66                                          LCSServiceTypeID ::= 66
serv67                                          LCSServiceTypeID ::= 67
serv68                                          LCSServiceTypeID ::= 68
serv69                                          LCSServiceTypeID ::= 69
serv70                                          LCSServiceTypeID ::= 70
serv71                                          LCSServiceTypeID ::= 71
serv72                                          LCSServiceTypeID ::= 72
serv73                                          LCSServiceTypeID ::= 73
serv74                                          LCSServiceTypeID ::= 74
serv75                                          LCSServiceTypeID ::= 75
serv76                                          LCSServiceTypeID ::= 76
serv77                                          LCSServiceTypeID ::= 77
serv78                                          LCSServiceTypeID ::= 78
serv79                                          LCSServiceTypeID ::= 79
serv80                                          LCSServiceTypeID ::= 80
serv81                                          LCSServiceTypeID ::= 81
serv82                                          LCSServiceTypeID ::= 82
serv83                                          LCSServiceTypeID ::= 83
serv84                                          LCSServiceTypeID ::= 84
serv85                                          LCSServiceTypeID ::= 85
serv86                                          LCSServiceTypeID ::= 86
serv87                                          LCSServiceTypeID ::= 87
serv88                                          LCSServiceTypeID ::= 88
serv89                                          LCSServiceTypeID ::= 89
serv90                                          LCSServiceTypeID ::= 90
serv91                                          LCSServiceTypeID ::= 91
serv92                                          LCSServiceTypeID ::= 92
serv93                                          LCSServiceTypeID ::= 93
serv94                                          LCSServiceTypeID ::= 94
serv95                                          LCSServiceTypeID ::= 95
serv96                                          LCSServiceTypeID ::= 96
serv97                                          LCSServiceTypeID ::= 97
serv98                                          LCSServiceTypeID ::= 98
serv99                                          LCSServiceTypeID ::= 99
serv100                                         LCSServiceTypeID ::= 100
serv101                                         LCSServiceTypeID ::= 101
serv102                                         LCSServiceTypeID ::= 102
serv103                                         LCSServiceTypeID ::= 103
serv104                                         LCSServiceTypeID ::= 104
serv105                                         LCSServiceTypeID ::= 105
serv106                                         LCSServiceTypeID ::= 106
serv107                                         LCSServiceTypeID ::= 107
serv108                                         LCSServiceTypeID ::= 108
serv109                                         LCSServiceTypeID ::= 109
serv110                                         LCSServiceTypeID ::= 110
serv111                                         LCSServiceTypeID ::= 111
serv112                                         LCSServiceTypeID ::= 112
serv113                                         LCSServiceTypeID ::= 113
serv114                                         LCSServiceTypeID ::= 114
serv115                                         LCSServiceTypeID ::= 115
serv116                                         LCSServiceTypeID ::= 116
serv117                                         LCSServiceTypeID ::= 117
serv118                                         LCSServiceTypeID ::= 118
serv119                                         LCSServiceTypeID ::= 119
serv120                                         LCSServiceTypeID ::= 120
serv121                                         LCSServiceTypeID ::= 121
serv122                                         LCSServiceTypeID ::= 122
serv123                                         LCSServiceTypeID ::= 123
serv124                                         LCSServiceTypeID ::= 124
serv125                                         LCSServiceTypeID ::= 125
serv126                                         LCSServiceTypeID ::= 126
serv127                                         LCSServiceTypeID ::= 127
```

```
PLMN-Id ::= OCTET STRING (SIZE (3))
    -- The internal structure is defined as follows:
    -- octet 1 bits 4321                Mobile Country Code 1st digit
    --         bits 8765                Mobile Country Code 2nd digit
    -- octet 2 bits 4321                Mobile Country Code 3rd digit
    --         bits 8765                Mobile Network Code 3rd digit
    --                                  or filler (1111) for 2 digit MNCs
    -- octet 3 bits 4321                Mobile Network Code 1st digit
    --         bits 8765                Mobile Network Code 2nd digit
```

-- data types for CAMEL

```
CellGlobalIdOrServiceAreaIdOrLAI ::= CHOICE {
    cellGlobalIdOrServiceAreaIdFixedLength   [0] CellGlobalIdOrServiceAreaIdFixedLength,
    laiFixedLength                           [1] LAIFixedLength}
```

```
CellGlobalIdOrServiceAreaIdFixedLength ::= OCTET STRING (SIZE (7))
    -- Refers to Cell Global Identification or Service Are Identification
    -- defined in 3GPP TS 23.003.
    -- The internal structure is defined as follows:
    -- octet 1 bits 4321                Mobile Country Code 1st digit
    --         bits 8765                Mobile Country Code 2nd digit
    -- octet 2 bits 4321                Mobile Country Code 3rd digit
    --         bits 8765                Mobile Network Code 3rd digit
    --                                  or filler (1111) for 2 digit MNCs
    -- octet 3 bits 4321                Mobile Network Code 1st digit
    --         bits 8765                Mobile Network Code 2nd digit
    -- octets 4 and 5                   Location Area Code according to 3GPP TS 24.008
    -- octets 6 and 7                   Cell Identity (CI) value or
    --                                  Service Area Code (SAC) value
    --                                  according to 3GPP TS 23.003
```

```
LAIFixedLength ::= OCTET STRING (SIZE (5))
    -- Refers to Location Area Identification defined in 3GPP TS 23.003 [17].
    -- The internal structure is defined as follows:
    -- octet 1 bits 4321                Mobile Country Code 1st digit
    --         bits 8765                Mobile Country Code 2nd digit
    -- octet 2 bits 4321                Mobile Country Code 3rd digit
    --         bits 8765                Mobile Network Code 3rd digit
    --                                  or filler (1111) for 2 digit MNCs
    -- octet 3 bits 4321                Mobile Network Code 1st digit
    --         bits 8765                Mobile Network Code 2nd digit
    -- octets 4 and 5                   Location Area Code according to 3GPP TS 24.008 [35]
```

-- data types for subscriber management

```
BasicServiceCode ::= CHOICE {
    bearerService                    [2] BearerServiceCode,
    teleservice                      [3] TeleserviceCode}
```

```
Ext-BasicServiceCode ::= CHOICE {
    ext-BearerService                [2] Ext-BearerServiceCode,
    ext-Teleservice                  [3] Ext-TeleserviceCode}
```

```
EMLPP-Info ::= SEQUENCE {
    maximumentitledPriority          EMLPP-Priority,
    defaultPriority                  EMLPP-Priority,
    extensionContainer               ExtensionContainer              OPTIONAL,
    ...}
```

```
EMLPP-Priority ::= INTEGER (0..15)
    -- The mapping from the values A,B,0,1,2,3,4 to the integer-value is
    -- specified as follows where A is the highest and 4 is the lowest
    -- priority level
    -- the integer values 7-15 are spare and shall be mapped to value 4
```

```
priorityLevelA                       EMLPP-Priority ::= 6
priorityLevelB                       EMLPP-Priority ::= 5
priorityLevel0                       EMLPP-Priority ::= 0
priorityLevel1                       EMLPP-Priority ::= 1
priorityLevel2                       EMLPP-Priority ::= 2
priorityLevel3                       EMLPP-Priority ::= 3
priorityLevel4                       EMLPP-Priority ::= 4
```

```
MC-SS-Info ::= SEQUENCE {
    ss-Code                          [0] SS-Code,
    ss-Status                        [1] Ext-SS-Status,
    nbrSB                            [2] MaxMC-Bearers,
    nbrUser                          [3] MC-Bearers,
    extensionContainer               [4] ExtensionContainer          OPTIONAL,
    ...}
```

```
MaxMC-Bearers ::= INTEGER (2..maxNumOfMC-Bearers)
```

```
MC-Bearers ::= INTEGER (1..maxNumOfMC-Bearers)
```

```
maxNumOfMC-Bearers  INTEGER ::= 7
```

```
Ext-SS-Status ::= OCTET STRING (SIZE (1..5))

     -- OCTET 1:
     --
     -- bits 8765: 0000 (unused)
     -- bits 4321: Used to convey the "P bit","R bit","A bit" and "Q bit",
     --            representing supplementary service state information
     --            as defined in TS 3GPP TS 23.011 [22]

     -- bit 4: "Q bit"

     -- bit 3: "P bit"

     -- bit 2: "R bit"

     -- bit 1: "A bit"

     -- OCTETS 2-5: reserved for future use. They shall be discarded if
     -- received and not understood.
```

```
   -- data types for geographic location

AgeOfLocationInformation ::= INTEGER (0..32767)
-- the value represents the elapsed time in minutes since the last
-- network contact of the mobile station (i.e. the actuality of the
-- location information).
-- value '0' indicates that the MS is currently in contact with the
--           network
-- value '32767' indicates that the location information is at least
--               32767 minutes old
```

```
END
```

17.7.9 Teleservice Codes

```
MAP-TS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version11 (11)}

DEFINITIONS

::=

BEGIN
```

```
TeleserviceCode ::= OCTET STRING (SIZE (1))
     -- This type is used to represent the code identifying a single
     -- teleservice, a group of teleservices, or all teleservices. The
     -- services are defined in TS GSM 22.003 [4].
     -- The internal structure is defined as follows:

     -- bits 87654321: group (bits 8765) and specific service
     -- (bits 4321)
```

```
Ext-TeleserviceCode ::= OCTET STRING (SIZE (1..5))
     -- This type is used to represent the code identifying a single
     -- teleservice, a group of teleservices, or all teleservices. The
     -- services are defined in TS GSM 22.003 [4].
     -- The internal structure is defined as follows:

     -- OCTET 1:
     -- bits 87654321: group (bits 8765) and specific service
     -- (bits 4321)

     -- OCTETS 2-5: reserved for future use. If received the
    -- Ext-TeleserviceCode shall be
     -- treated according to the exception handling defined for the
     -- operation that uses this type.

     -- Ext-TeleserviceCode includes all values defined for TeleserviceCode.
```

```
allTeleservices                    TeleserviceCode ::= '00000000'B
```

```
allSpeechTransmissionServices           TeleserviceCode ::= '00010000'B
telephony                               TeleserviceCode ::= '00010001'B
emergencyCalls                          TeleserviceCode ::= '00010010'B
```

```
allShortMessageServices                 TeleserviceCode ::= '00100000'B
shortMessageMT-PP                       TeleserviceCode ::= '00100001'B
shortMessageMO-PP                       TeleserviceCode ::= '00100010'B
```

```
allFacsimileTransmissionServices        TeleserviceCode ::= '01100000'B
facsimileGroup3AndAlterSpeech           TeleserviceCode ::= '01100001'B
automaticFacsimileGroup3                TeleserviceCode ::= '01100010'B
facsimileGroup4                         TeleserviceCode ::= '01100011'B
```

```
-- The following non-hierarchical Compound Teleservice Groups
-- are defined in TS 3GPP TS 22.030:
allDataTeleservices                     TeleserviceCode ::= '01110000'B
     -- covers Teleservice Groups 'allFacsimileTransmissionServices'
     -- and 'allShortMessageServices'
allTeleservices-ExeptSMS                TeleserviceCode ::= '10000000'B
     -- covers Teleservice Groups 'allSpeechTransmissionServices' and
     -- 'allFacsimileTransmissionServices'
--
-- Compound Teleservice Group Codes are only used in call
-- independent supplementary service operations, i.e. they
-- are not used in InsertSubscriberData or in
-- DeleteSubscriberData messages.
```

```
allVoiceGroupCallServices               TeleserviceCode ::= '10010000'B
voiceGroupCall                          TeleserviceCode ::= '10010001'B
voiceBroadcastCall                      TeleserviceCode ::= '10010010'B
```

```
allPLMN-specificTS                      TeleserviceCode ::= '11010000'B
plmn-specificTS-1                       TeleserviceCode ::= '11010001'B
plmn-specificTS-2                       TeleserviceCode ::= '11010010'B
plmn-specificTS-3                       TeleserviceCode ::= '11010011'B
plmn-specificTS-4                       TeleserviceCode ::= '11010100'B
plmn-specificTS-5                       TeleserviceCode ::= '11010101'B
plmn-specificTS-6                       TeleserviceCode ::= '11010110'B
plmn-specificTS-7                       TeleserviceCode ::= '11010111'B
plmn-specificTS-8                       TeleserviceCode ::= '11011000'B
plmn-specificTS-9                       TeleserviceCode ::= '11011001'B
plmn-specificTS-A                       TeleserviceCode ::= '11011010'B
plmn-specificTS-B                       TeleserviceCode ::= '11011011'B
plmn-specificTS-C                       TeleserviceCode ::= '11011100'B
plmn-specificTS-D                       TeleserviceCode ::= '11011101'B
plmn-specificTS-E                       TeleserviceCode ::= '11011110'B
plmn-specificTS-F                       TeleserviceCode ::= '11011111'B
```

```
END
```

17.7.10 Bearer Service Codes

```
MAP-BS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-BS-Code (20) version11 (11)}

DEFINITIONS

::=

BEGIN
```

```
BearerServiceCode ::= OCTET STRING (SIZE (1))
     -- This type is used to represent the code identifying a single
     -- bearer service, a group of bearer services, or all bearer
     -- services. The services are defined in TS 3GPP TS 22.002 [3].
     -- The internal structure is defined as follows:
     --
     -- plmn-specific bearer services:
     -- bits 87654321: defined by the HPLMN operator

     -- rest of bearer services:
     -- bit 8: 0 (unused)
     -- bits 7654321: group (bits 7654), and rate, if applicable
     -- (bits 321)
```

```
Ext-BearerServiceCode ::= OCTET STRING (SIZE (1..5))
     -- This type is used to represent the code identifying a single
     -- bearer service, a group of bearer services, or all bearer
     -- services. The services are defined in TS 3GPP TS 22.002 [3].
     -- The internal structure is defined as follows:
     --
     -- OCTET 1:
     -- plmn-specific bearer services:
     -- bits 87654321: defined by the HPLMN operator
     --
     -- rest of bearer services:
     -- bit 8: 0 (unused)
     -- bits 7654321: group (bits 7654), and rate, if applicable
     -- (bits 321)

     -- OCTETS 2-5: reserved for future use. If received the
    -- Ext-TeleserviceCode shall be
     -- treated according to the exception handling defined for the
     -- operation that uses this type.


     -- Ext-BearerServiceCode includes all values defined for BearerServiceCode.
```

```
allBearerServices                    BearerServiceCode ::= '00000000'B
```

```
allDataCDA-Services                  BearerServiceCode ::= '00010000'B
dataCDA-300bps                       BearerServiceCode ::= '00010001'B
dataCDA-1200bps                      BearerServiceCode ::= '00010010'B
dataCDA-1200-75bps                   BearerServiceCode ::= '00010011'B
dataCDA-2400bps                      BearerServiceCode ::= '00010100'B
dataCDA-4800bps                      BearerServiceCode ::= '00010101'B
dataCDA-9600bps                      BearerServiceCode ::= '00010110'B
general-dataCDA                      BearerServiceCode ::= '00010111'B
```

```
allDataCDS-Services                  BearerServiceCode ::= '00011000'B
dataCDS-1200bps                      BearerServiceCode ::= '00011010'B
dataCDS-2400bps                      BearerServiceCode ::= '00011100'B
dataCDS-4800bps                      BearerServiceCode ::= '00011101'B
dataCDS-9600bps                      BearerServiceCode ::= '00011110'B
general-dataCDS                      BearerServiceCode ::= '00011111'B
```

```
allPadAccessCA-Services              BearerServiceCode ::= '00100000'B
padAccessCA-300bps                   BearerServiceCode ::= '00100001'B
padAccessCA-1200bps                  BearerServiceCode ::= '00100010'B
padAccessCA-1200-75bps               BearerServiceCode ::= '00100011'B
padAccessCA-2400bps                  BearerServiceCode ::= '00100100'B
padAccessCA-4800bps                  BearerServiceCode ::= '00100101'B
padAccessCA-9600bps                  BearerServiceCode ::= '00100110'B
general-padAccessCA                  BearerServiceCode ::= '00100111'B
```

```
allDataPDS-Services                  BearerServiceCode ::= '00101000'B
dataPDS-2400bps                      BearerServiceCode ::= '00101100'B
dataPDS-4800bps                      BearerServiceCode ::= '00101101'B
dataPDS-9600bps                      BearerServiceCode ::= '00101110'B
general-dataPDS                      BearerServiceCode ::= '00101111'B
```

```
allAlternateSpeech-DataCDA           BearerServiceCode ::= '00110000'B
```

```
allAlternateSpeech-DataCDS           BearerServiceCode ::= '00111000'B
```

```
allSpeechFollowedByDataCDA           BearerServiceCode ::= '01000000'B
```

```
allSpeechFollowedByDataCDS           BearerServiceCode ::= '01001000'B
```

```
-- The following non-hierarchical Compound Bearer Service
-- Groups are defined in TS 3GPP TS 22.030:
allDataCircuitAsynchronous                BearerServiceCode ::= '01010000'B
     -- covers "allDataCDA-Services", "allAlternateSpeech-DataCDA" and
     -- "allSpeechFollowedByDataCDA"
allAsynchronousServices                   BearerServiceCode ::= '01100000'B
     -- covers "allDataCDA-Services", "allAlternateSpeech-DataCDA",
     -- "allSpeechFollowedByDataCDA" and "allPadAccessCDA-Services"
allDataCircuitSynchronous                 BearerServiceCode ::= '01011000'B
     -- covers "allDataCDS-Services", "allAlternateSpeech-DataCDS" and
     -- "allSpeechFollowedByDataCDS"
allSynchronousServices                    BearerServiceCode ::= '01101000'B
     -- covers "allDataCDS-Services", "allAlternateSpeech-DataCDS",
     -- "allSpeechFollowedByDataCDS" and "allDataPDS-Services"
--
-- Compound Bearer Service Group Codes are only used in call
-- independent supplementary service operations, i.e. they
-- are not used in InsertSubscriberData or in
-- DeleteSubscriberData messages.
```

```
allPLMN-specificBS                        BearerServiceCode ::= '11010000'B
plmn-specificBS-1                         BearerServiceCode ::= '11010001'B
plmn-specificBS-2                         BearerServiceCode ::= '11010010'B
plmn-specificBS-3                         BearerServiceCode ::= '11010011'B
plmn-specificBS-4                         BearerServiceCode ::= '11010100'B
plmn-specificBS-5                         BearerServiceCode ::= '11010101'B
plmn-specificBS-6                         BearerServiceCode ::= '11010110'B
plmn-specificBS-7                         BearerServiceCode ::= '11010111'B
plmn-specificBS-8                         BearerServiceCode ::= '11011000'B
plmn-specificBS-9                         BearerServiceCode ::= '11011001'B
plmn-specificBS-A                         BearerServiceCode ::= '11011010'B
plmn-specificBS-B                         BearerServiceCode ::= '11011011'B
plmn-specificBS-C                         BearerServiceCode ::= '11011100'B
plmn-specificBS-D                         BearerServiceCode ::= '11011101'B
plmn-specificBS-E                         BearerServiceCode ::= '11011110'B
plmn-specificBS-F                         BearerServiceCode ::= '11011111'B
```

```
END
```

17.7.11 Extension data types

```
MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS

   PrivateExtension,
   ExtensionContainer,
   SLR-ArgExtensionContainer;


-- IOC for private MAP extensions
```

```
MAP-EXTENSION  ::= CLASS {
     &ExtensionType                                                  OPTIONAL,
     &extensionId                         OBJECT IDENTIFIER }
     -- The length of the Object Identifier shall not exceed 16 octets and the
     -- number of components of the Object Identifier shall not exceed 16
```

```
-- data types
```

```
ExtensionContainer ::= SEQUENCE {
     privateExtensionList                [0]PrivateExtensionList           OPTIONAL,
     pcs-Extensions                      [1]PCS-Extensions                 OPTIONAL,
     ...}
```

```
SLR-ArgExtensionContainer ::= SEQUENCE {
     privateExtensionList                [0]PrivateExtensionList          OPTIONAL,
     slr-Arg-PCS-Extensions              [1]SLR-Arg-PCS-Extensions        OPTIONAL,
     ...}
```

```
PrivateExtensionList ::= SEQUENCE SIZE (1..maxNumOfPrivateExtensions) OF
                                         PrivateExtension
```

```
PrivateExtension ::= SEQUENCE {
     extId                               MAP-EXTENSION.&extensionId
                                         ({ExtensionSet}),
     extType                             MAP-EXTENSION.&ExtensionType
                                         ({ExtensionSet}{@extId})         OPTIONAL}
```

```
maxNumOfPrivateExtensions  INTEGER ::= 10
```

```
ExtensionSet                             MAP-EXTENSION ::=
          {...
           -- ExtensionSet is the set of all defined private extensions
     }
     -- Unsupported private extensions shall be discarded if received.
```

```
PCS-Extensions ::= SEQUENCE {
     ...}
```

```
SLR-Arg-PCS-Extensions ::= SEQUENCE {
     ...,
     na-ESRK-Request                     [0]  NULL                        OPTIONAL }
```

```
END
```

17.7.12 Group Call data types

```
MAP-GR-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-GR-DataTypes (23) version11 (11)}

DEFINITIONS

IMPLICIT TAGS

::=

BEGIN

EXPORTS
   PrepareGroupCallArg,
   PrepareGroupCallRes,
   SendGroupCallEndSignalArg,
   SendGroupCallEndSignalRes,
   ForwardGroupCallSignallingArg,
   ProcessGroupCallSignallingArg,
   SendGroupCallInfoArg,
   SendGroupCallInfoRes
;

IMPORTS
   ISDN-AddressString,
   IMSI,
   TMSI,
   EMLPP-Priority,
   ASCI-CallReference,
   SignalInfo,
   GlobalCellId,
   AccessNetworkSignalInfo
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   Ext-TeleserviceCode
FROM MAP-TS-Code {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-TS-Code (19) version11 (11)}

   Kc,
   AdditionalInfo,
```

```
   GroupId,
   Long-GroupId,
   AdditionalSubscriptions,
   Cksn
FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version11 (11)}

   ExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}
;
```

```
PrepareGroupCallArg ::= SEQUENCE {
     teleservice                        Ext-TeleserviceCode,
     asciCallReference                  ASCI-CallReference,
     codec-Info                         CODEC-Info,
     cipheringAlgorithm                 CipheringAlgorithm,
     groupKeyNumber-Vk-Id               [0] GroupKeyNumber              OPTIONAL,
     groupKey                           [1] Kc                          OPTIONAL,
     -- this parameter shall not be sent and shall be discarded if received
     priority                           [2] EMLPP-Priority              OPTIONAL,
     uplinkFree                         [3] NULL                        OPTIONAL,
     extensionContainer                 [4] ExtensionContainer          OPTIONAL,
     ...,
     vstk                               [5] VSTK                        OPTIONAL,
     vstk-rand                          [6] VSTK-RAND                   OPTIONAL,
     talkerChannelParameter             [7] NULL                        OPTIONAL }
```

```
VSTK ::= OCTET STRING (SIZE (16))
```

```
VSTK-RAND ::= OCTET STRING (SIZE (5))
     -- The 36 bit value is carried in bit 7 of octet 1 to bit 4 of octet 5
     -- bits 3, 2, 1, and 0 of octet 5 are padded with zeros.
```

```
PrepareGroupCallRes ::= SEQUENCE {
     groupCallNumber                    ISDN-AddressString,
     extensionContainer                 ExtensionContainer              OPTIONAL,
     ...}
```

```
SendGroupCallEndSignalArg ::= SEQUENCE {
     imsi                               IMSI                            OPTIONAL,
     extensionContainer                 ExtensionContainer              OPTIONAL,
     ...,
     talkerPriority                     [0]TalkerPriority               OPTIONAL,
     additionalInfo                     [1]AdditionalInfo               OPTIONAL }
```

```
TalkerPriority ::= ENUMERATED {
     normal  (0),
     privileged  (1),
     emergency  (2)}
```

```
SendGroupCallEndSignalRes ::= SEQUENCE {
     extensionContainer                 ExtensionContainer              OPTIONAL,
     ...}
```

```
ForwardGroupCallSignallingArg ::= SEQUENCE {
     imsi                               IMSI                            OPTIONAL,
     uplinkRequestAck                   [0] NULL                        OPTIONAL,
     uplinkReleaseIndication            [1] NULL                        OPTIONAL,
     uplinkRejectCommand                [2] NULL                        OPTIONAL,
     uplinkSeizedCommand                [3] NULL                        OPTIONAL,
     uplinkReleaseCommand               [4] NULL                        OPTIONAL,
     extensionContainer                 ExtensionContainer              OPTIONAL,
     ...,
     stateAttributes                    [5] StateAttributes             OPTIONAL,
     talkerPriority                     [6] TalkerPriority              OPTIONAL,
     additionalInfo                     [7] AdditionalInfo              OPTIONAL,
     emergencyModeResetCommandFlag      [8] NULL                        OPTIONAL,
     sm-RP-UI                           [9] SignalInfo                  OPTIONAL,
     an-APDU   [10] AccessNetworkSignalInfo    OPTIONAL
 }
```

```
ProcessGroupCallSignallingArg ::= SEQUENCE {
     uplinkRequest                          [0] NULL                          OPTIONAL,
     uplinkReleaseIndication                [1] NULL                          OPTIONAL,
     releaseGroupCall                       [2] NULL                          OPTIONAL,
     extensionContainer                     ExtensionContainer                OPTIONAL,
     ...,
     talkerPriority                         [3] TalkerPriority                OPTIONAL,
     additionalInfo                         [4] AdditionalInfo                OPTIONAL,
     emergencyModeResetCommandFlag          [5] NULL                          OPTIONAL,
     an-APDU   [6] AccessNetworkSignalInfoOPTIONAL }
```

```
GroupKeyNumber ::= INTEGER (0..15)
```

```
CODEC-Info ::= OCTET STRING (SIZE (5..10))
     -- Refers to channel type
     -- coded according to 3GPP TS 48.008 [49] and including Element identifier and Length
```

```
CipheringAlgorithm ::= OCTET STRING (SIZE (1))
     -- Refers to 'permitted algorithms' in 'encryption information'
     -- coded according to 3GPP TS 48.008 [49]:

     -- Bits 8-1
     -- 8765 4321
     -- 0000 0001                          No encryption
     -- 0000 0010                          GSM A5/1
     -- 0000 0100                          GSM A5/2
     -- 0000 1000                          GSM A5/3
     -- 0001 0000                          GSM A5/4
     -- 0010 0000                          GSM A5/5
     -- 0100 0000                          GSM A5/6
     -- 1000 0000                          GSM A5/7
```

```
StateAttributes ::= SEQUENCE {
     downlinkAttached                              [5] NULL                OPTIONAL,
     uplinkAttached                                [6] NULL                OPTIONAL,
     dualCommunication                             [7] NULL                OPTIONAL,
     callOriginator                                [8] NULL                OPTIONAL }

     -- Refers to 3GPP TS 44.068 for definitions of StateAttributes fields.
```

```
SendGroupCallInfoArg ::= SEQUENCE {
     requestedInfo                          RequestedInfo,
     groupId                                Long-GroupId,
     teleservice                            Ext-TeleserviceCode,
     cellId                                 [0] GlobalCellId                  OPTIONAL,
     imsi                                   [1] IMSI                          OPTIONAL,
     tmsi                                   [2] TMSI                          OPTIONAL,
     additionalInfo                         [3] AdditionalInfo                OPTIONAL,
     talkerPriority                         [4] TalkerPriority                OPTIONAL,
     cksn                                   [5] Cksn                          OPTIONAL,
     extensionContainer                     [6] ExtensionContainer            OPTIONAL,
     ... }
```

```
RequestedInfo ::= ENUMERATED {
     anchorMSC-AddressAndASCI-CallReference                                   (0),
     imsiAndAdditionalInfoAndAdditionalSubscription                           (1),
     ... }
--   exception handling:
--   an unrecognized value shall be rejected by the receiver with a return error cause of
--   unexpected data value
```

```
SendGroupCallInfoRes ::= SEQUENCE {
     anchorMSC-Address                      [0] ISDN-AddressString            OPTIONAL,
     asciCallReference                      [1] ASCI-CallReference            OPTIONAL,
     imsi                                   [2] IMSI                          OPTIONAL,
     additionalInfo                         [3] AdditionalInfo                OPTIONAL,
     additionalSubscriptions                [4] AdditionalSubscriptions       OPTIONAL,
     kc                                     [5] Kc                            OPTIONAL,
     extensionContainer                     [6] ExtensionContainer            OPTIONAL,
     ... }
```

```
END
```

17.7.13 Location service data types

```
MAP-LCS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-LCS-DataTypes (25) version11 (11)}

DEFINITIONS
IMPLICIT TAGS
::=
BEGIN

EXPORTS
   RoutingInfoForLCS-Arg,
   RoutingInfoForLCS-Res,
   ProvideSubscriberLocation-Arg,
   ProvideSubscriberLocation-Res,
   SubscriberLocationReport-Arg,
   SubscriberLocationReport-Res,
   LocationType,
   DeferredLocationEventType,
   LCSClientName,
   LCS-QoS,
   Horizontal-Accuracy,
   ResponseTime,
   Ext-GeographicalInformation,
   VelocityEstimate,
   SupportedGADShapes,
   Add-GeographicalInformation,
   LCSRequestorID,
   LCS-ReferenceNumber,
   LCSCodeword,
   AreaEventInfo,
   ReportingPLMNList,
   PeriodicLDRInfo,
   SequenceNumber
;

IMPORTS
   AddressString,
   ISDN-AddressString,
   IMEI,
   IMSI,
   LMSI,
   SubscriberIdentity,
   AgeOfLocationInformation,
   LCSClientExternalID,
   LCSClientInternalID,
   LCSServiceTypeID,
   CellGlobalIdOrServiceAreaIdOrLAI,
   PLMN-Id,
   GSN-Address
FROM MAP-CommonDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-CommonDataTypes (18) version11 (11)}

   ExtensionContainer,
   SLR-ArgExtensionContainer
FROM MAP-ExtensionDataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-ExtensionDataTypes (21) version11 (11)}

   USSD-DataCodingScheme,
   USSD-String
FROM MAP-SS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0) gsm-Network (1) modules (3)
   map-SS-DataTypes (14) version11 (11)}

   APN,
   SupportedLCS-CapabilitySets
FROM MAP-MS-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-MS-DataTypes (11) version11 (11)}

   Additional-Number
FROM MAP-SM-DataTypes {
   itu-t identified-organization (4) etsi (0) mobileDomain (0)
   gsm-Network (1) modules (3) map-SM-DataTypes (16) version11 (11)}
;
```

```
RoutingInfoForLCS-Arg ::= SEQUENCE {
     mlcNumber                          [0] ISDN-AddressString,
     targetMS                           [1] SubscriberIdentity,
     extensionContainer                 [2] ExtensionContainer          OPTIONAL,
     ...}

RoutingInfoForLCS-Res ::= SEQUENCE {
     targetMS                           [0] SubscriberIdentity,
     lcsLocationInfo                    [1] LCSLocationInfo,
     extensionContainer                 [2] ExtensionContainer          OPTIONAL,
     ...,
     v-gmlc-Address                     [3]  GSN-Address                OPTIONAL,
     h-gmlc-Address                     [4]  GSN-Address                OPTIONAL,
     ppr-Address                        [5]  GSN-Address                OPTIONAL,
     additional-v-gmlc-Address          [6]  GSN-Address                OPTIONAL }

LCSLocationInfo ::= SEQUENCE {
     networkNode-Number                 ISDN-AddressString,
     -- NetworkNode-number can be either msc-number or sgsn-number
     lmsi                               [0] LMSI                        OPTIONAL,
     extensionContainer                 [1] ExtensionContainer          OPTIONAL,
     ... ,
     gprsNodeIndicator                  [2] NULL                        OPTIONAL,
     -- gprsNodeIndicator is set only if the SGSN number is sent as the Network Node Number
     additional-Number                  [3] Additional-Number           OPTIONAL,
     supportedLCS-CapabilitySets        [4]  SupportedLCS-CapabilitySets  OPTIONAL,
     additional-LCS-CapabilitySets      [5]  SupportedLCS-CapabilitySets  OPTIONAL
     }

ProvideSubscriberLocation-Arg ::= SEQUENCE {
     locationType                       LocationType,
     mlc-Number                         ISDN-AddressString,
     lcs-ClientID                       [0] LCS-ClientID                OPTIONAL,
     privacyOverride                    [1] NULL                        OPTIONAL,
     imsi                               [2] IMSI                        OPTIONAL,
     msisdn                             [3] ISDN-AddressString          OPTIONAL,
     lmsi                               [4] LMSI                        OPTIONAL,
     imei                               [5] IMEI                        OPTIONAL,
     lcs-Priority                       [6] LCS-Priority                OPTIONAL,
     lcs-QoS                            [7] LCS-QoS                     OPTIONAL,
     extensionContainer                 [8] ExtensionContainer          OPTIONAL,
     ... ,
     supportedGADShapes                 [9]  SupportedGADShapes         OPTIONAL,
     lcs-ReferenceNumber                [10] LCS-ReferenceNumber        OPTIONAL,
     lcsServiceTypeID                   [11] LCSServiceTypeID           OPTIONAL,
     lcsCodeword                        [12] LCSCodeword                OPTIONAL,
     lcs-PrivacyCheck                   [13] LCS-PrivacyCheck           OPTIONAL,
     areaEventInfo                      [14] AreaEventInfo              OPTIONAL,
     h-gmlc-Address                     [15] GSN-Address                OPTIONAL,
     mo-lrShortCircuitIndicator         [16] NULL                       OPTIONAL,
     periodicLDRInfo                    [17] PeriodicLDRInfo            OPTIONAL,
     reportingPLMNList                  [18] ReportingPLMNList          OPTIONAL }

     -- one of imsi or msisdn is mandatory
     -- If a location estimate type indicates activate deferred location or cancel deferred
     -- location, a lcs-Reference number shall be included.

LocationType ::= SEQUENCE {
     locationEstimateType               [0] LocationEstimateType,
     ...,
     deferredLocationEventType          [1] DeferredLocationEventType   OPTIONAL }

LocationEstimateType ::= ENUMERATED {
     currentLocation                    (0),
     currentOrLastKnownLocation         (1),
     initialLocation                    (2),
     ...,
     activateDeferredLocation           (3),
     cancelDeferredLocation             (4) ,
     notificationVerificationOnly       (5) }
--   exception handling:
--   a ProvideSubscriberLocation-Arg containing an unrecognized LocationEstimateType
--   shall be rejected by the receiver with a return error cause of unexpected data value
```

```
DeferredLocationEventType ::= BIT STRING {
     msAvailable                          (0) ,
     enteringIntoArea                     (1),
     leavingFromArea                      (2),
     beingInsideArea                      (3) ,
     periodicLDR                          (4)  } (SIZE (1..16))
-- beingInsideArea is always treated as oneTimeEvent regardless of the possible value
-- of occurrenceInfo inside areaEventInfo.
-- exception handling:
-- a ProvideSubscriberLocation-Arg containing other values than listed above in
-- DeferredLocationEventType shall be rejected by the receiver with a return error cause of
-- unexpected data value.
```

```
LCS-ClientID ::= SEQUENCE {
     lcsClientType                        [0] LCSClientType,
     lcsClientExternalID                  [1] LCSClientExternalID          OPTIONAL,
     lcsClientDialedByMS                  [2] AddressString                OPTIONAL,
     lcsClientInternalID                  [3] LCSClientInternalID          OPTIONAL,
     lcsClientName                        [4] LCSClientName                OPTIONAL,
     ...,
     lcsAPN                               [5] APN                          OPTIONAL,
     lcsRequestorID                       [6] LCSRequestorID               OPTIONAL }
```

```
LCSClientType ::= ENUMERATED {
     emergencyServices                    (0),
     valueAddedServices                   (1),
     plmnOperatorServices                 (2),
     lawfulInterceptServices              (3),
     ... }
     --   exception handling:
     --   unrecognized values may be ignored if the LCS client uses the privacy override
     --   otherwise, an unrecognized value shall be treated as unexpected data by a receiver
     --   a return error shall then be returned if received in a MAP invoke
```

```
LCSClientName ::= SEQUENCE {
     dataCodingScheme                     [0] USSD-DataCodingScheme,
     nameString                           [2] NameString,
     ...,
     lcs-FormatIndicator                  [3] LCS-FormatIndicator          OPTIONAL }

-- The USSD-DataCodingScheme shall indicate use of the default alphabet through the
-- following encoding
--   bit  7 6 5 4 3 2 1 0
--        0 0 0 0 1 1 1 1
```

```
NameString ::= USSD-String (SIZE (1..maxNameStringLength))
```

```
maxNameStringLength  INTEGER ::= 63
```

```
LCSRequestorID ::= SEQUENCE {
     dataCodingScheme                     [0] USSD-DataCodingScheme,
     requestorIDString                    [1] RequestorIDString,
     ...,
     lcs-FormatIndicator                  [2] LCS-FormatIndicator          OPTIONAL }
```

```
RequestorIDString ::= USSD-String (SIZE (1..maxRequestorIDStringLength))
```

```
maxRequestorIDStringLength  INTEGER ::= 63
```

```
LCS-FormatIndicator ::= ENUMERATED {
     logicalName                          (0),
     e-mailAddress                        (1),
     msisdn                               (2),
     url                                  (3),
     sipUrl                               (4),
     ... }
```

```
LCS-Priority ::= OCTET STRING (SIZE (1))
     -- 0 = highest priority
     -- 1 = normal priority
     -- all other values treated as 1
```

```
LCS-QoS ::= SEQUENCE {
     horizontal-accuracy                [0] Horizontal-Accuracy          OPTIONAL,
     verticalCoordinateRequest          [1] NULL                         OPTIONAL,
     vertical-accuracy                  [2] Vertical-Accuracy            OPTIONAL,
     responseTime                       [3] ResponseTime                 OPTIONAL,
     extensionContainer                 [4] ExtensionContainer           OPTIONAL,
     ...,
     velocityRequest                    [5] NULL                         OPTIONAL
}
```

```
Horizontal-Accuracy ::= OCTET STRING (SIZE (1))
     -- bit 8 = 0
     -- bits 7-1 = 7 bit Uncertainty Code defined in 3GPP TS 23.032. The horizontal location
     -- error should be less than the error indicated by the uncertainty code with 67%
     -- confidence.
```

```
Vertical-Accuracy ::= OCTET STRING (SIZE (1))
     -- bit 8 = 0
     -- bits 7-1 = 7 bit Vertical Uncertainty Code defined in 3GPP TS 23.032.
     -- The vertical location error should be less than the error indicated
     -- by the uncertainty code with 67% confidence.
```

```
ResponseTime ::= SEQUENCE {
     responseTimeCategory               ResponseTimeCategory,
     ...}
--   note: an expandable SEQUENCE simplifies later addition of a numeric response time.
```

```
ResponseTimeCategory ::= ENUMERATED {
     lowdelay  (0),
     delaytolerant  (1),
     ... }
--   exception handling:
--   an unrecognized value shall be treated the same as value 1 (delaytolerant)
```

```
SupportedGADShapes ::= BIT STRING {
     ellipsoidPoint  (0),
     ellipsoidPointWithUncertaintyCircle (1),
     ellipsoidPointWithUncertaintyEllipse (2),
     polygon (3),
     ellipsoidPointWithAltitude (4),
     ellipsoidPointWithAltitudeAndUncertaintyElipsoid (5),
     ellipsoidArc  (6) } (SIZE (7..16))
-- A node shall mark in the BIT STRING all Shapes defined in 3GPP TS 23.032 it supports.
-- exception handling: bits 7 to 15 shall be ignored if received.
```

```
LCS-ReferenceNumber::= OCTET STRING (SIZE(1))
```

```
LCSCodeword ::= SEQUENCE {
     dataCodingScheme                   [0] USSD-DataCodingScheme,
     lcsCodewordString                  [1] LCSCodewordString,
     ...}
```

```
LCSCodewordString ::= USSD-String (SIZE (1..maxLCSCodewordStringLength))
```

```
maxLCSCodewordStringLength  INTEGER ::= 20
```

```
LCS-PrivacyCheck ::= SEQUENCE {
     callSessionUnrelated               [0] PrivacyCheckRelatedAction,
     callSessionRelated                 [1] PrivacyCheckRelatedAction     OPTIONAL,
     ...}
```

```
PrivacyCheckRelatedAction ::= ENUMERATED {
     allowedWithoutNotification (0),
     allowedWithNotification (1),
     allowedIfNoResponse (2),
     restrictedIfNoResponse (3),
     notAllowed (4),
     ...}
--   exception handling:
--   a ProvideSubscriberLocation-Arg containing an unrecognized PrivacyCheckRelatedAction
--   shall be rejected by the receiver with a return error cause of unexpected data value
```

```
AreaEventInfo ::= SEQUENCE {
     areaDefinition                  [0]  AreaDefinition,
     occurrenceInfo                  [1]  OccurrenceInfo              OPTIONAL,
     intervalTime                    [2]  IntervalTime                OPTIONAL,
     ...}

AreaDefinition ::= SEQUENCE {
     areaList                        [0]  AreaList,
     ...}

AreaList ::= SEQUENCE SIZE (1..maxNumOfAreas) OF Area

maxNumOfAreas  INTEGER ::= 10

Area ::= SEQUENCE {
     areaType                        [0]  AreaType,
     areaIdentification              [1]  AreaIdentification,
     ...}

AreaType ::= ENUMERATED {
     countryCode                     (0),
     plmnId                          (1),
     locationAreaId                  (2),
     routingAreaId                   (3),
     cellGlobalId                    (4),
     ...,
     utranCellId                     (5) }

AreaIdentification ::= OCTET STRING (SIZE (2..7))
     -- The internal structure is defined as follows:
     -- octet 1 bits 4321            Mobile Country Code 1st digit
     --         bits 8765            Mobile Country Code 2nd digit
     -- octet 2 bits 4321            Mobile Country Code 3rd digit
     --         bits 8765            Mobile Network Code 3rd digit if 3 digit MNC included
     --                              or filler (1111)
     -- octet 3 bits 4321            Mobile Network Code 1st digit
     --         bits 8765            Mobile Network Code 2nd digit
     -- octets 4 and 5               Location Area Code (LAC) for Local Area Id,
     --                              Routing Area Id and Cell Global Id
     -- octet 6                      Routing Area Code (RAC) for Routing Area Id
     -- octets 6 and 7               Cell Identity (CI) for Cell Global Id
     -- octets 4 until 7             Utran Cell Identity (UC-Id) for Utran Cell Id

OccurrenceInfo ::= ENUMERATED {
     oneTimeEvent                    (0),
     multipleTimeEvent               (1),
     ...}

IntervalTime ::= INTEGER (1..32767)
     -- minimum interval time between area reports in seconds

PeriodicLDRInfo ::= SEQUENCE {
    reportingAmount     ReportingAmount,
    reportingInterval   ReportingInterval,
    ...}
-- reportingInterval x reportingAmount shall not exceed 8639999 (99 days, 23 hours,
-- 59 minutes and 59 seconds) for compatibility with OMA MLP and RLP

ReportingAmount ::= INTEGER (1..maxReportingAmount)

maxReportingAmount INTEGER ::= 8639999

ReportingInterval ::= INTEGER (1..maxReportingInterval)
-- ReportingInterval is in seconds

maxReportingInterval INTEGER ::= 8639999

ReportingPLMNList::= SEQUENCE {
    plmn-ListPrioritized            [0] NULL                    OPTIONAL,
    plmn-List                       [1] PLMNList,
    ...}
```

```
PLMNList::= SEQUENCE SIZE (1..maxNumOfReportingPLMN) OF
                                        ReportingPLMN

maxNumOfReportingPLMN INTEGER ::= 20

ReportingPLMN::= SEQUENCE {
    plmn-Id                         [0] PLMN-Id,
    ran-Technology                  [1] RAN-Technology          OPTIONAL,
    ran-PeriodicLocationSupport     [2] NULL                    OPTIONAL,
    ...}

RAN-Technology ::= ENUMERATED {
    gsm         (0),
    umts        (1),
    ...}

ProvideSubscriberLocation-Res ::= SEQUENCE {
     locationEstimate                    Ext-GeographicalInformation,
     ageOfLocationEstimate               [0] AgeOfLocationInformation      OPTIONAL,
     extensionContainer                  [1] ExtensionContainer            OPTIONAL,
     ... ,
     add-LocationEstimate                [2] Add-GeographicalInformation   OPTIONAL,
     deferredmt-lrResponseIndicator      [3] NULL                          OPTIONAL,
     geranPositioningData                [4] PositioningDataInformation    OPTIONAL,
     utranPositioningData                [5] UtranPositioningDataInfo      OPTIONAL,
     cellIdOrSai                         [6] CellGlobalIdOrServiceAreaIdOrLAI   OPTIONAL,
     sai-Present                         [7] NULL                          OPTIONAL,
     accuracyFulfilmentIndicator         [8] AccuracyFulfilmentIndicator    OPTIONAL,
     velocityEstimate                    [9] VelocityEstimate              OPTIONAL,
     mo-lrShortCircuitIndicator          [10] NULL                         OPTIONAL }

--   if deferredmt-lrResponseIndicator is set, locationEstimate is ignored.

-- the add-LocationEstimate parameter shall not be sent to a node that did not indicate the
-- geographic shapes supported in the ProvideSubscriberLocation-Arg
-- The locationEstimate and the add-locationEstimate parameters shall not be sent if
-- the supportedGADShapes parameter has been received in ProvideSubscriberLocation-Arg
-- and the shape encoded in locationEstimate or add-LocationEstimate is not marked
-- as supported in supportedGADShapes. In such a case ProvideSubscriberLocation
-- shall be rejected with error FacilityNotSupported with additional indication
-- shapeOfLocationEstimateNotSupported.
-- sai-Present indicates that the cellIdOrSai parameter contains a Service Area Identity.

AccuracyFulfilmentIndicator ::= ENUMERATED {
     requestedAccuracyFulfilled  (0),
     requestedAccuracyNotFulfilled  (1),
     ...  }
```

```
Ext-GeographicalInformation ::= OCTET STRING (SIZE (1..maxExt-GeographicalInformation))
     -- Refers to geographical Information defined in 3GPP TS 23.032.
     -- This is composed of 1 or more octets with an internal structure according to
     -- 3GPP TS 23.032
     -- Octet 1: Type of shape, only the following shapes in 3GPP TS 23.032 are allowed:
     --       (a) Ellipsoid point with uncertainty circle
     --       (b) Ellipsoid point with uncertainty ellipse
     --       (c) Ellipsoid point with altitude and uncertainty ellipsoid
     --       (d) Ellipsoid Arc
     --       (e) Ellipsoid Point
     -- Any other value in octet 1 shall be treated as invalid
     -- Octets 2 to 8 for case (a) - Ellipsoid point with uncertainty circle
     --       Degrees of Latitude                                        3 octets
     --       Degrees of Longitude                                       3 octets
     --       Uncertainty code                                           1 octet
     -- Octets 2 to 11 for case (b) - Ellipsoid point with uncertainty ellipse:
     --       Degrees of Latitude                                        3 octets
     --       Degrees of Longitude                                       3 octets
     --       Uncertainty semi-major axis                                1 octet
     --       Uncertainty semi-minor axis                                1 octet
     --       Angle of major axis                                        1 octet
     --       Confidence                                                 1 octet
     -- Octets 2 to 14 for case (c) - Ellipsoid point with altitude and uncertainty ellipsoid
     --       Degrees of Latitude                                        3 octets
     --       Degrees of Longitude                                       3 octets
     --       Altitude                                                   2 octets
     --       Uncertainty semi-major axis                                1 octet
     --       Uncertainty semi-minor axis                                1 octet
     --       Angle of major axis                                        1 octet
     --       Uncertainty altitude                                       1 octet
     --       Confidence                                                 1 octet
     -- Octets 2 to 13 for case (d) - Ellipsoid Arc
     --       Degrees of Latitude                                        3 octets
     --       Degrees of Longitude                                       3 octets
     --       Inner radius                                               2 octets
     --       Uncertainty radius                                         1 octet
     --       Offset angle                                               1 octet
     --       Included angle                                             1 octet
     --       Confidence                                                 1 octet
     -- Octets 2 to 7 for case (e) - Ellipsoid Point
     --       Degrees of Latitude                                        3 octets
     --       Degrees of Longitude                                       3 octets

     --
     -- An Ext-GeographicalInformation parameter comprising more than one octet and
     -- containing any other shape or an incorrect number of octets or coding according
     -- to 3GPP TS 23.032 shall be treated as invalid data by a receiver.
     --
     -- An Ext-GeographicalInformation parameter comprising one octet shall be discarded
     -- by the receiver if an Add-GeographicalInformation parameter is received
     -- in the same message.
     --
     -- An Ext-GeographicalInformation parameter comprising one octet shall be treated as
     -- invalid data by the receiver if an Add-GeographicalInformation parameter is not
     -- received in the same message.
```

```
maxExt-GeographicalInformation  INTEGER ::= 20
     -- the maximum length allows for further shapes in 3GPP TS 23.032 to be included in later
     -- versions of 3GPP TS 29.002
```

```
VelocityEstimate ::= OCTET STRING (SIZE (4..7))
     -- Refers to Velocity description defined in 3GPP TS 23.032.
     -- This is composed of 4 or more octets with an internal structure according to
     -- 3GPP TS 23.032
     -- Octet 1: Type of velocity, only the following types in 3GPP TS 23.032 are allowed:
     --       (a) Horizontal Velocity
     --       (b) Horizontal with Vertical Velocity
     --       (c) Horizontal Velocity with Uncertainty
     --       (d) Horizontal with Vertical Velocity and Uncertainty
     -- For types Horizontal with Vertical Velocity and Horizontal with Vertical Velocity
     -- and Uncertainty, the direction of the Vertical Speed is also included in Octet 1
     -- Any other value in octet 1 shall be treated as invalid
     -- Octets 2 to 4 for case (a) Horizontal velocity:
     --       Bearing                                                    1 octet
     --       Horizontal Speed                                           2 octets
     -- Octets 2 to 5 for case (b) - Horizontal with Vertical Velocity:
     --       Bearing                                                    1 octet
     --       Horizontal Speed                                           2 octets
     --       Vertical Speed                                             1 octet
     -- Octets 2 to 5 for case (c) - Horizontal velocity with Uncertainty:
     --       Bearing                                                    1 octet
     --       Horizontal Speed                                           2 octets
     --       Uncertainty Speed                                          1 octet
     -- Octets 2 to 7 for case (d) - Horizontal with Vertical Velocity and Uncertainty:
     --       Bearing                                                    1 octet
     --       Horizontal Speed                                           2 octets
     --       Vertical Speed                                             1 octet
     --       Horizontal Uncertainty Speed                               1 octet
     --       Vertical Uncertainty Speed                                 1 octet
```

```
PositioningDataInformation ::= OCTET STRING (SIZE (2..maxPositioningDataInformation))
     -- Refers to the Positioning Data defined in 3GPP TS 49.031.
     -- This is composed of 2 or more octets with an internal structure according to
     -- 3GPP TS 49.031.
```

```
maxPositioningDataInformation INTEGER ::= 10
     --
```

```
UtranPositioningDataInfo ::= OCTET STRING (SIZE (3..maxUtranPositioningDataInfo))
     -- Refers to the Position Data defined in 3GPP TS 25.413.
     -- This is composed of the positioningDataDiscriminator and the positioningDataSet
     -- included in positionData as defined in 3GPP TS 25.413.
```

```
maxUtranPositioningDataInfo INTEGER ::= 11
     --
```

```
Add-GeographicalInformation ::= OCTET STRING (SIZE (1..maxAdd-GeographicalInformation))
     -- Refers to geographical Information defined in 3GPP TS 23.032.
     -- This is composed of 1 or more octets with an internal structure according to
     -- 3GPP TS 23.032
     -- Octet 1: Type of shape, all the shapes defined in 3GPP TS 23.032 are allowed:
     -- Octets 2 to n (where n is the total number of octets necessary to encode the shape
     -- according to 3GPP TS 23.032) are used to encode the shape itself in accordance with
the
     -- encoding defined in 3GPP TS 23.032
     --
     -- An Add-GeographicalInformation parameter, whether valid or invalid, received
     -- together with a valid Ext-GeographicalInformation parameter in the same message
     -- shall be discarded.
     --
     -- An Add-GeographicalInformation parameter containing any shape not defined in
     -- 3GPP TS 23.032 or an incorrect number of octets or coding according to
     -- 3GPP TS 23.032 shall be treated as invalid data by a receiver if not received
     -- together with a valid Ext-GeographicalInformation parameter in the same message.
```

```
maxAdd-GeographicalInformation  INTEGER ::= 91
     -- the maximum length allows support for all the shapes currently defined in 3GPP TS
23.032
```

```
SubscriberLocationReport-Arg ::= SEQUENCE {
     lcs-Event                          LCS-Event,
     lcs-ClientID                       LCS-ClientID,
     lcsLocationInfo                    LCSLocationInfo,
     msisdn                             [0] ISDN-AddressString            OPTIONAL,
     imsi                               [1] IMSI                          OPTIONAL,
     imei                               [2] IMEI                          OPTIONAL,
     na-ESRD                            [3] ISDN-AddressString            OPTIONAL,
     na-ESRK                            [4] ISDN-AddressString            OPTIONAL,
     locationEstimate                   [5] Ext-GeographicalInformation   OPTIONAL,
     ageOfLocationEstimate              [6] AgeOfLocationInformation      OPTIONAL,
     slr-ArgExtensionContainer          [7] SLR-ArgExtensionContainer     OPTIONAL,
     ... ,
     add-LocationEstimate               [8] Add-GeographicalInformation   OPTIONAL,
     deferredmt-lrData                  [9] Deferredmt-lrData             OPTIONAL,
     lcs-ReferenceNumber                [10] LCS-ReferenceNumber          OPTIONAL,
     geranPositioningData               [11] PositioningDataInformation   OPTIONAL,
     utranPositioningData               [12] UtranPositioningDataInfo     OPTIONAL,
     cellIdOrSai                        [13] CellGlobalIdOrServiceAreaIdOrLAI  OPTIONAL,
     h-gmlc-Address                     [14] GSN-Address                  OPTIONAL,
     lcsServiceTypeID                   [15] LCSServiceTypeID             OPTIONAL,
     sai-Present                        [17] NULL                         OPTIONAL,
     pseudonymIndicator                 [18] NULL                         OPTIONAL,
     accuracyFulfilmentIndicator        [19] AccuracyFulfilmentIndicator  OPTIONAL,
     velocityEstimate                   [20] VelocityEstimate             OPTIONAL,
     sequenceNumber                     [21] SequenceNumber               OPTIONAL,
     periodicLDRInfo                    [22] PeriodicLDRInfo              OPTIONAL,
     mo-lrShortCircuitIndicator         [23] NULL                         OPTIONAL }

     -- one of msisdn or imsi is mandatory
     -- a location estimate that is valid for the locationEstimate parameter should
     -- be transferred in this parameter in preference to the add-LocationEstimate.
     -- the deferredmt-lrData parameter shall be included if and only if the lcs-Event
     -- indicates a deferredmt-lrResponse.
     -- if the lcs-Event indicates a deferredmt-lrResponse then the locationEstimate
     -- and the add-locationEstimate parameters shall not be sent if the
     -- supportedGADShapes parameter had been received in ProvideSubscriberLocation-Arg
     -- and the shape encoded in locationEstimate or add-LocationEstimate was not marked
     -- as supported in supportedGADShapes. In such a case terminationCause
     -- in deferredmt-lrData shall be present with value
     -- shapeOfLocationEstimateNotSupported.
     -- If a lcs event indicates deferred mt-lr response, the lcs-Reference number shall be
     -- included.
     -- sai-Present indicates that the cellIdOrSai parameter contains a Service Area Identity.
```

```
Deferredmt-lrData ::= SEQUENCE {
     deferredLocationEventType          DeferredLocationEventType,
     terminationCause                   [0] TerminationCause              OPTIONAL,
     lcsLocationInfo                    [1] LCSLocationInfo               OPTIONAL,
     ...}
     -- lcsLocationInfo may be included only if a terminationCause is present
     -- indicating mt-lrRestart.
```

```
LCS-Event ::= ENUMERATED {
     emergencyCallOrigination  (0),
     emergencyCallRelease  (1),
     mo-lr  (2),
     ...,
     deferredmt-lrResponse  (3) ,
     deferredmo-lrTTTPInitiation  (4)  }
     --   deferredmt-lrResponse is applicable to the delivery of a location estimate
     --   for an LDR initiated earlier by either the network (via an MT-LR activate deferred
     --   location) or the UE (via a deferred MO-LR TTTP initiation)
     --   exception handling:
     --   a SubscriberLocationReport-Arg containing an unrecognized LCS-Event
     --   shall be rejected by a receiver with a return error cause of unexpected data value
```

```
TerminationCause ::= ENUMERATED {
     normal  (0),
     errorundefined  (1),
     internalTimeout  (2),
     congestion  (3),
     mt-lrRestart  (4),
     privacyViolation  (5),
     ...,
     shapeOfLocationEstimateNotSupported (6) ,
     subscriberTermination (7),
     uETermination (8),
     networkTermination (9)  }
-- mt-lrRestart shall be used to trigger the GMLC to restart the location procedure,
-- either because the sending node knows that the terminal has moved under coverage
-- of another MSC or SGSN (e.g. Send Identification received), or because the subscriber
-- has been deregistered due to a Cancel Location received from HLR.
--
-- exception handling
-- an unrecognized value shall be treated the same as value 1 (errorundefined)
```

```
SequenceNumber ::= INTEGER (1..maxReportingAmount)
```

```
SubscriberLocationReport-Res ::= SEQUENCE {
     extensionContainer                  ExtensionContainer                OPTIONAL,
     ...,
     na-ESRK                             [0] ISDN-AddressString            OPTIONAL,
     na-ESRD                             [1] ISDN-AddressString            OPTIONAL,
     h-gmlc-Address                      [2]  GSN-Address                  OPTIONAL,
     mo-lrShortCircuitIndicator          [3] NULL                          OPTIONAL,
     reportingPLMNList                   [4] ReportingPLMNList             OPTIONAL,
     lcs-ReferenceNumber                 [5]  LCS-ReferenceNumber          OPTIONAL }

-- na-ESRK and na-ESRD are mutually exclusive
--
-- exception handling
-- receipt of both na-ESRK and na-ESRD shall be treated the same as a return error
```

```
END
```

17.7.14 Void

18 General on MAP user procedures

18.1 Introduction

Clauses 18 to 25 describe the use of MAP services for GSM signalling procedures. GSM signalling procedures may involve one or several interfaces running one or several application protocols. The present document addresses only the signalling procedures which require at least the use of one MAP service.

When a signalling procedure takes place in the network, an application process invocation is created in each system component involved. Part of the application process invocation acts as a MAP user and handles one or several MAP dialogues. For each dialogue it employs an instance of the MAP service provider. It may also use other communication services to exchange information on other interfaces, but detailed description of these aspects is outside the scope of the present document.

18.2 Common aspects of user procedure descriptions

18.2.1 General conventions

For each signalling procedure the present document provides a brief textual overview accompanied by a flow diagram which represent the functional interactions between system components. Functional interactions are labelled using the MAP service name when the interaction results from a service request or by this service name followed by the symbol "ack" when this interaction results from a service response.

For each of the system components involved, the present document also provides a detailed textual description of the application process behaviour as well as an SDL diagram. SDL diagrams describe the sequence of events, as seen by the MAP-User, which occurs at MAP service provider boundaries as well as external events which occur at other interfaces and which impact on the previous sequence.

External events do not necessarily correspond to the messages of other protocols used in the system component. The MAP-user procedures are described as if a set of interworking functions (IWF) between the MAP-user and the other protocol entities was implemented (see figure 18.2/1). Such interworking functions are assumed to perform either an identity mapping or some processing or translation as required to eliminate information irrelevant to the MAP-user.

The mapping of service primitives on to protocol elements is described in clauses 14 to 17.

GSM signalling procedures are built from one or more sub-procedures (e.g. authentication, ciphering, ...).
Sub-procedures from which signalling procedures are built are represented using SDL MACRO descriptions.

In case of any discrepancy between the textual descriptions and the SDL descriptions, the latter take precedence.

18.2.2 Naming conventions

Events related to MAP are represented by MAP service primitives. The signal names used in the SDL diagrams are derived from the service primitive names defined in clauses 7 to 12, with some lexical transformations for readability and parsability purposes (blanks between words are replaced by underscores, the first letter of each word is capitalised).

Events received and sent on other interfaces are named by appending the message or signal name to a symbol representing the interface type, with some lexical transformations for readability and parsability purposes (blanks between words are replaced by underscores, the first letter of each word is capitalised).

The following symbols are used to represent the interface types:

"I": For interfaces to the fixed network. "I" stands for ISUP interface.

"A": For interfaces between the MSC and the BSS (i.e. A-interfaces);

"Gb": For interfaces between the SGSN and the BSS (i.e. Gb-interfaces);

"OM": For network management interfaces (communication with OMC, MML interface, ...);

"SC": For interfaces to a Service Centre;

"HO_CA": For internal interfaces to the Handover Control Application.

"US": For a local USSD application.

These naming conventions can be summarised by the following BNF description:

<Event_Name> ::= <MAP_Primitive> | <External_Event>

<MAP_Primitive> ::= <MAP_Open> | <MAP_Close> | <MAP_U_Abort> | <MAP_P_Abort> | <MAP_Specific> | <MAP_Notice>

<MAP_Open> ::= MAP_Open_Req | MAP_Open_Ind | MAP_Open_Rsp | MAP_Open_Cnf

<MAP_Close> ::= MAP_Close_Req | MAP_Close_Ind

<MAP_U_Abort> ::= MAP_U_Abort_Req | MAP_U_Abort_Ind

<MAP_P_Abort> ::= MAP_P_Abort_Ind

<MAP_Notice> ::= MAP_Notice_Ind

<MAP_Specific> ::= <MAP_Req> | <MAP_Ind> | <MAP_Rsp> | <MAP_Cnf>

<MAP_Req> ::= MAP_<Service_Name>_Req

<MAP_Ind> ::= MAP_<Service_Name>_Ind

<MAP_Rsp> ::= MAP_<Service_Name>_Rsp

<MAP_Cnf> ::= MAP_<Service_Name>_Cnf

<External_Event> ::= <Interface_Type>_<External_Signal>

<Interface_Type> ::= I | A | Gb | OM | SC | HO AC | US

<External_Signal> ::= <Lexical_Unit>

<Service_Name> ::= <Lexical_Unit>

<Lexical_Unit> ::= <Lexical_Component> | <Lexical_Unit>_ <Lexical_Component>

<Lexical_Component> ::= <Upper_Case_Letter><Letter_Or_Digit_List>

<Letter_Or_Digit_List> ::= <Letter_Or_Digit> | <Letter_Or_Digit_List><Letter_Or_Digit>

<Letter_Or_Digit> ::= <Letter> | <Digit>

<Letter> ::= <Lower_Case_Letter> | <Upper_Case_Letter>

<Upper_Case_Letter> ::= A|B|C|D|E|F|G|H|I|J|K|L|M|N|O|P|Q|R|S|T|U|V|W|X|Y|Z

<Lower_Case_Letter> ::= a|b|c|d|e|f|g|h|i|j|k|l|m|n|o|p|q|r|s|t|u|v|w|x|y|z

<Digit> ::= 1|2|3|4|5|6|7|8|9|0

Figure 18.2/1: Interfaces applicable to the MAP-User

18.2.3 Convention on primitives parameters

18.2.3.1 Open service

When the originating and destination reference parameters shall be included in the MAP-OPEN request primitive, their value are indicated as a comment to the signal which represents this primitive.

18.2.3.2 Close service

When a pre-arranged released is requested, a comment is attached to the signal which represents the MAP-CLOSE request primitive. In the absence of comment, a normal release is assumed.

18.2.4 Version handling at dialogue establishment

Unless explicitly indicated in subsequent clauses, the following principles regarding version handling procedures at dialogue establishment are applied by the MAP-user.

18.2.4.1 Behaviour at the initiating side

When a MAP user signalling procedure has to be executed, the MAP-user issues a MAP-OPEN request primitive with an appropriate application-context-name. If several names are supported (i.e. several versions) a suitable one is selected using the procedures described in clause 5.

If version n is selected (where 1 < n <= highest existing version) and a MAP-OPEN Confirm primitive is received in response to the MAP-OPEN request with a result parameter set to "refused" and a diagnostic parameter indicating "application context not supported" or "potential version incompatibility problem", the MAP-User issues a new MAP-OPEN request primitive with the equivalent version y context (where 1 <= y < n). This is informally represented in the SDL diagrams by task symbols indicating 'Perform Vr procedure".

18.2.4.2 Behaviour at the responding side

On receipt of a MAP-OPEN indication primitive, the MAP-User analyses the application-context-name and executes the procedure associated with the requested version context. For example,if it refers to a version one context, the associated V1 procedure is executed; if it refers to a version two context, the associated V2 procedure is executed;etc.

18.2.5 Abort Handling

Unless explicitly indicated in subsequent clauses, the following principles are applied by the MAP-user regarding abort handling procedures:

On receipt of a MAP-P-ABORT indication or MAP-U-ABORT Indication primitive from any MAP-provider invocation, the MAP-User issues a MAP-U-ABORT Request primitive to each MAP-provider invocation associated with the same user procedure.

If applicable a decision is made to decide if the affected user procedure has to be retried or not.

18.2.6 SDL conventions

The MAP SDLs make use of a number of SDL concepts and conventions, where not all of them may be widely known. Therefore, this clause outlines the use of a few concepts and conventions to improve understanding of the MAP SDLs.

The MAP User SDLs make use of SDL Processes, Procedures and Macros. Processes are independent from each other even if one process starts another one: The actions of both of them have no ordering in time. SDL Procedures and Macros are just used to ease writing of the specification: They contain parts of a behaviour used in several places, and the corresponding Procedure/Macro definition has to be expanded at the position of the Procedure/Macro call.

All Processes are started at system initialisation and live forever, unless process creation/termination is indicated explicitly (i.e. a process is created by some other process).

The direction of Input/Output Signals in the SDL graphs is used to indicate the entity to which/from which communication is directed. If a process A communicates in parallel with processes B and C, all Inputs/Outputs to/from B are directed to one side, whereas communication with C is directed to the other side. However, there has been no formal convention used that communication to a certain entity (e.g. a HLR) will always be directed to a certain side (e.g. right).

In each state all those Input Signals are listed, which result in an action and/or state change. If an Input Signal is not listed in a state, receipt of this input should lead to an implicit consumption without any action or state change (according to the SDL rules). This implicit consumption is mainly used for receipt of the MAP DELIMITER indication and for receipt of a MAP CLOSE indication, except for a premature MAP CLOSE.

18.3 Interaction between MAP Provider and MAP Users

Each MAP User is defined by at least one SDL process. On the dialogue initiating side, the MAP User will create a new instance of a MAP Provider implicit by issuing a MAP-OPEN request. This instance corresponds to a TC Dialogue and lives as long as the dialogue exists (see also clause 14.3). There is a fixed relation between MAP User and this Provider instance, i.e. all MAP service primitives from the MAP User for this dialogue are sent to this instance and all TC components received by this MAP Provider are mapped onto service primitives sent to this MAP User.

On the receiving side a MAP Provider instance is created implicit by receipt of a TC BEGIN indication. The corresponding MAP User is determined by the Application Context name included in this primitive, i.e. each Application Context is associated with one and only one MAP User. An instance of this User will be created implicitly by receiving a MAP-OPEN indication. Note that in some cases there exist several SDL Processes for one MAP User (Application Context), e.g. the processes Register_SS_HLR, Erase_SS_HLR, Activate_SS_HLR, Deactivate_SS_HLR, Interrogate_SS_HLR, and Register_Password for the AC Network_Functional_SS_Handling. In these cases, a coordinator process is introduced acting as a MAP User, which in turn starts a sub-process depending on the first MAP service primitive received.

19 Mobility procedures

19.1 Location management Procedures

The signalling procedures in this subclause support:

- Interworking between the VLR and the HLR and between the VLR and the previous VLR (PVLR) when a non-GPRS subscriber performs a location update to a new VLR service area;
- Interworking between the SGSN, the HLR and the VLR when a subscriber with both GPRS and non-GPRS subscriptions performs a routeing area update in an SGSN and the Gs interface is implemented;
- Interworking between the SGSN and the VLR when a GPRS subscriber performs a routeing area update to a new SGSN service area;
- Interworking between the HLR and the VLR and between the HLR and the SGSN to delete a subscriber record from the VLR or the SGSN;
- Interworking between the VLR and the HLR and between the SGSN and the HLR to report to the HLR that a subscriber record has been purged from the VLR or the SGSN.

The MAP co-ordinating process in the HLR to handle a dialogue opened with the network location updating context is shown in figure 19.1/1. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see clause 25.1.1.




Figure 19.1/1: Process Location_Management_Coordinator_HLR

19.1.1 Location updating

19.1.1.1 General


The stage 2 specification for GPRS is in 3GPP TS 23.060 [104]. The interworking between the MAP signalling procedures and the GPRS procedures in the SGSN and the HLR is shown by the transfer of signals between these procedures.

The message flow for successful inter-VLR location updating when the IMSI can be retrieved from the PVLR is shown in figure 19.1.1/2.

The message flow for successful inter-VLR location updating when the IMSI cannot be retrieved from the PVLR is shown in figure 19.1.1/3.

The message flow for successful GPRS Attach/RA update procedure (Gs interface not installed) is shown in figure 19.1.1/4.

The message flow for successful GPRS Attach/RA update procedure combined with a successful VLR location updating (Gs interface installed) is shown in figure 19.1.1/5.




PVLR = Previous VLR

1) A_LU_REQUEST (Note 1)
2) MAP_SEND_IDENTIFICATION_req/ind
3) MAP_SEND_IDENTIFICATION_rsp/cnf
4) MAP_UPDATE_LOCATION_req/ind
5) MAP_CANCEL_LOCATION_req/ind
6) MAP_CANCEL_LOCATION_rsp/cnf
7) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 2)
8) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 2)
9) MAP_INSERT_SUBSCRIBER_DATA_req/ind
10) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
11) MAP_UPDATE_LOCATION_rsp/cnf
12) A_LU_CONFIRM (Note 1)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: Services printed in *italics* are optional.

Figure 19.1.1/2: Message flow for location updating to a new VLR area, when the IMSI can be retrieved from the previous VLR




PVLR = Previous VLR

1) A_LU_REQUEST (Note 1)
2) A_IDENTITY_REQUEST (Note 1)
3) A_IDENTITY_RESPONSE (Note 1)
4) MAP_UPDATE_LOCATION_req/ind
5) MAP_CANCEL_LOCATION_req/ind
6) MAP_CANCEL_LOCATION_rsp/cnf
7) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 2)
8) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 2)
9) MAP_INSERT_SUBSCRIBER_DATA_req/ind
10) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
11) MAP_UPDATE_LOCATION_rsp/cnf
12) A_LU_CONFIRM (Note 1)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: Services printed in *italics* are optional.

Figure 19.1.1/3: Message flow for location updating to a new VLR area, when the IMSI cannot be retrieved from the previous VLR




PSGSN = Previous SGSN

1) Gb_ATTACH_REQUEST or RA_UPDATE_REQUEST (Note 1, note 2)
2) MAP_UPDATE_GPRS_LOCATION_req/ind
3) MAP_CANCEL_LOCATION_req/ind
4) MAP_CANCEL_LOCATION_rsp/cnf
5) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 3)
6) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 3)
7) MAP_INSERT_SUBSCRIBER_DATA_req/ind
8) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
9) MAP_UPDATE_GPRS_LOCATION_rsp/cnf
10) Gb_ATTACH_ACCEPT or RA_UPDATE_ACCEPT (Note 1)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. The services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For security functions (authentication, ciphering, IMEI check) triggering refer to 3GPP TS 23.060 [104]. The MAP signalling invoked for these functions is described in clause 25 of the present document.
NOTE 3: Services printed in *italics* are optional.
NOTE 4: Refer to 3GPP TS 23.060 [104] for termination of the procedure and triggering of the signalling on the interface between the BSS and the SGSN.

Figure 19.1.1/4: Message flow for GPRS location updating (Gs interface not installed)



1) Gb_ATTACH_REQUEST or RA_UPDATE_REQUEST (Note 1, note 2)
2) MAP_UPDATE_GPRS_LOCATION_req/ind
3) MAP_CANCEL_LOCATION_req/ind
4) MAP_CANCEL_LOCATION_rsp/cnf
5) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 3)
6) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 3)
7) MAP_INSERT_SUBSCRIBER_DATA_req/ind
8) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
9) MAP_UPDATE_GPRS_LOCATION_rsp/cnf
10) Gs_LOCATION_UPDATE_REQUEST (Note 4)
11) MAP_UPDATE_LOCATION_req/ind (Note 5)
12) MAP_INSERT_SUBSCRIBER_DATA_req/ind
13) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
14) MAP_UPDATE_LOCATION_rsp/cnf
15) Gs_LOCATION_UPDATE_ACCEPT (Note 4)
16) Gb_ATTACH_ACCEPT or RA_UPDATE_ACCEPT (Note 1)
17) Gb_TMSI_REALLOCATION_COMPLETE (Note 1)
18) Gs_TMSI_REALLOCATION_COMPLETE (Note 4)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35]. The services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For security functions (authentication, ciphering, IMEI check) triggering refer to 3GPP TS 23.060 [104]. MAP processes invoked for those procedures are described in subclause 25.5.
NOTE 3: Services printed in *italics* are optional.

NOTE 5: For details of the procedure on the path between the SGSN and the VLR, see 3GPP TS 29.018 [106]. The services shown in chain lines indicate the trigger provided by the signalling on the path between the SGSN and the VLR, and the signalling triggered on the path between the SGSN and the VLR.
NOTE 4: Refer to 3GPP TS 23.060 [104] for termination of the procedure and triggering of the signalling on the interface between the BSS and the SGSN.
NOTE 5: For simplicity, the Location Cancellation procedure towards the previous VLR and optional tracing activation towards the new VLR are not shown in this figure.

Figure 19.1.1/5: Message flow for GPRS location updating (Gs interface installed)

19.1.1.2 Procedures in the VLR

The MAP process in the VLR for location updating for a non-GPRS subscriber is shown in figure 19.1.1/6. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

The MAP process in the VLR to retrieve the IMSI of a subscriber from the previous VLR (PVLR) is shown in figure 19.1.1/7. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

The process in the VLR for location updating for a GPRS subscriber when the Gs interface is installed is shown in figure 19.1.1/8.

The macro GPRS_Location_Update_Completion_VLR is shown in figure 19.1.1/9. The macro invokes a process not defined in this clause; the definition of this process can be found as follows:

Subscriber_Present_VLR	see subclause 25.10.1.

The macro GPRS_Update_HLR_VLR is shown in figure 19.1.1/10. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;
Insert_Subs_Data_VLR	see subclause 25.7.1;
Activate_Tracing_VLR	see subclause 25.9.4.

19.1.1.3 Procedure in the PVLR

The MAP process in the PVLR to handle a request for the IMSI of a subscriber from the new VLR is shown in figure 19.1.1/11. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind	see subclause 25.1.1.

19.1.1.4 Procedure in the SGSN

The MAP process in the SGSN for location updating for a GPRS subscriber is shown in figure 19.1.1/12. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;
Insert_Subs_Data_SGSN	see subclause 25.7.2;

Activate_Tracing_SGSN see subclause 25.9.5.

Sheet 2: The procedure Check_User_Error_In_Serving_Network_Entity is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110].

19.1.1.5 Procedures in the HLR

The MAP process in the HLR to handle a location updating request from a VLR is shown in figure 19.1.1/13. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Confirmation see subclause 25.2.2.

The MAP process in the HLR to handle a location updating request from an SGSN is shown in figure 19.1.1/14. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1;

Check_Confirmation see subclause 25.2.2;

Control_Tracing_With_SGSN_HLR see subclause 25.9.7.

Sheet 2: The procedure Super_Charged_Cancel_Location_HLR is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110]. If the HLR does not support the Super-Charger functionality, processing continues from the "No" exit of the test "Result=Pass?".

Sheet 2: The procedure Super_Charged_Location_Updating_HLR is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110]. If the HLR does not support the Super-Charger functionality, processing continues from the "No" exit of the test "Result=Pass?".

Sheet 2: If the HLR supports the Administrative Restriction of Subscribers" Access feature and roaming is allowed in the VPLMN then the HLR may check the "Supported RAT Types" received from the VLR against the access restriction parameters. If this check fails then the decision box "Roaming allowed in this PLMN" shall take the exit "No".

The MAP process in the HLR to notify Short Message Service Centres that a subscriber is now reachable is shown in figure 19.1.1/15. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Alert_Service_Centre_HLR see subclause 25.10.3.




Figure 19.1.1/6 (sheet 1 of 2): Process Update_Location_VLR




Figure 19.1.1/6 (sheet 2 of 2): Process Update_Location_VLR




Figure 19.1.1/7 (sheet 1 of 2): Process Send_Identification_VLR




Figure 19.1.1/7 (sheet 2 of 2): Process Send_Identification_VLR




Figure 19.1.1/8 (sheet 1 of 2): Process GPRS_Update_Location_Area_VLR




Figure 19.1.1/8 (sheet 2 of 2): Process GPRS_Update_Location_Area_VLR




Figure 19.1.1/9: Macro GPRS_Location_Update_Completion_VLR




Figure 19.1.1/10 (sheet 1 of 2): Macro GPRS_Update_HLR_VLR




Figure 19.1.1/10 (sheet 2 of 2): Macro GPRS_Update_HLR_VLR




Figure 19.1.1/11 (sheet 1 of 2): Process Send_Identification_PVLR




Figure 19.1.1/11 (sheet 2 of 2): Process Send_Identification_PVLR




Figure 19.1.1/12 (sheet 1 of 2): Process Update_GPRS_Location_SGSN




Figure 19.1.1/12 (sheet 2 of 2): Process Update_GPRS_Location_SGSN




Figure 19.1.1/13 (sheet 1 of 3): Process Update_Location_HLR




Figure 19.1.1/13 (sheet 2 of 3): Process Update_Location_HLR




Figure 19.1.1/13 (sheet 3 of 3): Process Update_Location_HLR




Figure 19.1.1/14 (sheet 1 of 2): Process Update_GPRS_Location_HLR




Figure 19.1.1/14 (sheet 2 of 2): Process Update_GPRS_Location_HLR




Figure 19.1.1/15: Process Subscriber_Present_HLR

19.1.2 Location Cancellation


19.1.2.1 General

Location cancellation is used to delete a subscriber record from the serving node (VLR or SGSN). The procedure is invoked:

- because the subscriber has registered with a new serving node, or
- because the HPLMN operator has decided to delete the subscriber record from the serving node, e.g. because the subscription has been withdrawn, or because roaming restrictions have been imposed. Location cancellation can be used to force location updating including updating of subscriber data in the serving node at the next subscriber access.

The message flow for location cancellation for a non-GPRS subscriber is shown in figure 19.1.2/1.


The message flow for location cancellation for a GPRS subscriber is shown in figure 19.1.2/2.



1) MAP_UPDATE_LOCATION_req/ind
2) MAP_CANCEL_LOCATION_req/ind
3) MAP_CANCEL_LOCATION_rsp/cnf

NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.2/1: Message flow for Location Cancellation (non-GPRS)



1) MAP_UPDATE_GPRS_LOCATION_req/ind
2) MAP_CANCEL_LOCATION_req/ind
3) MAP_CANCEL_LOCATION_rsp/cnf

NOTE: The service shown in dotted lines indicates the trigger provided by other MAP signalling.

Figure 19.1.2/2: Message flow for Location Cancellation (GPRS)

19.1.2.2 Procedure in the HLR

The MAP process in the HLR to cancel the location information in a VLR is shown in figure 19.1.2/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

The MAP process in the HLR to cancel the location information in a VLR as an independent process invoked from another process is shown in figure 19.1.2/4.

The MAP process in the HLR to cancel the location information in an SGSN is shown in figure 19.1.2/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

The MAP process in the HLR to cancel the location information in an SGSN as an independent process invoked from another process is shown in figure 19.1.2/6.

19.1.2.3 Procedure in the VLR

The MAP process in the VLR to handle a location cancellation request is shown in figure 19.1.2/7. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

19.1.2.4 Procedure in the SGSN

The MAP process in the SGSN to handle a location cancellation request is shown in figure 19.1.2/8. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.




Figure 19.1.2/3: Process Cancel_Location_HLR




Figure 19.1.2/4: Process Cancel_Location_Child_HLR




Figure 19.1.2/5: Process Cancel_GPRS_Location_HLR




Figure 19.1.2/6: Process Cancel_GPRS_Location_Child_HLR




Figure 19.1.2/7: Process Cancel_Location_VLR




Figure 19.1.2/8: Process Cancel_Location_SGSN

19.1.3 Void


19.1.4 MS Purging

19.1.4.1 General

O&M procedures in the VLR or SGSN can trigger MS purging either because of administrative action or because the MS has been inactive for an extended period. The O&M process in the VLR or in the SGSN should ensure that during the MS purging procedure any other attempt to access the MS record is blocked, to maintain consistency of data.


The message flow for a VLR to report MS purging to the HLR is shown in figure 19.1.4/1.

The message flow for an SGSN to report MS purging to the HLR is shown in figure 19.1.4/2.



1) MAP_PURGE_MS_req/ind
2) MAP_PURGE_MS_rsp/cnf

Figure 19.1.4/1: Message flow for MS purging (non-GPRS)



1) MAP_PURGE_MS_req/ind
2) MAP_PURGE_MS_rsp/cnf

Figure 19.1.4/2: Message flow for MS purging (GPRS)

19.1.4.2 Procedure in the VLR

The MAP process in the VLR to report MS purging to the HLR is shown in figure 19.1.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

19.1.4.3 Procedure in the SGSN

The MAP process in the SGSN to report MS purging to the HLR is shown in figure 19.1.4/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

Sheet 1: The procedure Purge_MS_In_Serving_Network_Entity is specific to Super-Charger; it is specified in 3GPP TS 23.116 [110]. If the HLR does not support the Super-Charger functionality, processing continues from the "No" exit of the test "Result=Pass?".

19.1.4.4 Procedure in the HLR

The MAP process in the HLR to handle a notification from a VLR or an SGSN that an MS record has been purged is shown in figure 19.1.4/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

If the notification was received from a VLR, the MAP process communicates with the location management application process specified in 3GPP TS 23.012 [23]; if the notification was received from an SGSN, the MAP process communicates with the GPRS mobility management application process specified in 3GPP TS 23.060 [104].




Figure 19.1.4/3: Process Purge_MS_VLR




Figure 19.1.4/4 (sheet 1 of 2): Process Purge_MS_SGSN




Figure 19.1.4/4 (sheet 2 of 2): Process Purge_MS_SGSN




Figure 19.1.4/5: Process Purge_MS_HLR

19.2 Handover procedures

19.2.1 General

In this subclause, the term "Inter-MSC handover" is used to denote handover or relocation between different MSCs.

The interfaces involved for Inter-MSC handover are shown in figure 19.2/1. There are two Inter-MSC handover procedures:

1) Basic Inter-MSC handover:

   The call is handed over from the controlling MSC(MSC—A) to another MSC(MSC—B) (figure 19.2/1a).

   Figure 19.2/2 shows the message flow for a successful handover from MSC-A to MSC—B, including a request for handover number allocation from MSC-B to VLR-B.


2) Subsequent Inter-MSC handover:

   After the call has been handed over from MSC-A to MSC-B, a further handover either to MSC-A (figure 19.2/1a) or to a third MSC (MSC-B') (figure 19.2/1b) may be necessary in order to continue the call.

   Figure 19.2/3 shows the message flow for a successful subsequent handover to MSC-B'. For a successful subsequent handover to MSC-A, the messages to and from MSC-B' and VLR-B' are omitted..




a) Basic handover procedure MSC-A to MSC-B and subsequent handover procedure MSC-B to MSC-A.



b) Subsequent handover procedure MSC-B to MSC-B'.


Figure 19.2/1: Interface structure for handover



1) MAP_PREPARE_HANDOVER_req/ind
2) MAP_ALLOCATE_HANDOVER_NUMBER_req/ind
3) MAP_SEND_HANDOVER_REPORT_req/ind
4) MAP_PREPARE_HANDOVER_rsp/cnf
5) MAP_SEND_HANDOVER_REPORT_rsp/cnf (Note)
6) MAP_PROCESS_ACCESS_SIGNALLING_req/ind
7) MAP_SEND_END_SIGNAL_req/ind
8) MAP_FORWARD_ACCESS_SIGNALLING_req/ind
9) MAP_PROCESS_ACCESS_SIGNALLING_req/ind
10) MAP_SEND_END_SIGNAL_rsp/cnf

NOTE: This can be sent at any time after the connection between MSC-A and MSC-B is established.

Figure 19.2/2: Example of a successful basic handover procedure to MSC-B



1) MAP_PREPARE_HANDOVER_req/ind
2) MAP_ALLOCATE_HANDOVER_NUMBER_req/ind
3) MAP_SEND_HANDOVER_REPORT_req/ind
4) MAP_PREPARE_HANDOVER_rsp/cnf
5) MAP_SEND_HANDOVER_REPORT_rsp/cnf (Note 1)
6) MAP_PROCESS_ACCESS_SIGNALLING_req/ind
7) MAP_SEND_END_SIGNAL_req/ind
8) MAP_PREPARE_SUBSEQUENT_HANDOVER_req/ind
9) MAP_PREPARE_HANDOVER_req/ind
10) MAP_ALLOCATE_HANDOVER_NUMBER_req/ind
11) MAP_SEND_HANDOVER_REPORT_req/ind
12) MAP_PREPARE_HANDOVER_rsp/cnf
13) MAP_SEND_HANDOVER_REPORT_rsp/cnf (Note 2)
14) MAP_PREPARE_SUBSEQUENT_HANDOVER_rsp/cnf
15) MAP_PROCESS_ACCESS_SIGNALLING_req/ind
16) MAP_SEND_END_SIGNAL_req/ind
17) MAP_SEND_END_SIGNAL_rsp/cnf (Note 3)

NOTE 1: This can be sent at any time after the connection between MSC-A and MSC-B is established.
NOTE 2: This can be sent at any time after the connection between MSC-A and MSC-B' is established.
NOTE 3: At this stage, the subsequent handover is complete. Any further interworking between MSC-A and MSC-B' is the same as the interworking between MSC-A and MSC-B after basic handover

Figure 19.2/3: Example of a successful subsequent handover to a third MSC

The MAP signalling procedures for inter-MSC handover support the allocation of a handover number or one or more relocation numbers and the transfer of encapsulated BSSAP or RANAP messages.

The minimum application context version for the MAP handover application context shall be:

- version 3 for inter-MSC UTRAN to UTRAN handover;
- version 3 for inter-MSC intersystem handover from GSM BSS to UTRAN;
- version 2 for inter-MSC intersystem handover from UTRAN to GSM BSS.

NOTE: If the MAP handover application context version 2 is used, subsequent handover to UTRAN is not possible.

The minimum application context version for the MAP handover application context should be version 2 for inter-MSC handover from GSM BSS to GSM BSS.

NOTE: If the MAP handover application context version 2 or lower is used, subsequent handover to UTRAN is not possible.

The BSSAP or RANAP messages encapsulated in MAP messages are processed by the Handover Control Application in each MSC. The information in the encapsulated BSSAP or RANAP messages is passed from the Handover Control Application to the MAP process at the sending end; the notation used in the SDL diagrams for the MAP processes is "HO_CA_MESSAGE_ind(Message transfer)". The information in the encapsulated BSSAP or RANAP messages is passed from the MAP process to the Handover Control Application at the sending end; the notation used in the SDL diagrams for the MAP processes is "HO_CA_MESSAGE_req(Message transfer)".

For details of the interworking between the A-interface and MAP procedures or the Iu-interface and MAP procedures, see 3GPP TS 23.009 [21] and 3GPP TS 29.010 [58].

19.2.2 Procedure in MSC-A

This subclause describes the inter-MSC handover procedure in MSC-A; it covers basic inter-MSC handover to another MSC (MSC-B) and subsequent inter-MSC handover to a third MSC (MSC-B') or back to the controlling MSC (MSC-A).

The MAP process in MSC-A to handle inter-MSC handover is shown in figure 19.2/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1.
Check_Confirmation	see subclause 25.2.2.

Communication between the MAP handover process and the Handover Control application is represented by the HO_CA_MESSAGE service. For a detailed description of the interworking between the Handover Control applications in different MSCs for the inter-MSC handover procedure, see 3GPP TS 23.009 [21].

19.2.2.1 Basic handover

The handling in MSC-A for basic inter-MSC handover is shown in sheets 1 to 6 of figure 19.2/4.

Sheet 1: The MAP_PREPARE_HANDOVER request may contain:

- an indication that handover number allocation is not required;
- the target Cell ID, for compatibility for handover to GSM;
- the target RNC ID, for SRNS relocation or inter-system handover from GSM to UMTS;
- the IMSI;
- UMTS encryption information and UMTS integrity protection information, which are necessary for inter-system handover from GSM to UMTS;

- GSM radio resource information (channel type).

The conditions for the presence of these parameters and the processing in MSC-B (3G_MSC-B) are described in detail in 3GPP TS 29.010 [58] and 3GPP TS 23.009 [21].

Sheet 2: The MAP_PREPARE_HANDOVER confirmation contains one of:

- no handover number, if the MAP_PREPARE_HANDOVER request included an indication that handover number allocation is not required;
- a handover number;
- one or more relocation numbers.

Sheet 2: The MAP_PREPARE_HANDOVER confirmation contains BSSAP or RANAP signalling information, which is passed to the Handover Control application in MSC-A.

Sheet 2: If the MAP_PREPARE_HANDOVER confirmation contains an indication that MSC-B does not support multiple bearers, the Handover Control application in MSC-A may request handover of one bearer to the same cell in MSC-B.

Sheet 5: If the original MAP_PREPARE_HANDOVER request included a parameter indicating that handover number allocation is not required, the Handover Control application in MSC-A may request a handover number (or one or more relocation numbers); this triggers a further MAP_PREPARE_HANDOVER request towards MSC-B

19.2.2.2 Handling of access signalling

The Handover Control application in MSC-A may forward access signalling to any of the MS, RNS-B or BSS-B using the MAP_FORWARD_ACCESS_SIGNALLING service; any of the MS, RNS-B or BSS-B may forward access signalling to the Handover Control application in MSC-A using the MAP_PROCESS_ACCESS_SIGNALLING service. These are non-confirmed services.

19.2.2.3 Subsequent handover

The handling in MSC-A for subsequent inter-MSC handover is shown in sheets 7 & 8 of figure 19.2/4. If the Handover Control Application determines that the call is to be handed over to a third MSC (MSC-B') it triggers another instance of the MAP process to handle the basic handover to MSC-B', and reports the result of the subsequent handover to the instance of the MAP process which handles the dialogue with MSC-B.

Sheet 8: While the MAP process in MSC-A is waiting for the completion of subsequent handover, it relays access signalling between the Handover Control application and the MS, RNS-B or BSS-B as described in subclause 19.2.2.2.

19.2.3 Procedure in MSC-B

This subclause describes the handover or relocation procedure in MSC-B; it covers basic handover or relocation from the controlling MSC (MSC-A) and subsequent handover or relocation.

The MAP process in MSC-B to handle handover or relocation is shown in figure 19.2/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1.
Check_Confirmation	see subclause 25.2.2.

Communication between the MAP handover process and the Handover Control application is represented by the HO_CA_MESSAGE service. For a detailed description of the interworking between the Handover Control applications in different MSCs for the inter-MSC handover procedure, see 3GPP TS 23.009 [21].

The ordering of allocation of handover number and radio resources shown in the SDL diagrams is not mandatory.

19.2.3.1 Basic handover

The handling in MSC-B for basic inter-MSC handover is shown in sheets 1 to 7 of figure 19.2/5.

Sheet 2: If the MAP_PREPARE_HANDOVER indication included a parameter requesting multiple bearers but MSC-B does not support multiple bearers, MSC-B sends a MAP_PREPARE_HANDOVER response indicating that multiple bearers are not supported, and waits for a possible MAP_PREPARE_HANDOVER indication requesting handover of a single bearer.

Sheet 6: If the original MAP_PREPARE_HANDOVER indication included a parameter indicating that handover number allocation is not required, MSC-A may send a further MAP_PREPARE_HANDOVER request to request the allocation of a handover number (or one or more relocation numbers).

19.2.3.2 Handling of access signalling

The Handover Control application in MSC-A may forward access signalling to any of the MS, RNS-B or BSS-B using the MAP_FORWARD_ACCESS_SIGNALLING service; any of the MS, RNS-B or BSS-B may forward access signalling to the Handover Control application in MSC-A using the MAP_PROCESS_ACCESS_SIGNALLING service. These are non-confirmed services. Signals to or from any of the MS, RNS-B or BSS-B are routed through the Handover Control application in MSC-B.

19.2.3.3 Subsequent handover

The handling in MSC-B for subsequent inter-MSC handover is shown in sheet 8 of figure 19.2/5.

While the MAP process in MSC-B is waiting for the completion of subsequent handover, it relays access signalling between MSC-A and the MS, RNS-B or BSS-B through the Handover Control application as described in subclause 19.2.3.2.

19.2.4 Macro Receive_Error_From_HO_CA

This macro is used by the handover processes in MSC-A and MSC-B to receive errors from the Handover Control Application at any state of a handover process.

19.2.5 Procedure in VLR-B

The process in VLR-B to handle a request for a handover number is shown in figure 19.2/7. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Check_Indication	see subclause 25.2.1.




Figure 19.2/4 (sheet 1 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 2 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 3 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 4 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 5 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 6 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 7 of 8): Process HO_MSC_A




Figure 19.2/4 (sheet 8 of 8): Process HO_MSC_A




Figure 19.2/5 (sheet 1 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 2 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 3 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 4 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 5 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 6 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 7 of 8): Process HO_MSC_B




Figure 19.2/5 (sheet 8 of 8): Process HO_MSC_B




Figure 19.2/6: Macro Receive_error_from_HO_CA




Figure 19.2/7: Process HO_VLR_B

19.3 Fault recovery procedures


When a location register has restarted after a fault, the fault recovery procedures ensure that the subscriber data in the VLR or in the SGSN become consistent with the subscriber data that are stored in the HLR for the MS concerned and that the location information in the HLR , the VLR and the SGSN reflect accurately the current location of the MS.

The stage 2 specification of fault recovery procedures in location registers is 3GPP TS 23.007 [19].

19.3.1 VLR fault recovery procedures

19.3.1.1 General

Restoration of an IMSI record in a VLR can be triggered by a location registration request from the MS or by a request from the HLR for a roaming number to route a mobile terminated call to the MS. If the restoration is triggered by a location registration request from the MS, the VLR performs the location updating procedure described in 3GPP TS 23.012 [23] and subclause 19.1.1 of the present document. If the restoration is triggered by a request for a roaming number, the VLR provides the roaming number and triggers an independent dialogue to restore the subscriber data as described in 3GPP TS 23.018 [97]. The message flow for data restoration triggered by a request for a roaming number is shown in figure 19.3.1/1.



1) MAP_PROVIDE_ROAMING_NUMBER_req/ind
2) MAP_PROVIDE_ROAMING_NUMBER_rsp/cnf
3) *MAP_SEND_AUTHENTICATION_INFO_req/ind* (Note 1, note 2)
4) *MAP_SEND_AUTHENTICATION_INFO_rsp/cnf* (Note 1, note 2)
5) MAP_RESTORE_DATA_req/ind
6) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 1, note 3)
7) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 1, note 3)
8) MAP_INSERT_SUBSCRIBER_DATA_req/ind
9) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
10) MAP_RESTORE_DATA_rsp/cnf

NOTE 1: Services printed in *italics* are optional.
NOTE 2: If authentication is required.

NOTE 3: If subscriber tracing is active in the HLR.

Figure 19.3/1: Message flow for VLR restoration at mobile terminated call set-up

19.3.1.2 Procedure in the VLR

The procedure in the VLR to handle a dialogue for subscriber data restoration is defined in subclause 21.2.6 of the present document.

19.3.1.3 Procedure in the HLR

The MAP process in the HLR to handle a request for data restoration in the VLR is shown in figure 19.3.1/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check_Indication	see subclause 25.2.1;
Control_Tracing_With_VLR_HLR	see subclause 25.9.6.




Figure 19.3.1/2: Process Restore_Data_HLR

19.3.2 HLR fault recovery procedures

19.3.2.1 General


For the HLR, periodic back-up of data to non-volatile memory is mandatory.

Data that have been changed after the last back-up and before the restart of the HLR cannot be recovered by reload from the non-volatile memory. Therefore, a restoration procedure is triggered for each IMSI record that has been affected by the HLR fault at the first authenticated radio contact with the MS concerned.

As an implementation option, a notification can be forwarded to the MS to alert the subscriber to check the parameters for supplementary services that allow subscriber controlled input (MAP_FORWARD_CHECK_SS_INDICATION service). If the VLR receives this notification from the HLR it shall forward the notification to the MS. If the Gs-interface is implemented the VLR shall not forward this notification.

The message flow for HLR restoration for a non-GPRS subscriber is shown in figure 19.3.2/1.


The message flow for HLR restoration for a GPRS subscriber is shown in figure 19.3.2/2.



1) MAP_RESET_req/ind
2) MAP_PROCESS_ACCESS_REQUEST_req/ind
3) MAP_UPDATE_LOCATION_req/ind
4) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 1, Note 2)
5) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 1, Note 2)
6) MAP_INSERT_SUBSCRIBER_DATA_req/ind
7) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
8) MAP_UPDATE_LOCATION_rsp/cnf
9) *MAP_FORWARD_CHECK_SS_INDICATION_req/ind* (Note 1)
10) *MAP_FORWARD_CHECK_SS_INDICATION_req/ind* (Note 1)

NOTE 1: Services printed in *italics* are optional.
NOTE 2: If subscriber tracing is active in the HLR.

Figure 19.3.2/1: Message flow for HLR restoration (non-GPRS)



1) MAP_RESET_req/ind
2) MAP_UPDATE_GPRS_LOCATION_req/ind
3) *MAP_ACTIVATE_TRACE_MODE_req/ind* (Note 1, Note 2)
4) *MAP_ACTIVATE_TRACE_MODE_rsp/cnf* (Note 1, Note 2)
5) MAP_INSERT_SUBSCRIBER_DATA_req/ind
6) MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf
7) MAP_UPDATE_GPRS_LOCATION_rsp/cnf

NOTE 1: Services printed in *italics* are optional.
NOTE 2: If subscriber tracing is active in the HLR.

Figure 19.3.2/2: Message flow for HLR restoration (GPRS)

19.3.2.2 Procedure in the HLR

The MAP process in the HLR to notify the relevant serving nodes that the HLR has restarted is shown in figure 19.3.2/3.

The SGSN address list includes one instance of the address of each SGSN in which (according to the HLR data retrieved from the non-volatile memory) there is at least one subscriber registered who is affected by the HLR restart.

The VLR address list includes one instance of the address of each VLR in which (according to the HLR data retrieved from the non-volatile memory) there is at least one subscriber registered who is affected by the HLR restart.

The MAP process in the HLR to notify a VLR that the HLR has restarted is shown in figure 19.3.2/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Cnf see subclause 25.1.2.

The MAP process in the HLR to notify an SGSN that the HLR has restarted is shown in figure 19.3.2/5. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Cnf see subclause 25.1.2.

19.3.2.3 Procedure in the VLR

The MAP process in the VLR to handle a notification that an HLR has restarted is shown in figure 19.3.2/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

The VLR uses the HLR number or the HLR identity list included in the MAP_RESET indication to identify the IMSI records which are affected by the HLR restart.

19.3.2.4 Procedure in the SGSN

The MAP process in the SGSN to handle a notification that an HLR has restarted is shown in figure 19.3.2/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

The SGSN uses the HLR number or the HLR identity list included in the MAP_RESET indication to identify the IMSI records which are affected by the HLR restart.




Figure 19.3.2/3: Process Restart_HLR




Figure 19.3.2/4: Process Send_Reset_To_VLR_HLR




Figure 19.3.2/5: Process Send_Reset_To_SGSN_HLR




Figure 19.3.2/6: Process Receive_Reset_VLR





Figure 19.3.2/7: Process Receive_Reset_SGSN

19.4 Mobility Management event notification procedure

19.4.1 General

The Mobility Management event notification procedure is used to notify a gsmSCF about the successful completion of a Mobility Management event.

The message flow for Mobility Management event notification is shown in figure 19.4/1.



1) MAP_REPORT_MM_EVENT_req/ind
2) MAP_REPORT_MM_EVENT_rsp/cnf

Figure 19.5/1: Message flow for Mobility Management event notification

19.4.2 Procedure in the VLR or SGSN

The MAP process in the VLR or the SGSN to report a Mobility Management event to the gsmSCF is shown in figure 19.4/2.The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation: see subclause 25.2.2.

19.4.3 Procedure in the gsmSCF

The MAP process in the gsmSCF to handle the report of a Mobility Management event is shown in figure 19.4/3.The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;




Figure 19.4/2: Process Notify_MM_Event_VLR_Or_SGSN




Figure 19.4/3: Process Notify_MM_Event_gsmSCF

19.4 HLR Insert Subscriber Data macros

19.5.1 Macro Insert_Subs_Data_Framed_HLR

This macro is used to transfer subscriber data to the VLR as part of an existing dialogue for location updating or data restoration. The macro invokes a macro and a process not defined in this clause; the definitions of the macro and the process can be found as follows:

Wait_For_Insert_Subs_Data_Cnf see subclause 25.7.5;

Send_Insert_Subs_Data_HLR: see subclause 25.7.7.

The HLR may wait for each MAP_INSERT_SUBSCRIBER_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

If the VLR has indicated that it does not support a service or feature (e.g. Closed User Group or Advice Of Charge Charging Level) which the HLR operator regards as essential for the subscriber, the macro Wait_for_Insert_Subs_Data_Cnf takes the Replace_Service exit; the HLR sets the Roaming Restriction Due To Unsupported Feature flag to roaming restricted and sends Roaming Restriction Due To Unsupported Feature in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait_for_Insert_Subs_Data_Cnf takes the Replace_Service exit, the HLR sends the data for a replacement service in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

If subscriber data for CAMEL Phase 2 or later services are sent to a VLR which does not support the appropriate phase of CAMEL, the service behaviour may be unpredictable or incorrect. The HLR should therefore ensure that at the conclusion of a stand alone Insert Subscriber data procedure the data in the VLR do not require a capability that the VLR does not have. Possible mechanisms to ensure this are described in 3GPP TS 23.078 [98].

The HLR should send a Forwarded-to number which is not in E.164 international format to the VLR only when the HLR has ascertained that the VLR supports CAMEL Phase 2 or later. Thus, the ISD message containing the Forwarded-to number which is not in E.164 international format shall be sent to the VLR only if the HLR previously received confirmation from the VLR at Location Update that CAMEL Phase 2 or later is supported.

19.5.2 Macro Insert_GPRS_Subs_Data_Framed_HLR

This macro is used to transfer subscriber data to the SGSN as part of an existing dialogue for location updating. The macro invokes a macro and a process not defined in this clause; the definitions of the macro and the process can be found as follows:

Wait_For_Insert_GPRS_Subs_Data_Cnf see subclause 25.7.5;

Send_Insert_Subs_Data_HLR: see subclause 25.7.7.

The HLR may wait for each MAP_INSERT_SUBSCRIBER_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

If the SGSN has indicated that it does not support a service or feature which the HLR operator regards as essential for the subscriber, the macro Wait_for_Insert_GPRS_Subs_Data_Cnf takes the Replace_Service exit; the HLR sets the Roaming Restricted In SGSN Due To Unsupported Feature flag to roaming restricted and sends Roaming Restricted In SGSN Due To Unsupported Feature in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait_for_Insert_GPRS_Subs_Data_Cnf takes the Replace_Service exit, the HLR sends the data for a replacement service in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.




Figure 19.5/1: Macro Insert_Subs_Data_Framed_HLR




Figure 19.5/2: Macro Insert_GPRS_Subs_Data_Framed_HLR

20 Operation and maintenance procedures

20.1 General

The Operation and Maintenance procedures are used to support operation and maintenance of the network.

The following procedures exist for operation and maintenance purposes:

i) Tracing procedures;

ii) Subscriber Data Management procedures;

iii) Subscriber Identity procedure.

The following application contexts refer to complex MAP Users consisting of several processes:

- subscriberDataManagementContext;
- tracingContext.

Each of these two application contexts needs a co-ordinating process in the VLR or in the SGSN as described in the following subclauses.

20.1.1 Tracing Co-ordinator for the VLR

The Tracing Co-ordinator process in the VLR is shown the figure 20.1/1. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

20.1.2 Tracing Co-ordinator for the SGSN

The Tracing Co-ordinator process in the SGSN is shown in figure 20.1/2. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

20.1.3 Subscriber Data Management Co-ordinator for the VLR

The Subscriber Data Management Co-ordinator process in the VLR is shown in figure 20.1/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

20.1.4 Subscriber Data Management Co-ordinator for the SGSN

The Subscriber Data Management Co-ordinator process in the SGSN is shown in figure 20.1/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.




Figure 20.1/1: Process Co_Tracing_VLR




Figure 20.1/2: Process Co_Tracing_SGSN




Figure 20.1/3: Process Co_SDM_VLR




Figure 20.1/4: Process Co_SDM_SGSN

20.2 Tracing procedures


Three types of tracing procedures exist:

i) Subscriber tracing management procedures;

ii) Subscriber tracing procedures;


iii) Event tracing procedures.

The subscriber tracing management procedures are used to manage the status and the type of the tracing. The subscriber tracing activation procedure is used at location updating or data restoration when the trace mode of a subscriber is set active in the HLR or, as a stand alone procedure, when the subscriber is already registered and the trace mode becomes active in the HLR. The procedures to activate tracing in the VLR are shown in figures 20.2/1 and 20.2/3. The procedures to activate tracing in the SGSN are shown in figures 20.2/2 and 20.2/4.




1) Subscriber Tracing Activation
2) MAP_ACTIVATE_TRACE_MODE_req/ind
3) MAP_ACTIVATE_TRACE_MODE_rsp/cnf
4) Subscriber Tracing Activation Accepted

Figure 20.2/1: Stand-alone subscriber tracing activation procedure for non-GPRS




1) Subscriber Tracing Activation
2) MAP_ACTIVATE_TRACE_MODE_req/ind
3) MAP_ACTIVATE_TRACE_MODE_rsp/cnf
4) Subscriber Tracing Activation Accepted

Figure 20.2/2: Stand-alone subscriber tracing activation procedure for GPRS



1) MAP_UPDATE_LOCATION or MAP_RESTORE_DATA_req/ind
2) MAP_ACTIVATE_TRACE_MODE_req/ind
3) MAP_ACTIVATE_TRACE_MODE_rsp/cnf
4) MAP_UPDATE_LOCATION_rsp/cnf or MAP_RESTORE_DATA_rsp/cnf

Figure 20.2/3: Subscriber tracing activation procedure at location updating or data restoration




1) MAP_UPDATE_GPRS_LOCATION_req/ind
2) MAP_ACTIVATE_TRACE_MODE_req/ind
3) MAP_ACTIVATE_TRACE_MODE_rsp/cnf
4) MAP_UPDATE_GPRS_LOCATION_rsp/cnf

Figure 20.2/4: Subscriber tracing activation procedure at GPRS location updating


The MAP_ACTIVATE_TRACE_MODE request includes the IMSI, trace reference, trace type and identity of the OMC.

The subscriber tracing deactivation procedure is used when tracing of a subscriber in the VLR or in the SGSN is no longer required. The procedures are shown in figures 20.2/5 and 20.2/6.



1) Subscriber Tracing Deactivation
2) MAP_DEACTIVATE_TRACE_MODE_req/ind
3) MAP_DEACTIVATE_TRACE_MODE_rsp/cnf
4) Subscriber Tracing Deactivation Accepted


Figure 20.2/5: Subscriber tracing deactivation procedure for non-GPRS



1) Subscriber Tracing Deactivation
2) MAP_DEACTIVATE_TRACE_MODE_req/ind
3) MAP_DEACTIVATE_TRACE_MODE_rsp/cnf
4) Subscriber Tracing Deactivation Accepted

Figure 20.2/6: Subscriber tracing deactivation procedure for GPRS

The subscriber tracing procedures are used when the VLR detects any subscriber related activity for which the trace mode is activated, e.g. the VLR receives a MAP_PROCESS_ACCESS_REQUEST indication. The procedure is shown in figure 20.2/7.



1) MAP_PROCESS_ACCESS_REQUEST_req/ind
2) MAP_TRACE_SUBSCRIBER_ACTIVITY_req/ind
3) Subscriber tracing information

Figure 20.2/7: Subscriber tracing procedure in the serving MSC

20.2.1 Subscriber tracing activation procedure

20.2.1.1 Procedures in the HLR

A subscriber tracing activation request from the OMC starts the appropriate process in the HLR: ATM_With_VLR_HLR if tracing is required in the MSC/VLR, ATM_With_SGSN_HLR if tracing is required in the SGSN.

The process in the HLR to activate tracing in the VLR is shown in figure 20.2/8. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

The process in the HLR to activate tracing in the SGSN is shown in figure 20.2/9. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

20.2.1.2 Procedure in the VLR

The process in the VLR to activate tracing in a stand-alone dialogue is shown in figure 20.2/10. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.

20.2.1.3 Procedure in the SGSN

The process in the SGSN to activate tracing in a stand-alone dialogue is shown in figure 20.2/11. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.

20.2.2 Subscriber tracing deactivation procedure

20.2.2.1 Procedures in the HLR

A subscriber tracing deactivation request from the OMC starts the appropriate process in the HLR: DTM_HLR_With_VLR if tracing is no longer required in the MSC/VLR, DTM_HLR_With_SGSN if tracing is no longer required in the SGSN.

The process in the HLR to deactivate tracing in the VLR is shown in figure 20.2/12. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

The process in the HLR to deactivate tracing in the SGSN is shown in figure 20.2/13. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Sheet 1: If the Repeat attempt counter has reached its limit, the test "Repeat Attempt" takes the "No" exit; otherwise the test takes the "Yes" exit. The number of repeat attempts and the interval between successive repeat attempts are operator options.

20.2.2.2 Procedure in the VLR

The process in the VLR to deactivate tracing is shown in figure 20.2/14. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.

20.2.2.3 Procedure in the SGSN

The process in the SGSN to deactivate tracing is shown in figure 20.2/15. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.




Figure 20.2/8 (sheet 1 of 2): Process ATM_With_VLR_HLR




Figure 20.2/8 (sheet 2 of 2): Process ATM_With_VLR_HLR




Figure 20.2/9 (sheet 1 of 2): Process ATM_with_SGSN_HLR




Figure 20.2/9 (sheet 2 of 2): Process ATM_with_SGSN_HLR




Figure 20.2/10: Process ATM_Standalone_VLR




Figure 20.2/11: Process ATM_Standalone_SGSN




Figure 20.2/12 (sheet 1 of 2): Process DTM_with_VLR_HLR




Figure 20.2/12 (sheet 2 of 2): Process DTM_with_VLR_HLR




Figure 20.2/13 (sheet 1 of 2): Process DTM_with_SGSN_HLR




Figure 20.2/13 (sheet 2 of 2): Process DTM_with_SGSN_HLR




Figure 20.2/14: Process DTM_Standalone_VLR




Figure 20.2/15: Process DTM_Standalone_SGSN


20.3 Subscriber data management procedures

Two types of subscriber data management procedures exist:

1) Subscriber Deletion;

2) Subscriber Data Modification.


The subscriber deletion and subscriber data modification procedures are initiated by the OMC (see figures 20.3/1 , 20.3/2, 20.3/3 and 20.3/4).



1) Delete Subscriber
2) MAP_CANCEL_LOCATION_req/ind
3) MAP_CANCEL_LOCATION_rsp/cnf
4) Subscriber Deleted

Figure 20.3/1: Subscriber deletion procedure for non-GPRS


In the subscriber deletion procedure for a non-GPRS subscriber the subscriber data are removed from the VLR and the HLR. The HLR uses the MAP_CANCEL_LOCATION service.



1) Delete GPRS Subscriber
2) MAP_CANCEL_LOCATION_req/ind
3) MAP_CANCEL_LOCATION_rsp/cnf
4) GPRS Subscriber Deleted

Figure 20.3/2: Subscriber deletion procedure for GPRS

In the subscriber deletion procedure for a GPRS subscriber the subscriber data are removed from the SGSN and the HLR. The HLR uses the MAP_CANCEL_LOCATION service.



1) Modify Subscriber Data
2) MAP_CANCEL_LOCATION_req/ind, MAP_INSERT_SUBSCRIBER_DATA_req/ind or MAP_DELETE_SUBSCRIBER_DATA_req/ind
3) MAP_CANCEL_LOCATION_rsp/cnf, MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf or MAP_DELETE_SUBSCRIBER_DATA_rsp/cnf
4) Subscriber Data Modified

Figure 20.3/3: Subscriber data modification procedure for non-GPRS

1) Modify Subscriber Data
2) MAP_CANCEL_LOCATION_req/ind, MAP_INSERT_SUBSCRIBER_DATA_req/ind or MAP_DELETE_SUBSCRIBER_DATA_req/ind
3) MAP_CANCEL_LOCATION_rsp/cnf, MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf or MAP_DELETE_SUBSCRIBER_DATA_rsp/cnf
4) Subscriber Data Modified

Figure 20.3/4: Subscriber data modification procedure for GPRS

In the subscriber data modification procedure the subscriber data are modified in the HLR and when necessary also in the VLR or in the SGSN. The HLR initiates one of the MAP_INSERT_SUBSCRIBER_DATA, MAP_DELETE_SUBSCRIBER_DATA or MAP_CANCEL_LOCATION services depending on the modified data.

20.3.1 Subscriber deletion procedure

20.3.1.1 Procedure in the HLR

The subscriber deletion process in the HLR is shown in figure 20.3/5. The MAP process invokes processes not defined in this clause; the definitions of these processes can be found as follows:

Cancel_GPRS_Location_Child_HLR see subclause 19.1.2.2;

Cancel_Location_Child_HLR see subclause 19.1.2.2.

20.3.1.2 Procedure in the VLR

The subscriber deletion procedure in the VLR is described in subclause 19.1.2.3 of the present document.

20.3.1.3 Procedure in the SGSN

The subscriber deletion procedure in the SGSN is described in subclause 19.1. 2.4 of the present document.

20.3.2 Subscriber data modification procedure

20.3.2.1 Procedure in the HLR

The OMC can modify the subscriber data in several different ways. The modifications can be categorised in the following groups:

1) data shall be modified in the HLR; no effect in the VLR;
2) data shall be modified in both the HLR and the VLR;
3) withdrawal of a basic service or a supplementary service requiring change to VLR data;
4) modification affects the roaming permission for the subscriber and the subscriber record shall be removed from the VLR data base;
5) withdrawal of non-GPRS Subscription caused by a change of Network Access Mode;
6) data shall be modified in the HLR; no effect in the SGSN;
7) data shall be modified in both the HLR and the SGSN;
8) withdrawal of GPRS subscription data or a basic service or a supplementary service requiring change to SGSN data;
9) modification affects the roaming permission for the subscriber and the subscriber record shall be removed from the SGSN data base;
10) withdrawal of GPRS Subscription caused by a change of Network Access Mode;
11) authentication algorithm or authentication key of the subscriber is modified.

In cases 2 and 7 the HLR uses the MAP_INSERT_SUBSCRIBER_DATA service.

In cases 3 and 8 the HLR uses the MAP_DELETE_SUBSCRIBER_DATA service.

In cases 4, 5, 9, 10 and 11 the HLR uses the MAP_CANCEL_LOCATION service.

If the deletion of subscriber data fails, the HLR may repeat the request; the number of repeat attempts and the time in between are HLR operator options, depending on the error returned by the VLR or the SGSN.

The subscriber data modification process in the HLR is shown in figure 20.3/6. The MAP process invokes processes not defined in this clause; the definitions of these processes can be found as follows:

Insert_Subs_Data_Stand_Alone_HLR	see subclause 25.7.3;
Cancel_Location_Child_HLR	see subclause 19.1.2.2;
Insert_GPRS_Subs_Data_Stand_Alone_HLR	see subclause 25.7.4;
Cancel_GPRS_Location_Child_HLR	see subclause 19.1.2.2.

The macro Delete_Subscriber_Data_HLR is shown in figure 20.3/7. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

The macro Delete_GPRS_Subscriber_Data_HLR is shown in figure 20.3/8. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

20.3.2.2 Procedures in the VLR

The process in the VLR to update subscriber data in a stand-alone dialogue is shown in figure 20.3/9. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check_Indication	see subclause 25.2.1;
Insert_Subs_Data_VLR	see subclause 25.7.1.

The process in the VLR to delete subscriber data is shown in figure 20.3/10. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.

20.3.2.3 Procedures in the SGSN

The process in the SGSN to update subscriber data in a stand-alone dialogue is shown in figure 20.3/11. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check_Indication	see subclause 25.2.1;
Insert_Subs_Data_SGSN	see subclause 25.7.2.

The process in the SGSN to delete subscriber data is shown in figure 20.3/12. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.




Figure 20.3/5: Process Delete_Subscriber_HLR




Figure 20.3/6 (sheet 1 of 2): Process Modify_Data_HLR




Figure 20.3/6 (sheet 2 of 2): Process Modify_Data_HLR




Figure 20.3/7: Macro Delete_Subscriber_Data_HLR




Figure 20.3/8: Macro Delete_GPRS_Subscriber_Data_HLR




Figure 20.3/9 (sheet 1 of 2): Process Ins_Subs_Data_Stand_Alone_VLR




Figure 20.3/9 (sheet 2 of 2): Process Ins_Subs_Data_Stand_Alone_VLR




Figure 20.3/10: Process Delete_Subs_Data_VLR




Figure 20.3/11 (sheet 1 of 2): Process Ins_Subs_Data_Stand_Alone_SGSN




Figure 20.3/11 (sheet 2 of 2): Process Ins_Subs_Data_Stand_Alone_SGSN





Figure 20.3/12: Process Delete_Subs_Data_SGSN

20.4 Subscriber Identity procedure

In the subscriber identity procedure the IMSI of the subscriber is retrieved from the HLR. The procedure is shown in figure 20.4/1.



1) Identity request
2) MAP_SEND_IMSI_req/ind
3) MAP_SEND_IMSI_rsp/cnf
4) Identity confirm

Figure 20.4/1: The subscriber identity procedure

20.4.1 Procedure in the VLR

The subscriber identity process in the VLR is shown in figure 20.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

20.4.2 Procedure in the HLR

The subscriber identity process in the HLR is shown in figure 20.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Check_Indication	see subclause 25.2.1.




Figure 20.4/2: Process Send_IMSI_VLR




Figure 20.4/3: Process Send_IMSI_HLR

21 Call handling procedures

21.1 General

The MAP call handling procedures are used:

- to retrieve routeing information to handle a mobile terminating call;
- to transfer control of a call back to the GMSC if the call is to be forwarded;
- to retrieve and transfer information between anchor MSC and relay MSC for inter MSC group calls / broadcast calls;
- to handle the reporting of MS status for call completion services;
- to handle the notification of remote user free for CCBS;
- to handle the alerting and termination of ongoing call activities for a specific subscriber;
- to handle early release of no longer needed resources.

The procedures to handle a mobile originating call and a mobile terminating call after the call has arrived at the destination MSC do not require any signalling over a MAP interface. These procedures are specified in 3GPP TS 23.018 [97].

The stage 2 specification for the retrieval of routeing information to handle a mobile terminating call is in 3GPP TS 23.018 [97]; modifications to this procedure for CAMEL are specified in 3GPP TS 23.078 [98], for optimal routeing of a basic mobile-to-mobile call in 3GPP TS 23.079 [99] and for CCBS in 3GPP TS 23.093 [107]. The interworking between the MAP signalling procedures and the call handling procedures for each entity (GMSC, HLR and VLR) is shown by the transfer of signals between these procedures.

The stage 2 specification for the transfer of control of a call back to the GMSC if the call is to be forwarded is in 3GPP TS 23.079 [99]. The interworking between the MAP signalling procedures and the call handling procedures for each entity (VMSC and GMSC) is shown by the transfer of signals between these procedures.

The stage 2 specifications for inter MSC group calls / broadcast calls are in 3GPP TS 43.068 [100] and 3GPP TS 43.069 [101]. The interworking between the MAP signalling procedures and the group call /broadcast call procedures for each entity (Anchor MSC and Relay MSC) is shown by the transfer of signals between these procedures.


The interworking between the call handling procedures and signalling protocols other than MAP are shown in 3GPP TS 23.018, 3GPP TS 23.078 and 3GPP TS 23.079 [99].

The stage 2 specification for the handling of reporting of MS status for call completion services and notification of remote user free for CCBS is in 3GPP TS 23.093 [107].

21.2 Retrieval of routing information

21.2.1 General

The message flows for successful retrieval of routeing information for a mobile terminating call are shown in figure 21.2/1 (mobile terminating call which has not been optimally routed) and 21.2/2 (mobile-to-mobile call which has been optimally routed). The message flow for successful retrieval of routeing information for a gsmSCF initiated call is shown in figure 21.2/3.




1) I_IAM (Note 1)
2) MAP_SEND_ROUTING_INFORMATION_req/ind (Note 2)
3) *MAP_PROVIDE_SUBSCRIBER_INFO_req/ind* (Note 3, Note 4)
4) *MAP_PROVIDE_SUBSCRIBER_INFO_rsp/cnf* (Note 4)
5) *MAP_SEND_ROUTING_INFORMATION_rsp/cnf* (Note 4)
6) *MAP_SEND_ROUTING_INFORMATION_req/ind* (Note 4)
7) MAP_PROVIDE_ROAMING_NUMBER_req/ind
8) MAP_PROVIDE_ROAMING_NUMBER_rsp/cnf
9) MAP_SEND_ROUTING_INFORMATION_rsp/cnf
10) I_IAM (Note 1)
11) *MAP_RESTORE_DATA_req/ind* (Note 4)
12) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 4)
13) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 4)
12) *MAP_RESTORE_DATA_rsp/cnf* (Note 4)

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations and ETSI specification:
- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: This service may also be used by an ISDN exchange for obtaining routing information from the HLR.
NOTE 3: As a network operator option, the HLR sends MAP_PROVIDE_SUBSCRIBER_INFORMATION to the VLR. For further details on the CAMEL procedures refer to 3GPP TS 23.078 [98].
NOTE 4: Services printed in *italics* are optional.

Figure 21.2/1: Message flow for retrieval of routeing information (non-optimally routed call)




1) I_IAM (Note 1)
2) MAP_SEND_ROUTING_INFORMATION_req/ind
3) MAP_PROVIDE_SUBSCRIBER_INFO_req/ind (Note 2)
4) MAP_PROVIDE_SUBSCRIBER_INFO_rsp/cnf (Note 2)
5) MAP_PROVIDE_ROAMING_NUMBER_req/ind (Note 2)
6) MAP_PROVIDE_ROAMING_NUMBER_rsp/cnf (Note 2)
7) MAP_SEND_ROUTING_INFORMATION_rsp/cnf
8) I_IAM (Note 1)
9) *MAP_RESTORE_DATA_req/ind* (Note 3)
10) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 3)
11) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 3)
12) *MAP_RESTORE_DATA_rsp/cnf* (Note 3)

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations & ETSI specification:
- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: For Optimal Routeing phase 1, only one of the information flows for Provide Subscriber Info and Provide Roaming Number is used.

NOTE 3: Services printed in *italics* are optional.

Figure 21.2/2: Message flow for retrieval of routeing information (optimally routed call)



1) MAP_SEND_ROUTING_INFORMATION_req/ind
2) *MAP_SEND_ROUTING_INFORMATION_rsp/cnf* (Note 1)
3) *MAP_SEND_ROUTING_INFORMATION_req/ind* (Note 1)
4) MAP_PROVIDE_ROAMING_NUMBER_req/ind
5) MAP_PROVIDE_ROAMING_NUMBER_rsp/cnf
6) MAP_SEND_ROUTING_INFORMATION_rsp/cnf
7) *MAP_RESTORE_DATA_req/ind* (Note 1)
8) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 1)
9) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 1)
10) *MAP_RESTORE_DATA_rsp/cnf* (Note 1)

NOTE 1: Services printed in *italics* are optional.

Figure 21.2/3: Message flow for retrieval of routeing information for a gsmSCF initiated call

The following MAP services are used to retrieve routing information:

MAP_SEND_ROUTING_INFORMATION see subclause 10.1;

MAP_PROVIDE_ROAMING_NUMBER see subclause 10.2;

MAP_PROVIDE_SUBSCRIBER_INFO see subclause 8.11.2;

MAP_RESTORE_DATA see subclause 8.10.3.

21.2.2 Procedure in the GMSC

The MAP process in the GMSC to retrieve routeing information for a mobile terminating call is shown in figure 21.2/6. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

Sheet 1: if the MAP_SEND_ROUTING_INFORMATION request included the OR Interrogation parameter, the test "OR interrogation?" takes the "Yes" exit; otherwise the test takes the "No" exit.

21.2.9 Process in the gsmSCF

For the purposes of retrieving routeing information from the HLR, the gsmSCF takes the role of the GMSC and follows the process specified in subclause 21.2.2.

21.2.4 Procedure in the HLR

The MAP process in the HLR to retrieve routeing information for a mobile terminating call is shown in figure 21.2/7. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Sheet 3: if the MAP_PROVIDE_ROAMING_NUMBER request included the OR Interrogation parameter, the test "OR interrogation?" takes the "Yes" exit; otherwise the test takes the "No" exit.

21.2.5 Procedure in the VLR to provide a roaming number

The MAP process in the VLR to provide a roaming number for a mobile terminating call is shown in figure 21.2/8. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;

21.2.6 Procedure in the VLR to restore subscriber data

The MAP process in the HLR to restore subscriber data is shown in figure 21.2/9. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;
Insert_Subs_Data_VLR	see subclause 25.7.1;
Activate_Tracing_VLR	see subclause 25.9.4.

21.2.7 Procedure in the VLR to provide subscriber information

The MAP process in the VLR to provide subscriber information for a mobile terminating call subject to CAMEL invocation is shown in figure 21.2/9. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;




Figure 21.2/6 (sheet 1 of 2): Process SRI_GMSC




Figure 21.2/6 (sheet 2 of 2): Process SRI_GMSC




Figure 21.2/7 (sheet 1 of 3): Process SRI_HLR




Figure 21.2/7 (sheet 2 of 3): Process SRI_HLR




Figure 21.2/7 (sheet 3 of 3): Process SRI_HLR




Figure 21.2/8: Process PRN_VLR




Figure 21.2/9: Process Restore_Data_VLR





Figure 21.2/10: Process PSI_VLR

21.3 Transfer of call handling

21.3.1 General

The message flow for successful transfer of call handling to forward a call is shown in figure 21.3/1.



1) MAP_RESUME_CALL_HANDLING_req/ind
2) *MAP_SEND_ROUTING_INFORMATION_req/ind* (Note 2)
3) *MAP_SEND_ROUTING_INFORMATION_rsp/cnf* (Note 2)
4) MAP_RESUME_CALL_HANDLING_rsp/cnf
5) I_REL (Note 1)
6) I_IAM (Note 1)

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations & ETSI specification:
- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: Services printed in *italics* are optional.

Figure 21.3/1: Message flow for transfer of call handling

If the HLR indicated in the response to the original request for routeing information that forwarding interrogation is required, the GMSC executes the Send Routeing Information procedure with the HLR to obtain forwarding information; otherwise the GMSC uses the forwarding data which were sent in the MAP_RESUME_CALL_HANDLING req/ind.

21.3.2 Process in the VMSC

The MAP process in the VMSC to retrieve routeing information for a mobile terminating call is shown in figure 21.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

If the capacity of a message signal unit in the lower layers of the protocol is enough to carry all the information which has to be sent to the GMSC, the test "Segmentation needed?" takes the "No" exit; otherwise the test takes the "Yes" exit.

21.3.3 Process in the GMSC

The MAP process in the GMSC to handle a request for the GMSC to resume call handling is shown in figure 21.3/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

If the parameter All Information Sent was present in the MAP_RESUME_CALL_HANDLING indication, the test "All Information Sent" takes the "Yes" exit; otherwise the test takes the "No" exit.




Figure 21.3/2: Process RCH_VMSC





Figure 21.3/3: Process RCH_GMSC

21.4 Inter MSC Group Call Procedures

21.4.1 General

The message flow for successful inter MSC group call / broadcast call set-up is shown in figure 21.4/1.



1) I_IAM (Note 1)
2) MAP_PREPARE_GROUP_CALL_req/ind
3) MAP_PREPARE_GROUP_CALL_rsp/cnf
4) I_IAM (Note 1)
5) MAP_SEND_GROUP_CALL_END_SIGNAL_req/ind
6) I_ACM (Note 1)
7) I_ACM (Note 1)
8) MAP_FORWARD_GROUP_CALL_SIGNALLING_req/ind (Note 2)
9) MAP_PROCESS_GROUP_CALL_SIGNALLING_req/ind (Note 2)
10) MAP_SEND_GROUP_CALL_END_SIGNAL_rsp/cnf
11) I_REL (Note 3)
12) I_REL (Note 3)

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations and ETSI specification:
- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: The MAP_FORWARD_GROUP_CALL_SIGNALLING and MAP_PROCESS_GROUP_CALL_SIGNALLING services are not applicable for voice broadcast calls.

NOTE 3: The call can be released from the PSTN/ISDN or the Relay MSC

Figure 21.4/1: Message flow for inter MSC group call / broadcast call

21.4.2 Process in the Anchor MSC

The MAP process in the Anchor MSC to retrieve and transfer information from / to the Relay MSC for VBS and VGCS calls is shown in figure 21.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1;
Check_Confirmation	see subclause 25.2.2.

21.4.3 Process in the Relay MSC

The MAP process in the Relay MSC to receive and transfer information from / to the Anchor MSC for VBS and VGCS calls is shown in figure 21.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1.




Figure 21.4/2 (sheet 1 of 2): Process ASCI_Anchor_MSC




Figure 21.4/2 (sheet 2 of 2): Process ASCI_Anchor_MSC




Figure 21.4/3 (sheet 1 of 2): Process ASCI_Relay_MSC




Figure 21.4/3 (sheet 2 of 2): Process ASCI_Relay_MSC

21.4A Inter MSC Group Call Info Retrieval

21.4A.1 General

The message flow for successful inter MSC group call info retrieval is shown in figure 21.4A/1.




Figure 21.4A/1: Message flow for inter MSC group call info retrieval

21.4A.2 Process in the MSC

The MAP process in the MSC to retrieve and group call information is shown in figure 21.4A/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

Receive_Open_Ind see subclause 25.1.2;




Figure 21.4A/2 (sheet 1 of 2): Process Group_Call_Info_Retrieval_MSC




Figure 21.4A/2 (sheet 2 of 2): Process Group_Call_Info_Retrieval_MSC

21.5 Void

21.6 CCBS: monitoring and reporting the status of the subscriber


21.6.1 Reporting co-ordinator process in the VLR

The MAP co-ordinating process in the VLR to handle a dialogue opened with the reporting application context is shown in figure 21.6/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

21.6.2 Setting the reporting state – stand-alone

The message flow for setting the reporting state in a stand-alone dialogue is shown in figure 21.6/1.



1) MAP_SET_REPORTING_STATE_req/ind
2) MAP_SET_REPORTING_STATE_rsp/cnf

Figure 21.6/1: Message flow for setting the reporting state – stand-alone dialogue

21.6.2.1 Process in the HLR

The MAP process in the HLR to set the reporting state in the VLR in a stand-alone dialogue is shown in figure 21.6/7. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

The result of a request to stop reporting is not reported to the CCBS application in the HLR.


21.6.2.2 Process in the VLR

The MAP process in the VLR to set the reporting state is shown in figure 21.6/8.

The macro Set_Reporting_State_VLR is shown in figure 21.6/9.


21.6.3 Status Reporting

The message flows for reporting the status of a subscriber are shown in figures 21.6/2 and 21.6/3.



1) MAP_STATUS_REPORT_req/ind
2) MAP_STATUS_REPORT_rsp/cnf

Figure 21.6/2: Message flow for status reporting, when monitoring continues in the VLR



1) MAP_STATUS_REPORT_req/ind
2) MAP_STATUS_REPORT_rsp/cnf
3) MAP_SET_REPORTING_STATE_req/ind
4) MAP_SET_REPORTING_STATE_rsp/cnf

Figure 21.6/3: Message flow for status reporting, when monitoring stops

The MAP_SET_REPORTING_STATE request is used to stop monitoring in the VLR. If the HLR requires the VLR to continue monitoring, it closes the dialogue without sending a MAP_SET_REPORTING_STATE request.

21.6.3.1 Process in the VLR

The MAP process in the VLR to send a status report to the HLR is shown in figure 21.6/10. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

This process can be used to report:

- an event, such as the user becoming free, or
- the result of a CCBS call attempt

to the HLR

21.6.3.2 Process in the HLR

The MAP process in the HLR to handle a status report is shown in figure 21.6/11. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

It is an implementation option whether to send the MAP_DELIMITER request before invoking the macro Set_Reporting_State_HLR.


The macro Receive_Status_Report_HLR is shown in figure 21.6/12.

The macro Set_Reporting_State_HLR is shown in figure 21.6/13. The macro invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Confirmation see subclause 25.2.2.


21.6.4 CCBS: Remote User Free

The message flows for handling remote user free are shown in figures 21.6/4 and 21.6/5.



1) MAP_REMOTE_USER_FREE_req/ind
2) MAP_REMOTE_USER_FREE_rsp/cnf

Figure 21.6/4: Remote User Free: recall not accepted



1) MAP_REMOTE_USER_FREE_req/ind
2) MAP_REMOTE_USER_FREE_rsp/cnf
3) MAP_STATUS_REPORT_req/ind
4) MAP_STATUS_REPORT_rsp/cnf

Figure 21.6/5: Remote User Free: recall accepted

21.6.4.1 Process in the HLR

The MAP process in the HLR to handle Remote User Free is shown in figure 21.6/14. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

21.6.3.2 Process in the VLR

The MAP process in the VLR to handle Remote User Free is shown in figure 21.6/15. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Confirmation see subclause 25.2.2.




Figure 21.6/6: Process Reporting_Coord_VLR




Figure 21.6/7: Process Set_Reporting_State_Stand_Alone_HLR




Figure 21.6/8: Process Set_Reporting_State_VLR




Figure 21.6/9: Macro Receive_Set_Reporting_State_VLR




Figure 21.6/10 (sheet 1 of 2): Process Send_Status_Report_VLR




Figure 21.6/10 (sheet 2 of 2): Process Send_Status_Report_VLR




Figure 21.6/11: Process Status Report_HLR




Figure 21.6/12: Macro Receive_Status_Report_HLR




Figure 21.6/13: Macro Set_Reporting_State_HLR




Figure 21.6/14: Process Remote_User_Free_HLR




Figure 21.6/15 (sheet 1 of 2): Process Remote_User_Free_VLR




Figure 21.6/15 (sheet 2 of 2): Process Remote_User_Free_VLR

21.7 Void


21.8 Void

21.9 Immediate Service Termination (IST)

21.9.1 IST Alert

The Immediate Service Termination Alert procedure is used to keep track of the call activities performed by subscribers who are marked as being subject to IST monitoring and, possibly, to terminate the call activities for which the alert was sent, or all the call activities related to the subscriber for whom the alert was sent.

The message flow for alerting is shown in figure 21.9/1; the MSC may be a Visited MSC or a Gateway MSC.



1) MAP_IST_ALERT_req/ind
2) MAP_IST_ALERT_rsp/cnf

Figure 21.9/1: Message flow for IST Alert

21.9.1.1 Procedure in the MSC

The MAP process in the MSC (Visited MSC or Gateway MSC) is shown in figure 21.9/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

21.9.1.2 Procedure in the HLR


The MAP process in the HLR is shown in figure 21.9/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

21.9.2 IST Command

The Immediate Service Termination Command procedure is used to terminate the call activities related to a subscriber.

The message flow for the IST Command procedure is shown in figure 21.9/2; the MSC may be a Visited MSC or a Gateway MSC.



1) MAP_IST_COMMAND_req/ind
2) MAP_IST_COMMAND_rsp/cnf

Figure 21.9/2: Message flow for IST Command

21.9.2.1 Procedure in the HLR

The MAP process in the HLR is shown in figure 21.9/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

21.9.2.2 Procedure in the MSC

The MAP process in the MSC is shown in figure 21.9.6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.




Figure 21.9/3: Process IST_Alert_MSC




Figure 21.9/4: Process IST_Alert_HLR




Figure 21.9/5: Process IST_Command_HLR





Figure 21.9/6: Process IST_Command_MSC

21.10 Resource Management

21.10.1 General

The message flow for successful release of resources is shown in figure 21.10/1.



1) I_IAM (Note 1)
2) MAP_SEND_ROUTING_INFORMATION_req/ind
3) MAP_PROVIDE_ROAMING_NUMBER_req/ind
4) I_REL (Note 1)
5) MAP_PROVIDE_ROAMING_NUMBER_rsp/cnf
6) MAP_SEND_ROUTING_INFORMATION_rsp/cnf
7) MAP_RELEASE_RESOURCES (Note 2)

NOTE 1: TUP or ISUP may be used in signalling between MSCs, depending on the network type between the MSCs. For further details on the TUP and ISUP procedures refer to the following ITU-T Recommendations & ETSI specification:
- Q.721-725 - Telephone User Part (TUP);
- ETS 300 356-1 - Integrated Services Digital Network (ISDN); Signalling System No.7; ISDN User Part (ISUP) version 2 for the international interface; Part 1: Basic services.

NOTE 2: Services printed in *italics* are optional.

Figure 21.10/1: Message flow for early release of resources

21.3.2 Process in the GMSC

The MAP process in the GMSC to release resources is shown in figure 21.10/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

21.3.3 Process in the VMSC

The MAP process in the VMSC to handle a request for the GMSC to release resources is shown in figure 21.10/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;




Figure 21.10/2: Process Release Resources_GMSC




Figure 21.10/3: Process Release Resources_VMSC

22 Supplementary services procedures

22.1 Supplementary service co-ordinator processes

22.1.1 Supplementary service co-ordinator process for the MSC

The co-ordinator process in the MSC to handle a CM connection request with CM service type Supplementary service activation is shown in figure 22.1/1. The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Process_Access_Request_MSC see subclause 25.4.1.

22.1.2 Void

22.1.3 Functional supplementary service co-ordinator process for the HLR

The MAP co-ordinator process in the HLR to handle a dialogue opened with the networkFunctionalSS application context is shown in figure 22.1/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

22.1.4 Call completion supplementary service co-ordinator process for the HLR

The MAP co-ordinator process in the HLR to handle a dialogue opened with the callCompletion application context is shown in figure 22.1/4. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.




Figure 22.1/1 (sheet 1 of 2): Process SS_Coordinator_MSC




Figure 22.1/1 (sheet 2 of 2): Process SS_Coordinator_MSC

Figure 22.1/2 void




Figure 22.1/3: Process SS_Coordinator_HLR




Figure 22.1/4: Process CC_Coordinator_HLR

22.2 Registration procedure

22.2.1 General

The registration procedure is used to register data related to a supplementary service in the HLR. The registration procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.

The registration procedure is shown in figure 22.2.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST (see clauses 8 and 25);

MAP_TRACE_SUBSCRIBER_ACTIVITY (see clauses 9 and 25);

MAP_PROVIDE_IMSI (see clauses 8 and 25);

MAP_FORWARD_NEW_TMSI (see clauses 8 and 25);

MAP_AUTHENTICATE (see clauses 8 and 25);

MAP_SET_CIPHERING_MODE (see clauses 8 and 25);


MAP_CHECK_IMEI (see clauses 8 and 25);

MAP_READY_FOR_SM (see clauses 12 and 25);

MAP_INSERT_SUBSCRIBER_DATA (see clauses 8 and 25);

The following service is certainly used:

MAP_REGISTER_SS (defined in clause 11).



1) A_CM_SERV_REQ (Note 1)
2) MAP_PROCESS_ACCESS_REQUEST (Note 2)
3) A_REGISTER_SS (Note 1)
4) MAP_REGISTER_SS_req/ind
5) MAP_REGISTER_SS_req/ind
6) MAP_REGISTER_SS_rsp/cnf
7) MAP_REGISTER_SS_rsp/cnf
8) A_REGISTER_SS ack (Note 1)
9) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 3)
10) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 3)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.2.1/1: Message flow for supplementary service registration

22.2.2 Procedure in the MSC

The A_REGISTER_SS service indication received by the MAP process in the MSC contains the SS-Code and any parameters that are related to the supplementary service.

The MAP user transfers the received information to the VLR in the MAP_REGISTER_SS request without checking the contents of the service indication. Rules for the mapping are described in 3GPP TS 29.011 [59].

The information in the MAP_REGISTER_SS confirm from the VLR is relayed to the MS in the A_REGISTER_SS response message as described in 3GPP TS 24.08x, 3GPP TS 24.08x and 3GPP TS 29.011.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The registration process in the MSC is shown in figure 22.2.2/1.

22.2.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;
Process_Access_Request_VLR	see subclause 25.4.2.

The MAP process in the VLR transfers the information received in the MAP_REGISTER_SS indication to the HLR in the MAP_REGISTER_SS request without checking the contents. The MAP_OPEN request includes the IMSI of the subscriber as the destination reference and the VLR number as the originating reference.

If the MAP_REGISTER_SS confirm is properly formed and contains a result or a user error, the MAP process in the VLR shall transfer the information contained in this primitive to the MSC in the MAP_REGISTER_SS response.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The registration process in the VLR is shown in figure 22.2.3/1.

22.2.4 Procedure in the HLR

The MAP process invokes a macro and a process not defined in this clause; the definitions of the macro and process can be found as follows:

Check_Indication	see subclause 25.2.1;
Insert_Subs_Data_Stand_Alone_HLR	see subclause 25.7.3.

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to a successful result, a partially successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]):

The registration process in the HLR is shown in figure 22.2.4/1.




Figure 22.2.2/1: Process Register_SS_MSC




Figure 22.2.3/1 (sheet 1 of 2): Process Register_SS_VLR




Figure 22.2.3/1 (sheet 2 of 2): Process Register_SS_VLR




Figure 22.2.4/1: Process Register_SS_HLR

22.3 Erasure procedure

22.3.1 General

The erasure procedure is used to erase data related to a supplementary service in the HLR. The erasure procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.

The erasure procedure is shown in figure 22.3.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST (see clauses 8 and 25);

MAP_TRACE_SUBSCRIBER_ACTIVITY (see clauses 9 and 25);

MAP_PROVIDE_IMSI (see clauses 8 and 25);

MAP_FORWARD_NEW_TMSI (see clauses 8 and 25);

MAP_AUTHENTICATE (see clauses 8 and 25);

MAP_SET_CIPHERING_MODE (see clauses 8 and 25);


MAP_CHECK_IMEI (see clauses 8 and 25);

MAP_READY_FOR_SM (see clauses 12 and 25);

MAP_INSERT_SUBSCRIBER_DATA (see clauses 8 and 25);

The following service is certainly used:

MAP_ERASE_SS (defined in clause 11).



1) A_CM_SERV_REQ (Note 1)
2) MAP_PROCESS_ACCESS_REQUEST (Note 2)
3) A_ERASE_SS (Note 1)
4) MAP_ERASE_SS_req/ind
5) MAP_ERASE_SS_req/ind
6) MAP_ERASE_SS_rsp/cnf
7) MAP_ERASE_SS_rsp/cnf
8) A_ERASE_SS ack (Note 1)
9) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 3)
10) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 3)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.3.1/1: Message flow for supplementary service erasure

22.3.2 Procedure in the MSC

The MSC procedure for erasure is identical to that specified for registration in subclause 22.2.2. The text and diagrams in subclause 22.2.2 apply with all references to registration changed to erasure.

22.3.3 Procedure in the VLR

The VLR procedure for erasure is identical to that specified for registration in subclause 22.2.3. The text and diagrams in subclause 22.2.3 apply with all references to registration changed to erasure.

22.3.4 Procedure in the HLR

The HLR procedure for erasure is identical to that specified for registration in subclause 22.2.4. The text and diagrams in subclause 22.2.4 apply with all references to registration changed to erasure.

22.4 Activation procedure

22.4.1 General

The activation procedure is used to activate a supplementary service in the HLR. The activation procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.


The activation procedure is shown in figure 22.4.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);
MAP_GET_PASSWORD	(defined in clause 11);
MAP_INSERT_SUBSCRIBER_DATA	(see clauses 8 and 25);

The following service is certainly used:

MAP_ACTIVATE_SS	(defined in clause 11).



1) A_CM_SERV_REQ (Note 1)
2) MAP_PROCESS_ACCESS_REQUEST (Note 2)
3) A_ACTIVATE_SS (Note 1)
4) MAP_ACTIVATE_SS_req/ind
5) MAP_ACTIVATE_SS_req/ind
6) *MAP_GET_PASSWORD_req/ind* (Note 3)
7) *MAP_GET_PASSWORD_req/ind* (Note 3)
8) *A_GET_PASSWORD* (Note 1, Note 3)
9) *A_GET_PASSWORD ack* (Note 1, Note 3)
10) *MAP_GET_PASSWORD_rsp/cnf* (Note 3)
11) *MAP_GET_PASSWORD_rsp/cnf* (Note 3)
12) MAP_ACTIVATE_SS_rsp/cnf
13) MAP_ACTIVATE_SS_rsp/cnf
14) A_ACTIVATE_SS ack (Note 1)
15) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 3)
16) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 3)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 of this document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.4.1/1: Message flow for supplementary service activation

22.4.2 Procedure in the MSC

The A_ACTIVATE_SS service indication received by the MAP user in the MSC contains the SS-Code and any parameters related to the supplementary service.

The MSC transfers the received information to the VLR in the MAP_ACTIVATE_SS request without checking the contents of the service indication. Rules for the mapping are described in 3GPP TS 29.011 [59].

The information in the MAP_ACTIVATE_SS confirm from the VLR is relayed to the MS in the A_ACTIVATE_SS response message, as described in TS 24.08x, 3GPP TS 24.08x and 3GPP TS 29.011.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The activation process in the MSC is shown in figure 22.4.2/1.

22.4.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;
Process_Access_Request_VLR	see subclause 25.4.2.

The MAP process in the VLR transfers the information received in the MAP_ACTIVATE_SS indication to the HLR in the MAP_ACTIVATE_SS request without checking the contents. The MAP_OPEN request includes the IMSI of the subscriber as the destination reference and the VLR number as the originating reference.

If the MAP_REGISTER_SS confirm is properly formed and contains a result or a user error, the MAP process in the VLR shall transfer the information contained in this primitive to the MSC in the MAP_ACTIVATE_SS response.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The activation process in the VLR is shown in figure 22.4.3/1.

22.4.4 Procedure in the HLR

The MAP process invokes a macro and a process not defined in this clause; the definitions of the macro and process can be found as follows:

Check_Indication	see subclause 25.2.1;
Insert_Subs_Data_Stand_Alone_HLR	see subclause 25.7.3.

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to a successful result, a partially successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]):

The activation process in the HLR is shown in figure 22.4.4/1.




Figure 22.4.2/1: Process Activate_SS_MSC




Figure 22.4.3/1 (sheet 1 of 2): Process Activate_SS_VLR




Figure 22.4.3/1 (sheet 2 of 2): Process Activate_SS_VLR




Figure 22.4.4/1 (sheet 1 of 2): Process Activate_SS_HLR




Figure 22.4.4/1 (sheet 2 of 2): Process Activate_SS_HLR

22.5 Deactivation procedure

22.5.1 General

The deactivation procedure is used to deactivate a supplementary service in the HLR. The deactivation procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described in the clauses below.


The deactivation procedure is shown in figure 22.5.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);
MAP_GET_PASSWORD	(defined in clause 11);
MAP_INSERT_SUBSCRIBER_DATA	(see clauses 8 and 25);

The following service is certainly used:

MAP_DEACTIVATE_SS	(defined in clause 11).



1) A_CM_SERV_REQ (Note 1)

2) MAP_PROCESS_ACCESS_REQUEST (Note 2)
3) A_DEACTIVATE_SS (Note 1)
4) MAP_DEACTIVATE_SS_req/ind
5) MAP_DEACTIVATE_SS_req/ind
6) *MAP_GET_PASSWORD_req/ind* (Note 3)
7) *MAP_GET_PASSWORD_req/ind* (Note 3)
8) *A_GET_PASSWORD* (Note 1, Note 3)
9) *A_GET_PASSWORD ack* (Note 1, Note 3)
10) *MAP_GET_PASSWORD_rsp/cnf* (Note 3)
11) *MAP_GET_PASSWORD_rsp/cnf* (Note 3)
12) MAP_DEACTIVATE_SS_rsp/cnf
13) MAP_DEACTIVATE_SS_rsp/cnf
14) A_DEACTIVATE_SS ack (Note 1)
15) *MAP_INSERT_SUBSCRIBER_DATA_req/ind* (Note 3)
16) *MAP_INSERT_SUBSCRIBER_DATA_rsp/cnf* (Note 3)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.5.1/1: Message flow for supplementary service deactivation

22.5.2 Procedure in the MSC

The MSC procedure for deactivation is identical to that specified for activation in subclause 22.4.2. The text and diagrams in subclause 22.4.2 apply with all references to activation changed to deactivation.

22.5.3 Procedures in the VLR

The VLR procedure for deactivation is identical to that specified for activation in subclause 22.4.3. The text and diagrams in subclause 22.4.3 apply with all references to activation changed to deactivation.

22.5.4 Procedures in the HLR

The HLR procedure for deactivation is identical to that specified for activation in subclause 22.4.4. The text and diagrams in subclause 22.4.4 apply with all references to activation changed to deactivation.

22.6 Interrogation procedure

22.6.1 General

The interrogation procedure is used to retrieve information related to a supplementary service from the VLR or the HLR. It is the VLR which decides whether an interrogation request should be forwarded to the HLR or not. Some non-supplementary service related services may be invoked as a result of the procedure, as described in the clauses below.

The interrogation procedure is shown in figure 22.6.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST (see clauses 8 and 25);

MAP_TRACE_SUBSCRIBER_ACTIVITY (see clauses 9 and 25);

MAP_PROVIDE_IMSI (see clauses 8 and 25);

MAP_FORWARD_NEW_TMSI (see clauses 8 and 25);

MAP_AUTHENTICATE (see clauses 8 and 25);


MAP_SET_CIPHERING_MODE (see clauses 8 and 25);

MAP_CHECK_IMEI (see clauses 8 and 25);

MAP_READY_FOR_SM (see clauses 12 and 25);

The following service is certainly used:

MAP_INTERROGATE_SS (defined in clause 11).



1) A_CM_SERV_REQ (Note 1)
2) MAP_PROCESS_ACCESS_REQUEST (Note 2)
3) A_INTERROGATE_SS (Note 1)
4) MAP_INTERROGATE_SS_req/ind
5) *MAP_INTERROGATE_SS_req/ind*
6) *MAP_INTERROGATE_SS_rsp/cnf*
7) MAP_INTERROGATE_SS_rsp/cnf
8) A_INTERROGATE_SS ack (Note 1)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines indicate the trigger provided by the signalling on the radio path, and the signalling triggered on the radio path.
NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
NOTE 3: Services printed in *italics* are optional.

Figure 22.6.1/1: Message flow for supplementary service interrogation

22.6.2 Procedure in the MSC

The MSC procedures for interrogation are identical to those specified for registration in subclause 22.2.2. The text and diagrams in subclause 22.2.2 apply with all references to registration changed to interrogation.

22.6.3 Procedures in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2;

Process_Access_Request_VLR see subclause 25.4.2.

The interrogation is answered either by the VLR or by the HLR, depending on the service interrogated.

1) Interrogation to be handled by the VLR

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to a successful result, a partially successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

2) Interrogation to be handled by the HLR

If the interrogation is to be handled by the HLR, the MAP process in the VLR transfers the information received in the MAP_INTERROGATE_SS indication to the HLR in the MAP_INTERROGATE_SS request without checking the contents of the service indication. The MAP_OPEN request includes the IMSI of the subscriber as the destination reference and the VLR number as the originating reference.

If the MAP_INTERROGATE_SS confirm is properly formed and contains a result or a user error, the MAP process in the VLR shall transfer the information contained in this primitive to the MSC in the MAP_INTERROGATE_SS response.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The Interrogation process in the VLR is shown in figure 22.6.3/1.

22.6.4 Procedure in the HLR

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication see subclause 25.2.1.

The HLR acts as follows:

The interrogation is answered either by the VLR or by the HLR, depending on the service interrogated.

1) Interrogation to be handled by the VLR

If the interrogation procedure should have been answered by the VLR, then the HLR assumes that the VLR does not support the interrogated supplementary service, and returns the SS Not Available error to the VLR.

2) Interrogation to be handled by HLR

The supplementary service request shall be processed according to 3GPP TS 23.011 [22] and the 23.08x and 23.09x-series of technical specifications. This handling may lead to either a successful result or an error being returned.

For call independent SS operations, each message shall contain only a single component. Messages which contain more than one component will be stopped at the air interface (as specified in 3GPP TS 29.011 [59]).

The Interrogation process in the HLR is shown in figure 22.6.4/1.




Figure 22.6.3/1 (sheet 1 of 2): Process Interrogate_SS_VLR




Figure 22.6.3/1 (sheet 2 of 2): Process Interrogate_SS_VLR




Figure 22.6.4/1: Process Interrogate_SS_HLR

22.7 Void

Figure 22.7.2/1 void

Figure 22.7.3/1 void

22.8 Password registration procedure

22.8.1 General

The password registration procedure is used to register a password in the HLR. The password registration procedure is a fully transparent communication between the MS and the HLR, except that some services may be invoked as a result of the procedure, as described below.


The password registration procedure is shown in figure 22.8.1/1.

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);

The following services are certainly used:

MAP_REGISTER_PASSWORD	(defined in clause 11);
MAP_GET_PASSWORD	(defined in clause 11).



1) A_CM_SERV_REQ (Note 1)
2) MAP_PROCESS_ACCESS_REQUEST (Note 2)
3) A_REGISTER_PASSWORD (Note 1)
4) MAP_REGISTER_PASSWORD_req/ind
5) MAP_REGISTER_PASSWORD_req/ind
6) MAP_GET_PASSWORD_req/ind (Note 3)
7) MAP_GET_PASSWORD_req/ind (Note 3)
8) A_GET_PASSWORD (Note 1, Note 3)
9) A_GET_PASSWORD ack (Note 1, Note 3)
10) MAP_GET_PASSWORD_rsp/cnf (Note 3)
11) MAP_GET_PASSWORD_rsp/cnf (Note 3)
12) MAP_GET_PASSWORD_req/ind (Note 3)
13) MAP_GET_PASSWORD_req/ind (Note 3)
14) A_GET_PASSWORD (Note 1, Note 3)
15) A_GET_PASSWORD ack (Note 1, Note 3)
16) MAP_GET_PASSWORD_rsp/cnf (Note 3)
17) MAP_GET_PASSWORD_rsp/cnf (Note 3)
18) MAP_GET_PASSWORD_req/ind (Note 3)
19) MAP_GET_PASSWORD_req/ind (Note 3)
20) A_GET_PASSWORD (Note 1, Note 3)
21) A_GET_PASSWORD ack (Note 1, Note 3)
22) MAP_GET_PASSWORD_rsp/cnf (Note 3)
23) MAP_GET_PASSWORD_rsp/cnf (Note 3)
24) MAP_REGISTER_PASSWORD_rsp/cnf
25) MAP_REGISTER_PASSWORD_rsp/cnf
26) A_REGISTER_PASSWORD (Note 1)

NOTE 1: For details of the procedure on the radio path, see 3GPP TS 24.008 [35], 3GPP TS 24.010 [36], 3GPP TS 24.08x and 3GPP TS 24.09x. Services shown in dotted lines are triggers/ triggered signalling on the radio path.
NOTE 2: For details of the Process Access Request procedure, refer to subclause 25.4 in the present document.
NOTE 3: The use of each of the three MAP_GET_PASSWORD operations is described in subclause 22.8.4.

Figure 22.8.1/1: Message flow for supplementary service password registration

22.8.2 Procedure in the MSC

The password registration procedure in the MSC is identical to that for activation specified in subclause 22.4.2. All the text and diagrams in subclause 22.4.2 apply with all references to activation changed to password registration.

22.8.3 Procedure in the VLR

The password registration procedure in the VLR is identical to that for activation specified in subclause 22.4.3. All the text and diagrams in subclause 22.4.3 apply with all references to activation changed to password registration.

22.8.4 Procedure in the HLR

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication see subclause 25.2.1.

The HLR shall process the MAP_REGISTER_PASSWORD indication as specified in 3GPP TS 23.011 [22]. During the handling of password registration, the password procedure is initiated (as specified in 3GPP TS 23.011 [22]) This involves the sending of MAP_GET_PASSWORD requests to the VLR.

The password registration process in the HLR is shown in figure 22.8.4/1.




Figure 22.8.4/1 (sheet 1 of 2): Process Register_PW_HLR




Figure 22.8.4/1 (sheet 2 of 2): Process Register_PW_HLR

22.9 Mobile Initiated USSD procedure

22.9.1 General

The procedure supports supplementary service signalling procedures which allow PLMN specific services to be introduced.

The message flow for the procedure can be found in 3GPP TS 23.090 [34].

The following services may be used:

MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see clauses 9 and 25);
MAP_PROVIDE_IMSI	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_CHECK_IMEI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25);
MAP_UNSTRUCTURED_SS_REQUEST	(defined in clause 11);
MAP_UNSTRUCTURED_SS_NOTIFY	(defined in clause 11).

The following service is certainly used:

MAP_PROCESS_UNSTRUCTURED_SS_REQUEST	(defined in clause 11).

22.9.2 Procedure in the MSC

The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Confirmation	see subclause 25.2.2.

The A_PROCESS_UNSTRUCTURED_SS_REQUEST from the MS contains information input by the user; the message may be fed to an application contained locally in the MSC or to the VLR. The rules for determining this are specified in 3GPP TS 23.090 [34].

1) Message Destined for the VLR

If the message is destined for the VLR then the MSC shall transfer the message to the VLR using the mapping specified in detail in 3GPP TS 29.011 [59].

2) Message Destined for the Local Application

If the message is destined for the local USSD application then the MSC shall transfer the information contained in the message to the application.

The process in the MSC is shown in figure 22.9.2/1.

22.9.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2;

Process_Access_Request_VLR see subclause 25.4.2.

The MAP_PROCESS_UNSTRUCTURED_SS_REQUEST from the MSC contains information input by the user; the message may be fed to an application contained locally in the VLR or to the HLR. The rules for determining this are specified in 3GPP TS 23.090 [34].

1) Message Destined for the HLR

If the message is destined for the HLR then the VLR shall transfer the message transparently to the HLR.

2) Message Destined for the Local Application

If the message is destined for the local USSD application then the VLR shall transfer the information contained in the message to the application.

The process in the VLR is shown in figure 22.9.3/1.

22.9.4 Procedure in the HLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

The MAP_PROCESS_UNSTRUCTURED_SS_REQUEST from the VLR contains information input by the user. If the alphabet used for the message is understood then the message shall be fed to an application contained locally in the HLR or to the gsmSCF or to a secondary HLR where the USSD application is located.

1) Message Destined for the Local Application

If the message is destined for the local USSD application then the HLR shall transfer the information contained in the message to the local application.

2) Message Destined for the gsmSCF or the secondary HLR

If the message is destined for the gsmSCF or the secondary HLR then the primary HLR shall transfer the message transparently to the next node.

The process in the primary HLR is shown in figure 22.9.4/1.

22.9.5 Procedures in the gsmSCF/secondary HLR

The MAP process invokes a macro not defined in this clause; the definition of this macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

The process in the gsmSCF or secondary HLR is shown in figure 22.9.5/1.




Figure 22.9.2/1 (sheet 1 of 3): Process MS_Init_USSD_MSC




Figure 22.9.2/1 (sheet 2 of 3): Process MS_Init_USSD_MSC




Figure 22.9.2/1 (sheet 3 of 3): Process MS_Init_USSD_MSC




Figure 22.9.3/1 (sheet 1 of 4): Process MS_Init_USSD_VLR




Figure 22.9.3/1 (sheet 2 of 4): Process MS_Init_USSD_VLR




Figure 22.9.3/1 (sheet 3 of 4): Process_MS_Init_USSD_VLR




Figure 22.9.3/1 (sheet 4 of 4): Process_MS_Init_USSD_VLR

Figure 22.9.3/2 void




Figure 22.9.4/1 (sheet 1 of 4): Process MS_Init_USSD_HLR




Figure 22.9.4/1 (sheet 2 of 4): Process MS_Init_USSD_HLR




Figure 22.9.4/1 (sheet 3 of 4): Process MS_Init_USSD_HLR




Figure 22.9.4/1 (sheet 4 of 4): Process MS_Init_USSD_HLR




Figure 22.9.5/1 (sheet 1 of 2): Process MS_Init_USSD_gsmSCF_Secondary_HLR




Figure 22.9.5/1 (sheet 2 of 2): Process MS_Init_USSD_gsmSCF_Secondary_HLR

22.10 Network initiated USSD procedure

22.10.1 General

The procedure supports supplementary service signalling procedures which allow PLMN specific services to be introduced.

The message flow for the procedure can be found in 3GPP TS 23.090 [34].

The following services may be used:

MAP_PAGE	(see clauses 8 and 25);
MAP_SEARCH_FOR_MOBILE_SUBSCRIBER	(see clauses 8 and 25);
MAP_PROCESS_ACCESS_REQUEST	(see clauses 8 and 25);
MAP_AUTHENTICATE	(see clauses 8 and 25);
MAP_SET_CIPHERING_MODE	(see clauses 8 and 25);
MAP_FORWARD_NEW_TMSI	(see clauses 8 and 25);
MAP_READY_FOR_SM	(see clauses 12 and 25).

At least one of the following services will certainly be used, and both may be used:

MAP_UNSTRUCTURED_SS_REQUEST	(defined in clause 11);
MAP_UNSTRUCTURED_SS_NOTIFY	(defined in clause 11).

22.10.2 Procedure in the MSC

The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Page_MSC	see subclause 25.3.1;
Search_For_MS_MSC	see subclause 25.3.2;
Process_Access_Request_MSC	see subclause 25.4.1.

The process in the MSC is shown in figure 22.10.2/1.

22.10.3 Procedure in the VLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1;
Check_Confirmation	see subclause 25.2.2.

The process in the VLR is shown in figure 22.10.3/1.

MSC Initiated USSD

If a USSD application in the MSC wishes to use the network initiated USSD procedure, and a connection to the MS does not exist then the MSC opens a dialogue with the VLR. This dialogue leads to the VLR performing page or search using the macro Start_USSD_VLR.

Macro Start_USSD_VLR

The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check_Confirmation	see subclause 25.2.1;
Process_Access_Request_VLR	see subclause 25.4.2.

The macro is shown in figure 22.10.3/2.

22.10.4 Procedure in the HLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Receive_Open_Cnf	see subclause 25.1.2;
Check_Indication	see subclause 25.2.1;
Check_Confirmation	see subclause 25.2.2.

The process in the primary HLR is shown in figures 22.10.4/1 and 22.10.4/2.

22.10.5 Procedure in the gsmSCF or secondary HLR

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

The procedure in the gsmSCF or secondary HLR is shown in figure 22.10.5/1.




Figure 22.10.2/1 (sheet 1 of 4): Process NW_Init_USSD_MSC




Figure 22.10.2/1 (sheet 2 of 4): Process NW_Init_USSD_MSC




Figure 22.10.2/1 (sheet 3 of 4): Process NW_Init_USSD_MSC




Figure 22.10.2/1 (sheet 4 of 4): Process NW_Init_USSD_MSC




Figure 22.10.3/1 (sheet 1 of 5): Process NW_Init_USSD_VLR




Figure 22.10.3/1 (sheet 2 of 5): Process NW_Init_USSD_VLR




Figure 22.10.3/1 (sheet 3 of 5): Process NW_Init_USSD_VLR




Figure 22.10.3/1 (sheet 4 of 5): Process NW_Init_USSD_VLR




Figure 22.10.3/1 (sheet 5 of 5): Process NW_Init_USSD_VLR




Figure 22.10.3/2 (sheet 1 of 2): Macro Start_USSD_VLR




Figure 22.10.3/2 (sheet 2 of 2): Macro Start_USSD_VLR




Figure 22.10.4/1 (sheet 1 of 5): Process NW_Init_USSD_HLR




Figure 22.10.4/1 (sheet 2 of 5): Process NW_Init_USSD_HLR




Figure 22.10.4/1 (sheet 3 of 5): Process NW_Init_USSD_HLR




Figure 22.10.4/1 (sheet 4 of 5): Process NW_Init_USSD_HLR




Figure 22.10.4/1 (sheet 5 of 5): Process NW_Init_USSD_HLR




Figure 22.10.4/2: Macro Start_USSD_HLR




Figure 22.10.5/1 (sheet 1 of 2): Process NW_Init_USSD_gsmSCF_secondary_HLR




Figure 22.10.5/1 (sheet 2 of 2): Process NW_Init_USSD_gsmSCF_Secondary_HLR

22.11 Common macros for clause 22

The following macros are used for the description of more than one of the supplementary service processes described in clause 22.

22.11.1 SS Password handling macros

Macro Get_Password_MSC

This macro is used by the MSC to relay a request for password from the VLR to the MS, and to relay a response from the MS back to the VLR. The macro is shown in figure 22.11.1/1.

Macro Get_Password_VLR

This macro is used by the VLR to relay a request for password from the HLR to the MSC, and to relay a response from the MSC back to the HLR. The macro invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication	see subclause 25.2.1.

The macro is shown in figure 22.11.1/2.

22.11.2 Void




Figure 22.11.1/1: Macro Get_Password_MSC




Figure 22.11.1/2: Macro Get_Password_VLR

Figure 22.11.2/1 void

Figure 22.11.2/2 void

Figure 22.11.2/3 void

Figure 22.11.2/4 void

Figure 22.11.2/5 void

22.12 Supplementary Service Invocation Notification procedure


22.12.1 General

The Supplementary Service Invocation Notification procedure is used to notify a gsmSCF about the invocation of a GSM Supplementary Service.

The supplementary service invocation notification procedure is shown in figure 22.12.1/1.

The following service is certainly used:

MAP_SS_INVOCATION_NOTIFY (defined in clause 11).



1) MAP_SS_INVOCATION_NOTIFY_req/ind
2) MAP_SS_INVOCATION_NOTIFY_rsp/cnf

Figure 22.12.1/1: Message flow for supplementary service invocation notification

22.12.2 Procedure in the MSC

The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

The supplementary service invocation notification process in the MSC is shown in figure 22.12.2/1.

22.12.3 Procedure in the gsmSCF

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind	see subclause 25.1.1.

The supplementary service invocation notification process in thegsmSCF is shown in figure 22.12.3/1.




Figure 22.12.2/1: Process Notify_SS_Invocation_MSC




Figure 22.12.3/1: Process Note_SS_Invocation_gsmSCF


22.13 Activation of a CCBS request

22.13.1 General

The message flow to activate a CCBS request is shown in figure 22.13.1/1.

The following service is certainly used:

MAP_REGISTER_CC_ENTRY (defined in clause 11).



1) MAP_REGISTER_CC_ENTRY_req/ind
2) MAP_REGISTER_CC_ENTRY_rsp/cnf

Figure 22.13.1/1: Message flow to activate a CCBS request

22.13.2 Procedure in the VLR

The MAP process in the VLR to activate a CCBS request is shown in figure 22.13.2/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

22.13.3 Procedure in the HLR

The MAP process in the HLR to activate a CCBS request is shown in figure 22.13.2/1.




Figure 22.13.2/1: Process Register_CC_Entry_VLR




Figure 22.13.3/1: Process Register_CC_Entry_HLR


22.14 Deactivation of a CCBS request

22.14.1 General

The message flow to deactivate a CCBS request is shown in figure 22.14.1/1.

The following service is certainly used:

MAP_ERASE_CC_ENTRY (defined in clause 11).



1) MAP_ERASE_CC_ENTRY_req/ind
2) MAP_ERASE_CC_ENTRY_rsp/cnf

Figure 22.14.1/1: Message flow to deactivate a CCBS request

22.14.2 Procedure in the VLR

The MAP process in the VLR to deactivate a CCBS request is shown in figure 22.14.2/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

22.14.3 Procedure in the HLR

The MAP process in the HLR to deactivate a CCBS request is shown in figure 22.14.2/1.




Figure 22.14.2/1: Process Erase_CC_Entry_VLR




Figure 22.14.3/1: Process Erase_CC_Entry_HLR

23 Short message service procedures

23.1 General

The short message service procedures are used to control both mobile originated and mobile terminated short message transfer.

Four procedures exist for short message services:

- mobile originated short message service transfer;
- mobile terminated short message service transfer;
- short message alert procedure;
- short message delivery status report procedure.

The following application context refers to a complex MAP user consisting of several processes:

- shortMessageGatewayContext.

This application context needs a co-ordinating process in the HLR. Additionally a co-ordinating process needed for the mobile originated situation in the MSC, because the A_CM_SERV_REQ message does not distinguish between mobile originated short message transfer and the short message alert procedures.

NOTE: the A_CM_SERV_REQ message is not used for SMS over GPRS. The modelling is based on the assumption that the SGSN will trigger the appropriate process, according to whether an RP_MO_DATA or an RP_SM_MEMORY_AVAILABLE is received over the LLC layer.

23.1.1 Mobile originated short message service Co-ordinator for the MSC

The process starts when the MSC receives an A_CM_SERV_REQ message (see 3GPP TS 24.008 [35]), with a CM service type indicating short message service, from the A-interface. The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Process_Access_Request_MSC see subclause 25.4.1.

If the macro Process_Access_Request_MSC takes the "OK" exit (which means that the MSC has sent an A_CM_SERVICE_ACCEPT to the MS), , the MS initiates mobile originated short message transfer or sends an indication that it has memory available for more short messages.

The SMS Co-ordinator process in the MSC is shown in figure 23.1/1.

23.1.2 Short message Gateway Co-ordinator for the HLR

The process starts when the HLR receives a MAP_OPEN indication using when the application context shortMessageGatewayContext. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.

The SM Gateway Co-ordinator process in the HLR is shown in figure 23.1/2.

If the Receive_Open_Ind macro takes the Vr exit then HLR shall perform the MAP dialogue as specified for the appropriate application context version. Depending on the subscriber data, handling at the MAP user application level may be performed as specified in subclauses 23.3.2 and 23.5.2 of the present document:




Figure 23.1/1 (sheet 1 of 2): Process Co_SMS_MSC




Figure 23.1/1 (sheet 2 of 2): Process Co_SMS_MSC





Figure 23.1/2: Process Co_SM_Gateway_HLR

23.2 The mobile originated short message transfer procedure

The mobile originated short message service procedure is used to forward a short message from a mobile subscriber to a Service Centre. The message flow for the mobile originated short message service procedure is shown in figure 23.2/1.



1) Short Message (3GPP TS 24.011 [37]).
2) MAP_SEND_INFO_FOR_MO_SMS (*).
3) MAP_SEND_INFO_FOR_MO_SMS_ACK (*).
4) TCAP BEGIN (**)
4a) TCAP CONTINUE (**)
4b) MAP_MO_FORWARD_SHORT_MESSAGE.
5) Short message (3GPP TS 23.040).
6) Short message Acknowledgement (3GPP TS 23.040).
7) MAP_MO_FORWARD_SHORT_MESSAGE_ACK.
8) Short Message Acknowledgement (3GPP TS 24.011 [37]).
(*) Messages 2) and 3) are not used by the SGSN.
(**) If
a)
the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MO_FORWARD_SHORT_MESSAGE request in a single TC message

and
b) the Interworking MSC operator and the serving node (MSC or SGSN) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])

then
the TCAP handshake may be omitted.

Figure 23.2/1: Mobile originated short message transfer

In addition the following MAP services are used:

MAP_PROCESS_ACCESS_REQUEST (see subclause 8.3); (*)

MAP_AUTHENTICATE (see subclause 8.5); (*)

MAP_SET_CIPHERING_MODE (see subclause 8.6); (*)

MAP_PROVIDE_IMSI (see subclause 8.9); (*)

MAP_CHECK_IMEI (see subclause 8.7);

MAP_FORWARD_NEW_TMSI (see subclause 8.9); (*)

MAP_TRACE_SUBSCRIBER_ACTIVITY (see subclause 9.1); (*)

MAP_READY_FOR_SM (see subclause 12.4).

(*) These services are not used by the SGSN.

23.2.1 Procedure in the serving MSC

Any CAMEL-specific handling defined in this subclause is omitted if the MSC does not support CAMEL control of MO SMS, or if the subscriber does not have a subscription for CAMEL control of MO SMS.

The process starts when the MSC receives a short message from the MS. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Indication see subclause 25.2.1;

Check_Confirmation see subclause 25.2.2.

Sheet 1: If the MSC is integrated with the SMS-IWMSC, it communicates directly with the Short Message Service Centre (SMSC) using one of the protocols described in 3GPP TS 23.039 [25a]; otherwise it communicates with the SMS-IWMSC using MAP.

Sheet 3: If the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MO_FORWARD_SHORT_MESSAGE request in a single TC message, the test "Message segmentation needed" takes the "No" exit; otherwise the test takes the "Yes" exit.

Sheet 3:The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the serving MSC's operator and the SMS-IWMSC's operator (see 3GPP TS 33.204 [34a]).

The mobile originated short message service process in the MSC is shown in figure 23.2/2.

23.2.2 Procedure in the VLR

Any CAMEL-specific handling defined in this subclause is omitted if the VLR does not support CAMEL control of MO SMS.

The process starts when the VLR receives a dialogue opening request followed by a MAP_PROCESS_ACCESS_REQUEST including a CM service type Short Message Service. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1;

Process_Access_Request_VLR see subclause 25.4.2.

The mobile originated short message transfer process in the VLR is shown in figure 23.2/3.

23.2.3 Procedure in the SGSN

Any CAMEL-specific handling defined in this subclause is omitted if the SGSN does not support CAMEL control of MO SMS, or if the subscriber does not have a subscription for CAMEL control of MO SMS.

The process starts when the SGSN receives a short message received from the MS over the Gb interface. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

Sheet 2: If the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MO_FORWARD_SHORT_MESSAGE request in a single TC message, the test "Message segmentation needed" takes the "No" exit; otherwise the test takes the "Yes" exit.

Sheet 2:The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the serving SGSN's operator and the SMS-IWMSC's operator (see 3GPP TS 33.204 [34a]).

The mobile originated short message service process in the SGSN is shown in figure 23.2/4.

23.2.4 Procedure in the SMS Interworking MSC (SMS-IWMSC)

This procedure applies only when the SMS-IWMSC is not integrated with the serving MSC or SGSN.

The process starts when the SMS-IWMSC receives a dialogue opening request with the application context shortMsgMO-RelayContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

Sheet 1:The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the SMS-IWMSC's operator and the serving node's operator (see 3GPP TS 33.204 [34a]).

The mobile originated short message service transfer process in the SMS-IWMSC is shown in figure 23.2/5.




Figure 23.2/2 (sheet 1 of 4): Process MO_SM_MSC




Figure 23.2/2 (sheet 2 of 4): Process MO_SM_MSC




Figure 23.2/2 (sheet 3 of 4): Process MO_SM_MSC




Figure 23.2/2 (sheet 4 of 4): Process MO_SM_MSC




Figure 23.2/3 (sheet 1 of 2): Process MOSM_VLR




Figure 23.2/3 (sheet 2 of 2): Process MO_SM_VLR




Figure 23.2/4 (sheet 1 of 3): Process MO_SM_SGSN




Figure 23.2/4 (sheet 2 of 3): Process MO_SM_SGSN




Figure 23.2/4 (sheet 3 of 3): Process MO_SM_SGSN




Figure 23.2/5 (sheet 1 of 2): Process MO_SM_IWMSC




Figure 23.2/5 (sheet 2 of 2): Process MO_SM_IWMSC

23.3 The mobile terminated short message transfer procedure

The mobile terminated short message transfer procedure is used for forwarding a short message or several short messages from a Service Centre to a mobile subscriber. The message flow for the mobile terminated short message procedure for a single short message transfer is shown in figure 23.3/1.




Figure 23.3/1: Mobile terminated short message service procedures

1) Short Message (3GPP TS 23.040).
2) MAP_SEND_ROUTING_INFO_FOR_SM.
3) MAP_SEND_ROUTING_INFO_FOR_SM_ACK.
4) TCAP BEGIN (***)
4a) TCAP CONTINUE (***)
4b) MAP_MT_FORWARD_SHORT_MESSAGE.
5) MAP_SEND_INFO_FOR_MT_SMS (*).
5a) MAP_CONTINUE_CAMEL_SMS_HANDLING (*)(**)
5b) MAP_SEND_INFO_FOR_MT_SMS (*)(**)
6) MAP_PAGE/MAP_SEARCH_FOR_MOBILE_SUBSCRIBER (*).
7) Page (3GPP TS 24.008 [35]).
8) Page response (3GPP TS 24.008 [35]).
9) MAP_PROCESS_ACCESS_REQUEST_ACK and MAP_SEARCH_FOR_MOBILE_SUBSCRIBER_ACK (*).
10) MAP_SEND_INFO_FOR_MT_SMS_ACK (*).
11) Short Message (3GPP TS 24.011 [37]).
12) Short Message Acknowledgement (3GPP TS 24.011 [37]).
13) MAP_MT_FORWARD_SHORT_MESSAGE_ACK.
14) Short Message Acknowledgement (3GPP TS 23.040).

(*) Messages 5), 5a), 5b), 6), 9), and 10) are not used by the SGSN.
(**) These messages are used only for a subscriber provisioned with MT-SMS-CSI in the VLR.
(***) If
a)
- the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MT_FORWARD_SHORT_MESSAGE request in a single TC message,

and
b) the SMS Gateway MSC operator and the serving node (MSC or SGSN) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])
then
the TCAP handshake may be omitted.

The message flow for the mobile terminated short message procedure for multiple short message transfer is shown in figure 23.3/2.




Figure 23.3/2: Mobile terminated short message procedure for multiple short message transfer

1) Short Message (3GPP TS 23.040 [26]).
2) MAP_SEND_ROUTING_INFO_FOR_SM.
3) MAP_SEND_ROUTING_INFO_FOR_SM_ACK.
4) TCAP BEGIN (***)
4a TCAP CONTINUE (***)
4b) MAP_MT_FORWARD_SHORT_MESSAGE (note 1).
5) MAP_SEND_INFO_FOR_MT_SMS (*).
5a) MAP_CONTINUE_CAMEL_SMS_HANDLING (*)(**)
5b) MAP_SEND_INFO_FOR_MT_SMS (*)(**)
6) MAP_PAGE/MAP_SEARCH_FOR_MOBILE_SUBSCRIBER (*).
7) Page (*3GPP TS 48.008 [49]*).
8) Page response (3GPP TS 24.008 [35]).
9) MAP_PROCESS_ACCESS_REQUEST_ACK and MAP_SEARCH_FOR_MOBILE_SUBSCRIBER_ACK (*).
10) MAP_SEND_INFO_FOR_MT_SMS_ACK (*).
11) Short Message (3GPP TS 24.011 [37]).
12) Short Message Acknowledgement (3GPP TS 24.011 [37]).
13) MAP_MT_FORWARD_SHORT_MESSAGE_ACK.
14) Short Message Acknowledgement (3GPP TS 23.040 [26]).
15) Short Message (3GPP TS 23.040 [26]).

16) MAP_MT_FORWARD_SHORT_MESSAGE (note 2).
17) Short Message (3GPP TS 24.011 [37]).
18) Short Message Acknowledgement (3GPP TS 24.011 [37]).
19) MAP_MT_FORWARD_SHORT_MESSAGE_ACK.
20) Short Message Acknowledgement (3GPP TS 23.040 [26]).

(*) Messages 5), 5a), 5b) 6), 9), and 10) are not used by the SGSN.
(**) These messages are used only for a subscriber provisioned with MT-SMS-CSI in the VLR.
(***) If
a) the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MT_FORWARD_SHORT_MESSAGE request in a single TC message,
and
b) the SMS Gateway MSC operator and the serving node (MSC or SGSN) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])
then the TCAP handshake may be omitted.

NOTE 1: The 'More Messages To Send' flag is TRUE.
NOTE 2: The 'More Messages To Send' flag is FALSE.

In the multiple short message transfer the service MAP_MT_FORWARD_SHORT_MESSAGE can be used several times. However, the short message transfer is always acknowledged to the Service Centre before the next short message is sent.

In addition the following MAP services are used:

MAP_PROCESS_ACCESS_REQUEST	(see subclause 8.3); (*)
MAP_PAGE	(see subclause 8.2); (*)
MAP_SEARCH_FOR_MS	(see subclause 8.2); (*)
MAP_AUTHENTICATE	(see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE	(see subclause 8.6); (*)
MAP_CHECK_IMEI	(see subclause 8.7);
MAP_FORWARD_NEW_TMSI	(see subclause 8.9); (*)
MAP_REPORT_SM_DELIVERY_STATUS	(see subclause 12.3);
MAP_INFORM_SERVICE_CENTRE	(see subclause 12.6);
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see subclause 9.1); (*)
MAP_READY_FOR_SM	(see subclause 12.4).

(*) These services are not used by the SGSN.

A message flow example for the mobile terminated short message procedure for a single short message transfer in an environment that makes use of an SMS Router for MT-short-message-transfer is shown in figure 23.3/2a.

NOTE: This message flow can be applied only if no IP-SM-GW deployed in the same network.




Figure 23.3/2a Mobile terminated short message procedure with SMS Router

1) Short Message (3GPP TS 23.040 [26])
2) & 3) MAP_SEND_ROUTING_INFO_FOR_SM
NOTE: The HLR relays the message MAP_SEND_ROUTING_INFO_FOR_SM received from the SMS-GMSC to the SMS Router on SCCP level. How this is done is implementation specific.

4) MAP_SEND_ROUTING_INFO_FOR_SM
5) MAP_SEND_ROUTING_INFO_FOR_SM_ACK and conditionally MAP_INFORM_SERVICE_CENTRE
6) MAP_SEND_ROUTING_INFO_FOR_SM_ACK and conditionally MAP_INFORM_SERVICE_CENTRE
7) Conditionally: Inform Service Centre (3GPP TS 23.040 [26])
8) MAP_MT_FORWARD_SHORT_MESSAGE
NOTE: In this example the SMS-GMSC decides to attempt delivery via MSC. Therefore the SCCP called party SSN shall be set to SSN for MSC

9) MAP_MT_FORWARD_SHORT_MESSAGE
10) MAP_MT_FORWARD_SHORT_MESSAGE_ERROR
NOTE: In this example delivery via the MSC is unsuccessful e.g. due to IMSI detached

11) MAP_MT_FORWARD_SHORT_MESSAGE_ERROR
12) MAP_MT_FORWARD_SHORT_MESSAGE
NOTE: In this example the SMS-GMSC decides to retry delivery via the SGSN. Therefore the SCCP called party SSN shall be set to the SSN for SGSN.

13) MAP_MT_FORWARD_SHORT_MESSAGE
14) MAP_MT_FORWARD_SHORT_MESSAGE_ACK
NOTE: In this example delivery via SGSN is successful

15) MAP_MT_FORWARD_SHORT_MESSAGE_ACK
16) Conditionally: MAP_REPORT_SM_DELIVERY_STATUS
NOTE: In this example unsuccessful delivery via MSC and successful delivery via SGSN is reported

17) MAP_REPORT_SM_DELIVERY_STATUS_Ack

18) Short Message Acknowledgement (3GPP TS 23.040 [26]).

A message flow example for the mobile terminated short message procedure for a single short message transfer in an environment that makes use of an IP-SM-GW (see 3GPP TS 23.204 [134]) for MT-short-message-transfer is shown in figure 23.3/2b.

NOTE: SMS Routers can apply this message flow as well.




Figure 23.3/2b Mobile terminated short message procedure with IP-SM-GW

1) Short Message (3GPP TS 23.040 [26])
2) MAP_SEND_ROUTING_INFO_FOR_SM
the message is forwarded to the IP-SM-GW assigned to the recipient of the SM
3) MAP_SEND_ROUTING_INFO_FOR_SM
4) MAP_SEND_ROUTING_INFO_FOR_SM

since the message is received from an IP-SM-GW, it is not forwarded to an IP-SM-GW
5) MAP_SEND_ROUTING_INFO_FOR_SM_ACK and conditionally MAP_INFORM_SERVICE_CENTRE
6) MAP_SEND_ROUTING_INFO_FOR_SM_ACK and conditionally MAP_INFORM_SERVICE_CENTRE
The IP-SM-GW returns its own address within the network node number parameter
7) Conditionally: Inform Service Centre (3GPP TS 23.040 [26])
8) MAP_MT_FORWARD_SHORT_MESSAGE
9) MAP_MT_FORWARD_SHORT_MESSAGE_ACK
10) Conditionally: MAP_REPORT_SM_DELIVERY_STATUS
NOTE: As an IP-SM-GW is deployed the message is acknowledged ignoring its content

11) MAP_REPORT_SM_DELIVERY_STATUS_Ack
12) Conditionally: MAP_REPORT_SM_DELIVERY_STATUS
since the message is received from an IP-SM-GW, it is processed
13) MAP_REPORT_SM_DELIVERY_STATUS_Ack
NOTE: Step 12 and 13 is independent of steps 10, 11, and 14. They can run in parallel.

14) Short Message Acknowledgement (3GPP TS 23.040 [26]).

23.3.1 Procedure in the SMS-GMSC

Any CAMEL-specific handling described in this subclause is omitted if the SMS-GMSC does not support CAMEL. CAMEL-specific handling is invoked only if the SMS-GMSC is integrated with the VMSC.

The process starts when the SMS-GMSC receives an SC_RP_MT_DATA indication from a Service Centre. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

Process MT_SM_GMSC sheet 1: If the MAP_SEND_ROUTING_INFO_FOR_SM confirmation included an LMSI, it shall be included in the sm-RP-DA information field of the first MAP_MT_FORWARD_SHORT_MESSAGE request sent to the serving MSC. In this case, the IMSI shall be included in the Destination Reference of the MAP_OPEN request. The SMS-GMSC shall not send an LMSI to an SGSN. If the SMS-GMSC does not send an LMSI to the serving node, the sm-RP-DA information field in the first MAP_MT_FORWARD_SHORT_MESSAGE request sent to the serving MSC or SGSN shall contain the IMSI, and the Destination Reference in the MAP_OPEN request shall not be present. The parameter SM_RP_OA shall contain the Service Centre address.

Process MT_SM_GMSC sheet 1: The indication of which number belongs to the SGSN and which to the MSC, received from the HLR in the MAP_SEND_ROUTING_INFO_FOR_SM confirm (see subclause 23.3.2) will enable the SMS-GMSC to map the causes received from one or both serving nodes into the appropriate causes for non GPRS, GPRS or both, and send them to the SC and the HLR.

Process MT_SM_GMSC sheet 2: The SMS-GMSC maps "Unexpected data value" and "System failure" MAP errors from the serving node to a "System failure" RP_ERROR error cause. The mapping between other MAP error causes and the RP_ERROR error cause is given in 3GPP TS 23.040 [26] and 3GPP TS 24.011 [37].

Process MT_SM_GMSC sheet 2: If the SMS-GMSC receives both MSC and SGSN numbers from the HLR as routeing information, it may choose which serving node to use for the first delivery attempt.

Process MT_SM_GMSC sheet 2: If the SMS-GMSC makes two delivery attempts, it may report the result of each delivery attempt to the HLR according to the conditions described below.

Procedure MT_SM_Delivery_Attempt_GMSC sheet 1: if the macro MT_SM_Transfer_MSC takes the Error exit, the SMS-GMSC maps the MAP User Error to the corresponding SC_RP error, as defined in 3GPP TS 23.040 [26].

Procedure MT_SM_Delivery_Attempt_GMSC sheet 3: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the GMSC's operator and the serving node's operator (see 3GPP TS 33.204 [34a]).

Procedure MT_SM_Delivery_Attempt_GMSC sheet 1, sheet 2, sheet 4, sheet 5: The SMS-GMSC invokes the macro Report_SM_Delivery_Stat_GMSC if:

- the reason received from the serving node for failure to deliver the message is absent subscriber_SM, unidentified subscriber or SM delivery failure with error cause "MS memory capacity exceeded", and the SC address is not yet included in the MWD set, or

- the reason received from the serving node for failure to deliver the message is absent subscriber_SM, unidentified subscriber or SM delivery failure with error cause MS memory capacity exceeded, and the corresponding flag in the HLR (as indicated in the information received in the MAP_INFORM_ SERVICE_CENTRE) is not set, or

- the reason received from the serving node (MSC or SGSN) for failure to deliver the message is absent subscriber_SM and the absent subscriber diagnostic is different from the absent subscriber diagnostic received in the MAP_INFORM_ SERVICE_CENTRE.

Procedure MT_SM_Delivery_Attempt_GMSC sheet 1, sheet 2, sheet 4, sheet 5: If absent subscriber diagnostic information (see 3GPP TS 23.040 [26]) is included with the absent subscriber_SM error indication then the SMS-GMSC relays this information to the HLR using the MAP_REPORT_SM_DELIVERY_STATUS service.

Procedure MT_SM_Delivery_Attempt_GMSC sheet 1, sheet 4: The More Messages To Send flag is set to TRUE or FALSE according to the information received from the Service Centre.

Procedure MT_SM_Delivery_Attempt_GMSC sheet 3: If the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MT_FORWARD_SHORT_MESSAGE request in a single TC message, the test "Message segmentation needed" takes the "No" exit; otherwise the test takes the "Yes" exit.

The mobile terminated short message transfer process in the SMS-GMSC is shown in figure 23.3/3. The procedure MT_SM_Delivery_Attempt_GMSC is shown in figure 23.3/4. The macro MT_SM_Transfer_MSC is shown in figure 23.3/7.

23.3.2 Procedure in the HLR

The process starts when the HLR receives a MAP_SEND_ROUTING_INFO_FOR_SM indication from the SMS-GMSC. If an SMS Router is deployed, the HLR receives MAP_SEND_ROUTING_INFO_FOR_SM from the SMS Router (step 4 in figure 23.3/2a); relaying a message received from the SMS-GMSC to the SMS Router on SCCP level (steps 2 and 3 in figure 23.3/2a) is done by implementation specific means and is not shown in figure 23.3/5.

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication see subclause 25.2.1.

Sheet 3: If the SMS-GMSC does not support GPRS functionality, it uses the protocol defined in the Release 96 version of this specification. The parameter "msc-Number" in "RoutingInfoForSM-Res" in the Release 96 version of the protocol definition corresponds to the parameter "networkNode-Number" in "RoutingInfoForSM-Res" in the Release 97 (and later) version of the protocol definition; therefore if the HLR populates the parameter "networkNode-Number" with the SGSN number, the Release 96 SMS-GMSC will interpret the SGSN number as an MSC number. If the HLR populates the "gprsNodeIndicator" parameter in the MAP_SEND_ROUTING_INFO_FOR_SM response, a Release 96 SMS-GMSC will silently discard the parameter.

Sheet 5: If the HLR received a LMSI from the VLR at location updating, it shall include the LMSI in the MAP_SEND_ROUTING_INFO_FOR_SM response only if the MAP_SEND_ROUTING_INFO_FOR_SM response also includes the MSC number.

The mobile terminated short message transfer process in the HLR is shown in figure 23.3/5.

23.3.3 Procedure in the Serving MSC

Any CAMEL-specific handling defined in this subclause is omitted if the MSC does not support CAMEL control of MT SMS, or if the subscriber does not have a subscription for CAMEL control of MT SMS.

The process starts when the MSC receives a dialogue opening request with the application context shortMsgMT-RelayContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Check_Indication	see subclause 25.2.1.

The mobile terminated short message transfer process in the serving MSC is shown in figure 23.3/6

Procedure MT_SM_VMSC sheet 1: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the Serving MSC's operator and the SMS Gateway MSC's operator (see 3GPP TS 33.204 [34a]).

The macro MT_SM_Transfer_MSC may be invoked either in a stand-alone serving MSC or in a serving MSC which is integrated with the SMS-GMSC. It is used to transfer the first MT short message of a possible sequence of messages. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check_Confirmation	see subclause 25.2.2.
Page_MSC	see subclause 25.3.1;
Search_for_MS_MSC	see subclause 25.3.2;
Process_Access_Request_MSC	see subclause 25.4.1;
Trace_Subscriber_Activity_MSC	see subclause 25.9.1.

The macro MT_SM_Transfer_MSC is shown in figure 23.3/7. The macro Check_Subscr_Identity_For_MT_SMS is shown in figure 23.3/8.

23.3.4 Procedure in the VLR

Any CAMEL-specific handling defined in this subclause is omitted if the VLR does not support CAMEL control of MT SMS.

The process starts when the VLR receives a dialogue opening request from the MSC. The process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;
Check_Indication	see subclause 25.2.1;
Check_Confirmation	see subclause 25.2.2;
Process_Access_Request_VLR	see subclause 25.4.2.

The mobile terminated short message transfer process in the VLR is shown in figure 23.3/9.

23.3.5 Procedure in the SGSN

Any CAMEL-specific handling defined in this subclause is omitted if the SGSN does not support CAMEL control of MT SMS, or if the subscriber does not have a subscription for CAMEL control of MT SMS.

The process starts when the SGSN receives a dialogue opening request with the application context shortMsgMT-RelayContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

The mobile terminated short message transfer process in the SGSN is shown in figure 23.3/10.

Procedure MT_SM_SGSN sheet 1: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the Serving SGSN's operator and the SMS Gateway MSC's operator (see 3GPP TS 33.204 [34a]).

The macro MT_SM_Transfer_SGSN is used to transfer the first MT short message of a possible sequence of messages. It is shown in figure 23.3/11.

The macro Check_Subscr_Identity_For_MT_SMS is shown in figure 23.3/8. The page and search procedures are shown in figures 23.3/12 and 23.3/13.

23.3.6 Procedure in the SMS Router

If SMS Router is deployed together with IP-SM-GW, then mobile terminated short message transfer process for IP-SM-GW applies as described in subclause 23.3.7.

The mobile terminated short message transfer process in the SMS Router is shown in figure 23.3/14.

Procedure MT_SM_SMS_ROUTER sheet 2: Allocated MT Correlation IDs have a limited lifetime, managed by Timer T1. The value of Timer T1 shall be operator configurable (its value being dependant on such factors as subscriber base, network size, number of roaming/SMS-interworking partners, average and peak SMS traffic load, etc.).

Procedure MT_SM_SMS_ROUTER sheet 2: MAP parameters to be stored against the MT Correlation ID are IMSI, networkNode-Number, gprsNodeIndicator, and additional-Number (if and as received within MAP_SEND_ROUTING_INFO_FOR_SHORT_MESSAGE_cnf), and optionally MSISDN as received within MAP_SEND_ROUTING_INFO_FOR_SHORT_MESSAGE_ind from the SMS-GMSC (and relayed by the HLR)). The SMS Router may also store the GT, or just the CC and NDC parts of the GT, of the SMS-GMSC from which the MAP_SEND_ROUTING_INFO_FOR_SHORT_MESSAGE_ind was received.

Procedure MT_SM_SMS_ROUTER sheet 3: The SCCP called party SSN received with Open_ind is used to decide whether the new dialogue is opend with the MSC or with the SGSN.

Procedure MT_SM_SMS_ROUTER sheet 4: The decision box "Retry expected" takes the "Yes" exit if two addresses were received from the HLR, the first delivery attempt was unsuccessful, and the second attempt has not yet been made.

Procedure MT_SM_SMS_ROUTER sheet 4: The task "Release MT Correlation ID" includes deleting of data stored against the MT Correlation ID.

23.3.7 Procedure in the IP-SM-GW

Process MT_SM_IPSMGW sheet 3: After unsuccessful delivery via the S-CSCF the IP-SM-GW may retry delivery via MSC and/or SGSN if MSC address and/or SGSN address are available (unless the reported error was 'memory capacity exceeded' in which case a retry shall not be done). If the retry is successful, a positive response is returned to the SMS-GMSC. If the retry is unsuccessful, an error indication is returned to the SMS-GMSC as follows:
If one of the error indications received from S-CSCF, MSC, or SGSN is AbsentsSubscriberSM or UnidentifiedSubscriber, this error shall be returned to the SMS-GMSC.

Process MT_SM_IPSMGW sheet 3: The IP-SM-GW invokes the macro Report_SM_Delivery_Stat_IPSMGW if:

- the reason for failure to deliver the message is absent subscriber_SM, unidentified subscriber or SM delivery failure with error cause "MS memory capacity exceeded", and the SC address is not yet included in the MWD set, or

- the reason for failure to deliver the message is absent subscriber_SM, unidentified subscriber or SM delivery failure with error cause MS memory capacity exceeded, and the corresponding flag in the HLR (as indicated in the information received in the MAP_INFORM_SERVICE_CENTRE) is not set, or

- the reason for failure to deliver the message is absent subscriber_SM and the absent subscriber diagnostic is different from the absent subscriber diagnostic received in the MAP_INFORM_SERVICE_CENTRE.

The mobile terminated short message transfer process in the IP-SM-GW is shown in figure 23.3/15.




Figure 23.3/3 (sheet 1 of 2): Process MT_SM_GMSC




Figure 23.3/3 (sheet 2 of 2): Process MT_SM_GMSC




Figure 23.3/4 (sheet 1 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 2 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 3 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 4 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 5 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 6 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 7 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/4 (sheet 8 of 8): Procedure MT_SM_Delivery_Attempt_GMSC




Figure 23.3/5 (sheet 1 of 6): Process MT_SM_HLR




Figure 23.3/5 (sheet 2 of 6): Process MT_SM_HLR




Figure 23.3/5 (sheet 3 of 6): Process MT_SM_HLR




Figure 23.3/5 (sheet 4 of 6): Process MT_SM_HLR




Figure 23.3/5 (sheet 5 of 6): Process MT_SM_HLR




Figure 23.3/5 (sheet 6 of 6): Process MT_SM_HLR




Figure 23.3/5a (sheet 1 of 1): Procedure Perform_Relaying




Figure 23.3/6 (sheet 1 of 4): Procedure MT_SM_VMSC




Figure 23.3/6 (sheet 2 of 4): Procedure MT_SM_VMSC




Figure 23.3/6 (sheet 3 of 4): Procedure MT_SM_VMSC




Figure 23.3/6 (sheet 4 of 4): Procedure MT_SM_VMSC




Figure 23.3/7 (sheet 1 of 4): Macro MT_SM_Transfer_MSC




Figure 23.3/7 (sheet 2 of 4): Macro MT_SM_Transfer_MSC




Figure 23.3/7 (sheet 3 of 4): Macro MT_SM_Transfer_MSC




Figure 23.3/7 (sheet 4 of 4): Macro MT_SM_Transfer_MSC




Figure 23.3/8: Macro Check_Subscr_Identity_For_MT_SMS




Figure 23.3/9 (sheet 1 of 3): Process MT_SM_VLR




Figure 23.3/9 (sheet 2 of 3): Process MT_SM_VLR




Figure 23.3/9 (sheet 3 of 3): Process MT_SM_VLR




Figure 23.3/10 (sheet 1 of 4): Process MT_SM_SGSN




Figure 23.3/10 (sheet 2 of 4): Process MT_SM_ SGSN




Figure 23.3/10 (sheet 3 of 4): Process MT_SM_ SGSN




Figure 23.3/10 (sheet 4 of 4): Process MT_SM_ SGSN




Figure 23.3/11 (sheet 1 of 3): Macro MT_SM_TRANSFER_SGSN




Figure 23.3/11 (sheet 2 of 3): Macro MT_SM_TRANSFER_SGSN




Figure 23.3/11 (sheet 3 of 3): Macro MT_SM_TRANSFER_SGSN




Figure 23.3/12 (sheet 1 of 1): Procedure Page_SMS_SGSN




Figure 23.3/13 (sheet 1 of 1): Procedure Search_SMS_SGSN




Figure 23.3/14 (sheet 1 of 4): Process MT_SM_ SMS_ROUTER




Figure 23.3/14 (sheet 2 of 4): Process MT_SM_ SMS_ROUTER




Figure 23.3/14 (sheet 3 of 4): Process MT_SM_ SMS_ROUTER




Figure 23.3/14 (sheet 4 of 4): Process MT_SM_ SMS_ROUTER




Figure 23.3/15 (sheet 1 of 3): Process MT_SM_ IPSMGW




Figure 23.3/15 (sheet 2 of 3): Process MT_SM_ IPSMGW





Figure 23.3/15 (sheet 3 of 3): Process MT_SM_ IPSMGW

23.4 The Short Message Alert procedure

The Short Message Alert procedure is used to alert the Service Centre when the mobile subscriber is active after a short message transfer has failed because the mobile subscriber is not reachable, or when the MS has indicated that it has memory capacity to accept a short message.

The message flow for the Short Message Alert procedure for the case when the mobile subscriber was not reachable is shown in figure 23.4/1.




1) CM Service Request (**), Page response or Location Updating (3GPP TS 24.008 [35]).
2) MAP_PROCESS_ACCESS_REQUEST / MAP_UPDATE_LOCATION_AREA (**).
3) MAP_READY_FOR_SM (Mobile Present) / MAP_UPDATE_LOCATION / Supplementary Service Control Request (*).
4) MAP_READY_FOR_SM_ACK (*).
5) MAP_ALERT_SERVICE_CENTRE (notes 1 and 2).
6) Alert Service Centre (3GPP TS 23.040).
7) MAP_ALERT_SERVICE_CENTRE_ACK.

NOTE 1: To all Service Centres in the Message Waiting List.
NOTE 2: The HLR initiates the MAP_ALERT_SERVICE_CENTRE service only if the MS Memory Capacity Exceeded flag is clear.
(*) For GPRS, messages 3) and 4) are sent/received by the SGSN.
(**) These messages are not used by the SGSN.

Figure 23.4/1: Short message alert procedure (Mobile is present)

The message flow for the Short Message Alert procedure for the case where the MS indicates that it has memory capacity to accept one or more short messages is shown in figure 23.4/2.



1) SM memory capacity available (3GPP TS 24.011 [37]).
2) MAP_READY_FOR_SM (Memory Available) (*).
3) MAP_READY_FOR_SM (Memory Available) (**).
4) MAP_READY_FOR_SM_ACK (**).
5) MAP_READY_FOR_SM_ACK (*).
6) SM memory capacity available (Acknowledge) (3GPP TS 24.011 [37]).
7) MAP_ALERT_SERVICE_CENTRE (note).
8) Alert Service Centre (3GPP TS 23.040).
9) MAP_ALERT_SERVICE_CENTRE_ACK.

NOTE: To all Service Centres in the Message Waiting List.
(*) Messages 2) and 5) are not used by the SGSN.
(**) For GPRS, messages 3) and 4) are sent/received by the SGSN.


Figure 23.4/2: Short message alert procedure (MS memory capacity available)

In addition the following MAP services are used in the MS memory available case:

MAP_PROCESS_ACCESS_REQUEST	(see subclause 8.3); (*)
MAP_AUTHENTICATE	(see subclause 8.5); (*)
MAP_SET_CIPHERING_MODE	(see subclause 8.6); (*)
MAP_PROVIDE_IMSI	(see subclause 8.9); (*)
MAP_CHECK_IMEI	(see subclause 8.7);
MAP_FORWARD_NEW_TMSI	(see subclause 8.9); (*)
MAP_TRACE_SUBSCRIBER_ACTIVITY	(see subclause 9.1). (*)

(*) These services are not used by the SGSN.

The Short Message Alert procedure when the MS indicates successful transfer after polling is shown in figure 23.4/3.



1) MAP_REPORT_SM_DELIVERY_STATUS (Successful Transfer).
2) MAP_REPORT_SM_DELIVERY_STATUS_ACK.
3) MAP_ALERT_SERVICE_CENTRE (note).
4) Alert Service Centre (3GPP TS 23.040).
5) MAP_ALERT_SERVICE_CENTRE_ACK.

NOTE: To all Service Centres in the Message Waiting List.

Figure 23.4/3: Short message alert procedure (Successful transfer after polling)

23.4.1 Procedure in the Serving MSC – the MS has memory available

The process starts when the MSC receives a notification from the MS that it has memory available. The process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Confirmation see subclause 25.2.2.

The short message alert process in the MSC for the MS memory capacity available case is shown in figure 23.4/4.

23.4.2 Procedures in the VLR

23.4.2.1 The Mobile Subscriber is present

If the VLR successfully handles a MAP_PROCESS_ACCESS_REQUEST indication or a MAP_UPDATE_LOCATION_AREA indication while the MS Not Reachable Flag (MNRF) is set, the VLR sends a MAP_READY_FOR_SM request to the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for non GPRS. If authentication fails during the handling of a MAP_PROCESS_ACCESS_REQUEST indication or a MAP_UPDATE_LOCATION_AREA indication, the VLR shall not send a MAP_READY_FOR_SM request to the HLR. The process in the VLR is described in detail in subclause 25.10.1.

23.4.2.2 The MS has memory available

The process starts when the VLR receives dialogue opening request followed by a MAP_PROCESS_ACCESS_REQUEST indication including a CM service type Short Message Service. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Receive_Open_Cnf see subclause 25.1.2;

Check_Indication see subclause 25.2.1;

Check_Confirmation see subclause 25.2.2.

The short message alert process in the VLR for the MS memory capacity available case is shown in figure 23.4/5.

23.4.3 Procedures in the SGSN

23.4.3.1 The Mobile Subscriber is present

If the SGSN successfully handles a Page response, Attach request or Routing Area Update request message (3GPP TS 24.008 [35]), while the MS Not Reachable for GPRS (MNRG) flag is set, the SGSN sends a MAP_READY_FOR_SM request to the HLR. The Alert Reason is set to indicate that the mobile subscriber is present for GPRS. If authentication fails during the handling of a Page response, Attach request or Routing Area Update request, the SGSN shall not send a MAP_READY_FOR_SM request to the HLR

The process in the SGSN is described in detail in subclause 25.10.23.

23.4.3.2 The Mobile Equipment has memory available

The process starts when the SGSN receives an RP_SM_MEMORY_AVAILABLE indication from the MS. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

The short message alert procedure in the SGSN for the MS memory capacity available case is shown in figure 23.4/6.

23.4.4 Procedure in the HLR

The process starts when the HLR receives a dialogue opening request using the application context mwdMngtContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1;

Alert_Service_Centre_HLR see subclause 25.10.3.

Sheet 1: If the dialogue opening request is from an SGSN, version 2 and version 1 of the application context are not applicable.

The short message alert process in the HLR is shown in figure 23.4/7.

23.4.5 Procedure in the SMS Interworking MSC

The process starts when the SMS-IWMSC receives a dialogue opening request using the application context shortMsgAlertContext. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

The short message alert process in the SMS-IWMSC is shown in figure 23.4/8.




Figure 23.4/4: Procedure SM_Alert_MSC




Figure 23.4/5 (sheet 1 of 2): Procedure SM_Alert_VLR




Figure 23.4/5 (sheet 2 of 2): Procedure SM_Alert_VLR




Figure 23.4/6 (sheet 1 of 2): Process SM_Alert_SGSN




Figure 23.4/6 (sheet 2 of 2): Process SM_Alert_SGSN




Figure 23.4/7 (sheet 1 of 2): Process SM_Alert_HLR




Figure 23.4/7 (sheet 2 of 2): Process SM_Alert_HLR





Figure 23.4/8: Process Alert_SC_IWMSC

23.5 The SM delivery status report procedure

The SM delivery status report procedure is used:

- to set the Service Centre address into the message waiting list in the HLR after short message delivery has failed because the subscriber is absent or unidentified or the memory capacity is exceeded. The procedure sets:
  - the Memory Capacity Exceeded Flag (MCEF) in the HLR if the MS memory does not have room for more messages;
  - and/or the MS Not Reachable Flag for non-GPRS if there is no record for the subscriber in the VLR or the subscriber does not respond to paging for delivery via the MSC;
  - and/or the MS Not Reachable for GPRS (MNRG) flag if there is no record for the subscriber in the SGSN or the subscriber does not respond to paging for delivery via the SGSN;
  - and/or the UE Not Reachable for IP (UNRI) flag if delivery via the IMS was not successful.
- to report to the HLRthat delivery has succeeded. The conditions for report of a successful delivery are described in subclause 23.3.1.

The message flow for the SM delivery status report procedure is shown in figure 23.5/1.



1) MAP_MT_FORWARD_SHORT_MESSAGE_ACK/_NACK (Absent subscriber_SM, unidentified subscriber or memory capacity exceeded).
2) MAP_REPORT_SM_DELIVERY_STATUS. (The HLR ignores the content of this message when an IP-SM-GW is deployed)
2a) MAP_REPORT_SM_DELIVERY_STATUS (sent only by IP-SM-GW)
2b) MAP-REPORT_SM_DELIVERY_STATUS_ACK.
3) MAP_REPORT_SM_DELIVERY_STATUS_ACK.
4) Short Message Negative Acknowledgement (3GPP TS 23.040).

Figure 23.5/1: Short message delivery status report procedure

23.5.1 Procedure in the SMS-GMSC

The conditions for the GMSC to invoke the short message delivery status report procedure are specified in subclause 23.3.1.

The short message delivery status report macro in the SMS-GMSC is shown in figure 23.5/2.

23.5.2 Procedure in the HLR

When the HLR receives a MAP_REPORT_SM_DELIVERY_STATUS indication while an IP-SM-GW is deployed in the network and the message is not received from an IP-SM-GW or SMS Router, it ignores the information received in the message; otherwise it acts as described in subclause 23.6, macro Report_SM_Delivery_Stat_HLR.

The short message delivery status report process in the HLR is shown in figure 23.5/3.

23.5.3 Procedure in the IP-SM-GW

The conditions for the IP-SM-GW and for SMS Router, if deployed with IP-SM-GW, to invoke the short message delivery status report procedure are specified in subclause 23.3.7.

The short message delivery status report macro in the IP-SM-GW is shown in figure 23.5/4.




Figure 23.5/2: Macro Report_SM_Delivery_Stat_GMSC




Figure 23.5/3: Process SM_Delivery_Status_Report_HLR




Figure 23.5/4: Macro Report_SM_Delivery_Stat_IPSMGW

23.6 The macro Report_SM_Delivery_Stat_HLR

This macro is invoked when the HLR receives a MAP_REPORT_SM_DELIVERY_STATUS indication from the SMS-GMSC. The macro invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Check_Indication	see subclause 25.2.1;
Alert_Service_Centre_HLR	see subclause 25.10.3.

Sheet 1: If the MAP_REPORT_SM_DELIVERY_STATUS indication did not include the GPRS support indicator, the HLR deduces the domain for which the delivery report applies as follows:

- if the subscriber is a GPRS-only subscriber, the report applies for GPRS;
- if the subscriber is a non-GPRS-only subscriber, the report applies for non-GPRS;
- if the subscriber is a GPRS and non-GPRS subscriber and the subscription option for MT SMS delivery when the SMS-GMSC does not support GPRS is set to "Delivery via the SGSN", the report applies for GPRS;
- if the subscriber is a GPRS and non-GPRS subscriber and the subscription option for MT SMS delivery when the SMS-GMSC does not support GPRS is set to "Delivery via the MSC", the report applies for non-GPRS;

The short message delivery status report macro in the HLR is shown in figure 23.6/1.




Figure 23.6/1 (sheet 1 of 2): Macro Report_SM_Delivery_Stat_HLR




Figure 23.6/1 (sheet 2 of 2): Macro Report_SM_Delivery_Stat_HLR

23.7 The mobile terminated short message transfer procedure for VGCS

The mobile terminated short message transfer for VGCS procedure is used for forwarding a short message from a Service Centre to the group call anchor MSC. The message flow for the mobile terminated short message transfer procedure for VGCS is shown in figure 23.7/1.




Figure 23.7/1: Mobile terminated short message for VGCS service procedures

1) Short Message (3GPP TS 23.040).
2) TCAP BEGIN (*)
3) TCAP CONTINUE (*)
4) MAP_MT_FORWARD_SM_FOR_VGCS.
5) GCR_SMS_INTERROGATION (3GPP TS 43.068).
6) GCR_SMS_INTERROGATION_ACK (3GPP TS 43.068).
7) MAP_MT_FORWARD_SM_FOR_VGCS_ACK.
8) Short Message Acknowledgement (3GPP TS 23.040).

(*) If
a)
- the capacity of a message signal unit in the lower layers of the protocol is enough to carry the content of the MAP_OPEN request and the content of the MAP_MT_FORWARD_SM_FOR_VGCS request in a single TC message,

and
b) the SMS Gateway MSC operator and the serving node (Anchor-MSC) operator agreed not to use the TCAP handshake countermeasure against SMS fraud for messages exchanged between their networks (see 3GPP TS 33.204 [34a])
then
the TCAP handshake may be omitted.

23.7.1 Procedure in the SMS-GMSC

The process starts when the SMS-GMSC receives an SC_RP_MT_DATA indication from a Service Centre. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf	see subclause 25.1.2;
Check_Confirmation	see subclause 25.2.2.

The mobile terminated short message transfer for VGCS process in the SMS-GMSC is shown in figure 23.7/2.

23.7.2 Procedure in the Anchor MSC

The process starts when the MSC receives a dialogue opening request with the application context shortMsgMT-Relay-VGCS-Context. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind	see subclause 25.1.1;

The mobile terminated short message transfer for VGCS process in the Anchor MSC is shown in figure 23.7/3

Procedure MT_SM_VGCS_GMSC sheet 1: The decision box "TCAP Handshake required" takes the "yes" or "no" exit depending on agreements between the Serving MSC's operator and the SMS Gateway MSC's operator (see 3GPP TS 33.204 [34a]).




Figure 23.7/2 (sheet 1 of 2): Process MT_SM_VGCS_GMSC




Figure 23.7/2 (sheet 2 of 2): Process MT_SM_VGCS_GMSC




Figure 23.7/3 (sheet 1 of 2): Process MT_SM_VGCS_Anchor MSC




Figure 23.7/3 (sheet 2 of 2): Process MT_SM_VGCS_Anchor MSC

24 GPRS process description

The MAP GPRS procedures are used for the Network Requested PDP-Context Activation procedures.

The stage 2 specification for General Packet Radio Service (GPRS) is in 3GPP TS 23.060 [104].

24.1 Procedure for retrieval of routeing information for GPRS

24.1.1 Process in the GGSN

The MAP process in the GGSN to request routeing information for a network requested PDP context activation is shown in figure 24.1/2. The MAP process invokes macros not defined in this clause; the definition of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24.1.2 Process in the HLR

The MAP process in the HLR to provide routing information for a network-requested PDP context activation is shown in figure 24.1/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.




Figure 24.1/1: Process SRI_GPRS_GGSN




Figure 24.1/2: Process SRI_GPRS_HLR

24.2 Procedure for reporting failure to establish a network requested PDP context

24.2.1 Process in the GGSN

The MAP process in the GGSN to report the failure to establish a network requested PDP context is shown in figure 24.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24.2.2 Process in the HLR

The MAP process in the HLR to handle a notification from the GGSN that a network requested PDP context could not be established is shown in figure 24.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check Indication see subclause 25.2.1.




Figure 24.2/1: Process Failure_Report_GGSN




Figure 24.2/2: Process Failure_Report_HLR

24.3 Procedure for reporting that an MS has become reachable for GPRS

24.3.1 Process in the HLR

The MAP process in the HLR to report that an MS is reachable for GPRS is shown in figure 24.3/1. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24.3.2 Process in the GGSN for Note Ms Present For Gprs

The MAP process in the GGSN to handle a notification that the subscriber is present for GPRS again is shown in figure 24.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.




Figure 24.3/1: Process Note_MS_Present_For_GPRS_HLR




Figure 24.3/2: Process Note_MS_Present_For_GPRS_GGSN

24A CSE interrogation and control of subscriber data

24A.1 General

The MAP procedures for interrogation and control of subscriber data are used to allow the CSE:

- to retrieve subscriber data from the HLR;
- to modify subscriber data in the HLR;
- to receive notification from the HLR when there is a change in subscriber data;
- to request information about the location of a subscriber from the HLR or the GMLC;
- to request information about the state of a subscriber from the HLR.

The following application context refers to a complex MAP user consisting of several processes:

- anyTimeInfoHandlingContext

This application context needs a co-ordinating process in the HLR.

The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

The Any Time Info Handling Co-ordinator process in the HLR is shown in figure 24A.1/1.




Figure 24A.1/1: Process Co_ATIH_HLR

24A.2 Any Time Subscription Interrogation procedure

24A.2.1 General

The message flow for successful retrieval of subscription information related to an any time subscription interrogation from the CAMEL server are shown in figure 24A.1/1. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this procedure (see 3GPP TS 23.278 [125]).




Figure 24A.2/1: Message flow for any time subscription interrogation

The following MAP service is used to retrieve requested information:

MAP_ANY_TIME_SUBSCRIPTION_INTERROGATION see subclause 8.11.3.

24A.2.2 Process in the gsmSCF

The MAP process in the gsmSCF to obtain subscription information in response to a request from the application process in the gsmSCF is shown in figure 24A.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2

24A.2.3 Process in the HLR

The MAP process in the HLR to provide subscription information in response to an interrogation from the CAMEL server is shown in figure 24A.2/3. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Check_Indication see subclause 25.2.2

If the MAP_ANY_TIME_SUBSCRIPTION_INTERROGATION service response cannot be carried in a single TC-Result component, it is carried in one or more TC-Result-NL components (each sent in a TC-CONTINUE), followed by a TC-Result-L component in a TC-END message.




Figure 24A.2/2: Process ATSI_gsmSCF




Figure 24A.2/3: Process ATSI_HLR

24A.3 Any Time Modification procedure

24A.3.1 General

The message flow for successful modification of subscription information related to an any time modification request from the CAMEL server is shown in figure 24A.3/1




Figure 24A.3/1: Message flow for any time modification

The following MAP service is used to modify subscription information:

MAP_ANY_TIME_MODIFICATION see subclause 8.11.4.

24A.3.2 Process in the gsmSCF

The MAP process in the gsmSCF to modify subscription information in response to a request from the application process in the gsmSCF is shown in figure 24A.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2

24A.3.3 Process in the HLR

The MAP process in the HLR to modify subscriber information in response to a modification request from the CAMEL server is shown in figure 24A.3/3. The MAP process invokes a macro and a process not defined in this clause; the definitions of these can be found as follows:

Check_Indication see subclause 25.2.2;

Insert_Subs_Data_Stand_Alone_HLR see subclause 25.7.3;

If the macro takes the OK exit, the MAP process waits for a service indication.

If the MAP_ANY_TIME_MODIFICATION service response cannot be carried in a single TC-Result component, it is carried in one or more TC-Result-NL components (each sent in a TC-CONTINUE), followed by a TC-Result-L component in a TC-END message.

If the serving node (VLR or SGSN) is to be updated after the modification, the MAP process creates an instance of the appropriate process (Insert_Subs_Data_Stand_Alone_HLR for VLR update, Insert_GPRS_Subs_Data_Stand_Alone_HLR for SGSN update).




Figure 24A.3/2: Process ATM_gsmSCF




Figure 24A.3/3: Process ATM_HLR

24A.4 Subscriber Data Modification Notification procedure

24A.4.1 General

The Subscriber Data Modification Notification procedure is used to notify a gsmSCF about the modification of subscriber data. In an IP Multimedia Core Network, an IM-SSF can take on the role of a gsmSCF for this procedure.

The stage 2 specification for Subscriber Data Modification Notification is in 3GPP TS 23.078 [98] and 3GPP TS 23.278 [125]. The interworking between the MAP signalling procedures and the Subscriber Data Modification Notification procedures for each entity (HLR, gsmSCF) is shown by the transfer of signals between these processes.

The following services are used:




Figure 24A.4/1: Message flow for subscriber data modification notification

The following MAP service is used to send the notification to the gsmSCF:

MAP_NOTE_SUBSCRIBER_DATA_MODIFIED see subclause 8.11.5.

24A.4.2 Process in the HLR

The MAP process in the HLR to send modified data to the gsmSCF is shown in figure 24A.4/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

If the required information cannot be carried in a single MAP_NOTE_SUBSCRIBER_DATA_MODIFIED service request, the HLR segments the information into two or more requests. The "All Information Sent" parameter is omitted from each request except the last.

Sheet 2: If the MAP_NOTE_SUBSCRIBER_DATA_MODIFIED service request contained the "All Information Sent" parameter, the test "All information sent" takes the "Yes" exit.

24A.4.3 Process in the gsmSCF

The MAP process in the gsmSCF to handle a notification to the gsmSCF of change of subscriber data is shown in figure 24A.4/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1

If the MAP_NOTE_SUBSCRIBER_DATA_MODIFIED service indication contained the "All Information Sent" parameter, the test "All information sent" takes the "Yes" exit.

If the test "All information sent" takes the "No" exit, the MAP process stores the data received in the MAP_NOTE_SUBSCRIBER_DATA_MODIFIED service indication. If the test "All information sent" takes the "Yes" exit, the MAP process assembles the data received in all the MAP_NOTE_SUBSCRIBER_DATA_MODIFIED service indications received in the dialogue and sends the assembled data to the application process in the gsmSCF.




Figure 24A.4/2 (sheet 1 of 2): Process NSDC_HLR




Figure 24A.4/2 (sheet 2 of 2): Process NSDC_HLR





Figure 24A.4/3: Process NSDC_gsmSCF

24A.5 Any Time Interrogation procedure

24A.5.1 General

The message flows for successful retrieval of subscriber information related to an any time interrogation from the CAMEL server are shown in figure 24A.5/1 for interrogation directed to an HLR and figure 24A.5/2 for interrogation directed to a GMLC.



1) MAP_ANY_TIME_INTERROGATION_req/ind
2) MAP_PROVIDE_SUBSCRIBER_INFO_req/ind
3) MAP_PROVIDE_SUBSCRIBER_INFO_rsp/cnf
4) MAP_ANY_TIME_INTERROGATION_rsp/cnf


Figure 24A.5/1: Message flow for any time interrogation (gsmSCF to HLR)

The following MAP services are used to retrieve information about the status and/or location of a subscriber:

MAP_ANY_TIME_INTERROGATION see subclause 8.11.1;

MAP_PROVIDE_SUBSCRIBER_INFO see subclause 8.11.2.

The HLR sends the MAP_PROVIDE_SUBSCRIBER_INFO request to the SGSN or the VLR, according to the domain for which the gsmSCF requested the information.



1) MAP_ANY_TIME_INTERROGATION_req/ind
2) MAP_ANY_TIME_INTERROGATION_rsp/cnf

Figure 24A.5/2: Message flow for any time interrogation (gsmSCF to GMLC)

The following MAP service is used to retrieve location information from a GMLC:

MAP_ANY_TIME_INTERROGATION see subclause 8.11.1;

In addition, the GMLC may use MAP Services specific to Location Services.

24A.5.2 Procedures in the gsmSCF

The process in the gsmSCF to request information about the location and/or state of a subscriber from the HLR is shown in figure 24A.5/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

The process in the gsmSCF to request location information from the GMLC is shown in figure 24A.5/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24A.5.3 Procedure in the HLR

The MAP process in the HLR to provide subscriber information in response to an interrogation from the CAMEL server is shown in figure 24A.5/5. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24A.5.4 Procedure in the GMLC

The MAP process in the GMLC to provide location information in response to a request from the gsmSCF is shown in figure 24A.5/6. The MAP process invokes a macro not defined in this clause; the definition of this macro can be found as follows:

Receive_Open_Ind see subclause 25.1.1.




Figure 24A.5/3: Process ATI_To_HLR_gsmSCF




Figure 24A.5/4: Process ATI_To_GMLC_gsmSCF




Figure 24A.5/5 (sheet 1 of 2): Process ATI_HLR




Figure 24A.5/5 (sheet 2 of 2): Process ATI_HLR




Figure 24A.5/6: Process ATI_GMLC

24B Location Services process description

24B.1 Routeing information retrieval procedure for LCS

24B.1.1 General

The message flow for successful retrieval of routeing information related to location services is shown in figure 24B.1/1.




Figure 24B.1/1: Message flow for retrieval of routeing information for LCS

The following MAP service is used to retrieve routeing information:

MAP_SEND_ROUTING_INFO_FOR_LCS see subclause 13A.1.

24B.1.2 Process in the GMLC

The MAP process in the GMLC to request routeing information for LCS is shown in figure 24B.1/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24B.1.3 Process in the HLR

The MAP process in the HLR to handle a request for routeing information for LCS is shown in figure 24B.1/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.




Figure 24B.1/2: Process SRI_LCS_GMLC




Figure 24B.1/3: Process SRI_LCS_HLR

24B.2 Provide Subscriber Location procedure

24B.2.1 General

The message flow for successful retrieval of the location information of a target MS related to location services is shown in figure 24B.1/1.




Figure 24B.2/1: Message flow for retrieval of location information

The following MAP service is used to retrieve location information:

MAP_PROVIDE_SUBSCRIBER_LOCATION see subclause 13A.2.

24B.2.2 Process in the GMLC

The MAP process in the GMLC to request location information from an MSC or an SGSN is shown in figure 24B.2/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24B.2.3 Process in the MSC

The MAP process in the MSC to handle a request for location information from a GMLC is shown in figure 24B.2/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.

24B.2.4 Process in the SGSN

The MAP process in the SGSN to handle a request for location information from a GMLC is shown in figure 24B.2/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.




Figure 24B.2/2: Process PSL_GMLC




Figure 24B.2/3: Process PSL_MSC




Figure 24B.2/4: Process PSL_SGSN

24B.3 Subscriber Location Report procedure

24B.3.1 General

The message flow for successful report of the location information of a target MS related to location services is shown in figure 24B.3/1.




Figure 24B.3/1: Message flow for report of the location information

The following MAP services are used to report location information:

MAP_SUBSCRIBER_LOCATION_REPORT see subclause 13A.3.

24B.3.2 Process in the MSC

The MAP process in the MSC to send a subscriber location report to the GMLC is shown in figure 24B.3/2. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24B.3.3 Process in the SGSN

The MAP process in the SGSN to send a subscriber location report to the GMLC is shown in figure 24B.3/3. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Cnf see subclause 25.1.2;

Check_Confirmation see subclause 25.2.2.

24B.3.4 Process in the GMLC

The MAP process in the GMLC to handle a subscriber location report is shown in figure 24B.3/4. The MAP process invokes macros not defined in this clause; the definitions of these macros can be found as follows:

Receive_Open_Ind see subclause 25.1.1;

Check_Indication see subclause 25.2.1.




Figure 24B.3/2: Process SLR_MSC




Figure 24B.3/3: Process SLR_SGSN




Figure 24B.3/4: Process SLR_GMLC

25 General macro description

25.1 MAP_OPEN handling macros

25.1.1 Macro Receive_Open_Ind

This macro is used by a MAP service-user procedure when a peer entity requests opening of a dialogue.

25.1.2 Macro Receive_Open_Cnf

This macro is used by a user procedure after it has requested opening of a dialogue towards a peer entity.




Figure 25.1/1 (sheet 1 of 2): Macro Receive_Open_Ind




Figure 25.1/1 (sheet 2 of 2): Macro Receive_Open_Ind




Figure 25.1/2: Macro Receive_Open_Cnf




Figure 25.1/3: Macro Check_Reference

25.2 Macros to check the content of indication and confirmation primitives

25.2.1 Macro Check_Indication

This macro checks that an indication includes all the parameters required by the application, no more and no less, and that the parameters are all within the correct range. It does not handle syntax checking; that is part of the function of the MAP protocol machine.

25.2.2 Macro Check_Confirmation

This macro checks whether a confirmation contains an error or a result, and if it contains a result whether the result is correctly formed.




Figure 25.2/1: Macro Check_Indication




Figure 25.2/2: Macro Check_Confirmation

25.3 The page and search macros

25.3.1 Macro PAGE_MSC

This macro is called if an unstructured SS notification, a network-initiated unstructured SS request or a mobile terminating short message is to be delivered to the MS and the current location area identity of the MS is known in the VLR.

If an MM-connection over the radio link already exists for the given IMSI, the MSC sets the access connection status according to the characteristics of the existing connection (i.e. RR-connection established, ciphering mode on/off, MM-connection existing and authenticated or not).

If the MSC pages the MS and the VLR provided the TMSI, the MSC uses it to identify the MS at the radio interface; otherwise the MSC uses the IMSI. The MSC also uses the IMSI to determine the page group (see 3GPP TS 24.008 [35]).

If the MS responds with a channel request containing an establishment cause which is not "answer to paging" the MSC sends a MAP_PAGE response primitive with user error Busy Subscriber. This gives priority to the mobile originating request. Alternatively, as an implementation option, the MSC may treat this as a response to paging, which gives priority to the mobile terminating request.

If the paging is for MT SMS delivery and the VLR aborts the transaction before the MSC receives a response from the MS, the MSC aborts the transaction with the SMS-GMSC.

25.3.2 Macro Search_For_MS_MSC

This macro is called if an unstructured SS notification, a network-initiated unstructured SS request or a mobile terminating short message is to be delivered to the MS and the current location area identity of the MS is not known in VLR.

If an MM-connection over the radio link already exists for the given IMSI, the MSC returns a MAP_SEARCH_FOR_MS response containing the IMSI and current location area identification of the called MS to the VLR and sets the access connection status according to the characteristics of the existing connection (i.e. RR-connection established, ciphering mode on/off, MM-connection existing and authenticated or not).

If the MSC pages the MS, the MSC uses the IMSI to identify the subscriber and the page group (see 3GPP TS 24.008 [35]).

If the MS responds with a channel request containing an establishment cause which is not "answer to paging" the MSC sends a MAP_SEARCH_FOR_MS response with user error Busy Subscriber. This gives priority to the mobile originating request. Alternatively, as an implementation option, the MSC may treat this as a response to paging, which gives priority to the mobile terminating request.

If the paging is for MT SMS delivery and the VLR aborts the transaction before the MSC receives a response from the MS, the MSC aborts the transaction with the SMS-GMSC.




Figure 25.3/1: Macro Page_MSC




Figure 25.3/2: Macro Search_for_MS_MSC

25.4 Macros for handling an Access Request

These macros are invoked when a MS accesses the network, e.g. to submit an MO short message or when responding to paging. The macros handle identification and authentication of the mobile subscriber as well as invocation of security related features (see 3GPP TS 42.009 [6]).

25.4.1 Macro Process_Access_Request_MSC

Sheet 1: The MAP_PROCESS_ACCESS_REQUEST request includes the following parameters:

- the received subscriber identification (IMSI, TMSI);
- the CM service type, indicating the type of request;
- the status of the access connection, i.e. whether a connection to this MS already exists and if so, whether it is already authenticated and ciphered;
- the current location area id of the MS; and
- the CKSN received from the MS.

Sheet 2, sheet 3: If the MSC receives an A_SETUP indication while it is waiting for further instructions from the VLR or for the acknowledgment of TMSI reallocation from the MS, the MSC saves the setup request for processing after control has returned from the macro Process_Access_Request_MSC to the calling process.

Sheet 3: When the MSC is waiting for a possible instruction to allocate a new TMSI, a MAP_DELIMITER indication indicates that TMSI reallocation is not required.

Sheet 3: If the MS sends a TMSI reallocation failure in response to the TMSI reallocation command, the MSC takes the OK exit; the VLR treats the lack of response as a provider error (see macro Process_Access_Request_VLR).

25.4.2 Macro Process_Access_Request_VLR

Sheet 3: If the MSC does not send a positive response to the MAP_FORWARD_NEW_TMSI request, this is treated as a MAP_FORWARD_NEW_TMSI confirmation containing a provider error. The Macro takes the Error exit. If TMSI reallocation does not succeed, the old TMSI is frozen, to prevent it from being reallocated. In this case, both old and new TMSIs are regarded as valid.

25.4.3 Macro Obtain_Identity_VLR

This macro is invoked by the macro Process_Access_Request_VLR if the subscriber's identity is not known in the VLR.

It is an operator option to allow or prevent retrieval of the IMSI without encryption.

25.4.4 Process Update_Location_Child_VLR

This process is started when the subscriber successfully accesses the network, e.g. for mobile originated short message submission, response to paging or supplementary services handling.

The procedure Notify_gsmSCF is specified in 3GPP TS 23.078.




Figure 25.4/1 (sheet 1 of 3): Macro Process_Access_Request_MSC




Figure 25.4/1 (sheet 2 of 3): Macro Process_Access_Request_MSC




Figure 25.4/1 (sheet 3 of 3): Macro Process_Access_Request_MSC




Figure 25.4/2 (sheet 1 of 3): Macro Process_Access_Request_VLR




Figure 25.4/2 (sheet 2 of 3): Macro Process_Access_Request_VLR




Figure 25.4/2 (sheet 3 of 3): Macro Process_Access_Request_VLR




Figure 25.4/3: Macro Obtain_Identity_VLR




Figure 25.4/4 (sheet 1 of 2): Process Update_Location_Child_VLR




Figure 25.4/4 (sheet 2 of 2): Process Update_Location_Child_VLR

25.5 Authentication macros and processes

The following macros are used in the network in order to enable authentication of a mobile subscriber.

25.5.1 Macro Authenticate_MSC

This macro is used by the MSC to relay a request for authentication transparently from the VLR to the MS, wait for a response from the MS and relay the response from the MS back to the VLR.

25.5.2 Macro Authenticate_VLR

This macro is used by the VLR to control the authentication of a subscriber.

Sheet 1: The test "Received SRES=Expected SRES" indicates:

- a comparison of the Signed RESult received from the MS with the Signed RESult received from the HLR, if GSM authentication is used (see 3GPP TS 43.020 [24]), or
- a comparison of the RESult received from the MS with the expected RESult received from the HLR, if UMTS authentication is used (see 3GPP TS 33.102).

25.5.3 Macro Obtain_Authent_Params_VLR

This macro is used by the VLR to request authentication vectors from the HLR.

Sheet 1, sheet 2, sheet 3: It is an operator option whether to allow the re-use of old authentication triplets.

Sheet 2, sheet 3: Old UMTS quintuplets shall not be re-used.

Sheet 2: if the VLR requests more authentication vectors in the same dialogue, the subsequent MAP_SEND_AUTHENTIFICATION_INFO request has no parameters.

25.5.4 Process Obtain_Authentication_Sets_VLR

This process is initiated by the VLR to fetch authentication vectors from a subscriber's HLR independently of any other processing.

25.5.6 Process Obtain_Authent_Sets_SGSN

The procedure for authentication when the serving node is an SGSN is described in 3GPP TS 23.060 [104] and 3GPP TS 24.008 [35].

This Process is used by the SGSN to request authentication vectors from the HLR.

Sheet 1, sheet 2: It is an operator option whether to allow the re-use of old authentication triplets.

Sheet 2: Old UMTS quintuplets shall not be re-used.

25.5.6 Process Obtain_Authent_Sets_HLR

This process is used to provide authentication vectors (triplets or quintuplets) in response to a request from a VLR or an SGSN.

Upon receipt of an authentication information request for a UMTS subscriber, the HLR shall return authentication quintuplets. If the user is a GSM subscriber, the HLR shall return authentication triplets.

25.5.7 Authentication Failure Reporting

25.5.7.1 General

The Authentication Failure Report procedure is used to notify an HLR about the occurrence of an authentication failure in the SGSN or VLR.

The message flows for this procedure are shown in figures 25.5/7& 25.5/8.




Figure 25.5/7: Message Flow for Authentication Failure Report – VLR to HLR




Figure 25.5/8: Message Flow for Authentication Failure Report – SGSN to HLR

25.5.7.2 Process in the VLR

25.5.7.3 Process in the SGSN

25.5.7.4 Process in the HLR




Figure 25.5/1: Macro Authenticate_MSC




Figure 25.5/2 (sheet 1 of 2): Macro Authenticate_VLR




Figure 25.5/2 (sheet 2 of 2): Macro Authenticate_VLR




Figure 25.5/3 (sheet 1 of 3): Macro Obtain_Authent_Params_VLR




Figure 25.5/3 (sheet 2 of 3): Macro Obtain_Authent_Params_VLR




Figure 25.5/3 (sheet 3 of 3): Macro Obtain_Authent_Params_VLR




Figure 25.5/4: Process Obtain_Authent_Sets_VLR




Figure 25.5/5 (sheet 1 of 2): Process Obtain_Authent_Sets_SGSN




Figure 25.5/5 (sheet 2 of 2): Process Obtain_Authent_Sets_SGSN




Figure 25.5/6 (sheet 1 of 2): Process Obtain_Authent_Sets_HLR




Figure 25.5/6 (sheet 2 of 2): Process Obtain_Authent_Sets_HLR




Figure 25.5/7: Procedure Check_Available_Vectors




Figure 25.5/9: Process Report_Authentication_Failure_VLR




Figure 25.5/10: Process Report_Authentication_Failure_SGSN




Figure 25.5/11: Process Note_Authentication_Failure_HLR

25.6 IMEI Handling Macros

The following macros are used in the network in order to enable handling and checking of the mobile equipment identity.

25.6.1 Macro Check_IMEI_MSC

This macro is used by the MSC to receive a request from the VLR, relay it to the EIR, and pass the result from the EIR back to the VLR.

Sheet 1: If the dialogue with the EIR drops back to a previous protocol version and the EIR returned an error, the MSC relays the error to the VLR in the MAP_CHECK_IMEI response. If the dialogue with the EIR failed, or the EIR returned a badly formed result, the MSC sends a System Failure error to the VLR in the MAP_CHECK_IMEI response.

25.6.2 Macro Check_IMEI_VLR

This macro is used by the VLR to control the check of a mobile equipment's IMEI. It may also be used to request the BMUEF from the EIR.

25.6.3 Process Check_IMEI_SGSN

This process is used by the SGSN to control the check of a mobile equipment's IMEI. It may also be used to request the BMUEF from the EIR.

25.6.4 Process Check_IMEI_EIR

This process is used by the EIR to obtain the status of a mobile equipment, upon request from the MSC or from the SGSN. It may also be used to obtain the BMUEF.

25.6.5 Macro Obtain_IMEI_MSC

This macro is used by the MSC to respond to a request from the VLR to provide the IMEI.

25.6.6 Macro Obtain_IMEI_VLR

This macro is used by the VLR to obtain the IMEI from the MSC.




Figure 25.6/1 (sheet 1 of 2): Macro Check_IMEI_MSC




Figure 25.6/1 (sheet 2 of 2): Macro Check_IMEI_MSC




Figure 25.6/2: Macro Check_IMEI_VLR




Figure 25.6/3 (sheet 1 of 2): Process Check_IMEI_SGSN




Figure 25.6/3 (sheet 2 of 2): Process Check_IMEI_SGSN




Figure 25.6/4: Process Check_IMEI_EIR




Figure 25.6/5: Macro Obtain_IMEI_MSC




Figure 25.6/6: Macro Obtain_IMEI_VLR

25.7 Insert Subscriber Data macros and processes

25.7.1 Macro Insert_Subs_Data_VLR

This macro is used by any procedure in the VLR that triggers the reception of subscriber data (e.g. Update Location or Restore Data).

25.7.2 Macro Insert_Subs_Data_SGSN

This macro is used by any procedure that triggers the reception of subscriber data (e.g. Update GPRS Location).

25.7.3 Process Insert_Subs_Data_Stand_Alone_HLR

This process is used by HLR to transfer subscriber data to the VLR in a stand alone mode, i.e. in a separate dialogue. This is done whenever a change of subscriber data is performed either by the operator or by the subscriber and this change has to be reported to the VLR.

Sheet 1: The HLR may wait for each MAP_INSERT_SUBSCRIBER_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

Sheet 1, sheet 2: If the VLR has indicated that it does not support a service or feature (e.g. Closed User Group or Advice Of Charge Charging Level) which the HLR operator regards as essential for the subscriber, the macro Wait_for_Insert_Subs_Data_Cnf takes the Replace_Service exit; the HLR sets the Roaming Restriction Due To Unsupported Feature flag to roaming restricted and sends Roaming Restriction Due To Unsupported Feature in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

Sheet 1, sheet 2: If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait_for_Insert_Subs_Data_Cnf takes the Replace_Service exit, the HLR sends the data for a replacement service in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

Sheet 2: It is an operator option whether to repeat the download of subscriber data if the VLR returns an error response. The number of repeat attempts and the interval between them is also an operator option, depending on the error response from the VLR.

If subscriber data for CAMEL Phase 2 or later services are sent to a VLR which does not support the appropriate phase of CAMEL, the service behaviour may be unpredictable or incorrect. The HLR should therefore ensure that at the conclusion of a stand alone Insert Subscriber data procedure the data in the VLR do not require a capability that the VLR does not have. Possible mechanisms to ensure this are described in 3GPP TS 23.078 [98].

The HLR should send a Forwarded-to number which is not in E.164 international format to the VLR only when the HLR has ascertained that the VLR supports CAMEL Phase 2 or later. Thus, the ISD message containing the Forwarded-to number which is not in E.164 international format shall be sent to the VLR only if the HLR previously received confirmation from the VLR at Location Update that CAMEL Phase 2 or later is supported.

25.7.4 Process Insert_GPRS_Subs_Data_Stand_Alone_HLR

This process is used by the HLR to transfer subscriber data from the HLR to the SGSN in a stand alone mode, i.e. in a separate dialogue. This is done whenever a change of subscriber data is performed either by the operator or by the subscriber and this change has to be reported to the SGSN.

Sheet 1: The HLR may wait for each MAP_INSERT_SUBSCRIBER_DATA request to be acknowledged before it sends the next request, or it may handle the requests and the confirmations in parallel.

Sheet 1, sheet 2: If the SGSN has indicated that it does not support a service or feature which the HLR operator regards as essential for the subscriber, the macro Wait_for_Insert_GPRS_Subs_Data_Cnf takes the Replace_Service exit; the HLR sets the Roaming Restricted In SGSN Due To Unsupported Feature flag to roaming restricted and sends Roaming Restricted In SGSN Due To Unsupported Feature in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

Sheet 1, sheet 2: If the HLR operator does not regard the unsupported service or feature as essential for the subscriber but the macro Wait_for_Insert_GPRS_Subs_Data_Cnf takes the Replace_Service exit, the HLR sends the data for a replacement service in a subsequent MAP_INSERT_SUBSCRIBER_DATA request.

Sheet 2: It is an operator option whether to repeat the download of subscriber data if the SGSN returns an error response. The number of repeat attempts and the interval between them is also an operator option, depending on the error response from the SGSN.

25.7.5 Macro Wait_for_Insert_Subs_Data_Cnf

This macro is used by any process or macro that describes the handling in the HLR of the transfer of subscriber data to the VLR (e.g. Update Location or Restore Data).

25.7.6 Macro Wait_for_Insert_GPRS_Subs_Data_Cnf

This macro is used by any process or macro that describes the handling in the HLR of the transfer of subscriber data to the SGSN (e.g. Update GPRS Location).

25.7.7 Process Send_Insert_Subs_Data_HLR

This process is used by any process or macro in the HLR where a MAP_INSERT_SUBSCRIBER_DATA request is sent to the VLR or to the SGSN.




Figure 25.7/1: Macro Insert_Subs_Data_VLR




Figure 25.7/2: Macro Insert_Subs_Data_SGSN




Figure 25.7/3 (sheet 1 of 2): Process Insert_Subs_Data_Stand_Alone_HLR




Figure 25.7/3 (sheet 2 of 2): Process Insert_Subs_Data_Stand_Alone_HLR




Figure 25.7/4 (sheet 1 of 2): Process Insert_GPRS_Subs_Data_Stand_Alone_HLR




Figure 25.7/4 (sheet 2 of 2): Process Insert_GPRS_Subs_Data_Stand_Alone_HLR




Figure 25.7/5: Macro Wait_for_Insert_Subs_Data_Cnf




Figure 25.7/6: Macro Wait_for_Insert_GPRS_Subs_Data_Cnf




Figure 25.7/7: Process Send_Insert_Subs_Data_HLR

25.8 Request IMSI Macros

25.8.1 Macro Obtain_IMSI_MSC

This macro describes the handling of the request received from the VLR to provide the IMSI of a subscriber (e.g. at Location Updating).

25.8.2 Macro Obtain_IMSI_VLR

This macro describes the way VLR requests the MSC the IMSI of a subscriber (e.g. at Location Updating).




Figure 25.8/1: Macro Obtain_IMSI_MSC




Figure 25.8/2: Macro Obtain_IMSI_VLR

25.9 Tracing macros

25.9.1 Macro Trace_Subscriber_Activity_MSC

This macro shows the handling in the MSC for a request from the VLR to trace the activity of a subscriber.

25.9.2 Macro Trace_Subscriber_Activity_VLR

This macro is called during the handling of subscriber activity in the VLR to activate tracing if necessary.

25.9.3 Macro Trace_Subscriber_Activity_SGSN

This macro is called during the handling of subscriber activity in the SGSN to activate tracing if necessary.

25.9.4 Macro Activate_Tracing_VLR

This macro shows the handling in the VLR for a request from the HLR to activate tracing for a subscriber.

25.9.5 Macro Activate_Tracing_SGSN

This macro shows the handling in the SGSN for a request from the HLR to activate tracing for a subscriber.

25.9.6 Macro Control_Tracing_With_VLR_HLR

This macro shows the handling in the HLR to activate tracing in the VLR if it is required during a dialogue between the VLR and the HLR

25.9.7 Macro Control_Tracing_With_SGSN_HLR

This macro shows the handling in the HLR to activate tracing in the SGSN if it is required during a dialogue between the SGSN and the HLR




Figure 25.9/1: Macro Trace_Subscriber_Activity_MSC




Figure 25.9/2: Macro Trace_Subscriber_Activity_VLR




Figure 25.9/3: Macro Trace_Subscriber_Activity_SGSN




Figure 25.9/4: Macro Activate_Tracing_VLR




Figure 25.9/5: Macro Activate_Tracing_SGSN




Figure 25.9/6: Macro Control_Tracing_With_VLR_HLR




Figure 25.9/7: Macro Control_Tracing_With_SGSN_HLR

25.10 Short Message Alert procedures

25.10.1 Process Subscriber_Present_VLR

The VLR invokes the process Subscriber_Present_VLR when the mobile subscriber becomes active. The general description of the short message alert procedures is in subclause 23.4 of the present document.

25.10.2 Process SubscriberPresent_SGSN

The SGSN invokes the process Subscriber_Present_SGSN when it receives a Page response, a GPRS Attach request or a Routing area update request message (3GPP TS 24.008 [35]). The general description of the short message alert procedures is in subclause 23.4 of the present document.

25.10.3 Macro Alert_Service_Centre_HLR

The HLR invokes the macro Alert_Service_Centre_HLR when Service Centre(s) are to be alerted.

25.10.4 Process Alert_SC_HLR

It is an operator option to resend the MAP_ALERT_SERVICE_CENTRE request to the SMS-IWMSC if the alert is unsuccessful. The number of repeat attempts and the interval between them is also an operator option. The service centre address should be purged from the MWD list if the alert is consistently unsuccessful.




Figure 25.10/1: Process Subscriber_Present_VLR




Figure 25.10/2: Process Subscriber_Present_SGSN




Figure 25.10/3: Macro Alert_Service_Centre_HLR




Figure 25.10/4: Process Alert_SC_HLR

Annex A (informative): ASN.1 Cross-reference listing and fully expanded sources

The ASN.1 Cross-reference listing and the fully expanded ASN.1 sources of the MAP protocol are provided for information at http://www.3gpp.org/ftp/Specs/archive/29_series/29.002/ASN.1/

Annex B (informative): Void

Annex C (informative): Message Segmentation Mechanisms

Various segmentation mechanisms are in use to overcome the problem where a MAP parameter carried in an Invoke, Result (or Error) component is too long to fit into a single SCCP UDT message. These mechanisms are:

C.1 SCCP segmentation

Instead of one UDT message several XUDT messages are used according to

> Signalling Connection Control Part, Signalling System no. 7 ITU-T recommendation (07/96) Q.711 to Q.716 ("White Book SCCP").

This mechanism may be used for all MAP messages. If no segmentation mechanism at the TCAP or MAP level is available, this is the only remaining possibility.

This mechanism has no impact on the MAP provider level and above; the MAP provider sees the parameter as being sent in a single segment.

It should be noted that not all SCCP transit nodes (world wide) currently support the transfer of XUDT messages. Therefore XUDT messages may be lost without notice, depending on the route the message takes. The routes which successive messages take between two end points can differ because of load balancing. It is therefore recommended that this mechanism is used only for:

a) messages which do not cross PLMN boundaries (when the PLMN operator ensures that all SCCP transit nodes within his PLMN support White Book SCCP)

b) messages with low priority i.e. loss of the message does not result in serious misoperation.

It should be noted that the decision whether or not a message crosses PLMN boundaries needs to be taken at the MAP application level; it is therefore based on the message's operation code rather than on the SCCP called party address, i.e. only messages which never cross PLMN boundaries due to the type of message (SendIdentification, SendRoutingInfo without OR, AnyTimeInterrogation, ...) can be regarded as not crossing PLMN boundaries.

C.2 TCAP segmentation

At the TCAP level the following segmentation mechanisms are available:

C.2.1 Empty Begin

In a dialogue with AC version >1 the first forward message (Begin) must contain a Dialogue Portion. Instead of sending the Dialogue Portion and the Component Portion in the first forward message, an empty Begin (i.e. without a Component Portion) is sent, followed (after successful dialogue establishment) by a Continue message which can carry a longer Component Portion since no Dialogue Portion is present in the second forward message.

C.2.2 Empty Continue

In a dialogue with AC version >1 the first backward message (Continue / End) must contain a Dialogue Portion. Instead of sending the Dialogue Portion and the Component Portion in the first backward message, an empty Continue (i.e. without a Component Portion) is sent, followed by a Continue/End message which can carry a longer Component Portion since no Dialogue Portion is present in the second backward message.

C.2.3 TC-Result-NL

A Result component may be segmented into one or several Result-Not-Last components followed by a Result-Last component. As specified in subclause 15.6.3, the MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the result of the associated operation.

Note that this segmentation mechanism runs the risk that the message carrying the Result-Last component arrives before the message carrying a Result-Not-Last component which results in failure. The use of SCCP class 1 "Sequence guaranteed", which raises the chance of in sequence delivery, is recommended.

C.3 MAP Segmentation

At the MAP level the following segmentation mechanisms are available:

C.3.1 Invoke without explicit indication

An Invoke component may be segmented into several Invoke components. These may be sent in burst mode (in which case SCCP class 1 is recommended) or in acknowledged mode. The receiving node does not get an indication of whether or not more segments will be received, so it must not close the dialogue. The MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the invoke of the associated operation.

C.3.2 Invoke with explicit indication

An Invoke component may be segmented into several Invoke components sent in acknowledged mode. Each component contains at the MAP level an indication of whether or not subsequent components will follow. The receiving node terminates the dialogue when the last component is received. The MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the invoke of the associated operation.

C.3.3 Result

A Result (last) component may be segmented into several Result (last) components sent in acknowledged mode where a new (empty) Invoke component serves as an acknowledgment. The last segment is not acknowledged. The MAP user parameter shall be split so that each segment is compatible with the type defined for the parameter of the result of the associated operation.

The following tables show the applicability of the mechanisms described above:

AC Version 4:

Parameter	SCCP-segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
ResumeCallHandlingArg	allowed	not allowed	n.a.	n.a.	not allowed	recommended	n.a.

AC Version 3:

Parameter	SCCP-segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
InsertSubscriberDataArg	risky	not allowed	n.a.	n.a.	recommended	n.a.	n.a.
SendIdentificationRes	allowed	n.a.	not allowed	not allowed	n.a.	n.a.	recommended
PrepareHO-Arg	allowed	not allowed	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareHO-Res	allowed	n.a.	recommended	not recommended	n.a.	n.a.	not allowed
ProcessAccessSignalling-Arg	allowed	n.a.	n.a.	n.a.	not allowed	n.a.	n.a.
ForwardAccessSignalling-Arg	allowed	n.a.	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareSubsequentHO-Arg	allowed	n.a.	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareSubsequentHO-Res	allowed	n.a.	n.a	not recommended	n.a.	n.a.	not allowed
SendAuthenticationInfoRes	risky	n.a.	not allowed	not allowed	n.a.	n.a.	recommended
ProvideSubscriberInfoRes	allowed	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
AnyTimeInterrogationRes	allowed	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
AnyTimeModificationRes	allowed	n.a.	not allowed	recommended	n.a.	n.a.	not allowed
AnyTimeSubscriptionInterrogationRes	allowed	n.a.	not allowed	recommended	n.a.	n.a.	not allowed
noteSubscriberDataModifiedArg	allowed	not allowed	n.a.	n.a.	not allowed	recommended	n.a.
SendRoutingInfoRes	allowed	n.a.	not allowed	recommended	n.a.	n.a.	not allowed
MO-ForwardSM-Arg	risky	recommended	n.a.	n.a.	not allowed	n.a.	n.a.
MT-ForwardSM-Arg	risky	recommended	n.a.	n.a.	not allowed	n.a.	n.a.

AC Version 2:

Parameter	SCCP-segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
InsertSubscriberDataArg	risky	not allowed	not allowed	n.a.	recommended	n.a.	n.a.
SendIdentificationRes	allowed	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
SendAuthenticationInfoRes	risky	n.a.	not allowed	not recommended	n.a.	n.a.	not allowed
ForwardSM-Arg	risky	recommended	n.a.	n.a.	not allowed	n.a.	n.a.
PrepareHO-Res	allowed	n.a.	recommended	not recommended	n.a.	n.a.	not allowed

AC Version 1:

Parameter	SCCP-segmentation	Empty Begin	Empty Continue	TC-Result-NL	Invoke without indication	Invoke with indication	Result
InsertSubscriberDataArg	risky	n.a.	n.a.	n.a.	recommended	n.a.	n.a.
SentParameterList	risky	n.a.	n.a.	recommended	n.a.	n.a.	not allowed

In the tables above the keywords "recommended", "allowed", "risky", "not recommended", "not allowed" and "n.a." are used as follows:

"**recommended**"
indicates that the normative part of this specification explicitly specifies the use of this mechanism for the parameter in question;

"**allowed**"
indicates that the normative part of this specification allows the use of this mechanism for the sending node and mandates support of this mechanism for the receiving node;

"**risky**"
indicates that the mechanism is "allowed".However, the use of this mechanism for the parameter in question may result in serious misoperation because SCCP transit nodes are not guaranteed to support XUDT messages.

"**not recommended**"
indicates that the normative part of this specification does not explicitly specify the use of this mechanism for the parameter in question.

"**not allowed**"
indicates that the normative part of this specification implicitly prohibits the use of this mechanism for the parameter in question.

"**n.a.**"
indicates that the mechanism is not applicable for the parameter in question.

Annex D (informative): Void

Annex E (informative): Change History

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
04	N2-99227	29.002	3.0.0	A002	3	R98	A	Use of E interface	3.1.0	
04	N2-99578	29.002	3.0.0	A003		R98	B	Introduction of TIF-CSI for Call Deflection	3.1.0	
04	N2-99233	29.002	3.0.0	A004		R98	A	Clarification in ASN.1 encoding of O-CSI and T-CSI	3.1.0	
04	N2-99269	29.002	3.0.0	A005		R98	C	Introduction of MSISDN in USSD operation	3.1.0	
04	N2-99650	29.002	3.0.0	A006		R98	A	Modification of the O-CSI ASN.1 structure	3.1.0	
04	N2-99250	29.002	3.0.0	A007		R98	A	Adding of MAP_DELIMITER_req to the Status report operation	3.1.0	
04	N2-99628	29.002	3.0.0	A008		R98	A	Correction to the Purge MS "Detailed procedure in the HLR"	3.1.0	
04	N2-99677	29.002	3.0.0	A009		R98	A	Adding of MNP-indicator to the SRI ack	3.1.0	
04	N2-99228	29.002	3.0.0	A010		R98	F	New subscription options for call forwarding	3.1.0	
04	N2-99585	29.002	3.0.0	A011		R98	C	Adding the support of ANSI SCCP which is required in North America (World Zone 1)	3.1.0	
04	N2-99515	29.002	3.0.0	A012		R98	A	Introduction of 3-digit MNCs correction	3.1.0	
04	N2-99520	29.002	3.0.0	A013		R98	F	Export of NAEA-CIC	3.1.0	
04	N2-99548	29.002	3.0.0	A014		R98	D	Clarification to text to identify how the LSA data relevant in the current VPLMN can be determined	3.1.0	
04	3C99-468	29.002	3.0.0	A015		R97	F	Alignment with 04.80	3.1.0	
04	N2-99519	29.002	3.0.0	A016		R98	A	VBS data	3.1.0	
04	N2-99461	29.002	3.0.0	A017		R98	F	Introduction of Data Missing error to the Resume Call Handling	3.1.0	
04	N2-99583	29.002	3.0.0	A018		R97	F	Removal of 3-digit MNCs	3.1.0	
04	N2-99676	29.002	3.0.0	A019		R98	A	Corrections of mapping from MAP service to TC service	3.1.0	
04	3C99-206	29.002	3.0.0	A020		R98	B	Introduction of UUS service to Resume Call Handling	3.1.0	
05	N2-99906	29.002	3.1.0	021		R99	A	Clarification on VLR CAMEL Subscription Info	3.2.0	CAMEL Phase 2
05	N2-99908	29.002	3.1.0	022		R99	A	Clarification on DestinationNumberCriteria	3.2.0	CAMEL Phase 2
05	N2-99910	29.002	3.1.0	023		R99	A	Removal of TDP-Criteria from RCH	3.2.0	CAMEL Phase 2
05	N2-99934	29.002	3.1.0	025		R99	A	Various corrections related to GGSN-HLR Interface.	3.2.0	GPRS
05	N2-99936	29.002	3.1.0	034		R99	A	Update Location handling for GPRS-only subscription	3.2.0	GPRS
05	N2-99938	29.002	3.1.0	035		R99	A	Correction of OP & AC definitions for NoteMS-PresentForGPRS	3.2.0	GPRS
05	N2-99952	29.002	3.1.0	036		R99	A	Removal of redundant information from RCH	3.2.0	UUS
05	N2-99956	29.002	3.1.0	026		R99	A	OR capability IE in PRN	3.2.0	TEI
05	N2-99964	29.002	3.1.0	024	1	R99	A	GMSC-CAMEL phase 2 support IE in PRN	3.2.0	CAMEL Phase 2
05	N2-99A19	29.002	3.1.0	028		R99	A	Alignment of 29.002 with 02.67	3.2.0	eMLPP
05	N2-99A45	29.002	3.1.0	029	1	R99	B	Non-CAMEL IST implementation	3.2.0	IST
05	N2-99B57	29.002	3.1.0	027	2	R99	B	Addition of the information elements and the ASN.1 definitions for Pre-paging	3.2.0	Pre-Paging
05	N2-99C27	29.002	3.1.0	042		R99	A	Clarification on 'Supported CAMEL Phases' in ISD ack	3.2.0	CAMEL Phase 2
05	N2-99C78	29.002	3.1.0	044		R99	A	Editing error correction on VLR capabilities	3.2.0	SoLSA
05	N2-99D06	29.002	3.1.0	043	1	R99	A	Addition of exception handling to the CancellationType	3.2.0	GPRS
05	N2-99D33	29.002	3.1.0	046		R99	A	Clarification of LR-REJECT cause corresponding to RoamingRestrictionDueTo UnsupportedFeature	3.2.0	TEI

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
05	N2-99D35	29.002	3.1.0	047		R99		Clarification of returning the MSISDN in SRIack	3.2.0	MNP
06	N2-99G06	29.002	3.2.0	033	3	R99	C	Introduction of the Super-Charger Concept in TS 29.002	3.3.0	Super Charger
06	N2-99G18	29.002	3.2.0	032	2	R99	C	Introduction of White Book SCCP in MAP	3.3.0	TEI
06	N2-99G50	29.002	3.2.0	070		R99	A	Addition of GGSN number for the SRIforGPRS	3.3.0	GPRS
06	N2-99J88	29.002	3.2.0	075	1	R99	B	Introduction of Follow Me	3.3.0	Follow Me
06	N2-99K12	29.002	3.2.0	077		R99	A	Use of SSN for GPRS	3.3.0	GPRS
06	N2-99K24	29.002	3.2.0	069		R99	A	Correction of the USSD procedure in the HLR.	3.3.0	USSD & Follow Me
06	N2-99K52	29.002	3.2.0	060	1	R99	C	MAP Impacts for Location Services (LCS)	3.3.0	Location Services
06	N2-99K58	29.002	3.2.0	045	4	R99	B	Authentication Enhancements	3.3.0	Security
06	N2-99K60	29.002	3.2.0	050	5	R99	C	QoS-Subscribed field modification	3.3.0	QoS enhancements
06	N2-99L20	29.002	3.2.0	073	1	R99	C	Introduction of CAMEL Phase 3 in 3GPP TS 29.002	3.3.0	CAMEL Phase 3
06	N2-99J52	29.002	3.2.0	074		R99	D	Restructuring of MAP Location Management Procedures for the Circuit Switched Domain	3.3.0	TEI
06	N2-99J92	29.002	3.2.0	068		R99	B	Update of SDLs to support Super-Charger	3.3.0	Super-Charger
			3.3.0					New version created to fix a CR implementation error	3.3.1	
07	N2B000436	29.002	3.3.1	048	5	R99	B	Introduction of Multicall	3.4.0	Multicall
07	N2B000319	29.002	3.3.1	059	1	R99	B	Alternative solution for ALR	3.4.0	CAMEL phase 3
07	N2B000461	29.002	3.3.1	063	4	R99	B	MNP Database Mismatch	3.4.0	MNP
07	N2B000375	29.002	3.3.1	066	5	R99	B	Addition of the FTN-AddressString	3.4.0	Call Forwarding Enhancements
07	N2B000456	29.002	3.3.1	079	4	R99	C	Correction of SS Invocation Notification for CCBS	3.4.0	CAMEL Phase 3
07	N2A000023	29.002	3.3.1	080		R99	F	Corrections to ATSI, ATM, NCSD	3.4.0	CAMEL Phase 3
07	N2B000046	29.002	3.3.1	083		R99	A	Privacy notification/verification for call related privacy class	3.4.0	Location Services (LCS)
07	N2B000142	29.002	3.3.1	084	2	R99	B	Addition of CS Allocation/retention priority	3.4.0	QoS enhancements
07	N2B000144	29.022	3.3.1	086	1	R99	D	Editorial cleanup of 29.002	3.4.0	TEI
07	N2B000100	29.002	3.3.1	087		R99	A	Correction of LSA information	3.4.0	SoLSA
07	N2B000067	29.002	3.3.1	089		R99	F	Security interworking between release 99 and pre-99 MSC/VLRs	3.4.0	Security
07	N2B000113	29.002	3.3.1	090	1	R99	B	Improving GPRS charging efficiency	3.4.0	GPRS
07	N2B000120	29.002	3.3.1	094	2	R99	C	QoS-Subscribed field enhancements	3.4.0	QoS enhancements
07	N2B000322	29.002	3.3.1	095	1	R99	C	RANAP support on the E-interface	3.4.0	Handover
07	N2B000191	29.002	3.3.1	099		R99	B	UMTS Authentication	3.4.0	Security
07	N2B000466	29.002	3.3.1	100	5	R99	C	Support of 3G Handover, including Multicall	3.4.0	Multicall
07	N2B000372	29.002	3.3.1	101	1	R99	B	Introduction of Service Area Identification	3.4.0	TEI
07	N2B000380	29.002	3.3.1	102	2	R99	F	Clarification on Authentication Info Retrieval	3.4.0	Security
07	N2B000330	29.002	3.3.1	103	1	R99	B	Addition of UMTS security to MAP B interface	3.4.0	Security
07	N2B000244	29.002	3.3.1	104		R99	F	Re-Synchronisation Info	3.4.0	UMTS Security
07	N2B000324	29.002	3.3.1	105	1	R99	C	Introduction of additional service parameters for inter-system handover	3.4.0	Handover
07	N2B000281	29.002	3.3.1	107		R99	D	Removal of architectural information from clause 4	3.4.0	TEI

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
07	N2-000454	29.002	3.3.1	110	1	R99	B	Introduction of Authentication Failure Report	3.4.0	Security
07	N2B000357	29.002	3.3.1	111		R99	B	Use of MAP private extensions to implement region-specific requirements	3.4.0	TEI
07	N2B000470	29.002	3.3.1	112		R99	A	Prioritisation of MAP application context related to VGCS/VBS	3.4.0	ASCI Phase 2
07	N2B000472	29.002	3.3.1	113		R99	F	Correction of SS-Codes for LCS	3.4.0	LCS
08	N4-000098	29.002	3.4.0	115	1	R99	F	Minor corrections to CAMEL3 NSDC/ATM/ATSI information flows	3.5.0	CAMEL Phase 3
08	N4-000094	29.002	3.4.0	117	1	R99	A	Using DSD to delete CCBS-B from the subscriber	3.5.0	CCBS
08	N4-000089	29.002	3.4.0	118	1	R99	F	Indication in PRN of support of Long FTNs	3.5.0	CF enhancements
08	N4-000073	29.002	3.4.0	120	1	R99	F	QoS-Subscribed field enhancements	3.5.0	QoS enhancements
08	N4-000050	29.002	3.4.0	121		R99	F	Correction of introduction of additional service parameters for inter-system handover	3.5.0	Handover/Relocation
08	N4-000100	29.002	3.4.0	122	2	R99	C	Proposed information flow on NSDC	3.5.0	CAMEL Phase 3
08	N4-000321	29.002	3.4.0	124	3	R99	C	CAMEL Subscription Info	3.5.0	CAMEL Phase 3
08	N4-000068	29.002	3.4.0	125		R99	A	Clarification to GMLC List definition	3.5.0	LCS
08	N4-000320	29.002	3.4.0	127	1	R99	F	Optionality of parameters in d-csi and in sms-csi	3.5.0	CAMEL Phase 3
08	N4-000209	29.002	3.4.0	130		R99	F	Version 3 tags for handover messages	3.5.0	Handover
08	N4-000211	29.002	3.4.0	132		R99	A	Correction of version handling at dialogue establishment	3.5.0	TEI
08	N4-000357	29.002	3.4.0	133	1	R99	F	Various corrections and/or cleanup to 29.002	3.5.0	TEI
08	N4-000217	29.002	3.4.0	134		R99	A	Correction of errors in Figure 25.1/1: Macro Receive_Open_Ind	3.5.0	TEI
08	N4-000326	29.002	3.4.0	135	1	R99	B	Addition of charging characteristics per PDP context	3.5.0	TEI
08	N4-000264	29.002	3.4.0	138		R99	F	Clarification of SAI-ack segmentation procedure	3.5.0	Security
08	N4-000392	29.002	3.4.0	139	1	R99	A	Indication of unsupported position method	3.5.0	LCS
08	N4-000276	29.002	3.4.0	141		R99	A	Clarification for ReportSM-DeliveryStatus operation	3.5.0	GPRS
08	N4-000349	29.002	3.4.0	142	1	R99	C	Addition of a parameter in the subsequent Handover from UMTS to GSM with Multicall	3.5.0	Multicall
08	N4-000278	29.002	3.4.0	143		R99	D	Editorial correction to MSC-A handover SDLs	3.5.0	Multicall
08	N4-000378	29.002	3.4.0	144	1	R99	A	Use of NAM parameter with MAP-INSERT-SUBSCRIBER-DATA service between HLR and SGSN	3.5.0	GPRS
08	N4-000293	29.002	3.4.0	145		R99	F	Addition of state attributes in Forward group call signalling	3.5.0	ASCI
08	N4-000294	29.002	3.4.0	146		R99	F	New user error "target cell outside group call area" in MAP Prepare Handover message	3.5.0	ASCI
08	N4-000374	29.002	3.4.0	149		R99	A	Correction to the description of MAP-MO-Forward-Short-Message service	3.5.0	TEI
08	N4-000407	29.002	3.5.0	148	4	R00	B	Changes to MAP for secure transport of MAP messages	4.0.0	Security
08		29.002	4.0.0			R00		Version 4.0.1 created to allow inclusion of automatic update of Annexes A and B and of section 17	4.0.1	
09	N4-000543	29.002	4.0.1	152	1	R00	F	Clarifications for secure MAP transport	4.1.0	Core Network Security
09	N4-000539	29.002	4.0.1	153	1	R00	D	Generalization of version handling text in clause 18.2.4	4.1.0	TEI
09	N4-000491	29.002	4.0.1	158		R00	A	Deletion of informative Annexe C	4.1.0	TEI
09	N4-000540	29.002	4.0.1	159		R00	A	Aligning 29.002 with 25.413 (UTRAN Iu Interface RANAP Signalling)	4.1.0	Handover

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
09	N4-000541	29.002	4.0.1	160		R00	A	AUTS and AUTN parameter length	4.1.0	Security
09	N4-000744	29.002	4.0.1	161	2	R00	A	Clarification on Authentication Failure Report ack	4.1.0	Security
09	N4-000666	29.002	4.0.1	163	1	R00	A	Correction on Location Information	4.1.0	CAMEL phase 3
09	N4-000777	29.002	4.0.1	174	2	R00	A	Optionality of parameters in GPRS-CSI	4.1.0	CAMEL phase 3
09	N4-000788	29.002	4.0.1	176	1	R00	A	Correction to QoS indication	4.1.0	LCS
09	N4-000747	29.002	4.0.1	178	1	R00	A	Clarification of use of Radio Resource Information	4.1.0	Handover
09	N4-000750	29.002	4.0.1	180	2	R00	A	Correction to MSC-A handover SDLs	4.1.0	TEI
09	N4-000736	29.002	4.0.1	182		R00	A	Removal of LSAIdentity from NoteMM-EventArg	4.1.0	CAMEL phase 3
09	N4-000772	29.002	4.0.1	184		R00	A	LCS Support for CAMEL Phase 3	4.1.0	LCS
09	N4-000751	29.002	4.0.1	186	1	R00	A	Correction to MSC-A handover SDLs	4.1.0	TEI
09	N4-000779	29.002	4.0.1	188		R00	A	Clarification for segmentation of D-CSI and SMS-CSI	4.1.0	CAMEL phase 3
10	N4-000912	29.002	4.0.1	166	3	Rel-4	A	Corrections and clarifications for USSD procedures on the HLR - gsmSCF interface	4.2.0	USSD
10	N4-000908	29.002	4.1.0	191	1	Rel-4	A	Corrections of ISD data structure for CAMEL phase 3	4.2.0	CAMEL phase 3
10	N4-001069	29.002	4.1.0	193	2	Rel-4	A	USSD Corrections for Follow Me	4.2.0	USSD
10	N4-001071	29.002	4.1.0	196	1	Rel-4	A	GSM to 3G Handover: MAP parameter Target Cell ID	4.2.0	Handover
10	N4-000921	29.002	4.1.0	198		Rel-4	A	ASN.1 description of targetCellId	4.2.0	Handover
10	N4-001073	29.002	4.1.0	200	1	Rel-4	A	IMSI in MAP_PREPARE_HANDOVER	4.2.0	Handover
10	N4-001076	29.002	4.1.0	208	1	Rel-4	A	Alignment of the Target RNC-ID	4.2.0	Handover
10	N4-001089	29.002	4.1.0	211	1	Rel-4	A	Export of GSN-Address data type	4.2.0	CAMEL phase 3
10	N4-001095	29.002	4.1.0	212		Rel-4	A	Transport of long RANAP messages on MAP-E interface	4.2.0	Handover
-	-	29.002	4.2.0	-	-	Rel-4	-	Automatic update of annexes A and B	4.2.1	-
11	N4-010036	29.002	4.2.1	206	1	Rel-4	A	Correction to LCS application context	4.3.0	LCS
11	N4-010276	29.002	4.2.1	215	2	Rel-4	B	Add parameters to ISD and SRI for GPRS to handle ODB for PS	4.3.0	ODB enhancements
11	N4-010033	29.002	4.2.1	217		Rel-4	A	Correction to maximum number of RAB's	4.3.0	Multicall
11	N4-010198	29.002	4.2.1	222	2	Rel-4	B	PS domain support for LCS Release 4	4.3.0	LCS
11	N4-010058	29.002	4.2.1	224		Rel-4	A	Failure of Update GPRS Location when HLR is not reachable	4.3.0	GPRS R97
11	N4-010287	29.002	4.2.1	231	1	Rel-4	B	Extension of call related privacy class for LCS Release 4	4.3.0	LCS
11	N4-010375	29.002	4.2.1	232	2	Rel4	B	Maximum number of LCS Clients	4.3.0	LCS
11	N4-010261	29.002	4.2.1	234		Rel-4	B	MAP over IP according to SIGTRAN	4.3.0	SS7IP
11	N4-010465	29.002	4.2.1	236	1	Rel-4	B	Requesting node type in authentication set request	4.3.0	SEC1-EHCS
11	N4-010360	29.002	4.2.1	246		Rel-4	A	Adding EXPORT definition for LSAIdentity	4.3.0	Camel 3

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
11	N4-010361	29.002	4.2.1	247		Rel-4	A	Removing duplicate parameters from ss-CSI	4.3.0	CAMEL 3
11	N4-010362	29.002	4.2.1	248		Rel-4	A	Correction to description of SS-CSI in HLR to VLR information flow	4.3.0	CAMEL 3
11	N4-010365	29.002	4.2.1	250		Rel-4	A	GSM to UMTS handover: addition of MAP parameter RNC ID	4.3.0	Handover
11	N4-010393	29.002	4.2.1	252		Rel-4	A	Clarification of the use of multicall bearer information	4.3.0	Multicall
11	N4-010428	29.002	4.2.1	258		Rel-4	A	Adding EXPORT definition for GeographicalInformation	4.3.0	Camel 3
11	N4-010446	29.002	4.2.1	260		Rel-4	A	Failure of Authentication Parameter GPRS when HLR is not reachable	4.3.0	GPRS R97
11	N4-010484	29.002	4.2.1	262	1	Rel-4	A	Correction to D-CSI	4.3.0	CAMEL 3
12	N4-010728	29.002	4.3.0	239	4	Rel-4	A	Addition of selected UMTS algorithm indication to the handover procedures	4.4.0	Handover
12	N4-010730	29.002	4.3.0	241	4	Rel-4	A	Addition of allowed GSM algorithms indication to the handover procedures	4.4.0	Handover
12	N4-010733	29.002	4.3.0	244	4	Rel-4	A	Addition of allowed UMTS algorithm indication to the handover procedures	4.4.0	Handover
12	N4-010735	29.002	4.3.0	245	4	Rel-4	A	Addition of selected GSM algorithm indication to the handover procedures	4.4.0	Handover
12	N4-010739	29.002	4.3.0	254	2	Rel-4	A	Addition of radio resource list to the handover procedures	4.4.0	Multicall
12	NP-010247	29.002	4.3.0	256	3	Rel-4	A	Addition of GSM channel type and GSM chosen channel indications to handover procedures	4.4.0	Handover
12	N4-010787	29.002	4.3.0	264	3	Rel-4	A	Add support in MAP for all shapes defined in 23.032	4.4.0	LCS
12	N4-010633	29.002	4.3.0	270	1	Rel-4	A	Correction to description of RNCId parameter	4.4.0	Handover
12	N4-010635	29.002	4.3.0	272	1	Rel-4	A	Correction to Encryption Information and Integrity Protection parameters	4.4.0	Handover
12	N4-010767	29.002	4.3.0	279	3	Rel-4	A	Essential drawbacks on services due to introduction of Super-Charger function	4.4.0	TEI
12	N4-010741	29.002	4.3.0	283	1	Rel-4	A	Introduction of selected Rab-id to the Process Access Signalling operation	4.4.0	Multicall
12	N4-010673	29.002	4.3.0	285		Rel-4	A	Mistake in the definition of Authentication Failure Report Application Context	4.4.0	SEC
12	N4-010551	29.002	4.3.0	266		Rel-4	A	Add support in MAP for Ellipsoid Point	4.4.0	LCS
12	N4-010778	29.002	4.3.0	168	5	Rel-4	C	Security Header modification	4.4.0	Security
12	N4-010785	29.002	4.3.0	267	3	Rel-4	C	Additional Parameters in Authentication Failure Report	4.4.0	SEC1 - EHCS
12	N4-010783	29.002	4.3.0	268	3	Rel-4	F	MS presence notification procedure for LCS	4.4.0	LCS1

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
12	N4-010790	29.002	4.3.0	289	2	Rel-4	F	Component level granularity of protection	4.4.0	SEC1
		29.002	4.4.0			Rel-4		Corrupted headers fixed	4.4.1	
13	N4-010840	29.002	4.4.1	290		Rel-4	F	Clarifications on long forwarded-to numbers	4.5.0	TEI4
13	N4-010929	29.002	4.4.1	291	1	Rel-4	F	Corrections for Deferred MT-LR	4.5.0	LCS1
13	N4-010930	29.002	4.4.1	292	2	Rel-4	F	Clarifications on SupportedLCS-CapabilitySets	4.5.0	LCS1
13	N4-010958	29.002	4.4.1	295	2	Rel4	F	Corrections on the introduction of LCS for PS domain	4.5.0	LCS1
13	N4-010970	29.002	4.4.1	302	2	Rel-4	F	Additional SGSN related values to Access Type	4.5.0	SEC1-EHCS
13	N4-010976	29.002	4.4.1	306		Rel-4	A	Addition of data type definitions to EXPORT statements for the usage in CAP	4.5.0	CAMEL3
13	N4-011017	29.002	4.4.1	307	2	Rel-4	A	Minimum MAP application context for intersystem MSC handover from GSM to UMTS	4.5.0	Handover
13	N4-011019	29.002	4.4.1	309	2	Rel-4	A	Minimum MAP application context for intersystem MSC handover from UMTS to GSM	4.5.0	Handover
13	N4-010845	29.002	4.4.1	277	1	Rel4	F	Correction on the SDL of NW initiated USSD operations	4.5.0	TEI
13		29.002	4.4.1			Rel-4		Editorial Clean up	4.5.0	
14	N4-011031	29.002	4.5.0	313		Rel-4	A	Clarification on LCS parameters in MAP	4.6.0	LCS1
14	N4-011043	29.002	4.5.0	314		Rel-4	F	Handling of linked operations in the MAP protocol machine	4.6.0	TEI4
14	N4-011285	29.002	4.5.0	316		Rel-4	F	Corrections on the SDL diagrams for LCS	4.6.0	LCS1
14	N4-011198	29.002	4.5.0	318	1	Rel-4	A	Indication of deletion of CSI in Notify Subscriber Data Change	4.6.0	CAMEL3
14	N4-011074	29.002	4.5.0	320		Rel-4	A	Correct length of Add-GeographicalInformation	4.6.0	LCS
14	N4-011091	29.002	4.5.0	322		Rel-4	A	Clarify encoding of RNC Id	4.6.0	Handover
14	N4-011094	29.002	4.5.0	324		Rel-4	A	Clarify encoding of RANAP parameters in MAP	4.6.0	Handover
14	N4-011097	29.002	4.5.0	325		Rel-4	F	Clarifications on long forwarded-to numbers	4.6.0	TEI4
14	N4-011227	29.002	4.5.0	331	1	Rel-4	A	Clarification of methodology for maintaining data consistency in Supercharger	4.6.0	TEI
14	N4-011173	29.002	4.5.0	334		Rel-4	A	Addition of RAB ID to Prepare Handover procedure	4.6.0	Multicall
14	N4-011175	29.002	4.5.0	336		Rel-4	A	Correction to the Allowed GSM Algorithms parameter	4.6.0	Handover
14	N4-011177	29.002	4.5.0	337	1	Rel-4	F	Correction of references	4.6.0	TEI4
14	N4-011190	29.002	4.5.0	339		Rel-4	A	CUG-Info is not exported from 29.002	4.6.0	CAMEL3
14	N4-011209	29.002	4.5.0	341		Rel-4	A	Clarification on NSCD when data is withdrawn	4.6.0	CAMEL phase 3
14	N4-011211	29.002	4.5.0	343		Rel-4	A	Clarification of sending CAMEL information in stand alone ISD case	4.6.0	CAMEL phase 3
14	N4-011262	29.002	4.5.0	344		Rel-4	F	Correction of the priority for 'SRI for LCS'	4.6.0	LCS1

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
14	N4-011273	29.002	4.5.0	347		Rel-4	A	ASN.1 correction	4.6.0	CAMEL
14	N4-011437	29.002	4.5.0	349	2	Rel-4	F	Handling of MNRR in the HLR & SMS-GMSC	4.6.0	TEI4
14	N4-011433	29.002	4.5.0	354	1	Rel-4	A	Minimum MAP application context for G2G inter-MSC handover	4.6.0	Handover
14	N4-011439	29.002	4.5.0	359	2	Rel-4	A	Alignment of parameter lengths with those prescribed in 08.08	4.6.0	TEI
14	N4-011423	29.002	4.5.0	360	1	Rel-4	F	Aligning the security header elements with TS33.200	4.6.0	TEI-4
14	N4-011394	29.002	4.5.0	364		Rel-4	A	Syntax error in the ATM result and ATSI result	4.6.0	CAMEL phase 3
14	N4-011381	29.002	4.6.0	355	1	Rel-5	B	LCS Capability Handling for UE"s	5.0.0	TEI5
15	N4-020300	29.002	5.0.0	368	4	Rel-5	B	Collective CAMEL Phase 4 CR	5.1.0	CAMEL4
15	N4-020013	29.002	5.0.0	373		Rel-5	A	Inclusion of complete ODB data in ATSI and NSDC	5.1.0	CAMEL3
15	N4-020266	29.002	5.0.0	381	2	Rel-5	B	Introduction of the 'Requestor ID'	5.1.0	LCS1
15	N4-020068	29.002	5.0.0	386		Rel-5	A	Correction to AC version of gprsLocationInfoRetrievalContext	5.1.0	TEI4
15	N4-020248	29.002	5.0.0	390	1	Rel-5	A	Incomplete description of Restore Data parameters	5.1.0	TEI4
15	N4-020183	29.002	5.0.0	403		Rel-5	A	Clarification on CODEC-Info	5.1.0	TEI
15	N4-020250	29.002	5.0.0	407	1	Rel-5	A	ODB alignment	5.1.0	TEI4
16	N4-020530	29.002	5.1.0	428	2	Rel-5	A	LCS: error handling if shape not supported by GMLC	5.2.0	LCS1
16	N4-020622	29.002	5.1.0	453		Rel-5	A	Addition of Radio Resource List to the Forward Access Signalling operation	5.2.0	Multicall
16	N4-020641	29.002	5.1.0	460		Rel-5	A	Clarification on Resume Call Handling	5.2.0	TEI
16	N4-020746	29.002	5.1.0	440	2	Rel-5	A	Clarification on SendAuthenticationInfo	5.2.0	TEI
16	N4-020750	29.002	5.1.0	446	1	Rel-5	A	Addition of Service Handover parameters to MAP Handover messages	5.2.0	Handover
16	N4-020318	29.002	5.1.0	398		Rel-5	C	Check of NAM and Requesting Node Type on receipt of SendAuthenticationInfo	5.2.0	TEI4
16	N4-020333	29.002	5.1.0	410		Rel-5	A	Handling the MNRR flag in the HLR & SMS-GMSC	5.2.0	TEI4
16	N4-020499	29.002	5.1.0	420	1	Rel-5	A	Clarfication of introducing Session related and unrelated class	5.2.0	LCS1-PS
16	N4-020511	29.002	5.1.0	430	1	Rel-5	A	Corrections on the introduction of LCS for PS domain	5.2.0	LCS
16	N4-020743	29.002	5.1.0	448	1	Rel-5	A	Corrections in SS-code chapter	5.2.0	TEI
16	N4-020408	29.002	5.1.0	423		Rel-5	C	Clarification of handling of MT-SMS-TPDU-Type and SMS-TDP	5.2.0	CAMEL4
16	N4-020410	29.002	5.1.0	425		Rel-5	A	Clarify conditions to trigger restart of MTLR-Deferred procedure	5.2.0	LCS1
16	N4-020468	29.002	5.1.0	414	1	Rel-5	F	Corrections to the handling of Any Time Interrogation and Provide Subscriber Info	5.2.0	CAMEL4

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
16	N4-020476	29.002	5.1.0	435	1	Rel-5	D	Change PS-connected in PS-PDPactive	5.2.0	CAMEL4
16	N4-020483	29.002	5.1.0	422	1	Rel-5	F	Triggering of gsmSCF for MT-SMS-CSI	5.2.0	CAMEL4
16	N4-020485	29.002	5.1.0	408	2	Rel-5	C	Transferring the MS classmark & IMEI to the gsmSCF	5.2.0	CAMEL4
16	N4-020543	29.002	5.1.0	441		Rel-5	F	Correction of Object Identifiers for ASN.1 modules	5.2.0	TEI
16	N4-020608	29.002	5.1.0	450		Rel-5	C	Enhancement to LCS in the PS domain	5.2.0	LCS
16	N4-020623	29.002	5.1.0	454		Rel-5	F	Addition of Location Information GPRS to Note MM Event operation	5.2.0	CAMEL4-NMM
16	N4-020703	29.002	5.1.0	421	4	Rel-5	B	LCS: Codeword and Service Type	5.2.0	LCS1
16	N4-020756	29.002	5.1.0	436	2	Rel-5	B	Splitting of CAMEL phase 4	5.2.0	CAMEL4
17	N4-021001	29.002	5.2.0	437	3	Rel-5	F	Compatible upgrade to ASN.1:1997 of 29.002	5.3.0	TEI
17	NP-020399	29.002	5.2.0	462	2	Rel-5	F	Introduction of GERAN classmark	5.3.0	TEI
17	N4-020841	29.002	5.2.0	465		Rel-5	F	Clarification on Call Deflection	5.3.0	Call Deflection
17	N4-021040	29.002	5.2.0	470	1	Rel-5	F	Correction to the usage of "Roaming not allowed" error	5.3.0	TEI5
17	N4-021041	29.002	5.2.0	471	1	Rel-5	A	Clarifications on Send Identification	5.3.0	TEI
17	N4-021094	29.002	5.2.0	479	2	Rel-5	C	Handling of partial implementations of CAMEL phase 4	5.3.0	CAMEL4
17	N4-021047	29.002	5.2.0	480		Rel-5	C	Removal of ChargingNotification feature	5.3.0	CAMEL4
17	N4-020810	29.002	5.2.0	481		Rel-5	B	CR29.002-443 (rel5) on extensions to ATM for CAMEL control of IMS	5.3.0	IMS-CAMEL
17	N4-020809	29.002	5.2.0	482		Rel-5	B	CR to 29.002 for the support of the MAP Si interface	5.3.0	IMS-CAMEL
18	N4-021290	29.002	5.3.0	499		Rel-5	A	Correction to segmentation of O-CSI and T-CSI	5.4.0	CAMEL3
18	N4-021418	29.002	5.3.0	508		Rel-5	A	ODB correction	5.4.0	CAMEL3
18	N4-021563	29.002	5.3.0	511	1	Rel-5	A	Addtion of reference number to deferred location request procedure	5.4.0	LCS1
18	N4-021573	29.002	5.3.0	516	2	Rel-5	A	Correction to the Service Handover parameters	5.4.0	Multicall
18	N4-021299	29.002	5.3.0	442	3	Rel-5	F	Description of MT SM delivery via two serving nodes	5.4.0	TEI5
18	N4-021294	29.002	5.3.0	474	2	Rel-5	F	Correction of handling of MT-SMS in the SGSN	5.4.0	CAMEL4
18	N4-021124	29.002	5.3.0	475		Rel-5	F	ODB and CB for SMS	5.4.0	TEI5
18	N4-021153	29.002	5.3.0	486		Rel-5	F	Correction of IMEI check for SGSN	5.4.0	TEI5
18	N4-021467	29.002	5.3.0	489	5	Rel-5	F	Available codecs list and selected codec indication	5.4.0	TEI5
18	N4-021194	29.002	5.3.0	490		Rel-5	F	Clarification of the use of Requested CAMEL Subscription Info parameters	5.4.0	CAMEL4

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
18	N4-021252	29.002	5.3.0	495		Rel-5	F	Correction to RCH – adding O-CSI trigger criteria	5.4.0	CAMEL4
18	N4-021264	29.002	5.3.0	496		Rel-5	F	Additional MM-Code for MG-CSI	5.4.0	CAMEL4
18	N4-021296	29.002	5.3.0	497	1	Rel-5	F	Additional handling of partial implementations of CAMEL phase 4	5.4.0	CAMEL4
18	N4-021383	29.002	5.3.0	512		Rel-5	F	Correcion of Codeword Handling	5.4.0	LCS1-PS
18	N4-021443	29.002	5.3.0	513		Rel-5	F	Reference to TS 23.078 in TS 29.002 regarding handling of VMSC address is missing	5.4.0	CAMEL4
18	N4-021524	29.002	5.3.0	521	1	Rel-5	F	Editorial clean-up	5.4.0	TEI5
18	N4-021531	29.002	5.3.0	522		Rel-5	F	Introduction of the CHOICE element 'netDetNotReachable' for PS-SubscriberState	5.4.0	CAMEL4
18	N4-021260	29.002	5.4.0	491	1	Rel-6	B	Addition of LCS Format Indicator to LCS Client ID	6.0.0	LCS2
18	N4-021504	29.002	5.4.0	517	2	Rel-6	B	Addition of V-GMLC Address to the Update Location and Update GPRS Location requests	6.0.0	LCS2
18	N4-021567	29.002	5.4.0	518	3	Rel-6	B	Addition of V-GMLC and H-GMLC Addresses to the Send Routing Info for LCS response	6.0.0	LCS2
18-	N4-021506	29.002	5.4.0	519	2	Rel-6	B	Addition of PPR Address to the Send Routing Info for LCS response	6.0.0	LCS2
19	N4-030234	29.002	6.0.0	509	3	Rel-6	C	Introduction of Call Barring for SMS in PS domain	6.1.0	TEI6
19	N4-030325	29.002	6.0.0	524	3	Rel-6	A	Clean-up of SMS procedures chapter	6.1.0	TEI5
19	NP-030068	29.002	6.0.0	545	2	Rel-6	A	Correction to interactions between CAMEL control of MO SMS and barring	6.1.0	CAMEL3
19	N4-030061	29.002	6.0.0	526		Rel-6	F	Incrementing ASN.1 module versions	6.1.0	TEI6
19	N4-030063	29.002	6.0.0	528		Rel-6	A	LCS diagnostic alignment	6.1.0	LCS1
19	N4-030054	29.002	6.0.0	529		Rel-6	F	Addition of LCS Capability Set 4	6.1.0	LCS2
19	N4-030301	29.002	6.0.0	533	1	Rel-6	A	Correction to the definitions of Radio Resource List and BSSMAP Service Handover List	6.1.0	Multicall
19	N4-030305	29.002	6.0.0	541	2	Rel-6	A	Handover of Group Calls where MSC-B has bearer established	6.1.0	TEI
19	N4-030287	29.002	6.0.0	551	1	Rel-6	A	Change of SS-Code List description for Insert Subscriber Data	6.1.0	TEI
19	N4-030289	29.002	6.0.0	559	1	Rel-6	A	Missing of 'Continue Monitoring message' in SDL 21.7_3.2	6.1.0	TEI5
19	N4-030297	29.002	6.0.0	563	1	Rel-6	A	Alignment of TS 29.002 with TS 23.107 regarding QoS subscribed data	6.1.0	TEI5
19	N4-030222	29.002	6.0.0	566	1	Rel-6	F	Introduction of MSC Number as a new parameter in MAP-SEND-IDENTIFICATION operation	6.1.0	LCS2
20	N4-030692	29.002	6.1.0	536	2	Rel-6	A	Additional SGSN Related Access Type – Detach	6.2.0	SEC1-EHCS

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
20	N4-030658	29.002	6.1.0	568	4	Rel-6	A	Addition of Positioning Data IE to Provide Subscriber Location and Send Location Report	6.2.0	LCS
20	N4-030638	29.002	6.1.0	574	1	Rel-6	F	Provision of SDL diagrams and removal of redundant text in chapter 25	6.2.0	TEI6
20	N4-030713	29.002	6.1.0	595	2	Rel-6	A	Removal of redundant text from 29.002 Chapter 23	6.2.0	TEI5
20	N4-030439	29.002	6.1.0	599		Rel-6	A	LCS Client external ID	6.2.0	LCS
20	N4-030682	29.002	6.1.0	607	1	Rel-6	F	Provision of SDL diagrams and removal of redundant text in chapter 22	6.2.0	TEI5
20	N4-030608	29.002	6.1.0	608	1	Rel-6	B	Addition of LCS capability sets to MAP_SRI_for_LCS response	6.2.0	LCS2
20	N4-030647	29.002	6.1.0	612	1	Rel-6	A	Enhancement of the CheckIMEI operation to retrieve the BMUEF	6.2.0	Late UE
20	N4-030678	29.002	6.1.0	619	1	Rel-6	A	Correction to naming of PRN parameter	6.2.0	CAMEL4
20	N4-030609	29.002	6.1.0	624	1	Rel-6	F	Addition of Privacy Check Related Action to Provide Subscriber Location request	6.2.0	LCS2
20	N4-030642	29.002	6.1.0	610	1	Rel-6	A	Transfer of UE-specific behaviour bitmap at handover	6.2.0	Late UE
20	N4-030601	29.002	6.1.0	633		Rel-6	A	Missing SMSs over MSC even if the MS is capable of such sending	6.2.0	TEI5
21	N4-031043	29.002	6.2.0	584	2	Rel-6	A	Correction to MAP Process Secure_MAP_DSM SDLs	6.3.0	MAP Security
21	N4-031053	29.002	6.2.0	664	1	Rel-6	A	Correction of encoding description of Group-Id	6.3.0	ASCI
21	N4-030828	29.002	6.2.0	657		Rel-6	A	Reduce maximum length of 'LCS Requestor ID' and 'LCS Codeword'.	6.3.0	LCS2
21	N4-030922	29.002	6.2.0	647	1	Rel-6	A	UESBI -IU format	6.3.0	LATE-UE
21	N4-031069	29.002	6.2.0	616	3	Rel-6	A	Incorrect Charging with MNP	6.3.0	CAMEL4
21	N4-031057	29.002	6.2.0	660	2	Rel-6	A	Notification of the 2nd BSG in case of Late CF with OR	6.3.0	SCUDIF
21	N4-031059	29.002	6.2.0	614	3	Rel-6	A	HLR Interrogation for SCUDIF calls	6.3.0	SCUDIF
21	N4-030785	29.002	6.2.0	644		Rel-6	D	Removal of tables in section 7.6	6.3.0	TEI6
21	N4-030806	29.002	6.2.0	649		Rel-6	F	Correction of References	6.3.0	TEI
21	N4-030815	29.002	6.2.0	648		Rel-6	D	Correction of wrong AC name in the table in 17.1.6	6.3.0	TEI6
21	N4-030824	29.002	6.2.0	654		Rel-6	B	New LCS Service Types	6.3.0	LCS
21	N4-030951	29.002	6.2.0	671		Rel-6	D	SS-Barring Category	6.3.0	TEI
21	N4-031006	29.002	6.2.0	650	1	Rel-6	F	Add SGSN, GGSN, GMLC, gsmSCF, NPLR and AuC to network resource parameter	6.3.0	TEI6
21	N4-0301038	29.002	6.2.0	645	1	Rel-6	B	Introduction of North American Interim Location Based Routing of Emergency Call	6.3.0	LCS2
21	N4-031065	29.002	6.2.0	674		Rel-6	F	Positioning Data for UTRAN LCS	6.3.0	LCS2

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
21	N4-030953	29.002	6.2.0	637	1	Rel-6	A	Provision of SDL diagrams and removal of redundant text in chapter 19	6.3.0	TEI5
21	N4-030745	29.002	6.2.0	639		Rel-6	A	Provision of SDL diagrams and removal of redundant text in chapter 20	6.3.0	TEI5
21	N4-030747	29.002	6.2.0	641		Rel-6	A	Provision of SDL diagrams and removal of redundant text in chapter 21	6.3.0	TEI5
21	N4-030748	29.002	6.2.0	642		Rel-6	F	Removal of SIWF description	6.3.0	TEI6
21	N4-030749	29.002	6.2.0	643		Rel-6	D	Deletion of redundant Annex D	6.3.0	TEI6
22	N4-031098	29.002	6.3.0	677		Rel-6	B	Enhancements for the Partial Implementation for "Change of position procedure armed with criteria"	6.4.0	TEI6
22	N4-031135	29.002	6.3.0	687		Rel-6	B	Collective CR for Rel-6 Enhanced Dialled Services	6.4.0	EDCAMEL
22	N4-031274	29.002	6.3.0	648	2	Rel-6	D	Message Segmentation Mechanisms	6.4.0	TEI6
22	N4-031315	29.002	6.3.0	703		Rel-6	B	**Addition of requestingPLMN-ID to Send Authentication Info Request**	6.4.0	TEI6
22	N4-031372	29.002	6.3.0	680	2	Rel-6	F	Addition of CGI to LCS procedures	6.4.0	LCS2
22	N4-031373	29.002	6.3.0	696	2	Rel-6	F	Include v-gmlc parameter in RESTORE DATA MAP message	6.4.0	LCS2
22	N4-031365	29.002	6.3.0	702	2	Rel-6	B	Deferred MT-LR Area Event	6.4.0	LCS2
22	N4-031132	29.002	6.3.0	686		Rel-6	A	More spare bits for CAMEL4 enhancements	6.4.0	CAMEL4
22	N4-031163	29.002	6.3.0	692		Rel-6	A	Clarification on D-CSI segmentation	6.4.0	CAMEL4
22	N4-031342	29.002	6.3.0	676	2	Rel-6	A	MNP correction for prepaid charging	6.4.0	MNP
22	N4-031338	29.002	6.3.0	695	1	Rel-6	A	Remove reduntant option for retrieval of routeing information in figure 21.2.3	6.4.0	TEI5
22	N4-031108	29.002	6.3.0	679		Rel-6	F	Modification of description for conditions on inclusion of Positioning Data	6.4.0	LCS2
22	N4-031317	29.002	6.3.0	689	2	Rel-6	A	HSDPA impacts to MAP	6.4.0	HSDPA
22	NP-030533	29.002	6.3.0	704		Rel-6	F	EXPORT data types to CAP (Change of position armed with criteria)	6.4.0	TEI6
23	N4-040310	29.002	6.4.0	668	3	Rel-6	A	Codec Modification/ Mid-Call Codec Negotiation after Inter-MSC Relocation	6.5.0	OoBTC
23	N4-040193	29.002	6.4.0	670	2	Rel-6	A	Correction of Inter-MSC SRSN Relocation procedure	6.5.0	OoBTC
23	N4-040249	29.002	6.4.0	701	3	Rel-6	B	Introduction of Presence Stage 3 (Ph, Pc and Pg) to the MAP interface	6.5.0	PRESNC
23	N4-040333	29.002	6.4.0	708	2	Rel-6	F	Correction to Insert Subscriber Data message for LCS SS	6.5.0	LCS
23	N4-040328	29.002	6.4.0	709	1	Rel-6	F	SCCP segmentation for Inter PLMN MAP message	6.5.0	TEI6

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
23	N4-040327	29.002	6.4.0	711	2	Rel-6	F	Inclusion of UTRAN Positioning Data parameter	6.5.0	LCS2
23	N4-040284	29.002	6.4.0	717	1	Rel-6	B	Include administrative restriction subscription parameter	6.5.0	TEI6
23	N4-040340	29.002	6.4.0	720	2	Rel-6	A	Add new Unavailability cause for SCUDIF	6.5.0	SCUDIF
23	N4-040171	29.002	6.4.0	721		Rel-6	F	CR implemented by fault	6.5.0	TEI6
23	N4-040182	29.002	6.4.0	724		Rel-6	F	Removal of R-GMLC Address	6.5.0	LCS2
23	N4-040322	29.002	6.4.0	725	1	Rel-6	B	MO-LR Service Identity support	6.5.0	LCS2
23	N4-040267	29.002	6.4.0	726	1	Rel-6	B	CAMEL4 SCUDIF notification during active call for prepay	6.5.0	SCCAMEL
24	N4-040520	29.002	6.5.0	731		Rel-6	F	Introduction of North American Interim Location Based Routing of Emergency Call	6.6.0	LCS2
24	N4-040585	29.002	6.5.0	735		Rel-6	F	Modify IMEI parameter usage definition in MAP-PSL and MAP-SLR	6.6.0	TEI6
24	N4-040600	29.002	6.5.0	736		Rel-6	F	Addition of SAI-Present indication to the LCS procedures	6.6.0	LCS2
24	N4-040601	29.002	6.5.0	737		Rel-6	F	Clarification on the use of MSISDN parameter for Follow Me functionality	6.6.0	TAI6
24	N4-04732	29.002	6.5.0	734	1	Rel-6	F	Add Additional V-GMLC parameter in MAP-SRI-INFO-FOR-LCS	6.6.0	LCS2
24	N4-040736	29.002	6.5.0	718	6	Rel-6	B	Addition of IMEISV to Update Location Procedure for ADD function	6.6.0	TEI6
25	N4-040929	29.002	6.6.0	739		Rel-6	B	Export of UU-Data data type	6.7.0	TEI6
25	N4-041021	29.002	6.6.0	743		Rel-6	D	Wrong SDL flow page implemented	6.7.0	TEI6
25	N4-041128	29.002	6.6.0	732	2	Rel-6	B	Pre-Paging Resource Optimization	6.7.0	TEI6
26	N4-041272	29.002	6.7.0	747		Rel-6	F	Incorrect Implementation of CR 731	6.8.0	LCS2
26	N4-041477	29.002	6.7.0	752		Rel-6	F	Correction to the service response parameters of ATI	6.8.0	TEI6
26	N4-041662	29.002	6.7.0	746	1	Rel-6	B	Introducing VGCS/VBS ciphering	6.8.0	SECGKYV
26	N4-041683	29.002	6.7.0	757	2	Rel-6	F	Clarification about returning authentication data for a subscriber (GSM or UMTS)	6.8.0	TEI6
26	N4-041684	29.002	6.7.0	748	1	Rel-6	F	LCS Capability Handling for UE"s	6.8.0	TEI6
26	N4-041685	29.002	6.7.0	753	1	Rel-6	F	Enable NA-ESRD Provision from a GMLC for E911 Location in North America	6.8.0	LCS2
26	N4-041641	29.002	6.7.0	740	2	Rel-6	B	SMS Fraud countermeasures	6.8.0	TEI6
27	N4-050212	29.002	6.8.0	749	1	Rel-6	B	Management Based Activation Impacts	6.9.0	OEM-TRACE
27	N4-050369	29.002	6.8.0	761	1	Rel-6-	F	Addition of LAI to SendIdentification Request	6.9.0	TEI6
27	N4-050430	29.002	6.8.0	760	1	Rel-6	F	Subscribed Charging Characteristics	6.9.0	TEI6

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
27	N4-050444	29.002	6.8.0	759	1	Rel-6	C	Addition of TCAP-Handshake for MO-ForwardSM	6.9.0	TEI6
27	N4-050446	29.002	6.8.0	745	2	Rel-6	B	Introduction of Hop Counter for Send Identification	6.9.0	TEI6
27	N4-050463	29.002	6.8.0	738	8	Rel-6	F	Rel-6 trace management additions to trace activation and deactivation procedures	6.9.0	OEM-Trace
27	N4-050467	29.002	6.8.0	763	2	Rel-6	F	Pseudonym indicator support in MO-LR	6.9.0	LCS2
28	C4-050737	29.002	6.9.0	769	1	Rel-6	F	Correction to Trace parameters to allow trace at the BM-SC	6.10.0	OAM-Trace
28	C4-050832	29.002	6.9.0	770	6	Rel-6	F	Full RANAP support of network initiated SCUDIF	6.10.0	TEI6
28	C4-050895	29.002	6.9.0	766	2	Rel-6	F	Clarification on the use of Access Restriction Data parameter	6.10.0	TEI5
28	C4-050784	29.002	6.10.0	765	1	Rel-7	B	Addition of CollectInformation procedure to OfferedCAMEL4Functionalities	7.0.0	CAMELR7
29	C4-051013	29.002	7.0.0	771		Rel-7	F	ASN.1 module version update	7.1.0	TEI
29	C4-051295	29.002	7.0.0	776	2	Rel-7	B	Enabling the Providing of Velocity	7.1.0	LCS-7
29	C4-051333	29.002	7.0.0	772	1	Rel-7	B	Support of talker priorities and talker identity presentation	7.1.0	EGCS
29	C4-051334	29.002	7.0.0	773	1	Rel-7	B	Delivery of SMS to voice group call	7.1.0	EGCS
29	C4-051368	29.002	7.0.0	777	2	Rel-7	B	CS data Mobile Terminating calls from PSTN	7.1.0	TEI7
29	C4-051336	29.002	7.0.0	780	2	Rel-7	A	Correction on misalignment with stage 2 for Location Services	7.1.0	TEI6
30	C4-051775	29.002	7.1.0	783	2	Rel-7	A	Addition of UMTS Trace parameters to handover procedure	7.2.0	TEI6
31	C4-060320	29.002	7.2.0	794	1	Rel-7	A	Addition of UMTS Trace parameters to handover procedure	7.3.0	TEI6
31	C4-060295	29.002	7.2.0	790	1	Rel-7	C	Removal of MAPsec material	7.3.0	SEC7-TCAP
31	C4-060315	29.002	7.2.0	787	1	Rel-7	C	addition of "supported RAT types indicator" during location/routing area update	7.3.0	TEI7
31	C4-060378	29.002	7.2.0	792	1	Rel-7	B	Addition of Periodic Location Feature Support	7.3.0	LCS3
31	C4-060434	29.002	7.2.0	781	3	Rel-7	C	New LocationType for the notification based on current location of target UE	7.3.0	LCS7
31	C4-060318	29.002	7.2.0	788	1	Rel-7	F	SMS Relay Application Context Names for Version 1	7.3.0	TEI7
31	C4-060041	29.002	7.2.0	789		Rel-7	F	Precision on segmentation of MAP GPRSSubscriptionData parameter	7.3.0	TEI7
31	C4-060250	29.002	7.2.0	801		Rel7	C	Improvements to VGCS Call Establishment	7.3.0	TEI
31	C4-060011	29.002	7.2.0	786		Rel-7	F	Addition of Authentication Domains in MAP Send Authentication Info	7.3.0	TEI7
32	C4-060813	29.002	7.3.0	0808	2	Rel-7	C	List of MSISDNs and Basic Service Code for MAP Any Time Subscription Interrogation.	7.4.0	TEI7
32	C4-060499	29.002	7.3.0	0803		Rel-7	F	Correction of LCS parameter for emergency call usage	7.4.0	LCS7

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
32	C4-060680	29.002	7.3.0	0814		Rel-7	F	SSN for FFN	7.4.0	TEI7
32	C4-060706	29.002	7.3.0	0817		Rel-7	F	Removal of MAPsec material	7.4.0	SEC7-TCAP
33	CP-060522	29.002	7.4.0	0818	1	Rel-7	F	Removal of ASN.1 Expanded Source	7.5.0	TEI7
33	C4-061047	29.002	7.4.0	0805	1	Rel-7	B	Interoperability between VBS/VGCS and RANflex	7.5.0	VGCSflex
34	CP-060741	29.002	7.5.0	0795	1	Rel-7	B	Support of SMS over IP networks	7.6.0	SMSIP
34	C4-061800	29.002	7.5.0	0828	1	Rel-7	F	Extension of Group ID	7.6.0	EVGCS
34	C4-061633	29.002	7.5.0	0829		Rel-7	F	Addition of Teleservice Code to SendGroupCallInfo	7.6.0	VGCSFlex
34	C4-061775	29.002	7.5.0	0834		Rel-7	F	Accuracy Fulfillment Indicator parameter to MAP SLR for deferred MT-LR	7.6.0	TEI7
34	C4-060693	29.002	7.5.0	0832	2	Rel-7	C	Optional Suppress Terminating Services Bit String in SRI	7.6.0	TEI7
34	C4-061632	29.002	7.6.0	0807	2	Rel-8	B	Introduction of sending application-specific data to group call members	8.0.0	EVA
35	C4-070140	29.002	8.0.0	0843		Rel-8	F	ASN.1 module version update	8.1.0	TEI8
35	C4-070097	29.002	8.0.0	0837		Rel-8	A	Corrections to RAB Configuration Indicator and Iu-Selected codec	8.1.0	TEI7
35	C4-070229	29.002	8.0.0	0840		Rel-8	A	Addition of capability to route MT-SMs via the HPLMN of the receiving MS	8.1.0	SMSviaH
36	C4-070388	29.002	8.1.0	0849		Rel-8	A	Mobile Termination whilst the MS is moving to another MSC	8.2.0	MTmovMS
36	C4-070394	29.002	8.1.0	0842	2	Rel-8	A	Addition of SMS over IP functionality	8.2.0	SMSIP
36	CP-070476	29.002	8.1.0	0859		Rel-8	A	Detailed procedure in the IP-SM-GW	8.2.0	SMSIP
37	C4-071055	29.002	8.2.0	0862		Rel-8	A	QoS Extension	8.3.0	TEI7
37	C4-071072	29.002	8.2.0	0863		Rel-8	C	Talker Channel Parameter	8.3.0	EVA
37	C4-071266	29.002	8.2.0	0869		Rel-8	A	LMSI For MT-SMS	8.3.0	TEI7
37	C4-071281	29.002	8.2.0	0873	1	Rel-8	A	NPI for the call forwarding to number	8.3.0	TEI4
37	C4-071285	29.002	8.2.0	0864	1	Rel-8	A	Limit on number of concurrent MT-LR location requests	8.3.0	TEI7
37	C4-071383	29.002	8.2.0	0868	2	Rel-8	A	Corrections to SMS over IP handling	8.3.0	SMSIP
38	C4-071724	29.002	8.3.0	0876		Rel-8	F	TCRT: Clarification on coding of Notification Data	8.4.0	EVA
38	C4-071815	29.002	8.3.0	0879		Rel-8	A	Removal of CCBS_Call_Report_Ack and Event_Report_Ack	8.4.0	TEI7
38	C4-071855	29.002	8.3.0	0881		Rel-8	A	Restriction on the use of ccbs-A SS indication	8.4.0	TEI7
38	C4-071891	29.002	8.3.0	0877	3	Rel-8	C	SMS Router Optimization	8.4.0	TEI8
38	C4-071997	29.002	8.3.0	0875	1	Rel-8	A	Behaviour of the IP-SM-GW for SM Delivery Status Report	8.4.0	SMSIP
39	C4-080267	29.002	8.4.0	0885		Rel-8	A	Updating of RAT Types	8.5.0	TEI7

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
39	C4-080148	29.002	8.4.0	0883		Rel-8	F	SDL correction for procedure Check_Available_Vectors	8.5.0	TEI8
39	C4-080532	29.002	8.4.0	0886	2	Rel-8	C	HLR involvement in SMS Router Optimization	8.5.0	TEI8
40	C4-081277	29.002	8.5.0	0888	1	Rel-8	A	Extension of Group ID	8.6.0	TEI7
40	C4-080647	29.002	8.5.0	0882	1	Rel-8	B	Paging optimization with A/Iu flex	8.6.0	TEI8
41	C4-081730	29.002	8.6.0	0890		Rel-8	B	Addition of IMS Centralized Service subscription information	8.7.0	ICSRA
41	C4-082447	29.002	8.6.0	0891	1	Rel-8	F	eMLPP Priority in MAP SRI, PRN and PSI request	8.7.0	TEI8
41	C4-082335	29.002	8.6.0	0892	1	Rel-8	B	Gr+ enhancements for EPS	8.7.0	SAES
42	C4-082721	29.002	8.7.0	0894		Rel-8	F	Gr alignment	8.8.0	SAES
42	C4-082758	29.002	8.7.0	0896		Rel-8	F	RAT Frequency Selection Priority	8.8.0	SAES
42	C4-083029	29.002	8.7.0	0899		Rel-8	B	Change in AMBR placement	8.8.0	SAES
42	C4-083221	29.002	8.7.0	0901		Rel-8	F	PDN-GW-Identity	8.8.0	SAES
42	C4-083223	29.002	8.7.0	0902		Rel-8	F	APN-OIReplacement	8.8.0	SAES
42	C4-083247	29.002	8.7.0	0903		Rel-8	F	Access Restriction	8.8.0	SAES-MAP2Diam
42	CP-080706	29.002	8.7.0	0906	1	Rel-8	F	Access Restriction Data Handling	8.8.0	TEI8
42	Cp-080771	29.002	8.7.0	0895	4	Rel-8	B	Closed Subscriber Group	8.8.0	HomeNB-3G
42		29.002	8.8.0			Rel-8		SDL files added in Zip-file	8.8.1	
43	C4-090140	29.002	8.8.1	0908		Rel-8	B	Context Identifier for Update or Removal of PDN GW	8.9.0	SAES
43	C4-090269	29.002	8.8.1	0911		Rel-8	B	Handling LCS Subscription Data	8.9.0	SAES
43	C4-090507	29.002	8.8.1	0914		Rel-8	F	PDN GW Update for Wildcard APN	8.9.0	SAES
43	C4-090701	29.002	8.8.1	0909	1	Rel-8	B	Ready for SM	8.9.0	SAES
43	C4-090855	29.002	8.8.1	0915		Rel-8	B	Handling SMS Subscription Data	8.9.0	SAES
43	C4-090889	29.002	8.8.1	0916		Rel-8	F	Allocation Retention Priority Definition	8.9.0	SAES
44	C4-091071	29.002	8.9.0	0919		Rel-8	A	SMS over IP	8.10.0	SMSIP
44	C4-091028	29.002	8.9.0	0917		Rel-8	F	MAP RESTORE DATA service	8.10.0	TEI8
44	C4-091377	29.002	8.9.0	0921	1	Rel-8	F	Subscription Data Clarification for MAP Interface	8.10.0	SAES
44	C4-091429	29.002	8.9.0	0920	1	Rel-8	F	Trace	8.10.0	SAES
44	C4-091435	29.002	8.9.0	0922	1	Rel-8	F	Supported Features	8.10.0	SAES-MAP2DIAM
44	CP-090379	29.002	8.9.0	0923	1	Rel-8	F	User Data Download	8.10.0	SAES
45	C4-091713	29.002	8.10.0	0924		Rel-8	F	Notification of SMS over IP Non-Delivery for E-UTRAN and UE Reachability	8.11.0	SAES-MAP2DIAM
45	C4-092244	29.002	8.10.0	0927		Rel-8	F	SGSN interface list for trace	8.11.0	SAES
45	C4-092254	29.002	8.10.0	0925	2	Rel-8	F	Cancel Location for Initial Attach	8.11.0	SAES-MAP2DIAM
45	C4-092291	29.002	8.10.0	0929		Rel-8	F	Fix APN-Configuration to support dual IP addresses	8.11.0	SAES

SMG#	TDoc	SPEC	VERS	CR	REV	PHASE	CAT	SUBJECT	NEW_VERS	WORKITEM
46	C4-094140	29.002	8.11.0	0941	1	Rel-8	A	Alignment of specifications on Usage of MAP_SEND_AUTHENTICATION_INFO	8.12.0	TEI7
46	C4-093972	29.002	8.11.0	0942	1	Rel-8	F	SMS over SGs charging	8.12.0	TEI8
46	C4-094136	29.002	8.11.0	0936	1	Rel-8	F	Subscription to Notification of UE Reachability	8.12.0	TEI8

History

Document history		
V8.8.1	February 2009	Publication
V8.9.0	April 2009	Publication
V8.10.0	July 2009	Publication
V8.11.0	October 2009	Publication
V8.12.0	February 2010	Publication