

Add OctoPrint

Add printer

✓ Printer address 02 Connection

CONNECTION SELECTED

OctoPrint
192.0.2.68:5000
OctoPrint [Change address](#)

Printer name
OctoPrint

Monitor the printer connected to OctoPrint over your local network. Each OctoPrint instance is added separately.

OctoPrint API key [Show](#)

Create an application API key in OctoPrint with permission to read printer status and job information. PrintDeck only reads these values.

Review the details, then check the connection to add your printer.

[Back](#) [Check & add](#)

1. Choose the connection

Keep OctoPrint and PrintDeck on the same local network. In Add printer, open Other printers, enter the OctoPrint host and port, then select OctoPrint under Connection type. Each instance becomes one printer profile.

2. Check and add

Enter a name and an OctoPrint API key whose user can read printer status and job information. Choose Check & add. OctoPrint must also be connected to its printer; the check only reads data.

3. Monitor the print

Select the online profile to see the job, progress, elapsed and remaining time, and reported nozzle and bed temperatures. Missing values stay unavailable. This connection does not supply camera images, thumbnails or printer controls.

4. Edit safely

Leave the key blank to keep the saved key at the same address. Enter it again after changing the address. Keep the OctoPrint computer running; a reachable OctoPrint with a disconnected printer is not an online printer.