

=====

=====

TECHNOVA ELECTRONICS - COMPREHENSIVE TROUBLESHOOTING GUIDE

Common Issues and Solutions for All TechNova Products

=====

=====

VERSION: 1.0

DATE: January 2026

PART NUMBER: TN-TSG-001

=====

=====

TABLE OF CONTENTS

=====

=====

SECTION 1: GENERAL TROUBLESHOOTING 1

- 1.1 Basic Troubleshooting Steps
- 1.2 Common Issues Across Products
- 1.3 When to Contact Support

SECTION 2: SMARTWATCH TROUBLESHOOTING 5

- 2.1 Power and Charging Issues
- 2.2 Display Issues
- 2.3 Connectivity Issues
- 2.4 App and Sync Issues
- 2.5 Health Tracking Issues

- 2.6 Fitness Tracking Issues
- 2.7 Notification Issues
- 2.8 Calling Issues
- 2.9 Battery and Performance Issues

SECTION 3: EARBUDS TROUBLESHOOTING 15

- 3.1 Power and Charging Issues
- 3.2 Connectivity Issues
- 3.3 Audio Quality Issues
- 3.4 Call Quality Issues
- 3.5 Touch Control Issues
- 3.6 ANC and Sound Issues
- 3.7 Microphone Issues
- 3.8 Battery Issues
- 3.9 App and Firmware Issues

SECTION 4: SMART HOME DEVICES TROUBLESHOOTING 22

- 4.1 LED Bulb Issues
- 4.2 Smart Plug Issues
- 4.3 WiFi Router Issues
- 4.4 Webcam Issues
- 4.5 App and Connectivity Issues

SECTION 5: MOBILE ACCESSORIES TROUBLESHOOTING 26

- 5.1 Power Bank Issues
- 5.2 Charger Issues
- 5.3 Cable Issues
- 5.4 Phone Case Issues

SECTION 6: ADVANCED TROUBLESHOOTING 28

6.1 Factory Reset Procedures

6.2 Firmware Update Issues

6.3 Hardware Diagnostics

6.4 Error Codes and Messages

=====

=====

SECTION 1: GENERAL TROUBLESHOOTING

=====

=====

1.1 Basic Troubleshooting Steps

FOLLOW THESE STEPS FIRST FOR ANY ISSUE:

STEP 1: Restart the Device

Why:

- Clears temporary glitches
- Resets software
- Fixes 80% of common issues
- Quick and easy

How:

- Smartwatch: Settings → System → Restart
- Earbuds: Place in case, close lid for 10 seconds, remove
- Smart Home: Unplug for 30 seconds, plug back in
- Other: Power off, wait 10 seconds, power on

STEP 2: Check Power and Charging

Why:

- Low battery causes many issues
- Charging problems are common
- Easy to diagnose

How:

- Check battery level
- Ensure device is charged (20%+)
- Check charger and cable working
- Try different power source
- Clean charging contacts

STEP 3: Check Connectivity

Why:

- Bluetooth issues are common
- WiFi problems affect smart home
- Connection drops cause issues

How:

- Ensure Bluetooth is ON (phone)
- Bring devices closer (within 10 meters)
- Restart Bluetooth on phone
- Check WiFi connection (for smart home)
- Re-pair devices if needed

STEP 4: Update Software/Firmware

Why:

- Updates fix bugs
- Improve performance
- Add features
- Important for stability

How:

- Smartwatch: Settings → System → Software Update
- Earbuds: TechNova Audio app → Firmware Update
- Smart Home: TechNova Smart Home app → Updates
- Enable auto-updates

STEP 5: Check App Permissions

Why:

- Apps need permissions to work
- Missing permissions cause issues
- Easy to overlook

How:

- Android: Settings → Apps → TechNova App → Permissions → Allow all
- iOS: Settings → TechNova App → Enable all permissions
- Grant: Location, Notifications, Bluetooth, etc.

STEP 6: Reinstall App

Why:

- App corruption causes issues

- Reinstalling fixes software problems
- Refreshes connection

How:

1. Delete app from phone
2. Restart phone
3. Reinstall app from store
4. Log in and re-pair devices

STEP 7: Factory Reset (Last Resort)

Why:

- Resets to factory settings
- Fixes persistent software issues
- Last resort before service

How:

- Smartwatch: Settings → System → Factory Reset
- Earbuds: Place in case, hold touch sensors 10-15 seconds
- Smart Home: Reset button or app
- Note: Erases all data, re-setup required

1.2 Common Issues Across Products

COMMON PROBLEMS AND SOLUTIONS:

ISSUE: Device won't turn on

Possible Causes:

- Battery completely drained
- Charging issue
- Software crash
- Hardware failure

Solutions:

1. Charge device for 30+ minutes
2. Try different charger/cable
3. Try different power source
4. Clean charging contacts
5. Force restart (if applicable)
6. If still won't turn on → Contact support

ISSUE: Not connecting to phone

Possible Causes:

- Bluetooth off
- Too far from phone
- Interference
- Software issue
- Hardware issue

Solutions:

1. Ensure Bluetooth ON on phone
2. Bring device close to phone (within 1-2 meters)
3. Restart Bluetooth on phone
4. "Forget" device in Bluetooth settings
5. Re-pair device
6. Update firmware

7. Restart phone

8. If still not connecting → Contact support

ISSUE: Battery draining fast

Possible Causes:

- Heavy usage
- Always-on features
- Old battery
- Software issue
- Background apps

Solutions:

1. Check battery usage in app
2. Disable unnecessary features (AOD, continuous monitoring, etc.)
3. Lower brightness
4. Reduce notifications
5. Enable power saving mode
6. Update firmware
7. If battery still draining fast → Battery may be degraded, contact support

ISSUE: Overheating

Possible Causes:

- Heavy usage
- Charging while using
- Hot environment
- Software issue
- Hardware issue

Solutions:

1. Stop using device
2. Remove from charger
3. Let cool down (room temperature)
4. Avoid direct sunlight
5. Don't use heavy features while charging
6. If overheating persists → Contact support

ISSUE: Not charging

Possible Causes:

- Charging cable/adaptor issue
- Dirty contacts
- Power source issue
- Charging port issue
- Battery issue

Solutions:

1. Try different cable
2. Try different adapter
3. Try different power source
4. Clean charging contacts
5. Ensure proper connection
6. Check for debris in port
7. If still not charging → Contact support

ISSUE: App not working

Possible Causes:

- App crash
- Permissions issue
- Outdated app
- Phone compatibility
- Server issue

Solutions:

1. Force close and reopen app
2. Clear app cache (Android)
3. Update app to latest version
4. Check app permissions
5. Reinstall app
6. Check internet connection
7. If still not working → Contact support

ISSUE: Slow or laggy

Possible Causes:

- Too many apps running
- Low storage
- Outdated software
- Hardware limitations
- Software issue

Solutions:

1. Close unused apps
2. Restart device
3. Clear cache

4. Update firmware
5. Free up storage
6. If still slow → May need service

1.3 When to Contact Support

CONTACT SUPPORT IF:

Hardware Issues:

- Device won't turn on (after charging)
- Broken or damaged parts
- Water damage
- Charging port damaged
- Buttons not working
- Display cracked or unresponsive
- Battery swelling
- Physical damage

Persistent Software Issues:

- Issues persist after factory reset
- Can't update firmware
- Repeated crashes
- Boot loop (stuck on startup)
- Can't pair or connect
- Data loss
- App won't work (after reinstall)

Performance Issues:

- Severe battery drain (sudden)

- Overheating (normal use)
- Extremely slow or unresponsive
- Frequent disconnections
- Poor audio quality (hardware)
- Sensor failures

Warranty Claims:

- Manufacturing defects
- Product not working as expected
- Within warranty period
- Need repair or replacement

Getting Help:

Phone:

- 1800-123-4567 (Toll-free)
- Mon-Sat: 9 AM - 9 PM
- Sun: 10 AM - 6 PM

Email:

- support@technovaelectronics.com
- Include: Model, issue, steps tried, purchase date, invoice

Website:

- www.technovaelectronics.com/support
- Live chat
- Support ticket
- FAQs
- Troubleshooting guides

In-App:

- TechNova apps → Help & Support
- Chat with support
- Create ticket
- FAQs

Service Centers:

- Find nearest: Website → Service Centers
- Walk-in or appointment
- Carry device and invoice
- Diagnosis and repair

BEFORE CONTACTING:

Have Ready:

- Product model
- Serial number
- Purchase date
- Invoice number
- Issue description
- When it started
- Steps already tried
- Photos/videos (if applicable)
- Your contact details

=====

=====

SECTION 2: SMARTWATCH TROUBLESHOOTING

=====

=====

2.1 Power and Charging Issues

ISSUE: Watch won't turn on

Symptoms:

- No display when pressing buttons
- No vibration or response
- Black screen
- No LED indicators

Possible Causes:

- Battery completely drained
- Charging issue
- Software crash
- Hardware failure

Solutions:

Step 1: Charge the Watch

- Connect to charger
- Use provided cable and adapter
- Charge for at least 30 minutes
- Check for charging indicators
- If no indicators, try Step 2

Step 2: Check Charger and Cable

- Try different USB cable
- Try different USB adapter (5V/1A or 5V/2A)
- Try different power source (computer, power bank, wall adapter)
- Ensure cable connected properly
- Check for debris in charging port

Step 3: Clean Charging Contacts

- Use soft, dry cloth
- Clean contacts on watch back
- Clean contacts on charging cable
- Remove any dirt or debris
- Try charging again

Step 4: Force Restart

- Press and hold crown button for 10-15 seconds
- Watch should vibrate and restart
- If restarts, issue resolved
- If not, continue to Step 5

Step 5: Extended Charging

- Leave on charger for 2-3 hours
- Sometimes deeply discharged batteries need time
- Check periodically for charging indicators
- If still no response, continue to Step 6

Step 6: Contact Support

- If watch still won't turn on after all steps
- May be hardware issue
- Visit service center

- Warranty claim if applicable

PREVENTION:

- Charge watch before completely drained
- Don't let battery go to 0% frequently
- Charge at least once a week
- Use provided charger
- Keep charging contacts clean

ISSUE: Watch not charging or charging slowly

Symptoms:

- Charging icon not appearing
- Battery percentage not increasing
- Charging very slowly (>3 hours for full charge)
- Intermittent charging (starts and stops)

Possible Causes:

- Poor contact between charger and watch
- Dirty charging contacts
- Weak power source
- Damaged cable or charger
- Charging port issue

Solutions:

Step 1: Check Connection

- Ensure magnetic charger aligned properly
- All 4 pins should touch contacts

- Magnets should snap into place
- Adjust position if needed

Step 2: Clean Contacts

- Power off watch
- Use soft, dry cloth
- Clean charging contacts on watch
- Clean charging pins on cable
- Remove dirt, sweat, debris
- Try charging again

Step 3: Check Power Source

- Try different USB port (if using computer)
- Try different USB adapter (5V/1A or 5V/2A recommended)
- Avoid using low-power ports (some USB hubs, old computers)
- Use wall adapter for fastest charging

Step 4: Check Cable and Charger

- Inspect cable for damage
- Try different cable (USB Type-C)
- Try different adapter
- Ensure cable not frayed or damaged

Step 5: Check for Obstructions

- Inspect charging port on watch
- Look for debris, lint, or dirt
- Use soft brush or toothpick (gently)
- Don't use metal objects

Step 6: Restart Watch

- Restart watch (Settings → System → Restart)
- Sometimes software prevents charging
- Restart can fix charging issues

Step 7: Update Firmware

- Check for firmware updates
- Updates may fix charging issues
- Settings → System → Software Update

Step 8: Contact Support

- If still not charging or charging very slowly
- May be hardware issue (battery, charging port)
- Visit service center
- Warranty claim if applicable

PREVENTION:

- Clean charging contacts weekly
- Use provided cable
- Use proper adapter (5V/1A or 5V/2A)
- Don't charge in dusty environments
- Store charger properly

ISSUE: Battery draining too fast

Symptoms:

- Battery lasts 1-2 days instead of 7
- Rapid battery drain (10-20% per hour)
- Watch gets warm during use

- Battery percentage drops suddenly

Possible Causes:

- Always-on display enabled
- Continuous heart rate monitoring
- Many notifications
- Background apps
- Old or degraded battery
- Software issue
- Heavy usage

Solutions:

Step 1: Check Battery Usage

- Settings → Battery → Battery Usage
- See which features/apps using most power
- Identify power-hungry features

Step 2: Disable Always-On Display

- Settings → Display → Always-On Display → OFF
- Saves 30-40% battery
- Use raise-to-wake instead

Step 3: Adjust Heart Rate Monitoring

- Settings → Health → Heart Rate → Auto Monitor
- Change to "Every 10 minutes" or "Every 30 minutes"
- Or "Smart" mode
- Continuous monitoring drains battery

Step 4: Reduce Notifications

- App → Devices → Your Watch → Notifications
- Disable notifications for non-essential apps
- Fewer notifications = less battery drain

Step 5: Lower Brightness

- Settings → Display → Brightness
- Reduce to level 2 or 3
- Or enable auto-brightness

Step 6: Shorten Screen Timeout

- Settings → Display → Screen Timeout
- Set to 10 or 15 seconds
- Screen on less time = less battery

Step 7: Disable Unused Features

- Turn off:
 - SpO2 auto-monitoring
 - Stress monitoring (use manual)
 - Sleep tracking (if not needed)
 - Continuous GPS
 - Background apps

Step 8: Enable Power Saving Mode

- Settings → Battery → Power Saving Mode → ON
- Disables non-essential features
- Extends battery life significantly

Step 9: Update Firmware

- Settings → System → Software Update
- Updates may improve battery optimization
- Install latest firmware

Step 10: Check Battery Health

- App → Devices → Your Watch → Battery → Health
- Check maximum capacity
- If below 80%, battery may need replacement

Step 11: Factory Reset (Last Resort)

- Settings → System → Factory Reset
- Erases all data
- Sometimes fixes software-related drain
- Re-setup watch

Step 12: Contact Support

- If battery still draining fast after all steps
- Battery may be degraded or defective
- Visit service center
- Battery replacement may be needed

PREVENTION:

- Don't drain battery to 0% frequently
- Charge regularly (don't let sit discharged)
- Avoid extreme temperatures
- Disable unnecessary features
- Keep firmware updated

2.2 Display Issues

ISSUE: Screen not responding to touch

Symptoms:

- Tap/touch not registering
- Screen frozen or unresponsive
- Some areas not responding
- Touch delayed or erratic

Possible Causes:

- Screen protector interfering
- Wet or dirty screen
- Software crash
- Hardware issue

Solutions:

Step 1: Remove Screen Protector

- If using screen protector, remove it
- Poor quality protectors can interfere
- Try without protector
- If works, use better quality protector

Step 2: Clean Screen

- Power off watch
- Use soft, slightly damp cloth
- Clean screen thoroughly
- Remove dirt, oil, sweat
- Dry completely

- Try again

Step 3: Dry Screen

- If screen wet, dry thoroughly
- Use soft, dry cloth
- Wait for screen to dry completely
- Don't use while wet

Step 4: Restart Watch

- Settings → System → Restart
- Or hold crown for 10 seconds (force restart)
- Software may be frozen
- Restart often fixes touch issues

Step 5: Check for Software Updates

- Settings → System → Software Update
- Install any available updates
- Updates may fix touch issues

Step 6: Factory Reset

- Settings → System → Factory Reset
- Erases all data
- Last resort before service
- Back up data first

Step 7: Contact Support

- If still not responding
- May be hardware issue (touch sensor, display)
- Visit service center

- Warranty claim if applicable

PREVENTION:

- Use good quality screen protector
- Keep screen clean
- Don't use with wet fingers
- Don't press too hard
- Restart watch weekly

ISSUE: Screen cracked or damaged

Symptoms:

- Visible cracks on screen
- Display not showing properly
- Touch not working in damaged areas
- Glass broken or shattered

Possible Causes:

- Physical impact or drop
- Pressure on screen
- Manufacturing defect (rare)

Solutions:

Step 1: Assess Damage

- Check if display still works
- Check if touch works
- Check for glass shards (safety)
- Determine if usable

Step 2: Protect Yourself

- If glass shattered, handle carefully
- Avoid touching broken glass
- Can use clear tape to hold shards
- Don't use if glass may fall out

Step 3: Stop Using (If Severe)

- If display not working or unsafe
- Stop using watch
- Power off
- Contact support

Step 4: Contact Support

- Visit service center
- Display replacement needed
- Cost depends on warranty
- Out of warranty: Paid repair

PREVENTION:

- Use protective case
- Use good quality screen protector
- Avoid dropping watch
- Don't press hard on screen
- Handle with care

ISSUE: Display too dim or too bright

Symptoms:

- Can't see screen in sunlight (too dim)
- Screen too bright at night (too bright)
- Auto-brightness not working
- Manual adjustment not effective

Solutions:

Step 1: Adjust Manual Brightness

- Swipe down for quick settings
- Use brightness slider
- Or: Settings → Display → Brightness
- Set to comfortable level (1-5)

Step 2: Enable/Disable Auto-Brightness

- Swipe down for quick settings
- Tap "Auto" icon
- Or: Settings → Display → Auto-Brightness
- Auto adjusts to environment
- Recommended for most users

Step 3: Clean Ambient Light Sensor

- Sensor is near display (small dot)
- Clean gently with soft cloth
- Remove dirt or debris
- Auto-brightness may work better

Step 4: Check for Software Updates

- Settings → System → Software Update
- Install updates

- May fix brightness issues

Step 5: Contact Support

- If brightness still not appropriate
- May be sensor issue
- Visit service center

PREVENTION:

- Use auto-brightness
- Clean sensor regularly
- Adjust brightness to environment
- Avoid max brightness (drains battery)

ISSUE: Display showing wrong colors or lines

Symptoms:

- Colors look wrong or washed out
- Lines on screen (horizontal or vertical)
- Pixels stuck (dots on screen)
- Display flickering

Possible Causes:

- Software issue
- Display damage
- Loose connection (internal)
- Hardware failure

Solutions:

Step 1: Restart Watch

- Settings → System → Restart
- Or force restart (hold crown 10 seconds)
- May fix software-related issues

Step 2: Check for Updates

- Settings → System → Software Update
- Install updates
- May fix display issues

Step 3: Factory Reset

- Settings → System → Factory Reset
- Erases all data
- Last resort before service

Step 4: Contact Support

- If still showing wrong colors or lines
- Likely hardware issue (display)
- Visit service center
- Display replacement needed

PREVENTION:

- Avoid dropping watch
- Don't expose to extreme temperatures
- Don't press hard on screen
- Use protective case
- Handle with care

2.3 Connectivity Issues

ISSUE: Watch not connecting to phone

Symptoms:

- Watch shows "Disconnected"
- Phone shows watch not connected
- Notifications not coming to watch
- Data not syncing

Possible Causes:

- Bluetooth off on phone
- Too far from phone
- Interference
- Pairing issue
- Software issue

Solutions:

Step 1: Check Bluetooth on Phone

- Go to phone Settings → Bluetooth
- Ensure Bluetooth is ON
- If off, turn it on
- Wait for Bluetooth to activate

Step 2: Bring Watch Close to Phone

- Keep within 1-2 meters
- Remove obstacles
- Avoid interference (WiFi routers, microwaves)
- Direct line of sight helps

Step 3: Restart Bluetooth on Phone

- Turn Bluetooth OFF
- Wait 5-10 seconds
- Turn Bluetooth ON
- Wait for activation
- Check if watch connects

Step 4: Check Connection in App

- Open TechNova Fit app
- Devices → Your Watch
- Should show "Connected"
- If not, tap to connect

Step 5: Forget and Re-pair

- Phone Settings → Bluetooth
- Find "TechNova Pro X1" or similar
- Tap "Forget" or "Unpair"
- Put watch in pairing mode (Settings → Bluetooth)
- Pair again from app

Step 6: Restart Both Devices

- Restart watch (Settings → System → Restart)
- Restart phone
- Open app
- Check connection

Step 7: Update App and Firmware

- Update TechNova Fit app (Play Store/App Store)

- Update watch firmware (Settings → System → Software Update)
- Both should be latest version

Step 8: Clear App Cache (Android)

- Phone Settings → Apps → TechNova Fit
- Storage → Clear Cache
- Reopen app
- Check connection

Step 9: Reinstall App

- Delete app from phone
- Restart phone
- Reinstall app from store
- Log in and re-pair watch

Step 10: Contact Support

- If still not connecting
- May be hardware issue (Bluetooth)
- Visit service center

PREVENTION:

- Keep Bluetooth on
- Keep phone within 10 meters
- Restart Bluetooth weekly
- Update app and firmware regularly
- Re-pair if issues

ISSUE: Bluetooth keeps disconnecting

Symptoms:

- Watch connects then disconnects
- Frequent disconnections
- Connection drops randomly
- Have to re-connect often

Possible Causes:

- Too far from phone
- Interference
- Bluetooth issue on phone
- Software issue
- Hardware issue

Solutions:

Step 1: Keep Phone Close

- Stay within 10 meters
- Remove obstacles
- Avoid walls and interference
- Phone in pocket (not bag)

Step 2: Reduce Interference

- Move away from WiFi routers
- Move away from microwaves
- Turn off other Bluetooth devices
- Avoid crowded RF environments

Step 3: Check Phone Bluetooth

- Restart Bluetooth on phone

- Update phone OS
- Check for Bluetooth issues with other devices
- Test with different phone

Step 4: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May fix connectivity issues

Step 5: Forget and Re-pair

- Forget device in Bluetooth settings
- Re-pair from app
- Fresh connection

Step 6: Disable Battery Optimization (Android)

- Phone Settings → Apps → TechNova Fit
- Battery → Battery optimization
- Select "Don't optimize" or "unrestricted"
- App can run in background

Step 7: Allow Background Running (Android)

- Phone Settings → Apps → TechNova Fit
- Battery → Background restriction
- Disable background restriction
- App can sync in background

Step 8: Contact Support

- If still disconnecting frequently
- May be hardware issue

- Visit service center

PREVENTION:

- Keep phone within range
- Reduce interference
- Update firmware
- Keep app running in background
- Re-pair if needed

2.4 App and Sync Issues

ISSUE: App not syncing data

Symptoms:

- Health data not showing in app
- Steps not syncing
- Workouts not appearing
- Data outdated or missing

Possible Causes:

- Watch not connected
- App not syncing
- Sync settings off
- Software issue

Solutions:

Step 1: Check Connection

- Ensure watch connected to phone

- App should show "Connected"
- If not, connect first

Step 2: Manual Sync

- Open TechNova Fit app
- Pull down on dashboard (swipe down)
- Or tap sync icon
- Wait for sync to complete
- Check if data appears

Step 3: Check Sync Settings

- App → Devices → Your Watch → Sync Settings
- Ensure sync enabled
- Check what data is syncing
- Enable all needed data types

Step 4: Restart App

- Force close app
- Reopen app
- Try syncing again

Step 5: Restart Watch

- Settings → System → Restart
- Reopen app
- Try syncing again

Step 6: Update App

- Play Store/App Store → Update TechNova Fit
- Install latest version

- Try syncing again

Step 7: Clear App Cache (Android)

- Phone Settings → Apps → TechNova Fit
- Storage → Clear Cache
- Reopen app
- Try syncing

Step 8: Reinstall App

- Delete app
- Restart phone
- Reinstall app
- Log in and re-pair
- Try syncing

Step 9: Contact Support

- If still not syncing
- May be account or server issue
- Contact support

PREVENTION:

- Keep watch connected
- Sync regularly
- Don't disable sync
- Update app regularly
- Restart app weekly

ISSUE: App crashing or freezing

Symptoms:

- App closes unexpectedly
- App freezes or becomes unresponsive
- Can't navigate in app
- Error messages

Possible Causes:

- App bug or crash
- Outdated app
- Phone compatibility
- Storage issue
- Software conflict

Solutions:

Step 1: Force Close and Reopen

- Close app completely (from recent apps)
- Reopen app
- May work temporarily

Step 2: Clear App Cache (Android)

- Phone Settings → Apps → TechNova Fit
- Storage → Clear Cache
- Reopen app
- Check if issue resolved

Step 3: Clear App Data (Android)

- Phone Settings → Apps → TechNova Fit
- Storage → Clear Data

- Note: Erases app data, need to log in again
- Reopen app
- Log in and re-pair

Step 4: Update App

- Play Store/App Store → Update TechNova Fit
- Install latest version
- Check if issue resolved

Step 5: Restart Phone

- Restart phone
- Reopen app
- Check if issue resolved

Step 6: Check Phone Storage

- Phone Settings → Storage
- Ensure at least 100 MB free
- Free up space if needed
- Low storage can cause crashes

Step 7: Reinstall App

- Delete app
- Restart phone
- Reinstall app from store
- Log in and re-pair

Step 8: Check Phone Compatibility

- Ensure phone meets requirements:
 - Android 6.0+ or iOS 12.0+

- Bluetooth 4.0+
- 100 MB free storage
- Check app store for compatibility

Step 9: Contact Support

- If still crashing
- Report issue with details
- App version, phone model, OS version
- Support can investigate

PREVENTION:

- Keep app updated
- Don't let storage get too low
- Restart app weekly
- Clear cache monthly
- Report bugs to support

2.5 Health Tracking Issues

ISSUE: Heart rate not accurate or not measuring

Symptoms:

- Heart rate readings seem wrong
- Can't get heart rate reading
- Readings take too long
- Inconsistent readings

Possible Causes:

- Watch not snug enough

- Dirty sensors
- Movement during measurement
- Cold skin
- Tattoo or skin tone
- Incorrect positioning
- Hardware issue

Solutions:

Step 1: Wear Watch Properly

- Wear 1-2 cm above wrist bone
- Snug fit (not loose, not too tight)
- Sensors should touch skin
- Not too loose (sensors need contact)

Step 2: Clean Sensors

- Power off watch
- Use soft, slightly damp cloth
- Clean sensors on back of watch
- Remove dirt, sweat, oil
- Dry completely
- Try again

Step 3: Stay Still During Measurement

- Sit or stand still
- Don't move arm or wrist
- Don't talk
- Wait for full reading (15-30 seconds)

Step 4: Warm Up Skin

- If cold, rub wrist to warm up
- Blood flow improves in warmth
- Sensors work better on warm skin
- Wait for skin to warm up

Step 5: Adjust Position

- Try moving watch slightly up or down
- Find spot with good blood flow
- Different position may work better
- Avoid bones and tendons

Step 6: Check for Tattoos or Dark Skin

- Tattoos can interfere with sensors
- Darker skin may need snugger fit
- Try different position
- May need to try multiple times

Step 7: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May improve sensor accuracy

Step 8: Compare with Manual Pulse

- Measure pulse manually (15 seconds × 4)
- Compare with watch reading
- If consistently off by same amount, note it
- Watch may need calibration

Step 9: Contact Support

- If still inaccurate or not measuring
- May be sensor hardware issue
- Visit service center

PREVENTION:

- Wear watch properly
- Clean sensors regularly
- Stay still during measurement
- Keep firmware updated
- Compare with manual checks occasionally

ISSUE: Steps not counting or inaccurate

Symptoms:

- Steps not counting
- Step count seems wrong
- Counting steps when not walking
- Not counting steps when walking

Possible Causes:

- Watch not worn properly
- Calibration issue
- Software issue
- Sensor issue

Solutions:

Step 1: Wear Watch Properly

- Wear on wrist (not in pocket or bag)
- Snug fit
- Not too loose
- Watch should move with arm

Step 2: Check Wrist Setting

- Settings → Health → Steps → Wrist
- Ensure correct wrist (left or right)
- Wrong wrist affects accuracy

Step 3: Calibrate Steps

- Walk 100 steps (count manually)
- Check watch step count
- If significantly different, note it
- Watch may learn over time

Step 4: Reset Step Count

- App → Health → Steps → Reset
- Start fresh
- Monitor for accuracy

Step 5: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May improve step accuracy

Step 6: Restart Watch

- Settings → System → Restart
- Reopen app

- Check step counting

Step 7: Contact Support

- If still inaccurate
- May be sensor issue
- Visit service center

PREVENTION:

- Wear watch on wrist properly
- Keep firmware updated
- Calibrate occasionally
- Don't expect 100% accuracy (all devices have some variance)

ISSUE: Sleep tracking not working

Symptoms:

- Sleep data not showing
- Sleep not detected
- Inaccurate sleep times
- No sleep stages

Possible Causes:

- Not wearing watch to bed
- Sleep tracking disabled
- Low battery
- Software issue

Solutions:

Step 1: Wear Watch to Bed

- Wear watch while sleeping
- Snug fit (not too tight)
- Sensors should touch skin
- Battery 20%+ before bed

Step 2: Enable Sleep Tracking

- App → Health → Sleep Tracking
- Ensure enabled
- Check settings
- Set bedtime and wake time

Step 3: Check Battery

- Charge watch before bed
- At least 20% battery
- Low battery may disable tracking

Step 4: Check Sleep Settings

- App → Health → Sleep → Settings
- Set sleep schedule
- Enable sleep stages
- Enable smart alarm (if needed)

Step 5: Sync Data

- Open app in morning
- Pull down to sync
- Check sleep data
- May take few minutes to appear

Step 6: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May improve sleep tracking

Step 7: Contact Support

- If still not tracking sleep
- May be sensor or software issue
- Visit service center

PREVENTION:

- Wear watch to bed
- Charge before bed
- Enable sleep tracking
- Sync regularly
- Keep firmware updated

2.6 Fitness Tracking Issues

ISSUE: GPS not working or inaccurate

Symptoms:

- GPS not connecting
- Distance seems wrong
- Route not mapping correctly
- GPS signal lost frequently

Possible Causes:

- Phone not with you (connected GPS)

- GPS signal weak
- Phone GPS issue
- App not running
- Software issue

Solutions:

Step 1: Keep Phone with You

- Watch uses phone's GPS (connected GPS)
- Keep phone on you during workout
- Phone in pocket, armband, or visible
- Don't leave phone behind

Step 2: Open App Before Workout

- Open TechNova Fit app before starting
- Ensure app running in background
- GPS connects through app
- Wait for GPS lock before starting

Step 3: Wait for GPS Lock

- Before starting workout, wait 10-30 seconds
- GPS icon should appear
- Shows GPS locked
- Then start workout
- Better accuracy

Step 4: Check Phone GPS

- Open maps app on phone
- Check if GPS working

- If not, phone GPS issue
- Fix phone GPS first

Step 5: Clear View of Sky

- Go outdoors
- Away from tall buildings
- Clear view of sky
- GPS signal better outdoors

Step 6: Update App and Firmware

- Update TechNova Fit app
- Update watch firmware
- May improve GPS accuracy

Step 7: Restart Phone and Watch

- Restart both devices
- Reopen app
- Try GPS again

Step 8: Contact Support

- If still GPS issues
- May be hardware or software issue
- Visit service center

PREVENTION:

- Keep phone with you
- Open app before workout
- Wait for GPS lock
- Use outdoors with clear sky view

- Update regularly

ISSUE: Workout not tracking properly

Symptoms:

- Workout not recording
- Incomplete data
- Workout not saving
- Metrics missing

Possible Causes:

- Workout not started properly
- Low battery
- App not connected
- Software issue

Solutions:

Step 1: Start Workout Properly

- Open Workout app on watch
- Select workout type
- Set goals (if needed)
- Tap "Start"
- Wait for 3-second countdown
- Workout begins

Step 2: Check Battery

- Ensure watch 20%+ battery
- Long workouts drain battery

- Charge before long workout

Step 3: Keep Phone Connected

- Keep phone within 10 meters
- App running in background
- GPS needs phone (for outdoor workouts)

Step 4: End Workout Properly

- Don't just take off watch
- Press side button or tap end
- Confirm end workout
- Workout saves automatically

Step 5: Sync Data

- Open app after workout
- Pull down to sync
- Check workout data
- Should appear in app

Step 6: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May fix workout tracking

Step 7: Contact Support

- If still not tracking properly
- May be software or hardware issue
- Visit service center

PREVENTION:

- Start and end workouts properly
- Keep watch charged
- Keep phone connected
- Sync after workouts
- Update regularly

2.7 Notification Issues

ISSUE: Notifications not showing on watch

Symptoms:

- No notifications on watch
- Phone gets notifications, watch doesn't
- Notifications delayed
- Only some notifications showing

Possible Causes:

- Notifications disabled in app
- Do Not Disturb enabled
- App permissions not granted
- Watch not connected
- Phone notification settings

Solutions:

Step 1: Check Connection

- Ensure watch connected to phone
- App shows "Connected"

- If not, connect first

Step 2: Enable Notifications in App

- App → Devices → Your Watch → Notifications
- Toggle ON for notifications
- Select which apps to notify
- Enable needed apps (WhatsApp, calls, etc.)

Step 3: Grant Notification Permission (Phone)

Android:

- Phone Settings → Apps → TechNova Fit
- Notifications → Allow all notifications
- Or: Settings → Notifications → TechNova Fit → Allow

iOS:

- Phone Settings → Notifications → TechNova Fit
- Allow Notifications → ON
- Show in Notification Center → ON

Step 4: Check Do Not Disturb

- Swipe down on watch (quick settings)
- Check if DND (moon icon) enabled
- If enabled, disable it
- Or configure DND exceptions

Step 5: Check Phone Notification Settings

- Phone Settings → Notifications
- Ensure notifications enabled for apps

- Check app notification settings
- Enable notifications for desired apps

Step 6: Select Apps to Notify

- App → Devices → Your Watch → Notifications
- Toggle ON for each app you want:
 - Phone calls
 - Messages (SMS)
 - WhatsApp
 - Facebook
 - Instagram
 - Email
 - And others
- Toggle OFF for apps you don't want

Step 7: Restart App and Watch

- Restart TechNova Fit app
- Restart watch
- Check notifications

Step 8: Update App

- Update TechNova Fit app
- Install latest version
- May fix notification issues

Step 9: Contact Support

- If still not showing notifications
- May be software issue
- Visit service center

PREVENTION:

- Keep notifications enabled
- Keep watch connected
- Grant permissions
- Don't enable DND permanently
- Update app regularly

ISSUE: Notifications delayed or missing

Symptoms:

- Notifications arrive late
- Some notifications missing
- Notifications not consistent
- Have to check phone

Solutions:

Step 1: Keep App Running in Background

Android:

- Phone Settings → Apps → TechNova Fit
- Battery → Battery optimization → Don't optimize
- Battery → Background restriction → Disable
- App can run in background

iOS:

- Phone Settings → TechNova Fit
- Background App Refresh → ON

- App can refresh in background

Step 2: Don't Force Close App

- Don't swipe away app from recent apps
- Let app run in background
- Can sync notifications
- If force closed, may not sync

Step 3: Check Internet Connection

- Phone needs internet for notifications
- Ensure data or WiFi on
- Weak connection may delay notifications

Step 4: Restart App

- Force close app
- Reopen app
- Notifications should sync

Step 5: Update App

- Update TechNova Fit app
- Install latest version
- May fix notification issues

PREVENTION:

- Let app run in background
- Don't force close app
- Keep internet on
- Update app regularly

2.8 Calling Issues

ISSUE: Can't make or receive calls from watch

Symptoms:

- Call notifications not showing
- Can't answer calls from watch
- Can't make calls from watch
- Call audio not working

Possible Causes:

- Call notifications disabled
- Bluetooth not connected properly
- Microphone/speaker issue
- Software issue

Solutions:

Step 1: Enable Call Notifications

- App → Devices → Your Watch → Notifications
- Ensure "Phone calls" enabled
- Toggle ON
- Save settings

Step 2: Check Bluetooth Connection

- Ensure watch connected to phone
- Bluetooth connected for calls
- Not just notifications
- Check in app

Step 3: Check Call Settings

- App → Devices → Your Watch → Call Settings
- Ensure call features enabled
- Check audio routing
- Set preferences

Step 4: Test Call

- Have someone call you
- Watch should vibrate and show notification
- Tap to answer
- Should hear caller through watch
- Test both ways

Step 5: Check Microphone and Speaker

- Ensure not blocked by case or debris
- Clean microphone and speaker grilles
- Don't cover during calls

Step 6: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May fix calling issues

Step 7: Contact Support

- If still can't make/receive calls
- May be hardware issue (mic, speaker)
- Visit service center

PREVENTION:

- Enable call notifications
- Keep Bluetooth connected
- Don't block mic/speaker
- Update firmware
- Test calls regularly

ISSUE: Poor call quality

Symptoms:

- Caller can't hear you clearly
- You can't hear caller clearly
- Call audio cutting out
- Static or noise in calls

Possible Causes:

- Microphone blocked
- Speaker blocked
- Bluetooth interference
- Network issue
- Hardware issue

Solutions:

Step 1: Check Microphone

- Ensure not blocked
- Clean microphone grilles (soft brush)
- Don't cover during calls
- Speak clearly

Step 2: Check Speaker

- Ensure not blocked
- Clean speaker grilles (soft brush)
- Don't cover during calls
- Adjust volume during call

Step 3: Reduce Interference

- Stay within 10 meters of phone
- Reduce obstacles
- Move away from WiFi routers, microwaves
- Less interference

Step 4: Check Network

- Ensure phone has good network signal
- Poor network affects call quality
- Move to better coverage area

Step 5: Adjust Volume

- During call, rotate crown to adjust volume
- Higher volume may help
- Test different levels

Step 6: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- May improve call quality

Step 7: Contact Support

- If still poor call quality
- May be hardware issue (mic, speaker)
- Visit service center

PREVENTION:

- Keep mic/speaker clean
- Don't block during calls
- Stay within range
- Good network coverage
- Update firmware

2.9 Battery and Performance Issues

ISSUE: Watch slow or laggy

Symptoms:

- Watch responds slowly
- Apps take long to open
- Touch input delayed
- General sluggishness

Possible Causes:

- Too many apps running
- Low storage
- Outdated software
- Watch needs restart
- Hardware issue (rare)

Solutions:

Step 1: Restart Watch

- Settings → System → Restart
- Or hold crown 10 seconds (force restart)
- Clears memory
- Often fixes slowness

Step 2: Close Unused Apps

- Swipe up and hold (recent apps)
- Close apps not in use
- Free up memory

Step 3: Check Storage

- Settings → Storage
- Ensure at least 500 MB free
- Delete unused apps, watch faces, data
- Free up space if low

Step 4: Update Firmware

- Settings → System → Software Update
- Install latest firmware
- Updates often improve performance

Step 5: Factory Reset (Last Resort)

- Settings → System → Factory Reset
- Erases all data
- Back up important data
- Fresh start

Step 6: Contact Support

- If still slow after reset
- May be hardware issue
- Visit service center

PREVENTION:

- Restart watch weekly
- Don't install too many apps
- Keep storage clear
- Update firmware regularly
- Don't let storage get too low

=====

=====

SECTION 3: EARBUDS TROUBLESHOOTING

=====

=====

3.1 Power and Charging Issues

ISSUE: Earbuds won't turn on

Symptoms:

- No sound from earbuds
- No LED indicators
- No voice prompts
- No response to touch

Possible Causes:

- Battery completely drained

- Charging issue
- Software crash
- Hardware failure

Solutions:

Step 1: Charge the Case

- Place earbuds in charging case
- Ensure case has charge (check LED)
- If case low, charge case first
- Wait 10-15 minutes

Step 2: Charge the Earbuds

- Ensure earbuds seated properly in case
- Magnetic contacts should align
- Case LED should show earbuds charging
- Wait 15-30 minutes
- Remove earbuds, try to power on

Step 3: Check Charger and Cable

- Try different USB cable (Type-C)
- Try different USB adapter (5V/1A or 5V/2A)
- Try different power source (computer, wall, power bank)
- Ensure cable connected properly

Step 4: Clean Charging Contacts

- Use soft, dry cloth
- Clean contacts on earbuds
- Clean contacts in case

- Remove dirt, sweat, debris
- Try charging again

Step 5: Force Reset

- Place earbuds in case
- Keep lid open
- Press and hold touch sensors on both earbuds for 10-15 seconds
- LED flashes red and blue alternately
- Voice prompt: "Reset"
- Close lid, wait 10 seconds
- Remove earbuds, try to power on

Step 6: Extended Charging

- Leave earbuds in case for 1-2 hours
- Sometimes deeply discharged batteries need time
- Case should be charged
- Check periodically

Step 7: Contact Support

- If earbuds still won't turn on
- May be hardware issue (battery, charging)
- Visit service center
- Warranty claim if applicable

PREVENTION:

- Charge earbuds before completely drained
- Don't let battery go to 0% frequently
- Charge case regularly
- Use provided cable

- Keep contacts clean

ISSUE: Case not charging

Symptoms:

- Case LED not showing charging
- Case battery not increasing
- Charging very slowly
- Intermittent charging

Solutions:

Step 1: Check Cable and Connection

- Ensure USB Type-C cable connected properly
- Try different cable
- Try different USB adapter (5V/1A or 5V/2A)
- Try different power source

Step 2: Clean Charging Port

- Use soft brush or toothpick (gently)
- Clean USB Type-C port on case
- Remove lint, dust, debris
- Don't use metal objects
- Try charging again

Step 3: Check Power Source

- Use wall adapter (5V/1A or 5V/2A) for fastest charging
- Avoid low-power USB ports (some computers, USB hubs)
- Try different power outlet

- Ensure power source working

Step 4: Restart Case

- Disconnect from charger
- Wait 30 seconds
- Reconnect to charger
- Check if charging starts

Step 5: Contact Support

- If still not charging
- May be hardware issue (charging port, battery)
- Visit service center

PREVENTION:

- Use provided cable
- Use proper adapter
- Keep charging port clean
- Don't charge in dusty environments
- Handle cable gently

3.2 Connectivity Issues

ISSUE: Earbuds not connecting to phone

Symptoms:

- Earbuds not showing in Bluetooth list
- Can't pair earbuds
- Connection fails
- Only one earbud connecting

Solutions:

Step 1: Put Earbuds in Pairing Mode

- Remove earbuds from case
- If not in pairing mode, press and hold touch sensors on both earbuds
- Hold for 5 seconds
- Voice prompt: "Pairing"
- LED flashes blue rapidly
- Now in pairing mode

Step 2: Check Bluetooth on Phone

- Phone Settings → Bluetooth
- Ensure Bluetooth is ON
- Wait for Bluetooth to activate
- Scan for devices

Step 3: Bring Earbuds Close to Phone

- Keep within 1-2 meters
- Remove obstacles
- Avoid interference
- Direct line of sight helps

Step 4: Pair from Phone

- In Bluetooth settings, look for "TechNova AirBuds Pro"
- Tap on it
- If pairing request, tap "Pair" or "OK"
- Wait for connection
- Voice prompt: "Connected"

Step 5: Forget and Re-pair

- Phone Settings → Bluetooth
- Find "TechNova AirBuds Pro"
- Tap "Forget" or "Unpair"
- Put earbuds in pairing mode again
- Pair again

Step 6: Check Case and Charge

- Ensure earbuds charged (20%+)
- Charge case and earbuds
- Low battery may prevent pairing

Step 7: Reset Earbuds

- Place in case, keep lid open
- Hold touch sensors 10-15 seconds
- Reset to factory defaults
- Pair again from scratch

Step 8: Contact Support

- If still not connecting
- May be hardware issue (Bluetooth)
- Visit service center

PREVENTION:

- Keep earbuds charged
- Use pairing mode when needed
- Keep phone close during pairing
- Update firmware

- Re-pair if needed

ISSUE: Connection keeps dropping

Symptoms:

- Audio cuts out frequently
- Connection drops randomly
- Have to re-connect often
- Intermittent connection

Solutions:

Step 1: Keep Phone Close

- Stay within 10 meters
- Remove obstacles
- Phone in pocket (not bag)
- Avoid walls between phone and earbuds

Step 2: Reduce Interference

- Move away from WiFi routers
- Move away from microwaves
- Turn off other Bluetooth devices
- Less crowded RF environment

Step 3: Check Phone Bluetooth

- Restart Bluetooth on phone
- Update phone OS
- Check for Bluetooth issues with other devices
- Test with different phone

Step 4: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware
- May fix connectivity issues

Step 5: Forget and Re-pair

- Forget device in Bluetooth settings
- Re-pair from scratch
- Fresh connection

Step 6: Contact Support

- If still dropping frequently
- May be hardware issue
- Visit service center

PREVENTION:

- Keep phone within range
- Reduce interference
- Update firmware
- Re-pair if needed

3.3 Audio Quality Issues

ISSUE: Poor sound quality

Symptoms:

- Sound is muffled or unclear
- Bass weak or missing

- Highs harsh or distorted
- Not as expected

Solutions:

Step 1: Check Ear Tips Fit

- Ensure proper fit
- Try different ear tip sizes (S, M, L)
- Proper seal = better bass
- Insert properly (gentle twist)

Step 2: Clean Ear Tips and Nozzles

- Remove ear tips
- Clean ear tips (wash with mild soap and water)
- Clean nozzles (soft brush, gently)
- Remove earwax and debris
- Dry completely, reattach

Step 3: Check EQ Settings

- TechNova Audio app → Equalizer
- Try different presets (Bass Boost, Vocal, etc.)
- Or create custom EQ
- Adjust to preference

Step 4: Check Audio Source

- Test with different music/app
- High-quality audio file (not low bitrate)
- Some apps have better quality (Spotify, Apple Music, etc.)
- Check phone audio settings

Step 5: Check Bluetooth Codec

- TechNova Audio app → Settings → Codec
- Select AAC (if available) for better quality
- Or SBC (universal)
- Test both

Step 6: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware
- May improve audio quality

Step 7: Contact Support

- If still poor quality
- May be hardware issue (driver)
- Visit service center

PREVENTION:

- Use proper ear tips
- Clean ear tips and nozzles regularly
- Use good audio sources
- Update firmware
- Handle earbuds carefully

ISSUE: Audio cutting out or stuttering

Symptoms:

- Audio cuts out randomly
- Stuttering or skipping

- Intermittent sound
- Dropouts

Solutions:

Step 1: Check Connection

- Keep phone within 10 meters
- Reduce obstacles
- Reduce interference (WiFi, microwaves)
- Direct line of sight

Step 2: Check Phone

- Restart phone
- Close other apps
- Check phone not overloaded
- Update phone OS

Step 3: Check for Interference

- Move away from WiFi routers
- Move away from microwaves
- Turn off other Bluetooth devices
- Less crowded RF environment

Step 4: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware
- May fix audio issues

Step 5: Test with Different Phone

- Try with different phone
- If works fine, issue with original phone
- If still issue, earbuds may be problem

Step 6: Contact Support

- If still cutting out
- May be hardware issue
- Visit service center

PREVENTION:

- Keep phone within range
- Reduce interference
- Keep phone updated
- Update firmware
- Don't overload phone

3.4 Call Quality Issues

ISSUE: Caller can't hear me clearly

Symptoms:

- Caller says I sound muffled
- Caller says I sound distant
- Caller hears static or noise
- Caller can't hear me at all

Solutions:

Step 1: Check Microphone

- Ensure not blocked by hair, clothing, hand
- Microphone is on bottom of earbud stem
- Don't cover during calls
- Speak clearly and normally

Step 2: Clean Microphone

- Use soft brush (dry, gentle)
- Clean microphone grilles
- Remove dirt, debris, earwax
- Don't use liquids
- Don't poke with sharp objects

Step 3: Reduce Background Noise

- Move to quieter place
- Avoid windy environments
- Reduce background noise
- Call quality better in quiet

Step 4: Check Connection

- Keep phone within 10 meters
- Reduce interference
- Good Bluetooth connection
- Strong connection = better call quality

Step 5: Adjust Microphone Settings

- TechNova Audio app → Settings → Microphone
- Check noise cancellation setting
- Try different settings (High/Medium/Low)
- Adjust to preference

Step 6: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware
- May improve call quality

Step 7: Contact Support

- If still poor call quality
- May be hardware issue (microphone)
- Visit service center

PREVENTION:

- Keep microphone clean
- Don't block during calls
- Use in quiet environments
- Update firmware
- Handle earbuds carefully

3.5 Touch Control Issues

ISSUE: Touch controls not responding

Symptoms:

- Tap not registering
- Controls not working
- Delayed response
- Random activation

Solutions:

Step 1: Clean Touch Sensor

- Use soft, dry cloth
- Clean outer surface of earbuds
- Remove dirt, oil, sweat
- Dry completely
- Try controls again

Step 2: Check Touch Technique

- Use light touch (no need to press hard)
- Tap center of sensor zone (outer surface)
- Tap quickly and deliberately
- Don't brush against earbud

Step 3: Remove Wet Fingers

- Water affects touch sensitivity
- Dry fingers before using controls
- Don't use controls with wet hands
- Wipe earbuds dry if wet

Step 4: Check Gloves

- Can't use with thick gloves
- Remove gloves or use thin gloves
- Touch sensors need skin contact
- Or use phone controls

Step 5: Restart Earbuds

- Place in case, close lid
- Wait 10 seconds

- Remove earbuds
- Try controls again

Step 6: Reset Touch Controls

- TechNova Audio app → Touch Controls
- Reset to default
- Or customize controls
- May fix touch issues

Step 7: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware
- May fix touch issues

Step 8: Contact Support

- If still not responding
- May be hardware issue (touch sensor)
- Visit service center

PREVENTION:

- Keep touch sensors clean
- Use proper touch technique
- Don't use with wet fingers
- Update firmware
- Handle earbuds carefully

3.6 ANC and Sound Issues

ISSUE: ANC not working or weak

Symptoms:

- ANC not reducing noise
- ANC seems weak
- ANC not turning on
- ANC making weird sounds

Solutions:

Step 1: Check ANC Mode

- Long press right earbud (2 seconds)
- Cycles through: ANC On → ANC Off → Transparency
- Voice prompt confirms mode
- Ensure in "ANC On" mode

Step 2: Check in App

- TechNova Audio app → ANC
- Ensure ANC enabled
- Check mode (On/Off/Transparency)
- Adjust settings

Step 3: Check Ear Tips Fit

- Ensure proper fit and seal
- Try different ear tip sizes
- Proper seal = better ANC
- Insert properly (gentle twist)

Step 4: Update Firmware

- TechNova Audio app → Firmware Update

- Install latest firmware
- May fix ANC issues

Step 5: Test in Different Environment

- ANC works best with constant noise (AC, fans, airplane)
- Less effective with sudden noises
- Test in quiet room first
- Then test in noisy environment

Step 6: Contact Support

- If still not working or weak
- May be hardware issue (ANC microphones)
- Visit service center

PREVENTION:

- Use proper ear tips
- Keep firmware updated
- Clean microphone grilles
- Handle earbuds carefully

3.7 Microphone Issues

ISSUE: Microphone not picking up voice

Symptoms:

- Voice not being picked up
- Very quiet on calls
- People can't hear me
- Microphone seems dead

Solutions:

Step 1: Check Microphone Location

- Microphone on bottom of earbud stem
- Small holes/grilles
- Ensure not blocked
- Don't cover with hand

Step 2: Clean Microphone

- Use soft brush (dry, gentle)
- Clean microphone grilles
- Remove dirt, debris, earwax
- Don't use liquids
- Don't poke with sharp objects

Step 3: Check App Permissions

- TechNova Audio app → Permissions
- Ensure microphone permission granted
- Phone Settings → Apps → TechNova Audio → Permissions → Microphone → Allow

Step 4: Test with Different App

- Try different call app (WhatsApp, regular phone, etc.)
- If works in one app but not another, app issue
- If doesn't work in any app, earbuds issue

Step 5: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware

- May fix microphone issues

Step 6: Contact Support

- If still not picking up voice
- May be hardware issue (microphone)
- Visit service center

PREVENTION:

- Keep microphone clean
- Grant permissions
- Don't block during calls
- Update firmware

3.8 Battery Issues

ISSUE: Battery draining fast

Symptoms:

- Battery lasts 1-2 hours instead of 6-8
- Rapid battery drain
- Battery percentage drops quickly
- Can't use for full day

Solutions:

Step 1: Check Battery Usage

- TechNova Audio app → Battery
- See battery levels (case + earbuds)
- Check usage patterns

Step 2: Disable ANC When Not Needed

- ANC drains battery faster
- Use ANC only when needed
- Turn off ANC in quiet environments
- Use Transparency mode (less drain)

Step 3: Lower Volume

- High volume drains battery faster
- Lower volume to 50-70%
- Don't use max volume constantly
- Saves battery

Step 4: Turn Off When Not in Use

- Place earbuds in case when not using
- Case turns earbuds off
- Prevents battery drain
- Don't leave out of case

Step 5: Disable Unused Features

- Turn off:
 - 3D audio (if enabled)
 - Gaming mode (if not gaming)
 - Extra features not needed
- Saves battery

Step 6: Update Firmware

- TechNova Audio app → Firmware Update
- Install latest firmware

- May improve battery optimization

Step 7: Check Battery Health

- TechNova Audio app → Battery → Health
- Check maximum capacity
- If below 80%, battery may be degraded
- May need replacement

Step 8: Contact Support

- If still draining fast
- Battery may be degraded or defective
- Visit service center

PREVENTION:

- Use ANC only when needed
- Lower volume
- Store in case when not using
- Update firmware
- Don't drain to 0% frequently

3.9 App and Firmware Issues

ISSUE: App not detecting earbuds

Symptoms:

- App shows "Not connected"
- Can't see earbuds in app
- App can't control earbuds
- Features not working

Solutions:

Step 1: Check Connection

- Ensure earbuds connected to phone
- Bluetooth connected
- Not just paired, but actually connected
- Check in phone Bluetooth settings

Step 2: Open App

- Open TechNova Audio app
- Go to "Devices" tab
- Should show connected earbuds
- If not, tap to connect

Step 3: Grant Permissions

- App needs permissions to work
- Phone Settings → Apps → TechNova Audio → Permissions
- Grant: Location, Notifications, Bluetooth, Microphone, etc.

Step 4: Restart App

- Force close app
- Reopen app
- Check if earbuds detected

Step 5: Update App

- Play Store/App Store → Update TechNova Audio
- Install latest version
- May fix detection issues

Step 6: Reinstall App

- Delete app
- Restart phone
- Reinstall app from store
- Log in and re-pair earbuds

Step 7: Contact Support

- If still not detecting
- May be software issue
- Contact support

PREVENTION:

- Keep earbuds connected
- Grant permissions
- Update app regularly
- Reinstall if needed

=====

=====

SECTION 4: SMART HOME DEVICES TROUBLESHOOTING

=====

=====

4.1 LED Bulb Issues

ISSUE: Bulb not turning on

Symptoms:

- Bulb doesn't turn on

- No response to app
- No response to switch
- Bulb seems dead

Solutions:

Step 1: Check Power

- Ensure bulb screwed in properly
- Turn on/off wall switch
- Check if bulb receiving power
- Try different socket/fixture

Step 2: Check WiFi Connection

- Ensure 2.4GHz WiFi network available
- Bulb needs 2.4GHz (not 5GHz)
- Check WiFi password correct
- Move router closer if weak signal

Step 3: Reset Bulb

- Turn on/off wall switch 5 times quickly
- Bulb should blink (reset mode)
- Bulb in pairing mode
- Re-add in app

Step 4: Re-add in App

- TechNova Smart Home app → Add Device
- Select LED Bulb
- Follow setup process
- Connect to WiFi

Step 5: Contact Support

- If still not turning on
- May be hardware issue
- Visit service center

PREVENTION:

- Use proper voltage (220-240V in India)
- Don't exceed wattage
- Use 2.4GHz WiFi
- Keep firmware updated

4.2 Smart Plug Issues

ISSUE: Plug not responding

Solutions:

Step 1: Check Power

- Ensure plug inserted properly in socket
- Device plugged into smart plug
- Turn on/off device
- Check if power reaching device

Step 2: Check WiFi

- Ensure 2.4GHz WiFi network
- Check WiFi connection
- Reconnect if needed

Step 3: Reset Plug

- Hold reset button for 5 seconds
- LED should blink
- Plug in reset mode
- Re-add in app

Step 4: Contact Support

- If still not responding
- May be hardware issue
- Visit service center

4.3 WiFi Router Issues

ISSUE: No internet or slow speeds

Solutions:

Step 1: Restart Router

- Unplug router from power
- Wait 30 seconds
- Plug back in
- Wait 2-3 minutes for boot
- Check internet

Step 2: Check Connections

- Ensure all cables connected properly
- Check power cable
- Check Ethernet cables (if used)
- Check ISP connection

Step 3: Check Placement

- Place router in central location
- Away from walls and obstacles
- Away from microwaves, cordless phones
- Elevated position (not on floor)

Step 4: Update Firmware

- TechNova WiFi app → Settings → Firmware Update
- Install latest firmware
- May fix issues

Step 5: Contact ISP

- If still no internet
- May be ISP issue
- Contact your internet provider

4.4 Webcam Issues

ISSUE: Webcam not working

Solutions:

Step 1: Check Connection

- Ensure USB cable connected properly
- Try different USB port
- Check if computer detects webcam
- Try different computer

Step 2: Check Permissions

- Grant camera permission to apps
- Check app settings
- Ensure webcam selected as camera

Step 3: Update Drivers

- Update webcam drivers (if needed)
- Check manufacturer website
- Install latest drivers

Step 4: Contact Support

- If still not working
- May be hardware issue
- Visit service center

=====

=====

SECTION 5: MOBILE ACCESSORIES TROUBLESHOOTING

=====

=====

5.1 Power Bank Issues

ISSUE: Power bank not charging devices

Solutions:

Step 1: Check Power Bank Battery

- Press power button to check battery level
- LED indicators show charge

- If low, charge power bank first

Step 2: Check Cable

- Ensure cable connected properly
- Try different cable
- Try different USB port on power bank
- Ensure cable not damaged

Step 3: Check Device

- Ensure device supports charging from power bank
- Check device charging port
- Try charging different device

Step 4: Contact Support

- If still not charging
- May be hardware issue
- Visit service center

5.2 Charger Issues

ISSUE: Charger not charging device

Solutions:

Step 1: Check Connections

- Ensure charger plugged in properly
- Ensure cable connected to charger and device
- Check power outlet working
- Try different outlet

Step 2: Check Cable

- Try different cable
- Ensure cable not damaged
- Use good quality cable

Step 3: Check Charger

- Try charging different device
- If works, device issue
- If not, charger issue

Step 4: Contact Support

- If still not charging
- May be hardware issue
- Visit service center

5.3 Cable Issues

ISSUE: Cable not working

Solutions:

Step 1: Check Connections

- Ensure connected properly at both ends
- Try different ports
- Check for debris in ports

Step 2: Inspect Cable

- Check for visible damage

- Check for fraying or cuts
- If damaged, replace cable

Step 3: Try Different Device/Port

- Try with different device
- Try with different port
- If works, original device/port issue
- If not, cable issue

Step 4: Replace Cable

- If cable damaged or not working
- Replace with new cable
- Use good quality cable

=====

=====

SECTION 6: ADVANCED TROUBLESHOOTING

=====

=====

6.1 Factory Reset Procedures

SMARTWATCH:

Soft Reset (Restart):

- Settings → System → Restart
- Or hold crown 10 seconds
- Clears memory
- Fixes minor issues

Factory Reset (Hard Reset):

- Settings → System → Factory Reset
- Confirm reset
- Enter PIN (if set)
- Erases all data
- Returns to factory settings
- Use as last resort

EARBUDS:

Factory Reset:

- Place earbuds in case
- Keep lid open
- Press and hold touch sensors on both earbuds
- Hold for 10-15 seconds
- LED flashes red and blue alternately
- Voice prompt: "Reset"
- Release touch sensors
- Close lid
- Wait 10 seconds
- Remove earbuds, pair again
- Erases all settings and pairings

SMART HOME:

LED Bulb Reset:

- Turn on/off wall switch 5 times quickly
- Bulb should blink
- Reset complete

- Re-add in app

Smart Plug Reset:

- Hold reset button for 5 seconds
- LED should blink
- Reset complete
- Re-add in app

WiFi Router Reset:

- Hold reset button for 10 seconds
- Router restarts
- Factory settings
- Re-setup router

6.2 Firmware Update Issues

ISSUE: Update failing or stuck

Solutions:

Step 1: Check Battery

- Ensure device 50%+ battery
- Low battery may prevent update
- Charge device first

Step 2: Check Internet

- Ensure stable internet connection
- WiFi or mobile data
- Don't update on weak connection

Step 3: Keep Device Close to Phone

- During update, keep device close to phone
- Don't move away
- Ensure strong Bluetooth connection

Step 4: Don't Interrupt Update

- Don't close app during update
- Don't restart device during update
- Wait for update to complete
- May take 5-15 minutes

Step 5: Retry Update

- If update fails, try again
- Sometimes update fails once, succeeds next time
- Ensure all conditions met

Step 6: Contact Support

- If update repeatedly fails
- May be software or hardware issue
- Contact support

6.3 Hardware Diagnostics

SMARTWATCH:

Display Test:

- Settings → Diagnostics → Display
- Tests touch response

- Tests display colors
- Reports any issues

Sensor Test:

- Settings → Diagnostics → Sensors
- Tests heart rate sensor
- Tests accelerometer
- Tests other sensors
- Reports failures

Battery Test:

- Settings → Diagnostics → Battery
- Tests battery health
- Tests charging
- Reports capacity

EARBUDS:

Audio Test:

- TechNova Audio app → Diagnostics
- Tests left and right audio
- Tests microphone
- Reports issues

Battery Test:

- TechNova Audio app → Battery → Health
- Tests battery health
- Reports capacity
- Shows cycle count

6.4 Error Codes and Messages

COMMON ERROR CODES:

E001: Battery Low

- Charge device
- Use provided charger
- If persists, battery issue

E002: Connection Failed

- Check Bluetooth
- Re-pair device
- If persists, hardware issue

E003: Sensor Error

- Clean sensor
- Restart device
- If persists, sensor issue

E004: Charging Error

- Clean contacts
- Check charger
- If persists, charging port issue

E005: Firmware Error

- Retry update
- Use different power source
- If persists, contact support

E006: Overheating

- Stop using device
- Let cool down
- Avoid heavy use while charging
- If persists, hardware issue

E007: Storage Full

- Delete unused apps/data
- Clear cache
- Free up space

E008: Bluetooth Error

- Restart Bluetooth
- Re-pair device
- If persists, Bluetooth hardware issue

=====

=====

CONTACTING TECHNOVA SUPPORT

=====

=====

WHEN TO CONTACT:

Hardware Issues:

- Physical damage
- Water damage
- Charging issues
- Battery issues

- Sensor failures
- Display issues
- Button failures

Persistent Software Issues:

- Issues persist after factory reset
- Can't update firmware
- Repeated crashes
- Boot loop
- Data loss
- App won't work

Performance Issues:

- Severe battery drain
- Overheating (normal use)
- Extremely slow or unresponsive
- Frequent disconnections
- Poor audio quality (hardware)

HOW TO CONTACT:

Phone:

- 1800-123-4567 (Toll-free)
- Mon-Sat: 9 AM - 9 PM
- Sun: 10 AM - 6 PM

Email:

- support@technovaelectronics.com
- Include: Model, issue, steps tried, purchase date, invoice

Website:

- www.technovaelectronics.com/support
- Live chat
- Support ticket
- FAQs
- Troubleshooting guides

In-App:

- TechNova apps → Help & Support
- Chat with support
- Create ticket
- FAQs

Service Centers:

- Find nearest: Website → Service Centers
- Walk-in or appointment
- Carry device and invoice
- Diagnosis and repair

WHAT TO PROVIDE:

- Product model
- Serial number
- Purchase date
- Invoice number
- Issue description
- When it started
- Steps already tried

- Photos/videos (if applicable)
- Your contact details

=====

=====

Thank you for choosing TechNova!

=====

=====

=====

=====

END OF TROUBLESHOOTING GUIDE

=====

=====