

SOP-MNT-050 Centrifugal Pump Mechanical Seal Replacement

Revision A - Owner: Technical Services - Classification: Internal

1. Preparation

Obtain a work permit, isolate suction and discharge valves, drain and depressurise the casing, and lock out the motor at the switchgear.

2. Replacement

Measure shaft run-out before fitting the new seal. Run-out shall not exceed 0.05 mm TIR. Clean the seal faces with lint-free cloth and never touch them with bare hands.

3. Commissioning

Vent the seal chamber before start-up. Check for leakage for the first 30 minutes of operation.