

Clawdy: Anthropic Status Monitor

Provisioning & Setup

1. Power: Supply standard USB power.
2. Connect: Join the Clawdy_Setup Wi-Fi from any client.
3. Provision: Pass local Wi-Fi credentials via the captive portal (VPN unsupported)

UI Telemetry

- Blinking Eyes: Systems operational.
- 'X' Eyes: Active outage (degraded service scrolls below).
- Angry Brows: Systemic error (e.g., firewall block, routing timeout).

Hardware Toggles

Ensure the microcontroller is fully pushed back into the device. The two buttons are very small and near the back of the device.

- [R] Pinhole: Reboot device
- [B] Pinhole (Wipe): Tap [R]. At the startup prompt, hold [B] for 2 seconds to wipe network config.
 - Do this to change wifi settings if you want to connect Clawdy to a new network

