




Specs

Item name:	TAKER H743 BT Flight Controller
MCU:	STM32H743
IMU:	MPU6000 + ICM42688-P(dual gyro)
Black Box:	512M onboard
Bluetooth:	Supported
Barometer:	Supported
BEC Output:	5V@3A,12V@2.5A dual BEC
Target:	GEPRC_TAKER_H743
Size:	38.5x38.5mm
Mounting:	30.5x30.5mm
Input Voltage:	3-6S LiPo
UART Ports:	7 groups (UART3 fixed for Bluetooth)



Interface definition






Optional VTX voltage, the default onboard output is 12V,
If the VTX requires BAT voltage, connect the BAT and + pad



Super buzzer



ESC



The MPU6000 is the first gyro
The ICM42688-P is the second gyro
(BF and INAV firmware support only one gyro)


Board and Sensor Alignment

Roll Degrees: 0 Pitch Degrees: 0 Yaw Degrees: 0


First: GYRO/ACCEL CW 270* First GYRO CW 0* Second GYRO

First: MAG Alignment


Receiver



GND
5V
R2
T2



TBS Nano RX



GEPRC ELRS

- Setup
- Ports**
- Configuration
- Power&Battery
- Failsafe

Identifier	Configuration/MSP	Serial RX
USB VCP	☒ 115200 ▼	☐
UART1	☐ 115200 ▼	☐
UART2	☒ 115200 ▼	☒

Receiver

Serial(Via UART) ▼ Receiver Mode

•The UART for the receiver must be set to 'Serial RX' (in the Ports tab)
•Select the correct data format from the drop - down, below:

CRSF ▼ Serial Receiver Provider


Identifier	Configuration/MSP	Serial RX
USB VCP	☐ 115200 ▼	☐
UART1	☒ 115200 ▼	☐
UART2	☐ 115200 ▼	☒

Receiver


Serial (Via UART) ▼ Receiver Mode

Note: Remember to configure a Serial Port(via Ports tab) and choose a Ser Receiver Provider when using RX_SERIAL feature.

SBUS ▼ Serial Receiver Provider



If using an external receiver, disconnect this cable




CLI Commands:

```
set osd_displayport_device = MSP
set vcd_video_system = HD
SAVE
```

to enable high-definition OSD transmission

Analog VTX



Optional VTX voltage, the default onboard output is 12V,
If the VTX requires BAT voltage, connect the BAT and ⊕ pad

Identifier	Configuration/MSP		Peripherals	
USB VCP	☒ 115200 ▼		Disabled ▼	AUTO ▼
UART1	☐ 115200 ▼		VTX,IRC Tamp ▼	AUTO ▼
UART2	☐ 115200 ▼		Disabled ▼	AUTO ▼

GPS


GPS



SDA
SCL
RX
TX
5V
GND

SDA and SCL are for the compass and external barometer

SDA
SCL
T4
R4
5V
GND



GPS



GPS

GPS for navigation and telemetry



Note: Remember to configure a Serial Port(via Ports tab)when using GPS feature.

UBLOX

Protocol



Auto Baud



Auto Config



Use Galileo



Set Home Point Once





None

Ground Assistance Type

Identifier	Configuration/MSP		Sensor Input	
UART3	☐ 115200 ▼		Disabled ▼	AUTO ▼
UART4	☐ 115200 ▼		GPS ▼	115200 ▼

Bluetooth



Identifier	Configuration/MSP		Serial RX
USB VCP	☒	115200 ▾	☐
UART1	☒	115200 ▾	☐
UART2	☐	115200 ▾	☒
UART3	☒	115200 ▾	☐

CAUTION:

- 1 All wires should try to avoid the gyroscope, so as not to affect the normal work of the gyroscope.
 - 2 After soldering, please check that all connections are correct to avoid damage after power-on.
-



facebook

facebook.com/geprc



Official
website

www.geprc.com



Instagram

instagram.com/geprc



You
Tube

youtube.com/geprc




Manual


geprc.com/support

规格

产品名称:	TAKER H743 BT 飞控
MCU:	STM32H743
IMU:	MPU6000 + ICM42688-P(双陀螺仪)
黑匣子:	512M板载
蓝牙:	支持
气压计:	支持
BEC输出:	5V@3A,12V@2.5A双路输出
固件目标:	GEPRC_TAKER_H743
最大外尺寸:	38.5x38.5mm
安装孔距:	30.5x30.5mm
输入电压:	3-6S LiPo
UART串口:	7组(UART3固定用于蓝牙)



接口定义






超级BB响




ESC




第一个陀螺仪为MPU6000
第二个陀螺仪为ICM42688-P
(BF和INAV暂不支持双陀螺仪同时运行)




接收机



GND
5V
R2
T2



TBS Nano RX



GPRC ELRS



标识符	设置/MSP	串行数字接收机
USB VCP	☒ 115200 ▼	☐
UART1	☐ 115200 ▼	☐
UART2	☒ 115200 ▼	☒

接收机

串行接收机 (通过UART) ▼
 接收机模式

• 必须将接收机对应的 UART 设置为“数字串行接收机”(在端口页面)
 • 从下拉列表中选择正确的数据格式, 如下:

CRSF ▼
 串行数字接收机协议

高清图传


标识符	设置/MSP	串行数字接收机
USB VCP	☐ 115200 ▼	☐
UART1	☒ 115200 ▼	☐
UART2	☐ 115200 ▼	☒

接收机


Serial (Via UART) ▼ 接收机模式

注意: 使用串行接收机时, 请选择串口接收机类型, 并在串口页面设置相应的串口。

SBUS ▼ 串行数字接收机协议




如果使用外置接收机, 请断开此线



CLI命令行输入:
set osd_displayport_device = MSP
set vcd_video_system = HD
SAVE
以开启高清图传OSD回传

模拟图传



标识符	设置/MSP		外设	
USB VCP	☒ 115200 ▾		已禁用 ▾	AUTO ▾
UART1	☐ 115200 ▾		VTX,IRC Tamp ▾	AUTO ▾
UART2	☐ 115200 ▾		已禁用 ▾	AUTO ▾

GPS


GPS



SDA
SCL
RX
TX
5V
GND

SDA SCL用于罗盘和外界气压计使用

SDA
SCL
T4
R4
5V
GND



GPS



GPS

启用GPS导航



注意：使用GPS之前需要先在串口页面设置一个串口。

UBLOX

协议



自动波特率



自动设置



使用Galileo系统



设置单次返航点




自动检测

地面辅助类型

标识符	设置/MSP		传感器输入	
UART3	☐ 115200 ▼		已禁用 ▼	AUTO ▼
UART4	☐ 115200 ▼		GPS ▼	115200 ▼

蓝牙



标识符	设置/MSP	串行数字接收机
USB VCP	 115200 ▾	
UART1	 115200 ▾	
UART2	 115200 ▾	
UART3	 115200 ▾	

注意事项:

- 1 焊接的电线尽量避开陀螺仪，以免影响陀螺仪正常工作
 - 2 装机后请仔细检查连线是否正确，保持飞控整体干净 无多余焊锡残留
-

格普官方QQ群: 499699918

格普官方微信:



wechat

格普淘宝:



geprc.taobao.com

格普官网:



www.geprc.com