

Qumulo qq CLI Command Guide



Copyright © 2026 Qumulo, Inc.

Table of Contents

ad

ad_cancel	17
ad_distinguished_name_to_account	18
ad_expand_groups	19
ad_get_advanced_settings	20
ad_gid_to_sids	21
ad_join	22
ad_leave	24
ad_list	25
ad_name_to_accounts	26
ad_poll	27
ad_reconfigure	28
ad_set_advanced_settings	30
ad_sid_to_account	31
ad_sid_to_gid	32
ad_sid_to_uid	33
ad_sid_to_username	34
ad_uid_to_sids	35
ad_username_to_sids	36

add

add_nodes	37
add_object_storage_uris	38

audit

audit_create_destination	39
audit_delete_destination	40
audit_get_destination	41
audit_get_destination_status	42
audit_list_destinations	43
audit_modify_destination	44
audit_set_destination	45

auth

auth_add_group.....	46
auth_add_user.....	47
auth_assign_role.....	48
auth_clear_cache.....	49
auth_create_access_token.....	50
auth_create_role.....	51
auth_delete_access_token.....	53
auth_delete_group.....	54
auth_delete_role.....	55
auth_delete_user.....	56
auth_expand_identity.....	57
auth_find_identity.....	59
auth_get_access_token.....	61
auth_get_user_defined_mappings.....	62
auth_list_access_tokens.....	63
auth_list_group.....	64
auth_list_groups.....	65
auth_list_privileges.....	66
auth_list_role.....	68
auth_list_roles.....	69
auth_list_user.....	70
auth_list_users.....	71
auth_mod_group.....	72
auth_mod_user.....	73
auth_modify_access_token.....	74
auth_modify_role.....	75
auth_set_password.....	76
auth_set_user_defined_mappings.....	77
auth_unassign_role.....	78

authoritative

authoritative_dns_get_settings.....	79
authoritative_dns_modify_settings.....	80

capacity

capacity_clamp_get	81
capacity_clamp_set	82
capacity_history_files_get	83
capacity_history_get	84

change

change_password	85
-----------------------	----

checksumming

checksumming_get_status	86
-------------------------------	----

cluster

cluster_conf	87
cluster_create	88
cluster_slot_set_config	90
cluster_slots	91

container

container_restart	92
container_restart_cluster	93

create

create_object_backed_cluster	94
------------------------------------	----

current

current_activity_get	96
----------------------------	----

data

data_core_cluster_create	97
--------------------------------	----

dns

dns_clear_cache	98
dns_get_lookup_overrides	99
dns_get_system_config	100
dns_modify_system_config	101
dns_resolve_hostnames	102
dns_resolve_ips	103
dns_set_lookup_overrides	104

encryption

encryption_get_key_store	105
encryption_get_status.....	106
encryption_set_key_store	107

floating

floating_ip_allocation.....	108
-----------------------------	-----

fs

fs_acl_explain_chmod	109
fs_acl_explain_posix_mode	110
fs_acl_explain_rights.....	111
fs_copy.....	112
fs_create_dir	113
fs_create_file	114
fs_create_link.....	115
fs_create_symlink	116
fs_create_unix_file.....	117
fs_delete.....	118
fs_delete_user_metadata.....	119
fs_fetch_file.....	120
fs_fetch_tree.....	121
fs_file_get_attr	122
fs_file_modify_lock	124
fs_file_samples.....	126
fs_file_set_attr.....	127
fs_file_set_smb_attrs.....	129
fs_get_acl	130
fs_get_atime_settings.....	131
fs_get_notify_settings.....	132
fs_get_permissions_settings	133
fs_get_stats.....	134
fs_get_user_metadata	135
fs_list_lock_waiters_by_client.....	136
fs_list_lock_waiters_by_file	137
fs_list_locks	138
fs_list_named_streams.....	139
fs_list_user_metadata.....	140
fs_modify_acl.....	141
fs_notify.....	142
fs_punch_hole	143
fs_read.....	144
fs_read_dir	145
fs_read_dir_aggregates.....	148
fs_release_nlm_lock.....	149

fs_release_nlm_locks_by_client	150
fs_remove_stream.....	151
fs_rename	152
fs_resolve_paths	153
fs_security_add_key	154
fs_security_delete_key	155
fs_security_get_key	156
fs_security_get_key_replace_challenge	157
fs_security_get_key_usage.....	158
fs_security_list_keys.....	159
fs_security_modify_key.....	160
fs_security_replace_key.....	161
fs_set_acl	162
fs_set_atime_settings.....	163
fs_set_notify_settings.....	164
fs_set_permissions_settings.....	165
fs_set_user_metadata	166
fs_try_resolve_paths.....	167
fs_unlink.....	168
fs_walk_tree.....	169
fs_write.....	172

ftp

ftp_get_status.....	174
ftp_modify_settings.....	175

get

get_object_backed_nodes.....	176
get_object_storage_uris	177
get_vpn_keys.....	178

halt

halt_cluster	179
--------------------	-----

help

help	180
------------	-----

identity

identity_attributes_get	181
identity_attributes_set	182

install

install_vpn_keys	183
------------------------	-----

kerberos

kerberos_delete_keytab	184
kerberos_get_keytab	185
kerberos_get_settings	186
kerberos_modify_settings	187
kerberos_set_keytab	188

ldap

ldap_get_settings	189
ldap_get_status	190
ldap_login_name_to_gid_numbers	191
ldap_login_name_to_uid_numbers	192
ldap_set_settings	193
ldap_uid_number_to_login_name	195
ldap_update_settings	196

license

license_get_status	198
--------------------------	-----

login

login	199
-------------	-----

logout

logout	200
--------------	-----

metrics

metrics_get	201
-------------------	-----

modify

modify_object_backed_cluster_membership	202
---	-----

monitoring

monitoring_conf	204
monitoring_status_get	205

multitenancy

multitenancy_create_tenant	206
multitenancy_delete_tenant	208
multitenancy_get_tenant	209
multitenancy_list_tenants	210
multitenancy_modify_tenant	211
multitenancy_nfs_delete_settings	213
multitenancy_nfs_get_global_settings	214
multitenancy_nfs_get_settings	215
multitenancy_nfs_list_settings	216
multitenancy_nfs_modify_global_settings	217
multitenancy_nfs_modify_settings	219
multitenancy_smb_delete_settings	221
multitenancy_smb_get_global_settings	222
multitenancy_smb_get_settings	223
multitenancy_smb_list_settings	224
multitenancy_smb_modify_global_settings	225
multitenancy_smb_modify_settings	227

network

network_backend_interfaces	229
network_create_network	230
network_frontend_interfaces	231
network_get_config	232
network_list_connections	233
network_modify_interface	235
network_modify_network	236
network_put_config	237
network_remove_network	238
network_status	239

nexus

nexus_get_config	240
nexus_get_registration	241
nexus_set_config	242
nexus_set_registration	243

nfs

nfs_add_export.....	244
nfs_delete_export	248
nfs_get_export.....	249
nfs_get_settings.....	250
nfs_list_exports.....	251
nfs_mod_export.....	252
nfs_mod_export_host_access.....	254
nfs_modify_settings	255

node

node_chassis_status_get.....	256
node_state_get	257

nodes

nodes_list.....	258
-----------------	-----

object

object_backed_fault_tolerance_get.....	260
object_portal_create_bridge	261
object_portal_delete_bridge	263
object_portal_get_bridge	264
object_portal_list_bridges.....	265
object_portal_refresh	266

portal

portal_accept_hub	267
portal_authorize_hub_root	268
portal_create	269
portal_delete_hub	271
portal_delete_spoke	272
portal_delete_spoke_root	273
portal_deny_hub_root	274
portal_get_eviction_settings	275
portal_get_filesystem	276
portal_get_hub	277
portal_get_spoke	278
portal_list	279
portal_list_filesystems	280
portal_list_hubs	281
portal_list_quorum_events	282
portal_list_spokes	283
portal_modify_hub	284
portal_modify_spoke	285
portal_ping	286
portal_propose_spoke_root	287
portal_set_eviction_settings	288

protection

protection_status_get	289
-----------------------------	-----

quota

quota_create_quota	290
quota_delete_quota	291
quota_get_quota	292
quota_list_quotas	293
quota_update_quota	294

raw

raw	295
-----------	-----

reboot

reboot_pause296

reboot_resume.....297

reboot_start..... 298

reboot_status.....299

replace

replace_nodes.....300

replication

replication_abort_object_replication	301
replication_abort_replication.....	302
replication_add_blackout_window.....	303
replication_authorize	304
replication_create_object_relationship.....	305
replication_create_source_relationship	307
replication_delete_blackout_windows.....	308
replication_delete_object_relationship.....	309
replication_delete_source_relationship	310
replication_delete_target_relationship	311
replication_get_object_relationship.....	312
replication_get_object_relationship_status.....	313
replication_get_source_relationship.....	314
replication_get_source_relationship_status	315
replication_get_target_relationship_status	316
replication_link_snapshot_policy.....	317
replication_list_object_relationship_statuses.....	318
replication_list_object_relationships	319
replication_list_queued_snapshots.....	320
replication_list_source_relationship_statuses	321
replication_list_source_relationships	322
replication_list_target_relationship_statuses	323
replication_make_target_writable	324
replication_modify_source_relationship	325
replication_reconnect_target_relationship.....	326
replication_release_queued_snapshot.....	327
replication_replicate.....	328
replication_reverse_target_relationship.....	329
replication_set_snapshot_policy_replication_mode	330
replication_set_target_relationship_lock.....	331
replication_start_object_relationship	332
replication_unlink_snapshot_policy	333

restriper

restriper_status.....	334
-----------------------	-----

rotate

rotate_encryption_keys.....	335
-----------------------------	-----

s3

s3_abort_upload.....	336
s3_add_bucket.....	337
s3_bucket_policy_explain_access.....	338
s3_create_access_key.....	341
s3_delete_access_key.....	342
s3_delete_bucket.....	343
s3_delete_bucket_policy.....	344
s3_get_bucket.....	345
s3_get_bucket_policy.....	346
s3_get_settings.....	347
s3_list_access_keys.....	348
s3_list_buckets.....	349
s3_list_uploads.....	350
s3_modify_bucket.....	351
s3_modify_bucket_policy.....	353
s3_modify_settings.....	355
s3_set_bucket_policy.....	356

saml

saml_get_settings.....	357
saml_modify_settings.....	358

set

set_cluster_conf.....	359
set_monitoring_conf.....	360
set_node_identify_light.....	362

smb

smb_add_share.....	363
smb_close_file_handle.....	367
smb_close_sessions	368
smb_delete_share.....	369
smb_get_settings.....	370
smb_list_file_handles	371
smb_list_sessions	372
smb_list_share.....	373
smb_list_shares	375
smb_mod_share.....	376
smb_mod_share_permissions.....	380
smb_modify_settings	381

snapshot

snapshot_create_policy.....	384
snapshot_create_snapshot.....	385
snapshot_delete_policy	386
snapshot_delete_snapshot	387
snapshot_diff.....	388
snapshot_file_diff	389
snapshot_get_policy	390
snapshot_get_policy_status	391
snapshot_get_status.....	392
snapshot_get_total_used_capacity.....	393
snapshot_get_unlock_challenge	394
snapshot_list_policies	395
snapshot_list_policy_statuses	396
snapshot_list_statuses.....	397
snapshot_lock_snapshot	398
snapshot_modify_policy.....	399
snapshot_modify_snapshot.....	400
snapshot_unlock_snapshot.....	401

ssl

ssl_delete_ca_certificate	402
ssl_get_ca_certificate	403
ssl_get_ciphers	404
ssl_modify_ca_certificate	405
ssl_modify_certificate	406
ssl_modify_ciphers	407

sso

sso_login	408
-----------------	-----

static

static_ip_allocation	409
----------------------------	-----

stratus

stratus_cluster_create	410
------------------------------	-----

time

time_get	412
time_list_timezones	413
time_reset_configuration	414
time_series_get	415
time_set	416
time_status	417

tree

tree_delete_cancel	418
tree_delete_create	419
tree_delete_get	420
tree_delete_list	421
tree_delete_restart	422

unconfigured

unconfigured_nodes_list	423
unconfigured_upgrade_config	424
unconfigured_upgrade_config_set	425
unconfigured_upgrade_status	426

unprotected

unprotected_edge_cluster_create	427
---------------------------------------	-----

upgrade

upgrade_blocked	428
upgrade_cluster	429
upgrade_status.....	430
upgrade_verify_image	431

version

version	432
---------------	-----

web

web_ui_get_settings	433
web_ui_modify_settings.....	434

who

who_am_i.....	435
---------------	-----

qq ad_cancel

This section explains how to use the `qq ad_cancel` command.

Description

Cancel current AD join/leave operation and clear errors

Usage

```
qq ad_cancel [-h] [--no-wait]
```

Flags

Flag Name	Required	Description
<code>--no-wait</code>	No	Do not wait for the operation to complete

qq ad_distinguished_name_to_account

This section explains how to use the `qq ad_distinguished_name_to_account` command.

Description

Get all account info for a distinguished name

Usage

```
qq ad_distinguished_name_to_account [-h] -d DISTINGUISHED_NAME
```

Flags

Flag Name	Required	Description
<code>-d</code>	Yes	Get the account with this DN (e.g. CN=user,DC=example,DC=com

qq ad_expand_groups

This section explains how to use the `qq ad_expand_groups` command.

Description

Get the SIDs of all the groups that the given SID is a member of (including nested groups).

Usage

```
qq ad_expand_groups [-h] -s SID
```

Flags

Flag Name	Required	Description
<code>-s</code>	Yes	Get the SIDS of all the groups this SID belongs (including all nested groups).

qq ad_get_advanced_settings

This section explains how to use the `qq ad_get_advanced_settings` command.

Description

Get advanced Active Directory settings

Usage

```
qq ad_get_advanced_settings [-h]
```

qq ad_gid_to_sids

This section explains how to use the `qq ad_gid_to_sids` command.

Description

Get SIDs from GID

Usage

```
qq ad_gid_to_sids [-h] -g GID
```

Flags

Flag Name	Required	Description
<code>-g</code>	Yes	Get the SIDs that corresponds to this GID

qq ad_join

This section explains how to use the `qq ad_join` command.

Description

Join an Active Directory Domain

Usage

```
qq ad_join [-h] -d DOMAIN -u USERNAME [-p PASSWORD] [--domain-netbios DOMAIN_NETBIO  
S] [-o OU] [--disable-search-trusted-domains] [--use-ad-posix-attributes] [--base-d  
n BASE_DN] [--domain-controllers DOMAIN_CONTROLLERS] [--no-wait]
```

Flags

Flag Name	Required	Description
<code>-d</code>	Yes	Fully-qualified name of Active Directory Domain
<code>-u</code>	Yes	Domain user to perform the operation, e.g., Administrator
<code>-p</code>	No	Domain password (insecure, visible via ps)
<code>--domain-netbios</code>	No	NetBIOS name of the domain. By default, the first part of the domain name is used.
<code>-o</code>	No	Organizational Unit to join to
<code>--disable-search-trusted-domains</code>	No	Disallows the cluster from using trusted domains for user information. Disabling may prevent the cluster from finding all relevant user and group membership data for authenticated users.
<code>--use-ad-posix-attributes</code>	No	Use AD POSIX attributes.
<code>--base-dn</code>	No	When using LDAP POSIX extensions, query using this base DN

<code>--domain-controllers</code>	No	A single fully qualified domain name (FQDN) or a comma-separated list of FQDNs of the domain controllers (DCs) to use for LDAP queries and Netlogon authentication (for example, dc1.example.com). When you use this flag, the specified FQDN overrides the system's default discovery of DCs for the joined domain. When you specify multiple FQDNs in order of preference, Qumulo Core uses only one DC at a time and falls back to the remaining DCs if one of the FQDNs becomes unreachable.
<code>--no-wait</code>	No	Do not wait for the operation to complete

qq ad_leave

This section explains how to use the `qq ad_leave` command.

Description

Leave an Active Directory Domain

Usage

```
qq ad_leave [-h] -d DOMAIN [-u USERNAME] [-p PASSWORD] [--no-wait]
```

Flags

Flag Name	Required	Description
<code>-d</code>	Yes	Fully-qualified name of Active Directory Domain
<code>-u</code>	No	Domain user to perform the operation, e.g., Administrator
<code>-p</code>	No	Domain password (insecure, visible via ps)
<code>--no-wait</code>	No	Do not wait for the operation to complete

qq ad_list

This section explains how to use the `qq ad_list` command.

Description

Get Active Directory configuration and connection status

Usage

```
qq ad_list [-h]
```

qq ad_name_to_accounts

This section explains how to use the `qq ad_name_to_accounts` command.

Description

Get all account info for a sAMAccountName

Usage

```
qq ad_name_to_accounts [-h] -n NAME
```

Flags

Flag Name	Required	Description
<code>-n</code>	Yes	Get account info for this sAMAccountName

qq ad_poll

This section explains how to use the `qq ad_poll` command.

Description

Get status of a join, leave, or reconfigure operation with Active Directory

Usage

```
qq ad_poll [-h]
```

qq ad_reconfigure

This section explains how to use the `qq ad_reconfigure` command.

Description

Reconfigure Active Directory POSIX Attributes

Usage

```
qq ad_reconfigure [-h] [--enable-search-trusted-domains | --disable-search-trusted-domains] [--enable-ad-posix-attributes | --disable-ad-posix-attributes] [--base-dn BASE_DN] [--domain-controllers DOMAIN_CONTROLLERS] [--no-wait]
```

Flags

Flag Name	Required	Description
<code>--enable-search-trusted-domains</code>	No	Allows the cluster to search trusted domains for user information.
<code>--disable-search-trusted-domains</code>	No	Disallows the cluster from using trusted domains for user information. Disabling may prevent the cluster from finding all relevant user and group membership data for authenticated users.
<code>--enable-ad-posix-attributes</code>	No	Use AD POSIX attributes.
<code>--disable-ad-posix-attributes</code>	No	Do not use AD POSIX attributes.
<code>--base-dn</code>	No	When using AD POSIX extensions, query using this base DN

<code>--domain-controllers</code>	No	A single fully qualified domain name (FQDN) or a comma-separated list of FQDNs of the domain controllers (DCs) to use for LDAP queries and Netlogon authentication (for example, dc1.example.com). When you use this flag, the specified FQDN overrides the system's default discovery of DCs for the joined domain. When you specify multiple FQDNs in order of preference, Qumulo Core uses only one DC at a time and falls back to the remaining DCs if one of the FQDNs becomes unreachable.
<code>--no-wait</code>	No	Do not wait for the operation to complete

qq ad_set_advanced_settings

This section explains how to use the `qq ad_set_advanced_settings` command.

Description

Modify advanced Active Directory settings

Usage

```
qq ad_set_advanced_settings [-h] [--signing {off,prefer,require}] [--sealing {off,prefer,require}] [--crypto {off,prefer,require}]
```

Flags

Flag Name	Required	Description
<code>--signing</code>	No	Configure DCERPC signing to be off, prefer signing, or require signing. The default is to prefer signing.
<code>--sealing</code>	No	Configure DCERPC sealing to be off, prefer sealing, or require sealing. The default is to prefer sealing.
<code>--crypto</code>	No	Configure DCERPC to not use encryption, prefer AES encryption, or require AES encryption. The default is to prefer AES encryption.

qq ad_sid_to_account

This section explains how to use the `qq ad_sid_to_account` command.

Description

Get all account info for a SID

Usage

```
qq ad_sid_to_account [-h] -s SID
```

Flags

Flag Name	Required	Description
<code>-s</code>	Yes	Get the GID that corresponds to this SID

qq ad_sid_to_gid

This section explains how to use the `qq ad_sid_to_gid` command.

Description

Get GID from SID

Usage

```
qq ad_sid_to_gid [-h] -s SID
```

Flags

Flag Name	Required	Description
<code>-s</code>	Yes	Get the GID that corresponds to this SID

qq ad_sid_to_uid

This section explains how to use the `qq ad_sid_to_uid` command.

Description

Get UID from SID

Usage

```
qq ad_sid_to_uid [-h] -s SID
```

Flags

Flag Name	Required	Description
<code>-s</code>	Yes	Get the UID that corresponds to this SID

qq ad_sid_to_username

This section explains how to use the `qq ad_sid_to_username` command.

Description

Get AD username from SID

Usage

```
qq ad_sid_to_username [-h] -s SID
```

Flags

Flag Name	Required	Description
<code>-s</code>	Yes	Get the AD username that corresponds to this SID

qq ad_uid_to_sids

This section explains how to use the `qq ad_uid_to_sids` command.

Description

Get SIDs from UID

Usage

```
qq ad_uid_to_sids [-h] -u UID
```

Flags

Flag Name	Required	Description
<code>-u</code>	Yes	Get the SIDs that correspond to this UID

qq ad_username_to_sids

This section explains how to use the `qq ad_username_to_sids` command.

Description

Get SIDs from an AD username

Usage

```
qq ad_username_to_sids [-h] -u USERNAME
```

Flags

Flag Name	Required	Description
<code>-u</code>	Yes	Get the SIDs that correspond to this username

qq add_nodes

This section explains how to use the `qq add_nodes` command.

Description

Add unconfigured nodes to a Qumulo cluster

Usage

```
qq add_nodes [-h] (--node-uuids NODE_UUIDS [NODE_UUIDS ...] | --node-ips NODE_IPS [NODE_IPS ...] | --all-unconfigured) [--target-stripe-config BLOCKS_PER_STRIPE DATA_BLOCKS_PER_STRIPE] [--target-max-node-failures TARGET_MAX_NODE_FAILURES] [--dry-run] [--batch]
```

Flags

Flag Name	Required	Description
<code>--node-uuids</code>	No	The UUIDs of the unconfigured nodes to add to the cluster. The system adds nodes to the cluster in the same order that you list them after this flag.
<code>--node-ips</code>	No	The IP addresses of the unconfigured nodes to add to the cluster. The system adds nodes to the cluster in the same order that you list them after this flag.
<code>--all-unconfigured</code>	No	Add all network-connected, unconfigured nodes to the cluster. This flag does not allow specifying the order of the nodes and does not apply to cloud clusters.
<code>--target-stripe-config</code>	No	The stripe configuration to use
<code>--target-max-node-failures</code>	No	The minimum node fault tolerance level for the resulting cluster configuration. Note: In certain cases, a lower node fault tolerance level can result in higher usable capacity
<code>--dry-run</code>	No	Validate the node-add operation and calculate the resulting usable cluster capacity. When you use this flag, Qumulo Core does not add nodes or begin to change data protection configuration
<code>--batch</code>	No	Begin the node-add operation without asking for confirmation.

qq audit_create_destination

This section explains how to use the `qq audit_create_destination` command.

Description

Create new audit log destination

Usage

```
qq audit_create_destination [-h] --name NAME [--type {SYSLOG, CLOUDWATCH, LOCAL}] [--csv | --json] [--server-address SERVER_ADDRESS] [--server-port SERVER_PORT] [--log-group-name LOG_GROUP_NAME] [--region REGION] (--enable | --disable)
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	Audit log destination name.
<code>--type</code>	No	Audit log destination type (default: SYSLOG).
<code>--csv</code>	No	Use CSV format for SYSLOG destinations.
<code>--json</code>	No	Use JSON format for SYSLOG destinations.
<code>--server-address</code>	No	Syslog server address.
<code>--server-port</code>	No	Syslog server port.
<code>--log-group-name</code>	No	CloudWatch log group.
<code>--region</code>	No	CloudWatch region.
<code>--enable</code>	No	Enable audit log destination.
<code>--disable</code>	No	Disable audit log destination.

qq audit_delete_destination

This section explains how to use the `qq audit_delete_destination` command.

Description

Delete an audit log destination

Usage

```
qq audit_delete_destination [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Audit log destination ID.

qq audit_get_destination

This section explains how to use the `qq audit_get_destination` command.

Description

Retrieve audit log destination configuration

Usage

```
qq audit_get_destination [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Audit log destination ID.

qq audit_get_destination_status

This section explains how to use the `qq audit_get_destination_status` command.

Description

Retrieve audit log destination connection status

Usage

```
qq audit_get_destination_status [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Audit log destination ID.

qq audit_list_destinations

This section explains how to use the `qq audit_list_destinations` command.

Description

List all audit log destinations

Usage

```
qq audit_list_destinations [-h]
```

qq audit_modify_destination

This section explains how to use the `qq audit_modify_destination` command.

Description

Modify audit log destination configuration

Usage

```
qq audit_modify_destination [-h] --id ID (--enable | --disable)
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Audit log destination ID.
<code>--enable</code>	No	Enable audit log destination.
<code>--disable</code>	No	Disable audit log destination.

qq audit_set_destination

This section explains how to use the `qq audit_set_destination` command.

Description

Replace audit log destination configuration

Usage

```
qq audit_set_destination [-h] --id ID --name NAME [--type {SYSLOG,CLOUDWATCH,LOCAL}] [--csv | --json] [--server-address SERVER_ADDRESS] [--server-port SERVER_PORT] [--log-group-name LOG_GROUP_NAME] [--region REGION] (--enable | --disable)
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Audit log destination ID.
<code>--name</code>	Yes	Audit log destination name.
<code>--type</code>	No	Audit log destination type (default: SYSLOG).
<code>--csv</code>	No	Use CSV format for SYSLOG destinations.
<code>--json</code>	No	Use JSON format for SYSLOG destinations.
<code>--server-address</code>	No	Syslog server address.
<code>--server-port</code>	No	Syslog server port.
<code>--log-group-name</code>	No	CloudWatch log group.
<code>--region</code>	No	CloudWatch region.
<code>--enable</code>	No	Enable audit log destination.
<code>--disable</code>	No	Disable audit log destination.

qq auth_add_group

This section explains how to use the `qq auth_add_group` command.

Description

Add a new group

Usage

```
qq auth_add_group [-h] --name NAME [--gid GID]
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	New group's name (windows style)
<code>--gid</code>	No	Optional NFS gid

qq auth_add_user

This section explains how to use the `qq auth_add_user` command.

Description

Add a new user

Usage

```
qq auth_add_user [-h] --name NAME [--primary-group PRIMARY_GROUP] [--uid UID] [--home-directory HOME_DIRECTORY] [-p [PASSWORD]]
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	New user's name (windows style)
<code>--primary-group</code>	No	name or id of primary group (default is Users)
<code>--uid</code>	No	optional NFS uid
<code>--home-directory</code>	No	optional home directory
<code>-p</code>	No	Set user password; reads password from terminal if omitted

qq auth_assign_role

This section explains how to use the `qq auth_assign_role` command.

For more information, see [Managing Role-Based Access Control \(RBAC\) for Users and Groups in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

To Add a Trustee to an Existing Qumulo Core Role

Run the `qq auth_assign_role` command and specify the role and trustee. For example:

```
qq auth_assign_role \
  --role Observers \
  --trustee Everyone
```

```
qq auth_assign_role \
  --role Administrators \
  --trustee uid:1000
```

Description

Assign a user to a role

Usage

```
qq auth_assign_role [-h] -r ROLE -t TRUSTEE
```

Flags

Flag Name	Required	Description
<code>-r</code>	Yes	Name of the role to assign
<code>-t</code>	Yes	Assign the role to this trustee. e.g. Everyone, uid:1000, gid:1001, sid:S-1-5-2-3-4, or auth_id:500

qq auth_clear_cache

This section explains how to use the `qq auth_clear_cache` command.

Description

Clear all cached authorization information

Usage

```
qq auth_clear_cache [-h]
```

qq auth_create_access_token

This section explains how to use the `qq auth_create_access_token` command.

Description

Create a long-lived access token

Usage

```
qq auth_create_access_token [-h] [--self] [--expiration-time EXPIRATION_TIME] [--file PATH] [identifier]
```

Flags

Flag Name	Required	Description
<code>--self</code>	No	Create an access key that targets the currently logged in user.
<code>--expiration-time</code>	No	The expiration time of the access token. After this time, the token will no longer be usable for authentication. For example, "Jan 20 2024", "1/20/2024", or "2024-01-20 12:00", with times interpreted in UTC time-zone.
<code>--file</code>	No	File to store the access token credential. That file can be passed to the <code>--credentials-store</code> argument to authenticate using the created access token.

Positional Options

Option Name	Description
<code>identifier</code>	An auth_id, SID, or name optionally qualified with a domain prefix (e.g "local:name", "ad:name", "AD\name") or an ID type (e.g. "auth_id:513", "SID:S-1-1-0"). Groups are not supported for access tokens, must be a user.

qq auth_create_role

This section explains how to use the `qq auth_create_role` command.

For more information, see [Managing Role-Based Access Control \(RBAC\) for Users and Groups in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

To Create a New Custom Qumulo Core Role

Run the `qq auth_create_role` command and specify the custom role name, description, and the file that lists the necessary privileges. For example:

```
qq auth_create_role \  
--role "SMB-Manager" \  
--description "Manage SMB Shares" \  
--privileges-file privileges.txt
```

To Create a Custom Qumulo Core Role with Multiple Privileges

For this operation, you must run the `qq auth_list_privileges` and `qq auth_create_role` commands.

1. Run the `qq auth_list_privileges` command and use `grep` to write only the privileges that contain the word `WRITE` to the `privileges.txt` file. For example:

```
qq auth_list_privileges | \  
grep WRITE > privileges.txt
```

2. Run the `qq auth_create_role` command and specify the `privileges.txt` file to create a custom role. For example:

```
qq auth_create_role -r "Write-Everything" \  
-d "Can write, create, modify everything" \  
-p all-write-privileges.txt
```

Description

Create a custom role.

Usage

```
qq auth_create_role [-h] -r ROLE [-d DESCRIPTION] [-p PRIVILEGES_FILE]
```

Flags

Flag Name	Required	Description
-r	Yes	Name of the role to create
-d	No	Description of the new role
-p	No	File with privileges for the role (see auth_list_privileges)

qq auth_delete_access_token

This section explains how to use the `qq auth_delete_access_token` command.

Description

Delete the specified access token

Usage

```
qq auth_delete_access_token [-h] id
```

Positional Options

Option Name	Description
<code>id</code>	The unique ID of the access token to be deleted.

qq auth_delete_group

This section explains how to use the `qq auth_delete_group` command.

Description

Delete a group

Usage

```
qq auth_delete_group [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Name or ID of group to delete

qq auth_delete_role

This section explains how to use the `qq auth_delete_role` command.

Description

Delete a custom role.

Usage

```
qq auth_delete_role [-h] -r ROLE
```

Flags

Flag Name	Required	Description
<code>-r</code>	Yes	Name of the role to delete

qq auth_delete_user

This section explains how to use the `qq auth_delete_user` command.

Description

Delete a user

Usage

```
qq auth_delete_user [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Name or ID of user to delete

qq auth_expand_identity

This section explains how to use the `qq auth_expand_identity` command.

Description

Find equivalent identities and full group membership.

Usage

```
qq auth_expand_identity [-h] [--auth-id AUTH_ID] [--uid UID] [--gid GID] [--sid SID] [--name NAME] [--domain {LOCAL,WORLD,POSIX_USER,POSIX_GROUP,ACTIVE_DIRECTORY}] [--json] [--show-access-tokens] [identifier]
```

Flags

Flag Name	Required	Description
<code>--auth-id</code>	No	The canonical identifier used internally by QumuloFS.
<code>--uid</code>	No	An NFS UID
<code>--gid</code>	No	An NFS GID
<code>--sid</code>	No	An SMB SID
<code>--name</code>	No	A local, AD, or LDAP name. AD names may be unqualified, qualified with NetBIOS name (e.g. DOMAIN\user), or a universal principal name (e.g. user@domain.example.com). LDAP names may be either login names, or distinguished names (e.g. CN=John Doe,OU=users,DC=example,DC=com). Names of cluster-local users and groups may qualified with the cluster name (e.g. cluster\user).
<code>--domain</code>	No	Specify which auth_id domain is sought. This can be useful when looking up a duplicated name (e.g. if there is an AD user and cluster-local user with the same name) to specify which of the identifiers is meant.
<code>--json</code>	No	Print result as JSON object.

-- show- access- tokens	No	Print QFSD Access Tokens and S3 Access Keys associated with the user.
----------------------------------	----	---

Positional Options

Option Name	Description
identifier	A name or a SID, optionally qualified with a domain prefix (e.g "local:name", "world:Everyone", "ldap_user:name", "ldap_group:name", or "ad:name") or an ID type (e.g. "uid:1001", "gid:2001", "auth_id:513", "SID:S-1-1-0").

qq auth_find_identity

This section explains how to use the `qq auth_find_identity` command.

Description

Find all representations of an auth_id.

Usage

```
qq auth_find_identity [-h] [--auth-id AUTH_ID] [--uid UID] [--gid GID] [--sid SID]
[--name NAME] [--domain {LOCAL,WORLD,POSIX_USER,POSIX_GROUP,ACTIVE_DIRECTORY}] [--js
on] [identifier]
```

Flags

Flag Name	Required	Description
<code>--auth-id</code>	No	Find all external representations for an internal QumuloFS identifier.
<code>--uid</code>	No	Find the auth_id that will be used internally when a UID is written over NFS, and any other representations that would produce that auth_id.
<code>--gid</code>	No	Find the auth_id that will be used internally when a GID is written over NFS, and any other representations that would produce that auth_id.
<code>--sid</code>	No	Find the auth_id that will be used internally when a SID is written over SMB, and any other representations that would produce that auth_id.
<code>--name</code>	No	Find an auth_id that is uniquely identified by the given name. Names of Active Directory users and groups will produce the auth_id that is a representation of that principal's SID. AD names may be unqualified, qualified with NetBIOS name (e.g. DOMAIN\user), or a universal principal name (e.g. user@domain.example.com). Names of LDAP users or groups will produce the auth_id that is a representation of that principal's UID or GID. LDAP names may be either login names, or distinguished names (e.g. CN=John Doe,OU=users,DC=example,DC=com). Names of cluster-local users and groups will produce the auth_id assigned to that user or group.

<code>--do-main</code>	No	Specify which auth_id domain is sought. This can be useful when looking up a duplicated name (e.g. if there is an AD user and cluster-local user with the same name) to specify which of the identifiers is meant.
<code>--json</code>	No	Print result as JSON object.

Positional Options

Option Name	Description
<code>identifier</code>	A name or a SID, optionally qualified with a domain prefix (e.g "local:name", "world:Everyone", "ldap_user:name", "ldap_group:name", or "ad:name") or an ID type (e.g. "uid:1001", "gid:2001", "auth_id:513", "SID:S-1-1-0").

qq auth_get_access_token

This section explains how to use the `qq auth_get_access_token` command.

Description

Get metadata for the specified access token

Usage

```
qq auth_get_access_token [-h] id
```

Positional Options

Option Name	Description
<code>id</code>	The unique ID of the access token.

qq auth_get_user_defined_mappings

This section explains how to use the `qq auth_get_user_defined_mappings` command.

Description

Get the configured set of AD/LDAP static user defined mappings.

Usage

```
qq auth_get_user_defined_mappings [-h]
```

qq auth_list_access_tokens

This section explains how to use the `qq auth_list_access_tokens` command.

Description

List metadata for all access tokens

Usage

```
qq auth_list_access_tokens [-h] [--json] [--user USER | --self]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Output JSON instead of table.
<code>--user</code>	No	Show access tokens belonging to a specific user. Use an auth_id, SID, or name optionally qualified with a domain prefix (e.g "local:name", "ad:name", "AD\name") or an ID type (e.g. "auth_id:513", "SID:S-1-1-0"). Groups are not supported for access tokens, must be a user.
<code>--self</code>	No	List only access keys that target yourself.

qq auth_list_group

This section explains how to use the `qq auth_list_group` command.

Description

List a group

Usage

```
qq auth_list_group [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Name or ID of group to list

qq auth_list_groups

This section explains how to use the `qq auth_list_groups` command.

Description

List all groups

Usage

```
qq auth_list_groups [-h]
```

qq auth_list_privileges

This section explains how to use the `qq auth_list_privileges` command.

For more information, see [Managing Role-Based Access Control \(RBAC\) for Users and Groups in Qumulo Core](#) in the Qumulo Administrator Guide.

To view all existing users and groups with role-based control for your Qumulo cluster, run the `qq auth_list_roles` command.

Examples

To View the Privileges for an Existing Qumulo Core Role

Run the `qq auth_list_privileges` command and use `grep` to filter only the privileges that contain the word `SMB`. For example:

```
qq auth_list_privileges | grep SMB
```

To Create a Custom Qumulo Core Role with Multiple Privileges

For this operation, you must run the `qq auth_list_privileges` and `qq auth_create_role` commands.

1. Run the `qq auth_list_privileges` command and use `grep` to write only the privileges that contain the word `WRITE` to the `privileges.txt` file. For example:

```
qq auth_list_privileges | \
  grep WRITE > privileges.txt
```

2. Run the `qq auth_create_role` command and specify the `privileges.txt` file to create a custom role. For example:

```
qq auth_create_role -r "Write-Everything" \
  -d "Can write, create, modify everything" \
  -p all-write-privileges.txt
```

Description

List all privileges or privileges associated with a role.

Usage

```
qq auth_list_privileges [-h] [-r ROLE] [-v] [--json]
```

Flags

Flag Name	Required	Description
<code>-r</code>	No	List privileges associated with a role.
<code>-v</code>	No	Show granted and denied privileges with <code>--role</code> .
<code>--json</code>	No	Print JSON representation of the privileges.

qq auth_list_role

This section explains how to use the `qq auth_list_role` command.

Description

List a role.

Usage

```
qq auth_list_role [-h] -r ROLE [--json]
```

Flags

Flag Name	Required	Description
<code>-r</code>	Yes	Name of the role to lookup
<code>--json</code>	No	Print JSON representation of auth role.

qq auth_list_roles

This section explains how to use the `qq auth_list_roles` command.

Description

List all of the roles.

Usage

```
qq auth_list_roles [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Print JSON representation of auth roles.

qq auth_list_user

This section explains how to use the `qq auth_list_user` command.

Description

List a user

Usage

```
qq auth_list_user [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Name or ID of user to lookup

qq auth_list_users

This section explains how to use the `qq auth_list_users` command.

Description

List all users

Usage

```
qq auth_list_users [-h]
```


qq auth_mod_group

This section explains how to use the `qq auth_mod_group` command.

Description

Modify a group

Usage

```
qq auth_mod_group [-h] --id ID [--name NAME] [--gid GID]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Name or ID of group to modify
<code>--name</code>	No	Change group's name
<code>--gid</code>	No	Change the user's NFS gid (or specify "none" to remove)

qq auth_mod_user

This section explains how to use the `qq auth_mod_user` command.

Description

Modify a user

Usage

```
qq auth_mod_user [-h] --id ID [--name NAME] [--primary-group PRIMARY_GROUP] [--uid U ID] [--add-group ADD_GROUP] [--remove-group REMOVE_GROUP] [--home-directory HOME_DIRECTORY] [-p [PASSWORD]]
```

Flags

Flag Name	Required	Description
--id	Yes	Name or ID of user to modify
--name	No	Change user's name
--primary-group	No	Change the user's primary group
--uid	No	Change the user's NFS uid (or specify "none" to remove)
--add-group	No	Add this user to a group
--remove-group	No	Remove this user from a group
--home-directory	No	Change the user's home directory path (or specify "none" to remove)
-p	No	Change the user password

qq auth_modify_access_token

This section explains how to use the `qq auth_modify_access_token` command.

Description

Modify the specified access token

Usage

```
qq auth_modify_access_token [-h] [--expiration-time EXPIRATION_TIME] [--enable] [--disable] id
```

Flags

Flag Name	Required	Description
<code>--expiration-time</code>	No	The expiration time of the access token. After this time, the token will no longer be usable for authentication. For example, "Jan 20 2024", "1/20/2024", or "2024-01-20 12:00", with times interpreted in UTC time-zone.
<code>--enable</code>	No	Enable the access token.
<code>--disable</code>	No	Disable the access token. It can no longer be used to authenticate until it is enabled.

Positional Options

Option Name	Description
<code>id</code>	The unique ID of the access token to be modified.

qq auth_modify_role

This section explains how to use the `qq auth_modify_role` command.

For more information, see [Managing Role-Based Access Control \(RBAC\) for Users and Groups in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

To Add a Privilege to an Existing Custom Qumulo Core Role

Run the `qq auth_modify_role` command and specify the custom role name and the privilege to add. For example:

```
qq auth_modify_role \  
-r SMB-Manager \  
-G PRIVILEGE_SMB_SHARE_READ \
```

Description

Modify a custom role.

Usage

```
qq auth_modify_role [-h] -r ROLE [-d DESCRIPTION] [-p PRIVILEGES_FILE] [-G PRIVILEG  
E [PRIVILEGE ...]] [-R PRIVILEGE [PRIVILEGE ...]]
```

Flags

Flag Name	Required	Description
-r	Yes	Name of the role to modify
-d	No	New description of the role
-p	No	Overwrite the role's privileges with output from auth_list_privileges, cannot be used with -G or -R
-G	No	Privilege to add to this role (may be repeated)
-R	No	Privilege to remove from this role (may be repeated)

qq auth_set_password

This section explains how to use the `qq auth_set_password` command.

Description

Set a user's password

Usage

```
qq auth_set_password [-h] --id ID [-p PASSWORD]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Name or ID of user to modify
<code>-p</code>	No	The user's new password (insecure, visible via ps)

qq auth_set_user_defined_mappings

This section explains how to use the `qq auth_set_user_defined_mappings` command.

Description

Replace the configured set of AD/LDAP static identity mappings.

Usage

```
qq auth_set_user_defined_mappings [-h] (--file FILE | --stdin)
```

Flags

Flag Name	Required	Description
<code>--file</code>	No	JSON-encoded file containing mappings.
<code>--stdin</code>	No	Read JSON-encoded mappings from stdin

qq auth_unassign_role

This section explains how to use the `qq auth_unassign_role` command.
For more information, see [Managing Role-Based Access Control \(RBAC\) for Users and Groups in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

To Remove a Trustee from an Existing Qumulo Core Role

Run the `qq auth_unassign_role` command and specify the role and trustee. For example:

```
qq auth_unassign_role \  
  --role observers \  
  --trustee uid:2000
```

Description

Unassign a user from a role

Usage

```
qq auth_unassign_role [-h] -r ROLE -t TRUSTEE
```

Flags

Flag Name	Required	Description
-r	Yes	Name of the role to unassign
-t	Yes	Unassign the role from this trustee. e.g. Everyone, uid:1000, gid:1001, sid:S-1-5-2-3-4, or auth_id:500

qq authoritative_dns_get_settings

This section explains how to use the `qq authoritative_dns_get_settings` command.

Description

Retrieve settings for Qumulo Authoritative DNS server

Usage

```
qq authoritative_dns_get_settings [-h]
```


qq authoritative_dns_modify_settings

This section explains how to use the `qq authoritative_dns_modify_settings` command.

Description

Configure settings for Qumulo Authoritative DNS server

Usage

```
qq authoritative_dns_modify_settings [-h] [--fqdn FQDN] [--enable] [--disable] [--host-restrictions HOST_RESTRICTIONS [HOST_RESTRICTIONS ...]] [--disable-host-restrictions] [--record-ttl-seconds RECORD_TTL_SECONDS]
```

Flags

Flag Name	Required	Description
<code>--fqdn</code>	No	The fully qualified domain name (FQDN) for the Qumulo Authoritative DNS server.
<code>--enable</code>	No	Enable the Qumulo Authoritative DNS server
<code>--disable</code>	No	Disable the Qumulo Authoritative DNS server
<code>--host-restrictions</code>	No	The list of IP addresses that can query the Qumulo Authoritative DNS server
<code>--disable-host-restrictions</code>	No	Allow all IP addresses to query the Qumulo Authoritative DNS server
<code>--record-ttl-seconds</code>	No	How long resolvers may cache a record, from 0 to 3600 seconds.

qq capacity_clamp_get

This section explains how to use the `qq capacity_clamp_get` command.

Description

Get the capacity clamp value in bytes, which can be set via PUT API or during cluster creation. When the cluster provisions more pstores, it will take this value into account. The cluster will not provision new pstores if the usable capacity would exceed this value.

Usage

```
qq capacity_clamp_get [-h]
```

qq capacity_clamp_set

This section explains how to use the `qq capacity_clamp_set` command.

Description

Set the capacity clamp value in bytes. This limits the capacity that will be provisioned to be no more than the clamp value. A value below the current provisioned capacity has no effect. The actual stored value will be a pstore count that produces a byte count closest to the requested bytes without going over. If the change is applied successfully, quorum will be abandoned and the change will appear in the new quorum.

Usage

```
qq capacity_clamp_set [-h] (--clamp CLAMP | --disable)
```

Flags

Flag Name	Required	Description
<code>--clamp</code>	No	The capacity clamp to set as a human readable byte count (e.g. "10TB").
<code>--disable</code>	No	Remove the capacity clamp on the cluster.

qq capacity_history_files_get

This section explains how to use the `qq capacity_history_files_get` command.

Description

Get historical largest file data.

Usage

```
qq capacity_history_files_get [-h] --timestamp TIMESTAMP
```

Flags

Flag Name	Required	Description
<code>--timestamp</code>	Yes	Time period to retrieve, in epoch seconds.

qq capacity_history_get

This section explains how to use the `qq capacity_history_get` command.

Description

Get capacity history data.

Usage

```
qq capacity_history_get [-h] --begin-time BEGIN_TIME [--end-time END_TIME] [--interval {hourly,daily,weekly}]
```

Flags

Flag Name	Required	Description
<code>--begin-time</code>	Yes	Lower bound on history returned, in epoch seconds.
<code>--end-time</code>	No	Upper bound on history returned, in epoch seconds. Defaults to the most recent period for which data is available.
<code>--interval</code>	No	The interval at which to sample

qq change_password

This section explains how to use the `qq change_password` command.

Description

Change your password

Usage

```
qq change_password [-h] [-o OLD_PASSWORD] [-p NEW_PASSWORD]
```

Flags

Flag Name	Required	Description
<code>-o</code>	No	Your old password (insecure, visible via ps)
<code>-p</code>	No	Your new password (insecure, visible via ps)

qq checksumming_get_status

This section explains how to use the `qq checksumming_get_status` command.

Description

Get the checksumming status of the cluster.

Usage

```
qq checksumming_get_status [-h]
```

qq cluster_conf

This section explains how to use the `qq cluster_conf` command.

Description

Get the cluster config

Usage

```
qq cluster_conf [-h]
```


qq cluster_create

This section explains how to use the `qq cluster_create` command.

⚠ Important

To ensure that the Qumulo Core Web UI displays the nodes in your cluster in the same order that they are racked, enter the node UUIDs in the same order when you run the `qq cluster_create` command.

Description

Creates a Qumulo Cluster

Usage

```
qq cluster_create [-h] --cluster-name CLUSTER_NAME [--admin-password ADMIN_PASSWORD] [--blocks-per-stripe BLOCKS_PER_STRIPE] [--max-drive-failures MAX_DRIVE_FAILURES] [--max-node-failures MAX_NODE_FAILURES] [--accept-eula] [--reject-eula] [--host-instance-id HOST_INSTANCE_ID] (--node-uuids NODE_UUIDS [NODE_UUIDS ...] | --node-ips NODE_IPS [NODE_IPS ...] | --all-unconfigured)
```

Flags

Flag Name	Required	Description
<code>--cluster-name</code>	Yes	Cluster Name
<code>--admin-password</code>	No	Administrator Password
<code>--blocks-per-stripe</code>	No	Erasur coding stripe width
<code>--max-drive-failures</code>	No	Maximum allowable drive failures
<code>--max-node-failures</code>	No	Maximum allowable node failures
<code>--accept-eula</code>	No	Accept the EULA
<code>--reject-eula</code>	No	Reject the EULA
<code>--host-instance-id</code>	No	Instance ID of node receiving this request. Cloud only.
<code>--node-uuids</code>	No	Cluster node UUIDs

<code>--node-ips</code>	No	Cluster node IPv4 addresses
<code>--all-unconfigured</code>	No	Use all discoverable unconfigured nodes to make cluster

qq cluster_slot_set_config

This section explains how to use the `qq cluster_slot_set_config` command.

Description

Set the attributes for the given cluster slot. Currently only led_pattern may be set.

Usage

```
qq cluster_slot_set_config [-h] --slot SLOT [--locate | --no-locate]
```

Flags

Flag Name	Required	Description
<code>--slot</code>	Yes	Slot ID
<code>--locate</code>	No	Turn on the slot's locate LED.
<code>--no-locate</code>	No	Turn off the slot's locate LED.

qq cluster_slots

This section explains how to use the `qq cluster_slots` command.

Description

Get the cluster disk slots status

Usage

```
qq cluster_slots [-h] [--slot SLOT | --node NODE]
```

Flags

Flag Name	Required	Description
<code>--slot</code>	No	Slot ID
<code>--node</code>	No	Node ID

qq container_restart

This section explains how to use the `qq container_restart` command.

Description

Restart the qcore container

Usage

```
qq container_restart [-h] [--node-id NODE_ID]
```

Flags

Flag Name	Required	Description
<code>--node-id</code>	No	Restart the container on the specified node. Defaults to the current node.

qq container_restart_cluster

This section explains how to use the `qq container_restart_cluster` command.

Description

Restart the qcore container on every node in the cluster

Usage

```
qq container_restart_cluster [-h] [--force]
```

Flags

Flag Name	Required	Description
<code>--force</code>	No	Do not prompt

qq create_object_backed_cluster

This section explains how to use the `qq create_object_backed_cluster` command.

Description

Creates a Qumulo Object Backed Cluster

Usage

```
qq create_object_backed_cluster [-h] --cluster-name CLUSTER_NAME [--admin-password ADMIN_PASSWORD] --host-instance-id HOST_INSTANCE_ID --object-storage-uris OBJECT_STORAGE_URIS [OBJECT_STORAGE_URIS ...] --usable-capacity-clamp USABLE_CAPACITY_CLAMP --product-type PRODUCT_TYPE [--node-ips-and-fault-domains NODE_IPS_AND_FAULT_DOMAINS [NODE_IPS_AND_FAULT_DOMAINS ...]] --accept-eula [--azure-key-vault-uri KEY_VAULT | --key-vault KEY_VAULT]
```

Flags

Flag Name	Required	Description
<code>--cluster-name</code>	Yes	Cluster Name
<code>--admin-password</code>	No	Administrator Password
<code>--host-instance-id</code>	Yes	Instance ID of node receiving this request.
<code>--object-storage-uris</code>	Yes	Object storage URIs, e.g. <code>https://bucket.s3.region.amazonaws.com/</code>
<code>--usable-capacity-clamp</code>	Yes	Set usable capacity limit for the cluster, in human-readable format (e.g. 5TB).

<code>--product-type</code>	Yes	The product type of cluster to create. Valid options for AWS clusters are: ACTIVE_WITH_STANDARD_STORAGE, ACTIVE_WITH_INTELLIGENT_STORAGE, ARCHIVE_WITH_IA_STORAGE, ARCHIVE_WITH_GIR_STORAGE. Valid options for Azure clusters are: ACTIVE_WITH_HOT_STORAGE, ARCHIVE_WITH_COLD_STORAGE.
<code>--node-ips-and-fault-domains</code>	No	Cluster node ips and fault domains. Parsed as comma delimited tuples , ... To create a non-fault domain aware cluster, provide None in place of the fault domain ids ,None ,None ,None...
<code>--accept-eula</code>	Yes	Accept the EULA.
<code>--azure-key-vault-uri</code>	No	The URI of the key vault used to access blobs on Azure.
<code>--key-vault</code>	No	The key vault for accessing object storage. This is a key vault URL on Azure, and a secret bundle on OCI.

qq current_activity_get

This section explains how to use the `qq current_activity_get` command.

Description

Get the current sampled IOP and throughput rates

Usage

```
qq current_activity_get [-h] [-t {file-iops-read,file-iops-write,metadata-iops-read,metadata-iops-write,file-throughput-read,file-throughput-write}]
```

Flags

Flag Name	Required	Description
<code>-t</code>	No	The specific type of throughput to get

qq data_core_cluster_create

This section explains how to use the `qq data_core_cluster_create` command.

Description

Creates a Qumulo Data-Core Cluster

Usage

```
qq data_core_cluster_create [-h] --cluster-name CLUSTER_NAME [--admin-password ADMIN_PASSWORD] [--accept-eula] [--reject-eula] [--node-uuids NODE_UUIDS [NODE_UUIDS ...]] [--blocks-per-stripe BLOCKS_PER_STRIPE] [--max-drive-failures MAX_DRIVE_FAILURES] [--max-node-failures MAX_NODE_FAILURES] [--all-unconfigured]
```

Flags

Flag Name	Required	Description
<code>--cluster-name</code>	Yes	Cluster Name
<code>--admin-password</code>	No	Administrator Password
<code>--accept-eula</code>	No	Accept the EULA
<code>--reject-eula</code>	No	Reject the EULA
<code>--node-uuids</code>	No	Cluster node UUIDs
<code>--blocks-per-stripe</code>	No	Erasur coding stripe width
<code>--max-drive-failures</code>	No	Maximum allowable drive failures
<code>--max-node-failures</code>	No	Maximum allowable node failures
<code>--all-unconfigured</code>	No	Use all discoverable unconfigured nodes to make cluster

qq dns_clear_cache

This section explains how to use the `qq dns_clear_cache` command.

Description

Clear the local DNS cache

Usage

```
qq dns_clear_cache [-h] [--skip-reverse-cache | --skip-forward-cache]
```

Flags

Flag Name	Required	Description
<code>--skip-reverse-cache</code>	No	When this flag is set, the reverse lookup cache is not cleared.
<code>--skip-forward-cache</code>	No	When this flag is set, the forward lookup cache is not cleared.

qq dns_get_lookup_overrides

This section explains how to use the `qq dns_get_lookup_overrides` command.

Description

List the configured set of DNS lookup overrides.

Usage

```
qq dns_get_lookup_overrides [-h]
```

qq dns_get_system_config

This section explains how to use the `qq dns_get_system_config` command.

Description

Get the system's DNS configuration.

Usage

```
qq dns_get_system_config [-h]
```

qq dns_modify_system_config

This section explains how to use the `qq dns_modify_system_config` command.

Description

Modify the system's DNS configuration.

Usage

```
qq dns_modify_system_config [-h] [--dns-servers <address-or-range> [<address-or-range> ...] | --clear-dns-servers] [--dns-search-domains <search-domain> [<search-domain> ...] | --clear-dns-search-domains]
```

Flags

Flag Name	Required	Description
<code>--dns-servers</code>	No	List of DNS Server IP addresses. Can be a single address or multiple comma separated addresses. eg. 10.1.1.10 or 10.1.1.10,10.1.1.15
<code>--clear-dns-servers</code>	No	Clear the DNS servers
<code>--dns-search-domains</code>	No	List of DNS Search Domains to replace the current domains. Can be a single domain or multiple comma separated domains. eg. my.domain.com or my.domain.com,your.domain.com
<code>--clear-dns-search-domains</code>	No	Clear the DNS search domains

qq dns_resolve_hostnames

This section explains how to use the `qq dns_resolve_hostnames` command.

Description

Resolve hostnames to IP addresses

Usage

```
qq dns_resolve_hostnames [-h] --hosts HOSTS [HOSTS ...]
```

Flags

Flag Name	Required	Description
<code>--hosts</code>	Yes	Hostnames to resolve

qq dns_resolve_ips

This section explains how to use the `qq dns_resolve_ips` command.

Description

Resolve IP addresses to hostnames

Usage

```
qq dns_resolve_ips [-h] --ips IPS [IPS ...]
```

Flags

Flag Name	Required	Description
<code>--ips</code>	Yes	IP addresses to resolve

qq dns_set_lookup_overrides

This section explains how to use the `qq dns_set_lookup_overrides` command.

Description

Replace the configured set of DNS lookup overrides.

Usage

```
qq dns_set_lookup_overrides [-h] (--file FILE | --stdin)
```

Flags

Flag Name	Required	Description
<code>--file</code>	No	JSON-encoded file containing overrides.
<code>--stdin</code>	No	Read JSON-encoded overrides from stdin

qq encryption_get_key_store

This section explains how to use the `qq encryption_get_key_store` command.

Description

Get the active at-rest encryption configuration.

Usage

```
qq encryption_get_key_store [-h]
```

qq encryption_get_status

This section explains how to use the `qq encryption_get_status` command.

Description

Get the status of at-rest encryption.

Usage

```
qq encryption_get_status [-h]
```

qq encryption_set_key_store

This section explains how to use the `qq encryption_set_key_store` command.

Description

Set the active at-rest encryption configuration.

Usage

```
qq encryption_set_key_store [-h] {kms,local} ...
```

qq floating_ip_allocation

This section explains how to use the `qq floating_ip_allocation` command.

Description

Get cluster-wide floating IP allocation

Usage

```
qq floating_ip_allocation [-h]
```

qq fs_acl_explain_chmod

This section explains how to use the `qq fs_acl_explain_chmod` command.

Description

Explain how setting a POSIX mode would affect a file's ACL

Usage

```
qq fs_acl_explain_chmod [-h] (--path PATH | --id ID) --mode MODE [-v] [--json]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File or directory path
<code>--id</code>	No	File or directory ID
<code>--mode</code>	Yes	POSIX mode to hypothetically apply (e.g., 0744, rwxr--r--)
<code>-v</code>	No	Print more information in output
<code>--json</code>	No	Print JSON representation of POSIX mode derivation

qq fs_acl_explain_posix_mode

This section explains how to use the `qq fs_acl_explain_posix_mode` command.

Description

Explain the derivation of POSIX mode from a file's ACL

Usage

```
qq fs_acl_explain_posix_mode [-h] (--path PATH | --id ID) [--json]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File or directory path
<code>--id</code>	No	File or directory ID
<code>--json</code>	No	Print JSON representation of POSIX mode derivation

qq fs_acl_explain_rights

This section explains how to use the `qq fs_acl_explain_rights` command.

Description

Explain how rights are granted to a user for a file.

Usage

```
qq fs_acl_explain_rights [-h] (--path PATH | --id ID) -u ID [ID ...] [-g [ID [ID ...]]] [--no-expand] [-v] [--json]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File or directory path
<code>--id</code>	No	File or directory ID
<code>-u</code>	Yes	User for whom to explain rights. e.g. Alice, uid:1000, sid:S-1-5-2-3-4, or auth_id:500. If multiple are given, they will be considered equivalent for the purpose of the explanation.
<code>-g</code>	No	Groups that the user should be considered a member of for the purpose of the explanation.
<code>--no-expand</code>	No	Don't expand the given user and group IDs. This can be useful if you want to test a hypothetical (e.g 'what happens if I add/remove a user to some group?')
<code>-v</code>	No	Prints the credential that will be used for the explanation, after it has been expanded.
<code>--json</code>	No	Print JSON representation of rights explanation.

qq fs_copy

This section explains how to use the `qq fs_copy` command.

Description

Server-side copy a file.

Usage

```
qq fs_copy [-h] [--source-snapshot SOURCE_SNAPSHOT] [--overwrite] [--quiet] [--no-attributes] [--no-named-streams] source target
```

Flags

Flag Name	Required	Description
<code>--source-snapshot</code>	No	Snapshot ID to copy from
<code>--overwrite</code>	No	Overwrite an existing target file
<code>--quiet</code>	No	Do not show progress bar
<code>--no-attributes</code>	No	Do not copy file attributes and ACLs in addition to data
<code>--no-named-streams</code>	No	Do not copy named streams

Positional Options

Option Name	Description
<code>source</code>	Source file absolute path
<code>target</code>	Target file absolute path

qq fs_create_dir

This section explains how to use the `qq fs_create_dir` command.

Description

Create a new directory

Usage

```
qq fs_create_dir [-h] (--path PATH | --id ID) --name NAME
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Parent directory path
<code>--id</code>	No	Parent directory ID
<code>--name</code>	Yes	New directory name

qq fs_create_file

This section explains how to use the `qq fs_create_file` command.

Description

Create a new file

Usage

```
qq fs_create_file [-h] (--path PATH | --id ID) --name NAME
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Parent directory path
<code>--id</code>	No	Parent directory ID
<code>--name</code>	Yes	New file name

qq fs_create_link

This section explains how to use the `qq fs_create_link` command.

Description

Create a new link

Usage

```
qq fs_create_link [-h] (--path PATH | --id ID) --target TARGET --name NAME
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Parent directory path
<code>--id</code>	No	Parent directory ID
<code>--target</code>	Yes	Link target
<code>--name</code>	Yes	New link name

qq fs_create_symlink

This section explains how to use the `qq fs_create_symlink` command.

Description

Create a new symbolic link

Usage

```
qq fs_create_symlink [-h] (--path PATH | --id ID) --target TARGET [--target-type {FS_FILE_TYPE_UNKNOWN,FS_FILE_TYPE_FILE,FS_FILE_TYPE_DIRECTORY}] --name NAME
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Parent directory path
<code>--id</code>	No	Parent directory ID
<code>--target</code>	Yes	Link target (relative path recommended)
<code>--target-type</code>	No	Symlink target's type. If this is unspecified or FS_FILE_TYPE_UNKNOWN, the effect is the same as using 'ln -s' on a Unix NFS client. If this is FS_FILE_TYPE_FILE or FS_FILE_TYPE_DIRECTORY, the effect is the same as using 'mklink' or 'mklink /D' on a Windows SMB client.
<code>--name</code>	Yes	New symlink name

qq fs_create_unix_file

This section explains how to use the `qq fs_create_unix_file` command.

Description

Create a new pipe, character device, block device or socket

Usage

```
qq fs_create_unix_file [-h] (--path PATH | --id ID) [--major-minor-numbers major,min  
or] --name NAME --type TYPE
```

Flags

Flag Name	Required	Description
--path	No	Parent directory path
--id	No	Parent directory ID
--major-minor-numbers	No	Major and minor numbers for Character Device or Block Device
--name	Yes	New file name
--type	Yes	Type of UNIX file to create: FS_FILE_TYPE_UNIX_PIPE, FS_FILE_TYPE_UNIX_CHARACTER_DEVICE, FS_FILE_TYPE_UNIX_BLOCK_DEVICE, FS_FILE_TYPE_UNIX_SOCKET

qq fs_delete

This section explains how to use the `qq fs_delete` command.

Description

Delete a filesystem object

Usage

```
qq fs_delete [-h] (--path PATH | --id ID)
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Filesystem object path
<code>--id</code>	No	Filesystem object ID

qq fs_delete_user_metadata

This section explains how to use the `qq fs_delete_user_metadata` command.

Description

Delete the user metadata for a file by using the specified metadata key

Usage

```
qq fs_delete_user_metadata [-h] (--path PATH | --id ID) [--s3] --key KEY
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--s3</code>	No	In Qumulo Core, there are two types of user metadata, generic and S3. By default, qq CLI commands manipulate generic metadata. When you use the <code>--s3</code> flag, Qumulo Core makes user metadata visible to the S3 protocol as object metadata.
<code>--key</code>	Yes	Metadata key

qq fs_fetch_file

This section explains how to use the `qq fs_fetch_file` command.

Description

Fetch file data into cluster caches

Usage

```
qq fs_fetch_file [-h] (--path PATH | --id ID) [--progress] [-m MAX_BYTES]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--progress</code>	No	Show progress bar on stderr
<code>-m</code>	No	Fetch at most this many bytes

qq fs_fetch_tree

This section explains how to use the `qq fs_fetch_tree` command.

Description

Fetch file data into cluster caches for an entire file tree

Usage

```
qq fs_fetch_tree [-h] --path PATH [--no-progress] [--max-depth MAX_DEPTH] [-m MAX_BYTES_PER_FILE]
```

Flags

Flag Name	Required	Description
<code>--path</code>	Yes	Tree root path
<code>--no-progress</code>	No	Disable progress bar
<code>--max-depth</code>	No	Maximum depth to traverse
<code>-m</code>	No	Fetch at most this many bytes per file

qq fs_file_get_attr

This section explains how to use the `qq fs_file_get_attr` command.

For more information, see [How File Locks Work in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

Note

The following operations require Read ACL permissions for the file.

To Retrieve the Lock Status for a File

Run the `fs_file_get_attr` command, specify the path to the file, and use the `--retrieve-file-lock` flag. For example:

```
qq fs_file_get_attr \  
  --path /path-to/my-file \  
  --retrieve-file-lock
```

The following is example output.

```
{  
  "legal_hold": true,  
  "retention_period": "2024-09-15T23:41:40Z"  
}
```

Description

Get file attributes

Usage

```
qq fs_file_get_attr [-h] (--path PATH | --id ID) [--snapshot SNAPSHOT] [--retrieve-f  
ile-lock] [--stream-id STREAM_ID | --stream-name STREAM_NAME]
```

Flags

Flag Name	Required	Description
-----------	----------	-------------

<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--snapshot</code>	No	Snapshot ID to read from
<code>--retrieve-file-lock</code>	No	Retrieve the file lock for this file. Optional because it requires READ_ACL
<code>--stream-id</code>	No	Stream ID
<code>--stream-name</code>	No	Stream name

qq fs_file_modify_lock

This section explains how to use the `qq fs_file_modify_lock` command.

For more information, see [How File Locks Work in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

Note

The following operations require Write ACL permissions for the file and a role with the `FS_FILE_LOCK_WRITE` role-based access control (RBAC) privilege.

To Enable Locking for a File

Run the `fs_file_modify_lock` command, specify the path to the file, and use the `--enable-legal-hold` flag. For example:

```
qq fs_file_modify_lock \  
  --path /path-to/my-file \  
  --enable-legal-hold
```

To Disable Locking for a File

Run the `fs_file_modify_lock` command, specify the path to the file, and use the `--disable-legal hold` flag. For example:

```
qq fs_file_modify_lock \  
  --path /path-to/my-file \  
  --disable-legal-hold
```

To Set a Retention Period for a File

Run the `fs_file_modify_lock` command, specify the path to the file, and then specify a timestamp in the ISO 8601 UTC format followed by `Z`. For example:

```
qq fs_file_modify_lock \  
  --path /path-to/my-file \  
  --retention-period 2024-08-14T23:37:48Z
```

Alternatively, you can set the retention period in years or days. For example:

```
qq fs_file_modify_lock \  
  --path /path-to/my-file \  
  --days 3
```

Description

Modify a retention period or legal hold on a file.

Usage

```
qq fs_file_modify_lock [-h] (--path PATH | --id ID) [--enable-legal-hold | --disabl  
e-legal-hold] [--retention-period RETENTION_PERIOD | --retention-days RETENTION_DAY  
S | --retention-years RETENTION_YEARS]
```

Flags

Flag Name	Required	Description
--path	No	File path
--id	No	File ID
--enable-legal-hold	No	Set a legal hold on the file.
--disable-le- gal-hold	No	Unset a legal hold on the file.
--retention-pe- riod	No	Set the retention period for a file lock.
--retention- days	No	Set the retention period for a file lock to the specified number of days from now.
--retention- years	No	Set the retention period for a file lock to the specified number of years from now.

qq fs_file_samples

This section explains how to use the `qq fs_file_samples` command.

Description

Get a number of sample files from the filesystem

Usage

```
qq fs_file_samples [-h] (--path PATH | --id ID) --count COUNT [--sample-by {capacity,data,file,named_streams}]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Query root path
<code>--id</code>	No	Query root ID
<code>--sample-by</code>	No	Weight the sampling by the value specified: capacity (total bytes used for data and metadata), data (total bytes used for data only), file (file count), named_streams (named stream count)

qq fs_file_set_attr

This section explains how to use the `qq fs_file_set_attr` command.

Description

Set file attributes

Usage

```
qq fs_file_set_attr [-h] (--path PATH | --id ID) [--stream-id STREAM_ID | --stream-name STREAM_NAME] [--mode MODE] [--size SIZE] [--creation-time CREATION_TIME] [--access-time ACCESS_TIME] [--modification-time MODIFICATION_TIME]
    [--change-time CHANGE_TIME] [--owner OWNER | --owner-local OWNER_LOCAL | --owner-sid OWNER_SID | --owner-uid OWNER_UID] [--group GROUP | --group-local GROUP_LOCAL | --group-sid GROUP_SID | --group-gid GROUP_GID]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--stream-id</code>	No	Stream ID
<code>--stream-name</code>	No	Stream name
<code>--mode</code>	No	Posix-style file mode (octal)
<code>--size</code>	No	File size
<code>--creation-time</code>	No	File creation time (as RFC 3339 string)
<code>--access-time</code>	No	File access time (as RFC 3339 string)
<code>--modification-time</code>	No	File modification time (as RFC 3339 string)
<code>--change-time</code>	No	File change time (as RFC 3339 string)
<code>--owner</code>	No	File owner as auth_id
<code>--owner-local</code>	No	File owner as local user name

--owner-sid	No	File owner as SID
--owner-uid	No	File owner as NFS UID
--group	No	File group as auth_id
--group-local	No	File group as local group name
--group-sid	No	File group as SID
--group-gid	No	File group as NFS GID

qq fs_file_set_smb_attrs

This section explains how to use the `qq fs_file_set_smb_attrs` command.

Description

Change SMB extended attributes on the file

Usage

```
qq fs_file_set_smb_attrs [-h] (--path PATH | --id ID) [--archive BOOL] [--compressed BOOL] [--hidden BOOL] [--not-content-indexed BOOL] [--read-only BOOL] [--system BOOL] [--temporary BOOL] [--offline BOOL]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--archive</code>	No	Set ARCHIVE to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--compressed</code>	No	Set COMPRESSED to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--hidden</code>	No	Set HIDDEN to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--not-content-indexed</code>	No	Set NOT_CONTENT_INDEXED to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--read-only</code>	No	Set READ_ONLY to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--system</code>	No	Set SYSTEM to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--temporary</code>	No	Set TEMPORARY to a boolean-like value (e.g. true, false, yes, no, 1, 0).
<code>--offline</code>	No	Set OFFLINE to a boolean-like value (e.g. true, false, yes, no, 1, 0).

qq fs_get_acl

This section explains how to use the `qq fs_get_acl` command.

Description

Get file ACL

Usage

```
qq fs_get_acl [-h] (--path PATH | --id ID) [--snapshot SNAPSHOT] [--json]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--snapshot</code>	No	Snapshot ID to read from
<code>--json</code>	No	Print raw response JSON

qq fs_get_atime_settings

This section explains how to use the `qq fs_get_atime_settings` command.

Description

Get access time (atime) settings.

Usage

```
qq fs_get_atime_settings [-h]
```

qq fs_get_notify_settings

This section explains how to use the `qq fs_get_notify_settings` command.

Description

Get FS notify settings.

Usage

```
qq fs_get_notify_settings [-h]
```

qq fs_get_permissions_settings

This section explains how to use the `qq fs_get_permissions_settings` command.

Description

Get permissions settings

Usage

```
qq fs_get_permissions_settings [-h]
```

qq fs_get_stats

This section explains how to use the `qq fs_get_stats` command.

Description

Get filesystem statistics

Usage

```
qq fs_get_stats [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Print the output in JSON format.

qq fs_get_user_metadata

This section explains how to use the `qq fs_get_user_metadata` command.

Description

Retrieve a user metadata value for a file by using the specified metadata key

Usage

```
qq fs_get_user_metadata [-h] (--path PATH | --id ID) [--s3] --key KEY [--snapshot SNAPSHOT] [--hex | --base64]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--s3</code>	No	In Qumulo Core, there are two types of user metadata, generic and S3. By default, qq CLI commands manipulate generic metadata. When you use the <code>--s3</code> flag, Qumulo Core makes user metadata visible to the S3 protocol as object metadata.
<code>--key</code>	Yes	Metadata key
<code>--snapshot</code>	No	Snapshot ID to read user metadata from
<code>--hex</code>	No	Print binary values as hex
<code>--base64</code>	No	Print binary values as base64

qq fs_list_lock_waiters_by_client

This section explains how to use the `qq fs_list_lock_waiters_by_client` command.

Description

List waiting lock requests for a particular client machine

Usage

```
qq fs_list_lock_waiters_by_client [-h] --protocol {nlm} --lock-type {byte-range} [--name NAME] [--address ADDRESS]
```

Flags

Flag Name	Required	Description
<code>--protocol</code>	Yes	The protocol whose lock waiters should be listed
<code>--lock-type</code>	Yes	The type of lock whose waiters should be listed
<code>--name</code>	No	Client hostname
<code>--address</code>	No	Client IP address

qq fs_list_lock_waiters_by_file

This section explains how to use the `qq fs_list_lock_waiters_by_file` command.

Description

List waiting lock requests for a particular file

Usage

```
qq fs_list_lock_waiters_by_file [-h] (--path PATH | --id ID) --protocol {nlm} --lock-type {byte-range} [--snapshot SNAPSHOT]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--protocol</code>	Yes	The protocol whose lock waiters should be listed
<code>--lock-type</code>	Yes	The type of lock whose waiters should be listed
<code>--snapshot</code>	No	Snapshot id of the specified file.

qq fs_list_locks

This section explains how to use the `qq fs_list_locks` command.

Description

List file locks held by clients.

Usage

```
qq fs_list_locks [-h] --protocol {nlm,smb,nfs4} --lock-type {share-mode,byte-range}
[--path PATH | --id ID | --ip IP | --hostname HOSTNAME] [--snapshot SNAPSHOT] [--no-
resolve] [--json] [--sort {file,client}]
```

Flags

Flag Name	Required	Description
<code>--proto-col</code>	Yes	The protocol whose locks should be listed
<code>--lock-type</code>	Yes	The type of lock to list.
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--ip</code>	No	List all locks held by the client with this IP address.
<code>--host-name</code>	No	List all locks held by the client with this hostname. Only available for NLM locks.
<code>--snap-shot</code>	No	When a file is specified, list locks held on a specific snapshot.
<code>--no-re-solve</code>	No	Don't execute additional API calls to obtain file paths and client hostnames for results.
<code>--json</code>	No	Print a raw JSON response.
<code>--sort</code>	No	Sort results by this attribute.

qq fs_list_named_streams

This section explains how to use the `qq fs_list_named_streams` command.

Description

List all named streams on file or directory

Usage

```
qq fs_list_named_streams [-h] (--path PATH | --id ID) [--snapshot SNAPSHOT]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File or directory path
<code>--id</code>	No	File or directory ID
<code>--snapshot</code>	No	Snapshot ID to read from

qq fs_list_user_metadata

This section explains how to use the `qq fs_list_user_metadata` command.

Description

Retrieve user metadata of the specified type for a file

Usage

```
qq fs_list_user_metadata [-h] (--path PATH | --id ID) [--s3] [--json] [--snapshot SNAPSHOT] [--hex | --base64]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--s3</code>	No	In Qumulo Core, there are two types of user metadata, generic and S3. By default, qq CLI commands manipulate generic metadata. When you use the <code>--s3</code> flag, Qumulo Core makes user metadata visible to the S3 protocol as object metadata.
<code>--json</code>	No	Output the response in json. Without this option, keys and values will only show the first 50 characters.
<code>--snapshot</code>	No	Snapshot ID to read user metadata from
<code>--hex</code>	No	Print binary values as hex
<code>--base64</code>	No	Print binary values as base64

qq fs_modify_acl

This section explains how to use the `qq fs_modify_acl` command.

Description

Modify file ACL

Usage

```
qq fs_modify_acl [-h] (--path PATH | --id ID) [--json] {add_entry,remove_entry,modify_entry,set_posix_special_permissions} ...
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--json</code>	No	Print the raw JSON response.

qq fs_notify

This section explains how to use the `qq fs_notify` command.

Description

Notify on changes to files and directories under the specified directory. To cancel the listener, send a SIGQUIT signal (press CTRL+D).

Usage

```
qq fs_notify [-h] (--path PATH | --id ID) [--recursive]
  [--filter {child_file_added,child_dir_added,child_file_removed,child_dir_remove
d,child_file_moved_from,child_file_moved_to,child_dir_moved_from,child_dir_moved_t
o,child_btime_changed,child_mtime_changed,child_atime_changed,child_size_changed,chi
ld_extra_attrs_changed,child_acl_changed,child_owner_changed,child_group_changed,chi
ld_data_written,child_stream_added,child_stream_removed,child_stream_moved_from,child
_stream_moved_to,child_stream_size_changed,child_stream_data_written,self_removed}
  [{child_file_added,child_dir_added,child_file_removed,child_dir_removed,child_file_m
oved_from,child_file_moved_to,child_dir_moved_from,child_dir_moved_to,child_btime_ch
anged,child_mtime_changed,child_atime_changed,child_size_changed,child_extra_attrs_c
hanged,child_acl_changed,child_owner_changed,child_group_changed,child_data_writte
n,child_stream_added,child_stream_removed,child_stream_moved_from,child_stream_move
d_to,child_stream_size_changed,child_stream_data_written,self_removed} ...]]
  [--file FILE] [--json]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Directory path
<code>--id</code>	No	Directory ID
<code>--recursive</code>	No	Listen for changes recursively.
<code>--filter</code>	No	Specific notify types to filter to.
<code>--file</code>	No	File to receive data
<code>--json</code>	No	Output results as a json stream.

qq fs_punch_hole

This section explains how to use the `qq fs_punch_hole` command.

Description

Create a hole in a region of a file. Destroys all data within the hole.

Usage

```
qq fs_punch_hole [-h] (--path PATH | --id ID) [--stream-id STREAM_ID | --stream-name STREAM_NAME] --offset OFFSET --size SIZE
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--stream-id</code>	No	Stream ID
<code>--stream-name</code>	No	Stream name
<code>--offset</code>	Yes	Offset in bytes specifying the start of the hole to create
<code>--size</code>	Yes	Size in bytes of the hole to create

qq fs_read

This section explains how to use the `qq fs_read` command.

Description

Read an object

Usage

```
qq fs_read [-h] (--path PATH | --id ID) [--stream-id STREAM_ID | --stream-name STREAM_NAME] [--snapshot SNAPSHOT] [--offset OFFSET] [--length LENGTH] [--file FILE] [--force] [--stdout] [--skip-atime-update]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--stream-id</code>	No	Stream ID
<code>--stream-name</code>	No	Stream name
<code>--snapshot</code>	No	Snapshot ID to read from
<code>--offset</code>	No	Offset at which to read data. If not specified, read from the beginning of the file.
<code>--length</code>	No	Amount of data to read. If not specified, read the entire file.
<code>--file</code>	No	File to receive data
<code>--force</code>	No	Overwrite an existing file
<code>--stdout</code>	No	Output data to standard out
<code>--skip-atime-update</code>	No	Do not update the file's access time (atime) as a result of this read.

qq fs_read_dir

This section explains how to use the `qq fs_read_dir` command.

Examples

To List the Contents of a Directory on a Qumulo Cluster

Run the `qq fs_read_dir` command and specify the path whose contents to list. For example:

```
qq fs_read_dir --path /accounting
```

The following is example output. In this example, there are 2 files in the `/accounting` directory.

```

{
  "child_count": 2,
  "files": [{
    "blocks": "0",
    "change_time": "2024-02-04T19:29:48.136708478Z",
    "child_count": 2,
    "creation_time": "2024-02-04T19:29:16.846825314Z",
    "file_number": "4",
    "group": "513",
    "id": "4",
    "mode": "0777",
    "modification_time": "2024-02-04T19:29:48.136708478Z",
    "name": "receipts",
    "num_links": 2,
    "owner": "500",
    "path": "/receipts/",
    "size": "1024",
    "type": "FS_FILE_TYPE_DIRECTORY"
  }, {
    "blocks": "0",
    "change_time": "2015-02-04T19:34:17.113793299Z",
    "child_count": 1,
    "creation_time": "2015-02-04T19:24:12.201732558Z",
    "file_number": "3",
    "group": "513",
    "id": "3",
    "mode": "0777",
    "modification_time": "2015-02-04T19:34:17.113793299Z",
    "name": "invoices",
    "num_links": 2,
    "owner": "500",
    "path": "/invoices/",
    "size": "512",
    "type": "FS_FILE_TYPE_DIRECTORY"
  }],
  "id": "2",
  "paging": {
    "next": "",
    "prev": ""
  },
  "path": "/"
}

```

Description

Read directory

Usage

```
qq fs_read_dir [-h] (--path PATH | --id ID) [--page-size PAGE_SIZE] [--snapshot SNAP  
SHOT] [--smb-pattern SMB_PATTERN] [--skip-atime-update] [--include-acls]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Directory path
<code>--id</code>	No	Directory ID
<code>--page-size</code>	No	REST API pagination size to use. This affects the number of API calls made, and the structure of the resulting JSON output, but does not affect what entries are returned. Note that the system may impose an upper limit on the page size.
<code>--snapshot</code>	No	Snapshot ID to read from
<code>--smb-pattern</code>	No	SMB style match pattern.
<code>--skip-atime-update</code>	No	Do not update the directory's access time (atime) as a result of this read.
<code>--include-acls</code>	No	Provides ACL for each file in files[i].acl. When the caller does not have the READ_ACL permission on that entry, the entry in files[i].acl is null.

qq fs_read_dir_aggregates

This section explains how to use the `qq fs_read_dir_aggregates` command.

Description

Read aggregated data for the specified directory. To include the directory's children, use the `--recursive` flag.

Usage

```
qq fs_read_dir_aggregates [-h] (--path PATH | --id ID) [--recursive] [--max-entries  
MAX_ENTRIES] [--max-depth MAX_DEPTH]  
    [--order-by {total_blocks,total_datablocks,total_named_stream_datablocks,total_m  
etablocks,total_files,total_directories,total_symlinks,total_other,total_named_strea  
ms,total_external_objects,total_external_object_bytes}]  
    [--snapshot SNAPSHOT]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Directory path
<code>--id</code>	No	Directory ID
<code>--recursive</code>	No	This operation performs a breadth-first traversal of directories up to the limit specified by the <code>--max_entries</code> and <code>--max_depth</code> flags, or up to the system-imposed limit. It omits directory entries which are smaller than 10% of the directory's total size.
<code>--max-entries</code>	No	Maximum number of entries to return
<code>--max-depth</code>	No	Maximum depth to recurse when <code>--recursive</code> is set
<code>--order-by</code>	No	Specify field used for top N selection and sorting
<code>--snapshot</code>	No	Snapshot ID to read from

qq fs_release_nlm_lock

This section explains how to use the `qq fs_release_nlm_lock` command.

Description

Release an arbitrary NLM byte-range lock range. This is dangerous, and should only be used after confirming that the owning process has leaked the lock, and only if there is a very good reason why the situation should not be resolved by terminating that process.

Usage

```
qq fs_release_nlm_lock [-h] (--path PATH | --id ID) --offset OFFSET --size SIZE --owner-id OWNER_ID [--force] [--snapshot SNAPSHOT]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--offset</code>	Yes	NLM byte-range lock offset
<code>--size</code>	Yes	NLM byte-range lock size
<code>--owner-id</code>	Yes	Owner id
<code>--force</code>	No	This command can cause corruption, add this flag to release lock
<code>--snapshot</code>	No	Snapshot ID of the specified file

qq fs_release_nlm_locks_by_client

This section explains how to use the `qq fs_release_nlm_locks_by_client` command.

Description

Release NLM byte range locks held by client. This method releases all locks held by a particular client. This is dangerous, and should only be used after confirming that the client is dead.

Usage

```
qq fs_release_nlm_locks_by_client [-h] [--force] [--name NAME] [--address ADDRESS]
```

Flags

Flag Name	Required	Description
<code>--force</code>	No	This command can cause corruption, add this flag to release lock
<code>--name</code>	No	Client hostname
<code>--address</code>	No	Client IP address

qq fs_remove_stream

This section explains how to use the `qq fs_remove_stream` command.

Description

Remove a stream from file or directory

Usage

```
qq fs_remove_stream [-h] (--path PATH | --id ID) (--stream-id STREAM_ID | --stream-name STREAM_NAME)
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File or directory path
<code>--id</code>	No	File or directory ID
<code>--stream-id</code>	No	Stream id to remove
<code>--stream-name</code>	No	Stream name to remove

qq fs_rename

This section explains how to use the `qq fs_rename` command.

Description

Rename a filesystem object

Usage

```
qq fs_rename [-h] (--path PATH | --id ID) --source SOURCE --name NAME [--clobber]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Destination parent directory path
<code>--id</code>	No	Destination parent directory ID
<code>--source</code>	Yes	Source file path
<code>--name</code>	Yes	New name in destination directory
<code>--clobber</code>	No	Clobber destination if exists

qq fs_resolve_paths

This section explains how to use the `qq fs_resolve_paths` command.

Description

Resolve file IDs to paths

Usage

```
qq fs_resolve_paths [-h] --ids [IDS [IDS ...]] [--snapshot SNAPSHOT]
```

Flags

Flag Name	Required	Description
<code>--ids</code>	Yes	File IDs to resolve
<code>--snapshot</code>	No	Snapshot ID to read from

qq fs_security_add_key

This section explains how to use the `qq fs_security_add_key` command.

Description

Add a key to the filesystem key-store.

Usage

```
qq fs_security_add_key [-h] --name NAME [--private-key-file PRIVATE_KEY_FILE] [--public-key PUBLIC_KEY] [--verification-signature VERIFICATION_SIGNATURE] [--comment COMMENT] [--json]
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	The unique name to associate with the key to add to the key store. The name must not contain only numbers.
<code>--private-key-file</code>	No	The ECDSA private key file for the key to add to the key store.
<code>--public-key</code>	No	The ECDSA public key for the key to add to the key store.
<code>--verification-signature</code>	No	A signature generated by signing the key name with the ECDSA private key.
<code>--comment</code>	No	An optional comment that the system stores alongside the key to add to the key store.
<code>--json</code>	No	Print the output in JSON format. The default output is in a table.

qq fs_security_delete_key

This section explains how to use the `qq fs_security_delete_key` command.

Description

Delete a key from the filesystem key store.

Usage

```
qq fs_security_delete_key [-h] -k KEY
```

Flags

Flag Name	Required	Description
<code>-k</code>	Yes	The identifier or name of the key to delete from the key store.

qq fs_security_get_key

This section explains how to use the `qq fs_security_get_key` command.

Description

Get information for a key in the filesystem key store.

Usage

```
qq fs_security_get_key [-h] -k KEY [--json]
```

Flags

Flag Name	Required	Description
<code>-k</code>	Yes	The identifier or name of the key for which to show information.
<code>--json</code>	No	Print the output in JSON format. By default, the output is in a table.

qq fs_security_get_key_replace_challenge

This section explains how to use the `qq fs_security_get_key_replace_challenge` command.

Description

Get a security challenge for replacing the specified key without affecting the snapshots and snapshot policies associated with it.

Usage

```
qq fs_security_get_key_replace_challenge [-h] -k KEY
```

Flags

Flag Name	Required	Description
<code>-k</code>	Yes	The identifier or name of the key for which to get a security challenge.

qq fs_security_get_key_usage

This section explains how to use the `qq fs_security_get_key_usage` command.

Description

Show information about snapshot and snapshot policy usage for a key from the filesystem key store.

Usage

```
qq fs_security_get_key_usage [-h] -k KEY [--json]
```

Flags

Flag Name	Required	Description
<code>-k</code>	Yes	The key identifier or name for which to show usage information.
<code>--json</code>	No	Print the output in JSON format. By default, the output is in a table.

qq fs_security_list_keys

This section explains how to use the `qq fs_security_list_keys` command.

Description

List information for all keys in the filesystem key store.

Usage

```
qq fs_security_list_keys [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Print the output in JSON format. By default, the output is in a table.

qq fs_security_modify_key

This section explains how to use the `qq fs_security_modify_key` command.

Description

Modify the name or comment of a key in the filesystem key store. Enable or disable a key.

Usage

```
qq fs_security_modify_key [-h] -k KEY [--new-name NEW_NAME] [--comment COMMENT] [--enable | --disable] [--json]
```

Flags

Flag Name	Required	Description
<code>-k</code>	Yes	The identifier or name of the key to modify.
<code>--new-name</code>	No	The new name for the specified key.
<code>--comment</code>	No	The comment for the specified key.
<code>--enable</code>	No	Enable the specified key. You can use an enabled key to lock snapshots. You can also associate an enabled key with policies that take snapshots. Note: The system enables keys upon creation.
<code>--disable</code>	No	Disable the specified key. You cannot use a disabled key to lock new snapshots. Existing snapshots which use the disabled key remain locked. However, you can still use a disabled key to unlock the snapshots that it locked. Important: You cannot disable a key if any snapshot policy uses it.
<code>--json</code>	No	Print the output in JSON format. By default, the output is in a table.

qq fs_security_replace_key

This section explains how to use the `qq fs_security_replace_key` command.

Description

Replace the specified key without affecting the snapshots and snapshot policies associated with it.

Usage

```
qq fs_security_replace_key [-h] -k KEY [--old-private-key-file OLD_PRIVATE_KEY_FILE] [--replacement-private-key-file REPLACEMENT_PRIVATE_KEY_FILE] [--replacement-public-key REPLACEMENT_PUBLIC_KEY] [--old-key-verification-signature OLD_KEY_VERIFICATION_SIGNATURE] [--replacement-key-verification-signature REPLACEMENT_KEY_VERIFICATION_SIGNATURE] [--json]
```

Flags

Flag Name	Required	Description
<code>-k</code>	Yes	The identifier or name of the key to replace in the key store.
<code>--old-private-key-file</code>	No	The ECDSA private key file that corresponds to the existing public key.
<code>--replacement-private-key-file</code>	No	The ECDSA private key file with which to replace the existing key.
<code>--replacement-public-key</code>	No	The ECDSA public key with which to replace the existing key.
<code>--old-key-verification-signature</code>	No	A signature that you generate when you sign the challenge with the existing ECDSA private key.
<code>--replacement-key-verification-signature</code>	No	A signature that you generate when you sign the challenge with the replacement ECDSA private key.
<code>--json</code>	No	Print the output in JSON format. By default, the output is in a table.

qq fs_set_acl

This section explains how to use the `qq fs_set_acl` command.

Description

Set file ACL

Usage

```
qq fs_set_acl [-h] (--path PATH | --id ID) [--file FILE]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--file</code>	No	Local file containing ACL JSON with control flags, ACEs, and optionally special POSIX permissions (sticky, setgid, setuid)

qq fs_set_atime_settings

This section explains how to use the `qq fs_set_atime_settings` command.

Description

Set access time (atime) settings.

Usage

```
qq fs_set_atime_settings [-h] [--enable | --disable] [--granularity {HOUR,DAY,WEEK}]
```

Flags

Flag Name	Required	Description
<code>--enable</code>	No	Enable access time (atime) updates.
<code>--disable</code>	No	Disable access time (atime) updates.
<code>--granularity</code>	No	Specify granularity for access time (atime) updates.

qq fs_set_notify_settings

This section explains how to use the `qq fs_set_notify_settings` command.

Description

Set FS notify settings

Usage

```
qq fs_set_notify_settings [-h] [--recursive-mode RECURSIVE_MODE]
```

Flags

Flag Name	Required	Description
<code>--recursive-mode</code>	No	Notify recursive mode to set (ENABLED, DISABLED_ERROR, DISABLED_IGNORE)

qq fs_set_permissions_settings

This section explains how to use the `qq fs_set_permissions_settings` command.

Description

Set permissions settings

Usage

```
qq fs_set_permissions_settings [-h] mode
```

Positional Options

Option Name	Description
<code>mode</code>	Permissions mode to set (NATIVE or CROSS_PROTOCOL)

qq fs_set_user_metadata

This section explains how to use the `qq fs_set_user_metadata` command.

Description

Set or update a user metadata value for a file by using the specified metadata key and value

Usage

```
qq fs_set_user_metadata [-h] (--path PATH | --id ID) [--s3] --key KEY (--value VALUE | --hex-value HEX_VALUE | --base64-value BASE64_VALUE)
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--s3</code>	No	In Qumulo Core, there are two types of user metadata, generic and S3. By default, qq CLI commands manipulate generic metadata. When you use the <code>--s3</code> flag, Qumulo Core makes user metadata visible to the S3 protocol as object metadata.
<code>--key</code>	Yes	Metadata key
<code>--value</code>	No	Plaintext metadata value
<code>--hex-value</code>	No	Hex-encoded metadata value
<code>--base64-value</code>	No	Base64-encoded metadata value

qq fs_try_resolve_paths

This section explains how to use the `qq fs_try_resolve_paths` command.

Description

Resolve file IDs to paths, grouping IDs that cannot be resolved right now

Usage

```
qq fs_try_resolve_paths [-h] --ids [IDS [IDS ...]] [--snapshot SNAPSHOT]
```

Flags

Flag Name	Required	Description
<code>--ids</code>	Yes	File IDs to resolve
<code>--snapshot</code>	No	Snapshot ID to read from

qq fs_unlink

This section explains how to use the `qq fs_unlink` command.

Description

Delete a directory entry by name

Usage

```
qq fs_unlink [-h] (--path PATH | --id ID) --name NAME
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Parent directory path
<code>--id</code>	No	Parent directory ID
<code>--name</code>	Yes	Entry to delete

qq fs_walk_tree

This section explains how to use the `qq fs_walk_tree` command.

Examples

⚠ Important

We strongly recommend piping qq CLI commands to jq by using the `--stream` flag to avoid excessive memory use.

To Recursively Add a New ACL with Multithreading

For this operation, you must run the `qq fs_walk_tree` and `qq fs_modify_acl` commands.

📌 Note

For very large directories, we recommend running the following command in a screen session.

1. Ensure that the `jq` tool is installed on your system.
2. Run the `qq fs_walk_tree` command and use the `--path` flag to specify the path for the ACL. To extract the path for each item into an array, pipe the command to the `jq` tool. To modify the ACL for each path, pipe the command to `xargs` which in turn runs the `qq fs_set_acl` command on each path. For example:

```
qq fs_walk_tree --path /my_path | \  
jq --stream -j 'select(.[0][-1] == "path") | .[1], "\u0000"' | \  
xargs -0 -I % -n1 -P 4 \  
  qq fs_modify_acl --path '%' \  
    add_entry -t "DOMAIN\my_username" \  
      -y Allowed \  
      -r "Read" "Execute/Traverse" \  
      -f "Object inherit" "Container inherit"
```

To Recursively Apply a Permissions Template

For this operation, you must run the `qq fs_walk_tree` and `qq fs_modify_acl` commands.

1. Ensure that the `jq` tool is installed on your system.
2. Use a new or existing file with the necessary permissions to capture the ACL and save it in JSON format by using the `qq fs_get_acl` command. For example:

```
qq fs_get_acl --path /path_to_acl_source \  
--json >/history/new_permissions.json
```

3. To apply the captured ACL, run the `qq fs_walk_tree` command and use the `--path` flag to specify the path for the ACL. To extract the path for each item into an array, pipe the command to the `jq` tool. To modify the ACL for each path, pipe the command to `xargs` which in turn runs the `qq fs_set_acl` command on each path.

```
qq fs_walk_tree --path /my_target_path | \  
jq --stream -j 'select(.[0][-1] == "path") | .[1], "\u0000"' | \  
xargs -0 -I % -n1 -P 4 \  
qq fs_set_acl --path '%' \  
--file /history/new_permissions.json >> &>/dev/null
```

To Recursively Modify SMB Attributes

For this operation, you must run the `qq fs_walk_tree` and `qq fs_modify_acl` commands.

Run the `qq fs_walk_tree` command and use the `--path` flag to specify the path for the ACL. To extract the path for each item into an array, pipe the command to the `jq` tool. To modify the ACL for each path, pipe the command to `xargs` which in turn runs the `qq fs_set_acl` command on each path.

```
qq fs_walk_tree --path /my_path | \  
jq --stream -j 'select(.[0][-1] == "path") | .[1], "\u0000"' | \  
xargs -0 -I % -n1 -P 4 \  
qq fs_file_set_smb_attrs --path % \  
--hidden false
```

Description

Walk filesystem tree

Usage

```
qq fs_walk_tree [-h] [--path PATH] [--snapshot SNAPSHOT] [--file-only | --directory-  
only | --symlink-only] [--display-ownership | --display-all-attributes | --summary]  
[--output-file OUTPUT_FILE] [--max-depth MAX_DEPTH] [--progress]  
[-m MAX_BYTES_PER_FILE] [--fetch-data]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Tree root path
<code>--snapshot</code>	No	Snapshot ID to read from
<code>--file-only</code>	No	Only display files
<code>--directory-only</code>	No	Only display directories
<code>--symlink-only</code>	No	Only display symlinks
<code>--display-ownership</code>	No	Display detailed owner and group information
<code>--display-all-attributes</code>	No	Display all attributes
<code>--summary</code>	No	Output aggregate summary as JSON
<code>--output-file</code>	No	Output a file at the specified path instead of stdout
<code>--max-depth</code>	No	The maximum layers to traverse down the tree, starting from the path specified. For example, if the file tree is /dir/file, running the command with max-depth of 1 from root will yield / and /dir
<code>--progress</code>	No	Show progress bar (requires --output-file or --summary)
<code>-m</code>	No	Fetch at most this many bytes per file
<code>--fetch-data</code>	No	Fetch each file server-side to warm caches without transferring data

qq fs_write

This section explains how to use the `qq fs_write` command.

Examples

To Write a File to a Directory on a Qumulo Cluster

Run the `qq fs_write` command, use the `--create` flag and specify the source of and target locations for the file. For example:

```
qq fs_write --create \  
--file /upgrade/qinstall.qimg \  
--path /qinstall.qimg
```

The following is example output.

```
{  
  "blocks": "139355",  
  "change_time": "2024-02-04T00:28:50.778788345Z",  
  "child_count": 0,  
  "creation_time": "2024-02-04T00:28:50.766408341Z",  
  "file_number": "6981",  
  "group": "2",  
  "id": "6981",  
  "mode": "0644",  
  "modification_time": "2024-02-04T00:29:32.967968707Z",  
  "name": "",  
  "num_links": 1,  
  "owner": "500",  
  "path": "/qinstall.qimg",  
  "size": "570798080",  
  "type": "FS_FILE_TYPE_FILE"  
}
```

Description

Write data to an object

Usage

```
qq fs_write [-h] (--path PATH | --id ID) [--stream-id STREAM_ID | --stream-name STREAM_NAME | --create] [--offset OFFSET] [--file FILE] [--stdin]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	File path
<code>--id</code>	No	File ID
<code>--stream-id</code>	No	Stream ID
<code>--stream-name</code>	No	Stream name
<code>--create</code>	No	Create file before writing. Fails if exists or is used with stream identifiers.
<code>--offset</code>	No	Offset at which to write data. If not specified, the existing contents of the file will be replaced with the given contents.
<code>--file</code>	No	File data to send
<code>--stdin</code>	No	Write file from stdin

qq ftp_get_status

This section explains how to use the `qq ftp_get_status` command.

Description

Get FTP server settings and status

Usage

```
qq ftp_get_status [-h]
```

qq ftp_modify_settings

This section explains how to use the `qq ftp_modify_settings` command.

Description

Set FTP server settings

Usage

```
qq ftp_modify_settings [-h] [--enabled {true,false}] [--check-remote-host {true,false}]
[--log-operations {true,false}] [--chroot-users {true,false}] [--allow-unencrypted-connections {true,false}]
[--expand-wildcards {true,false}]
    [--anonymous-user-as-local-user ANONYMOUS_USER_AS_LOCAL_USER | --anonymous-user-
none | --greeting GREETING]
```


qq get_object_backed_nodes

This section explains how to use the `qq get_object_backed_nodes` command.

Description

Get the object-backed nodes.

Usage

```
qq get_object_backed_nodes [-h]
```

qq get_object_storage_uris

This section explains how to use the `qq get_object_storage_uris` command.

Description

Get the list of object storage uris configured on the cluster. These object storage uris store the persisted pstore data for an object-backed cluster. For a cluster that is not backed by objects, the returned list is always empty.

Usage

```
qq get_object_storage_uris [-h]
```

qq get_vpn_keys

This section explains how to use the `qq get_vpn_keys` command.

Description

Get VPN keys stored in the cluster.

Usage

```
qq get_vpn_keys [-h]
```

qq halt_cluster

This section explains how to use the `qq halt_cluster` command.

Description

Halt the cluster

Usage

```
qq halt_cluster [-h] [--force]
```

Flags

Flag Name	Required	Description
<code>--force</code>	No	Do not prompt

qq help

This section explains how to use the `qq help` command.

Description

QQ documentation

Usage

```
qq help [-h]
```

qq identity_attributes_get

This section explains how to use the `qq identity_attributes_get` command.

Description

Get attributes related to the given identity.

Usage

```
qq identity_attributes_get [-h] identifier
```

Positional Options

Option Name	Description
<code>identifier</code>	A name or a SID, optionally qualified with a domain prefix (e.g "local:name", "world:Everyone", "ldap_user:name", "ldap_group:name", or "ad:name") or an ID type (e.g. "uid:1001", "gid:2001", "auth_id:513", "SID:S-1-1-0").

qq identity_attributes_set

This section explains how to use the `qq identity_attributes_set` command.

Description

Set attributes related to the given identity.

Usage

```
qq identity_attributes_set [-h] --home-directory HOME_DIRECTORY identifier
```

Flags

Flag Name	Required	Description
<code>--home-directory</code>	Yes	The home directory for the identity.

Positional Options

Option Name	Description
<code>identifier</code>	A name or a SID, optionally qualified with a domain prefix (e.g "local:name", "world:Everyone", "ldap_user:name", "ldap_group:name", or "ad:name") or an ID type (e.g. "uid:1001", "gid:2001", "auth_id:513", "SID:S-1-1-0").

qq install_vpn_keys

This section explains how to use the `qq install_vpn_keys` command.

Description

Install VPN keys.

Usage

```
qq install_vpn_keys [-h] directory
```

Positional Options

Option Name	Description
<code>directory</code>	Directory with mqvpn-client.crt, mqvpn-client.key, and qumulo-ca.crt files.

qq kerberos_delete_keytab

This section explains how to use the `qq kerberos_delete_keytab` command.

Description

Delete the Kerberos keytab

Usage

```
qq kerberos_delete_keytab [-h]
```

qq kerberos_get_keytab

This section explains how to use the `qq kerberos_get_keytab` command.

Description

Get the Kerberos keytab

Usage

```
qq kerberos_get_keytab [-h]
```

qq kerberos_get_settings

This section explains how to use the `qq kerberos_get_settings` command.

Description

Get the Kerberos settings

Usage

```
qq kerberos_get_settings [-h]
```

qq kerberos_modify_settings

This section explains how to use the `qq kerberos_modify_settings` command.

Description

Modify the Kerberos settings

Usage

```
qq kerberos_modify_settings [-h] -a USE_ALT_SECURITY_IDENTITYES_MAPPING
```

Flags

Flag Name	Required	Description
<code>-a</code>	Yes	When enabled, map kerberos-authenticated users to LDAP records via the altSecurityIdentities field

qq kerberos_set_keytab

This section explains how to use the `qq kerberos_set_keytab` command.

Description

Set the Kerberos keytab

Usage

```
qq kerberos_set_keytab [-h] -k KEYTAB_FILE
```

Flags

Flag Name	Required	Description
-k	Yes	The Kerberos keytab file to set

qq ldap_get_settings

This section explains how to use the `qq ldap_get_settings` command.

Description

Get settings for LDAP interaction

Usage

```
qq ldap_get_settings [-h]
```

qq ldap_get_status

This section explains how to use the `qq ldap_get_status` command.

Description

Get LDAP client connection states

Usage

```
qq ldap_get_status [-h]
```

qq ldap_login_name_to_gid_numbers

This section explains how to use the `qq ldap_login_name_to_gid_numbers` command.

Description

Query the LDAP server for the gid numbers for all the groups of which the given login name is a member. This returns a vector of results in the case that the given login name maps to multiple uid numbers.

Usage

```
qq ldap_login_name_to_gid_numbers [-h] --login-name LOGIN_NAME
```


qq ldap_login_name_to_uid_numbers

This section explains how to use the `qq ldap_login_name_to_uid_numbers` command.

Description

Get the uidNumbers from a login name using the LDAP server

Usage

```
qq ldap_login_name_to_uid_numbers [-h] --login-name LOGIN_NAME
```

qq ldap_set_settings

This section explains how to use the `qq ldap_set_settings` command.

Description

Set settings for LDAP interaction

Usage

```
qq ldap_set_settings [-h] --use-ldap {true,false} --bind-uri BIND_URI --base-dn BASE_DN [--bind-username BIND_USERNAME] [--bind-password BIND_PASSWORD] [--encrypt-connection {true,false}] [--rfc2307]
    [--custom-group-member-attribute CUSTOM_GROUP_MEMBER_ATTRIBUTE] [--custom-user-group-identifier-attribute CUSTOM_USER_GROUP_IDENTIFIER_ATTRIBUTE] [--custom-login-name-attribute CUSTOM_LOGIN_NAME_ATTRIBUTE]
    [--custom-group-name-attribute CUSTOM_GROUP_NAME_ATTRIBUTE] [--custom-user-object-class CUSTOM_USER_OBJECT_CLASS] [--custom-group-object-class CUSTOM_GROUP_OBJECT_CLASS]
    [--custom-uid-number-attribute CUSTOM_UID_NUMBER_ATTRIBUTE] [--custom-gid-number-attribute CUSTOM_GID_NUMBER_ATTRIBUTE]
```

Flags

Flag Name	Required	Description
<code>--use-ldap</code>	Yes	Whether or not to enable the use of the LDAP server on the cluster.
<code>--bind-uri</code>	Yes	LDAP server URIs (for example, ldap://example.com). Separate multiple URIs with commas (.). When you specify multiple URIs in order of preference, Qumulo Core uses only one LDAP server at a time and falls back to the remaining servers if one of the URIs becomes unreachable.
<code>--base-dn</code>	Yes	Base DN (Distinguished Names). Separate multiple DN's using semicolons. Example: dc=account,dc=example,dc=com
<code>--bind-username</code>	No	Binding user's DN. Default is empty.
<code>--bind-password</code>	No	Password for simple authentication against LDAP server. If not specified, will use password that is currently stored on disk.

<code>--encrypt-connection</code>	No	If true, LDAP connection must be encrypted using TLS. Default is true.
<code>--rfc2307</code>	No	Use the standard schema defined in RFC2307. Cannot be combined with any custom schema arguments.
<code>--custom-group-member-attribute</code>	No	The attribute on a group object which contains references to the members in that group.
<code>--custom-user-group-identifier-attribute</code>	No	The attribute on a user that the value of the group_member_attribute on a group refers to.
<code>--custom-login-name-attribute</code>	No	The attribute on a user that identifies their login name.
<code>--custom-group-name-attribute</code>	No	The attribute on a group that identifies their name.
<code>--custom-user-object-class</code>	No	The class of user objects.
<code>--custom-group-object-class</code>	No	The class of group objects.
<code>--custom-uid-number-attribute</code>	No	The attribute on a user that identifies their uid number.
<code>--custom-gid-number-attribute</code>	No	The attribute on an object that identifies their gid number.

qq ldap_uid_number_to_login_name

This section explains how to use the `qq ldap_uid_number_to_login_name` command.

Description

Get login name from uidNumber using LDAP server

Usage

```
qq ldap_uid_number_to_login_name [-h] --uid-number UID_NUMBER
```

qq ldap_update_settings

This section explains how to use the `qq ldap_update_settings` command.

Description

Update settings for LDAP interaction

Usage

```
qq ldap_update_settings [-h] [--use-ldap {true,false}] [--bind-uri BIND_URI] [--base-dn BASE_DN] [--bind-username BIND_USERNAME] [--bind-password BIND_PASSWORD] [--encrypt-connection {true,false}] [--rfc2307]
    [--custom-group-member-attribute CUSTOM_GROUP_MEMBER_ATTRIBUTE] [--custom-user-group-identifier-attribute CUSTOM_USER_GROUP_IDENTIFIER_ATTRIBUTE] [--custom-login-name-attribute CUSTOM_LOGIN_NAME_ATTRIBUTE]
    [--custom-group-name-attribute CUSTOM_GROUP_NAME_ATTRIBUTE] [--custom-user-object-class CUSTOM_USER_OBJECT_CLASS] [--custom-group-object-class CUSTOM_GROUP_OBJECT_CLASS]
    [--custom-uid-number-attribute CUSTOM_UID_NUMBER_ATTRIBUTE] [--custom-gid-number-attribute CUSTOM_GID_NUMBER_ATTRIBUTE]
```

Flags

Flag Name	Required	Description
<code>--use-ldap</code>	No	Enable or disable the use of standalone LDAP.
<code>--bind-uri</code>	No	LDAP server URIs (for example, ldap://example.com). Separate multiple URIs with commas (.). When you specify multiple URIs in order of preference, Qumulo Core uses only one LDAP server at a time and falls back to the remaining servers if one of the URIs becomes unreachable.
<code>--base-dn</code>	No	Base DN (Distinguished Names). Example: dc=account,dc=example,dc=com
<code>--bind-username</code>	No	Binding user's DN.
<code>--bind-password</code>	No	Password for simple authentication against LDAP server.

<code>--encrypt-connection</code>	No	If true, LDAP connection must be encrypted using TLS.
<code>--rfc2307</code>	No	Use the standard schema defined in RFC2307. Cannot be combined with any custom schema arguments.
<code>--custom-group-member-attribute</code>	No	The attribute on a group object which contains references to the members in that group.
<code>--custom-user-group-identifier-attribute</code>	No	The attribute on a user that the value of the group_member_attribute on a group refers to.
<code>--custom-login-name-attribute</code>	No	The attribute on a user that identifies their login name.
<code>--custom-group-name-attribute</code>	No	The attribute on a group that identifies their name.
<code>--custom-user-object-class</code>	No	The class of user objects.
<code>--custom-group-object-class</code>	No	The class of group objects.
<code>--custom-uid-number-attribute</code>	No	The attribute on a user that identifies their uid number.
<code>--custom-gid-number-attribute</code>	No	The attribute on an object that identifies their gid number.

qq license_get_status

This section explains how to use the `qq license_get_status` command.

Description

Fetch the current license state of the cluster.

Usage

```
qq license_get_status [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Print JSON representation of license.

qq login

This section explains how to use the `qq login` command.

Description

Log in to qfsd to get REST credentials

Usage

```
qq login [-h] -u USERNAME [-p PASSWORD]
```

Flags

Flag Name	Required	Description
<code>-u</code>	Yes	User name
<code>-p</code>	No	Password (insecure, visible via ps)

qq logout

This section explains how to use the `qq logout` command.

Description

Remove qfsd REST credentials

Usage

```
qq logout [-h]
```

qq metrics_get

This section explains how to use the `qq metrics_get` command.

Description

Get all system metrics.

Usage

```
qq metrics_get [-h]
```

qq

modify_object_backed_cluster_membership

This section explains how to use the `qq modify_object_backed_cluster_membership` command.

Description

Modify the membership of an object-backed cluster by specifying the desired list of nodes expected to be part of the cluster after the modification. The nodes to be added, removed, or replaced are implicitly derived using the specified target membership and the current membership of the cluster.

Usage

```
qq modify_object_backed_cluster_membership [-h] (--node-ips-and-fault-domains NODE_IPS_AND_FAULT_DOMAINS [NODE_IPS_AND_FAULT_DOMAINS ...] | --node-uuids-and-fault-domains NODE_UUIDS_AND_FAULT_DOMAINS [NODE_UUIDS_AND_FAULT_DOMAINS ...]) [--batch] [--dry-run]
```

Flags

Flag Name	Required	Description
<code>--node-ips-and-fault-domains</code>	No	The node ips and fault domains of the new and existing nodes expected to remain in the cluster after the modification. Parsed as comma delimited tuples ,,...To specify a non-fault domain aware cluster, provide None in place of the fault domain ids ,None ,None ,None...The fault domain of an existing node cannot be changed. To be used for cloud object-backed clusters.
<code>--node-uuids-and-fault-domains</code>	No	The node uuids and fault domains of the new and existing nodes expected to remain in the cluster after the modification. Parsed as comma delimited tuples ,,...To specify a non-fault domain aware cluster, provide None in place of the fault domain ids ,None ,None ,None...The fault domain of an existing node cannot be changed. To be used for on prem object-backed clusters.
<code>--batch</code>	No	Begin the cluster modification operation without asking for confirmation.

<code>--dry-run</code>	No	Validate the cluster modification operation and return information about the resulting cluster. When you use this flag, Qumulo Core does not perform the cluster modification.
------------------------	----	--

qq monitoring_conf

This section explains how to use the `qq monitoring_conf` command.

Description

Get monitoring configuration.

Usage

```
qq monitoring_conf [-h]
```

qq monitoring_status_get

This section explains how to use the `qq monitoring_status_get` command.

Description

Get current monitoring status.

Usage

```
qq monitoring_status_get [-h]
```

qq multitenancy_create_tenant

This section explains how to use the `qq multitenancy_create_tenant` command.

Description

Create a tenant

Usage

```
qq multitenancy_create_tenant [-h] --name NAME [--network-id [NETWORK_ID [NETWORK_ID ...]]] [--enable-web-ui | --disable-web-ui] [--enable-rest-api | --disable-rest-api] [--enable-ssh | --disable-ssh]
                             [--enable-replication | --disable-replication] [--enable-nfs | --disable-nfs]
                             [--enable-smb | --disable-smb]
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	Unique name of the tenant chosen by the user.
<code>--network-id</code>	No	List of zero or more network IDs associated with this tenant, as returned by the <code>`network_list_networks`</code> command. Each network ID may be assigned to at most one tenant.
<code>--enable-web-ui</code>	No	Web UI is accessible from this tenant.
<code>--disable-web-ui</code>	No	Web UI is not accessible from this tenant. This is the default.
<code>--enable-rest-api</code>	No	REST API is accessible from this tenant.
<code>--disable-rest-api</code>	No	REST API is not accessible from this tenant. This is the default.
<code>--enable-ssh</code>	No	SSH is accessible from this tenant.
<code>--disable-ssh</code>	No	SSH is not accessible from this tenant. This is the default.

<code>--enable-replication</code>	No	Replication is accessible from this tenant.
<code>--disable-replication</code>	No	Replication is not accessible from this tenant. This is the default.
<code>--enable-nfs</code>	No	NFS is accessible from this tenant.
<code>--disable-nfs</code>	No	NFS is not accessible from this tenant. This is the default.
<code>--enable-smb</code>	No	SMB is accessible from this tenant.
<code>--disable-smb</code>	No	SMB is not accessible from this tenant. This is the default.

qq multitenancy_delete_tenant

This section explains how to use the `qq multitenancy_delete_tenant` command.

Description

Delete a tenant

Usage

```
qq multitenancy_delete_tenant [-h] --id ID [--force]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	The unique ID of the tenant to delete.
<code>--force</code>	No	Do not prompt

qq multitenancy_get_tenant

This section explains how to use the `qq multitenancy_get_tenant` command.

Description

Get a tenant

Usage

```
qq multitenancy_get_tenant [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	The unique ID of the tenant to retrieve.

qq multitenancy_list_tenants

This section explains how to use the `qq multitenancy_list_tenants` command.

Description

List all tenants

Usage

```
qq multitenancy_list_tenants [-h] [-j]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Output in JSON format

qq multitenancy_modify_tenant

This section explains how to use the `qq multitenancy_modify_tenant` command.

Description

Modify a tenant

Usage

```
qq multitenancy_modify_tenant [-h] --id ID [--name NAME] [--enable-web-ui | --disable-web-ui] [--enable-rest-api | --disable-rest-api] [--enable-ssh | --disable-ssh] [--enable-replication | --disable-replication] [--enable-nfs | --disable-nfs] [--enable-smb | --disable-smb] [--network-id [NETWORK_ID [NETWORK_ID ...]]]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	The unique ID of the tenant to modify.
<code>--name</code>	No	Unique name of the tenant chosen by the user. If not specified, the existing name will be preserved.
<code>--enable-web-ui</code>	No	Web UI is accessible from this tenant. If neither <code>--enable-web-ui</code> nor <code>--disable-web-ui</code> is specified, the existing setting will be preserved.
<code>--disable-web-ui</code>	No	Web UI is not accessible from this tenant. If neither <code>--enable-web-ui</code> nor <code>--disable-web-ui</code> is specified, the existing setting will be preserved.
<code>--enable-rest-api</code>	No	REST API is accessible from this tenant. If neither <code>--enable-rest-api</code> nor <code>--disable-rest-api</code> is specified, the existing setting will be preserved.
<code>--disable-rest-api</code>	No	REST API is not accessible from this tenant. If neither <code>--enable-rest-api</code> nor <code>--disable-rest-api</code> is specified, the existing setting will be preserved.
<code>--enable-ssh</code>	No	SSH is accessible from this tenant. If neither <code>--enable-ssh</code> nor <code>--disable-ssh</code> is specified, the existing setting will be preserved.
<code>--disable-ssh</code>	No	SSH is not accessible from this tenant. If neither <code>--enable-ssh</code> nor <code>--disable-ssh</code> is specified, the existing setting will be preserved.

<code>--enable-replication</code>	No	Replication is accessible from this tenant. If neither <code>--enable-replication</code> nor <code>--disable-replication</code> is specified, the existing setting will be preserved.
<code>--disable-replication</code>	No	Replication is not accessible from this tenant. If neither <code>--enable-replication</code> nor <code>--disable-replication</code> is specified, the existing setting will be preserved.
<code>--enable-nfs</code>	No	NFS is accessible from this tenant. If neither <code>--enable-nfs</code> nor <code>--disable-nfs</code> is specified, the existing setting will be preserved.
<code>--disable-nfs</code>	No	NFS is not accessible from this tenant. If neither <code>--enable-nfs</code> nor <code>--disable-nfs</code> is specified, the existing setting will be preserved.
<code>--enable-smb</code>	No	SMB is accessible from this tenant. If neither <code>--enable-smb</code> nor <code>--disable-smb</code> is specified, the existing setting will be preserved.
<code>--disable-smb</code>	No	SMB is not accessible from this tenant. If neither <code>--enable-smb</code> nor <code>--disable-smb</code> is specified, the existing setting will be preserved.
<code>--network-id</code>	No	List of zero or more network IDs associated with this tenant, as returned by the <code>`network_list_networks`</code> command. Each network ID may be assigned to at most one tenant. If specified, this must contain a complete list of all network IDs to be assigned to the tenant. Any already-assigned networks not present will be unassigned and services will be disabled on those networks. If not specified, the existing networks will be preserved.

qq multitenancy_nfs_delete_settings

This section explains how to use the `qq multitenancy_nfs_delete_settings` command.

Description

Delete NFS settings for a tenant

Usage

```
qq multitenancy_nfs_delete_settings [-h] --tenant-id TENANT_ID
```

Flags

Flag Name	Required	Description
<code>--tenant-id</code>	Yes	ID of the tenant to delete settings for

qq multitenancy_nfs_get_global_settings

This section explains how to use the `qq multitenancy_nfs_get_global_settings` command.

Description

Retrieve global default NFS settings

Usage

```
qq multitenancy_nfs_get_global_settings [-h]
```

qq multitenancy_nfs_get_settings

This section explains how to use the `qq multitenancy_nfs_get_settings` command.

Description

Retrieve NFS settings for a tenant

Usage

```
qq multitenancy_nfs_get_settings [-h] --tenant-id TENANT_ID
```

Flags

Flag Name	Required	Description
<code>--tenant-id</code>	Yes	ID of tenant to get settings for

qq multitenancy_nfs_list_settings

This section explains how to use the `qq multitenancy_nfs_list_settings` command.

Description

Retrieve NFS settings for all tenant that have tenant-specific settings configured

Usage

```
qq multitenancy_nfs_list_settings [-h]
```

qq

multitenancy_nfs_modify_global_settings

This section explains how to use the `qq multitenancy_nfs_modify_global_settings` command.

Description

Modify global default NFS settings

Usage

```
qq multitenancy_nfs_modify_global_settings [-h] [--enable-v4 | --disable-v4] [--enable-krb5 | --disable-krb5] [--enable-krb5p | --disable-krb5p] [--enable-krb5i | --disable-krb5i] [--enable-auth-sys | --disable-auth-sys] [--idmap-domain OVERRIDE | --clear-idmap-domain]
```

Flags

Flag Name	Required	Description
<code>--enable-v4</code>	No	Enables mounting with the NFSv4 protocol
<code>--disable-v4</code>	No	Disables mounting with the NFSv4 protocol
<code>--enable-krb5</code>	No	Enables mounting with KRB5 security
<code>--disable-krb5</code>	No	Disables mounting with KRB5 security
<code>--enable-krb5p</code>	No	Enables mounting with KRB5p security
<code>--disable-krb5p</code>	No	Disables mounting with KRB5p security
<code>--enable-krb5i</code>	No	Enables mounting with KRB5i security
<code>--disable-krb5i</code>	No	Disables mounting with KRB5i security
<code>--enable-auth-sys</code>	No	Enables mounting with AUTH_SYS security
<code>--disable-auth-sys</code>	No	Disables mounting with AUTH_SYS security
<code>--idmap-domain</code>	No	Sets a custom domain for mapping NFSv4 string identities.

<code>--clear-idmap-domain</code>	No	Clears the custom idmap domain.
-----------------------------------	----	---------------------------------

qq multitenancy_nfs_modify_settings

This section explains how to use the `qq multitenancy_nfs_modify_settings` command.

Description

Modify NFS settings for a tenant

Usage

```
qq multitenancy_nfs_modify_settings [-h] --tenant-id TENANT_ID [--enable-v4 | --disable-v4] [--enable-krb5 | --disable-krb5] [--enable-krb5p | --disable-krb5p] [--enable-krb5i | --disable-krb5i] [--enable-auth-sys | --disable-auth-sys] [--idmap-domain OVERRIDE | --clear-idmap-domain]
```

Flags

Flag Name	Required	Description
<code>--tenant-id</code>	Yes	ID of tenant to modify settings for
<code>--enable-v4</code>	No	Enables mounting with the NFSv4 protocol
<code>--disable-v4</code>	No	Disables mounting with the NFSv4 protocol
<code>--enable-krb5</code>	No	Enables mounting with KRB5 security
<code>--disable-krb5</code>	No	Disables mounting with KRB5 security
<code>--enable-krb5p</code>	No	Enables mounting with KRB5p security
<code>--disable-krb5p</code>	No	Disables mounting with KRB5p security
<code>--enable-krb5i</code>	No	Enables mounting with KRB5i security
<code>--disable-krb5i</code>	No	Disables mounting with KRB5i security
<code>--enable-auth-sys</code>	No	Enables mounting with AUTH_SYS security
<code>--disable-auth-sys</code>	No	Disables mounting with AUTH_SYS security
<code>--idmap-domain</code>	No	Sets a custom domain for mapping NFSv4 string identities.

<code>--clear-idmap-domain</code>	No	Clears the custom idmap domain.
-----------------------------------	----	---------------------------------

qq multitenancy_smb_delete_settings

This section explains how to use the `qq multitenancy_smb_delete_settings` command.

Description

Delete SMB settings for a tenant

Usage

```
qq multitenancy_smb_delete_settings [-h] --tenant-id TENANT_ID
```

Flags

Flag Name	Required	Description
<code>--tenant-id</code>	Yes	ID of the tenant to delete settings for

qq multitenancy_smb_get_global_settings

This section explains how to use the `qq multitenancy_smb_get_global_settings` command.

Description

Retrieve global default SMB settings

Usage

```
qq multitenancy_smb_get_global_settings [-h]
```

qq multitenancy_smb_get_settings

This section explains how to use the `qq multitenancy_smb_get_settings` command.

Description

Retrieve SMB settings for a tenant

Usage

```
qq multitenancy_smb_get_settings [-h] --tenant-id TENANT_ID
```

Flags

Flag Name	Required	Description
<code>--tenant-id</code>	Yes	ID of tenant to get settings for

qq multitenancy_smb_list_settings

This section explains how to use the `qq multitenancy_smb_list_settings` command.

Description

Retrieve SMB settings for all tenant that have tenant-specific settings configured

Usage

```
qq multitenancy_smb_list_settings [-h]
```

qq multitenancy_smb_modify_global_settings

This section explains how to use the `qq multitenancy_smb_modify_global_settings` command.

Description

Modify global default SMB settings

Usage

```
qq multitenancy_smb_modify_global_settings [-h] [-e {none,preferred,required}] [-d dialect_1 [dialect_2 ...]] [--hide-shares-from-unauthorized-hosts {true,false}] [--hide-shares-from-unauthorized-users {true,false}] [--snapshot-directory-mode {visible,hidden,disabled}] [--bypass-traverse-checking {true,false}] [--signing-required {true,false}]
```

Flags

Flag Name	Required	Description
<code>-e</code>	No	Server encryption mode to set
<code>-d</code>	No	Specify a space-separated list of SMB dialects that clients are permitted to negotiate. To disable SMB, specify <code>-d ""</code> . Available dialects: <code>smb2_dialect_2_002</code> , <code>smb2_dialect_2_1</code> , <code>smb2_dialect_3_0</code> , <code>smb2_dialect_3_11</code> . Alternatively, use <code>-d ALL</code> to allow all supported dialects.
<code>--hide-shares-from-unauthorized-hosts</code>	No	Configure share listing to omit shares to which the requesting host isn't authorized to connect.
<code>--hide-shares-from-unauthorized-users</code>	No	Configure share listing to omit shares to which the requesting user isn't authorized to connect. Important: Clients which don't have passwordless authentication typically list shares by using guest privileges. This flag typically hides all shares from this client type.

--snapshot-directory-mode	No	When you set this flag to visible, the .snapshot directory appears at the root of shares during directory listing operations. The .snapshot directory is also accessible by name in any directory. When you set this flag to hidden, .snapshot directories do not appear in directory listings but remains accessible by name. When you set this flag to disabled, .snapshot directories are not accessible and snapshots are available only through the Restore Previous Versions dialog box on Windows.
--bypass-traverse-checking	No	Enables bypass traverse checking for all users and directories. For example, a user who tries to access directory /x/y and has permissions to the /x directory but not to the /x/y directory can access the /x/y directory. A user still requires permissions to the /x directory to view its contents.
--signing-required	No	If the user is not a guest, require all messages to be signed. This flag applies to all SMB shares.

qq multitenancy_smb_modify_settings

This section explains how to use the `qq multitenancy_smb_modify_settings` command.

Description

Modify SMB settings for a tenant

Usage

```
qq multitenancy_smb_modify_settings [-h] --tenant-id TENANT_ID [-e {none,preferred,required}] [-d dialect_1 [dialect_2 ...]] [--hide-shares-from-unauthorized-hosts {true,false}] [--hide-shares-from-unauthorized-users {true,false}] [--snapshot-directory-mode {visible,hidden,disabled}] [--bypass-traverse-checking {true,false}] [--signing-required {true,false}]
```

Flags

Flag Name	Required	Description
<code>--tenant-id</code>	Yes	ID of tenant to modify settings for
<code>-e</code>	No	Server encryption mode to set
<code>-d</code>	No	Specify a space-separated list of SMB dialects that clients are permitted to negotiate. To disable SMB, specify <code>-d ""</code> . Available dialects: <code>smb2_dialect_2_002</code> , <code>smb2_dialect_2_1</code> , <code>smb2_dialect_3_0</code> , <code>smb2_dialect_3_11</code> . Alternatively, use <code>-d ALL</code> to allow all supported dialects.
<code>--hide-shares-from-unauthorized-hosts</code>	No	Configure share listing to omit shares to which the requesting host isn't authorized to connect.
<code>--hide-shares-from-unauthorized-users</code>	No	Configure share listing to omit shares to which the requesting user isn't authorized to connect. Important: Clients which don't have passwordless authentication typically list shares by using guest privileges. This flag typically hides all shares from this client type.

--snapshot-directory-mode	No	When you set this flag to visible, the .snapshot directory appears at the root of shares during directory listing operations. The .snapshot directory is also accessible by name in any directory. When you set this flag to hidden, .snapshot directories do not appear in directory listings but remains accessible by name. When you set this flag to disabled, .snapshot directories are not accessible and snapshots are available only through the Restore Previous Versions dialog box on Windows.
--bypass-traverse-checking	No	Enables bypass traverse checking for all users and directories. For example, a user who tries to access directory /x/y and has permissions to the /x directory but not to the /x/y directory can access the /x/y directory. A user still requires permissions to the /x directory to view its contents.
--signing-required	No	If the user is not a guest, require all messages to be signed. This flag applies to all SMB shares.

qq network_backend_interfaces

This section explains how to use the `qq network_backend_interfaces` command.

Description

Retrieve the list of backend interfaces for every node in the cluster.

Usage

```
qq network_backend_interfaces [-h]
```

qq network_create_network

This section explains how to use the `qq network_create_network` command.

Description

Add a network to the cluster-wide network config.

Usage

```
qq network_create_network [-h] --network-id NETWORK_ID --name NAME [--tenant-id TENANT_ID] {host_managed,dhcp,static} ...
```

Flags

Flag Name	Required	Description
<code>--network-id</code>	Yes	Network ID
<code>--name</code>	Yes	Network name
<code>--tenant-id</code>	No	The tenant that the network will be assigned to. If only one tenant exists, the network will default to that tenant. Otherwise, not specifying the tenant will create the network unassigned.

Positional Options

Option Name	Description
<code>assigned_by</code>	The kind of network you want to add.

qq network_frontend_interfaces

This section explains how to use the `qq network_frontend_interfaces` command.

Description

Retrieve the list of frontend interfaces for every node in the cluster.

Usage

```
qq network_frontend_interfaces [-h]
```


qq network_get_config

This section explains how to use the `qq network_get_config` command.

Description

Retrieve the cluster-wide network config

Usage

```
qq network_get_config [-h] [-o OUTPUT]
```

Flags

Flag Name	Required	Description
<code>-o</code>	No	The file to which the network config should be written.

qq network_list_connections

This section explains how to use the `qq network_list_connections` command.

Examples

To ensure the optimal performance of your cluster, its client connections must be distributed evenly.

To View Client Connections in JSON Format

Run the `qq network_list_connections` command to list the IP address and protocol for each client.

The following is example output.

```
[{
  "connections": [{
    "network_address": "203.0.113.0",
    "type": "CONNECTION_TYPE_SMB"
  }, {
    "network_address": "203.0.113.1",
    "type": "CONNECTION_TYPE_NFS"
  }],
  "id": 1
},
...
]
```

To View the Client Connection Counts

Run the `qq network_list_connections` command and use the `--counts` flag to view the balance of client connections.

Note

Using the `--counts` flag returns only the SMB and NFS connections without the client IP addresses.

The following is example output.

```
Total: SMB 70 NFS 30
Node1: SMB 17 NFS 8
Node2: SMB 17 NFS 7
Node3: SMB 18 NFS 6
Node4: SMB 18 NFS 9
```

Description

Get the list of SMB and NFS protocol connections per node.

Usage

```
qq network_list_connections [-h] [-c | --json]
```

Flags

Flag Name	Required	Description
<code>-c</code>	No	Pretty-print connection counts for the cluster and each node
<code>--json</code>	No	Print json instead of default pretty-printed connection table

qq network_modify_interface

This section explains how to use the `qq network_modify_interface` command.

Description

Modify a network interface in the cluster-wide network config.

Usage

```
qq network_modify_interface [-h] {bond,vlan} ...
```

Positional Options

Option Name	Description
<code>interface</code>	The kind of interface you want to modify.

qq network_modify_network

This section explains how to use the `qq network_modify_network` command.

Description

Modify a network in the cluster-wide network config.

Usage

```
qq network_modify_network [-h] --network-id NETWORK_ID [--name NAME] [--tenant-id TENANT_ID | --clear-tenant-id] {host_managed,dhcp,static} ...
```

Flags

Flag Name	Required	Description
<code>--network-id</code>	Yes	Network ID
<code>--name</code>	No	Network name
<code>--tenant-id</code>	No	The tenant that the network will be assigned to. If only one tenant exists, the network will default to that tenant. Otherwise, not specifying the tenant will create the network unassigned.
<code>--clear-tenant-id</code>	No	Clear the tenant from the network, making the network unassigned

Positional Options

Option Name	Description
<code>assigned_by</code>	The kind of network you want to add.

qq network_put_config

This section explains how to use the `qq network_put_config` command.

Description

Validate or overwrite the cluster-wide network configuration.

Usage

```
qq network_put_config [-h] [--dry-run] (--file FILE | --modify | --templates)
```

Flags

Flag Name	Required	Description
<code>--dry-run</code>	No	Validate a new cluster-wide network config without writing it to disk.
<code>--file</code>	No	The path to the JSON file that contains your new cluster-wide network config.
<code>--modify</code>	No	Open the current cluster-wide network config in your default editor. After saving and closing your editor, the modified config will be validated.
<code>--templates</code>	No	Print out the templates for configuring the API endpoint.

qq network_remove_network

This section explains how to use the `qq network_remove_network` command.

Description

Delete a network from the cluster-wide network config.

Usage

```
qq network_remove_network [-h] --network-id NETWORK_ID [--delete-orphaned-vlans]
```

Flags

Flag Name	Required	Description
<code>--network-id</code>	Yes	Network to delete
<code>--delete-orphaned-vlans</code>	No	Delete the vlan associated with the specified network if it is the only network on the VLAN.

qq network_status

This section explains how to use the `qq network_status` command.

Description

Retrieve the comprehensive network status

Usage

```
qq network_status [-h] [--node-id NODE_ID]
```

Flags

Flag Name	Required	Description
<code>--node-id</code>	No	Node ID

qq nexus_get_config

This section explains how to use the `qq nexus_get_config` command.

Description

Get Nexus connection configuration

Usage

```
qq nexus_get_config [-h]
```

qq nexus_get_registration

This section explains how to use the `qq nexus_get_registration` command.

Description

Get Nexus registration status

Usage

```
qq nexus_get_registration [-h]
```

qq nexus_set_config

This section explains how to use the `qq nexus_set_config` command.

Description

Set Nexus connection configuration

Usage

```
qq nexus_set_config [-h] [--enable | --disable] [--nexus-host NEXUS_HOST] [--nexus-port NEXUS_PORT] [--nexus-interval NEXUS_INTERVAL] [--enable-remote-support | --disable-remote-support] [--enable-sso | --disable-sso]
```

Flags

Flag Name	Required	Description
<code>--enable</code>	No	Enable Nexus connection
<code>--disable</code>	No	Disable Nexus connection
<code>--nexus-host</code>	No	Nexus host address
<code>--nexus-port</code>	No	Nexus port number
<code>--nexus-interval</code>	No	Nexus metrics interval in seconds
<code>--enable-remote-support</code>	No	Enable remote support capability
<code>--disable-remote-support</code>	No	Disable remote support capability
<code>--enable-sso</code>	No	Enable SSO capability
<code>--disable-sso</code>	No	Disable SSO capability

qq nexus_set_registration

This section explains how to use the `qq nexus_set_registration` command.

Description

Set Nexus registration or delete registration

Usage

```
qq nexus_set_registration [-h] (--delete | --join-key JOIN_KEY)
```

Flags

Flag Name	Required	Description
<code>--delete</code>	No	Delete Nexus registration and forget all registration info
<code>--join-key</code>	No	Join key for registering with Nexus

qq nfs_add_export

This section explains how to use the `qq nfs_add_export` command.

Example

To Configure Required Authentication Modes for Different Hosts

In the following example, we configure three export restrictions.

- The first export restriction allows only the specified hosts to use any authentication mode to access the NFS export.
- The second export restriction allows all hosts matching the wildcard pattern that use the `@KRB5` authentication mode to access the NFS export.
- The third export restriction allows any hosts that use the `@KRB5P` authentication mode to access the NFS export.

```

{
  "restrictions" : [
    {
      "read_only" : true,
      "host_restrictions" : [ "203.0.113.0", "203.0.113.0/24" ],
      "required_authentication_mode": "AUTHENTICATION_MODE_NONE",
      "user_mapping" : "root",
      "map_to_user": {
        "id_type" : "LOCAL_USER",
        "id_value" : "500"
      }
    },
    {
      "read_only" : false,
      "host_restrictions" : [ "*.example.com" ],
      "required_authentication_mode": "AUTHENTICATION_MODE_KRB5",
      "user_mapping" : "none"
    },
    {
      "read_only" : true,
      "host_restrictions" : [],
      "required_authentication_mode": "AUTHENTICATION_MODE_KRB5P",
      "user_mapping" : "all",
      "map_to_user" : {
        "id_type" : "NFS_UID",
        "id_value" : "500"
      },
      "map_to_group": {
        "id_type" : "NFS_GID",
        "id_value" : "501"
      }
    }
  ]
}

```

Description

Add a new NFS export

Usage

```

qq nfs_add_export [-h] --export-path EXPORT_PATH --fs-path FS_PATH [--tenant-id TENANT_ID] [--description DESCRIPTION] (--no-restrictions | --restrictions JSON_FILE_PATH) [--create-fs-path] [--fields-to-present-as-32-bit FIELD [FIELD ...]]

```

Flags

Flag Name	Required	Description
<code>--export-path</code>	Yes	NFS Export path
<code>--fs-path</code>	Yes	Filesystem path
<code>--tenant-id</code>	No	ID of the tenant to add the export to
<code>--description</code>	No	Description of this export
<code>--no-restrictions</code>	No	Specify no restrictions for this export.
<code>--restrictions</code>	No	Path to local file containing the restrictions in JSON format. host_restrictions is a comma separated list of: IPs IP ranges host-names wildcarded hostnames required_authentication_mode can be: "AUTHENTICATION_MODE_NONE" "AUTHENTICATION_MODE_KRB5" "AUTHENTICATION_MODE_KRB5I" "AUTHENTICATION_MODE_KRB5P" kerberos security flavors: KRB5: basic KRB5I: auth Integrity KRB5P: Privacy user_mapping can be: "none" "root" "all" map_to_user can be: "{ "id_type": "LOCAL_USER", "id_value": "" }" or "{ "id_type": "NFS_UID", "id_value": "" }" map_to_group can be: "{ "id_type": "NFS_GID", "id_value": "" }" If user_mapping is not "none", then: either specify "map_to_user" as a local user or specify both "map_to_user" and "map_to_group" as NFS user/group. ==Example JSON==: { "restrictions": [{ "read_only": true, "host_restrictions": ["1.2.3.1", "1.100.0.0/24"], "required_authentication_mode": "AUTHENTICATION_MODE_NONE", "user_mapping": "root", "map_to_user": { "id_type": "LOCAL_USER", "id_value": "500" } }, { "read_only": false, "host_restrictions": ["*.example.com"], "required_authentication_mode": "AUTHENTICATION_MODE_KRB5", "user_mapping": "none" }, { "read_only": true, "host_restrictions": [], "required_authentication_mode": "AUTHENTICATION_MODE_KRB5P", "user_mapping": "all", "map_to_user": { "id_type": "NFS_UID", "id_value": "500" }, "map_to_group": { "id_type": "NFS_GID", "id_value": "501" } }] }
<code>--create-fs-path</code>	No	Creates the specified filesystem path if it does not exist

<code>--fields-to-present-as-32-bit</code>	No	Fields that are forced to fit in 32 bits for the export, to support legacy clients and applications. Choices are: ['FILE_IDS', 'FILE_SIZES', 'FS_SIZE', 'NONE'] FILE_IDS: will hash file IDs (inode numbers), which can be observed by "stat", and is also necessary for some deprecated linux system calls (e.g. to list a directory) to work. FS_SIZE: saturates the available, used, and total capacity reported to tools like "df" to 4GiB. FILE_SIZES: saturates the reported size of individual files to 4GiB, and should be used with caution as it could cause application misbehavior in the handling of larger files. NONE: explicitly specifies no 32 bit mapping.
---	-----------	--

qq nfs_delete_export

This section explains how to use the `qq nfs_delete_export` command.

Description

Delete an export

Usage

```
qq nfs_delete_export [-h] (--export-id EXPORT_ID | --export-path EXPORT_PATH) [--tenant-id TENANT_ID]
```

Flags

Flag Name	Required	Description
<code>--export-id</code>	No	ID of export to delete
<code>--export-path</code>	No	Path of export to delete
<code>--tenant-id</code>	No	ID of the tenant the export is in. Only used if using the <code>--export-path</code> argument.

qq nfs_get_export

This section explains how to use the `qq nfs_get_export` command.

Description

Get an export

Usage

```
qq nfs_get_export [-h] (--export-id EXPORT_ID | --export-path EXPORT_PATH) [--tenant-id TENANT_ID] [--json]
```

Flags

Flag Name	Required	Description
<code>--export-id</code>	No	ID of export to modify
<code>--export-path</code>	No	Path of export to modify
<code>--tenant-id</code>	No	ID of the tenant to get the export from. Only used if using the <code>--export-path</code> argument.
<code>--json</code>	No	Print raw response JSON.

qq nfs_get_settings

This section explains how to use the `qq nfs_get_settings` command.

Description

Retrieve current NFS server configuration.

Usage

```
qq nfs_get_settings [-h]
```

qq nfs_list_exports

This section explains how to use the `qq nfs_list_exports` command.

Description

List all NFS exports

Usage

```
qq nfs_list_exports [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Print raw response JSON.

qq nfs_mod_export

This section explains how to use the `qq nfs_mod_export` command.

Description

Modify an export

Usage

```
qq nfs_mod_export [-h] (--export-id EXPORT_ID | --export-path EXPORT_PATH) [--tenant-id TENANT_ID] [--new-export-path NEW_EXPORT_PATH] [--new-tenant-id NEW_TENANT_ID] [--fs-path FS_PATH] [--description DESCRIPTION] [--no-restrictions | --restrictions JSON_FILE_PATH] [--create-fs-path] [--field s-to-present-as-32-bit FIELD [FIELD ...]]
```

Flags

Flag Name	Required	Description
<code>--export-id</code>	No	ID of export to modify
<code>--export-path</code>	No	Path of export to modify
<code>--tenant-id</code>	No	ID of the tenant the export is in. Only used if using the <code>--export-path</code> argument.
<code>--new-export-path</code>	No	Change NFS export path
<code>--new-tenant-id</code>	No	Change tenant that export is in
<code>--fs-path</code>	No	Change filesystem path
<code>--description</code>	No	Description of this export
<code>--no-restrictions</code>	No	Specify no restrictions for this export.

--restrictions	No	Path to local file containing the restrictions in JSON format. host_restrictions is a comma separated list of: IPs IP ranges host-names wildcarded hostnames required_authentication_mode can be: "AUTHENTICATION_MODE_NONE" "AUTHENTICATION_MODE_KRB5" "AUTHENTICATION_MODE_KRB5I" "AUTHENTICATION_MODE_KRB5P" kerberos security flavors: KRB5: basic KRB5I: auth Integrity KRB5P: Privacy user_mapping can be: "none" "root" "all" map_to_user can be: "{ "id_type": "LOCAL_USER", "id_value": "" }" or "{ "id_type": "NFS_UID", "id_value": "" }" map_to_group can be: "{ "id_type": "NFS_GID", "id_value": "" }" If user_mapping is not "none", then: either specify "map_to_user" as a local user or specify both "map_to_user" and "map_to_group" as NFS user/group. ==Example JSON==: { "restrictions" : [{ "read_only" : true, "host_restrictions" : ["1.2.3.1", "1.100.0.0/24"], "required_authentication_mode": "AUTHENTICATION_MODE_NONE", "user_mapping" : "root", "map_to_user": { "id_type" : "LOCAL_USER", "id_value" : "500" } }, { "read_only" : false, "host_restrictions" : ["*.example.com"], "required_authentication_mode": "AUTHENTICATION_MODE_KRB5", "user_mapping" : "none" }, { "read_only" : true, "host_restrictions" : [], "required_authentication_mode": "AUTHENTICATION_MODE_KRB5P", "user_mapping" : "all", "map_to_user" : { "id_type" : "NFS_UID", "id_value" : "500" }, "map_to_group": { "id_type" : "NFS_GID", "id_value" : "501" } }] }
--create-fs-path	No	Creates the specified filesystem path if it does not exist
--fields-to-present-as-32-bit	No	Fields that are forced to fit in 32 bits for the export, to support legacy clients and applications. Choices are: ['FILE_IDS', 'FILE_SIZES', 'FS_SIZE', 'NONE'] FILE_IDS: will hash file IDs (inode numbers), which can be observed by "stat", and is also necessary for some deprecated linux system calls (e.g. to list a directory) to work. FS_SIZE: saturates the available, used, and total capacity reported to tools like "df" to 4GiB. FILE_SIZES: saturates the reported size of individual files to 4GiB, and should be used with caution as it could cause application misbehavior in the handling of larger files. NONE: explicitly specifies no 32 bit mapping.

qq nfs_mod_export_host_access

This section explains how to use the `qq nfs_mod_export_host_access` command.

Description

Modify the access hosts are granted to an export

Usage

```
qq nfs_mod_export_host_access [-h] (--export-id EXPORT_ID | --export-path EXPORT_PATH) [--tenant-id TENANT_ID] [--json] {add_entry,modify_entry,remove_entry} ...
```

Flags

Flag Name	Required	Description
<code>--export-id</code>	No	ID of export to modify
<code>--export-path</code>	No	Path of export to modify
<code>--tenant-id</code>	No	ID of the tenant the export is in. Only used if using the <code>--export-path</code> argument
<code>--json</code>	No	Print raw response JSON

qq nfs_modify_settings

This section explains how to use the `qq nfs_modify_settings` command.

Description

Modify current NFS server configuration.

Usage

```
qq nfs_modify_settings [-h] [--enable-v4 | --disable-v4] [--enable-krb5 | --disable-krb5] [--enable-krb5p | --disable-krb5p] [--enable-krb5i | --disable-krb5i] [--enable-auth-sys | --disable-auth-sys] [--idmap-domain OVERRIDE | --clear-idmap-domain]
```

Flags

Flag Name	Required	Description
<code>--enable-v4</code>	No	Enables mounting with the NFSv4 protocol
<code>--disable-v4</code>	No	Disables mounting with the NFSv4 protocol
<code>--enable-krb5</code>	No	Enables mounting with KRB5 security
<code>--disable-krb5</code>	No	Disables mounting with KRB5 security
<code>--enable-krb5p</code>	No	Enables mounting with KRB5p security
<code>--disable-krb5p</code>	No	Disables mounting with KRB5p security
<code>--enable-krb5i</code>	No	Enables mounting with KRB5i security
<code>--disable-krb5i</code>	No	Disables mounting with KRB5i security
<code>--enable-auth-sys</code>	No	Enables mounting with AUTH_SYS security
<code>--disable-auth-sys</code>	No	Disables mounting with AUTH_SYS security
<code>--idmap-domain</code>	No	Sets a custom domain for mapping NFSv4 string identities.
<code>--clear-idmap-domain</code>	No	Clears the custom idmap domain.

qq node_chassis_status_get

This section explains how to use the `qq node_chassis_status_get` command.

Description

Get the status of node chassis

Usage

```
qq node_chassis_status_get [-h] [--node NODE]
```

Flags

Flag Name	Required	Description
<code>--node</code>	No	Node ID

qq node_state_get

This section explains how to use the `qq node_state_get` command.

Examples

The following is example output.

```
{  
  "cluster_id": "12345a6b-7c89-0d12-3456-78fe9012f345",  
  "node_id": 1,  
  "state": "ACTIVE"  
}
```

Description

Get the operational state of the node

Usage

```
qq node_state_get [-h]
```

qq nodes_list

This section explains how to use the `qq nodes_list` command.

Examples

To List Information about Nodes in Your Cluster

Run the `qq nodes_list` command.

The following is example output. This example shows a cluster with 4 nodes.

```
[{
  "id": 1,
  "label": "d0:82:77:72:01:1f",
  "model_number": "Q0626",
  "node_name": "qumulo-1",
  "node_status": "online",
  "uuid": "12345a6b-7c89-0d12-3456-78fe9012f345"
},{
  "id": 2,
  "label": "a0:2c:55:a3:3d:ce",
  "model_number": "Q0626",
  "node_name": "qumulo-2",
  "node_status": "online",
  "uuid": "abcde1f2-g3hi-j4kl-mnop-qr56stuv7wxy"
},{
  "id": 3,
  "label": "ec:fd:7d:3f:0b:e5",
  "model_number": "Q0626",
  "node_name": "qumulo-3",
  "node_status": "online",
  "uuid": "c3a7be37-d65b-42ec-831a-1d0e94a171de"
},{
  "id": 4,
  "label": "c4:e9:73:89:7c:76",
  "model_number": "Q0626",
  "node_name": "qumulo-4",
  "node_status": "online",
  "uuid": "31b43286-2b03-4dc7-af27-a8c4c35719ab"
}]
```

Description

List nodes

Usage

```
qq nodes_list [-h] [--node NODE]
```

Flags

Flag Name	Required	Description
<code>--node</code>	No	Node ID

qq object_backed_fault_tolerance_get

This section explains how to use the `qq object_backed_fault_tolerance_get` command.

Description

Get the current fault tolerance of an object-backed cluster.

Usage

```
qq object_backed_fault_tolerance_get [-h]
```

qq object_portal_create_bridge

This section explains how to use the `qq object_portal_create_bridge` command.

Description

Create a bridge filesystem rooted at an external object bucket.

Usage

```
qq object_portal_create_bridge [-h] --bucket-uri BUCKET_URI --mount-path MOUNT_PATH
[--key-prefix KEY_PREFIX] [--delimiter DELIMITER] [--key-vault-hostname KEY_VAULT_HOSTNAME]
[--notification-queue-url NOTIFICATION_QUEUE_URL] --protocol-access
{READ_WRITE_EXPORT,READ_ONLY} --metadata-import {OFF,AUTO}
```

Flags

Flag Name	Required	Description
<code>--bucket-uri</code>	Yes	Full bucket URI. Examples: <code>https://my-bucket.s3.us-west-2.amazonaws.com/</code> or <code>https://myaccount.blob.core.windows.net/my-container</code>
<code>--mount-path</code>	Yes	Absolute path in the primary filesystem where the bridge will be mounted. The parent directory must already exist; the basename is created during bridge creation.
<code>--key-prefix</code>	No	Optional prefix inside the bucket, matched against object keys as it is written. Must end with the delimiter. An empty prefix is refused; omit this option to bridge the whole bucket.
<code>--delimiter</code>	No	Object-key separator used to project bridge directories. Defaults to <code>"/"</code> .
<code>--key-vault-hostname</code>	No	Azure Key Vault hostname (e.g. <code>my-vault.vault.azure.net</code>) from which to fetch SAS tokens for an Azure Blob bucket.
<code>--notification-queue-url</code>	No	URL of an SQS queue that delivers this bucket's object-change notifications. Omit to use cache expiry only.

<code>--protocol-access</code>	Yes	READ_ONLY rejects protocol data and namespace writes to the bridge while the bucket keeps converging; file attributes stay writable. READ_WRITE_EXPORT leaves both writable and requires bucket versioning. Immutable after creation.
<code>--metadata-import</code>	Yes	Import file-mover object metadata (ownership, permissions, ACLs, timestamps) onto bridge inodes. AUTO translates objects matching a known mover dialect; OFF inherits everything from the parent directory. Immutable after creation.

qq object_portal_delete_bridge

This section explains how to use the `qq object_portal_delete_bridge` command.

Description

Delete a bridge filesystem, unmounting it and reclaiming its filesystem in the background.

Usage

```
qq object_portal_delete_bridge [-h] --filesystem-uuid FILESYSTEM_UUID
```

Flags

Flag Name	Required	Description
<code>--filesystem-uuid</code>	Yes	Filesystem UUID of the bridge to delete.

qq object_portal_get_bridge

This section explains how to use the `qq object_portal_get_bridge` command.

Description

Get the configuration of one bridge filesystem.

Usage

```
qq object_portal_get_bridge [-h] --filesystem-uuid FILESYSTEM_UUID
```

Flags

Flag Name	Required	Description
<code>--filesystem-uuid</code>	Yes	Filesystem UUID of the bridge.

qq object_portal_list_bridges

This section explains how to use the `qq object_portal_list_bridges` command.

Description

List every bridge filesystem on the cluster.

Usage

```
qq object_portal_list_bridges [-h] [-j]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Pretty-print JSON

qq object_portal_refresh

This section explains how to use the `qq object_portal_refresh` command.

Description

Converge one object key against its bucket now, without waiting for an event. An object no longer in the bucket has its local file deleted, or its directory marker dropped along with a chain of empty parent directories.

Usage

```
qq object_portal_refresh [-h] --bucket-uri BUCKET_URI --key KEY [--mode {MERGE,OVERWRITE}]
```

Flags

Flag Name	Required	Description
<code>--bucket-uri</code>	Yes	Bucket URI as it appears in the bridge's configuration. The value must match a configured bucket URI exactly. The server answers 200 and discards the call otherwise.
<code>--key</code>	Yes	Object key within the bucket. A directory is named by its marker key, including the trailing delimiter.
<code>--mode</code>	No	MERGE (the default) leaves locally changed attributes alone. OVERWRITE discards them for every attribute the object carries and cannot be undone.

qq portal_accept_hub

This section explains how to use the `qq portal_accept_hub` command.

Description

Accept the specified pending hub portal. Accepting a hub portal establishes a relationship with a spoke portal but does not provide data access automatically.

Usage

```
qq portal_accept_hub [-h] -i ID [-j] [-n] [-A] (-m SPOKE_HOSTS | -a SPOKE_ADDRESS)
[-p SPOKE_PORT]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Hub portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>-A</code>	No	Additionally authorize all pending hub portal roots
<code>-m</code>	No	The IP addresses and TCP ports of the remote cluster. Use a comma-delimited list to specify multiple hosts. Use colon as a separator after each IP address to provide custom TCP port (3713 is used by default). Ports specified this way override other --port arguments. Put brackets around an IPv6 address, such as [2001:db8::1] or [2001:db8::1]:4000. Use a dash to specify a range of IPv4 addresses that share their first three octets, such as 10.220.1.70-73 or 10.220.1.70-10.220.1.73. A port applies to the whole range.
<code>-a</code>	No	The IP address of a node in the remote cluster
<code>-p</code>	No	The TCP port for portal activity on the remote cluster. The default port 3713 is used if this field is not provided.

qq portal_authorize_hub_root

This section explains how to use the `qq portal_authorize_hub_root` command.

Description

Authorize the specified hub root directory for the specified hub portal. This allows the spoke portal to access the data in the hub root directory.

Usage

```
qq portal_authorize_hub_root [-h] -i ID [-j] [-n] (--hub-root-id HUB_ROOT_ID | --hub-root-path HUB_ROOT_PATH)
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Hub portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--hub-root-id</code>	No	File ID of the hub root directory
<code>--hub-root-path</code>	No	Path of the hub root directory

qq portal_create

This section explains how to use the `qq portal_create` command.

Example

To Propose an Initial Portal Relationship

Run the `qq portal_create` command and specify the spoke portal root directory, the proposed hub portal root directory on that cluster, and the IP addresses of the nodes in the remote cluster.

⚠ Important

- We strongly recommend using the `qq portal_create` command with the `--hub-hosts` flag to spread the workload across all nodes on the hub portal host cluster.
- For the command to succeed, don't use the backslash (\) to break the list of IP addresses across multiple lines.

For example:

```
qq portal_create \  
  --spoke-root /remote/projects \  
  --hub-address 203.0.113.0 \  
  --hub-root /projects \  
  --hub-root /projects \  
  --hub-hosts 203.0.113.1,203.0.113.2,203.0.113.3,203.0.113.4
```

Description

Create a spoke portal on the current cluster and propose a hub portal on another cluster

Usage

```
qq portal_create [-h] [--spoke-root SPOKE_ROOT] [--hub-root HUB_ROOT] [-j] [-n]  
[-r] (-m HUB_HOSTS | -a HUB_ADDRESS) [-p HUB_PORT]
```

Flags

Flag Name	Required	Description
-----------	----------	-------------

<code>--spoke-root</code>	No	The full path to the directory that serves as the spoke portal root directory. Qumulo Core creates this directory for you automatically. If this directory exists already, the system outputs an error.
<code>--hub-root</code>	No	The full path to the prospective directory that will serve as the hub portal root directory
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>-r</code>	No	Create a read-only spoke portal. Read-only spoke portals prevent users from creating or modifying files or directories under the hub portal root directory. To make the spoke portal writable later, run <code>`portal_modify_hub --type read-write`</code> on the hub cluster.
<code>-m</code>	No	The IP addresses and TCP ports of the remote cluster. Use a comma-delimited list to specify multiple hosts. Use colon as a separator after each IP address to provide custom TCP port (3713 is used by default). Ports specified this way override other <code>--port</code> arguments. Put brackets around an IPv6 address, such as <code>[2001:db8::1]</code> or <code>[2001:db8::1]:4000</code> . Use a dash to specify a range of IPv4 addresses that share their first three octets, such as <code>10.220.1.70-73</code> or <code>10.220.1.70-10.220.1.73</code> . A port applies to the whole range.
<code>-a</code>	No	The IP address of a node in the remote cluster
<code>-p</code>	No	The TCP port for portal activity on the remote cluster. The default port 3713 is used if this field is not provided.

qq portal_delete_hub

This section explains how to use the `qq portal_delete_hub` command.

Description

Delete a hub portal on the current cluster

Usage

```
qq portal_delete_hub [-h] -i ID [-j] [-n] [--force]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Hub portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--force</code>	No	Force the deletion of the hub portal. Caution: This operation deletes all data from the spoke portal, including any new and modified data on the spoke that has not yet synchronized with the hub portal. Data under the hub portal root directory is not affected.

qq portal_delete_spoke

This section explains how to use the `qq portal_delete_spoke` command.

Description

Delete a spoke portal on the current cluster

Usage

```
qq portal_delete_spoke [-h] -i ID [-j] [-n] [--force]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Spoke portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--force</code>	No	Force the deletion of the spoke portal. Caution: This operation deletes all data from the spoke portal, including any new and modified data on the spoke that has not yet synchronized with the hub portal. Data under the hub portal root directory is not affected.

qq portal_delete_spoke_root

This section explains how to use the `qq portal_delete_spoke_root` command.

Description

Delete the specified spoke root directory for the specified spoke portal. This action does not affect the data in the hub root directory. Requires connectivity with the hub portal host cluster.

Usage

```
qq portal_delete_spoke_root [-h] -i ID [-j] [-n] (--spoke-root-id SPOKE_ROOT_ID | --spoke-root-path SPOKE_ROOT_PATH)
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Spoke portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--spoke-root-id</code>	No	File ID of the spoke root directory
<code>--spoke-root-path</code>	No	Path of the spoke root directory

qq portal_deny_hub_root

This section explains how to use the `qq portal_deny_hub_root` command.

Description

Deny access to the specified hub root directory for the specified hub portal. This action does not affect the data in the hub root directory.

Usage

```
qq portal_deny_hub_root [-h] -i ID [-j] [-n] (--hub-root-id HUB_ROOT_ID | --hub-root-path HUB_ROOT_PATH)
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Hub portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--hub-root-id</code>	No	File ID of the hub root directory
<code>--hub-root-path</code>	No	Path of the hub root directory

qq portal_get_eviction_settings

This section explains how to use the `qq portal_get_eviction_settings` command.

Description

Retrieve the configuration for automated removal of cached data

Usage

```
qq portal_get_eviction_settings [-h]
```

qq portal_get_filesystem

This section explains how to use the `qq portal_get_filesystem` command.

Description

Retrieve portal information for a specific filesystem

Usage

```
qq portal_get_filesystem [-h] --uuid UUID [-j]
```

Flags

Flag Name	Required	Description
<code>--uuid</code>	Yes	Filesystem UUID
<code>-j</code>	No	Pretty-print JSON

qq portal_get_hub

This section explains how to use the `qq portal_get_hub` command.

Description

Get the configuration and status for a hub portal on the current cluster

Usage

```
qq portal_get_hub [-h] -i ID [-j] [-n] [-d]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Hub portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>-d</code>	No	Resolve peer IP addresses to names. The local cluster performs the lookup, so the names come from its DNS configuration and the caller needs the PRIVILEGE_DNS_USE privilege.

qq portal_get_spoke

This section explains how to use the `qq portal_get_spoke` command.

Description

Get the configuration and status for a spoke portal on the current cluster

Usage

```
qq portal_get_spoke [-h] -i ID [-j] [-n] [-d]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Spoke portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>-d</code>	No	Resolve peer IP addresses to names. The local cluster performs the lookup, so the names come from its DNS configuration and the caller needs the PRIVILEGE_DNS_USE privilege.

qq portal_list

This section explains how to use the `qq portal_list` command.

Description

Get the configuration and status for all portals on the current cluster

Usage

```
qq portal_list [-h] [-j]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Pretty-print JSON

qq portal_list_filesystems

This section explains how to use the `qq portal_list_filesystems` command.

Description

Retrieve portal information for all filesystems

Usage

```
qq portal_list_filesystems [-h] [-j]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Pretty-print JSON

qq portal_list_hubs

This section explains how to use the `qq portal_list_hubs` command.

Description

Get the configuration and status for all hub portals on the current cluster

Usage

```
qq portal_list_hubs [-h] [-j]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Pretty-print JSON

qq portal_list_quorum_events

This section explains how to use the `qq portal_list_quorum_events` command.

Description

List recent portal quorum success and abandon events recorded by the nodes of this cluster

Usage

```
qq portal_list_quorum_events [-h] [--begin-time BEGIN_TIME] [--end-time END_TIME]
[--type {success,abandon}] [--node-id NODE_ID] [--filesystem-uuid FILESYSTEM_UUID]
[--limit LIMIT]
```

Flags

Flag Name	Required	Description
<code>--begin-time</code>	No	Inclusive lower bound on event time, in RFC 3339 format or epoch seconds. If not specified, all available history is returned
<code>--end-time</code>	No	Exclusive upper bound on event time; defaults to the current system time
<code>--type</code>	No	Only return events of this kind
<code>--node-id</code>	No	Only return events recorded by this node
<code>--filesystem-uuid</code>	No	Only return events for the filesystem with this UUID
<code>--limit</code>	No	Maximum entries returned, oldest first (default 1000)

qq portal_list_spokes

This section explains how to use the `qq portal_list_spokes` command.

Description

Get the configuration and status for all spoke portals on the current cluster

Usage

```
qq portal_list_spokes [-h] [-j]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Pretty-print JSON

qq portal_modify_hub

This section explains how to use the `qq portal_modify_hub` command.

Description

Modify the spoke hosts and type of a hub portal

Usage

```
qq portal_modify_hub [-h] -i ID [-j] [-n] [--type {read-write,read-only}] [-m SPOKE_HOSTS | -a SPOKE_ADDRESS] [-p SPOKE_PORT]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Hub portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--type</code>	No	Change the type of the portal. Setting read-write takes effect immediately, as does setting read-only on a paused portal. Setting read-only on a read-write portal starts a transition that drains outstanding spoke writes; the portal reports the Quiescing state until the drain finishes.
<code>-m</code>	No	The IP addresses and TCP ports of the remote cluster. Use a comma-delimited list to specify multiple hosts. Use colon as a separator after each IP address to provide custom TCP port (3713 is used by default). Ports specified this way override other --port arguments. Put brackets around an IPv6 address, such as [2001:db8::1] or [2001:db8::1]:4000. Use a dash to specify a range of IPv4 addresses that share their first three octets, such as 10.220.1.70-73 or 10.220.1.70-10.220.1.73. A port applies to the whole range.
<code>-a</code>	No	The IP address of a node in the remote cluster
<code>-p</code>	No	The TCP port for portal activity on the remote cluster. The default port 3713 is used if this field is not provided.

qq portal_modify_spoke

This section explains how to use the `qq portal_modify_spoke` command.

Description

Modify the remote hub address and port for a spoke portal

Usage

```
qq portal_modify_spoke [-h] -i ID [-j] [-n] (-m HUB_HOSTS | -a HUB_ADDRESS) [-p HUB_PORT]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Spoke portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>-m</code>	No	The IP addresses and TCP ports of the remote cluster. Use a comma-delimited list to specify multiple hosts. Use colon as a separator after each IP address to provide custom TCP port (3713 is used by default). Ports specified this way override other --port arguments. Put brackets around an IPv6 address, such as [2001:db8::1] or [2001:db8::1]:4000. Use a dash to specify a range of IPv4 addresses that share their first three octets, such as 10.220.1.70-73 or 10.220.1.70-10.220.1.73. A port applies to the whole range.
<code>-a</code>	No	The IP address of a node in the remote cluster
<code>-p</code>	No	The TCP port for portal activity on the remote cluster. The default port 3713 is used if this field is not provided.

qq portal_ping

This section explains how to use the `qq portal_ping` command.

Description

Test connectivity from all local nodes to the specified remote hosts

Usage

```
qq portal_ping [-h] [-j | -b] (-m HOSTS | --spoke-id SPOKE_ID | --hub-id HUB_ID)
[-p PORTAL_PORT]
```

Flags

Flag Name	Required	Description
<code>-j</code>	No	Pretty-print JSON
<code>-b</code>	No	Summarize output if all connections are successful
<code>-m</code>	No	The IP addresses and TCP ports of the remote cluster. Use a comma-delimited list to specify multiple hosts. Use colon as a separator after each IP address to provide custom TCP port (3713 is used by default). Ports specified this way override other <code>--port</code> arguments. Put brackets around an IPv6 address, such as <code>[2001:db8::1]</code> or <code>[2001:db8::1]:4000</code> . Use a dash to specify a range of IPv4 addresses that share their first three octets, such as <code>10.220.1.70-73</code> or <code>10.220.1.70-10.220.1.73</code> . A port applies to the whole range.
<code>--spoke-id</code>	No	Ping all hub hosts defined in a local spoke portal
<code>--hub-id</code>	No	Ping all spoke hosts defined in a local hub portal
<code>-p</code>	No	The TCP port for portal activity on the remote cluster. The default port 3713 is used if this field is not provided.

qq portal_propose_spoke_root

This section explains how to use the `qq portal_propose_spoke_root` command.

Description

Propose a spoke root directory for the specified spoke portal. This creates a pending hub root directory on the paired remote hub portal.

Usage

```
qq portal_propose_spoke_root [-h] -i ID [-j] [-n] --spoke-root-path SPOKE_ROOT_PATH
--hub-root-path HUB_ROOT_PATH
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Spoke portal ID
<code>-j</code>	No	Pretty-print JSON
<code>-n</code>	No	Do not attempt to resolve file IDs present on the local cluster to paths.
<code>--spoke-root-path</code>	Yes	The full path to the directory that serves as the spoke portal root directory. Qumulo Core creates this directory for you automatically. If this directory exists already, the system outputs an error.
<code>--hub-root-path</code>	Yes	The full path to the prospective directory that will serve as the hub portal root directory

qq portal_set_eviction_settings

This section explains how to use the `qq portal_set_eviction_settings` command.

Description

Configure the automated removal of cached data

Usage

```
qq portal_set_eviction_settings [-h] -f FREE_THRESHOLD
```

Flags

Flag Name	Required	Description
<code>-f</code>	Yes	The threshold of remaining free capacity on a cluster, as a decimal number between 0 and 1, that triggers the automated removal of cached data. For example, if you set this value to 0.05, the system begins to remove cached data from spoke portals when the cluster is 95% full.

qq protection_status_get

This section explains how to use the `qq protection_status_get` command.

Description

Get cluster protection status

Usage

```
qq protection_status_get [-h]
```

qq quota_create_quota

This section explains how to use the `qq quota_create_quota` command.

Description

Create a directory quota

Usage

```
qq quota_create_quota [-h] [--path PATH] [--id ID] --limit LIMIT
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Path name
<code>--id</code>	No	File ID
<code>--limit</code>	Yes	Quota limit in bytes. Both base-10 and base-2 shorthand names are accepted: GB or GiB, TB or TiB (e.g. 50GB)

qq quota_delete_quota

This section explains how to use the `qq quota_delete_quota` command.

Description

Delete a directory quota

Usage

```
qq quota_delete_quota [-h] [--path PATH] [--id ID]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Path name
<code>--id</code>	No	File ID

qq quota_get_quota

This section explains how to use the `qq quota_get_quota` command.

Description

Get a directory quota

Usage

```
qq quota_get_quota [-h] [--path PATH] [--id ID]
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Path name
<code>--id</code>	No	File ID

qq quota_list_quotas

This section explains how to use the `qq quota_list_quotas` command.

Description

List all directory quotas

Usage

```
qq quota_list_quotas [-h] [--page-size PAGE_SIZE]
```

Flags

Flag Name	Required	Description
<code>--page-size</code>	No	Max quota entries to return per request

qq quota_update_quota

This section explains how to use the `qq quota_update_quota` command.

Description

Update a directory quota

Usage

```
qq quota_update_quota [-h] [--path PATH] [--id ID] --limit LIMIT
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	Path name
<code>--id</code>	No	File ID
<code>--limit</code>	Yes	Quota limit in bytes. Both base-10 and base-2 shorthand names are accepted: GB or GiB, TB or TiB (e.g. 50GB)

qq raw

This section explains how to use the `qq raw` command.

Description

Issue an HTTP request to a Qumulo REST endpoint. Content for modifying requests (i.e. PATCH, POST, and PUT) can be provided on stdin. Output is provided on stdout.

Usage

```
qq raw [-h] [--content-type {application/json,application/octet-stream}] {DELETE,GET,PATCH,POST,PUT} url
```

Flags

Flag Name	Required	Description
<code>--content-type</code>	No	Content MIME type for sending data with PATCH, POST, and PUT. Use application/octet-stream for binary input. (Default: application/json)

Positional Options

Option Name	Description
<code>method</code>	HTTP method. PATCH, POST, and PUT accept input on stdin
<code>url</code>	REST endpoint (e.g. /v1/ad/join)

qq reboot_pause

This section explains how to use the `qq reboot_pause` command.

Description

Pause a cluster-wide reboot

Usage

```
qq reboot_pause [-h]
```

qq reboot_resume

This section explains how to use the `qq reboot_resume` command.

Description

Resume a cluster-wide reboot

Usage

```
qq reboot_resume [-h]
```

qq reboot_start

This section explains how to use the `qq reboot_start` command.

Description

Start a cluster-wide reboot

Usage

```
qq reboot_start [-h] [--rolling] [--num-nodes NUM_NODES_TO_REBOOT] [--force]
```

Flags

Flag Name	Required	Description
<code>--rolling</code>	No	Reboot nodes one set at a time, depending on the number of node failures configured in the protection system
<code>--num-nodes</code>	No	Using the <code>--rolling</code> flag lets you specify the number of nodes to reboot at a time. The number of nodes must be greater than 0 and less than or equal to the number of node failures that your cluster permits. By default, this value is the number of permitted node failures minus 1 (1 node minimum).
<code>--force</code>	No	Do not prompt

qq reboot_status

This section explains how to use the `qq reboot_status` command.

Description

Retrieve status of reboot manager

Usage

```
qq reboot_status [-h]
```

qq replace_nodes

This section explains how to use the `qq replace_nodes` command.

Description

Replace configured nodes by adding nodes to a Qumulo cluster.

Usage

```
qq replace_nodes [-h] {register_plan,add_nodes_and_replace,get_plan,cancel_plan} ...
```

qq replication_abort_object_replication

This section explains how to use the `qq replication_abort_object_replication` command.

Description

Abort any ongoing replication job for the specified object replication relationship.

Usage

```
qq replication_abort_object_replication [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the object replication relationship

qq replication_abort_replication

This section explains how to use the `qq replication_abort_replication` command.

Description

Abort ongoing replication work for the specified source replication relationship.

Usage

```
qq replication_abort_replication [-h] --id ID [--skip-active-policy-snapshot {true,false}]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship
<code>--skip-active-policy-snapshot</code>	No	If set to true and the currently replicating snapshot was created by a policy, the next replication job will use the next queued snapshot instead of retrying the current one (default: false).

qq replication_add_blackout_window

This section explains how to use the `qq replication_add_blackout_window` command.

Description

Add a blackout window to the specified source replication relationship.

Usage

```
qq replication_add_blackout_window [-h] --id ID --start-time START_TIME --end-time END_TIME --days-of-week DAYS_OF_WEEK
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship.
<code>--start-time</code>	Yes	The 24 hour time of day start time for the blackout window (e.g. 15:30). Time is always in the timezone configured on the specified source replication relationship.
<code>--end-time</code>	Yes	The 24 hour time of day end time for the blackout window (e.g. 18:30) -- on the following day if earlier than the --start-time parameter.
<code>--days-of-week</code>	Yes	Days of the week the window applies to. Comma separated list (e.g. MON,TUE,WED,THU,FRI,SAT,SUN) or ALL.

qq replication_authorize

This section explains how to use the `qq replication_authorize` command.

Description

Authorize the specified replication relationship, establishing this cluster as the target of replication.

Usage

```
qq replication_authorize [-h] --id ID [--allow-non-empty-directory] [--allow-fs-path-create]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the target replication relationship
<code>--allow-non-empty-directory</code>	No	Allow the replication relationship to be authorized on a target directory containing existing data. Existing data in the target directory may be deleted or overwritten. If you wish to preserve this data, consider taking a snapshot before authorizing.
<code>--allow-fs-path-create</code>	No	Allow the target directory to be created with inherited permissions if it does not already exist

qq replication_create_object_relationship

This section explains how to use the `qq replication_create_object_relationship` command.

Description

Create an object replication relationship that initiates a copy of file data to or from S3.

Usage

```
qq replication_create_object_relationship [-h] (--local-directory-id LOCAL_DIRECTORY_ID | --local-directory-path LOCAL_DIRECTORY_PATH) --direction {COPY_TO_OBJECT,COPY_FROM_OBJECT} [--object-store-address OBJECT_STORE_ADDRESS] --object-folder OBJECT_FOLDER [--use-port USE_PORT] [--ca-certificate CA_CERTIFICATE] --bucket BUCKET [--bucket-addressing-style {BUCKET_STYLE_PATH,BUCKET_STYLE_VIRTUAL_HOSTED}] --region REGION --access-key-id ACCESS_KEY_ID [--secret-access-key SECRET_ACCESS_KEY]
```

Flags

Flag Name	Required	Description
<code>--local-directory-id</code>	No	File ID of the qumulo directory
<code>--local-directory-path</code>	No	Path of the qumulo directory
<code>--direction</code>	Yes	Whether data is to be copied to, or from, the object store.
<code>--object-store-address</code>	No	S3-compatible server address. If omitted, Amazon S3 address <code>s3.amazonaws.com</code> will be used.
<code>--object-folder</code>	Yes	Folder to use in the object store bucket. A slash separator is automatically used to specify a folder. For example, a folder "example" and a file path (relative to the <code>directory_path</code>) "dir/file" results in key "example/dir/file". Use empty value "" or "/" to replicate with the root of the bucket.

<code>--use-port</code>	No	HTTPS port to use when communicating with the object store (default: 443)
<code>--ca-certificate</code>	No	Path to a file containing the public certificate of the certificate authority to trust for connections to the object store, in PEM format. If not specified, the built-in trusted public CAs are used.
<code>--bucket</code>	Yes	Bucket in the object store to use for this relationship
<code>--bucket-addressing-style</code>	No	Addressing style for requests to the bucket. Set to <code>BUCKET_STYLE_PATH</code> for path-style addressing or <code>BUCKET_STYLE_VIRTUAL_HOSTED</code> for virtual hosted-style (the default). For Amazon S3, virtual hosted-style is recommended as path-style will be deprecated. Bucket names containing dots (".") or characters that are not valid in domain names may require path-style. The object-store-address should not include the bucket name, regardless of addressing style.
<code>--region</code>	Yes	Region the bucket is located in, e.g., us-west-2
<code>--access-key-id</code>	Yes	Access key ID to use when communicating with the object store
<code>--secret-access-key</code>	No	Secret access key to use when communicating with the object store

qq replication_create_source_relationship

This section explains how to use the `qq replication_create_source_relationship` command.

Description

Create a new replication relationship.

Usage

```
qq replication_create_source_relationship [-h] (--source-id SOURCE_ID | --source-path SOURCE_PATH) --target-path TARGET_PATH --target-address TARGET_ADDRESS [--target-port TARGET_PORT] [--enable-replication {true,false}] [--set-source-directory-read-only {true,false}] [--map-local-ids-to-nfs-ids {true,false}]
```

Flags

Flag Name	Required	Description
<code>--source-id</code>	No	File ID of the source directory
<code>--source-path</code>	No	Path to the source directory
<code>--target-path</code>	Yes	Path to the target directory
<code>--target-address</code>	Yes	The target IP address
<code>--target-port</code>	No	Network port to replicate to on the target (overriding default)

qq replication_delete_blackout_windows

This section explains how to use the `qq replication_delete_blackout_windows` command.

Description

Delete blackout windows of the specified source replication relationship.

Usage

```
qq replication_delete_blackout_windows [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship

qq replication_delete_object_relationship

This section explains how to use the `qq replication_delete_object_relationship` command.

Description

Delete the specified object replication relationship, which must not be running a job.

Usage

```
qq replication_delete_object_relationship [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the object replication relationship

qq replication_delete_source_relationship

This section explains how to use the `qq replication_delete_source_relationship` command.

Description

Delete the specified source replication relationship.

Usage

```
qq replication_delete_source_relationship [-h] --id ID [--force]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship
<code>--force</code>	No	Do not prompt

qq replication_delete_target_relationship

This section explains how to use the `qq replication_delete_target_relationship` command.

Description

Delete the specified target replication relationship.

Usage

```
qq replication_delete_target_relationship [-h] --id ID [--force]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the target replication relationship
<code>--force</code>	No	Do not prompt

qq replication_get_object_relationship

This section explains how to use the `qq replication_get_object_relationship` command.

Description

Get the configuration of the specified object replication relationship.

Usage

```
qq replication_get_object_relationship [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the object replication relationship

qq

replication_get_object_relationship_status

This section explains how to use the `qq replication_get_object_relationship_status` command.

Description

Get current status of the specified object replication relationship.

Usage

```
qq replication_get_object_relationship_status [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the object replication relationship

qq replication_get_source_relationship

This section explains how to use the `qq replication_get_source_relationship` command.

Description

Get information about the specified source replication relationship.

Usage

```
qq replication_get_source_relationship [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship

qq

replication_get_source_relationship_status

This section explains how to use the `qq replication_get_source_relationship_status` command.

Description

Get current status of the specified source replication relationship.

Usage

```
qq replication_get_source_relationship_status [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship

qq

replication_get_target_relationship_status

This section explains how to use the `qq replication_get_target_relationship_status` command.

Description

Get current target of the specified source replication relationship.

Usage

```
qq replication_get_target_relationship_status [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the target replication relationship

qq replication_link_snapshot_policy

This section explains how to use the `qq replication_link_snapshot_policy` command.

Description

Link a snapshot policy to a source replication relationship.

Usage

```
qq replication_link_snapshot_policy [-h] --relationship-id RELATIONSHIP_ID --snapshot-policy-id SNAPSHOT_POLICY_ID [-t TARGET_EXPIRATION]
```

Flags

Flag Name	Required	Description
<code>--relationship-id</code>	Yes	Unique identifier of the source replication relationship.
<code>--snapshot-policy-id</code>	Yes	Identifier of the snapshot policy to link.
<code>-t</code>	No	Duration after which to expire snapshots on the target cluster that were replicated from this snapshot policy, in format , where is a positive integer less than 100 and is one of [months, weeks, days, hours, minutes], e.g. 5days or 1hours. 'never' indicates snapshots should never expire and 'same_as_policy' indicates snapshots should expire at the same time as the snapshot policy specifies. (default: same_as_policy)

qq

replication_list_object_relationship_statuses

This section explains how to use the `qq replication_list_object_relationship_statuses` command.

Description

List the statuses for all existing object replication relationships.

Usage

```
qq replication_list_object_relationship_statuses [-h]
```

qq replication_list_object_relationships

This section explains how to use the `qq replication_list_object_relationships` command.

Description

List all the existing object replication relationships.

Usage

```
qq replication_list_object_relationships [-h]
```


qq replication_list_queued_snapshots

This section explains how to use the `qq replication_list_queued_snapshots` command.

Description

List information for all snapshots awaiting replication by the specified source replication relationship.

Usage

```
qq replication_list_queued_snapshots [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship.

qq

replication_list_source_relationship_statuses

This section explains how to use the `qq replication_list_source_relationship_statuses` command.

Description

List statuses for all existing source replication relationships.

Usage

```
qq replication_list_source_relationship_statuses [-h]
```

qq replication_list_source_relationships

This section explains how to use the `qq replication_list_source_relationships` command.

Description

List existing source replication relationships.

Usage

```
qq replication_list_source_relationships [-h]
```

qq

replication_list_target_relationship_statuses

This section explains how to use the `qq replication_list_target_relationship_statuses` command.

Description

List statuses for all existing target replication relationships.

Usage

```
qq replication_list_target_relationship_statuses [-h]
```

qq replication_make_target_writable

This section explains how to use the `qq replication_make_target_writable` command.

Description

Revert target directory to the latest recovery point.

Usage

```
qq replication_make_target_writable [-h] --id ID [--force]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the target replication relationship
<code>--force</code>	No	Do not prompt

qq replication_modify_source_relationship

This section explains how to use the `qq replication_modify_source_relationship` command.

Description

Modify an existing source replication relationship.

Usage

```
qq replication_modify_source_relationship [-h] --id ID [--new-target-address NEW_TARGET_ADDRESS] [--new-target-port NEW_TARGET_PORT] [-z TIMEZONE] [--enable-replication {true,false}] [--set-source-directory-read-only {true,false}] [--map-local-ids-to-nfs-ids {true,false}]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship
<code>--new-target-address</code>	No	The target IP address
<code>--new-target-port</code>	No	Network port to replicate to on the target
<code>-z</code>	No	The timezone for the relationship's blackout windows (e.g. America/Los_Angeles or UTC). See the <code>time_list_timezones qq</code> command for a complete list of supported timezones.

qq replication_reconnect_target_relationship

This section explains how to use the `qq replication_reconnect_target_relationship` command.

Description

Make the target directory read-only and revert any changes made to the target directory since the latest recovery point. Then reconnect the specified target replication relationship with its source directory. The revert action may take some time to complete before replication is resumed.

Usage

```
qq replication_reconnect_target_relationship [-h] --id ID [--force]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the target replication relationship
<code>--force</code>	No	Do not prompt

qq replication_release_queued_snapshot

This section explains how to use the `qq replication_release_queued_snapshot` command.

Description

Release a snapshot queued for replication from the queue of the specified source replication relationship.

Usage

```
qq replication_release_queued_snapshot [-h] --relationship-id RELATIONSHIP_ID --snapshot-id SNAPSHOT_ID
```

Flags

Flag Name	Required	Description
<code>--relationship-id</code>	Yes	Unique identifier of the source replication relationship.
<code>--snapshot-id</code>	Yes	Unique identifier of the snapshot to release.

qq replication_replicate

This section explains how to use the `qq replication_replicate` command.

Description

Replicate from the source to the target of the specified relationship.

Usage

```
qq replication_replicate [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship

qq replication_reverse_target_relationship

This section explains how to use the `qq replication_reverse_target_relationship` command.

Description

Reverse source and target for a replication relationship.

Usage

```
qq replication_reverse_target_relationship [-h] --id ID --source-address SOURCE_ADDR  
ESS [--source-port SOURCE_PORT]
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the target replication relationship
<code>--source-address</code>	Yes	The IP address of the current source cluster
<code>--source-port</code>	No	Network port of the current source cluster (defaults to 3712)

qq

replication_set_snapshot_policy_replication_mode

This section explains how to use the `qq replication_set_snapshot_policy_replication_mode` command.

Description

Set the replication mode of the specified source replication relationship. This command is only for a relationship that has linked snapshot policies.

Usage

```
qq replication_set_snapshot_policy_replication_mode [-h] --id ID --mode {REPLICATION_SNAPSHOT_POLICY,REPLICATION_SNAPSHOT_POLICY_WITH_CONTINUOUS}
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the source replication relationship.
<code>--mode</code>	Yes	Replication mode to set.

qq replication_set_target_relationship_lock

This section explains how to use the `qq replication_set_target_relationship_lock` command.

Description

The key that locks policy-created snapshots for a target replication relationship. Consider the following system behavior: If you don't set a key, the system does not lock the snapshots that the specified target replication relationship creates. The system locks only policy-created snapshots, unless you configure an expiration for the snapshot policy on the target cluster. If you reverse the relationship by switching the source and target, the new target cannot use this lock key and you must set a key for the new target. However, if you revert the relationship by returning the source and target to their original assignments, the system lets you use lock key from the original source-target relationship. If a target replication relationship uses a lock key, you cannot disable or delete the key, unless you reverse the relationship. If you disable or delete a lock key while a target replication relationship is reversed and then return the source and target to their original assignments, you must set a new key.

Usage

```
qq replication_set_target_relationship_lock [-h] --relationship-id RELATIONSHIP_ID  
(-k LOCK_KEY | --clear-lock-key)
```

Flags

Flag Name	Required	Description
<code>--relationship-id</code>	Yes	The unique identifier of the target replication relationship.
<code>-k</code>	No	The identifier or name of the lock key to associate with the specified target replication relationship.
<code>--clear-lock-key</code>	No	Disassociate the lock key from this target relationship

qq replication_start_object_relationship

This section explains how to use the `qq replication_start_object_relationship` command.

Description

Start a new replication job for an existing object replication relationship

Usage

```
qq replication_start_object_relationship [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	Unique identifier of the object replication relationship

qq replication_unlink_snapshot_policy

This section explains how to use the `qq replication_unlink_snapshot_policy` command.

Description

Unlink a snapshot policy from a source replication relationship.

Usage

```
qq replication_unlink_snapshot_policy [-h] --relationship-id RELATIONSHIP_ID --snaps  
hot-policy-id SNAPSHOT_POLICY_ID
```

Flags

Flag Name	Required	Description
<code>--relationship-id</code>	Yes	Unique identifier of the source replication relationship.
<code>--snapshot-policy-id</code>	Yes	Identifier of the snapshot policy to unlink.

qq restriper_status

This section explains how to use the `qq restriper_status` command.

Description

Get restriper status

Usage

```
qq restriper_status [-h]
```

qq rotate_encryption_keys

This section explains how to use the `qq rotate_encryption_keys` command.

Description

Rotate the at-rest encryption master keys.

Usage

```
qq rotate_encryption_keys [-h] [--key-id KEY_ID | --create-key-with-name KEY_NAME]
```

Flags

Flag Name	Required	Description
<code>--key-id</code>	No	The unique ID of the master key for at-rest encryption.
<code>--create-key-with-name</code>	No	The name of the key that will be created and used for at-rest encryption.

qq s3_abort_upload

This section explains how to use the `qq s3_abort_upload` command.

Description

Aborts an S3 upload in progress. You can perform this operation on user-initiated multipart uploads and system-initiated uploads that the PutObject and CopyObject API actions use.

Usage

```
qq s3_abort_upload [-h] --bucket BUCKET --upload-id UPLOAD_ID
```

Flags

Flag Name	Required	Description
<code>--bucket</code>	Yes	The S3 bucket to which the upload was initiated
<code>--upload-id</code>	Yes	The identifier of the upload to abort.

qq s3_add_bucket

This section explains how to use the `qq s3_add_bucket` command.

Description

Create an S3 bucket

Usage

```
qq s3_add_bucket [-h] --name NAME [--fs-path FS_PATH] [--create-fs-path] [--enable-object-lock] [--private]
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	The name of the bucket to create
<code>--fs-path</code>	No	The absolute path to use as the bucket root directory. The user must have permission to read the directory.
<code>--create-fs-path</code>	No	Create the bucket root directory if it does not already exist. The user must have permission to create the bucket root directory.
<code>--enable-object-lock</code>	No	Create the bucket with versioning and object locking enabled.
<code>--private</code>	No	Specifies whether to create a private S3 bucket. By default, Qumulo Core creates the bucket without a policy, allowing all S3 API users to perform S3 object read and write operations and the S3 bucket's creator and users with RBAC permissions to perform S3 bucket write operations. When enabled, Qumulo Core applies a policy that restricts both S3 object and S3 bucket operations to the S3 bucket's creator and users with RBAC permissions.

qq s3_bucket_policy_explain_access

This section explains how to use the `qq s3_bucket_policy_explain_access` command. For more information, see [Managing Access Policies for an S3 Bucket in a Qumulo Cluster](#) in the Qumulo Administrator Guide.

Examples

To Explain a User Access Policy for an S3 Bucket

Run the `s3_bucket_policy_explain_access` command and specify the bucket name and the auth ID of the Qumulo user. For example:

```
qq s3_bucket_policy_explain_access \  
  --bucket my-bucket \  
  --auth-id 1234
```

The following is example output. The command lists the S3 API permissions that the specified auth ID can perform on the specified S3 bucket.

```

Bucket `my-bucket` access for identity:
{
    "auth_id": "1234"
}

```

```

Policy statements access evaluation:
===== 1
=====

```

```

Effect: Allow
Actions: s3:GetObject, s3:ListBucket
===== 2
=====

```

```

Effect: None
===== 3
=====

```

```

Effect: Deny
Actions: s3:PutObject
===== 4
=====

```

```

Effect: Allow
Actions: s3:DeleteBucket
S3 actions granted by RBA:
s3:DeleteBucket, s3:GetBucketPolicy

```

```

S3 actions allowed for bucket:
action          source

```

```
e
=====
=====
s3:DeleteBucket      RBAC, polic
y
s3:GetBucketPolicy   RBA
C
s3:GetObject         polic
y
s3:ListBucket        policy
```

Description

Details a users access as allowed by the bucket policy

Usage

```
qq s3_bucket_policy_explain_access [-h] --bucket BUCKET [--auth-id AUTH_ID] [--anony
mous] [identifier]
```

Flags

Flag Name	Required	Description
--bucket	Yes	The bucket for which the access policy will be explained.
--auth-id	No	Auth ID of the qumulo user
--anonymous	No	An unauthenticated S3 user

Positional Options

Option Name	Description
identifier	An auth_id, SID, or name optionally qualified with a domain prefix (e.g "local:name", "ad:name", "AD\name") or an ID type (e.g. "auth_id:513", "SID:S-1-1-0"). Groups are not supported for access keys, must be a user.

qq s3_create_access_key

This section explains how to use the `qq s3_create_access_key` command.

Description

Create S3 access key

Usage

```
qq s3_create_access_key [-h] [--auth-id AUTH_ID] [--self] [identifier]
```

Flags

Flag Name	Required	Description
<code>--auth-id</code>	No	The auth_id of the Qumulo Core user
<code>--self</code>	No	Create an s3 access key for the currently logged on user

Positional Options

Option Name	Description
<code>identifier</code>	An auth_id, SID, or a name optionally qualified by a domain prefix (for example, "local:name", "ad:name", "AD\name") or an ID type (for example, "auth_id:513", "SID:S-1-1-0"). Qumulo Core supports only users (not groups) for S3 access keys.

qq s3_delete_access_key

This section explains how to use the `qq s3_delete_access_key` command.

Description

Delete an S3 access key

Usage

```
qq s3_delete_access_key [-h] --id ID
```

Flags

Flag Name	Required	Description
<code>--id</code>	Yes	The identifier of the access key to delete.

qq s3_delete_bucket

This section explains how to use the `qq s3_delete_bucket` command.

Description

Delete an S3 bucket

Usage

```
qq s3_delete_bucket [-h] --name NAME [--delete-root-dir]
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	The name of the S3 bucket to delete
<code>--delete-root-dir</code>	No	If specified, the operation succeeds only if the bucket root directory is empty, and the caller has the permissions for unlinking the bucket root directory from the S3 bucket. By default, the directory to be deleted can contain objects.

qq s3_delete_bucket_policy

This section explains how to use the `qq s3_delete_bucket_policy` command. For more information, see [Managing Access Policies for an S3 Bucket in a Qumulo Cluster](#) in the Qumulo Administrator Guide.

Examples

To Delete an Access Policy for an S3 Bucket

⚠ Important

This command removes any existing access policy restrictions.

Run the `qq s3_delete_bucket_policy` command and use the `--bucket` flag to specify the name of your S3 bucket. For example:

```
qq s3_delete_bucket_policy --bucket MyBucket
```

Description

Remove the access policy stored at `BUCKET`.

Usage

```
qq s3_delete_bucket_policy [-h] --bucket BUCKET
```

Flags

Flag Name	Required	Description
<code>--bucket</code>	Yes	The target bucket for which the access policy will be removed.

qq s3_get_bucket

This section explains how to use the `qq s3_get_bucket` command.

Examples

To Get Configuration Information for an S3 Bucket

Run the `qq s3_get_bucket` command and use the `--bucket` flag to specify the name of your bucket. For example:

```
qq s3_get_bucket_policy --bucket MyBucket
```

The following is example output. All times are in the UTC time zone.

```
{
  "creation_time": "2022-12-20T19:42:26.833076147Z",
  "name": "MyBucket",
  "path": "/buckets/my-bucket"
}
```

Description

Retrieve details for an S3 bucket

Usage

```
qq s3_get_bucket [-h] --name NAME
```

Flags

Flag Name	Required	Description
<code>--name</code>	Yes	The name of the S3 bucket for which to retrieve details

qq s3_get_bucket_policy

This section explains how to use the `qq s3_get_bucket_policy` command.

For more information, see [Managing Access Policies for an S3 Bucket in a Qumulo Cluster](#) in the Qumulo Administrator Guide.

Examples

To Retrieve an Access Policy for an S3 Bucket

Run the `qq s3_get_bucket_policy` command, and use the `--bucket` flag to specify the name of your bucket. For example:

```
qq s3_get_bucket_policy --bucket MyBucket
```

Description

Retrieve entries of the access policy json stored at `BUCKET`.

Usage

```
qq s3_get_bucket_policy [-h] [--bucket BUCKET] [--example]
```

Flags

Flag Name	Required	Description
<code>--bucket</code>	No	The target bucket for which the access policy will be retrieved
<code>--example</code>	No	Print an example Policy.

qq s3_get_settings

This section explains how to use the `qq s3_get_settings` command.

Description

Retrieve S3 server settings

Usage

```
qq s3_get_settings [-h]
```

qq s3_list_access_keys

This section explains how to use the `qq s3_list_access_keys` command.

Description

List S3 access keys

Usage

```
qq s3_list_access_keys [-h] [--json] [--user USER | --self]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Output JSON instead of table.
<code>--user</code>	No	Show access keys belonging to a specific user. Use an auth_id, SID, or name optionally qualified with a domain prefix (e.g "local:name", "ad:name", "AD\name") or an ID type (e.g. "auth_id:513", "SID:S-1-1-0"). Groups are not supported for access tokens, must be a user.
<code>--self</code>	No	List only access keys that target yourself.

qq s3_list_buckets

This section explains how to use the `qq s3_list_buckets` command.

Description

List all S3 buckets

Usage

```
qq s3_list_buckets [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	List S3 buckets in JSON format (not in a table)

qq s3_list_uploads

This section explains how to use the `qq s3_list_uploads` command.

Description

List S3 uploads in progress, including user-initiated multipart uploads and system-initiated uploads that the PutObject and CopyObject API actions use.

Usage

```
qq s3_list_uploads [-h] --bucket BUCKET [--starts-with STARTS_WITH]
```

Flags

Flag Name	Required	Description
<code>--bucket</code>	Yes	The S3 bucket for which to list uploads
<code>--starts-with</code>	No	List uploads only for keys that begin with the specified string

qq s3_modify_bucket

This section explains how to use the `qq s3_modify_bucket` command.

For more information, see [Managing Access Policies for an S3 Bucket in a Qumulo Cluster](#) in the Qumulo Administrator Guide.

Note

By default, an S3 bucket is in the Unversioned state.

Examples

To Enable Versioning for an S3 Bucket

Run the `qq s3_modify_bucket` command, specify the bucket name, and use the `--enable-versioning` flag. For example:

```
qq s3_modify_bucket \  
  --name MyBucket \  
  --enable-versioning
```

The following is example output. All times are in the UTC time zone.

```
{  
  "creation_time": "2024-05-22T21:42:11.295718303Z",  
  "name": "MyBucket",  
  "path": "/my-bucket",  
  "versioning": "Enabled"  
}
```

To Suspend Versioning for an S3 Bucket

Run the `qq s3_modify_bucket` command, specify the bucket name, and use the `--suspend-versioning` flag.

Description

Modify the settings of the given bucket. Use this command to update the bucket versioning state. Using this command to enable anonymous access to a bucket has been disabled, use `s3_set_bucket_policy` instead.

Usage

```
qq s3_modify_bucket [-h] --name NAME [--suspend-versioning | --enable-versioning]
[--enable-object-lock-without-retention | --enable-object-lock-with-retention-days R
ETENTION_DAYS | --enable-object-lock-with-retention-years RETENTION_YEARS]
```

Flags

Flag Name	Required	Description
--name	Yes	The name of the bucket to be modified
--suspend-versioning	No	Suspends object versioning
--enable-versioning	No	Enables object versioning
--enable-object-lock-without-retention	No	Enable Object Lock with no default retention period. (Requires versioning to be enabled for the specified S3 bucket.)
--enable-object-lock-with-retention-days	No	Enable Object Lock with the retention period specified in days.
--enable-object-lock-with-retention-years	No	Enable Object Lock with the retention period specified in years.

qq s3_modify_bucket_policy

This section explains how to use the `qq s3_modify_bucket_policy` command.

For more information, see [Managing Access Policies for an S3 Bucket in a Qumulo Cluster](#) in the Qumulo Administrator Guide.

Examples

To Modify a Statement in an Access Policy for an S3 Bucket

Run the `qq s3_modify_bucket_policy` command and use the `--bucket` flag to specify the name of the S3 bucket. For the `modify_statement` subcommand:

- Use the `--index` flag to specify the index of the statement to modify.
- Use the `--type` flag to specify the statement type.
- Use the `--sid` flag to specify the security identifier.
- Use the `--new-principals` flag to specify a comma-separated list of principals (with which to replace the existing ones), enclosed in quotation marks (").
- Use the `--new-actions` flag to specify a comma-separated list of S3 API actions (with which to replace the existing ones), enclosed in quotation marks (").

For example:

```
qq s3_modify_bucket_policy --bucket AnotherBucket \  
  modify_statement --index 1 \  
    --type Deny \  
    --sid DenyGuest \  
    --new-principals "Authenticated Users" \  
    --new-actions "s3:PutBucketPolicy"
```

To Append a Statement to an Access Policy for an S3 Bucket

Run the `qq s3_modify_bucket_policy` command and use the `--bucket` flag to specify the name of the S3 bucket. For the `append_statement` subcommand:

- Use the `--type` flag to specify the statement type.
- Use the `--sid` flag to specify the security identifier.
- Use the `--principals` flag to specify a comma-separated list of principals, enclosed in quotation marks (").
- Use the `--actions` flag to specify a comma-separated list of S3 API actions, enclosed in quotation marks (").

For example:

```
qq s3_modify_bucket_policy --bucket MyBucket \  
  append_statement --type Allow \  
    --sid AllowGuest \  
    --principals "local:guest,local:Mary" \  
    --actions "s3:GetBucketPolicy,s3:AbortMultipartUpload"
```

To Delete a Statement from an Access Policy for an S3 Bucket

Run the `qq s3_modify_bucket_policy` command and use the `--bucket` flag to specify the name of the S3 bucket. For the `delete_statement` subcommand, use the `--index` flag to specify the index of the statement to delete. For example:

```
qq s3_modify_bucket_policy --bucket MyBucket \  
  delete_statement --index 2
```

Description

Modify the access policy for `--bucket`.

Usage

```
qq s3_modify_bucket_policy [-h] --bucket BUCKET [--allow-remove-self] {delete_statem  
ent,append_statement,modify_statement} ...
```

Flags

Flag Name	Required	Description
<code>--bucket</code>	Yes	The name of the S3 bucket whose access policy is to be modified
<code>--allow-remove-self</code>	No	Allow the policy set to remove the ability for this user to change the policy.

qq s3_modify_settings

This section explains how to use the `qq s3_modify_settings` command.

Description

Modify S3 server settings

Usage

```
qq s3_modify_settings [-h] [--disable | --enable] [--base-path BASE_PATH] [--multipart-upload-expiry-interval MULTIPART_UPLOAD_EXPIRY_INTERVAL] [--secure | --insecure]
```

Flags

Flag Name	Required	Description
<code>--disable</code>	No	Disable S3 server
<code>--enable</code>	No	Enable S3 server
<code>--base-path</code>	No	The default bucket directory prefix for all S3 buckets created without an explicitly specified path. You must specify this directory as an absolute path.
<code>--multipart-upload-expiry-interval</code>	No	The time period during which the system permits a multipart upload to remain unmodified. When this time period elapses, the system considers the multipart upload stale and cleans it up automatically. Specify the time period in the format (for example, 5days). Quantity must be a positive integer less than 100 and units must be one of the following: months, weeks, days, or hours. To disable automatic multipart upload cleanup, specify never for quantity and do not specify any units.
<code>--secure</code>	No	Configure the S3 server to accept only HTTPS connections
<code>--insecure</code>	No	Configure the S3 server to accept only HTTP connections

qq s3_set_bucket_policy

This section explains how to use the `qq s3_set_bucket_policy` command.

For more information, see [Managing Access Policies for an S3 Bucket in a Qumulo Cluster](#) in the Qumulo Administrator Guide.

Examples

To Configure an Access Policy for an S3 Bucket

Run the `qq s3_set_bucket_policy` command, use the `--bucket` flag to specify the name of your bucket and the `--file` flag to specify the JSON file with the access policy. For example:

```
qq s3_set_bucket_policy --bucket MyBucket --file mypolicy.json
```

Description

Upload the access policy JSON file that the `--file` flag specifies to the S3 bucket name that the `--bucket` flag specifies.

Usage

```
qq s3_set_bucket_policy [-h] --bucket BUCKET --file FILE [--allow-remove-self]
```

Flags

Flag Name	Required	Description
<code>--bucket</code>	Yes	The name of the S3 bucket whose policy is to be configured
<code>--file</code>	Yes	The access policy file to upload. For an access policy template, use the <code>qq s3_get_bucket_policy --example</code> command. For what actions you are allowed use, run the <code>qq s3_bucket_policy_explain_access admin</code> command on the bucket.
<code>--allow-remove-self</code>	No	Allow the configured policy to remove the ability to modify itself from the current user.

qq saml_get_settings

This section explains how to use the `qq saml_get_settings` command.

Description

Get cluster SAML configuration

Usage

```
qq saml_get_settings [-h]
```

qq saml_modify_settings

This section explains how to use the `qq saml_modify_settings` command.

Description

Modify cluster SAML configuration

Usage

```
qq saml_modify_settings [-h] [--disable | --enable] [--idp-sso-url IDP_SSO_URL] [--idp-certificate IDP_CERTIFICATE | --idp-certificate-file IDP_CERTIFICATE_FILE] [--idp-entity-id IDP_ENTITY_ID] [--cluster-dns-name CLUSTER_DNS_NAME] [--require-sso {true,false}]
```

Flags

Flag Name	Required	Description
<code>--disable</code>	No	Disable authentication via SAML
<code>--enable</code>	No	Enable authentication via SAML
<code>--idp-sso-url</code>	No	Sets the cluster's configured IDP SSO URL.
<code>--idp-certificate</code>	No	Sets the cluster's configured IDP public key with the given value in PEM format.
<code>--idp-certificate-file</code>	No	Sets the cluster's configured IDP public key from a PEM file.
<code>--idp-entity-id</code>	No	Sets the URI for the IDP this cluster trusts to authenticate users via SAML.
<code>--cluster-dns-name</code>	No	Sets the cluster's configured DNS name (must be FQDN).
<code>--require-sso</code>	No	If set, requires SSO for Active Directory (AD) users to be able to manage this cluster. The cluster rejects password-based authentication from AD users of the Web UI, qq CLI, and REST API. This setting does not restrict access over file protocols such as SMB.

qq set_cluster_conf

This section explains how to use the `qq set_cluster_conf` command.

Description

Set the cluster config

Usage

```
qq set_cluster_conf [-h] --cluster-name CLUSTER_NAME
```

Flags

Flag Name	Required	Description
<code>--cluster-name</code>	Yes	Cluster Name

qq set_monitoring_conf

This section explains how to use the `qq set_monitoring_conf` command.

Description

Update monitoring configuration.

Usage

```
qq set_monitoring_conf [-h] [--enabled | --disabled] [--vpn-enabled | --vpn-disabled] [--mq-host MQ_HOST] [--mq-port MQ_PORT] [--mq-proxy-host MQ_PROXY_HOST] [--mq-proxy-port MQ_PROXY_PORT] [--s3-proxy-host S3_PROXY_HOST] [--s3-proxy-port S3_PROXY_PORT] [--s3-proxy-disable-https] [--all-proxy-host HOST] [--all-proxy-port PORT] [--period PERIOD] [--vpn-host VPN_HOST] [--nexus-enabled | --nexus-disabled] [--nexus-host NEXUS_HOST] [--nexus-port NEXUS_PORT] [--nexus-interval NEXUS_INTERVAL] [--nexus-registration-key NEXUS_REGISTRATION_KEY]
```

Flags

Flag Name	Required	Description
<code>--enabled</code>	No	Enable monitoring service.
<code>--disabled</code>	No	Disable monitoring service.
<code>--vpn-enabled</code>	No	Enable support VPN.
<code>--vpn-disabled</code>	No	Disable support VPN.
<code>--mq-host</code>	No	Specify MQ host name or IP.
<code>--mq-port</code>	No	Optional MQ service port.
<code>--mq-proxy-host</code>	No	Optional MQ proxy host.
<code>--mq-proxy-port</code>	No	Optional MQ proxy port.
<code>--s3-proxy-host</code>	No	Optional S3 proxy host.
<code>--s3-proxy-port</code>	No	Optional S3 proxy port.
<code>--s3-proxy-disable-https</code>	No	Optional S3 proxy disable HTTPS.

<code>--all-proxy-host</code>	No	Optional Set both MQ and S3 proxy host to HOST.
<code>--all-proxy-port</code>	No	Optional Set both MQ and S3 proxy port to PORT.
<code>--period</code>	No	Monitoring poll interval in seconds.
<code>--vpn-host</code>	No	Support VPN host name or IP.
<code>--nexus-enabled</code>	No	Enable Nexus monitoring.
<code>--nexus-disabled</code>	No	Disable Nexus monitoring.
<code>--nexus-host</code>	No	Optional nexus host.
<code>--nexus-port</code>	No	Optional nexus port.
<code>--nexus-interval</code>	No	Nexus poll interval in seconds.
<code>--nexus-registration-key</code>	No	Optional nexus registration key.

qq set_node_identify_light

This section explains how to use the `qq set_node_identify_light` command.

Description

Turn node identification light on or off

Usage

```
qq set_node_identify_light [-h] --node NODE {on,off}
```

Flags

Flag Name	Required	Description
<code>--node</code>	Yes	Node ID

Positional Options

Option Name	Description
<code>light_state</code>	Should light be visible

qq smb_add_share

This section explains how to use the `qq smb_add_share` command.

For more information, see [Using SMB Host Restrictions in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

To Create an SMB Share with Host Restrictions

Note

The `qq smb_add_share` and `qq smb_mod_share` commands use the same flags.

Run the `qq smb_add_share` command and specify the path, share name, and [host restriction level](#). In the following example, Qumulo Core grants hosts 203.0.113.42 and 203.0.113.84 full control, all hosts in 203.0.113.0/24 read-only access, and denies all other hosts.

```
qq smb_add_share --fs-path / \  
  --name my-share \  
  --all-access \  
  --full-control-hosts 203.0.113.42 203.0.113.84 \  
  --read-only-hosts 203.0.113.0/24
```

The following is example output.

```

ID: 3
Name: share
Path: /
Description:
Access Based Enumeration: False
Encryption Required: False
Default File Create Mode: 0644
Default Directory Create Mode: 0755

Permissions:
ID Trustee  Type    Rights
== =====
1  Everyone Allowed Read, Write, Change permissions

Network Permissions:
ID Trustee                                Type    Rights
== =====
1  203.0.113.0/24                          Denied  Write, Change permissions
2  203.0.113.0/24                          Allowed Read
3  203.0.113.42, 203.0.113.84             Allowed Read, Write, Change permissions

```

Description

Add a new SMB share

Usage

```

qq smb_add_share [-h] [--tenant-id TENANT_ID] --name NAME --fs-path FS_PATH [--description DESCRIPTION] [--access-based-enumeration-enabled {true,false}] [--create-fs-path] [--expand-fs-path-variables]
  [--default-file-create-mode DEFAULT_FILE_CREATE_MODE] [--default-directory-create-mode DEFAULT_DIRECTORY_CREATE_MODE] [--require-encryption {true,false}]
  [--offline-files-caching-mode {no_caching,manual_caching,automatic_caching}] [--json] [--no-access | --read-only | --all-access] [--grant-read-access TRUSTEE [TRUSTEE ...]]
  [--grant-read-write-access TRUSTEE [TRUSTEE ...]]
  [--grant-all-access TRUSTEE [TRUSTEE ...]] [--deny-access TRUSTEE [TRUSTEE ...]] [--full-control-hosts IP/RANGE [IP/RANGE ...]] [--read-only-hosts IP/RANGE [IP/RANGE ...]]
  [--deny-hosts IP/RANGE [IP/RANGE ...]]
  [--deny-all-hosts]

```

Flags

Flag Name	Required	Description
-----------	----------	-------------

<code>--tenant-id</code>	No	The ID of the tenant to which to add the share.
<code>--name</code>	Yes	Name of share.
<code>--fs-path</code>	Yes	Filesystem path.
<code>--description</code>	No	Description of this share.
<code>--access-based-enumeration-enabled</code>	No	Enable Access-Based Enumeration for this share.
<code>--create-fs-path</code>	No	Creates the specified filesystem path if the path does not exist already.
<code>--expand-fs-path-variables</code>	No	Enable expanding %U in the specified filesystem path to the SMB username during connection.
<code>--default-file-create-mode</code>	No	Change the default POSIX file create mode bits (octal) for the specified SMB share. These mode bits are applied to new files as they are created. Note: If an inheritable ACE is present in the permissions ACL, this flag has no effect.
<code>--default-directory-create-mode</code>	No	Change the default POSIX directory create mode bits (octal) for the specified SMB share. These mode bits are applied to new directories as they are created. Note: If an inheritable ACE is present in the permissions ACL, this flag has no effect.
<code>--require-encryption</code>	No	Require encryption for all traffic for the specified share. When set to true, clients without encryption capability cannot connect to this share.
<code>--offline-files-caching-mode</code>	No	Offline-files caching mode advertised to SMB clients. When set to no_caching (the default), client-side caching is disabled. When set to manual_caching, clients may cache files that the user designates as available offline. When set to automatic_caching, clients may cache files as they are opened.
<code>--json</code>	No	Print the raw JSON response.

<code>--no-access</code>	No	Grant no access.
<code>--read-only</code>	No	Grant everyone except guest read-only access.
<code>--all-access</code>	No	Grant everyone except guest full access.
<code>--grant-read-access</code>	No	Grant read access to the specified trustees. For example: Everyone, uid:1000, gid:1001, sid:S-1-5-2-3-4, auth_id:500
<code>--grant-read-write-access</code>	No	Grant read-write access to these trustees.
<code>--grant-all-access</code>	No	Grant all access to these trustees.
<code>--deny-access</code>	No	Deny all access to these trustees.
<code>--full-control-hosts</code>	No	The host addresses or subnet ranges for which access to to this share are not limited by network permissions. Access may still be limited by share and file permissions.
<code>--read-only-hosts</code>	No	Address ranges which should be permitted read-only access at most.
<code>--deny-hosts</code>	No	The host addresses or subnet ranges for which access to the specified share is denied, regardless of other permissions. Important: Because using this flag alone results in all hosts being denied, use the correct --full-control-hosts or --read-only-hosts flags as necessary.
<code>--deny-all-hosts</code>	No	Deny all access to this share. Important: To avoid configuration issues, do not apply this flag alongside any others.

qq smb_close_file_handle

This section explains how to use the `qq smb_close_file_handle` command.

Description

Force-close the specified SMB file handle

Usage

```
qq smb_close_file_handle [-h] --location LOCATION
```

Flags

Flag Name	Required	Description
<code>--location</code>	Yes	The location of the file handle to close as returned from <code>smb_list_file_handles</code> .

qq smb_close_sessions

This section explains how to use the `qq smb_close_sessions` command.

Description

Force close SMB sessions matching one or more of a set of filters.

Usage

```
qq smb_close_sessions [-h] [--identity IDENTITY] [--location LOCATION] [--share-name SHARE_NAME] [--ip IP]
```

Flags

Flag Name	Required	Description
<code>--identity</code>	No	Close only the sessions that match the specified user's identity in one of the following forms: a name or a SID optionally qualified with a domain prefix (for example, "local:name", "S-1-1-0", "name", "world:Everyone", "ldap_user:name", "ad:name"), or an ID type (for example, "uid:1001", "auth_id:513", "SID:S-1-1-0").
<code>--location</code>	No	Use the list of sessions from the <code>smb_list_sessions</code> command to close only the session with the specified location.
<code>--share-name</code>	No	Close only the sessions that are connected to the share with the specified case-sensitive name. Sessions connected to multiple shares will disconnect from all shares using the session.
<code>--ip</code>	No	Close only the sessions that originate from the specified IP address.

qq smb_delete_share

This section explains how to use the `qq smb_delete_share` command.

Description

Delete a share

Usage

```
qq smb_delete_share [-h] (--id ID | --name NAME) [--tenant-id TENANT_ID]
```

Flags

Flag Name	Required	Description
<code>--id</code>	No	ID of share to delete.
<code>--name</code>	No	Name of share to delete.
<code>--tenant-id</code>	No	The ID of the tenant from which to delete the share. Use this flag only if you also use the <code>--name</code> flag.

qq smb_get_settings

This section explains how to use the `qq smb_get_settings` command.

Description

Get SMB settings

Usage

```
qq smb_get_settings [-h]
```

qq smb_list_file_handles

This section explains how to use the `qq smb_list_file_handles` command.

Description

List SMB open file handles

Usage

```
qq smb_list_file_handles [-h] [--page-size PAGE_SIZE] [--file-number FILE_NUMBER]
[-p] [--path PATH]
```

Flags

Flag Name	Required	Description
<code>--page-size</code>	No	Max files to return per request.
<code>--file-number</code>	No	Limits results to the specified file, as returned from a command like <code>fs_file_get_attr</code> or <code>fs_read_dir</code> .
<code>-p</code>	No	Returns the primary path of the opened file.
<code>--path</code>	No	Path to file

qq smb_list_sessions

This section explains how to use the `qq smb_list_sessions` command.

Description

List SMB open sessions

Usage

```
qq smb_list_sessions [-h] [--page-size PAGE_SIZE] [--identity IDENTITY]
```

Flags

Flag Name	Required	Description
<code>--page-size</code>	No	Max sessions to return per request
<code>--identity</code>	No	List only the sessions that match the specified user's identity in one of the following forms: a name or a SID optionally qualified with a domain prefix (for example, "local:name", "S-1-1-0", "name", "world:Everyone", "ldap_user:name", "ad:name"), or an ID type (for example, "uid:1001", "auth_id:513", "SID:S-1-1-0").

qq smb_list_share

This section explains how to use the `qq smb_list_share` command.

For more information, see [Using SMB Host Restrictions in Qumulo Core](#) in the Qumulo Administrator Guide.

Examples

To View Existing SMB Share Host Restrictions

Run the `qq smb_list_share` command and specify the share ID. For example:

```
qq smb_list_share --id 4
```

The following is example output.

```
ID: 4
Name: share2
Path: /
Description:
Access Based Enumeration: False
Encryption Required: False
Default File Create Mode: 0644
Default Directory Create Mode: 0755

Permissions:
ID Trustee  Type    Rights
== =====
1  Everyone Allowed Read, Write, Change permissions

Network Permissions:
ID Trustee      Type    Rights
== =====
1  203.0.113.0/24 Allowed Read, Write, Change permissions
```

Description

List a share

Usage

```
qq smb_list_share [-h] (--id ID | --name NAME) [--tenant-id TENANT_ID] [--json]
```

Flags

Flag Name	Required	Description
<code>--id</code>	No	ID of share to list.
<code>--name</code>	No	Name of share to list.
<code>--tenant-id</code>	No	ID of the tenant to get the share from. Only used if using the <code>--name</code> argument.
<code>--json</code>	No	Print the raw JSON response.

qq smb_list_shares

This section explains how to use the `qq smb_list_shares` command.

Description

List all SMB shares

Usage

```
qq smb_list_shares [-h] [--json] [--populate-trustee-names]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Print JSON representation of shares.
<code>--populate-trustee-names</code>	No	Populate trustee names in the response.

qq smb_mod_share

This section explains how to use the `qq smb_mod_share` command.

Examples

Modifying Host Restrictions

For more information, see [Using SMB Host Restrictions in Qumulo Core](#) in the Qumulo Administrator Guide.

To Modify Host Restrictions for an Existing SMB Share

i Note

- The `qq smb_add_share` and `qq smb_mod_share` commands use the same flags.
- If you specify new host restrictions, they overwrite any existing host restrictions. You must explicitly specify which host restrictions to retain.
- If you don't include any flags, no changes take place.

Run the `qq smb_mod_share` command and specify the path, share name, and [host restriction level](#). In the following example, Qumulo Core grants hosts 203.0.113.0/16 and 203.0.113.0/24 full control, and denies all other hosts.

The following is example output.

```
ID: 4
Name: share2
Path: /
Description:
Access Based Enumeration: False
Encryption Required: False
Default File Create Mode: 0644
Default Directory Create Mode: 0755

Permissions:
ID Trustee  Type    Rights
== =====
1  Everyone Allowed Read, Write, Change permissions

Network Permissions:
ID Trustee                                Type    Rights
== =====
1  203.0.113.0/16, 203.0.113.0/24 Allowed Read, Write, Change permissions
```

To Remove All Host Restrictions from an Existing SMB Share

Run the `qq smb_mod_share` command, specify the share ID, and specify full control. For example:

For more information, see [Managing SMB3 Encryption in Transit in Qumulo Core](#) in the Qumulo Administrator Guide.

```
qq smb_mod_share --id=4 \
  --full-control="*"
```

Configuring SMB3 Encryption

For more information, see [Managing SMB3 Encryption in Transit in Qumulo Core](#) in the Qumulo Administrator Guide.

To Configure Share-Level SMB3 Encryption

Run the `qq smb_mod_share` command, specify the share name or ID, and use the `--require-encryption` flag to specify `true` or `false`. For example:

```
qq smb_mod_share --name my_share \
  --require-encryption true
```

Description

Modify a share

Usage

```
qq smb_mod_share [-h] (--id ID | --name NAME) [--tenant-id TENANT_ID] [--new-name NEW_NAME] [--new-tenant-id NEW_TENANT_ID] [--fs-path FS_PATH] [--description DESCRIPTION] [--access-based-enumeration-enabled {true,false}] [--create-fs-path]
  [--expand-fs-path-variables] [--default-file-create-mode DEFAULT_FILE_CREATE_MODE] [--default-directory-create-mode DEFAULT_DIRECTORY_CREATE_MODE] [--require-encryption {true,false}]
  [--offline-files-caching-mode {no_caching,manual_caching,automatic_caching}] [--json] [--full-control-hosts IP/RANGE [IP/RANGE ...]] [--read-only-hosts IP/RANGE [IP/RANGE ...]]
  [--deny-hosts IP/RANGE [IP/RANGE ...]]
  [--deny-all-hosts]
```

Flags

Flag Name	Required	Description
-----------	----------	-------------

<code>--id</code>	No	The ID of the share to modify.
<code>--name</code>	No	The name of the share to modify.
<code>--tenant-id</code>	No	ID of the tenant the share is in. Only used if using the <code>--name</code> argument.
<code>--new-name</code>	No	Change SMB share name.
<code>--new-tenant-id</code>	No	Change the tenant that the share is in.
<code>--fs-path</code>	No	Change filesystem path.
<code>--description</code>	No	Change share description.
<code>--access-based-enumeration-enabled</code>	No	Enable Access-Based Enumeration for this share.
<code>--create-fs-path</code>	No	Creates the specified filesystem path if the path does not exist already.
<code>--expand-fs-path-variables</code>	No	Enable expanding %U in the specified filesystem path to the SMB username during connection.
<code>--default-file-create-mode</code>	No	Change the default POSIX file create mode bits (octal) for the specified SMB share. These mode bits are applied to new files as they are created. Note: If an inheritable ACE is present in the permissions ACL, this flag has no effect.
<code>--default-directory-create-mode</code>	No	Change the default POSIX directory create mode bits (octal) for the specified SMB share. These mode bits are applied to new directories as they are created. Note: If an inheritable ACE is present in the permissions ACL, this flag has no effect.
<code>--require-encryption</code>	No	Require all traffic for this share to be encrypted. If true, clients without encryption capabilities will not be able to connect.

<code>--offline-files-caching-mode</code>	No	Offline-files caching mode advertised to SMB clients. When set to <code>no_caching</code> , client-side caching is disabled. When set to <code>manual_caching</code> , clients may cache files that the user designates as available offline. When set to <code>automatic_caching</code> , clients may cache files as they are opened.
<code>--json</code>	No	Print the raw JSON response.
<code>--full-control-hosts</code>	No	The host addresses or subnet ranges for which access to to this share are not limited by network permissions. Access may still be limited by share and file permissions.
<code>--read-only-hosts</code>	No	Address ranges which should be permitted read-only access at most.
<code>--deny-hosts</code>	No	The host addresses or subnet ranges for which access to the specified share is denied, regardless of other permissions. Important: Because using this flag alone results in all hosts being denied, use the correct <code>--full-control-hosts</code> or <code>--read-only-hosts</code> flags as necessary.
<code>--deny-all-hosts</code>	No	Deny all access to this share. Important: To avoid configuration issues, do not apply this flag alongside any others.

qq smb_mod_share_permissions

This section explains how to use the `qq smb_mod_share_permissions` command.

Description

Modify a share's permissions

Usage

```
qq smb_mod_share_permissions [-h] (--id ID | --name NAME) [--tenant-id TENANT_ID]
[--json] {add_entry,remove_entry,modify_entry,replace} ...
```

Flags

Flag Name	Required	Description
<code>--id</code>	No	The ID of the share to modify.
<code>--name</code>	No	The name of the share to modify.
<code>--tenant-id</code>	No	The ID of the tenant from which to delete the share. Use this flag only if you also use the <code>--name</code> flag.
<code>--json</code>	No	Print the raw JSON response.

qq smb_modify_settings

This section explains how to use the `qq smb_modify_settings` command.

Examples

Hiding an SMB Share from Unauthorized Hosts

For more information, see [Using SMB Host Restrictions in Qumulo Core](#) in the Qumulo Administrator Guide.

To Hide an SMB Share from Unauthorized Hosts

Run the `qq smb_modify_settings` command and set the `--hide-shares-from-unauthorized-hosts` flag to `true`.

Configuring Cluster-Level SMB3 Encryption

For more information, see [Managing SMB3 Encryption in Transit in Qumulo Core](#) in the Qumulo Administrator Guide.

To Configure Cluster-Level SMB3 Encryption

Run the `qq smb_modify_settings` command and set the `--encryption-mode` flag to one of the following:

- `NONE`
- `PREFER`
- `REQUIRE`

To Disable SMB3 Negotiation to Improve Workload Performance

Run the `qq smb_modify_settings` command and specify the supported SMB dialects. For example:

```
qq smb_modify_settings \  
  --supported-dialects SMB2_DIALECT_2_1
```

To Enable SMB3 Negotiation

Run the `qq smb_modify_settings` command and specify the supported SMB dialects. For example:

```
qq smb_modify_settings \  
  --supported-dialects SMB2_DIALECT_2_1 \  
  SMB2_DIALECT_3_0
```

Description

Set SMB server settings

Usage

```
qq smb_modify_settings [-h] [-e {none,preferred,required}] [-d dialect_1 [dialect_2 ...]] [--hide-shares-from-unauthorized-hosts {true,false}] [--hide-shares-from-unauthorized-users {true,false}] [--snapshot-directory-mode {visible,hidden,disabled}] [--bypass-traverse-checking {true,false}] [--signing-required {true,false}]
```

Flags

Flag Name	Required	Description
-e	No	Server encryption mode to set
-d	No	Specify a space-separated list of SMB dialects that clients are permitted to negotiate. To disable SMB, specify -d "". Available dialects: smb2_dialect_2_002, smb2_dialect_2_1, smb2_dialect_3_0, smb2_dialect_3_11. Alternatively, use -d ALL to allow all supported dialects.
--hide-shares-from-unauthorized-hosts	No	Configure share listing to omit shares to which the requesting host isn't authorized to connect.
--hide-shares-from-unauthorized-users	No	Configure share listing to omit shares to which the requesting user isn't authorized to connect. Important: Clients which don't have passwordless authentication typically list shares by using guest privileges. This flag typically hides all shares from this client type.
--snapshot-directory-mode	No	When you set this flag to visible, the .snapshot directory appears at the root of shares during directory listing operations. The .snapshot directory is also accessible by name in any directory. When you set this flag to hidden, .snapshot directories do not appear in directory listings but remains accessible by name. When you set this flag to disabled, .snapshot directories are not accessible and snapshots are available only through the Restore Previous Versions dialog box on Windows.

--bypass-traverse-checking	No	Enables bypass traverse checking for all users and directories. For example, a user who tries to access directory /x/y and has permissions to the /x directory but not to the /x/y directory can access the /x/y directory. A user still requires permissions to the /x directory to view its contents.
--signing-required	No	If the user is not a guest, require all messages to be signed. This flag applies to all SMB shares.

qq snapshot_create_policy

This section explains how to use the `qq snapshot_create_policy` command.

Description

Create a new snapshot scheduling policy.

Usage

```
qq snapshot_create_policy [-h] {hourly_or_less,daily,monthly} ...
```

qq snapshot_create_snapshot

This section explains how to use the `qq snapshot_create_snapshot` command.

Description

Create a new snapshot

Usage

```
qq snapshot_create_snapshot [-h] [--source-file-id SOURCE_FILE_ID | --path PATH]
[-e EXPIRATION] [-n NAME]
```

Flags

Flag Name	Required	Description
<code>--source-file-id</code>	No	ID of directory to snapshot
<code>--path</code>	No	Path of directory to snapshot
<code>-e</code>	No	Time of snapshot expiration. An empty string indicates that the snapshot never expires. The time format follows RFC 3339, a normalized subset of ISO 8601.
<code>-n</code>	No	Snapshot name

qq snapshot_delete_policy

This section explains how to use the `qq snapshot_delete_policy` command.

Description

Delete a single scheduling policy

Usage

```
qq snapshot_delete_policy [-h] -i ID
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Identifier of the snapshot policy to delete.

qq snapshot_delete_snapshot

This section explains how to use the `qq snapshot_delete_snapshot` command.

Description

Delete a single snapshot

Usage

```
qq snapshot_delete_snapshot [-h] -i ID
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Snapshot ID

qq snapshot_diff

This section explains how to use the `qq snapshot_diff` command.

Description

List the changed files and directories between two snapshots.

Usage

```
qq snapshot_diff [-h] --newer-snapshot NEWER_SNAPSHOT --older-snapshot OLDER_SNAPSHOT [--page-size PAGE_SIZE]
```

Flags

Flag Name	Required	Description
<code>--newer-snapshot</code>	Yes	Snapshot ID of the newer snapshot
<code>--older-snapshot</code>	Yes	Snapshot ID of the older snapshot
<code>--page-size</code>	No	Max snapshot diff entries to return per request

qq snapshot_file_diff

This section explains how to use the `qq snapshot_file_diff` command.

Description

List changed byte ranges of a file between two snapshots.

Usage

```
qq snapshot_file_diff [-h] --newer-snapshot NEWER_SNAPSHOT --older-snapshot OLDER_SNAPSHOT (--path PATH | --file-id FILE_ID) [--page-size PAGE_SIZE]
```

Flags

Flag Name	Required	Description
<code>--newer-snapshot</code>	Yes	Snapshot ID of the newer snapshot
<code>--older-snapshot</code>	Yes	Snapshot ID of the older snapshot
<code>--path</code>	No	Path to file
<code>--file-id</code>	No	File ID
<code>--page-size</code>	No	Maximum number of entries to return per request

qq snapshot_get_policy

This section explains how to use the `qq snapshot_get_policy` command.

Description

Get a single policy

Usage

```
qq snapshot_get_policy [-h] -i ID
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Identifier of the snapshot policy to list.

qq snapshot_get_policy_status

This section explains how to use the `qq snapshot_get_policy_status` command.

Description

Get a single snapshot policy status

Usage

```
qq snapshot_get_policy_status [-h] -i ID
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Identifier of the snapshot policy.

qq snapshot_get_status

This section explains how to use the `qq snapshot_get_status` command.

Description

Get the information for a single snapshot.

Usage

```
qq snapshot_get_status [-h] -i ID
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	The identifier of the snapshot to list.

qq snapshot_get_total_used_capacity

This section explains how to use the `qq snapshot_get_total_used_capacity` command.

Description

Get the total space consumed by all snapshots.

Usage

```
qq snapshot_get_total_used_capacity [-h]
```

qq snapshot_get_unlock_challenge

This section explains how to use the `qq snapshot_get_unlock_challenge` command.

Description

Get a security challenge for unlocking a snapshot.

Usage

```
qq snapshot_get_unlock_challenge [-h] -i ID
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	The identifier of the snapshot to unlock.

qq snapshot_list_policies

This section explains how to use the `qq snapshot_list_policies` command.

Description

List all policies

Usage

```
qq snapshot_list_policies [-h]
```

qq snapshot_list_policy_statuses

This section explains how to use the `qq snapshot_list_policy_statuses` command.

Description

List all snapshot policy statuses

Usage

```
qq snapshot_list_policy_statuses [-h]
```

qq snapshot_list_statuses

This section explains how to use the `qq snapshot_list_statuses` command.

Description

List the information for every snapshot.

Usage

```
qq snapshot_list_statuses [-h] [--exclude-in-delete | --only-in-delete] [--exclude-locked | --only-locked]
```

Flags

Flag Name	Required	Description
<code>--exclude-in-delete</code>	No	Exclude all snapshots in process of being deleted from the list. You can use this flag together with the <code>--exclude-locked</code> or <code>--only-locked</code> flag.
<code>--only-in-delete</code>	No	Display only snapshots in process of being deleted. You can use this flag together with the <code>--exclude-locked</code> or <code>--only-locked</code> flag.
<code>--exclude-locked</code>	No	Exclude all locked snapshots from the list. You can use this flag together with the <code>--exclude-in-delete</code> or <code>--only-in-delete</code> flag.
<code>--only-locked</code>	No	List only locked snapshots. You can use this flag together with the <code>--exclude-in-delete</code> or <code>--only-in-delete</code> flag.

qq snapshot_lock_snapshot

This section explains how to use the `qq snapshot_lock_snapshot` command.

Description

Lock a snapshot.

Usage

```
qq snapshot_lock_snapshot [-h] -i ID [-f] -k LOCK_KEY
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	The identifier of the snapshot to lock.
<code>-f</code>	No	Do not prompt for confirmation. The default setting is "false".
<code>-k</code>	Yes	The identifier or name of the key in the filesystem key store that protects the snapshot. Important: You must specify either the name or the identifier of the key.

qq snapshot_modify_policy

This section explains how to use the `qq snapshot_modify_policy` command.

Description

Modify an existing snapshot scheduling policy.

Usage

```
qq snapshot_modify_policy [-h] {modify_non_schedule_fields,change_to_hourly_or_les  
s,change_to_daily,change_to_monthly} ...
```


qq snapshot_modify_snapshot

This section explains how to use the `qq snapshot_modify_snapshot` command.

Description

Modify an existing snapshot

Usage

```
qq snapshot_modify_snapshot [-h] -i ID [-e EXPIRATION] [-f]
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	Identifier of the snapshot to modify.
<code>-e</code>	No	Time of snapshot expiration. An empty string indicates that the snapshot never expires. The time format follows RFC 3339, a normalized subset of ISO 8601.
<code>-f</code>	No	Do not prompt for confirmation. The default setting is "false".

qq snapshot_unlock_snapshot

This section explains how to use the `qq snapshot_unlock_snapshot` command.

Description

Unlock a snapshot.

Usage

```
qq snapshot_unlock_snapshot [-h] -i ID (-s SIGNATURE | -k PRIVATE_KEY_FILE)
```

Flags

Flag Name	Required	Description
<code>-i</code>	Yes	The identifier of the snapshot to unlock.
<code>-s</code>	No	The verification signature of the security challenge from the output of the <code>qq snapshot_get_unlock_challenge</code> command.
<code>-k</code>	No	The location of the private key file that locks the snapshot.

qq ssl_delete_ca_certificate

This section explains how to use the `qq ssl_delete_ca_certificate` command.

Description

Delete SSL CA certificate. This certificate is used to authenticate connections to external LDAP servers.

Usage

```
qq ssl_delete_ca_certificate [-h]
```

qq ssl_get_ca_certificate

This section explains how to use the `qq ssl_get_ca_certificate` command.

Description

Get SSL CA certificate. This certificate is used to authenticate connections to external LDAP servers.

Usage

```
qq ssl_get_ca_certificate [-h]
```

qq ssl_get_ciphers

This section explains how to use the `qq ssl_get_ciphers` command.

Description

Get SSL cipher suites for the TLS 1.2 and 1.3 protocols.

Usage

```
qq ssl_get_ciphers [-h]
```

qq ssl_modify_ca_certificate

This section explains how to use the `qq ssl_modify_ca_certificate` command.

Description

Set SSL CA certificate. This certificate is used to authenticate connections to external LDAP servers.

Usage

```
qq ssl_modify_ca_certificate [-h] -c CERTIFICATE
```

Flags

Flag Name	Required	Description
<code>-c</code>	Yes	SSL CA certificate file in PEM format

qq ssl_modify_certificate

This section explains how to use the `qq ssl_modify_certificate` command.

Description

Set the SSL certificate chain and private key for the web UI and REST servers

Usage

```
qq ssl_modify_certificate [-h] -c CERTIFICATE -k PRIVATE_KEY
```

Flags

Flag Name	Required	Description
-c	Yes	SSL certificate chain in PEM format. Must contain entire certificate chain up to the root CA
-k	Yes	RSA private key file in PEM format

qq ssl_modify_ciphers

This section explains how to use the `qq ssl_modify_ciphers` command.

Description

Set SSL cipher suites for the TLS 1.2 and 1.3 protocols. Note that ciphers required by Qumulo Core to function cannot be removed.

Usage

```
qq ssl_modify_ciphers [-h] [--tls12 TLS12] [--tls13 TLS13]
```

Flags

Flag Name	Required	Description
<code>--tls12</code>	No	Cipher suites used for the TLS 1.2 protocol as a colon-delimited string
<code>--tls13</code>	No	Cipher suites used for the TLS 1.3 protocol as a colon-delimited string.

qq sso_login

This section explains how to use the `qq sso_login` command.

Description

Perform an interactive SAML single sign-on (SSO) authentication process for the cluster.

Usage

```
qq sso_login [-h]
```

qq static_ip_allocation

This section explains how to use the `qq static_ip_allocation` command.

Description

Get cluster-wide static IP allocation

Usage

```
qq static_ip_allocation [-h] [--try-ranges TRY_RANGES] [--try-netmask TRY_NETMASK]
[--try-floating-ranges TRY_FLOATING_RANGES]
```

Flags

Flag Name	Required	Description
<code>--try-ranges</code>	No	Specify ip range list to try (e.g. '1.1.1.10-12,10.20.5.0/24')
<code>--try-netmask</code>	No	Specify netmask to apply when using --try-range option
<code>--try-floating-ranges</code>	No	Specify floating ip range list to try (e.g. '1.1.1.10-12,10.20.5.0/24')

qq stratus_cluster_create

This section explains how to use the `qq stratus_cluster_create` command.

Description

Create a Qumulo Stratus Tenant Cluster

Usage

```
qq stratus_cluster_create [-h] --cluster-name CLUSTER_NAME [--admin-password ADMIN_PASSWORD] [--accept-eula] [--reject-eula] [--cluster-uuid CLUSTER_UUID] [--admin-pbkdf2-hash ADMIN_PBKDF2_HASH] [--admin-pbkdf2-salt ADMIN_PBKDF2_SALT] [--admin-pbkdf2-num-iterations ADMIN_PBKDF2_NUM_ITERATIONS] [--node-uuids-and-fault-domains NODE_UUIDS_AND_FAULT_DOMAINS [NODE_UUIDS_AND_FAULT_DOMAINS ...]] [--all-unconfigured] --usable-capacity USABLE_CAPACITY --object-store-uris OBJECT_STORE_URIS [OBJECT_STORE_URIS ...] [--object-store-credentials OBJECT_STORE_CREDENTIALS [OBJECT_STORE_CREDENTIALS ...]]
```

Flags

Flag Name	Required	Description
<code>--cluster-name</code>	Yes	Cluster Name
<code>--admin-password</code>	No	Administrator Password
<code>--accept-eula</code>	No	Accept the EULA
<code>--reject-eula</code>	No	Reject the EULA
<code>--cluster-uuid</code>	No	Cluster UUID
<code>--admin-pbkdf2-hash</code>	No	Administrator password PBKDF2 hash (hexadecimal string)
<code>--admin-pbkdf2-salt</code>	No	Administrator password PBKDF2 salt (hexadecimal string)

<code>--admin-pbkdf2-num-iterations</code>	No	Administrator password PBKDF2 num iterations
<code>--node-uuids-and-fault-domains</code>	No	Cluster node UUIDs and fault domains. For each node, specify comma-separated tuple of (UUID, fault domain ID). To create a cluster without fault domains, specify None for the fault domain IDs.
<code>--all-unconfigured</code>	No	Use all discoverable unconfigured nodes to make cluster
<code>--usable-capacity</code>	Yes	Set usable capacity limit for the cluster, in human-readable format (e.g. 5TB).
<code>--object-store-uris</code>	Yes	Object store URI(s) provided by data core cluster(s)
<code>--object-store-credentials</code>	No	Object store credentials for all object stores referenced by the URIs. For each unique store name, specify comma-separated tuple of (store name, access key ID, secret access key).

qq time_get

This section explains how to use the `qq time_get` command.

Description

Get time configuration.

Usage

```
qq time_get [-h]
```

qq time_list_timezones

This section explains how to use the `qq time_list_timezones` command.

Description

List timezones supported by QC

Usage

```
qq time_list_timezones [-h]
```

qq time_reset_configuration

This section explains how to use the `qq time_reset_configuration` command.

Description

Set time configuration to this platform's default

Usage

```
qq time_reset_configuration [-h]
```

qq time_series_get

This section explains how to use the `qq time_series_get` command.

Description

Get specified time series data.

Usage

```
qq time_series_get [-h] [-b BEGIN_TIME] [--csv]
```

Flags

Flag Name	Required	Description
<code>-b</code>	No	Begin time for time series intervals, in epoch seconds
<code>--csv</code>	No	Format output as Comma Separated Values

qq time_set

This section explains how to use the `qq time_set` command.

Description

Set time configuration.

Usage

```
qq time_set [-h] [--source SOURCE] [--set-use-ad] [--unset-use-ad] [--ntp-servers NTP_SERVERS]
```

Flags

Flag Name	Required	Description
<code>--source</code>	No	The time source type. For all platforms other than Azure, must be API_TIME_SOURCE_NTP. For Azure, can be either API_TIME_SOURCE_NTP or API_TIME_SOURCE_HYPERVISOR.
<code>--set-use-ad</code>	No	Use Active Directory controller for NTP.
<code>--unset-use-ad</code>	No	Don't use Active Directory controller for NTP.
<code>--ntp-servers</code>	No	Set of NTP servers specified as comma delimited list.

qq time_status

This section explains how to use the `qq time_status` command.

Description

Get time configuration status.

Usage

```
qq time_status [-h]
```

qq tree_delete_cancel

This section explains how to use the `qq tree_delete_cancel` command.

Description

Cancel delete job

Usage

```
qq tree_delete_cancel [-h] id
```

Positional Options

Option Name	Description
<code>id</code>	Directory id

qq tree_delete_create

This section explains how to use the `qq tree_delete_create` command.

Description

Create delete job

Usage

```
qq tree_delete_create [-h] [--force] directory
```

Flags

Flag Name	Required	Description
<code>--force</code>	No	Bypass path confirmation. WARNING! Tree delete can be canceled with <code>tree_delete_cancel</code> , but already deleted items cannot be recovered.

Positional Options

Option Name	Description
<code>directory</code>	Directory id or path

qq tree_delete_get

This section explains how to use the `qq tree_delete_get` command.

Description

Get information about one delete job

Usage

```
qq tree_delete_get [-h] [--json] id
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Output JSON instead of table.

Positional Options

Option Name	Description
<code>id</code>	Directory id

qq tree_delete_list

This section explains how to use the `qq tree_delete_list` command.

Description

Get information about all tree delete jobs

Usage

```
qq tree_delete_list [-h] [--json]
```

Flags

Flag Name	Required	Description
<code>--json</code>	No	Output JSON instead of table.

qq tree_delete_restart

This section explains how to use the `qq tree_delete_restart` command.

Description

Retry errored delete job

Usage

```
qq tree_delete_restart [-h] id
```

Positional Options

Option Name	Description
<code>id</code>	Directory id

qq unconfigured_nodes_list

This section explains how to use the `qq unconfigured_nodes_list` command.

Description

Get the list of unconfigured nodes

Usage

```
qq unconfigured_nodes_list [-h] [--table] [--include-incompatibles]
```

Flags

Flag Name	Required	Description
<code>--table</code>	No	Print output as a table, instead of JSON
<code>--include-incompatibles</code>	No	Include incompatible unconfigured nodes in the output.

qq unconfigured_upgrade_config

This section explains how to use the `qq unconfigured_upgrade_config` command.

Description

List current upgrade prepare config for an unconfigured node

Usage

```
qq unconfigured_upgrade_config [-h]
```

qq unconfigured_upgrade_config_set

This section explains how to use the `qq unconfigured_upgrade_config_set` command.

Description

Upgrade on an unconfigured node with the FS path to an upgrade image

Usage

```
qq unconfigured_upgrade_config_set [-h] --path PATH [--target TARGET]
```

Flags

Flag Name	Required	Description
<code>--path</code>	Yes	FS path to upgrade image
<code>--target</code>	No	Target: idle, prepare, arm.

qq unconfigured_upgrade_status

This section explains how to use the `qq unconfigured_upgrade_status` command.

Description

List the current upgrade status for an unconfigured node

Usage

```
qq unconfigured_upgrade_status [-h] [--wait-until-prepared]
```

Flags

Flag Name	Required	Description
<code>--wait-until-prepared</code>	No	Monitor the upgrade status until the PREPARING state is complete.

qq unprotected_edge_cluster_create

This section explains how to use the `qq unprotected_edge_cluster_create` command.

Description

Creates a Single-Node Unprotected Qumulo Edge Device

Usage

```
qq unprotected_edge_cluster_create [-h] --edge-cluster-name EDGE_CLUSTER_NAME [--admin-password ADMIN_PASSWORD] [--accept-eula] [--reject-eula]
```

Flags

Flag Name	Required	Description
<code>--edge-cluster-name</code>	Yes	Edge Device Name
<code>--admin-password</code>	No	Administrator Password
<code>--accept-eula</code>	No	Accept the EULA
<code>--reject-eula</code>	No	Reject the EULA

qq upgrade_blocked

This section explains how to use the `qq upgrade_blocked` command.

Description

Get information on whether and for what reason an upgrade is blocked

Usage

```
qq upgrade_blocked [-h]
```

qq upgrade_cluster

This section explains how to use the `qq upgrade_cluster` command.

Description

Run a cluster upgrade to the image specified by the provided path

Usage

```
qq upgrade_cluster [-h] [--path PATH] [--no-monitor] [--rolling] [--num-nodes-to-reboot NO_COMMAND_NUM_NODES_TO_REBOOT] {prepare,commit} ...
```

Flags

Flag Name	Required	Description
<code>--path</code>	No	FS path to upgrade image
<code>--no-monitor</code>	No	Skip monitoring the upgrade
<code>--num-nodes-to-reboot</code>	No	Using the --rolling flag lets you specify the number of nodes to reboot at a time. The number of nodes must be greater than 0 and less than or equal to the number of node failures that your cluster permits. By default, this value is the number of permitted node failures minus 1 (1 node minimum).

qq upgrade_status

This section explains how to use the `qq upgrade_status` command.

Description

Get the status of the upgrade system

Usage

```
qq upgrade_status [-h] [--raw]
```

Flags

Flag Name	Required	Description
<code>--raw</code>	No	Skip monitoring an in-flight upgrade and just return the raw status

qq upgrade_verify_image

This section explains how to use the `qq upgrade_verify_image` command.

Description

Verify an image path for upgrade

Usage

```
qq upgrade_verify_image [-h] --path PATH
```

Flags

Flag Name	Required	Description
<code>--path</code>	Yes	FS path to upgrade image

qq version

This section explains how to use the `qq version` command.

Examples

To Show the Qumulo Core Version Running on Your Cluster

Run the `qq version` command.

The following is example output.

```
{
  "build_date": "2024-02-10T19:50:58Z",
  "build_id": "123456.7.8",
  "flavor": "release",
  "revision_id": "Qumulo Core 8.0.1"
}
```

Description

Print version information

Usage

```
qq version [-h]
```

qq web_ui_get_settings

This section explains how to use the `qq web_ui_get_settings` command.

Description

Get configuration options for the Web UI

Usage

```
qq web_ui_get_settings [-h] [--inactivity-timeout | --login-banner]
```

Flags

Flag Name	Required	Description
<code>--inactivity-timeout</code>	No	Gets the inactivity timeout
<code>--login-banner</code>	No	Gets the configuration for the login banner

qq web_ui_modify_settings

This section explains how to use the `qq web_ui_modify_settings` command.

Description

Modify configuration options for the Web UI

Usage

```
qq web_ui_modify_settings [-h] [--inactivity-timeout MINUTES | --disable-inactivity-timeout] [--login-banner BANNER_MARKDOWN_FILE | --disable-login-banner]
```

Flags

Flag Name	Required	Description
<code>--inactivity-timeout</code>	No	Sets the inactivity timeout
<code>--disable-inactivity-timeout</code>	No	Disables the inactivity timeout
<code>--login-banner</code>	No	Sets the login banner
<code>--disable-login-banner</code>	No	Disables the login banner

qq who_am_i

This section explains how to use the `qq who_am_i` command.

Description

Get information on the current user

Usage

```
qq who_am_i [-h]
```