ALARM CHECK LIST (6DE-18)

DESCRIPTION	MARK	METHOD	E.CONDITION
L.O INLET PRESSURE LOW **(TRIP)**	**63Q2**	USE PRESSURE CALIBRATOR **(BELOW 0.3MPa)**	**RUN**
H.T CW OUTLET TEMPERATURE HIGH **(TRIP)**	**26WH2**	USE HEAT CALIBRATOR **(OVER 95°C)**	**RUN**
OVER SPEED **(TRIP)**		ADJUST AT ECD **(35:950RPM)**	**RUN**
EMERGENCY STOP (REMOTE/LOCAL) **(TRIP)**		PRESS EMERGENCY BUTTON ON **ECD** AND **ECR**	**RUN**
SYSTEM FAILURE	**STATUS**		**STOP**
SCR COMMON ALARM		DISPLAY ON E.C.R	**STOP**
ENGINE SPEED	**STATUS**		**RUN**
LOAD	**STATUS**		**RUN**
RUNNING HOUR	**STATUS**		**RUN**
ENGINE RUN	**STATUS**		**RUN**
READY TO START	**STATUS**		**STOP**
LINK TO E.C.D	**ECD**	REMOVE PLUG ON ECU	**STOP**
EMG. STOP SWITCH ON ECD	**ECD**	REMOVE PLUG ON ECU	**STOP**
CONTROL MODULE FAILURE		SETTING ON ECD **81-1**	**STOP**
SAFETY MODULE FAILURE		SETTING ON ECD **81-2**	**STOP**
LINK TO REMOTE I/O 1 FAILURE		SETTING ON ECD **81-3**	**STOP**
LINK TO REMOTE I.O 2 FAILURE		SETTING ON ECD **81-4**	**STOP**
START FAILURE		SHUT OFF STARTING AIR VALVE	**STOP**
PRIMING PUMP THERMAL FAILURE		RESET GREEN BUTTON INSIDE PRIMING BOX	**STOP**
L.O SUMP TANK LEVEL LOW	**33QL**	REMOVE **1** WIRE	**STOP**
PRIMING L.O PRESSURE LOW		STOP RUNNING PRIMING PUMP	**STOP**
EMG. STOP SWITCH OF EXTERNAL		REMOVE REGISTER INSIDE **ECU** OR PANEL IN **ECR**	**STOP**
F.O LEAK TANK LEVEL HIGH	**33F**	REMOVE AND TAKE OUT SENSOR	**STOP**
LOAD INPUT FAILURE		REMOVE WIRE NUMBER **57** INSIDE **ECU**	**STOP**
NO.1 CYLINDER EX.GAS TEMP S.S FAIL	**A1**	REMOVE PLUG ON **ECU**	**STOP**
NO.2 CYLINDER EX.GAS TEMP S.S FAIL	**A2**	REMOVE PLUG ON **ECU**	**STOP**
NO.3 CYLINDER EX.GAS TEMP S.S FAIL	**A3**	REMOVE PLUG ON **ECU**	**STOP**
NO.4 CYLINDER EX.GAS TEMP S.S FAIL	**A4**	REMOVE PLUG ON **ECU**	**STOP**
NO.5 CYLINDER EX.GAS TEMP S.S FAIL	**A5**	REMOVE PLUG ON **ECU**	**STOP**
NO.6 CYLINDER EX.GAS TEMP S.S FAIL	**A6**	REMOVE PLUG ON **ECU**	**STOP**
EX.GAS TEMP. T/C INLET 1 S.S FAILURE	**A9**	REMOVE PLUG ON **ECU**	**STOP**

EX.GAS TEMP. T/C INLET 2 S.S FAILURE	**A10**	REMOVE PLUG ON **ECU**	**STOP**
EX.GAS TEMP. T/C OUTLET S.S FAILURE	**A11**	REMOVE PLUG ON **ECU**	**STOP**
L.O TEMP. INLET S.S FAILURE	**A12**	REMOVE PLUG ON **ECU**	**STOP**
EMG. SOLENNOID VALVE	**D5, D6**	REMOVE BOTH PLUG ON **ECU**	**STOP**
H.T CW TEMP SWITCH HIGH	**D10**	REMOVE PLUG ON **ECU**	**STOP**
H.T CW TEMP. OUTLET S.S FAILURE	**A15**	REMOVE PLUG ON **ECU**	**STOP**
STARTING AIR PRESS S.S FAILURE	**I4**	REMOVE PLUG ON **ECU**	**STOP**
L.O INLET PRESSURE SWITCH LOW	**D16**	REMOVE PLUG ON **ECU**	**STOP**
L.O INLET PRESS S.S FAILURE	**I1**	REMOVE PLUG ON **ECU**	**STOP**
F.O INLET PRESS S.S FAILURE	**I2**	REMOVE PLUG ON **ECU**	**STOP**
H.T CW PRESS INLET S.S FAILURE	**I6**	REMOVE PLUG ON **ECU**	**STOP**
L.T CW PRESS INLET S.S FAILURE	**I7**	REMOVE PLUG ON **ECU**	**STOP**
ALL SPEED PICKUP S.S FAILURE	**TS1,TS2**	REMOVE PLUG ON **ECU**	**STOP**

L.O INLET PRESSURE LOW **(ALARM)**	**PTQ**	USE PRESSURE CALIBRATOR **(BELOW 0.35 MPa)**	**RUN**
H.T WATER PRESS ENGINE INLET	**PTWH**	USE PRESSURE CALIBRATOR **(BELOW 0.15 MPa)**	**RUN**
L.O FILTER DIFF. PRESSURE HIGH	**63QDM**	OPEN VALVE & LOOSE THE SCREW ON LEFT SIDE ON **L.O BACKWASH FILTER (OVER 0.09 MPa)**	**RUN**
L.T WATER PRESS ENGINE INLET	**PTWL**	USE PRESSURE CALIBRATOR **(BELOW 0.15 MPa)**	**RUN**
STARTING AIR PRESSURE	**PTAS**	USE PRESSURE CALIBRATOR **(BELOW 1.5 MPa)**	**RUN**
T/C L.O INLET PRESSURE LOW	**63QT**	USE PRESSURE CALIBRATOR **(BELOW 0.06 MPa)**	**RUN**
F.O PRESSURE ENGINE INLET	**PTF**	USE PRESSURE CALIBRATOR **(BELOW 0.35 MPa)**	**RUN**

L.O TEMPERATURE ENGINE INLET	**TRQ**	USE HEAT CALIBRATOR **(OVER 65°C)**	**RUN**
DG FORE BEARING TEMPERATURE		USE HEAT CALIBRATOR **(OVER 90°C)**	**RUN**
H.T WATER TEMP ENGINE OULET **(ALARM)**	**TRWHO**	USE HEAT CALIBRATOR **(OVER 90°C)**	**RUN**
NO.1 CYLINDER EX.GAS TEMPERATURE	**TRC1**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
NO.2 CYLINDER EX.GAS TEMPERATURE	**TRC2**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
NO.3 CYLINDER EX.GAS TEMPERATURE	**TRC3**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
NO.4 CYLINDER EX.GAS TEMPERATURE	**TRC4**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
NO.5 CYLINDER EX.GAS TEMPERATURE	**TRC5**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
NO.6 CYLINDER EX.GAS TEMPERATURE	**TRC6**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
EXHAUST GAS TEMPERATURE T/C OUTLET	**TRTO**	USE HEAT CALIBRATOR **(OVER 500°C)**	**RUN**
EXHAUST GAS TEMPERATURE T/C INLET 1	**TRTI1**	USE HEAT CALIBRATOR **(OVER 580°C)**	**RUN**
EXHAUST GAS TEMPERATURE T/C INLET 2	**TRTI2**	USE HEAT CALIBRATOR **(OVER 580°C)**	**RUN**

Prepared by: Tin DVN