

[Support](#) » [APIs](#) » XIMEA Linux Software Package

Support

[Downloads](#)[Knowledge Base](#)[Contact Support](#)

XIMEA Linux Software Package



XIMEA Linux Software Package is tarred installer of [xiAPI](#) with examples.

It is designed to run on most common Linux distribution that includes the usual tools and libraries like:

Ubuntu, Red Hat, Arch, Gentoo etc.

Please note: Even though cameras and API can work with such systems, XIMEA does not guarantee reliable functionality on the ones which are NOT included in the list of tested versions mentioned below.

Supported CPU

xiAPI supports following CPU families:

- **Intel x86** - tested with Linux Ubuntu x86_64: **14.04, 16.04, 18.04**
- **ARM** - tested with **Linux for Tegra** on NVIDIA:
 - [Jetson TX1](#)
 - [Jetson TX2](#)
 - [Jetson TX2i](#)
 - [Jetson Nano](#)
 - [Jetson AGX Xavier](#)

See also additional helpful materials:

[Linux TX1, TX2, TX2i, Nano and AGX Xavier Support](#),
[Jetson TX2 vs AGX Xavier](#),
[Jetson Nano Benchmarks](#),
[Jetson Nano, TX2 and AGX Xavier benchmarks](#)
[Jetson Image Processing](#),
[Jetson Zero Copy for Embedded applications](#),
[Realtime image processing on NVIDIA GeForce RTX 2080ti](#),
[Multimedia User Guide](#)

Contents

The Package contains:

- Driver (newest beta version) for XIMEA **USB 2.0** and **USB 3.0** cameras
 - Read more about [Linux USB2.0 Support](#)
 - Read more about [Linux USB3.0 Support](#)
- Driver for **XIMEA PCIe Cameras**
- Driver (newest beta version) for XIMEA Firewire cameras
 - Read more about [Linux Firewire Support](#)
- Kernel Driver for **CURRERA-R** cameras
- **CamTool** - interactive viewer
- **xiAPI** - SDK for camera control by your software

- [Python](#)

- [OpenCV](#)

XIMEA Linux Software Package
Supported CPU
Contents
Installation
Uninstallation
Troubleshooting
Supported Vision Libraries
Knowledge Base

- Examples:
 - xiSample - sample showing basic image acquisition in xiAPI
 - streamViewer - camera live image viewer for picture check
 - streamViewer is based on gstreamer. It must be installed before streamViewer is started. Please read more in README file.

Installation

- Download [XIMEA Linux Software Package](#)

```
wget https://www.ximea.com/downloads/recent/XIMEA_Linux_SP.tgz
```

- Untar

```
tar xzf XIMEA_Linux_SP.tgz
cd package
```

- Start installation script

- For **PCIe Cameras** - please start script with option -pcie.

```
./install -pcie
```

If it fails, make sure that you have necessary tools installed, e.g. run the following command on Ubuntu:

```
sudo apt-get update && sudo apt-get install build-essential linux-headers-"$(uname -r)"
```

or this one on Red Hat:

```
sudo yum install gcc make kernel-devel
```

- For other cameras (i.e. USB3 cameras)

```
./install
```

- If logged in user is not root, you will be asked for your password to get root access because the installation runs with root account using sudo.

Uninstallation

Run uninstall script:

```
/opt/XIMEA/uninstall
```

If logged in user is not root, you will be asked for your password to get root access same as with install script.

Troubleshooting

If you should run into any issues during installing XIMEA API, before submitting a [Support request](#), please read our troubleshooting pages:

- [USB 2.0 Support](#),
- [USB 3.0 Support](#),
- [Firewire Support](#),
- [ARM Support](#),
- [Nvidia Jetson TX1/TX2/Nano/AGX Xavier Support](#),

Supported Vision Libraries

- [OpenCV](#)

Knowledge Base

You can find a solution for known issues in our [Linux SP Knowledge Base](#).