USER MANUAL

AGRIMATE®
Maximum **Power** - Super **Economy**

AGRIMATE

TURBO MIST BLOWER CUM DUSTER

AM-MBD-5650



BEFORE OPERATING THIS MACHINE,
PLEASE READ THESE INSTRUCTIONS CAREFULLY

DISCLAIMER: DUE TO CONSTANT UPGRADATION, FEATURES AND SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE



ratnagiri impex

BRINGING YOU THE FUTURE... NOW

Celebrating 20 Years Ratnagiri Impex

CARING AND GROWING TOGETHER SINCE 1999

Dear Sir/Madam,

Thank you for choosing Agrimate product. You are the proud owner of high technology and durable machine. Trust that our franchisee/dealer installed the product and explained you about the usage and service instructions. Please visit our authorised dealer for your future requirement of our other equipments, genuine spares, accessories and service. Service coupons are attached with this manual and you can avail free service.

About Ratnagiri

We import and market of high quality of agriculture wide range of equipment's Which we are selling through our authorized franchisee or dealer network. We are in this field from past 20 years serving the former community. For further details, you may please visit our website www.agrimart.in.

Range of Brands

AGRIMATE Maximum Power - Super Economy | Oleo-Mac ITALY-GERMANY-USA our power, your passion | KASEI Advanced Technology | GP Green Panther

Our Retail Formats

AGRIMART FARM EQUIPMENT | GREEN CARE | SERVICES | AGRIMART MEGA FARM EQUIPMENT | GREEN CARE | SERVICES | AGRIMART ZONE FARM EQUIPMENT | GREEN CARE | SERVICES

Agriculture | Horticulture | Sericulture | Plantations | Forestry | Garden | Health care

Guide to Using this Manual

Pictograms

All the pictograms attached to the machine are shown and explained in this manual. The operating and handling instructions are supported by illustrations.

Symbols in text

The individual steps or procedures described in the manual may be marked in different ways:

- Step or procedure without direct reference to an illustration.

Description of step or procedure that refers directly to the illustration and contains item numbers that appear in the illustration.
Example:

Loosen the screw **(1)**

Lever **(2)** ...

In addition to the operating instructions, this manual may contain paragraphs that require your special attention Such paragraphs are marked with the symbols described below:

⚠ Warning where there is a risk of an accident or personal injury or serious damage to property.

Warning where there is a risk of damaging the machine or individual components.

Note or hint which is not essential for using the machine, but may improve the operator's understanding of the situation and result in better use of the machine.

Note or hint on correct procedure in order to avoid damage to the environment.

* Equipment and features

This instruction manual refers to several models with different features. Components that are not installed in all models and related applications are marked thus. Such components are available as special accessories from your dealer.

Engineering improvements

Philosophy is to continually improve all of its products. As a result, engineering changes and improvement are made from time to time. If the operating characteristics or the appearance of your machine differ from those described in this manual, please contact your dealer for assistance.

Therefore, we cannot be responsible for changes, modifications or improvements not covered in this manual.

Safety Precautions



Special safety precautions must be observed when working with the power tool.



It is important that you read, fully understand and observe the following safety precautions and warnings.

Careless or improper use of any blower may cause serious or fatal injury.

Have your dealer show you how to operate your blow etc. Observe all applicable local safety regulations, standards and ordinances.

Minors should never be allowed to use a blower.

Bystanders, especially children, and animals should not be allowed in the area where a blower is in use.
The operator is responsible for avoiding injury to third parties and damage to their property. Do not lend or rent your blower without the owner's manual. Be sure that anyone using your blower understands the information contained in this manual.

You must be fit to work with a blower

- Rested, healthy and in good physical and mental condition
- if you get tired, take a break in good time
- Do not operate the blower if you are under the influence of any substance (drugs, alcohol, etc.) which might impair vision, dexterity or judgment.

Only attachments supplied are expressly approved for use with your specific model are authorized.

Other attachments must not be used because of the increased risk of accidents. Excludes all liability for personal injury and damage to property caused while using unauthorized attachments.

Wear proper clothing and equipment



Clothing must be sturdy and snug-fitting, but allow complete freedom of movement - a safety coverall is recommended.



Avoid loose-fitting jackets, scarfs, neckties, jewelry, flared or cuffed pants, unconfined long hair or anything that could get into the air intake.



Wear sturdy boots with nonslip soles. Steel-toed safety boots are recommended.



Wear safety glasses, goggles or a face shield.

Wear sound barriers (ear plugs or ear mufflers) to protect your hearing.



Wear heavy-duty, nonslip gloves, preferably made of chrome leather.

Always shut off the engine before refueling.



Gasoline is an extremely flammable fuel. Do not smoke or bring any fire or flame near the fuel.

Do not fuel a hot engine - fuel may spill and cause a fire.
Remove the fuel filler cap on the unit carefully so as to allow any pressure build-up in the tank to release slowly.
Fuel your blower, in well-ventilated areas, outdoors only. Wipe off any spilled fuel before starting and check for leakage. Take care not to get fuel on your clothing. If this happens, Change immediately.



Unit vibrations can cause an improperly tightened fuel cap to loosen or come off and spill quantities of fuel.

In order to reduce risk of fuel spillage and fire, tighten fuel cap as speeifred.

On units with a screw cap: Tighten the cap by hand with as much force as possible. On units with hinged handle on the fuel cap: Tighten as described in chapter "Fueling".

Check for fuel leakage while refueling and during operation. If fuel leakage is found, do not start or run the engine until leak is fixed.

Store gasoline and oil in properly labelled, approved safety-type cans.

Transporting the unit

Always stop the engine.

Transporting in a vehicle: Properly secure your unit to prevent turnover, fuel spillage and damage. When the unit is not in use (work break), put it down so that it does not endanger others.

Before starting

Check the following points:

- Throttle trigger must move freely and spring back to idle position when released.
- Stop switch must move easily to "OFF"
- Tightness of spark plug boot-if boot is Loose, sparks may occur and ignite the escaping fuel vapor!

Starting

- Start the engine at least 3 m (10 ft) from the fueling spot, outdoors only.
- To reduce the risk of breathing toxic fumes, never start or run your unit in confined spaces.
- Place the unit on firm ground in an open area.
- Make sure you have good balance and secure footing.
- Hold the unit securely.

Your blower is a one-person unit. Do not allow other persons to be near the running unit - even when starting.
For specific starting instructions, see chapter "Starting" in the owner's manual.

During operation

Warning!

Your blower produces toxic exhaust fumes as soon as the engine is running. These gases

(e.g. carbon monoxide) may be colorless and odorless. To reduce the risk of serious or fatal injury from breathing toxic fumes, never run the blower indoors or in poorly ventilated locations.

Ensure proper ventilation when working in trenches, hollows or other confined areas.


To reduce the risk of igniting highly combustible fuel vapor and causing a fire, never smoke while working with or standing next to the blower.

Always hold your unit firmly- make sure you always have a firm and secure footing.

Examine the work area: Do not direct

The air blast towards bystanders

Since the air flow can blow small objects at great speed.



Take care in slippery conditions

- On ice, in wet or snow
- On slopes or uneven ground

Watch out for obstacles:

Roots, ditches, holes or rubbish which could cause you are to trip or stumble.

Spraying attachment

⚠ In the interests of the general public and the environment it is essential to observe all general safety regulations when handling and using plant protection products and other chemicals.

Follow the safety precautions and instructions given by the manufacturer of the plant protection products.

Change clothing immediately if it becomes soaked with plant protection chemical or spay solution.

⚠ To reduce the risk of inhaling poisonous fumes from chemicals and exhaust gases, do not operate the mist blower in confined spaces. Always wear a respirator when working in well-ventilated greenhouses, in dense, high stands and performing any work with dangerous dusting chemicals. Be alert to the wind direction do not work into the wind. Walk forwards only when the unit is running.

After finishing work, drain and clean the container. Do not empty residual spray solution or flushing fluids into waterways, gullies, sinks, drainage ditches or shafts. Dispose of properly in accordance with local waste disposal regulations.

Always drain and clean the container before transporting the mist blower in a vehicle.

⚠ In an emergency, release the quick-action buckles, slip out of the harness and throw off the machine.

Vibrations

Prolonged use of the unit may result in vibration-induced circulation problems in the hands (white finger disease).

No general recommendation can be given for the length of usage because it depends on several factors. The period of usage is prolonged by:

- Hand protection (wearing warm gloves)
- breaks

The period of usage is shortened by:

- Any personal tendency to suffer from poor circulation (symptoms: frequently cold fingers, itching).
- Low outside temperatures.
- Gripping force (a tight grip hinders circulation).

Continual and regular users should monitor closely the condition of their hands and fingers. If any of the above symptoms appear, seek medical advice.

Maintenance and repairs

Do not attempt any maintenance or repair work not described in your owner's manual. Have such work performed at your service shop only.
Never modify your power tool in any way as this could result in serious injury.


Always stop the engine and disconnect the spark plug boot before doing any maintenance or repair work or cleaning the machine.

Exception: Carburetor and idle adjustments.
Always clean dust and dirt off the machine after finishing work.

Do not service or store your unit near any fire or flame!


- Check fuel cap regularly for leaks.
- Use only a approved spark plug (see Specifications) and make sure it is in good condition.
- Inspect ignition lead (insulation in good condition, secure connection).
- To reduce the risk of fire due to ignition outside the cylinder, move the stop switch to OFF or ON before turning the engine over on the starter with the spark plug boot removed or the spark plug unscrewed.
- Check condition of muffler periodically.
- To avoid **risk of fire and hearing loss**, do not operate your unit if the muffler is damaged or missing.
- Never touch a hot muffler or burn will result.


Assembling the Unit



Mounting the spraying attachment


- Push the extension tube into the pleated hose as far as it will go.
- Rotate the tube to the left (counter-clockwise) as far as stop and leave it in that position until you have completed the following adjustments.
- Turn the control handle counterclockwise to the horizontal position.
- Now rotate the extension rube counterclockwise until the metering unit points in the same direction as the control handle.
- Tighten down clamp screw (see "Adjusting the control handle").
- Attach liquid hose to the pleated hose with the retainer.





- Push the free end of the liquid hose over the stub on the stop cock and secure in position with the hose clip.
- Close the stop cock (move lever to vertical position).
- Fill up with water and check all hose connections for leaks.

Adjusting the control handle




- Put the unit on your back.
- Release the clamp screw.
- Slide the control handle along the pleated hose to the most comfortable position.
- Retighten the clamp screw.

Adjusting the harness straps

- Pull the ends of the straps downward to tighten the harness.

Fuel



Your engine requires a mixture of gasoline and engine oil. The quality of these constituents and the mix ratio have a decisive influence on the function and service life of the engine.

Loosening the harness straps

- Lift the tabs of the two sliding adjusters.
- Adjust the straps so that the back plate is held firmly and comfortably against your back.

⚙ Unsuitable fuels or lubricants or mix ratios other than those specified may result in serious damage to the engine (piston seizure, rapid rate of wear, etc.).

Gasoline

Use only regular branded gasoline with a minimum octane rating or 90. If the octane rating of the regular grade gasoline in your area is lower, use premium fuel - leaded or unleaded.

For health and environmental reasons, you should give preference to unleaded gasoline. If your machine is equipped with a **catalytic converter**, you must use **unleaded gasoline.**

⚙ A few tankful of leaded gasoline will greatly reduce the efficiency of the catalytic converter.

Engine oil

Use only quality two-stroke engine oil.
Other quality two-stroke engine oils must conform to classification TC.

⚙ Poor quality gasoline or engine oil may damage the engine, sealing rings, hoses and the fuel tank.


Mixed fuel

⚠ Avoid direct skin contact with gasoline and avoid inhaling gasoline vapour.

- Use a canister approved for storing fuel. Pour oil (1) into the canister first, then add gasoline (2) and mix thoroughly.

Mix ratio

Two-stroke engine oils (classification TC): 25 parts gasoline to 1 part oil



Fueling



Storing fuel

Fuel mix ages:
Only mix sufficient fuel for a few months' work.
Store in approved safety - type fuel canisters in a dry and safe location.

- Thoroughly shake the mixture in the canister before fueling your machine.

⚠ Pressure may build up in the canister - open it carefully.

- Clean the fuel tank and canister from time to time.

Dispose of cleaning fluid properly at authorized disposal location.


- Before fueling, clean the filler cap and the area a around it to ensure that no dirt falls into the tank.
- Position the unit so that the filler cap is facing up.

Take care not to spill fuel while fueling and do not overfill the tank.

⚠ After fueling, tighten down filler cap by hand as securely as possible.


Change the fuel pickup body once every year

- Drain the fuel tank.
- Use a hook to pull the fuel pickup body out of the tank and take it off the hose.
- Push the new pickup body into the hose.
- Place the pickup body in the tank.



See "Guide to Using this Manual"

Starting / Stopping the Engine



- Observe safety precautions - see chapter" Safety Precautions".
- Slide the stop switch (1) to ON
- Move the setting lever (2) to the center position - **this is the starting throttle position**


Note:


The setting lever can be used to select any throttle opening between idle speed (lower stop) and full throttle (upper stop).

Set the lever to idle position before switching off the engine.

Before starting


- Move stop cock lever (3) to upright position.





- If the engine is cold, turn the choke knob to
- If the engine is warm, turn the choke lever to

Also use this position is the engine has been running but is still cold.




- Put the unit on the ground. Check that bystanders are well clear of the general work area and the nozzle.
- Make sure you have a firm footing: Hold the unit with your left hand on the housing and put one foot again the base plate to prevent it slipping.
- Pull the starter grip slowly with your right hand until you feel it engage and give it a brisk strong pull. Do not pull the starter rope out all the way as it might otherwise break.
- Do not let the starter grip snap back.


- Guide it slowly back into the housing so that the starter rope can rewind properly.


When engine begins to fire:


If engine is **cold:**

- Turn choke knob to ⊼ and continue cranking until engine runs.
- If engine is **warm:**
  Continue cranking until engine runs.









As soon as engine runs:

- Move the setting lever **(2)** to the lower stop so that the engine settles down to idle speed.

To shut down the engine:

- Slide the stop switch **(1)** to **OFF**

At very low outside temperatures: Allow engine to warm up

As soon as engine runs:

- Move the setting lever to the lower stop - the engine settles down to idle speed.
- Open throttle slightly - warm up engine for a short period.

If the engine does not start:

If you did not turn the choke knob to ⊼ quickly enough after the engine began to fire, the combustion chamber is flooded.

- Pull off the spark plug boot.
- Unscrew and dry off the spark plug.

- Set the stop switch to OFF
- Open the throttle fully.
- Pull the starter rope several times to clear the combustion chamber.
- Fit the spark plug and reconnect the spark plug boot.
- Move the stop switch to ON
- Turn the choke knob to even if the engine is cold.
- Now start the engine.

Fuel tank run until dry and then refueled

- Pull the starter rope several times to prime the fuel line.



Operating instructions

During break-in period

A factory new machine should not be run at high revs (full throttle off load) for the first three tank fillings. This avoids unnecessary high loads during the bresk-in period. As all moving parts have to bed in during the bresk-in period, the frictional resistances in the engine are greater during this period. The engine develops its maximum power after about 5 to 15 tank fillings.

During operation

After a long period of full-throttle operation, allow engine to run for a while at idle speed so that the heat in the engine can be dissipated by flow of cooling air. This protects engine-mounted components (ignition, carburetor) from thermal overload.

After finishing work

Storing for short period:
Wait for engine to cool down. To avoid condensation, fill the fuel tank and keep the unit in a dry place until you need it again. Storing for a long period: see chapter "Storing the Machine".

Using the Mist blower

The mist blower is carried as a backpack and designed for single-handed operation. It is ideal for spraying plant protection products.
Furthermore, the unit is suitable for spreading granulate, e. g. fertilizers and fish feed, and grass seed (special accessory).

Filling the Container

Mix chemical solutions outdoors or in well-ventilated rooms only. After preparing the spray solution, empty and thoroughly rinse all containers used for the products. Calculate the amount of chemical solution required so that none is left over.

Never spray undiluted chemicals!

It is essential to observe the safety precautions and instructions given by the manufacturer of the plant protection products.

When filling the machine's container with water, close the stop cock and take particular care to avoid foaming and overflowing.

Never store chemical solution in machine's container for several days.


Even the smallest traces of plant protection chemicals in open waterways are a danger to the environment .Do not submerge filling hoses in the chemical solution since there is a risk of chemical Being succeed into the water pipe (e.g. drinking water supply) in the event of a sudden drop in line pressure (vacuum).

Metering Unit

The stop cock (1) on the control handle opens and closes the solution feed hose.


- Turn lever to horizontal position for maximum flow.
- Turn lever to upright position to shut off flow.
- The discharge rate can be infinitely varied by turning the metering knob on the nozzle.

Metering knob position "1" is the minimum spray solution flow rate and "4" the maximum. The required number on the metering knob must be lined up with the molded lug.



Check operation of metering unit at regular intervals (without pressure pump)

- Place the unit on the ground.
- Fill the container with water up to 10 liter mark.
- Set metering knob toq4r•
- Start the unit (baffle removed).
- Hold the spray tube horizontally, run the engine at full throttle, spray the contents of the container down to the 5 liter mark and note the time taken.



The time required to spray 5 liters fluid should be between 80 and 100 sec.

If the time required is longer, check the metering unit for contamination and clean if necessary. Also check carburetor setting and correct if necessary.

If there is no noticeable improvement, contact your dealer for assistance.

Mist blowing

The mist blower uses air as an additional transport medium for the active ingredient. An engine-powered fan produces a powerful, concentrated airstream to which the solution (active ingredient in a carrier liquid) is added via a metering system. The solution is atomized into very fine droplets and discharged at high velocity by the airstream.

Dirty air filers reduce engine power increase fuel consumption and make starting more difficult.

If there is a noticeable loss of engine power

- Turn choke knob to
- Release the screws (1) and pull off the filter cover (2).
- Remove the filter from the cover and inspect it - if it is dirty or damaged, clean the filter or fit a new one.
- Install the main filter and pre filter elements in the filter cover.
- Fit the cover on the filter base and tighten it down firmly.

Carburetor

General information


Your carburetor comes from the factory with a standard setting.
This setting provides an optimum fuel-air mixture under most operating conditions.
The high speed screw alters the engine's power output and the maximum off-load engine speed.

⚙ If the setting is too lean there is a risk of engine damage due to insufficient lubrication and overheating.

Standard Setting


Carburetor with limiter caps

- Shut off the engine.
- Screw down the high speed screw (H) and low speed screw (L) counterclockwise as far as stop (no more than 1/4 turn).



Carburetor without limiter caps


- Shut off the engine.
- Carefully screw both adjusting screws down onto their seats (clockwise).
- Open the high speed screw (H) one full turn.
- Open the low speed screw (L) one full turn.



Adjusting Idle Speed

Engine stops while idling

- Carry out standard setting on low speed screw.
- Turn the idle speed screw (LA) clockwise until the engine runs smoothly.



Erratic idling behavior, poor acceleration

- Carry out standard setting on low speed screw.
- Turn low speed screw (L) counterclockwise until the engine runs and accelerates smoothly.

It is usually necessary to change the setting of the idle Speed screw **(LA)** after every correction to the low speed screw **(L)**

Fine Tuning for Operation at High Altitude


A slight correction of the setting may be necessary if engine power is not satisfactory when operating at high altitude:

- Check the standard setting.
- Warm up the engine.
- Turn the high speed screw (H) slightly clockwise (leaner). On models with limiter caps, turn high speed screw (H) 1/4 turn, but no further than stop.

Checking the Spark Plug


If engine is down on power, difficult to start or runs poorly at idle speed first check the spark plug.

- Remove the spark plug - see "Starting / Stopping the Engine"
- Check electrode gap (A) and readjust if necessary - see "Specifications".



Rectify the problems which have caused fouling of spark plug:


. To much oil in fuel mix.
. Dirty air filter.
. Unfavorable running conditions.



Fit a new spark plug after about 100 operating hours .

or sooner if the electrodes are badly eroded.

To reduce the risk of arcing and fire:




- If the spark plug comes with a detachable adapter nut (1), screw it on fi rm ly.
  On all spark plugs:
- Always press the boot (2) firmly on to the spark plug (3).

Engine Running Behavior


If engine running behavior is unsatisfactory even though the air filter is clean and the carburetor properly adjusted, the cause may be in the muffler.
Have the muffler checked for contamination (coking) by dealer.


Replacing Starter Rope and Rewind Spring




Replacing Starter Rope and Rewind Spring


- Remove the screws (1).
- Take the starter cover(2) off the engine.








- Remove the spring clip (3).
- Remove the rope rotor with washer (4) and pawl (5).
- Ease the cap (6) out of the starter grip.
- Remove remaining rope from the rotor and grip.
- Tie a simple overhand knot in the end of the new starter rope (see Specifications) and then thread the rope through the top of the grip and the rope bush (7).
- Refit the cap in the grip.
- Thread the rope through the rotor and secure it in the rotor with a simple overhand knot.





- Fit the pawl (5) in the rotor and slip the washer (4) over the starter post.
- Use a screwdriver or suitable pliers to install the spring clip (3) on starter post and over the peg on the] pawl-the spring clip must point clock wise - see illustration. Go to "Tensioning rewind spring".


Replacing a broken rewind spring

- Lubricate the new spring with a few drops of non-resinous oil.
- Remove the rope rotor as described in "Replacing the starter rope".
- Remove parts of old spring.
- Fit new spring housing. Bottom plate must face downward. Engage outer spring loop over the lug.
- Refit the rope rotor.
  Go to "Tensioning rewind spring".
  If the spring pops out and uncoils during installation: Refit it in the spring housing in the counter- clockwise direction . Start outside and work inward.

Tensioning rewind spring

Make a loop in the unwound starter rope and use it to turn the rope rotor six full revolutions in the direction of the arrow (see illustration).

- Make a loop in the unwound starter rope and use it to turn the rope rotor six full revolutions in the direction of the arrow (see illustration).
- Hold the rotor steady, Straighten the twisted rope.
- Release the rotor and let go of rope slowly so that it winds onto the rotor.
- The starter grip must sit firmly in the rope guide bush. If the grip droops to one side: increase spring tension by one additional turn.



When the starter rope is fully extended it must be possible to rotate the rotor at least another half turn. If this is not possible, the spring is over tensioned and could break. Take one turn of the rope off the rotor.

- Fit the starter cover on the engine.
- Tighten down the screws firmly.
- Move the stop switch to OFF

Storing the Machine

For periods of about 3 months or longer

- Drain and clean the fuel tank in a well ventilated area.
- Drain and clean the container.
- Run engine until carburetor is dry this helps prevent carburetor diaphragms sticking together.
- Thoroughly clean the machine. Pay special attention to the cylinder fins and air filter.
- Store the machine in a dry, high or locked location - out of the reach of children and other unauthorized persons.
- Do not expose the container to direct sunlight for unnecessarily long periods. UV rays can make the container material brittle, which could result in leaks or breakage.

Maintenance Chart

The following maintenance intervals apply to normal operating conditions only. If your daily working time is longer than normal or operating conditions are difficult (very dusty work area etc.), shorten the specified intervals accordingly.		before starting work	after finishing work or daily	after each refueling stop	weekly	monthly	every 12 months	if problem	if damaged	if required
Complete machine	Visual inspection (conditon, leaks)	x		x						
	Clean		x							
Control handle	Check operation	x		x						
Air filter	Clean							x		
	Replace								x	
Filter in fuel tank	Check							x		
	Replace						x			x
fuel tank	Clean					x				
Carburetor	Check idle setting	x		x						
	Readjust idle									x
Spark plug	Readjust electrode gap							x		
Cooling air intakes	Clean				x					
Spark arresting screen in muffler	Check									x
	Clean or replace							x		
All accessible screws and nuts (notadjusting screws)	Tighten									x
Container with hose	Visual inspection (condition, leaks)	x								
Metering unit	Check							x		
Anti-vibration elements	Visual inspection	x								
	Have replaced by dealer							x	x	

Minimize Wear and Avoid Damage

Observing the instructions in this manual helps reduce the risk of unnecessary wear and damage to the power tool.

The power tool must be operated, maintained and stored with the due care and attention described in this owner's manual.

The user is responsible for all damage caused by non-observance of the safety precautions, operating and maintenance instructions in this manual. This includes in particular:

. Alterations or modifications to the product not approved by dealer.
. Using attachments, Power Tool Attachments or cutting tools not approved by dealer.
. Using the product for purposes for which it was not designed.
. Using the product for sports or competitive events.
. Consequential damage caused by continuing to use the product with defective components.

Maintenance Work

All the operations described in the "Maintenance Chart" must be performed on a regular basis. If these maintenance operations cannot be performed by the owner, they should be performed by an authorized servicing dealer.

If these operations are not carried out as specified, the user assumes responsibility for any damage that may occur. Among other things, this includes:

. Damage to the engine due to neglect or deficient maintenance (e.g. of air and fuel filters), incorrect carburetor adjustment or inadequate cleaning of cooling air inlets (intake ports, cylinder fins).
. Corrosion and other consequential damage resulting from improper storage.
. Damage and consequential damage resulting from the use of parts other than original replacement parts.
. Damage resulting from maintenance or repair work performed by authorized servicing dealers.


Parts Subject to Wear and Tear

Some parts of the power tool are subject to normal wear and tear even during regular operation in accordance with instructions and, depending on the type and duration of use, have to be replaced in good time.


Among other parts, this includes:


. Filters (air, fuel)
. Fan wheel
. Starter mechanism
. Spark plug
. Components of anti-vibration system

Parts and Controls



1 Baffle screen
2 Standard nozzle
3 Metering knob
4 Extension tube
5 Throttle trigger
6 Setting lever
7 Stop switch
8 Control handle
9 Stop cock
10 Pleated hose
11 Harness
12 Back plate
13 Back padding
14 Air filter





15 Anti-vibration elements
16 Container filler cap
17 Container
18 Spark plug boot
19 Carburetor adjusting screws
20 Choke knob
21 Fuel filler cap
22 Starter grip
23 Fuel tank
24 Muffler

Specifications

Single cylinder two-stroke engine

Displacement:	56.5 cm^3
Bore:	46 mm
Stroke:	34 mm
Idle speed:	2.800 rpm
Engine power:	2.5 kw
Weight:	9.5 kg
Ari flow rate:	1060 m^3/h

Spraying attachment

Container capacity:	14 l
Size of filler strainer mesh:	1 mm
Discharge rate	0.14-3.03 l/min (infinitely variable)
Quantity left in container:	0.1 l (design related)

Rewind Starter

Starter rope:
3.5 mm dia.
x 960 mm

1) Weighted equivalent level includes idling and racing with the same duration of exposure


Ignition System

Type:	Electronic magneto ignition
Spark plug (suppressed):	Bosch WSE 6 F or BPMR 7 A;
Electrode gap:	0.5 mm
Spark plug thread:	M 14 x 1.25; 9.5 mm long


Fuel System

Carburetor:	All position diaphragm carburetor with integral fuel pump
Air filter:	Paper element
Fuel tank capacity:	1.5 l
Fuel mix:	see chapter "Fuel"


Assembly Instructions Dusting




Remove retainer(1) from the pleated hose.




Unscrew the union nut (2) and pull out the reducer (3) with hose(4).




Release and rmove screws (5).Take the shut-0ff coke remove (6) off the cotrol handle (7).




Unscrew metering knob (8) of standard nozzle(9).




Push the assembled elbow (10) supplied with the attachment into the fan hosing as far as stop.




Push pleated hose (11) over the stub (A) as far as it will go.




Rotate the pleated hose (11) that the marks in the positions shown in the illustration the pleated hose in this position, make sure the control handle is vertical and tighten it down firmly.




Push the stub (12)into the cotainer.
Fit the union nut (2) and screw it in tightly.




Unsrew the hose clamps (13) on the bellows (14) (hose clamps are used again).




Unscrew the container's cap. Pull the container (15) off the hose (16).




Push the reducer (17) out of the container (from inside) and remove it together with the hose (16).



Join up the twos haft shells (18) and secure them to the container and fan housing with the hose clamps (13).




Fit the air agitator tube (19) in the container.



The funnel (20) must be fitted in the container to achieve extra fine distribution to achieve extra fine distribution for dusting applications. Remove the funnel before filling the container with granulated matenial. Fit the cap on the container.

PART DIAGRAM OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER



PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:

SL NO.	PART NO.	Part Name
1	AM-MBD-5650- SP01	Belt
2	AM-MBD-5650- SP02	SUPPORT
3	AM-MBD-5650- SP03	NST
4	AM-MBD-5650- SP04	WASHER
5	AM-MBD-5650- SP05	WASHER
6	AM-MBD-5650- SP06	PLASTIC CLIP
7	AM-MBD-5650- SP07	SCREWS
8	AM-MBD-5650- SP08	BACK MAT
9	AM-MBD-5650- SP09	FRAME
10	AM-MBD-5650- SP10	PLATE
11	AM-MBD-5650- SP11	SCREW
12	AM-MBD-5650- SP12	ANTI-VIBRATE SPRING
13	AM-MBD-5650- SP13	SPRING SUPPORT
14	AM-MBD-5650- SP14	WASHER
15	AM-MBD-5650- SP15	SCREW
16	AM-MBD-5650- SP16	VOLOTE CASE
17	AM-MBD-5650- SP17	IMPELLER
18	AM-MBD-5650- SP18	VOLUTE CASE
19	AM-MBD-5650- SP19	NUT
20	AM-MBD-5650- SP20	LID
21	AM-MBD-5650- SP21	SEALING WASHER
22	AM-MBD-5650- SP22	PLVG
23	AM-MBD-5650- SP23	CLEANER

PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:

24	AM-MBD-5650- SP24	TANK
25	AM-MBD-5650- SP25	PLASTIC PIPE
26	AM-MBD-5650- SP26	SEALING WASHER
27	AM-MBD-5650- SP27	AIWALVE
28	AM-MBD-5650- SP28	CLIP22-38
29	AM-MBD-5650- SP29	RVBBER PIPE
30	AM-MBD-5650- SP30	CLIP22-38
31	AM-MBD-5650- SP31	PAN JOINT
32	AM-MBD-5650- SP32	STOPPER AXIS
33	AM-MBD-5650- SP33	STOPPER
34	AM-MBD-5650- SP34	CLIP 64-67
35	AM-MBD-5650- SP35	CLIP
36	AM-MBD-5650- SP36	HOSE
37	AM-MBD-5650- SP37	PIPE
38	AM-MBD-5650- SP38	LONG JOINT TVBE
39	AM-MBD-5650- SP39	NOZZLE ASSY
40	AM-MBD-5650- SP40	SWALING WASHER
41	AM-MBD-5650- SP41	PULING
42	AM-MBD-5650- SP42	CONNECTOR LID
43	AM-MBD-5650- SP43	CLIP
44	AM-MBD-5650- SP44	PLASTIC PIR
45	AM-MBD-5650- SP45	SCREW
46	AM-MBD-5650- SP46	COCK ASSEM

PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:


47	AM-MBD-5650- SP47	SUPPORT
48	AM-MBD-5650- SP48	SCREW
49	AM-MBD-5650- SP49	PLASTIC PIPE
50	AM-MBD-5650- SP50	CLIP
51	AM-MBD-5650- SP51	RZGHI CONTOROL CASE
52	AM-MBD-5650- SP52	SCREW
53	AM-MBD-5650- SP53	WASHER
54	AM-MBD-5650- SP54	AXIS SLEEPE
55	AM-MBD-5650- SP55	CONTACI
56	AM-MBD-5650- SP56	SWITCH
57	AM-MBD-5650- SP57	AXIS CLIP
58	AM-MBD-5650- SP58	SADDLEWASHER
59	AM-MBD-5650- SP59	WASHER
60	AM-MBD-5650- SP60	LEFT CONTOROL CASE
61	AM-MBD-5650- SP61	HANDLE一
62	AM-MBD-5650- SP62	HANDLE二
63	AM-MBD-5650- SP63	HADDLE AXIS
64	AM-MBD-5650- SP64	LEVER ASS'Y
65	AM-MBD-5650- SP65	DUST PARTS
66	AM-MBD-5650- SP66	RVBBER PIPE
67	AM-MBD-5650- SP67	PIPE
68	AM-MBD-5650- SP68	ACROSS PIPE
69	AM-MBD-5650- SP69	UPRIGHT PIPE

PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:

70	AM-MBD-5650- SP70	CONNECTOR
71	AM-MBD-5650- SP71	CLIP
72	AM-MBD-5650- SP72	RETURN SPRING
73	AM-MBD-5650- SP73	REGULATOR VALVE
74	AM-MBD-5650- SP74	0-RING
75	AM-MBD-5650- SP75	NOZZLE
76	AM-MBD-5650- SP76	COVER BOARD（一）
77	AM-MBD-5650- SP77	COVER BOARD（二）
78	AM-MBD-5650- SP78	COVER BOARD（三）
79	AM-MBD-5650- SP79	CONNECTOR
80	AM-MBD-5650- SP80	RUBBER PLUG
81	AM-MBD-5650- SP81	PIN

ENGINE PART DIAGRAM OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER



ENGINE PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:

SL. NO.	PART NUMBER	DESCRIPTION
1	AM-MBD-5650-EP01	STARTER
2	AM-MBD-5650-EP02	NUT
3	AM-MBD-5650-EP03	WASHER
4	AM-MBD-5650-EP04	RATCHET
5	AM-MBD-5650-EP05	OIL SEAL
6	AM-MBD-5650-EP06	REAR HALFCQANK CASE
7	AM-MBD-5650-EP07	PIN
8	AM-MBD-5650-EP08	BALL BEARING
9	AM-MBD-5650-EP09	CRANK SHAFT COMP
10	AM-MBD-5650-EP10	KEY
11	AM-MBD-5650-EP11	NEEDLE BEARING
12	AM-MBD-5650-EP12	PISTON PINI
13	AM-MBD-5650-EP13	PISTON PIN CIRCLET
14	AM-MBD-5650-EP14	PISTON
15	AM-MBD-5650-EP15	PISTON RING
16	AM-MBD-5650-EP16	CRANK CASE GASKET
17	AM-MBD-5650-EP17	FRANT HALFCRANK CASE
18	AM-MBD-5650-EP18	WASHER
19	AM-MBD-5650-EP19	WASHER
20	AM-MBD-5650-EP20	SCREW
21	AM-MBD-5650-EP21	MAGNETO STATOR
22	AM-MBD-5650-EP22	OIL SEAL
23	AM-MBD-5650-EP23	NAGNETO STATOR

ENGINE PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:

SL. NO.	PART NUMBER	DESCRIPTION
24	AM-MBD-5650-EP24	FUEL TANK LID
25	AM-MBD-5650-EP25	SCREW
26	AM-MBD-5650-EP26	TVELTANK INNERLID
27	AM-MBD-5650-EP27	CYLINDER WASHER
28	AM-MBD-5650-EP28	CYLINDER
29	AM-MBD-5650-EP29	CABLE COMP
30	AM-MBD-5650-EP30	CASKET
31	AM-MBD-5650-EP31	MVFFLER COMP
32	AM-MBD-5650-EP32	SCREW
33	AM-MBD-5650-EP33	SPARK PLOG BPMR7A
34	AM-MBD-5650-EP34	COVER
35	AM-MBD-5650-EP35	Threaded pipe
36	AM-MBD-5650-EP36	CYLINDER WASHER
37	AM-MBD-5650-EP37	BOARD
38	AM-MBD-5650-EP38	LINE CLIP
39	AM-MBD-5650-EP39	CLEANER
40	AM-MBD-5650-EP40	INLET MANIFOLD
41	AM-MBD-5650-EP41	SCREW
42	AM-MBD-5650-EP42	GASKET
43	AM-MBD-5650-EP43	CARBVRETOR
44	AM-MBD-5650-EP44	LINKER
45	AM-MBD-5650-EP45	OVTLET FOEL PIPE
46	AM-MBD-5650-EP46	SCREW

ENGINE PART LIST OF AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Machine Parts:

SL. NO.	PART NUMBER	DESCRIPTION
47	AM-MBD-5650-EP47	BLOCK
48	AM-MBD-5650-EP48	SCREW
49	AM-MBD-5650-EP49	SCREW
50	AM-MBD-5650-EP50	RUBBER SEAL
51	AM-MBD-5650-EP51	CORE
52	AM-MBD-5650-EP52	BOARD
53	AM-MBD-5650-EP53	COVER
54	AM-MBD-5650-EP54	SCREW
55	AM-MBD-5650-EP55	FULE TANK
56	AM-MBD-5650-EP56	RUBBER LID
57	AM-MBD-5650-EP57	PLASTIC LID

Warranty Card

CUSTOMER COPY

Purchaser's Name & Address

Product Name

AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Product Serial No.

Invoice / DN No.

Date of Delivery

Dealer's Office Seal

Dealer Sign

Customer Sign.

I/We accept the terms and conditions of Warranty as in the Warranty Card.

Warranty Card

DEALER'S COPY

Purchaser's Name & Address

Product Name

AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Product Serial No.

Invoice / DN No.

Date of Delivery

Dealer's Office Seal

Dealer Sign

Customer Sign.

I/We accept the terms and conditions of Warranty as in the Warranty Card.

Warranty Card

COMPANY COPY

Purchaser's Name & Address

Product Name

AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Product Serial No.

Invoice / DN No.

Date of Delivery

Dealer's Office Seal

Dealer Sign

Customer Sign.

I/We accept the terms and conditions of Warranty as in the Warranty Card.

1st Free Service Coupon

ISO 9001-2015
CERTIFIED COMPANY

FREE SERVICE COUPON (30 Days / 30 hrs (Which ever is earlier)

Model
AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Serial Number

PDI Date

Service No.

Purchase bill no. Date

Dealer's Office Seal & Signature

Customer Signature.....

Conditions: Operations listed have been performed to my entire satisfaction without any labour charges. Only consumables were charged.

WARRANTY AND FREE SERVICE COUPON

agriculture | horticulture | sericulture | plantations | forestry | garden | health care

2nd Free Service Coupon

ISO 9001-2015
CERTIFIED COMPANY

FREE SERVICE COUPON (60 Days / 60 hrs (Which ever is earlier)

Model
AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Serial Number

PDI Date

Service No.

Purchase bill no. Date

Dealer's Office Seal & Signature

Customer Signature.....

Conditions: Operations listed have been performed to my entire satisfaction without any labour charges. Only consumables were charged.

WARRANTY AND FREE SERVICE COUPON

agriculture | horticulture | sericulture | plantations | forestry | garden | health care

3rd Free Service Coupon

ISO 9001-2015
CERTIFIED COMPANY

FREE SERVICE COUPON (90 Days /120hrs (Which ever is earlier)

Model
AM-MBD-5650 TURBO MIST BLOWER CUM DUSTER

Serial Number

PDI Date

Service No.

Purchase bill no. Date

Dealer's Office Seal & Signature

Customer Signature.....

Conditions: Operations listed have been performed to my entire satisfaction without any labour charges. Only consumables were charged.

WARRANTY AND FREE SERVICE COUPON

agriculture | horticulture | sericulture | plantations | forestry | garden | health care

Do's & Don'ts

- Always read the instruction manual supplied along with the equipments and understand the correct installation and operating procedures before attempting to use the equipments.

- It is important to use the personal protection equipments such as head helmet with visor, ear defenders, goggles, safety gloves, cut resistant shoes, trousers and jackets while operating potentially dangerous machines.

- Avoid untrained persons using the equipments. Children must not be allowed to handle these equipments.

- Always use genuine spares and accessories in repairs and usage to derive maximum life of the equipments.

- Always keep the equipments in good working condition to minimize loss of output as well as to reduce the pollution and save the environment.

- Do not use the machine within range of persons unless they wear protective clothing.

- Do not operate the machine when fatigued or under the influence of alcohol or drugs.

- For more query kindly contact for our Service Center/Dealer/ franchise





Small and Timely Maintenance - Big Savings

MULTIPLY PROFITS

WITH OUR MULTI CROP, MULTI PURPOSE EQUIPMENTS

AGRIMATE
Maximum Power - Super Economy

RANGE OF PRODUCTS


BATTERY / MANUAL SPRAYER


PORTABLE POWER SPRAYER


KNAPSACK POWER SPRAYER


ROTARY TILLER


CHAFF CUTTER


TEA PRUNER


FOGGER


POWER WEEDER


CHAINSAW


ROTARY TILLER


LAWN MOWER


HIGH PRESSURE WASHER


EARTH AUGER


RIDE ON MOWER

ITALY-GERMANY-USA
Oleo-Mac
our power, your passion

RANGE OF PRODUCTS

KASEI
Advanced Technology

Advanced Technology

RANGE OF PRODUCTS


BRUSH CUTTER - PUSH TYPE


BRUSH CUTTER - BACK PACK


BRUSH CUTTER - MULTI TOOL


POLE PRUNER


BLOWER BACK PACK


LAWN MOWER


BRUSH CUTTER


BACK PACK BC


TILLER


FOGGER


EARTH AUGER

GP
Green Panther®

RANGE OF PRODUCTS

OUR RETAIL FORMATS

AGRIMART MEGA™
FARM EQUIPMENT | GREEN CARE | SERVICES

AGRIMART®
FARM EQUIPMENT | GREEN CARE | SERVICES

AGRIMART ZONE™
FARM EQUIPMENT | GREEN CARE | SERVICES

IMPORTERS & MARKETED BY:

Ratnagiri Impex Pvt. Ltd.
Annapurna House, # 1/1G,
7th Cross New Guddadahalli,
Mysore Road Bangalore - 560 026, India
Ph: 080-26985100/1/2
Email: info@ratnagiriimpex.com

TOLL FREE : 1800-425-3036

www.ratnagiriimpex.com
www.agrimart.in



ratnagiri® impex
BRINGING YOU THE FUTURE... NOW

An ISO 9001:2015 Certified Company

agriculture | horticulture | sericulture | plantations | forestry | garden | health care