

模式切换	按 键		交互功能	按 键
零力矩	L2 + Y	★	└ 握手	SELECT + A
① 阻尼	L2 + B	★	└ 高举挥手	SELECT + Y
② 锁定站立	L2 + D	★	└ 双手打X	SELECT + X
⑤ 躺 -> 站	L2 + X	★	└ 胸前挥手	双击 Y
④ 落座	L2 + ▲	▲	└ 飞吻	双击 X
⑥ 蹲 <-> 站	L2 + A	▲	└ 鼓掌	双击 A
运控切换			└ 右手平举	双击 B
③ 走跑运控	R2 + A	▲	└ 举左手	双击 ▲
└ 低速 / 高速	R2 + ( D / L )	★	└ 举右手	双击 □
⑦ 常规运控	R1 + X (单腰) / Y (三腰)	▲	└ 举双手	双击 □
└ 低速 / 高速	双击 L2 / L1	★	⑧ 越障运控	R2 + B
⑨ 舞蹈运控	R1 + B	▲	└ 踏步 / 站立	双击 START
└ 功夫	R1 + SELECT	★	I. ★ 代表短按一次生效，▲ 代表长按 2 秒生效	
└ 舞蹈 1	R1 + D	★	II. 运控状态下长按 5 秒 ①，设备进入阻尼保护状态	
└ 舞蹈 2	R1 + ▲	★	III. 躺倒开机：开机 - ① - ⑤ - 演示 - ⑥ - 关机	
└ 舞蹈 3	R1 + □	★	IV. 蹲姿开机：开机 - ① - ⑥ - 演示 - ⑥ - 关机	
└ 翻滚起身	R1 + L	★	V. 座椅开机（推荐）：开机 - ① - ② - ③ - 演示 - ④ - 关机	
└ 截拳道	R2 + D	★	Tips : ② - ③ 过程需要人扶直站立	
└ 扭扭舞	R2 + ▲	★	VI. 舞蹈运控下，双击 start 可紧急中断舞蹈	

Mode	Button	Interactional	Button
Zero Moment	L2 + Y	★ L Handshake	SELECT + A
① Damping	L2 + B	★ L Wave Hand	SELECT + Y
② Locked Standing	L2 + □	★ L Reject	SELECT + X
⑤ Lie -> Stand	L2 + X	★ L Face Wave	Double Click Y
④ Seated Mode	L2 + ▷	▲ L Right Kiss	Double Click X
⑥ Squat <-> Stand	L2 + A	▲ L Clap	Double Click A
<b>Motion Control Switching</b>	<b>Button</b>	<b>L Right Raise</b>	<b>Double Click B</b>
③ Running Mode	R2 + A	▲ L Flex Left	Double Click ▷
L Low/High Speed	R2 + ( □ / △ )	★ L Flex Right	Double Click □
Regular Mode	R1 + X ( 1-DoF Waist ) / Y ( 3-DoF Waist )	▲ L Flex Both	Double Click □
L Low/High Speed	Double Click L2 / L1	★ ⑧ Climb Mode	R2 + B
⑨ Dance Mode	R1 + B	▲ L Stepping/Standing	Double Click START
L Kung Fu	R1 + SELECT	★ I. ★ a single short press to activate	
L Dance 1	R1 + □	▲ a long press for 2 seconds to activate	
L Dance 2	R1 + ▷	II. In motion control mode, long-pressing button ① for 5 seconds enter damping protection mode	
L Dance 3	R1 + △	III. Lie down and turn on: Turn On - ① - ⑤ - Demo - ⑥ - Turn off	
L Roll Up	R1 + ▲	IV. Squat position turn on: Turn On - ① - ⑥ - Demo - ⑥ - Turn off	
L Jeet Kune Do	R2 + □	V. Seat power on (recommended): Turn On - ① - ② - ③ - Demo - ④ - Turn off	
L Twist	R2 + ▷	Tips: ② and ③ require manual assistance to help the robot stand upright	
		VI. In Dance Mode, double-click Start to perform an emergency stop	