# TUNER, DEMUX, PLAYER API







#### -Tuner

Tuner\_Init

Tuner\_Lock\_To\_Frequency

Tuner\_Register\_Status\_Callback

Tuner\_Unregister\_Status\_Callback

Tuner\_Get\_Signal\_Quality

Tuner\_Deinit

#### -Demux

Demux\_Set\_Filter

Demux\_Register\_Section\_Filter\_Callback

Demux\_Unregister\_Section\_Filter\_Callback

Demux Free Filter

### -Player

Player\_Init

Player\_Deinit

Player\_Source\_Open

Player\_Source\_Close

Player\_Stream\_Create

Player\_Stream\_Remove

Player Volume Get

Player\_Volume\_Set

## Tuner 1/2



- t\_Error Tuner\_Init();

Povratna vrijednost: NO\_ERROR – Inicijalizacija tunera uspješna ERROR – Inicijalizacija tunera neuspješna

- t\_Error Tuner\_Register\_Status\_Callback(Tuner\_Status\_Callback tunerStatusCallback);

Parametri: tunerStatusCallback – callback funkcija
- typedef int32 t(\*Tuner Status Callback)(t LockStatus status);

Povratna vrijednost: NO\_ERROR – Registrovanje callback-a uspješno ERROR – Registrovanje callback-a neuspješno

- t\_Error Tuner\_Unregister\_Status\_Callback(Tuner\_Status\_Callback tunerStatusCallback);

Parametri: tunerStatusCallback – callback funkcija

Povratna vrijednost: NO\_ERROR – Registrovanje callback-a uspješno ERROR – Registrovanje callback-a neuspješno

### Tuner 2/2



 - t\_Error Tuner\_Lock\_To\_Frequency(uint32\_t tuneFrequency, uint32\_t bandwidth, t Module modul);

Parametri: *tuneFrequency* – Frekvencija u Hz *bandwidth* – širina opsega u MHz *modul* – DVBT ili DVBT2

Povratna vrijednost: NO\_ERROR – Zaključavanje na frekvenciju uspješno ERROR – Zaključavanje na frekvenciju neuspješno

- t\_Error Tuner\_Deinit();

Povratna vrijednost: NO\_ERROR – Deinicijalizacija tunera uspješna ERROR – Deinicijalizacija tunera neuspješna

- t\_Error Tuner\_Get\_Signal\_Quality(uint8\_t \*signalQuality);

Parametri: signalQuality – kvalitet signala

Povratna vrijednost: NO\_ERROR – Dobavljanje kvaliteta signala uspješno ERROR – Dobavljanje kvaliteta signala neuspješno

## Demux 1/2



```
- t_Error Demux_Set_Filter(uint32_t playerHandle,
                             uint32 t PID,
                             uint32 t tableID,
                             uint32 t *filterHandle);
        Parametri: playerHandle – handle inicijalizovanog Player-a
                   PID - PID tabele
                   tableID - ID tabele
                   filterHandle – pokazivač na handle filtera
        Povratna vrijednost: NO_ERROR – Postavljanje filtera uspješno
                            ERROR – Postavljanje filtera neuspješno
- t_Error Demux_Free_Filter(uint32_t playerHandle, uint32_t filterHandle);
        Parametri: playerHandle – handle inicijalizovanog Player-a
                   filterHandle – pokazivač na handle filtera
        Povratna vrijednost: NO ERROR – Oslobađanje filtera uspješno
                            ERROR – Oslobađanje filtera neuspješno
```

## Demux 2/2



# - t\_Error Demux\_Register\_Section\_Filter\_Callback(Demux\_Section\_Filter\_Callback); demuxSectionFilterCallback);

Parametri: demuxSectionFilterCallback – callback funkcija - typedef int32\_t(\*Demux\_Section\_Filter\_Callback)(uint8\_t \*buffer);

Povratna vrijednost: NO\_ERROR – Registrovanje callback-a uspješno ERROR – Registrovanje callback-a neuspješno

# - t\_Error Demux\_Unregister\_Section\_Filter\_Callback(Demux\_Section\_Filter\_Callback demuxSectionFilterCallback);

Parametri: demuxSectionFilterCallback – callback funkcija

Povratna vrijednost: NO\_ERROR – Deregistrovanje callback-a uspješno ERROR – Deregistrovanje callback-a neuspješno

# Player 1/3



#### - t\_Error Player\_Init(uint32\_t \*playerHandle);

Parametri: *playerHandle* – handle player-a

Povratna vrijednost: NO\_ERROR – Inicijalizacija player-a uspješna

ERROR – Inicijalizacija player-a neuspješna

#### - t\_Error Player\_Deinit(uint32\_t playerHandle);

Parametri: playerHandle – handle inicijalizovanog player-a

Povratna vrijednost: NO\_ERROR – Deinicijalizacija player-a uspješna

ERROR – Deinicijalizacija player-a neuspješna

#### - t\_Error Player\_Source\_Open(uint32\_t playerHandle, uint32\_t \*sourceHandle);

Parametri: playerHandle – handle inicijalizovanog player-a

sourceHandle - handle source-a

Povratna vrijednost: NO\_ERROR – Otvaranje source-a uspješno

*ERROR* – Otvaranje source-a neuspješno

# Player 2/3



- t\_Error Player\_Source\_Close(uint32\_t playerHandle, uint32\_t sourceHandle);

Parametri: playerHandle – handle inicijalizovanog player-a

sourceHandle – handle otvorenog source-a

Povratna vrijednost: NO\_ERROR – Zatvaranje source-a uspješno

ERROR – Zatvaranje source-a neuspješno

- t\_Error Player\_Stream\_Create(uint32\_t playerHandle, uint32\_t sourceHandle uint32\_t PID, tStreamType streamType, uint32\_t \*streamHandle);

Parametri: playerHandle – handle inicijalizovanog player-a

sourceHandle – handle otvorenog source-a

PID – PID stream-a

*streamType* – tip stream-a

streamHandle - handle stream-a

Povratna vrijednost: NO\_ERROR – Stvaranje stream-a uspješno

*ERROR* – Stvaranje stream-a neuspješno

# Player 3/3



#### t\_Error Player\_Stream\_Remove(uint32\_t playerHandle, uint32\_t sourceHandle uint32\_t streamHandle);

Parametri: playerHandle – handle inicijalizovanog player-a

sourceHandle - handle otvorenog source-a

streamHandle - handle otvorenog source-a

Povratna vrijednost: NO\_ERROR – Uklanjanje stream-a uspješno

ERROR – Uklanjanje stream-a neuspješno

#### - t\_Error Player\_Volume\_Get(uint32\_t playerHandle, uint32\_t \*volume);

Parametri: playerHandle – handle inicijalizovanog player-a

volume – jačina zvuka

Povratna vrijednost: NO\_ERROR – Dobavljanje jačine zvuka uspješno

ERROR – Dobavljanje jačine zvuka neuspješno

#### - t\_Error Player\_Volume\_Set(uint32\_t playerHandle, uint32\_t volume);

Parametri: playerHandle – handle inicijalizovanog player-a

volume – jačina zvuka

Povratna vrijednost: NO\_ERROR – Postavljanje jačine zvuka uspješno

ERROR – Postavljanje jačine zvuka neuspješno

## Zadatak



- Zaključati se na frekvenciju
- U callback funkciji sačekati da se zaključavanje uspješno završi
- Otvoriti "source" (omogućiti tok podataka između tuner-a i demultipleksera)
- Postaviti filter na demultiplekser za prijem PAT sekcija
- U callback funkciji ispisati sadržaj PAT sekcije

# Thank you for your attention!

Contact us

RT-RK Institute for Computer Based Systems
Narodnog fronta 23a
21000 Novi Sad
Serbia

www.rt-rk.com info@rt-rk.com

