



LCD Monitor User Manual

Programming Monitor | RD Series

Copyright

Copyright © 2026 by BenQ Corporation. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of BenQ Corporation.

Disclaimer

BenQ Corporation makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Further, BenQ Corporation reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation of BenQ Corporation to notify any person of such revision or changes.

BenQ flicker-free technology maintains a stable backlight with a DC dimmer that eliminates the primary cause of monitor flicker, making it easier on the eyes. The performance of flicker-free may be affected by external factors such as poor cable quality, unstable power supply, signal interference, or poor grounding, and not limited to the above mentioned external factors. (Applicable for flicker-free models only.)

Product support

This document aims to provide the most updated and accurate information to customers, and thus all contents may be modified from time to time without prior notice. Please visit the website for the latest version of this document and other product information. Available files vary by model.

1. Make sure your computer is connected to the Internet.
2. Visit the local website from Support.BenQ.com. The website layout and content may vary by region/country.
 - User manual and related document
 - Drivers and applications
 - (EU only) Dismantled information: Available on the user manual download page. This document is provided based on Regulation (EU) 2019/2021 to repair or recycle your product. Always contact the local customer service for servicing within the warranty period. If you wish to repair an out-of-warranty product, you are recommended to go to a qualified service personnel and obtain repair parts from BenQ to ensure compatibility. Do not disassemble the product unless you are aware of the consequences. If you cannot find the dismantled information on your product, contact the local customer service for assistance.

Firmware upgrade

You are recommended to upgrade the product to the latest firmware version (if available) and refer to the most up-to-date user manual to make best use of the product.

To upgrade your monitor, download and install the **Display QuickKit** software from the BenQ website.

- Support.BenQ.com > model name > **Software & Driver** > **Display QuickKit** (available only when your monitor is compatible)
- Support.BenQ.com > **Display QuickKit** (availability may vary by region)

The software utility checks the compatibility of your monitor automatically once launched. Refer to the user manual of the software utility for instructions.

If your monitor is not compatible with **Display QuickKit**, and you wonder if there is an updated firmware version available, please contact BenQ customer service.

Advanced software

Apart from the built-in technologies and features available on this product, you are provided with more software applications to enhance and extend the product functionality. Download the software and its user guide as instructed from the BenQ website.

• Display Pilot 2

Display Pilot 2 is a software utility that allows for quick accurate tuning of the display with the ability to easily save and use monitor configurations that are best suited for you. All adjustments are controlled via software to eliminate the need to use the monitor on-screen displays (OSD).

Q&A index

Start with the topics that you are interested in.

Setup

How to set up the monitor and turn it on?

Safety precautions	6
How to assemble your monitor hardware (for models with stand)	21
Adjusting the monitor angle	27

How to adjust the monitor viewing angle?

Viewing angle adjustment	28
--------------------------	----

How to wall mount the monitor?

Using the monitor wall mounting kit (purchased separately)	29
--	----

Useful tools to enhance efficiency

How can I efficiently manage the display settings?

Display Pilot 2	3
-----------------	---

How to boost coding productivity using Coding HotKey and Function Key?

Customizing the Function Key	32
Working with Quick Menu	33

Functions to reduce eye strain

How to minimize my screen brightness under extremely dark environment?

Working with Night Hours Protection	34
-------------------------------------	----

How to set the appropriate screen brightness?

Adjusting screen brightness and color temperature automatically (Visual Optimizer)	34
--	----

How to reduce the blue light emitted from the display?

Working with Low Blue Light	34
-----------------------------	----

Menus and accessories

Can I set hot keys to frequently used functions or menus?

Customizing the Function Key	32
Working with Quick Menu	34

How to use the OSD menu?

5-way controller and basic menu operations	31
Navigating the main menu	39

Maintenance and product support

How to clean the monitor?


Care and cleaning	8
Cleaning the LCD screen	11
How to keep the monitor not in use for a long time?	
How to detach the stand (for models with stand)	26
Care and cleaning	8
I need more support.	
Product support	3
Servicing	9

Safety precautions

Power safety



Please follow these safety instructions for best performance, and long life for your monitor.



- The AC plug isolates this equipment from the AC supply.
- The power supply cord serves as a power disconnect device for pluggable equipment. The socket outlet should be installed near the equipment and be easily accessible.
- This product should be operated from the type of power indicated on the marked label. If you are not sure of the type of power available, consult your dealer or local power company.
- The Class I pluggable equipment Type A must be connected to protective earth.
- An approved power cord greater or equal to H03VV-F or H05VV-F, 2G or 3G, 0.75mm² must be used.
- Use only the power cord provided by BenQ. Never use a power cord that appears to be damaged or frayed.
- To avoid possible damage to the monitor, do not use it in a region where power supply is unstable.
- Ensure that the power cord is connected to a grounded power outlet before turning on the monitor.
- To avoid possible danger, observe the total electric load when using the monitor with a (multi-outlet) extension cord.
- Always turn off the monitor before unplugging the power cord.

For Germany only:

- (If the weight of the product is less than or equal to 3 kg) An approved power cord greater or equal to H03VV-F, 3G, 0.75mm² must be used.
- (If the weight of the product is more than 3 kg) An approved power cord greater or equal to H05VV-F or H05RR-F, 3G, 0.75mm² must be used.
- (If a remote control is provided) RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

For models with adapter:

- Use only the power adapter supplied with your LCD Monitor. Use of another type of power adapter will result in malfunction and/or danger.
- Allow adequate ventilation around the adapter when using it to operate the device or charge the battery. Do not cover the power adapter with paper or other objects that will reduce cooling. Do not use the power adapter while it is inside a carrying case.
- Connect the power adapter to a proper power source.
- Do not attempt to service the power adapter. There are no service parts inside. Replace the unit if it is damaged or exposed to excess moisture.

Installation

- Do not use your monitor under any of the following environmental conditions:
 - Extremely high or low temperature, or in direct sunlight
 - Dusty places
 - Highly humid, exposed to rain, or close to water
 - Exposed to vibrations or impacts in places such as cars, buses, trains, and other rail vehicles
 - Near heating appliances such as radiators, heaters, fuel stoves, and other heat-generating items (including audio amplifiers)
 - An enclosed place (such as a closet or bookcase) without appropriate ventilation
 - An uneven or sloping surface
 - Exposed to chemical substances or smoke
- Carry the monitor carefully.
- Do not place heavy loads on the monitor to avoid possible personal injury or damage to the monitor.
- Ensure that children do not hang or climb onto the monitor.
- Keep all packing bags out of reach of children.

Operation

- To protect your eyesight, please refer to the user manual to set the optimal screen resolution and the viewing distance.
- To reduce eye fatigue, take a break on a regular basis while using the monitor.
- Avoid taking either one of the following actions for a long time. Otherwise, burn marks may occur.
 - Play images that cannot occupy the screen entirely.
 - Place a still image on the screen.
- To avoid possible damage to the monitor, do not touch the monitor panel by finger tip, pen, or any other sharp objects.
- Excessively frequent plug and unplug of video connectors may cause damage to the monitor.
- This monitor is designed mainly for personal use. If you want to use the monitor in a public place or a harsh environment, contact your nearest BenQ service center for assistance.
- To avoid possible electric shock, do not disassemble or repair the monitor.
- If a bad smell or an abnormal sound appears to come from the monitor, contact your nearest BenQ service center for assistance immediately.

Caution

- The distance between you and the monitor should be 2.5 to 3 times the diagonal width of the screen.
- Looking at the screen for an extended period of time causes eye fatigue and may deteriorate your eyesight. Rest your eyes for 5 ~ 10 minutes for every 1 hour of product use.
- Reduce your eye strain by focusing on objects far away.
- Frequent blinking and eye exercise help keep your eyes from drying out.

Safety notice for remote control (applicable if a remote control is provided)

- Do not put the remote control in the direct heat, humidity, and avoid fire.
- Do not drop the remote control.
- Do not expose the remote control to water or moisture. Failure to do so could result in malfunction.
- Confirm there is no object between the remote control and the remote sensor of the product.
- When the remote control will not be used for an extended period, remove the batteries.

Battery safety notice (applicable if a remote control is provided)

The use of the wrong type of batteries may cause chemical leaks or explosion. Please note the following:

- Always ensure that the batteries are inserted with the positive and negative terminals in the correct direction as shown in the battery compartment.
- Different types of batteries have different characteristics. Do not mix different types.
- Do not mix old and new batteries. Mixing old and new batteries will shorten battery life or cause chemical leaks from the old batteries.
- When batteries fail to function, replace them immediately.
- Chemicals which leak from batteries may cause skin irritation. If any chemical matter seeps out of the batteries, wipe it up immediately using a dry cloth, and replace the batteries as soon as possible.
- Due to varying storage conditions, the battery life for the batteries included with your product may be shortened. Replace them within 3 months or as soon as you can after initial use.
- There may be local restrictions on the disposal or recycling of batteries. Consult your local regulations or waste disposal provider.

If the supplied remote control contains a coin / button cell battery, pay attention to the following notice as well.


- Do not ingest battery. Chemical Burn Hazard.
- The remote control supplied with this product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Care and cleaning

- Do not place the monitor face down on the floor or a desk surface directly. Otherwise, scratches on the panel surface may occur.
- The equipment is to be secured to the building structure before operation.
- (For models that support wall or ceiling mounting)
 - Install your monitor and monitor mounting kit on a wall with flat surface.

- Ensure that the wall material and the standard wall mount bracket (purchased separately) are stable enough to support the weight of the monitor.
- Turn off the monitor and the power before disconnecting the cables from the LCD monitor.
- Always unplug the product from the power outlet before cleaning. To clean the monitor, see [Cleaning the LCD screen on page 11](#) for more information.
- Slots and openings on the back or top of the cabinet are for ventilation. They must not be blocked or covered. Your monitor should never be placed near or over a radiator or heat sources, or in a built-in installation unless proper ventilation is provided.
- Do not place heavy loads on the monitor to avoid possible personal injury or damage to the monitor.
- Consider keeping the box and packaging in storage for use in the future when you may need to transport the monitor.
- Refer to the product label for information on model name, power rating, manufacturing date, barcode, serial number, and identification markings. The locations of labels vary by model. See the illustration below for where the labels can be.

Possible label location:



Servicing

- Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltages or other risks. If any of the above mentioned misuse or other accident such as dropping or mishandling occurs, contact qualified service personnel for servicing.
- For replacement of power cord, connection cables, remote control or power adapter, please contact BenQ customer service.
- Contact your place of purchase or visit the local website from Support.BenQ.com for more support.



General warranty information

Note that the monitor warranty may be void if any of the following conditions occurs:

- Documents required for warranty services have been altered by unauthorized use or is illegible.
- The model number or production number on the product has been altered, deleted, removed or made illegible.
- Repairs, modifications, or alterations have been made by unauthorized service organizations or persons.
- Damage caused by improper storage of the monitor (including but not limited to force majeure, direct exposure to sunlight, water, or fire).

- Reception problems occurred due to external signals (such as antenna, Cable TV) outside the monitor.
- Defects caused by abuse or misuse of the monitor.
- Before using the monitor, it is the sole responsibility of the user to check whether the monitor is compatible with local technical standards if the user brings the monitor out of its intended sales area. Failure to do so may cause product breakdown and the user will have to pay the repairing costs.
- It is the sole responsibility of the user if problems (such as data loss and system failure) occurred due to non-factory provided software, parts, and/or non-original accessories.
- Please use the original accessories (e.g. power cable) only with the device to avoid possible dangers such as electric shock and fire.

Typographics

Icon / Symbol	Item	Meaning
	Warning	Information mainly to prevent the damage to components, data, or personal injury caused by misuse and improper operation or behavior.
	Tip	Useful information for completing a task.
	Note	Supplementary information.

In this document, the steps needed to reach a menu may be shown in condensed form, for example: **Menu > System > Information.**

Cleaning the LCD screen



Please follow these safety instructions for best performance, and long life for your monitor.

As your monitor panel comes with a special coating, use and clean the monitor carefully.


- Stains on the monitor screen could be obvious. Be cautious when you use or clean the monitor and avoid getting oil or dust on the screen.
- Fingerprints and dust under normal use could be wiped away by a microfiber cleaning cloth.
- Clean the screen surface gently and carefully. Hard scrubbing could damage the screen coating.

Be sure to follow the instructions to clean the screen surface appropriately.

Using a microfiber cleaning cloth* (recommended)

You are recommended to use a microfiber cleaning cloth to clean your monitor screen. It is an eco-friendly design as it is reusable, washable, and liquid-free.

1. Unplug the monitor from the power outlet before cleaning.
2. Make sure there is no sharp debris on the cleaning cloth to avoid scratching the screen.
3. Hold the edge of the monitor and avoid excessive force on the screen.
4. Make sure the cleaning cloth is clean and dry. Start with a small, clean part of the cloth and wipe the stained area of the screen gently in circles. If it is still not clean, continue with another clean part of the cloth to avoid spreading the grease around. If both sides of the cloth are used and get dirty, wash and dry the cloth properly.




• *:The availability of the cleaning cloth varies by model. See [Getting started on page 15](#) for your package contents.

• To prevent the seams around the cleaning cloth from marring the screen surface, avoid wiping the screen with the edge of the cleaning cloth.

5. If necessary, apply a small drop of alcohol-free screen cleaner on a small, clean part of the cleaning cloth, and wipe the stained area gently in circles. See [Using a screen cleaner on page 12](#) for more information.

6. Use a clean part of the cloth to wipe dry the screen completely. If it is still not clean, continue with another clean part of the cloth to avoid spreading the grease around. Repeat this step until the screen is clean.



7. The cleaning cloth may get dirty after using several times and may not be able to clean the screen properly. Wash it with detergent and remove debris from it by hand if necessary. Keep it in a cool place until it is dry. Make sure it is completely dry before next cleaning.

Using a screen cleaner

- Use screen cleaning wipes which are pre-moistened and alcohol-free. You can wipe away oil and fingerprints easily.
- Use an alcohol-free screen cleaner kit. Spray on the microfiber cloth that came with the screen cleaner kit, and wipe stains off the screen. Never spray anything directly onto the screen.
- Make sure no liquid goes into the gap between the screen and the bezel. Liquids inside the monitor could cause short circuits.











Table of Contents

Copyright	2
Product support	3
Firmware upgrade	3
Advanced software	3
Q&A index	4
Safety precautions	6
Power safety	6
Installation	7
Operation	7
Caution	7
Safety notice for remote control (applicable if a remote control is provided)	8
Battery safety notice (applicable if a remote control is provided)	8
Care and cleaning	8
Servicing	9
General warranty information	9
Cleaning the LCD screen	11
Using a microfiber cleaning cloth* (recommended)	11
Using a screen cleaner	12
Getting started	15
Getting to know your monitor	17
Front view	17
Back view	18
Connections	19
Power delivery of USB-C™ port on your monitor	20
How to assemble your monitor hardware (for models with stand)	21
How to detach the stand (for models with stand)	26
Adjusting the monitor angle	27
Adjusting the monitor height	27
Rotating the monitor	27
Viewing angle adjustment	28
Using the monitor wall mounting kit (purchased separately)	29
How to adjust your monitor	30
The function bar	30
5-way controller and basic menu operations	31
Customizing the Function Key	32
Working with Quick Menu	33
Working with Night Hours Protection	34
Working with Low Blue Light	34

Adjusting screen brightness and color temperature automatically (Visual Optimizer)	34
Enabling color vision accessibility (Color Weakness)	35
Adjusting display mode.....	35
Choosing an appropriate color mode	35
Available menu options to each Color Mode	36
Charging the connected device via USB-C™ port	38
Navigating the main menu	39
Input menu	40
Eye Care menu	41
Color Mode menu	43
Audio menu	46
Custom menu	47
System menu	49
Troubleshooting	54
Frequently asked questions (FAQ)	54
Need more help?.....	57

Getting started

When unpacking please check you have the following items. If any are missing or damaged, please contact the place of purchase for a replacement.

BenQ LCD Monitor	
Monitor Stand (For models with stand)	
Monitor Base (For models with stand)	
User Documents • Quick Start Guide • Safety Instructions • Regulatory Statements	
Power Cord (Supplied item may differ by model or region.)	
Video Cable: HDMI	
USB Cable: USB-C™	
Screen Cleaning Cloth (Supplied item may differ by model or region.)	




- Available accessories and the pictures shown here may differ from the actual contents and the product supplied for your region. And the package contents may subject to change without prior notice. For cables that are not supplied with your product, you can purchase them separately.
- Consider keeping the box and packaging in storage for use in the future when you may need to transport the monitor. The fitted foam packing is ideal for protecting the monitor during transport.
- Accessories and cables may be included or sold separately depending on the product supplied for your region.



Always keep the product and accessories out of reach of small children.


Getting to know your monitor

Front view



1. Light sensor
2. Power button and power LED indicator
3. 5-way controller
4. Function key
5. Coding hotkey
6. USB-A ports (downstream; connecting to USB devices)
7. USB-C port (downstream; connecting to USB devices)
8. Headphone jack

Back view



1. Speakers
2. HDMI socket
3. DisplayPort socket
4. USB-C™ port (for video, data transfer and power delivery up to 65W)
5. Kensington lock slot
6. AC power input jack
7. VESA cover




- Depending on the product specifications, the supported resolution and timing may vary.
- Above diagram may vary depending on the model.
- Picture may differ from product supplied for your region.
- (Applicable for products with white case) The case of the product may turn yellow in about 3 years due to the photo-oxidation reactions induced by light. This is a normal phenomenon and should not be considered as manufacturing defect.
- For more information on USB-C™ port power delivery, see [Power delivery of USB-C™ port on your monitor on page 20](#).

Connections

The following connection illustrations are for your reference only. For cables that are not supplied with your product, you can purchase them separately.

For detailed connection methods, see page [23](#) - [24](#).



Due to USB-C™ technology limitation, the USB transmission speed is determined only by the selected refresh rate. See for [USB-C Configuration on page 51](#) more information.

Power delivery of USB-C™ port on your monitor

With the power delivery function, your monitor helps supply power to the connected USB-C™ devices. -

USB-C™ 65W ()	USB-C™ Downstream 7.5W ()
5V / 3A	5V / 1.5A
9V / 3A	N/A
12V / 3A	N/A
15V / 3A	N/A
20V / 3.25A	N/A

- A connected device needs to be equipped with a USB-C™ connector that supports charging function via USB power delivery.
- The connected device can be charged via USB-C™ port even when the monitor is in power saving mode. (*)
- The USB power delivery is up to 65W. If the connected device requires more than 65W for operation or for boot up (when the battery is drained), use the original power adapter that came with the device.
- The information is based on the standard testing criteria and is provided for reference. The compatibility is not guaranteed as the user environments vary. If a separately purchased USB-C™ cable is used, make sure the cable is certified by USB-IF and is full-featured, with power delivery and video / audio / data transfer functions.



*: Charging via USB-C™ in monitor power saving mode is available when both **USB-C Awake** and **Power-on Charging** function are enabled. Go to **System > Standby Charging/Power-on Charging** and select **ON**.

How to assemble your monitor hardware (for models with stand)




- If the computer is turned on you must turn it off before continuing. Do not plug-in or turn-on the power to the monitor until instructed to do so.
- The following illustrations are for your reference only. The location and available input and output jacks may vary depending on the purchased model.



Avoid finger pressure on the screen surface.



Never stand your monitor on a desk or floor without its stand arm and base. The controls on the bottom of the front bezel are not designed to hold the weight of the monitor and may be damaged.




1. Attach the monitor base.




Please be careful to prevent damage to the monitor. Placing the screen surface on an object like a stapler or a mouse will crack the glass or damage the LCD substrate voiding your warranty. Sliding or scraping the monitor around on your desk will scratch or damage the monitor surround and controls.

Protect the monitor and screen by clearing a flat open area on your desk and placing a soft item like the monitor packaging bag on the desk for padding.


Gently lay the screen face up on a flat clean padded surface.




Attach the monitor stand to the monitor base as illustrated.



Tighten the thumbscrew on the bottom of the monitor base as illustrated.




Orient and align the stand arm with the monitor (1), push them together until they click and lock into place (2).



Take the monitor out of the box by holding the stand arm. Carefully lift the monitor, turn it over and place it upright on its stand on a flat even surface.

As the product is heavy, you may need assistance from another person to balance and ensure safety.




You might want to adjust the monitor stand height. See [Adjusting the monitor height on page 27](#) for more information.



Your monitor is an edge-to-edge monitor and should be handled with care. Avoid finger pressure on the screen surface and the function bar area. Adjust the screen angle by placing your hands on the top and on the bottom of the monitor as illustrated.



You should position the monitor and angle the screen to minimize unwanted reflections from other light sources.



2. Connect the PC video cable




The video cables included in your package and the socket illustrations on the right may vary depending on the product supplied for your region.



Use a latchless DP cable for easy connections.


1. Establish a video cable connection. Connect the monitor to your video source(s) via HDMI/DP/USB-C™ cable as illustrated.



2. Connect the other end of the video cable to an appropriate port of a digital output source (e.g. a computer).

3. Connect the headphone.

You may connect the headphones to the headphone jack found below the lower-right of the front bezel.



4. Connect the USB devices.


When the video input is HDMI/DP

1. Connect the input source via HDMI or DP.
2. Connect the USB cable between the PC and the monitor (via the USB-C™ data upstream port at the back). This upstream port transmits data between the PC and the USB devices connected to the monitor.
3. Connect USB devices via other USB ports (downstream) on the monitor. These downstream USB ports transmit data between connected USB devices and the upstream port.


When the video input is USB-C™

1. Connect the video source via USB-C™ video port (≡ ≡).
2. Connect USB devices via other USB ports (downstream) on the monitor. These downstream USB ports transmit data between connected USB devices and the upstream port.

Video input via HDMI/DP



Video input via USB-C™




5. Connect the power cable.

1. Plug one end of the power cord into the socket labelled  on the rear of the monitor.
2. Plug the other end of the power cord into a power outlet.



Picture may differ from product supplied for your region.




6. Turn on the power.

Turn on the monitor by pressing the power button on the monitor.

Turn on the computer too.



To extend the service life of the product, we recommend that you use your computer's power management function.



How to detach the stand (for models with stand)


1. Prepare the monitor and area.

Turn off the monitor and the power before unplugging the power cable. Turn off the computer before unplugging the monitor signal cable.

Protect the monitor and screen by clearing a flat open area on your desk and placing a soft item like a towel on the desk for padding, before laying the screen face down on a flat clean padded surface.




Please be careful to prevent damage to the monitor. Placing the screen surface on an object like a stapler or a mouse will crack the glass or damage the LCD substrate voiding your warranty. Sliding or scraping the monitor around on your desk will scratch or damage the monitor surround and controls.




2. Remove the monitor stand.

Push the quick release button (1) to release the monitor. Then, detach the stand from the monitor (2 and 3).




3. Remove the monitor base.

Release the thumbscrew on the bottom of the monitor base.




And then detach the base from the stand.




Adjusting the monitor angle

Adjusting the monitor height

To adjust the monitor height, hold both the left and the right sides of the monitor to lower the monitor or lift it up to the desired height.



- Avoid placing hands on the upper or lower part of the height-adjustable stand or at the bottom of the monitor, as ascending or descending monitor might cause personal injuries. Keep children out of reach of the monitor while performing this operation.



- If the monitor has been rotated to portrait mode and height adjustment is desired, you should be noted that the wide screen will keep the monitor from being lowered to its minimum height.

Rotating the monitor

1. Pivot the OSD Menu.

Go to **System** > **OSD Settings** > **Pivot** to choose your desired orientation, **90°** or **270°**.

2. Pivot the display.

Before rotating the monitor with a portrait viewing orientation, the display has to be rotated 90 degrees.

Right-click the desktop and select **Screen resolution** from the popup menu. Select **Portrait** in **Orientation**, and apply the setting.




Depending on the operating system on your PC, different procedures should be followed to adjust the screen orientation. Refer to the help document of your operating system for details.

3. Fully extend the monitor and tilt it.

Gently lift the display up and extend it to the maximum extended position. Then tilt the monitor.



The monitor should be vertically extended to allow to rotate from landscape to portrait mode.




4. Rotate the monitor 90 degrees

Applicable angle of rotation:

90 degrees clockwise or counterclockwise




- To avoid the edge of the LCD display hitting the monitor base surface while it is being rotated, do tilt and extend the monitor to the highest position before you start to rotate the display. You should also make sure there are no obstacles around the monitor and there is enough room for cables. Remove the items placed on the monitor base, the connected USB peripherals and cables first.



5. Adjust the monitor to the desired viewing angle.

Viewing angle adjustment

You may position the screen to the desired angle with monitor tilt, swivel, and height adjustment functions. Check the product specifications on the website for details.



Using the monitor wall mounting kit (purchased separately)


The back of your LCD monitor has a VESA standard mount with 100mm pattern, allowing the installation of a wall mount bracket. Before starting to install a monitor wall mounting kit, please read the precautions carefully.

Precautions

- Install your monitor and monitor mounting kit on a wall with flat surface.
- Ensure that the wall material and the standard wall mount bracket (purchased separately) are stable enough to support the weight of the monitor. Refer to the product specifications on the website for weight information.
- Turn off the monitor and the power before disconnecting the cables from the LCD monitor.


1. Remove the monitor stand.

Lay the screen face down on a clean and well-padded surface. Detach the monitor stand as instructed in [How to detach the stand \(for models with stand\) on page 26](#).



2. Remove the screws on the back cover.

Use a cross-pointed screwdriver to release the screws on the back cover. The use of a magnetic-head screwdriver is recommended to avoid losing the screws.



In case you intend to use your monitor on the stand in the future, please keep the monitor base, monitor stand, and screws somewhere safe for future use.


3. Follow the instruction manuals of the wall mount bracket you purchased to complete the installation.



Use four M4 x 10 mm screws to fix a VESA standard wall mount bracket to the monitor. Make sure that all screws are tightened and secured properly. Consult a professional technician or BenQ service for wall mount installation and safety precautions.

How to adjust your monitor


The function bar



No.	Name	Description
1.	Power key & Power key LED	- Turns the power on or off. • Power key LED lights up if the power is turned on. • Go to System > Function Bar > Power Key LED to adjust the LED behavior.
2.	5-way controller	Accesses the functions or menu items as instructed by the on-screen icons. See 5-way controller and basic menu operations on page 31 for more information.
3.	Function key	• By default, the key is the hot key for Input. • Go to Custom > Function Key to access the Function Key setting menu. See Customizing the Function Key on page 32 for more information.
4.	Coding HotKey	• Toggles among different color modes for coding. • Go to Custom > Coding Hotkey to access the Coding Hotkey setting menu. See Working with Quick Menu on page 33 for more information.


5-way controller and basic menu operations

The 5-way controller is located below the lower part of the front bezel. While sitting in front of the monitor, move the controller to the directions instructed by the on-screen icons for menu navigation and operations.



OSD icon	5-way controller operation	Function
(When no menu has been activated)		
N/A	Press the 5-way controller	Activates the main menu.
(When a menu has been activated)		
	Press	Confirms the selection.
	Move to the right	• Enters sub menus. • Confirms the selection.
	Move up	• Goes to the previous menu item. • For up / increase adjustment.
	Move down	• Goes to the next menu item. • For down / decrease adjustment.
	Move to the left	• Returns to the previous menu. • Exits OSD menu.


All OSD (On Screen Display) menus can be accessed by the control keys. You can use the OSD menu to adjust all the settings on your monitor. Available menu options may vary depending on the input sources, functions and settings.



1. Press  to bring up the main menu.
2. On the main menu, follow the on-screen icons on the bottom of the menu to make adjustments or selection. See [Navigating the main menu on page 39](#) for details on the menu options.

Customizing the Function Key

1. Go to **Menu > Custom > Function Key** to access the Function Key setting menu.
2. In the sub menu, select a function that can be accessed by this key. A pop-up message will appear, showing that the setup is complete.




Working with Quick Menu

The **Quick Menu** is a quick access to different color modes for coding and to change monitor settings frequently adjusted.

1. Bring up Quick Menu.

Press  (Coding HotKey).




2. Cycle through different coding modes.

Use either option below:


a. Press  (Coding HotKey) again.

b. Press  / .

a.



b.



Coding mode options:

- **Coding - Dark Theme**
- **Coding - Light Theme**
- **Coding - Paper Color**
- Last selected color mode


3. Adjust color mode settings

• Press  /  to access different setting options.

• Press  /  to make adjustments.



If the **Night Hours Protection** settings is grayed out, see [Night Hours Protection is grayed out in Quick menu. on page 57](#) for more information.



Customizing Coding Hotkey options

1. Press  to bring up the main menu.

2. Go to **Custom > Coding Hotkey**.

3. In the sub menu, choose 3 color mode options to be accessed by the **Quick Menu**.



Default color mode options on Quick Menu:

- **Coding - Dark Theme**
- **Coding - Light Theme**
- **Coding - Paper Color**
- Last selected color mode

See [Coding Hotkey on page 47](#) for all the available options.

Customizing **Quick Menu** options

1. Press  to bring up the main menu.
2. Go to **Custom > Quick Menu**.
3. In the sub menu, choose 2 to 4 options to be accessed by the Quick Menu. See [Quick Menu on page 48](#) for all the available options.

Working with **Night Hours Protection**

The **Night Hours Protection** aims to safeguard your eyes by offering a minimum brightness technology. Its intelligent ambient light detection and auto-switch capabilities ensure effortless and consistent eye care.

1. Press  to bring up the main menu.
2. Go to **Eye Care > Night Hours Protection**.
3. Under **Switch**, choose either **ON** or **Auto Switch**. For **Auto Switch**, the monitor automatically enables or disables the function depending on your ambient light.
4. Under **Level**, adjust the value of the filter. A stronger effect is produced as the value increases.

Working with **Low Blue Light**



The function works with certain picture modes (color modes) only. If it is not available, its menu options will become grayed out.

The Low Blue Light technology helps decrease the blue light emitted from the display to reduce the risk of blue light exposure to your eyes.

You can reduce the blue light as desired regardless of color mode.

1. Press  to bring up the main menu.
2. Go to **Eye Care > Low Blue Light**.
3. Adjust the value of the **Low Blue Light** feature from 0 to 5. A stronger effect is produced as the value increases.

Adjusting screen brightness and color temperature automatically (**Visual Optimizer**)



The function works with certain picture modes (color modes) only. If it is not available, its menu options will become grayed out.

The built-in light sensor, works with Visual Optimizer (V.O.) technology, automatically adjust screen settings based on ambient light. User can choose to adjust only brightness or both brightness and color temperature. This ensure optimal image clarity and comfort, reducing eye strain during use.

1. Press  to bring up the main menu.
2. Go to **Eye Care > Visual Optimizer (V.O.)**.
3. Under **Switch**, choose **ON**. The monitor automatically adjust both brightness and color temperature (**Bri.+ Color Temp.**) based on the ambient light. To auto-adjust only brightness, go to **Mode** under **Visual Optimizer (V.O.)** and switch to **Brightness**.

4. To display the light condition around the monitor on the screen, go to **Light Meter** and choose **ON**.



The performance of Visual Optimizer (V.O.) may be impacted by the light sources and the monitor tilt angle. If you prefer to manually adjust the brightness again as desired, go to **Menu > Eye Care > Visual Optimizer (V.O.)**. See [Visual Optimizer \(V.O.\) on page 42](#) for more information.

Enabling color vision accessibility (**Color Weakness**)



The function works with certain picture modes (color modes) only. If it is not available, its menu options will become grayed out.

Color Weakness is accessibility that helps people with color vision deficiency to distinguish colors. You are provided with **Red Filter** and **Green Filter** on this monitor. Choose one as needed.

1. Press  to bring up the main menu.
 2. Go to **Eye Care > Color Weakness**.
 3. Choose either **Red Filter** or **Green Filter**.
- Adjust the value of the filter. A stronger effect is produced as the value increases.

Adjusting display mode

To display images of aspect ratios and sizes other than the native aspect ratio and display size, you can adjust the display mode on the monitor.

1. Press  to bring up the main menu.
2. Go to **System > Display Mode**.
3. Select an appropriate display mode. The setting will take effect immediately.

Choosing an appropriate color mode

Your monitor provides various color modes that are suitable for different types of images. See [Color Mode menu on page 43](#) for all the available color modes.

Go to **Color Mode** for a desired color mode.

Available menu options to each **Color Mode**

Depending on the **Color Mode** you just set, the available options for each color adjustment may vary. The list is for reference only as available options also vary by input. Menu options that are not available will become grayed out.

Color Mode	Coding - Dark Theme	Coding - Light Theme	Coding - Paper Color	M-book	Cinema	Game	HDR	ePaper	sRGB	User
Options										
Brightness Visual Optimizer (V.O.)	V	V	V	V	V	V	X	V	X	V
Bri.+ Color Temp. Visual Optimizer (V.O.)	V	V	V	V	V	V	X	V	X	V
Brightness Brightness (V.O. On)	V	V	V	V	V	V	V	V	V	V
Contrast	V	V	V	V	V	V	V	V	V	V
Local Contrast	V	V	V	V	V	V	X	V	X	V
Sharpness	V	V	V	V	V	V	V	V	V	V
Saturation	V	V	V	X	X	X	X	X	X	V
Gamma	X	X	X	X	X	X	X	X	X	V
Color Temp. Normal Bluish Reddish	V	V	V	V	X	X	X	X	X	V
Color Temp. User Define R/G/B	V	V	V	V	X	X	X	X	X	V
Color Weakness	V	V	V	X	V	V	X	X	X	V
Low Blue Light	V	V	V	V	V	V	X	V	X	V
Night Hours Protection	V	V	V	V	V	V	V	V	V	V



- V: Available.
- X: Not available.

Adjustable OSD settings

While some settings (e.g. OSD language) are changed and take effect immediately regardless of other monitor settings or input, most OSD settings can be adjusted and saved to go with color modes. As a color mode is selected, the desired settings are applied.

Item	Description
Brightness / Brightness (V.O. On)	Saved and applied by color mode switch.
Contrast	
Local Contrast	
Sharpness	
Saturation	
Gamma	
Color Temperature	
Night Hours Protection	
Low Blue Light	
Visual Optimizer (V.O.)	
Color Weakness	

Charging the connected device via USB-C™ port

The USB-C™ port on the rear of your monitor supports power delivery in standby mode yet it is disabled by default. If video source via USB-C™ port is detected, you will be prompted to enable USB-C™ power delivery function in monitor standby mode. Select **YES** to proceed.

If **USB-C Awake** from **System** has been turned to **ON**, the power delivery will start without further notification.

The maximum power delivery of each USB-C™ port varies. To charge a device properly, check its charging specification first and make sure an appropriate USB-C™ port is connected.

Icon	Power delivery
	65W
	7.5W

Working with a Mac series product

You can connect your monitor to a Mac series product. Note the compatibility is up to the performance and specifications of the Mac chip on your Mac product and may be updated without prior notice.

- When connecting your monitor to a Mac product, direct connection via Thunderbolt 3 or USB-C™ cable (if available on both Mac and the monitor) is recommended to ensure good image quality. See [Connect the PC video cable on page 23](#) for details.
- To reduce the color difference, you are recommended to set the picture mode (color mode) of your monitor to **M-book**, **Display P3**, or **DCI-P3** mode (if available). See [Color Mode menu on page 43](#) for details.
- If your monitor supports certain BenQ software, check the software webpage from www.BenQ.com to see if they work on your Mac product.
- If you have any inquiries about the compatibilities with Mac products, visit Support.BenQ.com and look for related topics from **FAQ** or **Knowledge**.

Navigating the main menu

You can use the OSD (On Screen Display) menu to adjust all the settings on your monitor.

Press  to bring up the main menu. See [5-way controller and basic menu operations on page 31](#) for details.

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.




The OSD menu languages may differ from the product supplied to your region, see [Language on page 50](#) under **System** and **OSD Settings** for more details.

For more information on each menu, please refer to the following pages:

- [Input menu on page 40](#)
- [Eye Care menu on page 41](#)
- [Color Mode menu on page 43](#)
- [Audio menu on page 46](#)
- [Custom menu on page 47](#)
- [System menu on page 49](#)

Input menu

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.




1. Press  to bring up the main menu.
2. Use  or  to select **Input**.
3. Select  to go to a sub menu, and then use  or  to select a menu item.
4. Use  or  to make adjustment, or use  to make selection.
5. To return to the previous menu, select .
6. To exit the menu, select .

Item	Function	Range
Input	Use this to change the input to that appropriate to your video cable connection type.	• USB-C • HDMI • DP

Eye Care menu

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.




1. Press to bring up the main menu.
2. Use or to select **Eye Care**.
3. Select to go to a sub menu, and then use or to select a menu item.
4. Use or to make adjustment, or use to make selection.
5. To return to the previous menu, select .
6. To exit the menu, select .

Item	Function		Range
Night Hours Protection	Minimize screen brightness to protect your eyes under extremely dark environment. See Working with Night Hours Protection on page 34 for more information.		
	Switch	If your environment is too dark, the monitor displays a pop-up message that asks you to turn on the function.	• Auto Switch • ON • OFF
	Level	A stronger effect is produced as the value increases.	1 ~ 10
Low Blue Light	Decreases the blue light emitted from the display to reduce the risk of blue light exposure to your eyes. A stronger effect is produced as the value increases. See Working with Low Blue Light on page 34 for more information.		0 ~ 5

Item	Function		Range
Visual Optimizer (V.O.)	Automatically adjust screen brightness and color temperature based on ambient light to ensure optimal image clarity and comfort. See Adjusting screen brightness and color temperature automatically (Visual Optimizer) on page 34 for more information.		
	Switch	Toggle to turn on or off.	• ON • OFF
	Mode	Select to automatically adjust either brightness or both brightness and color temperature.	• Bri. + Color Temp. • Brightness
	Light Meter	Sets to display the light condition around the monitor on the screen.	• ON • OFF
	Sensor Sensitivity	Adjusts the sensitivity of the built-in sensor.	0 ~ 10
Color Weakness	Adjusts color matching representation for people with color vision deficiency to distinguish colors easily.		
	Red Filter	Decides the effect produced by the red filter. A stronger effect is produced as the value increases.	0 ~ 10
	Green Filter	Decides the effect produced by the green filter. A stronger effect is produced as the value increases.	0 ~ 10

Color Mode menu

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.



1. Press  to bring up the main menu.
2. Use  or  to select **Color Mode**.
3. Select  to go to a sub menu, and then use  or  to select a menu item.
4. Use  or  to make adjustment, or use  to make selection.
5. To return to the previous menu, select .
6. To exit the menu, select .

Item	Function
Coding - Dark Theme	For coding environment (IDE) in dark theme.
Coding -Light Theme	For coding environment (IDE) in light theme.
Coding - Paper Color	For coding environment (IDEs) in any IDE theme, Coding - Paper Color delivers an eye-friendly experience with a paper-like display effect for comfortable reading and code review.
M-book	Minimizes the visual differences between the monitor and the connected MacBook series product.
Cinema	For viewing videos. Enhances contrast and saturation for better image clarity and color enrichment.
Game	For playing video games.
HDR	For better color matching representation with High Dynamic Range (HDR) technology.

Item	Function
ePaper	For reading e-books or documents in black and white with suitable on-screen brightness and clear texts.
sRGB	For better color matching representation with the peripheral devices, such as printers, digital cameras, etc.
User	Applies a combination of picture settings defined by users.

Customizing each **Color Mode**


For different color modes, you can further adjust the color settings for detailed color adjustment. The available options for each color mode may vary.

Item	Function	Range
Brightness /Brightness (V.O. On)	Adjusts the balance between light and dark shades.  When Visual Optimizer (V.O.) is off, the display shows the original brightness adjustment. When V.O. is on, the display reflects the V.O. brightness adjustment.	0 to 100
Contrast	Adjusts the degree of difference between darkness and lightness.	0 to 100
Local Contrast	Real-time auto contrast adjustment technology that ensures optimal detail presentation across different coding environments, delivering enhanced clarity and refined contrast in darker scenes.	• ON • OFF
Sharpness	Adjusts the clarity and visibility of the edges of the subjects in the image.	1 to 10
Saturation	Adjusts the purity degree of colors.	0 to 10
Gamma	Adjusts the tone luminance. The default value is 3 (the standard value for Windows).	• 1 • 2 • 3 • 4 • 5

Item	Function		Range
Color Temperature	Normal	Allows video and still photographs to be viewed with natural coloring. This is the factory default color.	
	Bluish	Applies a cool tint to the image and is factory pre-set to the PC industry standard white color.	
	Reddish	Applies a warm tint to the image and is factory pre-set to the news print standard white color.	
	User Define	The blend of the Red, Green and Blue primary colors can be altered to change the color tint of the image. Go to the succeeding R (red), G (green), and B (blue) menus to change the settings. Decreasing one or more of the colors will reduce their respective influence on the color tint of the image. (e.g. if you reduce the Blue level the image will gradually take on a yellowish tint. If you reduce Green, the image will become a magenta tint.)	• R (0~100) • G (0~100) • B (0~100)
Reset Color	Resets the custom color settings to the factory defaults.		• YES • NO

Audio menu

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.




1. Press to bring up the main menu.
2. Use or to select **Audio**.
3. Select to go to a sub menu, and then use or to select a menu item.
4. Use or to make adjustment, or use to make selection.
5. To return to the previous menu, select .
6. To exit the menu, select .

Item	Function		Range
Volume	Adjusts the audio volume.		0 ~ 50
Audio Scenario	Selects one of the equalizers to obtain the best audio effect in certain scenarios.		
	Standard	Balances all settings for use without a specific scenario.	
	Dialogue	Cancels noise to improve sound clarity.	
	Music	Keeps the music and the vocal in harmony as if in live.	
Mute	Turns the volume on or off.		• ON • OFF

Custom menu

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.




1. Press to bring up the main menu.
2. Use or to select **Custom**.
3. Select to go to a sub menu, and then use or to select a menu item.
4. Use or to make adjustments, or use to make selection.
5. To return to the previous menu, select . To exit the menu, press the Exit key.

Item	Function	Range
Coding Hotkey	Selects three color modes as options for Coding Hotkey switching. The HDR option is not available and will be grayed out.	• Coding - Dark Theme • Coding - Light Theme • Coding - Paper Color • M-book • Cinema • Game • HDR • ePaper • sRGB • User

Item	Function	Range
Quick Menu	Sets the function to be accessed by Quick Menu. Choose 2 to 4 options to be accessed by this key.	• Brightness/ Brightness (V.O. On) • Contrast • Sharpness • Low Blue Light • Night Hours Protection
Function Key	Sets the function to be accessed by Function key.	• Input • Color Mode • Audio Mute • Audio Scenario • Visual Optimizer (V.O.)

System menu

Available menu options may vary depending on the input sources, functions and settings. Menu options that are not available will become grayed out. And keys that are not available will be disabled and the corresponding OSD icons will disappear. For models without certain functions, their settings and related items will not appear on the menu.



1. Press to bring up the main menu.
2. Use or to select **System**.
3. Select to go to a sub menu, and then use or to select a menu item.
4. Use or to make adjustment, or use to make selection.
5. To return to the previous menu, select .
6. To exit the menu, select .

Item	Function	Range
Software	Displays the QR code of Display Pilot 2 . Scan for quick access to the software download page.	

Item	Function		Range
OSD Settings	Language	Sets the OSD menu language.  The language options displayed on your OSD may differ from those shown on the right, depending on the product supplied in your region.	• English • Français • Deutsch • Italiano • Español • Polski • Český • Magyar • Română • Nederlands • Русский • Svenska • Português • 日本語 • 繁體中文 • 简体中文 • العربية • 한국어 • Українська • Български • Ελληνικά
	Display Time	Adjusts the display time of the OSD menu.	• 5 sec. • 10 sec. • 15 sec. • 20 sec. • 25 sec. • 30 sec.
	OSD Lock	Prevents all the monitor settings from being accidentally changed. When this function is activated, the OSD controls and hotkey operations will be disabled.  To unlock the OSD controls, press and hold any key for 5 seconds.	
	Pivot	Sets the orientation of the OSD menu to match the physical orientation of the monitor.	• 90° • 270° • OFF
Function Bar	Adjusts the LED indicator under the function bar.		
	Power Key LED		• ON • OFF

Item	Function		Range
Auto Power Off	Sets the time to power off the monitor automatically in power saving mode.		• 10 min • 20 min • 30 min • OFF
Input Auto Scan	Sets to automatically detect the available input source.		• ON • OFF
USB-C Configuration	Sets the refresh rate of the input video via USB-C™ port. The USB transmission speed changes accordingly due to USB-C™ technology limitation.		
	USB 3.2	Refresh rate: 2560 x 1440 @ 60Hz (based on video source) USB transmission speed: 5 Gbps	
	USB 2.0	Refresh rate: 2560 x 1440 @ 144Hz USB transmission speed: 480 Mbps	
USB-C Awake	When both Power-on Charging and Standby Charging are ON , this feature allows your connected device to wake the monitor from standby mode via USB-C™ or Hub.		• ON • OFF
Power-on Charging	Keep your USB-C™ upstream charging your device; disabling Power-on Charging also disables Standby Charging .		• ON • OFF
Standby Charging	Keep your USB-C™ and Hub charging in standby mode when both USB-C Awake and Power-on Charging are ON .		• ON • OFF
Power-off Charging	Keep your USB-C™ and Hub charging in power-off mode when USB-C Awake is ON .		• ON • OFF
Deep Sleep	Sets to enable/disable deep sleep (power-saving) mode. • If enabled, the monitor enters deep sleep mode when the power button is pressed, consuming less power. • If disabled, the monitor turns off the backlight without entering deep sleep mode when the power button is pressed. This allows the monitor to wake up more quickly and recover from sleep mode in a shorter time.		• ON • OFF
AMA	Improves the gray level response time of the LCD panel.		• Premium • High • OFF

Item	Function	Range		
FreeSync	Switches FreeSync on or off. Monitors featuring with the FreeSync will eliminate screen tearing, stuttering, and juddering during gaming. If this function is enabled, the FreeSync and HDR functions are activated, with the support of your monitor, the graphic card, and the input of HDR content. Available FreeSync function varies by content. For any questions related to FreeSync™ performance, please refer to www.AMD.com.	• ON • OFF		
DDC/CI	Allows the monitor settings to be set through the software on the PC.  DDC/CI, short for Display Data Channel/Command Interface, which was developed by Video Electronics Standards Association (VESA). DDC/CI capability allows monitor controls to be sent via the software for remote diagnostics.	• ON • OFF		
Display Mode	This feature is provided to allow aspect ratios other than the native aspect ratio to be displayed without geometric distortion.  The options under Display Mode will be different depending on the input signal sources.			
	<table><tr><td>Full</td><td>Scales the input image to fill the screen. Ideal for images that fits the native aspect ratio.</td></tr></table>	Full	Scales the input image to fill the screen. Ideal for images that fits the native aspect ratio.	
	Full	Scales the input image to fill the screen. Ideal for images that fits the native aspect ratio.		
<table><tr><td>Aspect</td><td>The input image is displayed without geometric distortion filling as much of the display as possible.</td></tr></table>	Aspect	The input image is displayed without geometric distortion filling as much of the display as possible.		
Aspect	The input image is displayed without geometric distortion filling as much of the display as possible.			
Overscan	Slightly enlarges the input image. Use this feature to hide annoying edge noise if present around your image.  Available only when the input source is HDMI.	• ON • OFF		
RGB PC Range	Determines the range of color scales. Select an option that matches the RGB range setting on the connected HDMI device.	• Auto Detect • RGB (0~255) • RGB (16~235)		
Resolution Notice	Sets whether to display the resolution notice of the recommended resolution when a new input source is detected by the monitor.	• ON • OFF		

Item	Function	Range
Information	Displays the current monitor property settings.	• Current Resolution • Optimum Resolution (best with the monitor) • HDR • Model Name • FW Version
Reset All	Resets all mode, color and geometry settings to the factory default values.	• YES • NO

Troubleshooting

Frequently asked questions (FAQ)

Imaging

-  The image is blurred.
-  • Download **Resolution** file from the website (see [Product support on page 3](#)). Refer to "**Adjusting the Screen Resolution**". And then select the correct resolution, refresh rate and make adjustments based on these instructions.
- If a VGA extension cable is used, remove the extension cable for the test. Is the image now in focus? Download **Resolution** file from the website (see [Product support on page 3](#)). Refer to "**Adjusting the Screen Resolution**". And then select the correct resolution, refresh rate and make adjustments based on these instructions to optimize the image. It is normal for blurring to occur due to conduction losses in extension cables. You can minimize these losses by using an extension cable with better conduction quality or with a built-in booster.
-  Does the blurring only occur at resolutions lower than the native (maximum) resolution?
-  Download **Resolution** file from the website (see [Product support on page 3](#)). Refer to "**Adjusting the Screen Resolution**". Select the native resolution.
-  Pixel errors can be seen.
- One of several pixels is permanently black, one or more pixels are permanently white, one or more pixels are permanently red, green, blue or another color.
-  • Clean the LCD screen.
- Cycle power on-off.
- These are pixels that are permanently on or off and is a natural defect that occurs in LCD technology.
-  The image has a faulty coloration.
-  It has a yellow, blue or pink appearance.
- Go to **Color** and **Reset Color**, and then choose **YES** to reset the color settings to the factory defaults.
- If the image is still not correct and the OSD also has faulty coloration, this means one of the three primary colors is missing in the signal input. Now check the signal cable connectors. If any pin is bent or broken off, please contact your dealer to get necessary support.
-  The image is distorted, flashes or flickers.
-  Download **Resolution** file from the website (see [Product support on page 3](#)). Refer to "**Adjusting the Screen Resolution**". And then select the correct resolution, refresh rate and make adjustments based on these instructions.

- ? You are running the monitor at its native resolution, but the image is still distorted.
- ✓ Images from different input sources may appear distorted or stretched on the monitor running at its native resolution. To have the optimal display performance of each type of input sources, you can use the **Display Mode** function to set a proper aspect ratio for the input sources. See [Display Mode on page 52](#) for details.
- ? The image is displaced in one direction.
- ✓ Download **Resolution** file from the website (see [Product support on page 3](#)). Refer to "**Adjusting the Screen Resolution**". And then select the correct resolution, refresh rate and make adjustments based on these instructions.
- ? Faint shadow from the static image displayed is visible on the screen.
- ✓
 - Activate the power management function to let your computer and monitor go into a low power "sleep" mode when not actively in use.
 - Use a screensaver to prevent the occurrence of image retention.

LED indicator

- ? The power LED indicator is white or orange.
- ✓
 - If the LED lights up in solid white, the monitor is powered on.
 - If the LED is illuminated in white and there is a message **Out of Range** on the screen, this means you are using a display mode that this monitor does not support, please change the setting to one of the supported mode. Download **Resolution** file from the website (see [Product support on page 3](#)). Refer to "**Adjusting the Screen Resolution**". And then select the correct resolution, refresh rate and make adjustments based on these instructions.
 - If the LED is illuminated in orange, the power management mode is active. Press any button on the computer keyboard or move the mouse. If that does not help, check the signal cable connectors. If any pin is bent or broken off, please contact your dealer to get necessary support.
 - If the LED is off, check the power supply mains socket, the external power supply and the mains switch.

OSD controls

- ? The OSD controls are inaccessible.
- ✓ To unlock the OSD controls when it is preset to be locked, press and hold any key for 5 seconds.

OSD messages

- ? A message **Out of Range** on the screen during computer boot up process.
- ✓ If there is a message **Out of Range** on the screen during computer boot up process, this means computer compatibility caused by operating system or graphic card. The system will adjust the refresh rate automatically. Just wait until the operating system is launched.

Audio

- ?** No sound can be heard from the built-in speakers.

 - ✓** • Check whether the desired cable to input audio signals is properly connected. See [Connect the headphone. on page 24](#) for details.
 - Increase the volume (volume may be muted or too low).
 - Remove your headphone and/or external speakers. (If they are connected to the monitor, the built-in speakers are automatically muted.)
- ?** Sound from the built-in speakers is low or unclear.

 - ✓** • Increase the volume (volume may be too low).
 - Make sure the Noise Filter function of the built-in speakers is disabled. This function is not recommended for music or movie playback. To disable the Noise Filter function, press the Noise Filter Speaker key and select **OFF** from the hotkey menu.
- ?** No sound can be heard from the connected external speakers.


 - ✓** • Remove your headphone (if the headphone is connected to the monitor).
 - Check whether the headphone jack is properly connected.
 - If the external speakers are USB-powered, check whether the USB connection is OK.
 - Increase the volume (volume may be muted or too low) on the external speakers.
- ?** The built-in microphone does not respond when the monitor is connected to a PC.

 - ✓** • (Models with USB-C™) Check if the certified USB-C™ cable with signal transmission and power delivery functions is properly connected.
 - Increase the MIC volume from the **Audio** menu. See [Audio menu on page 46](#) for more information.

Sensors

- ?** The light sensor of the monitor does not work well.

 - ✓** The light sensor is located at the front bottom of the monitor. Please check:
 - If you have removed the sensor protection sticker.
 - If the Visual Optimizer (V.O.) function is set to **ON**. Check **Eye Care > Visual Optimizer (V.O.)**.
 - If there are any obstacles in front of the sensor that keep the sensor from detecting the light properly.
 - If there are any objects or clothing in bright colors in front of the sensor. Bright colors (especially white and fluorescent colors) reflect light and the sensor cannot detect the main light sources.



USB-C™ connection (models with USB-C™)

-  No video or audio output from the laptop with USB-C™ connection.
-  Check the cable connections and menu settings in the following order.
 - Check if the USB-C™ cable has been connected to the monitor and the laptop properly. See [Connect the PC video cable on page 23](#) for more information.
 - Check if the input source has been selected to **USB-C** from **Input**.

Night Hours Protection

-  **Night Hours Protection** is grayed out in Quick menu.
-  **Night Hours Protection** settings in the Quick Menu will become grayed out if the function is (1) set to **OFF**, or (2) set to **Auto Switch** and is not activated under a bright environment.
 - If the function is set to **OFF**, go to **Menu > Eye Care > Night Hours Protection > Switch** and set the function to **ON**.
 - To adjust the level directly, go to **Menu > Eye Care > Night Hours Protection > Level**. The adjustment will be saved under your current color mode.

Need more help?

If your problems remain after checking this manual, please contact your place of purchase or visit the local website from [Support.BenQ.com](https://support.benq.com) for more support and local customer service.