

Cleaning the screen

The 5-way controller is located below the lower part of the front bezel. While sitting in front of the monitor, move the controller to the directions instructed by the on-screen icons for menu navigation and operations.

Use a clean part of the cloth to wipe dry the screen completely. If it is still not clean, continue with another clean part of the cloth to avoid spreading the grease around.

Available menu options may vary depending on the input sources and settings. Keep the shipping carton and packing materials for future use, in case you need to transport the monitor a long distance.