Yokogawa for Dummies

(Useful knowledge not taught in Purdue Computer Science Department)

The following is a set of instructions and rationale.

| Instructions/अनुदेश/说明/సూచనలను | Why? /क्यूं कर? /为什么?/ఎందుకు? |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Connect the black cable to a power outlet Turn on the Machine | Because you have to turn on the machine before you can use it. |
| Notice there are 2 grey cables with yellow heads, connect the yellow head labelled "SOURCE" to a power outlet and the other labelled "LOAD" to the device which the power you are measuring | You have to provide power to the device and then measure the the power. |
| Upon connecting the plugs, you should be able to see the values on the WT310E | |
| 3. To change the values on the screen to the one you want to view, use the "FUNCTION" button a. E.g. change from V to A, press "FUNCTION" | |
| 1. Connect the white usb to the black DELL with the "LPIRC" blue sticker a. If using DELL, use PCMS software b. Desktop -> YOKOGAWA -> Power Consumption Measuring Software -> IEC62301 -> PCMS.exe | Connect to a computer to use the software for further analysis and to churn out reports in .pdf and .cvs format. |
| Or, if you would like to use it on your own CPU then download the "Power Measurement Application Software" from the Yokogawa website | |
| ** However, when attempting to download, user rights is required which we do not have. | |

| The only software a user without user rights is able to download is the "Trial Version" ** PCMS on DELL is much more user-friendly | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|
| 1. How to use PCMS.exe a. Connection Tab i. Select WT Series -> "WT310E" ii. Press "Connect" b. Preparing for Measurement Tab i. Skip c. Condition and Measurement Tab i. Press Start ii. We measure the power per quarter of a second d. Output Tab i. Choose the options that you want | To generate the report |