

ATSAMD21G18A-AUT

PA13

PA14

PA15

PA16

PA17

PA18

PA19 PA20

PA21

PA23

PA24

PA25 PA27

PA28

PA30

RESET

RS485\_ENABLE 23

2C\_ENABLE \_24 \_25 \_26 \_27 \_28 \_29 \_30 \_12C\_SDA\_31 \_12C\_SCL\_32 \_D = \_33 \_D + \_34 \_39 \_41 SWD\_CLK\_45 SWD\_CLK\_45 SWD\_0\_61

SWD\_IO\_46 PA31

MCU\_RST\_40

+3V3

 $\rightarrow$ 


GND

SW2

SW\_Reset

GND

+3V3














18

 $\uparrow$ 

 $\rightarrow$ 

GND GND

