

## SERVICE JOB REPORT

Job Number: BD21120002

**Date:** 01/30/2022

Time: 00:59:56

| PART NUMBER | DESCRIPTION   | QTY  | LOCATION |  |
|-------------|---|------|----------|--|
| 001         | ทดสอบ   | 1.00 | LOCATION |  |
| 000072      | It was barking very loud. Bobby opened his window. He looked at the barking dog. "Why are you barking so loud?" | 2.00 | LOCATION |  |
|             | TOTAL LABOUR HOURS  | QTY  | LOCATION |  |

CUSTOMERS NAME: พวงผกา กาญจนวิเศษชาญ SIGNATURE: DATE: 01/30/2022

| BATTERY DETAILS  |            |            | CHARGER DETAILS  |            |
|------------------|------------|------------|------------------|------------|
|                  | BATTERY #1 | BATTERY #2 | MANUFACTURER     | 2          |
| MODEL            | 123        | 123        | MODEL            | 2          |
| SERIAL           | 12         | 312        | SERIAL           | 2          |
| AMP HRS          | 312        | 312        | TAG DATE<br>HOUR | 20/12/2564 |
| DATE CODE        | 123        | 2          | HOUR METER       |            |
| SPECIFIC GRAVITY | 1231.00    | 2.00       |                  |            |
| VOLT STATIC      | 312.00     | 2.00       | 2                |            |
| VOLT U/LOAD      | 31.00      | 2.00       |                  |            |

| SERVICEMAN | LABOUR | TRAVEL | TOTAL | WARRANTY TYPE    | FAILURE CODE | FAIR WEAR |
|------------|--------|--------|-------|------------------|--------------|-----------|
| 1          | 1.00   | 1.00   | 1.00  |                  | 1            | 3         |
|            |        |        |       | OFFICE USE ONLY: |              |           |
|            |        |        |       |                  |              |           |
| TOTAL      |        |        |       |                  |              |           |



Customer: Job Card No: BD21120002

| DESCRIPTION                    | INSP     | ACT | REMARK |
|--------------------------------|----------|-----|--------|
| Visual Inspection              | <b>√</b> |     |        |
| Leaks                          |          | ✓   | 12312  |
| Overhead Guard Bolts Tight     |          |     |        |
| Mast Assembly                  | <b>√</b> |     |        |
| Forks & Latches                | <b>√</b> |     |        |
| Load Backrest                  | <b>√</b> |     |        |
| Tire&Whel Cond-Dtire, LugBolts | <b>√</b> |     |        |
| Tire&Wheel Cond-Steer Tire     | <b>√</b> |     |        |
| Brake Pedal                    | <b>√</b> |     |        |
| Hoses                          | <b>√</b> |     |        |
| Control Cables                 | <b>√</b> |     |        |
| Lift Chains and Anchors        | <b>√</b> |     |        |
| Battery Retainers              | <b>√</b> |     |        |
| Seat Belt Condition Operation  | <b>√</b> |     |        |
| Seat Deck Latch                | <b>√</b> |     |        |
| Bent or Damaged Parts          | <b>√</b> |     |        |
| Floorboard                     | <b>√</b> |     |        |
| Sfty Lbls/Decls,Cap&DataPlates | <b>√</b> |     |        |
| Battery                        | <b>√</b> |     |        |
| Battery Condition              | <b>√</b> |     |        |
| Electrolyte Level              | <b>√</b> |     |        |
| Water Added                    | <b>√</b> |     |        |
| Battery Retainer Condition     | <b>√</b> |     |        |
| Cable Condition                | <b>√</b> |     |        |
| Battery Plug - Condition       | <b>√</b> |     |        |
| Wiring Harness Condition       | <b>√</b> |     |        |
| Clean & Lubricate              | <b>√</b> |     |        |
| Blow Off Truck                 | <b>√</b> |     |        |
| Blow Low Presure Ovr Elec Pnls | <b>√</b> |     |        |
| Lube Al Lubrication Points     | <b>√</b> |     |        |
| Lubricate Brake Linkages       | <b>√</b> |     |        |
| Lift/Tilt/Aux. Lever Asm.      | <b>√</b> |     |        |
| Lube Mast & Roller Assemblies  | <b>✓</b> |     |        |
| Lubricate Lift Chains          |          |     |        |
| Lube Miscellaneous Linkages    |          |     |        |
| Attachments                    | <b>√</b> |     |        |
| Hydraulic Pump & Motor         | <b>√</b> |     |        |
| Mounting Secure                | <b>✓</b> |     |        |

| DESCRIPTION                    | INSP     | ACT      | REMARK |
|--------------------------------|----------|----------|--------|
| Hose & Fitting Conditions      | <b>√</b> |          |        |
| Leaks                          | <b>√</b> |          |        |
| Brush & Armature Condition     | <b>√</b> |          |        |
| Blow Brush Dust From Motor     | <b>√</b> |          |        |
| Cable Connections - Secure     | <b>√</b> |          |        |
| Pump Operation                 | <b>√</b> |          |        |
| Drive Unit                     | <b>√</b> |          |        |
| Oil Level & Condition          | <b>√</b> |          |        |
| Leaks                          | <b>√</b> |          |        |
| Secure Motor Mountings         | <b>√</b> |          |        |
| Power Cable Connections Secure | <b>√</b> |          |        |
| Secure Motor Mountings         | <b>√</b> |          |        |
| Wheel Lug Bolts                | <b>√</b> |          |        |
| Power Cables & Control Wiring  | <b>√</b> |          |        |
| Power Cable Conditions         | <b>√</b> |          |        |
| Power Cable Connections Secure | <b>√</b> |          |        |
| Wiring Condition               | <b>√</b> |          |        |
| Wiring Connections Secure      | <b>√</b> |          |        |
| Contactor Panel&Pwr Contactors | <b>√</b> |          |        |
| Pump Contactor Tip Condition   | <b>√</b> |          |        |
| Line Contactor Tip Condition   | <b>√</b> |          |        |
| Brakes                         | <b>√</b> |          |        |
| Pedal Operation                | <b>√</b> |          |        |
| Air Gap                        | <b>√</b> |          |        |
| Steering                       | <b>√</b> |          |        |
| Power Steering Operation       | <b>√</b> |          |        |
| Steering Control Unit          | <b>√</b> |          |        |
| Pump & Motor Mounting Secure   |          | <b>√</b> | 212212 |
| Steering Column                | <b>√</b> |          |        |
| Steering Column Position Lock  | <b>√</b> |          |        |
| Brush & Armature Condition     | <b>√</b> |          |        |
| Blow Brush Dust From Motor     | <b>√</b> |          |        |
| Steer wheel lug bolts Secure   | <b>√</b> |          |        |
| Wheel Bearings Condition       | <b>√</b> |          |        |
| Steering Encoder Operation     | <b>√</b> |          |        |
| Accelerator                    | <b>√</b> |          |        |
| Pedal Operation                | <b>√</b> |          |        |
| Switch Adjustment              | <b>√</b> |          |        |
| Hydraulic System               | <b>√</b> |          |        |
| Oil Level & Condition          | <b>√</b> |          |        |
| Leaks                          | <b>√</b> |          |        |
| Breather Cap                   |          | ✓        | 132312 |

| DESCRIPTION   | INSP     | ACT      | REMARK |
|---|----------|----------|--------|
| Hose & Fitting Conditions   | <b>√</b> |          |        |
| Filter(s)   | ✓        |          |        |
| Strainer  | ✓        |          |        |
| Mast Assembly & Misc.   | ✓        |          |        |
| Roller&Tracking-Wear or Damage  | ✓        |          |        |
| Lift Chain Condition - Wear   | ✓        |          |        |
| Lift Chain Adjustment   | ✓        |          |        |
| Mast Cables & Hoses   | <b>√</b> |          |        |
| Limit Switch(es)  | ✓        |          |        |
| Lift Cyl-Loose/Missing Hdware   | ✓        |          |        |
| Tilt Cyl-Adj, Mountings, Leaks  | ✓        |          |        |
| MntingBolts to PowerUnitSecure  | <b>√</b> |          |        |
| Mast Pivot Bushes&Mountings   | <b>√</b> |          |        |
| Poly Stops/Bumpers  | <b>√</b> |          |        |
| Overhead Guard  | <b>√</b> |          |        |
| Freezer Condition Trucks  | <b>√</b> |          |        |
| Heater Operation  | <b>√</b> |          |        |
| Wiring Operation  | <b>√</b> |          |        |
| Operational Check & Test Drive  | <b>√</b> |          |        |
| Display   | <b>√</b> |          |        |
| Horn  | <b>√</b> |          |        |
| Power Steering Operation  | <b>√</b> |          |        |
| Brake Operation as per manual   | <b>√</b> |          |        |
| Plugging as per manual  | <b>√</b> |          |        |
| Lift/Tilt/Aux. Operation  | <b>√</b> |          |        |
| Interlock Switch operation  | <b>√</b> |          |        |
| Creep Speed   | <b>√</b> |          |        |
| Mast Height Switch Operation  | <b>√</b> |          |        |
| Sfty Lbis/Decls,Cap&DataPlates  | <b>√</b> |          |        |
| Event Log   | <b>√</b> |          |        |
| Directional Control   | <b>√</b> |          |        |
| Travel Alarm  | <b>√</b> |          |        |
| Tail Lights   | <b>√</b> |          |        |
| Turn Signals  | <b>√</b> |          |        |
| Work Lights   | <b>√</b> |          |        |
| Pedestrian Light  | <b>√</b> |          |        |
| Attachment Operation  | <b>√</b> |          |        |
| Customer Care   | <b>√</b> |          |        |
| Wipe The Truck Clean  | <b>√</b> |          |        |
| Clean Work Area Remove Rubbish  |          | <b>√</b> | 12122  |
| Component identification and location with regards to appropriate inspect | <u> </u> |          | 1      |