


## **Precondition**

This test case is a continuation of test case TC47 and should not be executed without it being executed first.

Steps		Click "Tab" or "Shift + Tab" to navigate grid ?
1	If the NMEA Simulator is still running, stop it.	
	<i>₫</i>	


o<sup>\*</sup>





requirements at once):    True Wind	
<b>♂</b>	_
Start the "run" on NMEA emulator. The test dashboard window should show the values now as follows:	
TW Calc Test	
True HDG	
10° true	
SOG	
5.00 kts	
App. Wind Spee 8.30 m/s	
App. Wind Angle 29°<	
True Wind Spee	
6.17 m/s True Wind Direc	
50° true	
Note that between the previous test case (STW) and this one, the STW value should	
disappear, otherwise the Watchdog in Dashboard is not working. Otherwise, observe	
the values for correctness.	


3 of 5

面









ACTIVITY HISTORY COMMENTS