Tessera shortcuts

A + B: hold A, then press or turn B. **Held**: about 0.7 s (the GLO and SCL layers: MENU > HOLD, 0.3 to 0.6 s); ARP, FX, LFO and OCT+ on GEN work as soon as they are down. Page buttons act when let go. KNOB 1 to 4 are the four knobs from the left.

Getting around

HOME	The home page: four tracks, their sounds and knobs
HOME held	The menu (held again: leaves it)
ALGORITHM	Picks the track, on every page (MENU > TRACK KNOB LEFT swaps it with PRESETS)
SELECT	The pages of the section shown, both ways
A page button again	That section's next page (from elsewhere most return to the page last used)
OCT- (off HOME)	Back: closes a list, sheet or map, else HOME
OCT+ (off HOME)	Enter: opens the row, slot or note picked; does the action picked
OCT+ held	The page's sheet: the sound's (HOME, EDIT, ENV, LFO, FX), the pattern's (GEN, NOTES, PATTERN), the song's (SONG), the pattern's on PATTERNS
A sheet: **KNOB 1**, **OCT+** / **OCT-**	Picks the row / does it / closes
A dialog: **OCT+** / **OCT-**	Yes / no
Lists (menu, SCL, VOICE): **KNOB 1** / **KNOB 2**	The row / its value

The page buttons

SEQ	GEN, then the MODE's pages. STEP: EVOLVE, NOTES. ARP: ARP, ARP 2, NOTES. A generator: EVOLVE, FORM, TWEAK, TWEAK 2, LENGTH, TIMING, ENERGY. All: PATTERN, TEMPO, PATTERNS, SONG
SEQ held	PATTERNS
ARP	STEP track: switches it to ARP, the ARP page (again: ARP 2). Generator track: GEN ("ARP: MODE ON GEN")
LFO	MODS, MATRIX, LFO, LFO 2, ORGANIC, LFO DEST; on FM6 then FM LFO, FM LFO 2
ENV	ENV, ENV DEST; on FM6 instead EG RATE, EG LVL, PITCH EG, PITCH LV
SCL	SCALES, SCL, CHORD
EDIT	The sound's EDIT pages
EDIT on an EDIT page	The map of the sound's pages: KNOB 1 across, KNOB 2 rows, OCT+ opens, OCT- or EDIT closes
PRESETS on an EDIT page	The next / previous section (FM6: Algo, OP1 to OP6, Pitch, LFO, Ctrl, Store)
FX	The insert and send effects
GLO	MIXER, GLOBAL, SYSTEM
SAVE	USER (save the sound), PROJECT, PRESETS

Quick layers: hold GLO or SCL

GLO held	[GLO] SET over the page
GLO + black keys F#3 G#3 A#3 C#4	Mute / unmute track 1 to 4 (lit: sounding)
GLO + white keys F3 G3 A3 B3	Solo track 1 to 4 while the key is held
GLO + C4 / F4	Unmute all / tap the tempo (three taps or more; INT clock)
GLO + KNOB 1 to 4	Level of track 1 to 4
GLO + PLAY	Restart from the top without stopping
SCL + any key	ROOT: that key's note name
SCL + KNOB 1 to 4	ROOT, SCALE, CHRD, VOIC
GLO / **SCL** + OCT-	Puts back what the layer changed since it opened
GLO or **SCL** tapped twice	Locks the layer open; press it again to close

Knob holds

ARP + a knob	The help card for that knob; turn on: larger text, or scroll
FX + a knob	Mod shortcut: a cord from the track's LFO to that parameter, the turn sets its amount
FX + SELECT	The mod shortcut's source
LFO + a knob	A momentary change: back as it was when LFO is let go
LFO + a knob, then **OCT+**	Keeps the change ("KEPT")
OCT- / **OCT+** on HOME	Octave down / up; both together: octave 0

Steps and notes (SEQ > NOTES)

Keys	The cursor step (pressed together: a chord of up to 4); let go: the cursor moves on
A key + SELECT	That note's length
ENV + SELECT or KNOB 1	The cursor's note longer / shorter
SCL + SELECT or KNOB 1	Moves the note (ties, chord and velocity with it)
EDIT tapped	Deletes the note and its ties
OCT+	The note's sheet (length, velocity...)
OCT+ + SELECT, KNOB 1 or 2	Selects a run of notes; let go: the Selected notes sheet (move, copy, quantize, delete)
OCT-	Clears the selection
PRESETS	Zooms the notes

The drum grid (NOTES on a DRUM track)

White keys	The selected lane's hit on that step, on or off
Black keys F#3 to A#4	Pick lane 1 to 8
C#5 + white key	The hit's accent
D#5 / F#5	Page down / up (patterns over 16 steps)
KNOB 1 to 4	STEP, LANE, HIT, ACC
EDIT	Clears the cursor step
OCT+	The hit's sheet (accent, chance...)

Patterns

SEQ + white keys F3 to F4	Pattern 1 to 8 (playing: from the next bar)
SEQ + a pattern key held + another	Copies the first pattern onto the second
SEQ + SELECT	The next / previous pattern
PATTERNS: KNOB 1 to 4	Track 1 to 4's next pattern
PATTERNS: **OCT-**	Clears the queue (again: HOME)

Recording and transport

PLAY	Start / stop; on SONG: plays the song. Generators start from the top of their seed
REC	Arms / disarms the track (playing: waits for the loop)
REC + PLAY	Records now
REC held	Generator track: prints its last bars into STEP. STEP EVOLVE: keeps the changes. STEP: captures what you played
REC held on SONG	Take jam: the patterns played since PLAY become the song
EDIT held, recording on NOTES	Erases as the steps pass
EDIT held	Undo (the last load, capture or print; on NOTES the last edit)
EDIT + OCT- / OCT+	Undo / redo

Saving and projects

SAVE + REC	Saves the project to its slot (stops playback first)
SAVE	USER, its Save sheet ready: OCT+ saves the sound
EDIT on USER or PROJECT	Renames the slot
OCT+ on a PROJECT slot	Load, Save here, Rename, Boot, Erase

Generators

GEN: **KNOB 1**	MODE: STEP, ARP or a generator
GEN: **OCT+** held	The second layer of QUAD, CHORD, ATLAS and CONSTL
ATLAS: **OCT+** + a black key	The fourth part's sound (TOM, CLAP, OPEN HAT, RIM, BELL)
CHORD, PROG USER: **OCT+** + keys	One chord a key, its root the key's note
AWAKE: a white key	Picks that step: KNOB 1 its A, KNOB 2 its B; the key again lets it go
EVOLVE: **KNOB 4** (ROLL)	A new seed a click; turn back for the last one
FORM: **KNOB 3** (CLEAR)	Forgets B and C
MODS: **OCT+**	The picked mod: BI / UNI
MATRIX: **OCT+**	Opens the picked mod in MODS

Power-on and update

OCT- alone while switching on	The update loader (three key-light flashes), to reinstall from the web installer
OCT- + **OCT+** while switching on	HARDWARE CALIBRATION: teach each button and knob
OCT- + **OCT+** held 5 s	Update mode (UBOOT); a countdown from 2 s, let go to cancel