

For an AMI BIOS, **3 repeating beeps with no display** typically indicate a **base memory (first 64 KB RAM) failure** during POST. This means the BIOS could not successfully read or write to the system's initial RAM area, so the computer stops before it can initialize the display.

Likely hardware issue:

- Faulty or improperly seated **RAM module(s)**
- Dirty or damaged RAM contacts
- A bad motherboard memory slot or memory controller issue (less common)

Two troubleshooting steps:

1. Reseat and test the RAM

- Power off the PC and unplug it.
- Remove the RAM sticks, clean any dust from the slots, and reinstall them firmly.
- If there are multiple RAM sticks, try booting with **one stick at a time** to identify a faulty module.

2. Check for memory compatibility or motherboard issues

- Verify that the RAM type, speed, and capacity are supported by the motherboard.
- Try a known-good compatible RAM stick if available. If the problem continues, the motherboard memory slot or motherboard itself may be the cause.