

Rave Generation

PRESENTS

DRE-3000



USER MANUAL

Introduction

DRE-3000 is a digital reverberator modeled on the Sony DRE-2000 of 1981, one of the first digital reverbs. It runs the original unit's own programs, in both of its software versions: four reverbs, two echoes and two delays, played from a replica of the original's remote control.

Signal Flow

INPUT → REVERB / ECHO / DELAY → LOW CUT → HIGH CUT → OUTPUT → MIX

The left and right inputs are summed to mono, as on the original's single input; the output is stereo. Mix blends it with the dry signal.

Key Features

- Both software versions: v1, the original, and v2, the update the DRE-2000A came with
- Four reverbs (A to D), two echoes and two delays
- Reverb time from 0.0 to 9.9 s, with separate low and high frequency decay ranges
- Early reflection and sub reverb, each with its own level and delay, and a pre-delay of up to 255 ms
- Echoes and delays of up to 999 ms (T1) and 499 ms (T2), with repeats
- LOW CUT and HIGH CUT filters, four settings each, modeled on the original's output stage
- Delay times glide when you change them, bending the pitch like the original
- The original remote as the panel: keys, LED displays and the HEADROOM meter
- Mode keys load each mode's factory settings, as on the original
- 53 factory presets: the original factory programs of both versions, five halls, and 32 settings recreated from recordings of a v2 unit, each also as a send version with Mix at 100%

User Interface Tips

Keys and Displays

Each display shows one value at a time, and the keys under it pick which: E.RFL or SUB REV for LEVEL; E.RFL, PRE DLY or SUB REV for DELAY TIME. The SEC display always shows REVERB TIME. Drag a display up or down, or scroll over it, to set its value.

Greyed Keys

What the current mode does not use is greyed out: the green echo labels in the reverb modes; REVERB TIME, the RT ranges and the blue reverb labels in the echo and delay modes.

Hint Bar

Hover over any control to read a one-line description in the bar at the bottom of the panel. The icon in the header switches the bar on and off.

Knobs

Hold Shift while dragging INPUT, MIX or OUTPUT for fine adjustment. Right-click a knob to return it to its default (Alt+click works too, Option+click on macOS); double-click it to type a value.

Menu Bar

Undo and Redo; the panel's opacity, 0% to 100%, to see the DAW behind it; the interface size, 70% to 200%; and the preset menu, which browses, loads and saves presets and copies and pastes them between instances.

Software and Modes

Software

Parameter	Range	Default	Description
Software	v1, v2	v2	v1 is the original software, v2 the update the DRE-2000A came with. The two sound different in every reverb mode

Changing the software or the mode clears the reverb, as on the original.

Modes

Mode	Description
A Reverb	Builds from sparse early echoes into a smooth tail
B Reverb	Dense from the start
C Reverb	Many early reflections, wide in stereo
D Reverb	Wide in stereo like C, with a grainier build
Echo 1, Delay 1	One delay, T1, in both channels. K1 sets its repeats
Echo 2, Delay 2	Two delays: T1 on the left and T2 on the right, with K1 and K2 setting their repeats

The reverb descriptions are for v2. In v1 the four reverbs are closer to each other.

Mode Keys

Pressing a mode key loads that mode's factory settings, as on the original. Mix, Input and Output stay as they are. ECHO and DELAY run the same programs: the ECHO keys load repeating echoes, the DELAY keys single delays.

Loading a preset or a project keeps its own settings, and switching the software keeps the current ones.

Controls

Reverb

Parameter	Range	Default	Description
REVERB TIME	0.0-9.9 s	3.0 s	Decay time of the reverb
RT LOW FREQ RANGE	x0.5, x1.0, x1.5, x2.0	x1.5	Decay of the low frequencies, relative to REVERB TIME
RT HIGH FREQ RANGE	x0.25, x0.33, x0.5, x1.0	x0.33	Decay of the high frequencies, relative to REVERB TIME
E.RFL level	0.0-0.9	0.5	Level of the early reflection, a distinct echo before the reverb
E.RFL delay	0-255 ms	45 ms	When the early reflection arrives
PRE DLY	0-255 ms	67 ms	Delay before the reverb starts
SUB REV level	0.0-0.9	0.0	Level of the sub reverb, a second start of the reverb that thickens the tail
SUB REV delay	0-255 ms	0 ms	How long after the reverb the sub reverb starts

Echo and Delay

Parameter	Range	Default	Description
T1	0-999 ms	150 ms	Delay time of the first echo
T2	0-499 ms	218 ms	Delay time of the second echo (Echo 2 and Delay 2)
K1	0.0-0.9	0.5	Repeats of T1. 0 plays it once
K2	0.0-0.9	0.0	Repeats of T2

K1 and K2 share their keys with the E.RFL and SUB REV levels. Changing a delay time while audio plays glides to the new time: the echoes bend down in pitch while the delay grows and up while it shrinks.

Filters

Parameter	Range	Default	Description
LOW CUT FREQ	30, 50, 100, 200 Hz	100 Hz	High-pass on the output
HIGH CUT FREQ	2.5, 5, 10, 13 kHz	10 kHz	Low-pass on the output

Both work in every mode.

Input, Mix and Output

Parameter	Range	Default	Description
INPUT	-24 to +24 dB	0 dB	Level into the reverb. The dry signal is not affected
MIX	0-100%	35%	Dry and wet balance. 100% is the reverb alone, for use on a send
OUTPUT	-24 to +24 dB	0 dB	Level of the reverb (wet) signal
HEADROOM			Level at the converter. The 0dB LED lights 6 dB below clipping: keep it from staying lit

Factory Presets

The preset menu holds seven folders, plus Default, the plugin's starting settings.

Folder	Presets
v1 Factory	The original factory programs of the v1 software, one per mode: A Reverb to Delay 2
v2 Factory	The same for the v2 software
Halls	Royal Opera House, Metropolitan Opera House, Beethovenhalle, Small Room and Airport: hall settings recreated from recordings of an original unit
v2 Short	Rooms and snare reverbs from 0.3 to 0.9 s, recreated from recordings of a v2 unit. Each name gives the mode and the reverb time
v2 Medium	Halls, wide rooms and a snare reverb from 1.0 to 2.0 s, recreated the same way
v2 Long	Halls and wide spaces from 3.0 to 9.8 s, recreated the same way
Sends (Wet Only)	Every preset above, and Default, with Mix at 100% for use on a send

Installation

System Requirements

- Windows 10/11 (64-bit) or macOS 10.13+
- VST3 or AU: the AU version for Logic Pro, the VST3 version for every other DAW

Support

For technical support, updates and additional information:

Website: ravegeneration.io

Email: support@ravegeneration.io

© 2026 Rave Generation. All rights reserved.