Rave Generation

presents



JPFX

Synth Effects Section

User Manual

1. Overview

JPFX is the EFFECTS section of the Roland JP-8000 synthesizer: TONE CONTROL, MULTI-FX and DELAY. It runs the JP-8000's own effects program, with the settings its firmware sends for every knob position and type: the Super Chorus, flangers and phasers, Twisting, Freeze Phase and the five delays, with the delay and the chorus synced to your song's tempo.

The panel follows the JP-8080's effects section. The settings the JP keeps in its menus (the two types, the two syncs and Dry) are the displays below the knobs.

2. Signal Flow

INPUT → TONE CONTROL → DELAY → MULTI-FX → OUTPUT

The effects take the sum of the left and right inputs; the dry signal stays stereo. TONE CONTROL shapes both. The DELAY and MULTI-FX levels add the effects to the dry signal: turning them up does not turn the dry down. JPFX delays its output by about 2 ms and reports this to your DAW, so its delay compensation keeps every track in time.

3. The Panel

TONE CONTROL

Parameter	Range	Description
BASS	0-127	Boosts the low end to the right of 64, cuts it to the left. 64, the default, is flat.
TREBLE	0-127	Boosts the high end to the right of 64, cuts it to the left. 64, the default, is flat.

MULTI-FX

Parameter	Range	Description
LEVEL	0-127	Amount of the Multi-FX. 0, the default, is off.
TYPE	12 types	The effect, listed below. Default Super Chorus Slow.
SYNC	Off, 1/16 to 8 Bars	Sets the speed of the modulation to a note value or a number of bars at the song's tempo. Default Off.

Type	Effect
Super Chorus Slow	Slow chorus with deep modulation
Super Chorus Mid	Chorus at medium speed
Super Chorus Fast	Fast chorus with shallow modulation
Super Chorus Clear	A light, transparent chorus, strongest on the highs
Flanger Slow, Deep, Fast	Flanger with a slow, a deep or a fast sweep
Deep Phasing Slow	Slow phaser with deep modulation
Jet Phasing	A jet plane taking off and landing
Twisting	Twists the sound
Freeze Phase 1, 2	A short delay that adds a metallic resonance

DELAY

Parameter	Range	Description
TIME	0-127	Time between echoes, shown in ms. The longest time depends on the type. Default 64.
FEEDBACK	0-127	How long the echoes repeat. At 127 they fade very slowly but never run away. Default 64.
LEVEL	0-127	Level of the echoes. Default 100.
TYPE	5 types	Where the echoes sound, listed below. Default Panning L>R.
SYNC	Off, 1/16 to 1/2	Sets the time to a note value at the song's tempo; TIME then has no effect. A note value too long for the type is halved until it fits, as on the JP. Default Off.

Type	Echoes
Panning L>R	Alternate between left and right, starting on the left. Up to 625 ms
Panning R>L	The same, starting on the right
Panning Short	Alternate, starting on the right. Up to 156 ms
Mono Short	In the centre. Up to 156 ms
Mono Long	In the centre. Up to 1250 ms

DRY

On plays the dry signal with the effects. Off plays the effects alone, for use on a send. Default On.

Knobs and Displays

Hold Shift while dragging a knob for fine adjustment. Right-click a knob to return it to its default (Alt+click works too, Option+click on macOS); double-click it to type a value. Click a display to open its list.

Menu Bar

Undo and Redo; the panel's opacity, 0% to 100%, to see the DAW behind it; the interface size, 70% to 200%; and the preset menu, which loads and saves presets and copies and pastes them between instances.

Support

For technical support, updates, and additional information:

Website: ravegeneration.io

Email: support@ravegeneration.io

© 2026 Rave Generation. All rights reserved.

All product names, trademarks and registered trademarks are the property of their respective owners. Names are used for identification purposes only and do not imply any affiliation with or endorsement by the trademark holders.