Rave Generation

presents



TubEQ

User Manual

1. Overview

TubEQ is an equalizer with a tube stage. Its low section is modeled on the Pultec EQP-1A, its six bands on the Maag EQ4, and after them sits a tube stage modeled on a 12AX7.

With every knob at 0 and Tube Level at 0 the sound passes untouched. Each section comes in as you turn its knobs up.

2. Signal Flow

INPUT → LOW SECTION → EQ BANDS → TUBE → AUTO GAIN → OUTPUT → 0dB CLIP

TubEQ works in mono and stereo and adds no latency.

3. Low Section

LF BOOST

Lifts the lows below the LF Band frequency, 0 to 10: about 8 dB at 5 and 16 dB at 10. Default 0.

LF ATTEN

Cuts the lows below the LF Band frequency, 0 to 10: about 8 dB at 5 and 19 dB at 10. Default 0.

Turned up together, LF Boost and LF Atten keep a lift in the deep lows and add a gentle dip of about 2 dB around ten times the LF Band frequency.

LF BAND

Sets where the boost and the cut start: 20, 30, 60 or 100 Hz. Default 60 Hz.

4. EQ Bands

10 HZ, 40 HZ, 160 HZ, 650 HZ

Boost or cut a broad band around each frequency, -5 to +5. The boosts are strong: about +10 dB at +3 and +17 dB at +5. The cuts reach about -4 to -5 dB. Default 0.

2.5 KHZ

Boosts or cuts everything above about 2.5 kHz, -5 to +5: about +13 dB at +3 and +20 dB at +5, down to about -6 dB. Default 0.

AIR GAIN

Lifts the top above the Air Band frequency, 0 to 10. Gentle up to 5, about +3 dB at the top, and strong above: about +12 dB at 8 and +18 dB at 10. Default 0.

AIR BAND

Sets where the air lift starts: Off, 2.5, 5, 10, 15, 20 or 40 kHz. 15 kHz is an extra position between 10 and 20 kHz. Default 10 kHz.

STEPS

The small switch at the top left of the section. On, the six knobs above click to 21 steps, as on the original; off, they turn freely. Switching on moves each knob to its nearest step, and switching off returns it to where it was. Default Off.

Besides its own boost or cut, every band raises or lowers the whole range a little. Auto Gain takes that part back off.

5. Tube

TUBE IN

How hard the signal drives the tube, 0 to 1. It also sets the level: 0.25 is about 5 dB quieter than 0.5, and 1.0 about 6 dB louder. With Tube Level at 0 it does nothing. Default 0.5.

TUBE LEVEL

The amount of tube, 0 to 1: harmonics and gentle compression. At 0 the tube is off; it fades in up to 0.2 and gets heavier and louder toward 1.0, so match the level with Output. Default 0.

6. Output

OUTPUT

The final level, -12 to +12 dB. Default 0 dB.

AUTO GAIN

On, takes back off what the EQ bands add to or take from the whole range, so everything they do not touch stays at its level and only their own boosts and cuts change the sound. The low section and the tube are not affected. Default Off.

0dB CLIP

Clips the output at 0 dBFS, after Output. Below 0 dBFS nothing changes. Default Off.

EFFECT IN

Off passes the input through untouched, Output and 0dB Clip included. Default On.

Menu Bar

Undo and Redo, the preset menu with the factory presets, the panel’s opacity and the interface size.

Support

For technical support, updates, and additional information:

Website: ravegeneration.io

Email: support@ravegeneration.io

© 2026 Rave Generation. All rights reserved.

All product names, trademarks and registered trademarks are the property of their respective owners. Names are used only to identify hardware and software studied during the development of this plugin, and do not imply any affiliation with, endorsement by, sponsorship by or licensing from the trademark holders.