Procedure MP-7: quarterly pump check (synthetic)

1. Switch off the pump at the local isolator and lock it off.
2. Close the suction and delivery valves.
    1. Close the suction valve fully.
    2. Close the delivery valve fully.
    3. Open the drain cock and let the casing empty.
3. Remove the coupling guard and check the coupling for wear.
4. Check the mechanical seal.
    1. Look for leaks at the seal housing.
    2. Replace the seal if more than ten drops per minute leak.
5. Refit the guard, open the valves and remove the lock.

Record the result in the maintenance log.