

Quick Reference Guide

Reset Instructions

APPLIES TO

DW 450, DW 500, DW C-200, DW T-400/IR, DW T-100

OVERVIEW

This guide gives instructions on how to reset your DreamWriter if the device locks up (freezes) or won't turn off.

INSTRUCTIONS

The most typical cause of a DreamWriter freezing is the DreamWriter's battery charge being allowed to run very low or the unit is not being charged correctly. Without the appropriate charge in the battery, insufficient power is provided to the DreamWriter's systems causing sporadic and in some cases, unpredictable behaviour to occur.

The best way to avoid this issue is to ensure that the DreamWriter is placed on a charging system when the low battery indicator is first presented to the user. In addition, you may wish to consider purchasing new batteries every school year to ensure that you don't have "dead" batteries (i.e., unable to properly charge). Rechargeable batteries will lose approx. 1% of their charging capacity each time they are fully charged, so their shelf-life in a normal school is usually no more than 12 months.

To unfreeze the unit, you will need to perform a reset of the device. There are two types of reset; a soft reset and a battery removal (hard) reset. You should first attempt the soft reset, and only if that does not work, perform the hard reset.

SOFT RESET

A soft reset will cause all documents in the Working Memory to be lost, but files in the Built-in Memory will not be lost.

1. Turn the DreamWriter off. If the DreamWriter will not power off using the power button you will have to briefly remove the NiCad battery to interrupt the power.
2. If you removed the battery to turn the unit off, plug it back in but do not turn the unit on.
3. Press and hold the **F**, **J**, and **Spacebar** keys with one hand and then simultaneously press and hold the **power** button.
4. You should see the word "diagnostic" appear on the upper left side of the screen. If this message does not appear, continue to hold the **F**, **J**, and **Spacebar** keys and toggle the **power** button until it does appear.
5. Release all the keys.

6. Press and hold the **CTRL** key and simultaneously press the **WP** key. The Unit will reinitialize.

The Diagnostic and Initialize screens are the indicators that the reset has completed successfully. If the Diagnostic and Initialize screens do not appear, you will need to perform the BATTERY REMOVAL RESET outlined below.

BATTERY REMOVAL (HARD) RESET

By performing a battery removal (hard) reset, all documents/files/custom settings stored on the DreamWriter will be lost and the DreamWriter will be returned to default factory settings.

1. Taking care not to damage the connector on the Nicad battery pack, remove both the Nicad battery pack AND the small round lithium battery from the DreamWriter for a minimum of 60 minutes (overnight is best).
2. After the waiting period, and with the batteries still removed, connect the DreamWriter A/C adapter to the DreamWriter and then plug it into the electrical socket.
3. Make sure that the DreamWriter is turned off.
4. Press and hold the **F, J**, and **Spacebar** keys; at the same time, press and hold the **power** button.
5. You should see the word "diagnostic" appear on the upper left side of the screen. If this message does not appear, continue to hold the **F, J**, and **Spacebar** keys and toggle the **power** button until it does appear.
6. Release all the keys.
7. Press and hold the **CTRL** key and simultaneously press the **WP** key. The Unit will reinitialize.
8. Replace both the Nicad battery pack and the lithium battery taking care to install them correctly.

Best practice after a hard reset is to charge the unit overnight or power it with the AC adapter until you can charge it fully.