



RTAL-AudioDSP-Release

```
1 #include "
2
3 void setup
4 {
5     RTALBo
6 }
7
8 void loop
9 {
10     delay
11 }
```

ola

:

NV

Ungültige Bibliothek

Ungültige Bibliothek

Ungültige Bibliothek

Automatische Formatierung Strg+T

Sketch archivieren

Kodierung korrigieren & neu laden

Bibliotheken verwalten... Strg+Umsch

Serieller Monitor Strg+Umscha

Serieller Plotter Strg+Umscha

ESP32 LittleFS Data Upload

ESP32 Partition Tool

ESP32 Sketch Data Upload

ESP8266 Sketch Data Upload

Teensy 4 Security

WiFi101 / WiFinINA Firmware Updater

ESP32 Sketch Data Upload

Board: "ESP32S3 Dev Module"

Upload Speed: "921600"

USB Mode: "Hardware CDC and JTAG"

USB CDC On Boot: "Disabled"

USB Firmware MSC On Boot: "Disabled"

USB DFU On Boot: "Disabled"

Upload Mode: "UART0 / Hardware CDC"

CPU Frequency: "240MHz (WiFi)"

Flash Mode: "QIO 120MHz"

Flash Size: "4MB (32Mb)"

Partition Scheme: "Huge APP (3MB No OTA/1MB SPIFFS)"

Core Debug Level: "Keine"

PSRAM: "OPI PSRAM"

Arduino Runs On: "Core 1"

Events Run On: "Core 1"

Erase All Flash Before Sketch Upload: "Disabled"

JTAG Adapter: "Disabled"

Port: "COM12"

Boardinformationen holen

Programmer

Bootloader brennen