

Description of STM32F4xx HAL drivers

Introduction

STM32Cube™ is an STMicroelectronics original initiative to ease developers life by reducing development efforts, time and cost. STM32Cube™ covers STM32 portfolio.

STM32Cube™ Version 1.x includes:

- The STM32CubeMX, a graphical software configuration tool that allows generating C initialization code using graphical wizards.
- A comprehensive embedded software platform, delivered per series (such as STM32CubeF4 for STM32F4 series)
 - The STM32Cube HAL, an STM32 abstraction layer embedded software, ensuring maximized portability across STM32 portfolio
 - A consistent set of middleware components such as RTOS, USB, TCP/IP, Graphics
 - All embedded software utilities coming with a full set of examples.

The HAL drivers layer provides a generic multi instance simple set of APIs (application programming interfaces) to interact with the upper layer (application, libraries and stacks). It is composed of generic and extension APIs. It is directly built around a generic architecture and allows the built-upon layers, such as the middleware layer, to implement their functions without knowing in-depth how to use the MCU. This structure improves the library code reusability and guarantees an easy portability on other devices.

The HAL drivers include a complete set of ready-to-use APIs which simplify the user application implementation. As an example, the communication peripherals contain APIs to initialize and configure the peripheral, to manage data transfers based on polling, to handle interrupts or DMA, and to manage communication errors.

The HAL drivers APIs are split into two categories: generic APIs which provide common and generic functions for all the STM32 series and extension APIs which include specific and customized functions for a given family or part number.

The HAL drivers are feature-oriented instead of IP-oriented. As an example, the timer APIs are split into several categories following the functions offered by the IP: basic timer, capture, pulse width modulation (PWM), etc..

The drivers source code is developed in Strict ANSI-C which makes it independent from the development tools. It is checked with CodeSonar™ static analysis tool. It is fully documented and is MISRA-C 2004 compliant.

The HAL drivers layer implements run-time failure detection by checking the input values of all functions. Such dynamic checking contributes to enhance the firmware robustness. Run-time detection is also suitable for user application development and debugging.

This user manual is structured as follows:

- Overview of the HAL drivers
- Detailed description of each peripheral driver: configuration structures, functions, and how to use the given API to build your application.



Contents

1 Acronyms and definitions.....	59
2 Overview of HAL drivers	61
2.1 HAL and user-application files.....	61
2.1.1 HAL driver files	61
2.1.2 User-application files	63
2.2 HAL data structures	64
2.2.1 Peripheral handle structures	65
2.2.2 Initialization and configuration structure	66
2.2.3 Specific process structures	66
2.3 API classification	66
2.4 Devices supported by HAL drivers	68
2.5 HAL drivers rules.....	70
2.5.1 HAL API naming rules	70
2.5.2 HAL general naming rules	71
2.5.3 HAL interrupt handler and callback functions.....	72
2.6 HAL generic APIs.....	73
2.7 HAL extension APIs	74
2.7.1 HAL extension model overview	74
2.7.2 HAL extension model cases	75
2.8 File inclusion model.....	77
2.9 HAL common resources.....	77
2.10 HAL configuration.....	78
2.11 HAL system peripheral handling	79
2.11.1 Clock.....	79
2.11.2 GPIOs.....	80
2.11.3 Cortex NVIC and SysTick timer.....	82
2.11.4 PWR	82
2.11.5 EXTI.....	83
2.11.6 DMA.....	84
2.12 How to use HAL drivers	85
2.12.1 HAL usage models	85
2.12.2 HAL initialization	86
2.12.3 HAL IO operation process	88
2.12.4 Timeout and error management.....	91
3 HAL System Driver	96

3.1	HAL System Driver.....	96
3.2	HAL Firmware driver API description	96
3.2.1	How to use this driver	96
3.2.2	Initialization and de-initialization functions	96
3.2.3	HAL Control functions.....	96
3.2.4	HAL_Init.....	97
3.2.5	HAL_Delnit	97
3.2.6	HAL_MspInit.....	97
3.2.7	HAL_MspDeInit	98
3.2.8	HAL_InitTick	98
3.2.9	HAL_IncTick	98
3.2.10	HAL_GetTick	98
3.2.11	HAL_Delay	98
3.2.12	HAL_SuspendTick.....	99
3.2.13	HAL_ResumeTick.....	99
3.2.14	HAL_GetHalVersion	99
3.2.15	HAL_GetREVID	99
3.2.16	HAL_GetDEVID	99
3.2.17	HAL_DBGMCU_EnableDBGSleepMode	100
3.2.18	HAL_DBGMCU_DisableDBGSleepMode	100
3.2.19	HAL_DBGMCU_EnableDBGStopMode	100
3.2.20	HAL_DBGMCU_DisableDBGStopMode	100
3.2.21	HAL_DBGMCU_EnableDBGStandbyMode	100
3.2.22	HAL_DBGMCU_DisableDBGStandbyMode	100
3.2.23	HAL_EnableCompensationCell	100
3.2.24	HAL_DisableCompensationCell	101
3.2.25	HAL_EnableMemorySwappingBank	101
3.2.26	HAL_DisableMemorySwappingBank	101
3.3	HAL Firmware driver defines.....	101
3.3.1	HAL.....	101
4	HAL ADC Generic Driver.....	104
4.1	HAL ADC Generic Driver	104
4.2	ADC Firmware driver registers structures	104
4.2.1	ADC_InitTypeDef.....	104
4.2.2	ADC_HandleTypeDef.....	105
4.2.3	ADC_ChannelConfTypeDef	106
4.2.4	ADC_AnalogWDGConfTypeDef.....	106

4.3	ADC Firmware driver API description.....	107
4.3.1	ADC Peripheral features.....	107
4.3.2	How to use this driver	107
4.3.3	Initialization and de-initialization functions	109
4.3.4	IO operation functions	110
4.3.5	Peripheral Control functions	110
4.3.6	Peripheral State and errors functions.....	110
4.3.7	HAL_ADC_Init	110
4.3.8	HAL_ADC_DelInit.....	111
4.3.9	HAL_ADC_MspInit	111
4.3.10	HAL_ADC_MspDeInit.....	111
4.3.11	HAL_ADC_Start	111
4.3.12	HAL_ADC_Stop.....	112
4.3.13	HAL_ADC_PollForConversion	112
4.3.14	HAL_ADC_PollForEvent	112
4.3.15	HAL_ADC_Start_IT	112
4.3.16	HAL_ADC_Stop_IT	113
4.3.17	HAL_ADC_IRQHandler.....	113
4.3.18	HAL_ADC_Start_DMA	113
4.3.19	HAL_ADC_Stop_DMA.....	113
4.3.20	HAL_ADC_GetValue	114
4.3.21	HAL_ADC_ConvCpltCallback	114
4.3.22	HAL_ADC_ConvHalfCpltCallback	114
4.3.23	HAL_ADC_LevelOutOfWindowCallback	114
4.3.24	HAL_ADC_ErrorCallback	114
4.3.25	HAL_ADC_ConfigChannel	115
4.3.26	HAL_ADC_AnalogWDGConfig	115
4.3.27	HAL_ADC_GetState.....	115
4.3.28	HAL_ADC_GetError	115
4.4	ADC Firmware driver defines	116
4.4.1	ADC	116
5	HAL ADC Extension Driver	124
5.1	HAL ADC Extension Driver	124
5.2	ADCEx Firmware driver registers structures	124
5.2.1	ADC_InjectionConfTypeDef	124
5.2.2	ADC_MultiModeTypeDef.....	125
5.3	ADCEx Firmware driver API description	125
5.3.1	How to use this driver	125

5.3.2	Extended features functions	126
5.3.3	HAL_ADCEx_InjectedStart	127
5.3.4	HAL_ADCEx_InjectedStart_IT	127
5.3.5	HAL_ADCEx_InjectedStop.....	127
5.3.6	HAL_ADCEx_InjectedPollForConversion	128
5.3.7	HAL_ADCEx_InjectedStop_IT	128
5.3.8	HAL_ADCEx_InjectedGetValue	128
5.3.9	HAL_ADCEx_MultiModeStart_DMA	128
5.3.10	HAL_ADCEx_MultiModeStop_DMA.....	129
5.3.11	HAL_ADCEx_MultiModeGetValue	129
5.3.12	HAL_ADCEx_InjectedConvCpltCallback	129
5.3.13	HAL_ADCEx_InjectedConfigChannel	129
5.3.14	HAL_ADCEx_MultiModeConfigChannel	130
5.4	ADCEx Firmware driver defines	130
5.4.1	ADCEx	130
6	HAL CAN Generic Driver.....	133
6.1	HAL CAN Generic Driver	133
6.2	CAN Firmware driver registers structures	133
6.2.1	CAN_InitTypeDef.....	133
6.2.2	CAN_FilterConfTypeDef.....	134
6.2.3	CanTxMsgTypeDef.....	135
6.2.4	CanRxMsgTypeDef	135
6.2.5	CAN_HandleTypeDef	136
6.3	CAN Firmware driver API description.....	137
6.3.1	How to use this driver	137
6.3.2	Initialization and de-initialization functions	138
6.3.3	IO operation functions	138
6.3.4	Peripheral State and Error functions	138
6.3.5	HAL_CAN_Init	139
6.3.6	HAL_CAN_ConfigFilter.....	139
6.3.7	HAL_CAN_DeInit.....	139
6.3.8	HAL_CAN_MspInit	139
6.3.9	HAL_CAN_MspDeInit.....	139
6.3.10	HAL_CAN_Transmit	140
6.3.11	HAL_CAN_Transmit_IT.....	140
6.3.12	HAL_CAN_Receive	140
6.3.13	HAL_CAN_Receive_IT.....	140
6.3.14	HAL_CAN_Sleep.....	140

6.3.15	HAL_CAN_WakeUp	141
6.3.16	HAL_CAN_IRQHandler	141
6.3.17	HAL_CAN_TxCpltCallback	141
6.3.18	HAL_CAN_RxCpltCallback	141
6.3.19	HAL_CAN_ErrorCallback	141
6.3.20	HAL_CAN_GetState	142
6.3.21	HAL_CAN_GetError	142
6.4	CAN Firmware driver defines	142
6.4.1	CAN	142
7	HAL CEC Generic Driver	150
7.1	HAL CEC Generic Driver	150
7.2	CEC Firmware driver registers structures	150
7.2.1	CEC_InitTypeDef	150
7.2.2	CEC_HandleTypeDef	151
7.3	CEC Firmware driver API description.....	152
7.3.1	How to use this driver	152
7.3.2	Initialization and Configuration functions	152
7.3.3	IO operation functions	152
7.3.4	Peripheral Control function	153
7.3.5	HAL_CEC_Init	153
7.3.6	HAL_CEC_DelInit	153
7.3.7	HAL_CEC_MspInit	153
7.3.8	HAL_CEC_MspDeInit	153
7.3.9	HAL_CEC_Transmit	153
7.3.10	HAL_CEC_Receive	154
7.3.11	HAL_CEC_Transmit_IT	154
7.3.12	HAL_CEC_Receive_IT	154
7.3.13	HAL_CEC_GetReceivedFrameSize	155
7.3.14	HAL_CEC_IRQHandler	155
7.3.15	HAL_CEC_TxCpltCallback	155
7.3.16	HAL_CEC_RxCpltCallback	155
7.3.17	HAL_CEC_ErrorCallback	155
7.3.18	HAL_CEC_GetState	155
7.3.19	HAL_CEC_GetError	156
7.4	CEC Firmware driver defines	156
7.4.1	CEC	156
8	HAL CORTEX Generic Driver.....	166

8.1	HAL CORTEX Generic Driver	166
8.2	CORTEX Firmware driver registers structures	166
8.2.1	MPU_Region_InitTypeDef.....	166
8.3	CORTEX Firmware driver API description	167
8.3.1	How to use this driver	167
8.3.2	Initialization and de-initialization functions	168
8.3.3	Peripheral Control functions	168
8.3.4	HAL_NVIC_SetPriorityGrouping	168
8.3.5	HAL_NVIC_SetPriority	168
8.3.6	HAL_NVIC_EnableIRQ	169
8.3.7	HAL_NVIC_DisableIRQ.....	169
8.3.8	HAL_NVIC_SystemReset.....	169
8.3.9	HAL_SYSTICK_Config.....	169
8.3.10	HAL_MPUIConfigRegion.....	170
8.3.11	HAL_NVIC_GetPriorityGrouping	170
8.3.12	HAL_NVIC_GetPriority	170
8.3.13	HAL_NVIC_SetPendingIRQ	170
8.3.14	HAL_NVIC_GetPendingIRQ	171
8.3.15	HAL_NVIC_ClearPendingIRQ.....	171
8.3.16	HAL_NVIC_GetActive	171
8.3.17	HAL_SYSTICK_CLKSourceConfig	171
8.3.18	HAL_SYSTICK_IRQHandler	172
8.3.19	HAL_SYSTICK_Callback	172
8.4	CORTEX Firmware driver defines	172
8.4.1	CORTEX.....	172
9	HAL CRC Generic Driver.....	176
9.1	HAL CRC Generic Driver	176
9.2	CRC Firmware driver registers structures	176
9.2.1	CRC_HandleTypeDef.....	176
9.3	CRC Firmware driver API description	176
9.3.1	How to use this driver	176
9.3.2	Initialization and de-initialization functions	176
9.3.3	Peripheral Control functions	177
9.3.4	Peripheral State functions	177
9.3.5	HAL_CRC_Init	177
9.3.6	HAL_CRC_DelInit	177
9.3.7	HAL_CRC_MspInit	177

9.3.8	HAL_CRC_MspDeInit.....	177
9.3.9	HAL_CRC_Accumulate.....	178
9.3.10	HAL_CRC_Calculate.....	178
9.3.11	HAL_CRC_GetState.....	178
9.4	CRC Firmware driver defines	178
9.4.1	CRC	178
10	HAL CRYP Generic Driver.....	180
10.1	HAL CRYP Generic Driver	180
10.2	CRYP Firmware driver registers structures	180
10.2.1	CRYP_InitTypeDef	180
10.2.2	CRYP_HandleTypeDef.....	181
10.3	CRYP Firmware driver API description	181
10.3.1	How to use this driver	181
10.3.2	Initialization and de-initialization functions	182
10.3.3	AES processing functions	182
10.3.4	DES processing functions	183
10.3.5	TDES processing functions	184
10.3.6	DMA callback functions	184
10.3.7	CRYP IRQ handler management.....	184
10.3.8	Peripheral State functions	184
10.3.9	HAL_CRYP_Init.....	184
10.3.10	HAL_CRYP_Delnit	185
10.3.11	HAL_CRYP_MspInit	185
10.3.12	HAL_CRYP_MspDeInit	185
10.3.13	HAL_CRYP_AESECB_Encrypt.....	185
10.3.14	HAL_CRYP_AESCBC_Encrypt	186
10.3.15	HAL_CRYP_AESCTR_Encrypt.....	186
10.3.16	HAL_CRYP_AESECB_Decrypt	186
10.3.17	HAL_CRYP_AESCBC_Decrypt	186
10.3.18	HAL_CRYP_AESCTR_Decrypt	187
10.3.19	HAL_CRYP_AESECB_Encrypt_IT	187
10.3.20	HAL_CRYP_AESCBC_Encrypt_IT	187
10.3.21	HAL_CRYP_AESCTR_Encrypt_IT	188
10.3.22	HAL_CRYP_AESECB_Decrypt_IT	188
10.3.23	HAL_CRYP_AESCBC_Decrypt_IT	188
10.3.24	HAL_CRYP_AESCTR_Decrypt_IT	189
10.3.25	HAL_CRYP_AESECB_Encrypt_DMA.....	189
10.3.26	HAL_CRYP_AESCBC_Encrypt_DMA	189

10.3.27	HAL_CRYP_AESCTR_Encrypt_DMA.....	189
10.3.28	HAL_CRYP_AESECB_Decrypt_DMA	190
10.3.29	HAL_CRYP_AESCBC_Decrypt_DMA	190
10.3.30	HAL_CRYP_AESCTR_Decrypt_DMA	190
10.3.31	HAL_CRYP_DESECB_Encrypt	191
10.3.32	HAL_CRYP_DESECB_Decrypt	191
10.3.33	HAL_CRYP_DESCBC_Encrypt	191
10.3.34	HAL_CRYP_DESCBC_Decrypt	191
10.3.35	HAL_CRYP_DESECB_Encrypt_IT	192
10.3.36	HAL_CRYP_DESCBC_Encrypt_IT	192
10.3.37	HAL_CRYP_DESECB_Decrypt_IT	192
10.3.38	HAL_CRYP_DESCBC_Decrypt_IT	193
10.3.39	HAL_CRYP_DESECB_Encrypt_DMA	193
10.3.40	HAL_CRYP_DESCBC_Encrypt_DMA	193
10.3.41	HAL_CRYP_DESECB_Decrypt_DMA	194
10.3.42	HAL_CRYP_DESCBC_Decrypt_DMA	194
10.3.43	HAL_CRYP_TDESECB_Encrypt	194
10.3.44	HAL_CRYP_TDESECB_Decrypt	194
10.3.45	HAL_CRYP_TDESCBC_Encrypt	195
10.3.46	HAL_CRYP_TDESCBC_Decrypt	195
10.3.47	HAL_CRYP_TDESECB_Encrypt_IT	195
10.3.48	HAL_CRYP_TDESCBC_Encrypt_IT	196
10.3.49	HAL_CRYP_TDESECB_Decrypt_IT	196
10.3.50	HAL_CRYP_TDESCBC_Decrypt_IT	196
10.3.51	HAL_CRYP_TDESECB_Encrypt_DMA	196
10.3.52	HAL_CRYP_TDESCBC_Encrypt_DMA	197
10.3.53	HAL_CRYP_TDESECB_Decrypt_DMA	197
10.3.54	HAL_CRYP_TDESCBC_Decrypt_DMA	197
10.3.55	HAL_CRYP_InCpltCallback	198
10.3.56	HAL_CRYP_OutCpltCallback	198
10.3.57	HAL_CRYP_ErrorCallback	198
10.3.58	HAL_CRYP_IRQHandler.....	198
10.3.59	HAL_CRYP_GetState	198
10.4	CRYP Firmware driver defines.....	199
10.4.1	CRYP	199
11	HAL CRYP Extension Driver.....	203
11.1	HAL CRYP Extension Driver	203
11.2	CRYPEx Firmware driver API description	203

11.2.1	How to use this driver	203
11.2.2	Extended AES processing functions	204
11.2.3	CRYPEx IRQ handler management.....	204
11.2.4	HAL_CRYPEx_AESCCM_Encrypt.....	204
11.2.5	HAL_CRYPEx_AESGCM_Encrypt	205
11.2.6	HAL_CRYPEx_AESGCM_Decrypt	205
11.2.7	HAL_CRYPEx_AESGCM_Finish.....	205
11.2.8	HAL_CRYPEx_AESCCM_Finish	205
11.2.9	HAL_CRYPEx_AESCCM_Decrypt	206
11.2.10	HAL_CRYPEx_AESGCM_Encrypt_IT	206
11.2.11	HAL_CRYPEx_AESCCM_Encrypt_IT	206
11.2.12	HAL_CRYPEx_AESGCM_Decrypt_IT	207
11.2.13	HAL_CRYPEx_AESCCM_Decrypt_IT	207
11.2.14	HAL_CRYPEx_AESGCM_Encrypt_DMA	207
11.2.15	HAL_CRYPEx_AESCCM_Encrypt_DMA.....	208
11.2.16	HAL_CRYPEx_AESGCM_Decrypt_DMA	208
11.2.17	HAL_CRYPEx_AESCCM_Decrypt_DMA	208
11.2.18	HAL_CRYPEx_GCMCCM_IRQHandler.....	208
11.3	CRYPEx Firmware driver defines.....	209
11.3.1	CRYPEx	209
12	HAL DAC Generic Driver	210
12.1	HAL DAC Generic Driver	210
12.2	DAC Firmware driver registers structures	210
12.2.1	DAC_HandleTypeDef	210
12.2.2	DAC_ChannelConfTypeDef	210
12.3	DAC Firmware driver API description.....	211
12.3.1	DAC Peripheral features.....	211
12.3.2	How to use this driver	212
12.3.3	Initialization and de-initialization functions	213
12.3.4	IO operation functions	213
12.3.5	Peripheral Control functions	213
12.3.6	Peripheral State and Errors functions	213
12.3.7	HAL_DAC_Init	214
12.3.8	HAL_DAC_DelInit.....	214
12.3.9	HAL_DAC_MspInit	214
12.3.10	HAL_DAC_MspDelInit.....	214
12.3.11	HAL_DAC_Start	215
12.3.12	HAL_DAC_Stop.....	215

12.3.13	HAL_DAC_Start_DMA	215
12.3.14	HAL_DAC_Stop_DMA.....	215
12.3.15	HAL_DAC_GetValue	216
12.3.16	HAL_DAC_IRQHandler.....	216
12.3.17	HAL_DAC_ConvCpltCallbackCh1	216
12.3.18	HAL_DAC_ConvHalfCpltCallbackCh1	216
12.3.19	HAL_DAC_ErrorCallbackCh1	217
12.3.20	HAL_DAC_DMAUnderrunCallbackCh1	217
12.3.21	HAL_DAC_ConfigChannel	217
12.3.22	HAL_DAC_SetValue	217
12.3.23	HAL_DAC_GetState.....	218
12.3.24	HAL_DAC_GetError	218
12.3.25	HAL_DAC_IRQHandler.....	218
12.3.26	HAL_DAC_ConvCpltCallbackCh1	218
12.3.27	HAL_DAC_ConvHalfCpltCallbackCh1	218
12.3.28	HAL_DAC_ErrorCallbackCh1	219
12.3.29	HAL_DAC_DMAUnderrunCallbackCh1	219
12.4	DAC Firmware driver defines	219
12.4.1	DAC	219
13	HAL DAC Extension Driver	224
13.1	HAL DAC Extension Driver	224
13.2	DACEEx Firmware driver API description	224
13.2.1	How to use this driver	224
13.2.2	Extended features functions	224
13.2.3	HAL_DACEEx_DualGetValue	224
13.2.4	HAL_DACEEx_TriangleWaveGenerate	224
13.2.5	HAL_DACEEx_NoiseWaveGenerate	225
13.2.6	HAL_DACEEx_DualSetValue.....	226
13.2.7	HAL_DACEEx_ConvCpltCallbackCh2	226
13.2.8	HAL_DACEEx_ConvHalfCpltCallbackCh2	226
13.2.9	HAL_DACEEx_ErrorCallbackCh2	227
13.2.10	HAL_DACEEx_DMAUnderrunCallbackCh2	227
13.3	DACEEx Firmware driver defines	227
13.3.1	DACEx	227
14	HAL DCMI Generic Driver	229
14.1	HAL DCMI Generic Driver	229
14.2	DCMI Firmware driver registers structures.....	229

14.2.1	DCMI_HandleTypeDef	229
14.3	DCMI Firmware driver API description	230
14.3.1	How to use this driver	230
14.3.2	Initialization and Configuration functions	230
14.3.3	IO operation functions	230
14.3.4	Peripheral Control functions	231
14.3.5	Peripheral State and Errors functions	231
14.3.6	HAL_DCMI_Init.....	231
14.3.7	HAL_DCMI_DeInit	231
14.3.8	HAL_DCMI_MspInit.....	232
14.3.9	HAL_DCMI_MspDeInit	232
14.3.10	HAL_DCMI_Start_DMA.....	232
14.3.11	HAL_DCMI_Stop	232
14.3.12	HAL_DCMI_IRQHandler	232
14.3.13	HAL_DCMI_ErrorCallback	233
14.3.14	HAL_DCMI_LineEventCallback	233
14.3.15	HAL_DCMI_VsyncEventCallback	233
14.3.16	HAL_DCMI_FrameEventCallback	233
14.3.17	HAL_DCMI_ConfigCROP.....	233
14.3.18	HAL_DCMI_DisableCROP	234
14.3.19	HAL_DCMI_EnableCROP	234
14.3.20	HAL_DCMI_GetState	234
14.3.21	HAL_DCMI_GetError.....	234
14.4	DCMI Firmware driver defines.....	235
14.4.1	DCMI.....	235
15	HAL DCMI Extension Driver.....	240
15.1	HAL DCMI Extension Driver.....	240
15.2	DCMIEEx Firmware driver registers structures.....	240
15.2.1	DCMI_CodesInitTypeDef.....	240
15.2.2	DCMI_InitTypeDef	240
15.3	DCMIEEx Firmware driver API description	241
15.3.1	DCMI peripheral extension features.....	241
15.3.2	How to use this driver	241
15.3.3	Initialization and Configuration functions	241
15.3.4	HAL_DCMI_Init.....	242
15.4	DCMIEEx Firmware driver defines	242
15.4.1	DCMIEEx	242

16 HAL DMA2D Generic Driver	243
16.1 HAL DMA2D Generic Driver.....	243
16.2 DMA2D Firmware driver registers structures	243
16.2.1 DMA2D_ColorTypeDef.....	243
16.2.2 DMA2D_CLUTCfgTypeDef	243
16.2.3 DMA2D_InitTypeDef.....	244
16.2.4 DMA2D_LayerCfgTypeDef.....	244
16.2.5 __DMA2D_HandleTypeDef	244
16.3 DMA2D Firmware driver API description.....	245
16.3.1 How to use this driver.....	245
16.3.2 Initialization and Configuration functions.....	246
16.3.3 IO operation functions	247
16.3.4 Peripheral Control functions	247
16.3.5 Peripheral State and Errors functions	247
16.3.6 HAL_DMA2D_Init	248
16.3.7 HAL_DMA2D_DelInit.....	248
16.3.8 HAL_DMA2D_MspInit	248
16.3.9 HAL_DMA2D_MspDelInit.....	248
16.3.10 HAL_DMA2D_Start	248
16.3.11 HAL_DMA2D_Start_IT	249
16.3.12 HAL_DMA2D_BlendingStart	249
16.3.13 HAL_DMA2D_BlendingStart_IT	249
16.3.14 HAL_DMA2D_Abort	250
16.3.15 HAL_DMA2D_Suspend.....	250
16.3.16 HAL_DMA2D_Resume.....	250
16.3.17 HAL_DMA2D_PollForTransfer	250
16.3.18 HAL_DMA2D_IRQHandler	251
16.3.19 HAL_DMA2D_ConfigLayer	251
16.3.20 HAL_DMA2D_ConfigCLUT	251
16.3.21 HAL_DMA2D_EnableCLUT	251
16.3.22 HAL_DMA2D_DisableCLUT	252
16.3.23 HAL_DMA2D_ProgramLineEvent	252
16.3.24 HAL_DMA2D_GetState.....	252
16.3.25 HAL_DMA2D_GetError	252
16.4 DMA2D Firmware driver defines	253
16.4.1 DMA2D	253
17 HAL DMA Generic Driver	259

Contents	UM1725
17.1 HAL DMA Generic Driver	259
17.2 DMA Firmware driver registers structures	259
17.2.1 DMA_InitTypeDef	259
17.2.2 __DMA_HandleTypeDef	260
17.3 DMA Firmware driver API description	261
17.3.1 How to use this driver	261
17.3.2 Initialization and de-initialization functions	262
17.3.3 IO operation functions	262
17.3.4 State and Errors functions	263
17.3.5 HAL_DMA_Init	263
17.3.6 HAL_DMA_DeInit	263
17.3.7 HAL_DMA_Start	263
17.3.8 HAL_DMA_Start_IT	264
17.3.9 HAL_DMA_Abort	264
17.3.10 HAL_DMA_PollForTransfer	264
17.3.11 HAL_DMA_IRQHandler	265
17.3.12 HAL_DMA_GetState	265
17.3.13 HAL_DMA_GetError	265
17.4 DMA Firmware driver defines	265
17.4.1 DMA	265
18 HAL DMA Extension Driver	269
18.1 HAL DMA Extension Driver	269
18.2 DMAEx Firmware driver API description	269
18.2.1 How to use this driver	269
18.2.2 Extended features functions	269
18.2.3 HAL_DMAEx_MultiBufferStart	269
18.2.4 HAL_DMAEx_MultiBufferStart_IT	269
18.2.5 HAL_DMAEx_ChangeMemory	270
18.3 DMAEx Firmware driver defines	270
18.3.1 DMAEx	270
19 HAL DSI Generic Driver	271
19.1 HAL DSI Generic Driver	271
19.2 DSI Firmware driver registers structures	271
19.2.1 DSI_InitTypeDef	271
19.2.2 DSI_PLLInitTypeDef	271
19.2.3 DSI_VidCfgTypeDef	271
19.2.4 DSI_CmdCfgTypeDef	273

19.2.5	DSI_LPCmdTypeDef	274
19.2.6	DSI_PHY_TimerTypeDef	275
19.2.7	DSI_HOST_TimeoutTypeDef	276
19.2.8	DSI_HandleTypeDef.....	277
19.3	DSI Firmware driver API description	277
19.3.1	Initialization and Configuration functions	277
19.3.2	IO operation functions	278
19.3.3	Peripheral Control functions	278
19.3.4	Peripheral State and Errors functions	279
19.3.5	HAL_DSI_Init.....	279
19.3.6	HAL_DSI_DelInit	279
19.3.7	HAL_DSI_GetError.....	279
19.3.8	HAL_DSI_ConfigErrorMonitor	279
19.3.9	HAL_DSI_MspInit	280
19.3.10	HAL_DSI_MspDelInit	280
19.3.11	HAL_DSI_IRQHandler.....	280
19.3.12	HAL_DSI_TearingEffectCallback	280
19.3.13	HAL_DSI_EndOfRefreshCallback.....	280
19.3.14	HAL_DSI_ErrorCallback.....	281
19.3.15	HAL_DSI_SetGenericVCID	281
19.3.16	HAL_DSI_ConfigVideoMode	281
19.3.17	HAL_DSI_ConfigAdaptedCommandMode	281
19.3.18	HAL_DSI_ConfigCommand	281
19.3.19	HAL_DSI_ConfigFlowControl.....	282
19.3.20	HAL_DSI_ConfigPhyTimer.....	282
19.3.21	HAL_DSI_ConfigHostTimeouts	282
19.3.22	HAL_DSI_Start.....	282
19.3.23	HAL_DSI_Stop	283
19.3.24	HAL_DSI_Refresh	283
19.3.25	HAL_DSI_ColorMode	283
19.3.26	HAL_DSI_Shutdown.....	283
19.3.27	HAL_DSI_ShortWrite.....	284
19.3.28	HAL_DSI_LongWrite	284
19.3.29	HAL_DSI_Read	284
19.3.30	HAL_DSI_EnterULPMDData	285
19.3.31	HAL_DSI_ExitULPMDData.....	285
19.3.32	HAL_DSI_EnterULPM	285
19.3.33	HAL_DSI_ExitULPM.....	285

19.3.34	HAL_DSI_PatternGeneratorStart	285
19.3.35	HAL_DSI_PatternGeneratorStop	286
19.3.36	HAL_DSI_SetSlewRateAndDelayTuning	286
19.3.37	HAL_DSI_SetLowPowerRXFilter	286
19.3.38	HAL_DSI_SetSDD	286
19.3.39	HAL_DSI_SetLane Pins Configuration	287
19.3.40	HAL_DSI_SetPHYTimings	287
19.3.41	HAL_DSI_ForceTXStopMode	287
19.3.42	HAL_DSI_ForceRXLowPower	288
19.3.43	HAL_DSI_ForceDataLanesInRX	288
19.3.44	HAL_DSI_SetPullDown	288
19.3.45	HAL_DSI_SetContentionDetectionOff	288
19.3.46	HAL_DSI_GetState	288
19.4	DSI Firmware driver defines	289
19.4.1	DSI	289
20	HAL ETH Generic Driver	298
20.1	HAL ETH Generic Driver	298
20.2	ETH Firmware driver registers structures	298
20.2.1	ETH_InitTypeDef	298
20.2.2	ETH_MACInitTypeDef	298
20.2.3	ETH_DMAMainTypeDef	301
20.2.4	ETH_DMADescTypeDef	302
20.2.5	ETH_DMARxFrameInfos	303
20.2.6	ETH_HandleTypeDef	304
20.3	ETH Firmware driver API description	304
20.3.1	How to use this driver	304
20.3.2	Initialization and de-initialization functions	305
20.3.3	IO operation functions	305
20.3.4	Peripheral Control functions	306
20.3.5	Peripheral State functions	306
20.3.6	HAL_ETH_Init	306
20.3.7	HAL_ETH_DeInit	306
20.3.8	HAL_ETH_DMATxDescListInit	306
20.3.9	HAL_ETH_DMARxDescListInit	307
20.3.10	HAL_ETH_MspInit	307
20.3.11	HAL_ETH_MspDeInit	307
20.3.12	HAL_ETH_TransmitFrame	307
20.3.13	HAL_ETH_GetReceivedFrame	307

20.3.14	HAL_ETH_GetReceivedFrame_IT	308
20.3.15	HAL_ETH_IRQHandler	308
20.3.16	HAL_ETH_TxCpltCallback	308
20.3.17	HAL_ETH_RxCpltCallback.....	308
20.3.18	HAL_ETH_ErrorCallback.....	308
20.3.19	HAL_ETH_ReadPHYRegister.....	309
20.3.20	HAL_ETH_WritePHYRegister	309
20.3.21	HAL_ETH_Start.....	309
20.3.22	HAL_ETH_Stop	309
20.3.23	HAL_ETH_ConfigMAC	310
20.3.24	HAL_ETH_ConfigDMA.....	310
20.3.25	HAL_ETH_GetState	310
20.4	ETH Firmware driver defines.....	310
20.4.1	ETH.....	310
21	HAL FLASH Generic Driver.....	342
21.1	HAL FLASH Generic Driver.....	342
21.2	FLASH Firmware driver registers structures	342
21.2.1	FLASH_ProcessTypeDef	342
21.3	FLASH Firmware driver API description.....	342
21.3.1	FLASH peripheral features	342
21.3.2	How to use this driver	343
21.3.3	Programming operation functions	343
21.3.4	Peripheral Control functions	343
21.3.5	Peripheral Errors functions	343
21.3.6	HAL_FLASH_Program	344
21.3.7	HAL_FLASH_Program_IT	344
21.3.8	HAL_FLASH_IRQHandler	344
21.3.9	HAL_FLASH_EndOfOperationCallback	344
21.3.10	HAL_FLASH_OperationErrorHandler	344
21.3.11	HAL_FLASH_Unlock.....	345
21.3.12	HAL_FLASH_Lock	345
21.3.13	HAL_FLASH_OB_Unlock.....	345
21.3.14	HAL_FLASH_OB_Lock	345
21.3.15	HAL_FLASH_OB_Launch.....	345
21.3.16	HAL_FLASH_GetError	345
21.3.17	FLASH_WaitForLastOperation.....	346
21.4	FLASH Firmware driver defines	346

21.4.1	FLASH	346
22	HAL FLASH Extension Driver	352
22.1	HAL FLASH Extension Driver	352
22.2	FLASHEx Firmware driver registers structures	352
22.2.1	FLASH_EraseInitTypeDef	352
22.2.2	FLASH_OBProgramInitTypeDef	352
22.2.3	FLASH_AdvOBProgramInitTypeDef	353
22.3	FLASHEx Firmware driver API description.....	354
22.3.1	Flash Extension features.....	354
22.3.2	How to use this driver	354
22.3.3	Extended programming operation functions	354
22.3.4	HAL_FLASHEx_Erase	355
22.3.5	HAL_FLASHEx_Erase_IT	355
22.3.6	HAL_FLASHEx_OBProgram.....	355
22.3.7	HAL_FLASHEx_OBGetConfig	355
22.3.8	HAL_FLASHEx_AdvOBProgram	355
22.3.9	HAL_FLASHEx_AdvOBGetConfig	356
22.3.10	HAL_FLASHEx_OB_SelectPCROP.....	356
22.3.11	HAL_FLASHEx_OB_DeSelectPCROP	356
22.3.12	HAL_FLASHEx_OB_GetBank2WRP	357
22.4	FLASHEx Firmware driver defines	357
22.4.1	FLASHEx	357
23	HAL FLASH__RAMFUNC Generic Driver.....	362
23.1	HAL FLASH__RAMFUNC Generic Driver.....	362
23.2	FLASH__RAMFUNC Firmware driver API description	362
23.2.1	APIs executed from Internal RAM	362
23.2.2	ramfunc functions	362
23.2.3	HAL_FLASHEx_StopFlashInterfaceClk	362
23.2.4	HAL_FLASHEx_StartFlashInterfaceClk	362
23.2.5	HAL_FLASHEx_EnableFlashSleepMode	363
23.2.6	HAL_FLASHEx_DisableFlashSleepMode.....	363
23.3	FLASH__RAMFUNC Firmware driver defines	363
23.3.1	FLASH__RAMFUNC	363
24	HAL FMP12C Generic Driver	364
24.1	HAL FMP12C Generic Driver	364
24.2	FMP12C Firmware driver registers structures.....	364
24.2.1	FMP12C_InitTypeDef	364

24.2.2	FMPI2C_HandleTypeDef	365
24.3	FMPI2C Firmware driver API description	365
24.3.1	Initialization and de-initialization functions	365
24.3.2	IO operation functions	366
24.3.3	Peripheral State and Errors functions	367
24.3.4	HAL_FMPI2C_Init.....	367
24.3.5	HAL_FMPI2C_DelInit.....	367
24.3.6	HAL_FMPI2C_MspInit.....	368
24.3.7	HAL_FMPI2C_MspDeInit	368
24.3.8	HAL_FMPI2C_Master_Transmit	368
24.3.9	HAL_FMPI2C_Master_Receive	368
24.3.10	HAL_FMPI2C_Slave_Transmit	369
24.3.11	HAL_FMPI2C_Slave_Receive	369
24.3.12	HAL_FMPI2C_Master_Transmit_IT	369
24.3.13	HAL_FMPI2C_Master_Receive_IT	370
24.3.14	HAL_FMPI2C_Slave_Transmit_IT	370
24.3.15	HAL_FMPI2C_Slave_Receive_IT	370
24.3.16	HAL_FMPI2C_Master_Transmit_DMA	370
24.3.17	HAL_FMPI2C_Master_Receive_DMA	371
24.3.18	HAL_FMPI2C_Slave_Transmit_DMA	371
24.3.19	HAL_FMPI2C_Slave_Receive_DMA	371
24.3.20	HAL_FMPI2C_Mem_Write	372
24.3.21	HAL_FMPI2C_Mem_Read	372
24.3.22	HAL_FMPI2C_Mem_Write_IT	372
24.3.23	HAL_FMPI2C_Mem_Read_IT	373
24.3.24	HAL_FMPI2C_Mem_Write_DMA.....	373
24.3.25	HAL_FMPI2C_Mem_Read_DMA.....	374
24.3.26	HAL_FMPI2C_IsDeviceReady	374
24.3.27	HAL_FMPI2C_EV_IRQHandler	374
24.3.28	HAL_FMPI2C_ER_IRQHandler	374
24.3.29	HAL_FMPI2C_MasterTxCpltCallback	375
24.3.30	HAL_FMPI2C_MasterRxCpltCallback.....	375
24.3.31	HAL_FMPI2C_SlaveTxCpltCallback	375
24.3.32	HAL_FMPI2C_SlaveRxCpltCallback.....	375
24.3.33	HAL_FMPI2C_MemTxCpltCallback	375
24.3.34	HAL_FMPI2C_MemRxCpltCallback	376
24.3.35	HAL_FMPI2C_ErrorCallback	376
24.3.36	HAL_FMPI2C_GetState	376

24.3.37	HAL_FMPI2C_GetError.....	376
24.4	FMPI2C Firmware driver defines.....	377
24.4.1	FMPI2C	377
25	HAL FMPI2C Extension Driver.....	383
25.1	HAL FMPI2C Extension Driver.....	383
25.2	FMPI2CEEx Firmware driver API description	383
25.2.1	Extension features functions	383
25.2.2	HAL_FMPI2CEEx_AnalogFilter_Config	383
25.2.3	HAL_FMPI2CEEx_DigitalFilter_Config.....	383
25.2.4	HAL_FMPI2CEEx_EnableWakeUp	383
25.2.5	HAL_FMPI2CEEx_DisableWakeUp	384
25.2.6	HAL_FMPI2CEEx_EnableFastModePlus.....	384
25.2.7	HAL_FMPI2CEEx_DisableFastModePlus.....	384
25.3	FMPI2CEEx Firmware driver defines	384
25.3.1	FMPI2CEEx	384
26	HAL GPIO Generic Driver.....	385
26.1	HAL GPIO Generic Driver	385
26.2	GPIO Firmware driver registers structures	385
26.2.1	GPIO_InitTypeDef	385
26.3	GPIO Firmware driver API description	385
26.3.1	GPIO Peripheral features	385
26.3.2	How to use this driver	386
26.3.3	Initialization and de-initialization functions	386
26.3.4	IO operation functions	387
26.3.5	HAL_GPIO_Init.....	387
26.3.6	HAL_GPIO_DelInit	387
26.3.7	HAL_GPIO_ReadPin.....	387
26.3.8	HAL_GPIO_WritePin	388
26.3.9	HAL_GPIO_TogglePin	388
26.3.10	HAL_GPIO_LockPin.....	388
26.3.11	HAL_GPIO_EXTI_IRQHandler	389
26.3.12	HAL_GPIO_EXTI_Callback.....	389
26.4	GPIO Firmware driver defines.....	389
26.4.1	GPIO	389
27	HAL GPIO Extension Driver.....	394
27.1	HAL GPIO Extension Driver	394
27.2	GPIOEx Firmware driver defines.....	394

27.2.1	GPIOEx	394
28	HAL HASH Generic Driver	395
28.1	HAL HASH Generic Driver	395
28.2	HASH Firmware driver registers structures	395
28.2.1	HASH_InitTypeDef	395
28.2.2	HASH_HandleTypeDef.....	395
28.3	HASH Firmware driver API description	396
28.3.1	How to use this driver	396
28.3.2	HASH processing using polling mode functions	397
28.3.3	HASH processing using interrupt mode functions.....	397
28.3.4	HASH processing using DMA mode functions	397
28.3.5	HMAC processing using polling mode functions	398
28.3.6	HMAC processing using DMA mode functions	398
28.3.7	Peripheral State functions	398
28.3.8	Initialization and de-initialization functions	398
28.3.9	HAL_HASH_MD5_Start	399
28.3.10	HAL_HASH_MD5_Accumulate	399
28.3.11	HAL_HASH_SHA1_Start.....	399
28.3.12	HAL_HASH_SHA1_Accumulate	400
28.3.13	HAL_HASH_MD5_Start_IT	400
28.3.14	HAL_HASH_SHA1_Start_IT	400
28.3.15	HAL_HASH_IRQHandler.....	401
28.3.16	HAL_HMAC_SHA1_Start.....	401
28.3.17	HAL_HMAC_MD5_Start.....	401
28.3.18	HAL_HASH_MD5_Start_DMA	401
28.3.19	HAL_HASH_MD5_Finish	402
28.3.20	HAL_HASH_SHA1_Start_DMA	402
28.3.21	HAL_HASH_SHA1_Finish	402
28.3.22	HAL_HASH_SHA1_Start_IT	403
28.3.23	HAL_HASH_MD5_Start_IT	403
28.3.24	HAL_HMAC_MD5_Start.....	403
28.3.25	HAL_HMAC_SHA1_Start.....	404
28.3.26	HAL_HASH_SHA1_Start_DMA	404
28.3.27	HAL_HASH_SHA1_Finish	404
28.3.28	HAL_HASH_MD5_Start_DMA	404
28.3.29	HAL_HASH_MD5_Finish	405
28.3.30	HAL_HMAC_MD5_Start_DMA.....	405
28.3.31	HAL_HMAC_SHA1_Start_DMA.....	405

28.3.32	HAL_HASH_GetState	406
28.3.33	HAL_HASH_IRQHandler.....	406
28.3.34	HAL_HASH_Init.....	406
28.3.35	HAL_HASH_DeInit	406
28.3.36	HAL_HASH_MspInit	406
28.3.37	HAL_HASH_MspDeInit	407
28.3.38	HAL_HASH_InCpltCallback	407
28.3.39	HAL_HASH_ErrorCallback.....	407
28.3.40	HAL_HASH_DgstCpltCallback.....	407
28.3.41	HAL_HASH_GetState	407
28.3.42	HAL_HASH_MspInit	408
28.3.43	HAL_HASH_MspDeInit	408
28.3.44	HAL_HASH_InCpltCallback	408
28.3.45	HAL_HASH_DgstCpltCallback.....	408
28.3.46	HAL_HASH_ErrorCallback.....	408
28.4	HASH Firmware driver defines.....	409
28.4.1	HASH.....	409
29	HAL HASH Extension Driver.....	412
29.1	HAL HASH Extension Driver	412
29.2	HASHEx Firmware driver API description	412
29.2.1	How to use this driver	412
29.2.2	HASH processing using polling mode functions	413
29.2.3	HMAC processing using polling mode functions	413
29.2.4	HASH processing using interrupt functions.....	413
29.2.5	HASH processing using DMA functions	413
29.2.6	HMAC processing using DMA functions	414
29.2.7	HAL_HASHEx_SHA224_Start	414
29.2.8	HAL_HASHEx_SHA256_Start	414
29.2.9	HAL_HASHEx_SHA224_Accumulate	414
29.2.10	HAL_HASHEx_SHA256_Accumulate	415
29.2.11	HAL_HMACEx_SHA224_Start.....	415
29.2.12	HAL_HMACEx_SHA256_Start.....	415
29.2.13	HAL_HASHEx_SHA224_Start_IT	416
29.2.14	HAL_HASHEx_SHA256_Start_IT	416
29.2.15	HAL_HASHEx_IRQHandler	416
29.2.16	HAL_HASHEx_SHA224_Start_DMA	417
29.2.17	HAL_HASHEx_SHA224_Finish	417
29.2.18	HAL_HASHEx_SHA256_Start_DMA	417

29.2.19	HAL_HASHEx_SHA256_Finish	417
29.2.20	HAL_HMACEx_SHA224_Start_DMA.....	418
29.2.21	HAL_HMACEx_SHA256_Start_DMA.....	418
29.2.22	HAL_HASHEx_SHA224_Start	418
29.2.23	HAL_HASHEx_SHA256_Start	419
29.2.24	HAL_HASHEx_SHA224_Accumulate	419
29.2.25	HAL_HASHEx_SHA256_Accumulate	419
29.2.26	HAL_HMACEx_SHA224_Start.....	419
29.2.27	HAL_HMACEx_SHA256_Start.....	420
29.2.28	HAL_HASHEx_SHA224_Start_IT	420
29.2.29	HAL_HASHEx_SHA256_Start_IT	420
29.2.30	HAL_HASHEx_SHA224_Start_DMA	421
29.2.31	HAL_HASHEx_SHA224_Finish	421
29.2.32	HAL_HASHEx_SHA256_Start_DMA	421
29.2.33	HAL_HASHEx_SHA256_Finish	422
29.2.34	HAL_HMACEx_SHA224_Start_DMA.....	422
29.2.35	HAL_HMACEx_SHA256_Start_DMA.....	422
29.2.36	HAL_HASHEx_IRQHandler	423
29.3	HASHEx Firmware driver defines.....	423
29.3.1	HASHEx	423
30	HAL HCD Generic Driver.....	424
30.1	HAL HCD Generic Driver	424
30.2	HCD Firmware driver registers structures	424
30.2.1	HCD_HandleTypeDef.....	424
30.3	HCD Firmware driver API description	424
30.3.1	How to use this driver	424
30.3.2	Initialization and de-initialization functions	425
30.3.3	IO operation functions	425
30.3.4	Peripheral Control functions	425
30.3.5	Peripheral State functions	425
30.3.6	HAL_HCD_Init	425
30.3.7	HAL_HCD_HC_Init.....	426
30.3.8	HAL_HCD_HC_Halt	426
30.3.9	HAL_HCD_DeInit	426
30.3.10	HAL_HCD_MspInit	427
30.3.11	HAL_HCD_MspDeInit.....	427
30.3.12	HAL_HCD_HC_SubmitRequest.....	427
30.3.13	HAL_HCD_IRQHandler.....	427

30.3.14	HAL_HCD_SOF_Callback	427
30.3.15	HAL_HCD_Connect_Callback	428
30.3.16	HAL_HCD_Disconnect_Callback	428
30.3.17	HAL_HCD_HC_NotifyURBChange_Callback	428
30.3.18	HAL_HCD_Start	428
30.3.19	HAL_HCD_Stop	428
30.3.20	HAL_HCD_ResetPort	429
30.3.21	HAL_HCD_GetState	429
30.3.22	HAL_HCD_HC_GetURBState	429
30.3.23	HAL_HCD_HC_GetXferCount	429
30.3.24	HAL_HCD_HC_GetState	429
30.3.25	HAL_HCD_GetCurrentFrame	430
30.3.26	HAL_HCD_GetCurrentSpeed	430
30.4	HCD Firmware driver defines	430
30.4.1	HCD	430
31	HAL I2C Generic Driver	432
31.1	HAL I2C Generic Driver	432
31.2	I2C Firmware driver registers structures	432
31.2.1	I2C_InitTypeDef	432
31.2.2	I2C_HandleTypeDef	432
31.3	I2C Firmware driver API description	433
31.3.1	How to use this driver	433
31.3.2	Initialization and de-initialization functions	436
31.3.3	IO operation functions	436
31.3.4	Peripheral State and Errors functions	438
31.3.5	HAL_I2C_Init	438
31.3.6	HAL_I2C_DeInit	438
31.3.7	HAL_I2C_MspInit	438
31.3.8	HAL_I2C_MspDeInit	438
31.3.9	HAL_I2C_Master_Transmit	439
31.3.10	HAL_I2C_Master_Receive	439
31.3.11	HAL_I2C_Slave_Transmit	439
31.3.12	HAL_I2C_Slave_Receive	440
31.3.13	HAL_I2C_Master_Transmit_IT	440
31.3.14	HAL_I2C_Master_Receive_IT	440
31.3.15	HAL_I2C_Slave_Transmit_IT	440
31.3.16	HAL_I2C_Slave_Receive_IT	441
31.3.17	HAL_I2C_Master_Transmit_DMA	441

31.3.18	HAL_I2C_Master_Receive_DMA.....	441
31.3.19	HAL_I2C_Slave_Transmit_DMA.....	441
31.3.20	HAL_I2C_Slave_Receive_DMA.....	442
31.3.21	HAL_I2C_Mem_Write.....	442
31.3.22	HAL_I2C_Mem_Read	442
31.3.23	HAL_I2C_Mem_Write_IT	443
31.3.24	HAL_I2C_Mem_Read_IT	443
31.3.25	HAL_I2C_Mem_Write_DMA	443
31.3.26	HAL_I2C_Mem_Read_DMA	444
31.3.27	HAL_I2C_IsDeviceReady.....	444
31.3.28	HAL_I2C_EV_IRQHandler	444
31.3.29	HAL_I2C_ER_IRQHandler.....	445
31.3.30	HAL_I2C_MasterTxCpltCallback.....	445
31.3.31	HAL_I2C_MasterRxCpltCallback	445
31.3.32	HAL_I2C_SlaveTxCpltCallback.....	445
31.3.33	HAL_I2C_SlaveRxCpltCallback	445
31.3.34	HAL_I2C_MemTxCpltCallback.....	445
31.3.35	HAL_I2C_MemRxCpltCallback	446
31.3.36	HAL_I2C_ErrorCallback	446
31.3.37	HAL_I2C_GetState	446
31.3.38	HAL_I2C_GetError	446
31.4	I2C Firmware driver defines	446
31.4.1	I2C	446
32	HAL I2C Extension Driver	453
32.1	HAL I2C Extension Driver	453
32.2	I2CEx Firmware driver API description	453
32.2.1	I2C peripheral extension features	453
32.2.2	How to use this driver	453
32.2.3	Extension features functions	453
32.2.4	HAL_I2CEx_ConfigAnalogFilter	453
32.2.5	HAL_I2CEx_ConfigDigitalFilter	453
32.3	I2CEx Firmware driver defines	454
32.3.1	I2CEx	454
33	HAL I2S Generic Driver	455
33.1	HAL I2S Generic Driver.....	455
33.2	I2S Firmware driver registers structures	455
33.2.1	I2S_InitTypeDef.....	455

33.2.2	I2S_HandleTypeDef	455
33.3	I2S Firmware driver API description	456
33.3.1	How to use this driver	456
33.3.2	Initialization and de-initialization functions	458
33.3.3	IO operation functions	458
33.3.4	Peripheral State and Errors functions	459
33.3.5	HAL_I2S_Init	459
33.3.6	HAL_I2S_DelInit	460
33.3.7	HAL_I2S_MspInit	460
33.3.8	HAL_I2S_MspDelInit	460
33.3.9	HAL_I2S_Transmit	460
33.3.10	HAL_I2S_Receive	460
33.3.11	HAL_I2S_Transmit_IT	461
33.3.12	HAL_I2S_Receive_IT	461
33.3.13	HAL_I2S_Transmit_DMA	462
33.3.14	HAL_I2S_Receive_DMA	462
33.3.15	HAL_I2S_DMAPause	463
33.3.16	HAL_I2S_DMAResume	463
33.3.17	HAL_I2S_DMAStop	463
33.3.18	HAL_I2S_IRQHandler	463
33.3.19	HAL_I2S_TxHalfCpltCallback	463
33.3.20	HAL_I2S_TxCpltCallback	464
33.3.21	HAL_I2S_RxHalfCpltCallback	464
33.3.22	HAL_I2S_RxCpltCallback	464
33.3.23	HAL_I2S_ErrorCallback	464
33.3.24	HAL_I2S_GetState	464
33.3.25	HAL_I2S_GetError	464
33.3.26	HAL_I2S_SetState	465
33.3.27	HAL_I2S_SetError	465
33.4	I2S Firmware driver defines	465
33.4.1	I2S	465
34	HAL I2S Extension Driver	470
34.1	HAL I2S Extension Driver	470
34.2	I2SEEx Firmware driver API description	470
34.2.1	I2S Extension features	470
34.2.2	How to use this driver	470
34.2.3	Extension features Functions	471
34.2.4	HAL_I2S_Init	471

34.2.5	HAL_I2SEEx_TransmitReceive	472
34.2.6	HAL_I2SEEx_TransmitReceive_IT	472
34.2.7	HAL_I2SEEx_TransmitReceive_DMA	473
34.2.8	HAL_I2S_DMAPause	473
34.2.9	HAL_I2S_DMAResume	473
34.2.10	HAL_I2S_DMAStop	473
34.2.11	HAL_I2S_IRQHandler	474
34.2.12	HAL_I2SEEx_TransmitReceive	474
34.2.13	HAL_I2SEEx_TransmitReceive_IT	474
34.2.14	HAL_I2SEEx_TransmitReceive_DMA	475
34.3	I2SEEx Firmware driver defines	475
34.3.1	I2SEEx	475
35	HAL IRDA Generic Driver	476
35.1	HAL IRDA Generic Driver	476
35.2	IRDA Firmware driver registers structures	476
35.2.1	IRDA_InitTypeDef	476
35.2.2	IRDA_HandleTypeDef	476
35.3	IRDA Firmware driver API description	477
35.3.1	How to use this driver	477
35.3.2	Initialization and Configuration functions	478
35.3.3	IO operation functions	479
35.3.4	Peripheral State and Errors functions	480
35.3.5	HAL_IRDA_Init	480
35.3.6	HAL_IRDA_DeInit	480
35.3.7	HAL_IRDA_MspInit	481
35.3.8	HAL_IRDA_MspDeInit	481
35.3.9	HAL_IRDA_Transmit	481
35.3.10	HAL_IRDA_Receive	481
35.3.11	HAL_IRDA_Transmit_IT	482
35.3.12	HAL_IRDA_Receive_IT	482
35.3.13	HAL_IRDA_Transmit_DMA	482
35.3.14	HAL_IRDA_Receive_DMA	482
35.3.15	HAL_IRDA_DMAPause	483
35.3.16	HAL_IRDA_DMAResume	483
35.3.17	HAL_IRDA_DMAStop	483
35.3.18	HAL_IRDA_IRQHandler	483
35.3.19	HAL_IRDA_TxCpltCallback	483
35.3.20	HAL_IRDA_TxHalfCpltCallback	484

Contents	UM1725
35.3.21 HAL_IRDA_RxCpltCallback	484
35.3.22 HAL_IRDA_RxHalfCpltCallback.....	484
35.3.23 HAL_IRDA_ErrorCallback	484
35.3.24 HAL_IRDA_GetState.....	484
35.3.25 HAL_IRDA_GetError	485
35.4 IRDA Firmware driver defines	485
35.4.1 IRDA	485
36 HAL IWDG Generic Driver.....	492
36.1 HAL IWDG Generic Driver	492
36.2 IWDG Firmware driver registers structures	492
36.2.1 IWDG_InitTypeDef	492
36.2.2 IWDG_HandleTypeDef.....	492
36.3 IWDG Firmware driver API description	492
36.3.1 IWDG Specific features	492
36.3.2 How to use this driver	493
36.3.3 Initialization and de-initialization functions	494
36.3.4 IO operation functions	494
36.3.5 Peripheral State functions	494
36.3.6 HAL_IWDG_Init	494
36.3.7 HAL_IWDG_MspInit	494
36.3.8 HAL_IWDG_Start	494
36.3.9 HAL_IWDG_Refresh	495
36.3.10 HAL_IWDG_GetState.....	495
36.4 IWDG Firmware driver defines	495
36.4.1 IWDG	495
37 HAL LPTIM Generic Driver.....	498
37.1 HAL LPTIM Generic Driver.....	498
37.2 LPTIM Firmware driver registers structures	498
37.2.1 LPTIM_ClockConfigTypeDef	498
37.2.2 LPTIM_ULPClockConfigTypeDef.....	498
37.2.3 LPTIM_TriggerConfigTypeDef	498
37.2.4 LPTIM_InitTypeDef.....	499
37.2.5 LPTIM_HandleTypeDef.....	499
37.3 LPTIM Firmware driver API description.....	500
37.3.1 How to use this driver	500
37.3.2 Initialization and de-initialization functions	501
37.3.3 LPTIM Start Stop operation functions	501

37.3.4	LPTIM Read operation functions	502
37.3.5	LPTIM IRQ handler.....	502
37.3.6	Peripheral State functions	503
37.3.7	HAL_LPTIM_Init	503
37.3.8	HAL_LPTIM_DelInit.....	503
37.3.9	HAL_LPTIM_MspInit	503
37.3.10	HAL_LPTIM_MspDeInit.....	503
37.3.11	HAL_LPTIM_PWM_Start.....	503
37.3.12	HAL_LPTIM_PWM_Stop.....	504
37.3.13	HAL_LPTIM_PWM_Start_IT	504
37.3.14	HAL_LPTIM_PWM_Stop_IT	504
37.3.15	HAL_LPTIM_OnePulse_Start	504
37.3.16	HAL_LPTIM_OnePulse_Stop.....	504
37.3.17	HAL_LPTIM_OnePulse_Start_IT	505
37.3.18	HAL_LPTIM_OnePulse_Stop_IT	505
37.3.19	HAL_LPTIM_SetOnce_Start	505
37.3.20	HAL_LPTIM_SetOnce_Stop	505
37.3.21	HAL_LPTIM_SetOnce_Start_IT	506
37.3.22	HAL_LPTIM_SetOnce_Stop_IT	506
37.3.23	HAL_LPTIM_Encoder_Start.....	506
37.3.24	HAL_LPTIM_Encoder_Stop	506
37.3.25	HAL_LPTIM_Encoder_Start_IT.....	506
37.3.26	HAL_LPTIM_Encoder_Stop_IT.....	507
37.3.27	HAL_LPTIM_TimeOut_Start	507
37.3.28	HAL_LPTIM_TimeOut_Stop.....	507
37.3.29	HAL_LPTIM_TimeOut_Start_IT	507
37.3.30	HAL_LPTIM_TimeOut_Stop_IT	508
37.3.31	HAL_LPTIM_Counter_Start	508
37.3.32	HAL_LPTIM_Counter_Stop.....	508
37.3.33	HAL_LPTIM_Counter_Start_IT	508
37.3.34	HAL_LPTIM_Counter_Stop_IT	508
37.3.35	HAL_LPTIM_ReadCounter	509
37.3.36	HAL_LPTIM_ReadAutoReload	509
37.3.37	HAL_LPTIM_ReadCompare	509
37.3.38	HAL_LPTIM_IRQHandler.....	509
37.3.39	HAL_LPTIM_CompareMatchCallback	509
37.3.40	HAL_LPTIM_AutoReloadMatchCallback	509
37.3.41	HAL_LPTIM_TriggerCallback.....	510

37.3.42	HAL_LPTIM_CompareWriteCallback	510
37.3.43	HAL_LPTIM_AutoReloadWriteCallback	510
37.3.44	HAL_LPTIM_DirectionUpCallback	510
37.3.45	HAL_LPTIM_DirectionDownCallback	510
37.3.46	HAL_LPTIM_GetState	511
37.4	LPTIM Firmware driver defines	511
37.4.1	LPTIM	511
38	HAL LTDC Generic Driver	522
38.1	HAL LTDC Generic Driver	522
38.2	LTDC Firmware driver registers structures	522
38.2.1	LTDC_ColorTypeDef	522
38.2.2	LTDC_InitTypeDef	522
38.2.3	LTDC_LayerCfgTypeDef	523
38.2.4	LTDC_HandleTypeDef	524
38.3	LTDC Firmware driver API description	525
38.3.1	How to use this driver	525
38.3.2	Initialization and Configuration functions	526
38.3.3	IO operation functions	526
38.3.4	Peripheral Control functions	526
38.3.5	Peripheral State and Errors functions	527
38.3.6	HAL_LTDC_Init	527
38.3.7	HAL_LTDC_DeInit	527
38.3.8	HAL_LTDC_MspInit	527
38.3.9	HAL_LTDC_MspDeInit	528
38.3.10	HAL_LTDC_ErrorCallback	528
38.3.11	HAL_LTDC_LineEventCallback	528
38.3.12	HAL_LTDC_IRQHandler	528
38.3.13	HAL_LTDC_ErrorCallback	528
38.3.14	HAL_LTDC_LineEventCallback	529
38.3.15	HAL_LTDC_ConfigLayer	529
38.3.16	HAL_LTDC_ConfigColorKeying	529
38.3.17	HAL_LTDC_ConfigCLUT	529
38.3.18	HAL_LTDC_EnableColorKeying	530
38.3.19	HAL_LTDC_DisableColorKeying	530
38.3.20	HAL_LTDC_EnableCLUT	530
38.3.21	HAL_LTDC_DisableCLUT	530
38.3.22	HAL_LTDC_EnableDither	531
38.3.23	HAL_LTDC_DisableDither	531

38.3.24	HAL_LTDC_SetWindowSize	531
38.3.25	HAL_LTDC_SetWindowPosition	531
38.3.26	HAL_LTDC_SetPixelFormat	531
38.3.27	HAL_LTDC_SetAlpha	532
38.3.28	HAL_LTDC_SetAddress	532
38.3.29	HAL_LTDC_SetPitch	532
38.3.30	HAL_LTDC_ProgramLineEvent	533
38.3.31	HAL_LTDC_GetState	533
38.3.32	HAL_LTDC_GetError	533
38.4	LTDC Firmware driver defines	533
38.4.1	LTDC	533
39	HAL LTDC Extension Driver	540
39.1	HAL LTDC Extension Driver	540
39.2	LTDCEx Firmware driver API description	540
39.2.1	Initialization and Configuration functions	540
39.2.2	HAL_LTDC_StructInitFromVideoConfig	540
39.2.3	HAL_LTDC_StructInitFromAdaptedCommandConfig	540
39.3	LTDCEx Firmware driver defines	541
40	HAL NAND Generic Driver	542
40.1	HAL NAND Generic Driver	542
40.2	NAND Firmware driver registers structures	542
40.2.1	NAND_IDTypeDef	542
40.2.2	NAND_AddressTypeDef	542
40.2.3	NAND_InfoTypeDef	542
40.2.4	NAND_HandleTypeDef	543
40.3	NAND Firmware driver API description	543
40.3.1	How to use this driver	543
40.3.2	NAND Initialization and de-initialization functions	544
40.3.3	NAND Input and Output functions	544
40.3.4	NAND Control functions	545
40.3.5	NAND State functions	545
40.3.6	HAL_NAND_Init	545
40.3.7	HAL_NAND_DelInit	545
40.3.8	HAL_NAND_MspInit	545
40.3.9	HAL_NAND_MspDelInit	546
40.3.10	HAL_NAND_IRQHandler	546
40.3.11	HAL_NAND_ITCallback	546

40.3.12	HAL_NAND_Read_ID	546
40.3.13	HAL_NAND_Reset.....	546
40.3.14	HAL_NAND_Read_Page	546
40.3.15	HAL_NAND_Write_Page.....	547
40.3.16	HAL_NAND_Read_SpareArea	547
40.3.17	HAL_NAND_Write_SpareArea.....	547
40.3.18	HAL_NAND_Erase_Block	548
40.3.19	HAL_NAND_Read_Status	548
40.3.20	HAL_NAND_Address_Inc	548
40.3.21	HAL_NAND_ECC_Enable	548
40.3.22	HAL_NAND_ECC_Disable.....	548
40.3.23	HAL_NAND_GetECC	549
40.3.24	HAL_NAND_GetState	549
40.3.25	HAL_NAND_Read_Status	549
40.4	NAND Firmware driver defines.....	549
40.4.1	NAND.....	549
41	HAL NOR Generic Driver.....	552
41.1	HAL NOR Generic Driver	552
41.2	NOR Firmware driver registers structures	552
41.2.1	NOR_IDTypeDef	552
41.2.2	NOR_CFITypeDef	552
41.2.3	NOR_HandleTypeDef.....	553
41.3	NOR Firmware driver API description	553
41.3.1	How to use this driver	553
41.3.2	NOR Initialization and de_initialization functions	554
41.3.3	NOR Input and Output functions	554
41.3.4	NOR Control functions.....	554
41.3.5	NOR State functions.....	554
41.3.6	HAL_NOR_Init.....	554
41.3.7	HAL_NOR_DelInit	555
41.3.8	HAL_NOR_MspInit	555
41.3.9	HAL_NOR_MspDelInit	555
41.3.10	HAL_NOR_MspWait.....	555
41.3.11	HAL_NOR_Read_ID	555
41.3.12	HAL_NOR_ReturnToReadMode.....	556
41.3.13	HAL_NOR_Read	556
41.3.14	HAL_NOR_Program.....	556
41.3.15	HAL_NOR_ReadBuffer	556

41.3.16	HAL_NOR_ProgramBuffer	557
41.3.17	HAL_NOR_Erase_Block	557
41.3.18	HAL_NOR_Erase_Chip.....	557
41.3.19	HAL_NOR_Read_CFI	557
41.3.20	HAL_NOR_WriteOperation_Enable	557
41.3.21	HAL_NOR_WriteOperation_Disable	558
41.3.22	HAL_NOR_GetState	558
41.3.23	HAL_NOR_GetStatus.....	558
41.4	NOR Firmware driver defines.....	558
41.4.1	NOR.....	558
42	HAL PCCARD Generic Driver	561
42.1	HAL PCCARD Generic Driver	561
42.2	PCCARD Firmware driver registers structures.....	561
42.2.1	PCCARD_HandleTypeDef	561
42.3	PCCARD Firmware driver API description	561
42.3.1	How to use this driver	561
42.3.2	PCCARD Initialization and de-initialization functions	562
42.3.3	PCCARD Input and Output functions	562
42.3.4	PCCARD State functions.....	562
42.3.5	HAL_PCCARD_Init.....	562
42.3.6	HAL_PCCARD_DelInit	563
42.3.7	HAL_PCCARD_MspInit.....	563
42.3.8	HAL_PCCARD_MspDelInit	563
42.3.9	HAL_PCCARD_Read_ID	563
42.3.10	HAL_PCCARD_Read_Sector	563
42.3.11	HAL_PCCARD_Write_Sector	564
42.3.12	HAL_PCCARD_Erase_Sector	564
42.3.13	HAL_PCCARD_Reset	564
42.3.14	HAL_PCCARD_IRQHandler	565
42.3.15	HAL_PCCARD_ITCallback	565
42.3.16	HAL_PCCARD_GetState	565
42.3.17	HAL_PCCARD_GetStatus	565
42.3.18	HAL_PCCARD_ReadStatus	565
42.4	PCCARD Firmware driver defines.....	566
42.4.1	PCCARD	566
43	HAL PCD Generic Driver	568
43.1	HAL PCD Generic Driver	568

43.2	PCD Firmware driver registers structures	568
43.2.1	PCD_HandleTypeDef	568
43.3	PCD Firmware driver API description.....	568
43.3.1	How to use this driver	568
43.3.2	Initialization and de-initialization functions	569
43.3.3	IO operation functions	569
43.3.4	Peripheral Control functions	569
43.3.5	Peripheral State functions	570
43.3.6	HAL_PCD_Init	570
43.3.7	HAL_PCD_DelInit.....	570
43.3.8	HAL_PCD_MspInit	570
43.3.9	HAL_PCD_MspDeInit.....	570
43.3.10	HAL_PCD_Start	570
43.3.11	HAL_PCD_Stop.....	571
43.3.12	HAL_PCD_IRQHandler.....	571
43.3.13	HAL_PCD_DataOutStageCallback	571
43.3.14	HAL_PCD_DataInStageCallback	571
43.3.15	HAL_PCD_SetupStageCallback	571
43.3.16	HAL_PCD_SOFCallback.....	571
43.3.17	HAL_PCD_ResetCallback.....	572
43.3.18	HAL_PCD_SuspendCallback.....	572
43.3.19	HAL_PCD_ResumeCallback.....	572
43.3.20	HAL_PCD_ISOOUTIncompleteCallback.....	572
43.3.21	HAL_PCD_ISOINIncompleteCallback.....	572
43.3.22	HAL_PCD_ConnectCallback.....	573
43.3.23	HAL_PCD_DisconnectCallback	573
43.3.24	HAL_PCD_DevConnect	573
43.3.25	HAL_PCD_DevDisconnect.....	573
43.3.26	HAL_PCD_SetAddress	573
43.3.27	HAL_PCD_EP_Open	573
43.3.28	HAL_PCD_EP_Close	574
43.3.29	HAL_PCD_EP_Receive	574
43.3.30	HAL_PCD_EP_GetRxCount	574
43.3.31	HAL_PCD_EP_Transmit	574
43.3.32	HAL_PCD_EP_SetStall.....	575
43.3.33	HAL_PCD_EP_ClrStall.....	575
43.3.34	HAL_PCD_EP_Flush	575
43.3.35	HAL_PCD_ActivateRemoteWakeUp	575
43.3.36	HAL_PCD_DeActivateRemoteWakeUp.....	575

43.3.37	HAL_PCD_GetState.....	576
43.4	PCD Firmware driver defines	576
43.4.1	PCD	576
44	HAL PCD Extension Driver	578
44.1	HAL PCD Extension Driver	578
44.2	PCDEx Firmware driver API description	578
44.2.1	Extended features functions	578
44.2.2	HAL_PCDEx_SetTxFiFo	578
44.2.3	HAL_PCDEx_SetRxFiFo.....	578
44.2.4	HAL_PCDEx_ActivateLPM	578
44.2.5	HAL_PCDEx_DeActivateLPM.....	578
44.2.6	HAL_PCDEx_LPM_Callback	579
44.3	PCDEx Firmware driver defines	579
44.3.1	PCDEx	579
45	HAL PWR Generic Driver	580
45.1	HAL PWR Generic Driver.....	580
45.2	PWR Firmware driver registers structures	580
45.2.1	PWR_PVDTTypeDef	580
45.3	PWR Firmware driver API description	580
45.3.1	Initialization and de-initialization functions	580
45.3.2	Peripheral Control functions	580
45.3.3	HAL_PWR_Delnit.....	582
45.3.4	HAL_PWR_EnableBkUpAccess	583
45.3.5	HAL_PWR_DisableBkUpAccess.....	583
45.3.6	HAL_PWR_ConfigPVD	583
45.3.7	HAL_PWR_EnablePVD.....	583
45.3.8	HAL_PWR_DisablePVD.....	583
45.3.9	HAL_PWR_EnableWakeUpPin.....	583
45.3.10	HAL_PWR_DisableWakeUpPin	584
45.3.11	HAL_PWR_EnterSLEEPMode.....	584
45.3.12	HAL_PWR_EnterSTOPMode.....	584
45.3.13	HAL_PWR_EnterSTANDBYMode	585
45.3.14	HAL_PWR_PVD_IRQHandler.....	585
45.3.15	HAL_PWR_PVDCallback.....	585
45.3.16	HAL_PWR_EnableSleepOnExit.....	585
45.3.17	HAL_PWR_DisableSleepOnExit	586
45.3.18	HAL_PWR_EnableSEVOnPend	586

45.3.19	HAL_PWR_DisableSEVOnPend.....	586
45.4	PWR Firmware driver defines	586
45.4.1	PWR	586
46	HAL PWR Extension Driver	592
46.1	HAL PWR Extension Driver.....	592
46.2	PWREx Firmware driver API description.....	592
46.2.1	Peripheral extended features functions	592
46.2.2	HAL_PWREx_EnableBkUpReg	593
46.2.3	HAL_PWREx_DisableBkUpReg	593
46.2.4	HAL_PWREx_EnableFlashPowerDown	593
46.2.5	HAL_PWREx_DisableFlashPowerDown.....	593
46.2.6	HAL_PWREx_GetVoltageRange	594
46.2.7	HAL_PWREx_ControlVoltageScaling	594
46.2.8	HAL_PWREx_EnableWakeUpPinPolarityRisingEdge	595
46.2.9	HAL_PWREx_EnableWakeUpPinPolarityFallingEdge	595
46.2.10	HAL_PWREx_EnableOverDrive	595
46.2.11	HAL_PWREx_DisableOverDrive.....	595
46.2.12	HAL_PWREx_EnterUnderDriveSTOPMode	595
46.3	PWREx Firmware driver defines	596
46.3.1	PWREx	596
47	HAL QSPI Generic Driver	600
47.1	HAL QSPI Generic Driver	600
47.2	QSPI Firmware driver registers structures	600
47.2.1	QSPI_InitTypeDef.....	600
47.2.2	QSPI_HandleTypeDef	600
47.2.3	QSPI_CommandTypeDef.....	601
47.2.4	QSPI_AutoPollingTypeDef	602
47.2.5	QSPI_MemoryMappedTypeDef	602
47.3	QSPI Firmware driver API description.....	602
47.3.1	How to use this driver	602
47.3.2	Initialization and Configuration functions	605
47.3.3	IO operation functions	605
47.3.4	Peripheral Control and State functions.....	605
47.3.5	HAL_QSPI_Init	606
47.3.6	HAL_QSPI_DelInit.....	606
47.3.7	HAL_QSPI_MspInit	606
47.3.8	HAL_QSPI_MspDelInit.....	606

47.3.9	HAL_QSPI_IRQHandler	606
47.3.10	HAL_QSPI_Command	607
47.3.11	HAL_QSPI_Command_IT	607
47.3.12	HAL_QSPI_Transmit	607
47.3.13	HAL_QSPI_Receive	607
47.3.14	HAL_QSPI_Transmit_IT	608
47.3.15	HAL_QSPI_Receive_IT	608
47.3.16	HAL_QSPI_Transmit_DMA	608
47.3.17	HAL_QSPI_Receive_DMA	608
47.3.18	HAL_QSPI_AutoPolling	609
47.3.19	HAL_QSPI_AutoPolling_IT	609
47.3.20	HAL_QSPI_MemoryMapped	609
47.3.21	HAL_QSPI_ErrorCallback	610
47.3.22	HAL_QSPI_CmdCpltCallback	610
47.3.23	HAL_QSPI_RxCpltCallback	610
47.3.24	HAL_QSPI_TxCpltCallback	610
47.3.25	HAL_QSPI_RxHalfCpltCallback	610
47.3.26	HAL_QSPI_TxHalfCpltCallback	610
47.3.27	HAL_QSPI_FifoThresholdCallback	611
47.3.28	HAL_QSPI_StatusMatchCallback	611
47.3.29	HAL_QSPI_TimeOutCallback	611
47.3.30	HAL_QSPI_GetState	611
47.3.31	HAL_QSPI_GetError	611
47.3.32	HAL_QSPI_Abort	611
47.3.33	HAL_QSPI_SetTimeout	612
47.3.34	HAL_QSPI_ErrorCallback	612
47.3.35	HAL_QSPI_FifoThresholdCallback	612
47.3.36	HAL_QSPI_CmdCpltCallback	612
47.3.37	HAL_QSPI_RxCpltCallback	612
47.3.38	HAL_QSPI_TxCpltCallback	612
47.3.39	HAL_QSPI_RxHalfCpltCallback	613
47.3.40	HAL_QSPI_TxHalfCpltCallback	613
47.3.41	HAL_QSPI_StatusMatchCallback	613
47.3.42	HAL_QSPI_TimeOutCallback	613
47.3.43	HAL_QSPI_GetState	613
47.3.44	HAL_QSPI_GetError	614
47.3.45	HAL_QSPI_Abort	614
47.3.46	HAL_QSPI_SetTimeout	614

47.4	QSPI Firmware driver defines	614
47.4.1	QSPI	614
48	HAL RCC Generic Driver	622
48.1	HAL RCC Generic Driver	622
48.2	RCC Firmware driver registers structures	622
48.2.1	RCC_OscInitTypeDef	622
48.2.2	RCC_ClkInitTypeDef	622
48.3	RCC Firmware driver API description	623
48.3.1	RCC specific features	623
48.3.2	RCC Limitations	623
48.3.3	Initialization and de-initialization functions	624
48.3.4	Peripheral Control functions	625
48.3.5	HAL_RCC_DeInit	625
48.3.6	HAL_RCC_OscConfig	625
48.3.7	HAL_RCC_ClockConfig	625
48.3.8	HAL_RCC_MCOConfig	626
48.3.9	HAL_RCC_EnableCSS	627
48.3.10	HAL_RCC_DisableCSS	627
48.3.11	HAL_RCC_GetSysClockFreq	627
48.3.12	HAL_RCC_GetHCLKFreq	628
48.3.13	HAL_RCC_GetPCLK1Freq	628
48.3.14	HAL_RCC_GetPCLK2Freq	628
48.3.15	HAL_RCC_GetOscConfig	628
48.3.16	HAL_RCC_GetClockConfig	629
48.3.17	HAL_RCC_NMI_IRQHandler	629
48.3.18	HAL_RCC_CSSCallback	629
48.4	RCC Firmware driver defines	629
48.4.1	RCC	629
49	HAL RCC Extension Driver	647
49.1	HAL RCC Extension Driver	647
49.2	RCCEEx Firmware driver registers structures	647
49.2.1	RCC_PLLInitTypeDef	647
49.2.2	RCC_PLLI2SInitTypeDef	647
49.2.3	RCC_PLLSAllInitTypeDef	648
49.2.4	RCC_PeriphCLKInitTypeDef	648
49.3	RCCEEx Firmware driver API description	649
49.3.1	Extended Peripheral Control functions	649

49.3.2	HAL_RCC_DeInit	650
49.3.3	HAL_RCCEx_PeriphCLKConfig.....	650
49.3.4	HAL_RCCEx_GetPeriphCLKConfig.....	650
49.3.5	HAL_RCC_OscConfig	651
49.3.6	HAL_RCC_GetOscConfig	651
49.3.7	HAL_RCCEx_SelectLSEMode.....	651
49.4	RCCEx Firmware driver defines.....	651
49.4.1	RCCEx.....	651
50	HAL RNG Generic Driver.....	658
50.1	HAL RNG Generic Driver	658
50.2	RNG Firmware driver registers structures	658
50.2.1	RNG_HandleTypeDef.....	658
50.3	RNG Firmware driver API description	658
50.3.1	How to use this driver	658
50.3.2	Initialization and de-initialization functions	658
50.3.3	Peripheral Control functions	659
50.3.4	Peripheral State functions	659
50.3.5	HAL_RNG_Init.....	659
50.3.6	HAL_RNG_DeInit	659
50.3.7	HAL_RNG_MspInit	659
50.3.8	HAL_RNG_MspDeInit	660
50.3.9	HAL_RNG_GenerateRandomNumber	660
50.3.10	HAL_RNG_GenerateRandomNumber_IT.....	660
50.3.11	HAL_RNG_IRQHandler.....	660
50.3.12	HAL_RNG_GetRandomNumber	661
50.3.13	HAL_RNG_GetRandomNumber_IT	661
50.3.14	HAL_RNG_ReadLastRandomNumber.....	661
50.3.15	HAL_RNG_ReadyDataCallback.....	661
50.3.16	HAL_RNG_ErrorCallback.....	662
50.3.17	HAL_RNG_GetState	662
50.4	RNG Firmware driver defines.....	662
50.4.1	RNG.....	662
51	HAL RTC Generic Driver	666
51.1	HAL RTC Generic Driver.....	666
51.2	RTC Firmware driver registers structures	666
51.2.1	RTC_HandleTypeDef.....	666
51.2.2	RTC_TimeTypeDef.....	666

51.2.3	RTC_DateTypeDef	667
51.2.4	RTC_AlarmTypeDef	668
51.2.5	RTC_HandleTypeDef	668
51.3	RTC Firmware driver API description	669
51.3.1	Backup Domain Operating Condition	669
51.3.2	Backup Domain Reset	669
51.3.3	Backup Domain Access	670
51.3.4	How to use this driver	670
51.3.5	RTC and low power modes	670
51.3.6	Initialization and de-initialization functions	670
51.3.7	RTC Time and Date functions	671
51.3.8	RTC Alarm functions	671
51.3.9	Peripheral Control functions	671
51.3.10	Peripheral State functions	672
51.3.11	HAL_RTC_Init	672
51.3.12	HAL_RTC_DelInit	672
51.3.13	HAL_RTC_MspInit	672
51.3.14	HAL_RTC_MspDeInit	672
51.3.15	HAL_RTC_SetTime	672
51.3.16	HAL_RTC_GetTime	673
51.3.17	HAL_RTC_SetDate	673
51.3.18	HAL_RTC_GetDate	674
51.3.19	HAL_RTC_SetAlarm	674
51.3.20	HAL_RTC_SetAlarm_IT	674
51.3.21	HAL_RTC_DeactivateAlarm	675
51.3.22	HAL_RTC_GetAlarm	675
51.3.23	HAL_RTC_AlarmIRQHandler	675
51.3.24	HAL_RTC_AlarmAEventCallback	675
51.3.25	HAL_RTC_PollForAlarmAEvent	675
51.3.26	HAL_RTC_WaitForSynchro	676
51.3.27	HAL_RTC_GetState	676
51.4	RTC Firmware driver defines	676
51.4.1	RTC	676
52	HAL RTC Extension Driver	687
52.1	HAL RTC Extension Driver	687
52.2	RTCEx Firmware driver registers structures	687
52.2.1	RTC_TamperTypeDef	687
52.3	RTCEx Firmware driver API description	688

52.3.1	How to use this driver	688
52.3.2	RTC TimeStamp and Tamper functions	688
52.3.3	RTC Wake-up functions	689
52.3.4	Extension Peripheral Control functions	689
52.3.5	Extended features functions	690
52.3.6	HAL_RTCEx_SetTimeStamp	690
52.3.7	HAL_RTCEx_SetTimeStamp_IT	690
52.3.8	HAL_RTCEx_DeactivateTimeStamp	691
52.3.9	HAL_RTCEx_GetTimeStamp	691
52.3.10	HAL_RTCEx_SetTamper	691
52.3.11	HAL_RTCEx_SetTamper_IT	692
52.3.12	HAL_RTCEx_DeactivateTamper	692
52.3.13	HAL_RTCEx_TamperTimeStampIRQHandler	692
52.3.14	HAL_RTCEx_TimeStampEventCallback	692
52.3.15	HAL_RTCEx_Tamper1EventCallback	692
52.3.16	HAL_RTCEx_Tamper2EventCallback	693
52.3.17	HAL_RTCEx_PollForTimeStampEvent	693
52.3.18	HAL_RTCEx_PollForTamper1Event	693
52.3.19	HAL_RTCEx_PollForTamper2Event	693
52.3.20	HAL_RTCEx_SetWakeUpTimer	694
52.3.21	HAL_RTCEx_SetWakeUpTimer_IT	694
52.3.22	HAL_RTCEx_DeactivateWakeUpTimer	694
52.3.23	HAL_RTCEx_GetWakeUpTimer	694
52.3.24	HAL_RTCEx_WakeUpTimerIRQHandler	694
52.3.25	HAL_RTCEx_WakeUpTimerEventCallback	695
52.3.26	HAL_RTCEx_PollForWakeUpTimerEvent	695
52.3.27	HAL_RTCEx_BKUPWrite	695
52.3.28	HAL_RTCEx_BKUPRead	695
52.3.29	HAL_RTCEx_SetCoarseCalib	696
52.3.30	HAL_RTCEx_DeactivateCoarseCalib	696
52.3.31	HAL_RTCEx_SetSmoothCalib	696
52.3.32	HAL_RTCEx_SetSynchroShift	697
52.3.33	HAL_RTCEx_SetCalibrationOutPut	697
52.3.34	HAL_RTCEx_DeactivateCalibrationOutPut	697
52.3.35	HAL_RTCEx_SetRefClock	698
52.3.36	HAL_RTCEx_DeactivateRefClock	698
52.3.37	HAL_RTCEx_EnableBypassShadow	698
52.3.38	HAL_RTCEx_DisableBypassShadow	698

52.3.39	HAL_RTCEx_AlarmBEventCallback	699
52.3.40	HAL_RTCEx_PollForAlarmBEvent	699
52.4	RTCEx Firmware driver defines	699
52.4.1	RTCEx	699
53	HAL SAI Generic Driver	719
53.1	HAL SAI Generic Driver	719
53.2	SAI Firmware driver registers structures	719
53.2.1	SAI_InitTypeDef	719
53.2.2	SAI_FrameInitTypeDef	720
53.2.3	SAI_SlotInitTypeDef	721
53.2.4	__SAI_HandleTypeDef	721
53.3	SAI Firmware driver API description	722
53.3.1	How to use this driver	722
53.3.2	Initialization and de-initialization functions	725
53.3.3	IO operation functions	725
53.3.4	Peripheral State and Errors functions	726
53.3.5	HAL_SAI_InitProtocol	726
53.3.6	HAL_SAI_Init	726
53.3.7	HAL_SAI_DelInit	727
53.3.8	HAL_SAI_MspInit	727
53.3.9	HAL_SAI_MspDeInit	727
53.3.10	HAL_SAI_Transmit	727
53.3.11	HAL_SAI_Receive	727
53.3.12	HAL_SAI_Transmit_IT	728
53.3.13	HAL_SAI_Receive_IT	728
53.3.14	HAL_SAI_DMAPause	728
53.3.15	HAL_SAI_DMAResume	728
53.3.16	HAL_SAI_DMAStop	729
53.3.17	HAL_SAI_Abort	729
53.3.18	HAL_SAI_Transmit_DMA	729
53.3.19	HAL_SAI_Receive_DMA	729
53.3.20	HAL_SAI_EnableTxMuteMode	729
53.3.21	HAL_SAI_DisableTxMuteMode	730
53.3.22	HAL_SAI_EnableRxMuteMode	730
53.3.23	HAL_SAI_DisableRxMuteMode	730
53.3.24	HAL_SAI_IRQHandler	730
53.3.25	HAL_SAI_TxCpltCallback	730
53.3.26	HAL_SAI_TxHalfCpltCallback	731

53.3.27	HAL_SAI_RxCpltCallback	731
53.3.28	HAL_SAI_RxHalfCpltCallback.....	731
53.3.29	HAL_SAI_ErrorCallback.....	731
53.3.30	HAL_SAI_GetState.....	731
53.3.31	HAL_SAI_GetError	732
53.4	SAI Firmware driver defines	732
53.4.1	SAI.....	732
54	HAL SAI Extension Driver.....	740
54.1	HAL SAI Extension Driver	740
54.2	SAIEx Firmware driver API description	740
54.2.1	SAI peripheral extension features	740
54.2.2	How to use this driver	740
54.2.3	Extension features Functions	740
54.2.4	SAI_BlockSynchroConfig	740
54.2.5	SAI_GetInputClock	740
54.3	SAIEx Firmware driver defines.....	740
54.3.1	SAIEx.....	740
55	HAL SDRAM Generic Driver	741
55.1	HAL SDRAM Generic Driver	741
55.2	SDRAM Firmware driver registers structures	741
55.2.1	SDRAM_HandleTypeDef.....	741
55.3	SDRAM Firmware driver API description	741
55.3.1	How to use this driver	741
55.3.2	SDRAM Initialization and de_initialization functions	742
55.3.3	SDRAM Input and Output functions	742
55.3.4	SDRAM Control functions.....	742
55.3.5	SDRAM State functions.....	743
55.3.6	HAL_SDRAM_Init.....	743
55.3.7	HAL_SDRAM_DelInit	743
55.3.8	HAL_SDRAM_MspInit	743
55.3.9	HAL_SDRAM_MspDeInit	743
55.3.10	HAL_SDRAM_IRQHandler	744
55.3.11	HAL_SDRAM_RefreshErrorCallback	744
55.3.12	HAL_SDRAM_DMA_XferCpltCallback.....	744
55.3.13	HAL_SDRAM_DMA_XferErrorCallback	744
55.3.14	HAL_SDRAM_Read_8b	744
55.3.15	HAL_SDRAM_Write_8b	745

55.3.16	HAL_SDRAM_Read_16b	745
55.3.17	HAL_SDRAM_Write_16b	745
55.3.18	HAL_SDRAM_Read_32b	745
55.3.19	HAL_SDRAM_Write_32b	746
55.3.20	HAL_SDRAM_Read_DMA	746
55.3.21	HAL_SDRAM_Write_DMA	746
55.3.22	HAL_SDRAM_WriteProtection_Enable	747
55.3.23	HAL_SDRAM_WriteProtection_Disable	747
55.3.24	HAL_SDRAM_SendCommand	747
55.3.25	HAL_SDRAM_ProgramRefreshRate	747
55.3.26	HAL_SDRAM_SetAutoRefreshNumber	747
55.3.27	HAL_SDRAM_GetModeStatus	748
55.3.28	HAL_SDRAM_GetState	748
55.4	SDRAM Firmware driver defines	748
55.4.1	SDRAM	748
56	HAL SD Generic Driver	749
56.1	HAL SD Generic Driver	749
56.2	SD Firmware driver registers structures	749
56.2.1	SD_HandleTypeDef	749
56.2.2	HAL_SD_CSDTypedef	750
56.2.3	HAL_SD_CIDTypedef	752
56.2.4	HAL_SD_CardStatusTypedef	753
56.2.5	HAL_SD_CardInfoTypedef	753
56.3	SD Firmware driver API description	754
56.3.1	How to use this driver	754
56.3.2	Initialization and de-initialization functions	756
56.3.3	IO operation functions	756
56.3.4	Peripheral Control functions	757
56.3.5	Peripheral State functions	757
56.3.6	HAL_SD_Init	757
56.3.7	HAL_SD_DeInit	757
56.3.8	HAL_SD_MspInit	757
56.3.9	HAL_SD_MspDeInit	757
56.3.10	HAL_SD_ReadBlocks	758
56.3.11	HAL_SD_WriteBlocks	758
56.3.12	HAL_SD_ReadBlocks_DMA	758
56.3.13	HAL_SD_WriteBlocks_DMA	759
56.3.14	HAL_SD_CheckReadOperation	759

56.3.15	HAL_SD_CheckWriteOperation	759
56.3.16	HAL_SD_Erase	759
56.3.17	HAL_SD_IRQHandler.....	760
56.3.18	HAL_SD_XferCpltCallback.....	760
56.3.19	HAL_SD_XferErrorCallback	760
56.3.20	HAL_SD_DMA_RxCpltCallback.....	760
56.3.21	HAL_SD_DMA_RxErrorCallback	760
56.3.22	HAL_SD_DMA_TxCpltCallback	760
56.3.23	HAL_SD_DMA_TxErrorCallback	761
56.3.24	HAL_SD_Get_CardInfo.....	761
56.3.25	HAL_SD_WideBusOperation_Config.....	761
56.3.26	HAL_SD_StopTransfer.....	761
56.3.27	HAL_SD_HighSpeed.....	762
56.3.28	HAL_SD_SendSDStatus	762
56.3.29	HAL_SD_GetStatus.....	762
56.3.30	HAL_SD_GetCardStatus.....	762
56.4	SD Firmware driver defines	763
56.4.1	SD.....	763
57	HAL SMARTCARD Generic Driver.....	776
57.1	HAL SMARTCARD Generic Driver	776
57.2	SMARTCARD Firmware driver registers structures	776
57.2.1	SMARTCARD_InitTypeDef	776
57.2.2	SMARTCARD_HandleTypeDef.....	777
57.3	SMARTCARD Firmware driver API description.....	778
57.3.1	How to use this driver	778
57.3.2	Initialization and Configuration functions	779
57.3.3	IO operation functions	780
57.3.4	Peripheral State and Errors functions	782
57.3.5	HAL_SMARTCARD_Init	782
57.3.6	HAL_SMARTCARD_DeInit	782
57.3.7	HAL_SMARTCARD_MspInit	782
57.3.8	HAL_SMARTCARD_MspDeInit	783
57.3.9	HAL_SMARTCARD_ReInit	783
57.3.10	HAL_SMARTCARD_Transmit.....	783
57.3.11	HAL_SMARTCARD_Receive.....	783
57.3.12	HAL_SMARTCARD_Transmit_IT	784
57.3.13	HAL_SMARTCARD_Receive_IT	784
57.3.14	HAL_SMARTCARD_Transmit_DMA.....	784

57.3.15	HAL_SMARTCARD_Receive_DMA.....	784
57.3.16	HAL_SMARTCARD_IRQHandler.....	785
57.3.17	HAL_SMARTCARD_TxCpltCallback	785
57.3.18	HAL_SMARTCARD_RxCpltCallback	785
57.3.19	HAL_SMARTCARD_ErrorCallback.....	785
57.3.20	HAL_SMARTCARD_GetState	786
57.3.21	HAL_SMARTCARD_GetError.....	786
57.4	SMARTCARD Firmware driver defines	786
57.4.1	SMARTCARD.....	786
58	HAL SPDIFRX Generic Driver	795
58.1	HAL SPDIFRX Generic Driver.....	795
58.2	SPDIFRX Firmware driver registers structures	795
58.2.1	SPDIFRX_InitTypeDef.....	795
58.2.2	SPDIFRX_SetDataFormatTypeDef.....	796
58.2.3	SPDIFRX_HandleTypeDef	796
58.3	SPDIFRX Firmware driver API description.....	797
58.3.1	How to use this driver.....	797
58.3.2	Initialization and de-initialization functions	799
58.3.3	IO operation functions	799
58.3.4	Peripheral State and Errors functions	800
58.3.5	HAL_SPDIFRX_Init	800
58.3.6	HAL_SPDIFRX_DeInit.....	800
58.3.7	HAL_SPDIFRX_MspInit	801
58.3.8	HAL_SPDIFRX_MspDeInit.....	801
58.3.9	HAL_SPDIFRX_SetDataFormat	801
58.3.10	HAL_SPDIFRX_ReceiveDataFlow.....	801
58.3.11	HAL_SPDIFRX_ReceiveControlFlow.....	801
58.3.12	HAL_SPDIFRX_ReceiveDataFlow_IT	802
58.3.13	HAL_SPDIFRX_ReceiveControlFlow_IT	802
58.3.14	HAL_SPDIFRX_ReceiveDataFlow_DMA.....	802
58.3.15	HAL_SPDIFRX_ReceiveControlFlow_DMA.....	802
58.3.16	HAL_SPDIFRX_DMAStop	803
58.3.17	HAL_SPDIFRX_IRQHandler	803
58.3.18	HAL_SPDIFRX_RxHalfCpltCallback	803
58.3.19	HAL_SPDIFRX_RxCpltCallback	803
58.3.20	HAL_SPDIFRX_CxHalfCpltCallback	803
58.3.21	HAL_SPDIFRX_CxCpltCallback	804
58.3.22	HAL_SPDIFRX_ErrorCallback	804

58.3.23	HAL_SPDIFRX_GetState.....	804
58.3.24	HAL_SPDIFRX_GetError	804
58.4	SPDIFRX Firmware driver defines	804
58.4.1	SPDIFRX	804
59	HAL SPI Generic Driver.....	810
59.1	HAL SPI Generic Driver	810
59.2	SPI Firmware driver registers structures	810
59.2.1	SPI_InitTypeDef	810
59.2.2	__SPI_HandleTypeDef.....	811
59.3	SPI Firmware driver API description	812
59.3.1	How to use this driver	812
59.3.2	Initialization and de-initialization functions	812
59.3.3	IO operation functions	813
59.3.4	Peripheral State and Errors functions	813
59.3.5	HAL_SPI_Init	814
59.3.6	HAL_SPI_DeInit	814
59.3.7	HAL_SPI_MspInit	814
59.3.8	HAL_SPI_MspDeInit.....	814
59.3.9	HAL_SPI_Transmit.....	814
59.3.10	HAL_SPI_Receive.....	815
59.3.11	HAL_SPI_TransmitReceive.....	815
59.3.12	HAL_SPI_Transmit_IT.....	815
59.3.13	HAL_SPI_Receive_IT.....	815
59.3.14	HAL_SPI_TransmitReceive_IT	816
59.3.15	HAL_SPI_Transmit_DMA.....	816
59.3.16	HAL_SPI_Receive_DMA.....	816
59.3.17	HAL_SPI_TransmitReceive_DMA.....	816
59.3.18	HAL_SPI_DMAPause.....	817
59.3.19	HAL_SPI_DMAResume	817
59.3.20	HAL_SPI_DMAStop	817
59.3.21	HAL_SPI_IRQHandler.....	817
59.3.22	HAL_SPI_TxCpltCallback	818
59.3.23	HAL_SPI_RxCpltCallback	818
59.3.24	HAL_SPI_TxRxCpltCallback	818
59.3.25	HAL_SPI_TxHalfCpltCallback	818
59.3.26	HAL_SPI_RxHalfCpltCallback.....	818
59.3.27	HAL_SPI_TxRxHalfCpltCallback.....	818
59.3.28	HAL_SPI_ErrorCallback	819

59.3.29	HAL_SPI_GetState.....	819
59.3.30	HAL_SPI_GetError.....	819
59.4	SPI Firmware driver defines.....	819
59.4.1	SPI.....	819
60	HAL SRAM Generic Driver	825
60.1	HAL SRAM Generic Driver.....	825
60.2	SRAM Firmware driver registers structures.....	825
60.2.1	SRAM_HandleTypeDef	825
60.3	SRAM Firmware driver API description.....	825
60.3.1	How to use this driver	825
60.3.2	SRAM Initialization and de_initialization functions	826
60.3.3	SRAM Input and Output functions	826
60.3.4	SRAM Control functions	826
60.3.5	SRAM State functions	827
60.3.6	HAL_SRAM_Init	827
60.3.7	HAL_SRAM_DeInit.....	827
60.3.8	HAL_SRAM_MspInit.....	827
60.3.9	HAL_SRAM_MspDeInit.....	827
60.3.10	HAL_SRAM_DMA_XferCpltCallback	828
60.3.11	HAL_SRAM_DMA_XferErrorCallback.....	828
60.3.12	HAL_SRAM_Read_8b.....	828
60.3.13	HAL_SRAM_Write_8b.....	828
60.3.14	HAL_SRAM_Read_16b.....	828
60.3.15	HAL_SRAM_Write_16b.....	829
60.3.16	HAL_SRAM_Read_32b.....	829
60.3.17	HAL_SRAM_Write_32b.....	829
60.3.18	HAL_SRAM_Read_DMA.....	830
60.3.19	HAL_SRAM_Write_DMA.....	830
60.3.20	HAL_SRAM_WriteOperation_Enable.....	830
60.3.21	HAL_SRAM_WriteOperation_Disable.....	830
60.3.22	HAL_SRAM_GetState.....	830
60.4	SRAM Firmware driver defines	831
60.4.1	SRAM	831
61	HAL TIM Generic Driver	832
61.1	HAL TIM Generic Driver	832
61.2	TIM Firmware driver registers structures.....	832
61.2.1	TIM_Base_InitTypeDef.....	832

61.2.2	TIM_OC_InitTypeDef.....	832
61.2.3	TIM_OnePulse_InitTypeDef	833
61.2.4	TIM_IC_InitTypeDef	834
61.2.5	TIM_Encoder_InitTypeDef	834
61.2.6	TIM_ClockConfigTypeDef	835
61.2.7	TIM_ClearInputConfigTypeDef.....	836
61.2.8	TIM_SlaveConfigTypeDef	836
61.2.9	TIM_HandleTypeDef	837
61.3	TIM Firmware driver API description	837
61.3.1	TIMER Generic features.....	837
61.3.2	How to use this driver	838
61.3.3	Time Base functions	838
61.3.4	Time Output Compare functions	839
61.3.5	Time PWM functions	839
61.3.6	Time Input Capture functions	840
61.3.7	Time One Pulse functions	840
61.3.8	Time Encoder functions.....	841
61.3.9	IRQ handler management.....	841
61.3.10	Peripheral Control functions	841
61.3.11	TIM Callbacks functions	842
61.3.12	Peripheral State functions	842
61.3.13	HAL_TIM_Base_Init	842
61.3.14	HAL_TIM_Base_DelInit.....	843
61.3.15	HAL_TIM_Base_MspInit.....	843
61.3.16	HAL_TIM_Base_MspDelInit.....	843
61.3.17	HAL_TIM_Base_Start.....	843
61.3.18	HAL_TIM_Base_Stop.....	843
61.3.19	HAL_TIM_Base_Start_IT	843
61.3.20	HAL_TIM_Base_Stop_IT	844
61.3.21	HAL_TIM_Base_Start_DMA	844
61.3.22	HAL_TIM_Base_Stop_DMA.....	844
61.3.23	HAL_TIM_OC_Init	844
61.3.24	HAL_TIM_OC_DelInit.....	845
61.3.25	HAL_TIM_OC_MspInit	845
61.3.26	HAL_TIM_OC_MspDelInit.....	845
61.3.27	HAL_TIM_OC_Start	845
61.3.28	HAL_TIM_OC_Stop.....	845
61.3.29	HAL_TIM_OC_Start_IT	846

61.3.30	HAL_TIM_OC_Stop_IT	846
61.3.31	HAL_TIM_OC_Start_DMA	846
61.3.32	HAL_TIM_OC_Stop_DMA	847
61.3.33	HAL_TIM_PWM_Init.....	847
61.3.34	HAL_TIM_PWM_DelInit.....	847
61.3.35	HAL_TIM_PWM_MspInit.....	847
61.3.36	HAL_TIM_PWM_MspDelInit	847
61.3.37	HAL_TIM_PWM_Start.....	848
61.3.38	HAL_TIM_PWM_Stop	848
61.3.39	HAL_TIM_PWM_Start_IT.....	848
61.3.40	HAL_TIM_PWM_Stop_IT	849
61.3.41	HAL_TIM_PWM_Start_DMA.....	849
61.3.42	HAL_TIM_PWM_Stop_DMA	849
61.3.43	HAL_TIM_IC_Init.....	849
61.3.44	HAL_TIM_IC_DelInit	850
61.3.45	HAL_TIM_IC_MspInit	850
61.3.46	HAL_TIM_IC_MspDelInit.....	850
61.3.47	HAL_TIM_IC_Start	850
61.3.48	HAL_TIM_IC_Stop	850
61.3.49	HAL_TIM_IC_Start_IT	851
61.3.50	HAL_TIM_IC_Stop_IT	851
61.3.51	HAL_TIM_IC_Start_DMA	851
61.3.52	HAL_TIM_IC_Stop_DMA	852
61.3.53	HAL_TIM_OnePulse_Init.....	852
61.3.54	HAL_TIM_OnePulse_DelInit	852
61.3.55	HAL_TIM_OnePulse_MspInit	852
61.3.56	HAL_TIM_OnePulse_MspDelInit	853
61.3.57	HAL_TIM_OnePulse_Start.....	853
61.3.58	HAL_TIM_OnePulse_Stop	853
61.3.59	HAL_TIM_OnePulse_Start_IT.....	853
61.3.60	HAL_TIM_OnePulse_Stop_IT	854
61.3.61	HAL_TIM_Encoder_Init	854
61.3.62	HAL_TIM_Encoder_DelInit	854
61.3.63	HAL_TIM_Encoder_MspInit	854
61.3.64	HAL_TIM_Encoder_MspDelInit.....	855
61.3.65	HAL_TIM_Encoder_Start	855
61.3.66	HAL_TIM_Encoder_Stop	855
61.3.67	HAL_TIM_Encoder_Start_IT	855
61.3.68	HAL_TIM_Encoder_Stop_IT	856

61.3.69	HAL_TIM_Encoder_Start_DMA	856
61.3.70	HAL_TIM_Encoder_Stop_DMA	856
61.3.71	HAL_TIM_IRQHandler	857
61.3.72	HAL_TIM_OC_ConfigChannel	857
61.3.73	HAL_TIM_IC_ConfigChannel	857
61.3.74	HAL_TIM_PWM_ConfigChannel	857
61.3.75	HAL_TIM_OnePulse_ConfigChannel	858
61.3.76	HAL_TIM_DMABurst_WriteStart	858
61.3.77	HAL_TIM_DMABurst_WriteStop	859
61.3.78	HAL_TIM_DMABurst_ReadStart	859
61.3.79	HAL_TIM_DMABurst_ReadStop	860
61.3.80	HAL_TIM_GenerateEvent	860
61.3.81	HAL_TIM_ConfigOCrefClear	860
61.3.82	HAL_TIM_ConfigClockSource	861
61.3.83	HAL_TIM_ConfigTI1Input	861
61.3.84	HAL_TIM_SlaveConfigSynchronization	861
61.3.85	HAL_TIM_SlaveConfigSynchronization_IT	862
61.3.86	HAL_TIM_ReadCapturedValue	862
61.3.87	HAL_TIM_PeriodElapsedCallback	862
61.3.88	HAL_TIM_OC_DelayElapsedCallback	862
61.3.89	HAL_TIM_IC_CaptureCallback	863
61.3.90	HAL_TIM_PWM_PulseFinishedCallback	863
61.3.91	HAL_TIM_TriggerCallback	863
61.3.92	HAL_TIM_ErrorCallback	863
61.3.93	HAL_TIM_Base_GetState	863
61.3.94	HAL_TIM_OC_GetState	864
61.3.95	HAL_TIM_PWM_GetState	864
61.3.96	HAL_TIM_IC_GetState	864
61.3.97	HAL_TIM_OnePulse_GetState	864
61.3.98	HAL_TIM_Encoder_GetState	864
61.4	TIM Firmware driver defines	865
61.4.1	TIM	865
62	HAL TIM Extension Driver	880
62.1	HAL TIM Extension Driver	880
62.2	TIMEx Firmware driver registers structures	880
62.2.1	TIM_HallSensor_InitTypeDef	880
62.2.2	TIM_MasterConfigTypeDef	880
62.2.3	TIM_BreakDeadTimeConfigTypeDef	881

62.3	TIMEx Firmware driver API description.....	881
62.3.1	TIMER Extended features	881
62.3.2	How to use this driver	882
62.3.3	Timer Hall Sensor functions	882
62.3.4	Timer Complementary Output Compare functions.....	883
62.3.5	Timer Complementary PWM functions.....	883
62.3.6	Timer Complementary One Pulse functions.....	884
62.3.7	Peripheral Control functions	884
62.3.8	Extension Callbacks functions.....	884
62.3.9	Extension Peripheral State functions	884
62.3.10	HAL_TIMEx_HallSensor_Init.....	884
62.3.11	HAL_TIMEx_HallSensor_DelInit	885
62.3.12	HAL_TIMEx_HallSensor_MspInit.....	885
62.3.13	HAL_TIMEx_HallSensor_MspDeInit	885
62.3.14	HAL_TIMEx_HallSensor_Start.....	885
62.3.15	HAL_TIMEx_HallSensor_Stop	885
62.3.16	HAL_TIMEx_HallSensor_Start_IT.....	886
62.3.17	HAL_TIMEx_HallSensor_Stop_IT	886
62.3.18	HAL_TIMEx_HallSensor_Start_DMA.....	886
62.3.19	HAL_TIMEx_HallSensor_Stop_DMA	886
62.3.20	HAL_TIMEx_OCN_Start.....	887
62.3.21	HAL_TIMEx_OCN_Stop	887
62.3.22	HAL_TIMEx_OCN_Start_IT	887
62.3.23	HAL_TIMEx_OCN_Stop_IT	887
62.3.24	HAL_TIMEx_OCN_Start_DMA	888
62.3.25	HAL_TIMEx_OCN_Stop_DMA.....	888
62.3.26	HAL_TIMEx_PWMN_Start	888
62.3.27	HAL_TIMEx_PWMN_Stop	889
62.3.28	HAL_TIMEx_PWMN_Start_IT	889
62.3.29	HAL_TIMEx_PWMN_Stop_IT	889
62.3.30	HAL_TIMEx_PWMN_Start_DMA	890
62.3.31	HAL_TIMEx_PWMN_Stop_DMA	890
62.3.32	HAL_TIMEx_OnePulseN_Start	890
62.3.33	HAL_TIMEx_OnePulseN_Stop	891
62.3.34	HAL_TIMEx_OnePulseN_Start_IT	891
62.3.35	HAL_TIMEx_OnePulseN_Stop_IT	891
62.3.36	HAL_TIMEx_ConfigCommutationEvent	891
62.3.37	HAL_TIMEx_ConfigCommutationEvent_IT	892
62.3.38	HAL_TIMEx_ConfigCommutationEvent_DMA	893

62.3.39	HAL_TIMEx_MasterConfigSynchronization	893
62.3.40	HAL_TIMEx_ConfigBreakDeadTime	894
62.3.41	HAL_TIMEx_RemapConfig	894
62.3.42	HAL_TIMEx_CommutationCallback	894
62.3.43	HAL_TIMEx_BreakCallback	895
62.3.44	TIMEx_DMACommutationCplt	895
62.3.45	HAL_TIMEx_HallSensor_GetState	895
62.4	TIMEx Firmware driver defines	895
62.4.1	TIMEX	895
63	HAL UART Generic Driver.....	897
63.1	HAL UART Generic Driver	897
63.2	UART Firmware driver registers structures	897
63.2.1	UART_InitTypeDef	897
63.2.2	UART_HandleTypeDef.....	898
63.3	UART Firmware driver API description	899
63.3.1	How to use this driver	899
63.3.2	Initialization and Configuration functions	901
63.3.3	IO operation functions	901
63.3.4	Peripheral Control functions	902
63.3.5	Peripheral State and Errors functions	902
63.3.6	HAL_UART_Init	903
63.3.7	HAL_HalfDuplex_Init	903
63.3.8	HAL_LIN_Init	903
63.3.9	HAL_MultiProcessor_Init	903
63.3.10	HAL_UART_DeInit	904
63.3.11	HAL_UART_MspInit	904
63.3.12	HAL_UART_MspDeInit	904
63.3.13	HAL_UART_Transmit	904
63.3.14	HAL_UART_Receive	905
63.3.15	HAL_UART_Transmit_IT	905
63.3.16	HAL_UART_Receive_IT	905
63.3.17	HAL_UART_Transmit_DMA	905
63.3.18	HAL_UART_Receive_DMA	906
63.3.19	HAL_UART_DMAPause	906
63.3.20	HAL_UART_DMAResume	906
63.3.21	HAL_UART_DMAStop	906
63.3.22	HAL_UART_IRQHandler	907
63.3.23	HAL_UART_TxCpltCallback	907

63.3.24	HAL_UART_TxHalfCpltCallback	907
63.3.25	HAL_UART_RxCpltCallback	907
63.3.26	HAL_UART_RxHalfCpltCallback	907
63.3.27	HAL_UART_ErrorCallback	908
63.3.28	HAL_LIN_SendBreak	908
63.3.29	HAL_MultiProcessor_EnterMuteMode	908
63.3.30	HAL_MultiProcessor_ExitMuteMode	908
63.3.31	HAL_HalfDuplex_EnableTransmitter	909
63.3.32	HAL_HalfDuplex_EnableReceiver	909
63.3.33	HAL_UART_GetState	909
63.3.34	HAL_UART_GetError	909
63.4	UART Firmware driver defines	909
63.4.1	UART	909
64	HAL USART Generic Driver	921
64.1	HAL USART Generic Driver	921
64.2	USART Firmware driver registers structures	921
64.2.1	USART_InitTypeDef	921
64.2.2	USART_HandleTypeDef	922
64.3	USART Firmware driver API description	922
64.3.1	How to use this driver	922
64.3.2	Initialization and Configuration functions	924
64.3.3	IO operation functions	925
64.3.4	Peripheral State and Errors functions	926
64.3.5	HAL_USART_Init	926
64.3.6	HAL_USART_DeInit	926
64.3.7	HAL_USART_MspInit	926
64.3.8	HAL_USART_MspDeInit	927
64.3.9	HAL_USART_Transmit	927
64.3.10	HAL_USART_Receive	927
64.3.11	HAL_USART_TransmitReceive	927
64.3.12	HAL_USART_Transmit_IT	928
64.3.13	HAL_USART_Receive_IT	928
64.3.14	HAL_USART_TransmitReceive_IT	928
64.3.15	HAL_USART_Transmit_DMA	929
64.3.16	HAL_USART_Receive_DMA	929
64.3.17	HAL_USART_TransmitReceive_DMA	929
64.3.18	HAL_USART_DMAPause	930
64.3.19	HAL_USART_DMAResume	930

64.3.20	HAL_USART_DMAStop	930
64.3.21	HAL_USART_IRQHandler	930
64.3.22	HAL_USART_TxCpltCallback	930
64.3.23	HAL_USART_TxHalfCpltCallback	931
64.3.24	HAL_USART_RxCpltCallback	931
64.3.25	HAL_USART_RxHalfCpltCallback	931
64.3.26	HAL_USART_TxRxCpltCallback	931
64.3.27	HAL_USART_ErrorCallback	932
64.3.28	HAL_USART_GetState	932
64.3.29	HAL_USART_GetError	932
64.4	USART Firmware driver defines	932
64.4.1	USART	932
65	HAL WWDG Generic Driver	940
65.1	HAL WWDG Generic Driver	940
65.2	WWDG Firmware driver registers structures	940
65.2.1	WWDG_InitTypeDef	940
65.2.2	WWDG_HandleTypeDef	940
65.3	WWDG Firmware driver API description	941
65.3.1	WWDG specific features	941
65.3.2	How to use this driver	941
65.3.3	Initialization and de-initialization functions	941
65.3.4	IO operation functions	942
65.3.5	Peripheral State functions	942
65.3.6	HAL_WWDG_Init	942
65.3.7	HAL_WWDG_DeInit	942
65.3.8	HAL_WWDG_MspInit	943
65.3.9	HAL_WWDG_MspDeInit	943
65.3.10	HAL_WWDG_WakeupCallback	943
65.3.11	HAL_WWDG_Start	943
65.3.12	HAL_WWDG_Start_IT	943
65.3.13	HAL_WWDG_Refresh	944
65.3.14	HAL_WWDG_IRQHandler	944
65.3.15	HAL_WWDG_WakeUpCallback	944
65.3.16	HAL_WWDG_GetState	944
65.4	WWDG Firmware driver defines	945
65.4.1	WWDG	945
66	HAL WWDG Generic Driver	949

Contents	UM1725
66.1 HAL_WWDG_Generic_Driver	949
66.2 WWDG Firmware driver registers structures.....	949
66.2.1 WWDG_InitTypeDef	949
66.2.2 WWDG_HandleTypeDef	949
66.3 WWDG Firmware driver API description	950
66.3.1 WWDG specific features	950
66.3.2 How to use this driver	950
66.3.3 Initialization and de-initialization functions	950
66.3.4 IO operation functions	951
66.3.5 Peripheral State functions	951
66.3.6 HAL_WWDG_Init.....	951
66.3.7 HAL_WWDG_DeInit.....	951
66.3.8 HAL_WWDG_MspInit.....	952
66.3.9 HAL_WWDG_MspDeInit	952
66.3.10 HAL_WWDG_WakeupCallback	952
66.3.11 HAL_WWDG_Start.....	952
66.3.12 HAL_WWDG_Start_IT.....	952
66.3.13 HAL_WWDG_Refresh.....	953
66.3.14 HAL_WWDG_IRQHandler	953
66.3.15 HAL_WWDG_WakeupCallback	953
66.3.16 HAL_WWDG_GetState	953
66.4 WWDG Firmware driver defines.....	954
66.4.1 WWDG.....	954
67 FAQs.....	958
68 Revision history	962

List of tables

Table 1: Acronyms and definitions	59
Table 2: HAL drivers files	61
Table 3: User-application files	63
Table 4: APis classification	67
Table 5: List of devices supported by HAL drivers	68
Table 6: HAL API naming rules	70
Table 7: Macros handling interrupts and specific clock configurations	71
Table 8: Callback functions	72
Table 9: HAL generic APIs	73
Table 10: HAL extension APIs	74
Table 11: Define statements used for HAL configuration	78
Table 12: Description of GPIO_InitTypeDef structure	80
Table 13: Description of EXTI configuration macros	83
Table 14: MSP functions	88
Table 15: Timeout values	91
Table 16: USART frame formats	780
Table 17: Document revision history	962

List of figures

Figure 1: Example of project template	64
Figure 2: Adding device-specific functions	75
Figure 3: Adding family-specific functions	75
Figure 4: Adding new peripherals	76
Figure 5: Updating existing APIs	76
Figure 6: File inclusion model	77
Figure 7: HAL driver model	85

1 Acronyms and definitions

Table 1: Acronyms and definitions

Acronym	Definition
ADC	Analog-to-digital converter
ANSI	American National Standards Institute
API	Application Programming Interface
BSP	Board Support Package
CAN	Controller area network
CEC	Consumer Electronics Control
CMSIS	Cortex Microcontroller Software Interface Standard
CPU	Central Processing Unit
CRYP	Cryptographic processor unit
CRC	CRC calculation unit
DAC	Digital to analog converter
DCMI	Digital Camera Module Interface
DMA	Direct Memory Access
DMA2D	Chrom-Art Accelerator™ controller
DSI	Display Serial Interface
ETH	Ethernet controller
EXTI	External interrupt/event controller
FLASH	Flash memory
FSMC	Flexible Static Memory controller
FMC	Flexible Memory controller
FMP12C	Fast-mode Plus inter-integrated circuit
GPIO	General purpose I/Os
HAL	Hardware abstraction layer
HASH	Hash processor
HCD	USB Host Controller Driver
I2C	Inter-integrated circuit
I2S	Inter-integrated sound
IRDA	InfraRed Data Association
IWDG	Independent watchdog
LPTIM	Low-power Timer
LTDC	LCD TFT Display Controller
MSP	MCU Specific Package
NAND	NAND external Flash memory
NOR	NOR external Flash memory

Acronym	Definition
NVIC	Nested Vectored Interrupt Controller
PCCARD	PCCARD external memory
PCD	USB Peripheral Controller Driver
PWR	Power controller
QSPI	QuadSPI Flash memory Interface
RCC	Reset and clock controller
RNG	Random Number Generator
RTC	Real-time clock
SAI	Serial Audio Interface
SD	Secure Digital
SDRAM	SDRAM external memory
SRAM	SRAM external memory
SMARTCARD	Smartcard IC
SPDIFRX	SPDIF-RX Receiver Interface
SPI	Serial Peripheral interface
SysTick	System tick timer
TIM	Advanced-control, general-purpose or basic timer
UART	Universal asynchronous receiver/transmitter
USART	Universal synchronous receiver/transmitter
WWDG	Window watchdog
USB	Universal Serial Bus
PPP	STM32 peripheral or block

2 Overview of HAL drivers

The HAL drivers were designed to offer a rich set of APIs and to interact easily with the application upper layers.

Each driver consists of a set of functions covering the most common peripheral features. The development of each driver is driven by a common API which standardizes the driver structure, the functions and the parameter names.

The HAL drivers consist of a set of driver modules, each module being linked to standalone peripheral. However, in some cases, the module is linked to a peripheral functional mode. As an example, several modules exist for the USART peripheral: USART driver module, USART driver module, SMARTCARD driver module and IRDA driver module.

The HAL main features are the following:

- Cross-family portable set of APIs covering the common peripheral features as well as extension APIs in case of specific peripheral features.
- Three API programming models: polling, interrupt and DMA.
- APIs are RTOS compliant:
 - Fully reentrant APIs
 - Systematic usage of timeouts in polling mode.
- Peripheral multi-instance support allowing concurrent API calls for multiple instances of a given peripheral (USART1, USART2...)
- All HAL APIs implement user-callback functions mechanism:
 - Peripheral Init/DeInit HAL APIs can call user-callback functions to perform peripheral system level Initialization/De-Initialization (clock, GPIOs, interrupt, DMA)
 - Peripherals interrupt events
 - Error events.
- Object locking mechanism: safe hardware access to prevent multiple spurious accesses to shared resources.
- Timeout used for all blocking processes: the timeout can be a simple counter or a timebase.

2.1 HAL and user-application files

2.1.1 HAL driver files

HAL drivers are composed of the following set of files:

Table 2: HAL drivers files

File	Description
<i>stm32f4xx_hal_ppp.c</i>	Main peripheral/module driver file. It includes the APIs that are common to all STM32 devices. <i>Example: stm32f4xx_hal_adc.c, stm32f4xx_hal_irda.c, ...</i>
<i>stm32f4xx_hal_ppp.h</i>	Header file of the main driver C file It includes common data, handle and enumeration structures, define statements and macros, as well as the exported generic APIs. <i>Example: stm32f4xx_hal_adc.h, stm32f4xx_hal_irda.h, ...</i>

File	Description
<i>stm32f4xx_hal_ppp_ex.c</i>	Extension file of a peripheral/module driver. It includes the specific APIs for a given part number or family, as well as the newly defined APIs that overwrite the default generic APIs if the internal process is implemented in different way. <i>Example: stm32f4xx_hal_adc_ex.c, stm32f4xx_hal_dma_ex.c, ...</i>
<i>stm32f4xx_hal_ppp_ex.h</i>	Header file of the extension C file. It includes the specific data and enumeration structures, define statements and macros, as well as the exported device part number specific APIs <i>Example: stm32f4xx_hal_adc_ex.h, stm32f4xx_hal_dma_ex.h, ...</i>
<i>stm32f4xx_ll_ppp.c</i>	Peripheral low layer driver that can be accessed from one or more HAL drivers. It offers a set of APIs and services used by the upper driver. From the user point of view, low-level drivers are not accessible directly. They are used only by the HAL drivers built upon them. <i>Example: stm32f4xx_ll_fmc.c offers a set of API used by stm32f4xx_hal_sdram.c, stm32f4xx_hal_sram.c, stm32f4xx_hal_nor.c, stm32f4xx_hal_nand.c, ...</i>
<i>stm32f4xx_ll_ppp.h</i>	Header file of the low layer C file. It is included in the HAL driver header file, thus making the low-level driver an intrinsic add-on of the HAL driver that is not visible from the application. <i>Example: stm32f4xx_ll_fmc.h, stm32f4xx_ll_usb.h, ...</i>
<i>stm32f4xx_hal.c</i>	This file is used for HAL initialization and contains DBGMCU, Remap and Time Delay based on systick APIs.
<i>stm32f4xx_hal.h</i>	<i>stm32f4xx_hal.c</i> header file
<i>stm32f4xx_hal_msp_template.c</i>	Template file to be copied to the user application folder. It contains the MSP initialization and de-initialization (main routine and callbacks) of the peripheral used in the user application.
<i>stm32f4xx_hal_conf_template.h</i>	Template file allowing to customize the drivers for a given application.
<i>stm32f4xx_hal_def.h</i>	Common HAL resources such as common define statements, enumerations, structures and macros.



Since the low-level drivers are only used by the HAL drivers built upon them, the APIs provided by these drivers will not be described in this document.

2.1.2 User-application files

The minimum files required to build an application using the HAL drivers are listed in the table below:

Table 3: User-application files

File	Description
<code>system_stm32f4xx.c</code>	<p>This file contains SystemInit() which is called at startup just after reset and before branching to the main program. It does not configure the system clock at startup (contrary to the standard library). This must be performed using the HAL APIs in the user files.</p> <p>It allows to :</p> <ul style="list-style-type: none"> • relocate the vector table in internal SRAM. • configure FSMC/FMC peripheral (when available) to use as data memory the external SRAM or SDRAM mounted on the evaluation board.
<code>startup_stm32f4xx.s</code>	<p>Toolchain specific file that contains reset handler and exception vectors. For some toolchains, it allows adapting the stack/heap size to fit the application requirements.</p>
<code>stm32f4xx_flash.icf (optional)</code>	<p>Linker file for EWARM toolchain allowing mainly to adapt the stack/heap size to fit the application requirements.</p>
<code>stm32f4xx_hal_msp.c</code>	<p>This file contains the MSP initialization and de-initialization (main routine and callbacks) of the peripheral used in the user application.</p>
<code>stm32f4xx_hal_conf.h</code>	<p>This file allows the user to customize the HAL drivers for a specific application.</p> <p>It is not mandatory to modify this configuration. The application can use the default configuration without any modification.</p>
<code>stm32f4xx_it.c/h</code>	<p>This file contains the exceptions handler and peripherals interrupt service routine, and calls HAL_IncTick() at regular time intervals to increment a local variable (declared in <code>stm32f4xx_hal.c</code>) used as HAL timebase. By default, this function is called each 1ms in SysTick ISR. .</p> <p>The PPP_IRQHandler() routine must call HAL_PPP_IRQHandler() if an interrupt based process is used within the application.</p>
<code>main.c/h</code>	<p>This file contains the main program routine, mainly:</p> <ul style="list-style-type: none"> • the call to HAL_Init() • assert_failed() implementation • system clock configuration • peripheral HAL initialization and user application code.

The STM32Cube package comes with ready-to-use project templates, one for each supported board. Each project contains the files listed above and a preconfigured project for the supported toolchains.

Each project template provides empty main loop function and can be used as a starting point to get familiar with project settings for STM32Cube. Their characteristics are the following:


- It contains sources of HAL, CMSIS and BSP drivers which are the minimal components to develop a code on a given board.
- It contains the include paths for all the firmware components.

- It defines the STM32 device supported, and allows to configure the CMSIS and HAL drivers accordingly.
- It provides ready to use user files preconfigured as defined below:
 - HAL is initialized
 - SysTick ISR implemented for HAL_Delay()
 - System clock configured with the maximum frequency of the device.



If an existing project is copied to another location, then include paths must be updated.

Figure 1: Example of project template



2.2 HAL data structures

Each HAL driver can contain the following data structures:

- Peripheral handle structures
- Initialization and configuration structures
- Specific process structures.

2.2.1 Peripheral handle structures

The APIs have a modular generic multi-instance architecture that allows working with several IP instances simultaneous.

PPP_HandleTypeDef *handle is the main structure that is implemented in the HAL drivers. It handles the peripheral/module configuration and registers and embeds all the structures and variables needed to follow the peripheral device flow.

The peripheral handle is used for the following purposes:

- Multi-instance support: each peripheral/module instance has its own handle. As a result instance resources are independent.
- Peripheral process intercommunication: the handle is used to manage shared data resources between the process routines.
Example: global pointers, DMA handles, state machine.
- Storage : this handle is used also to manage global variables within a given HAL driver.

An example of peripheral structure is shown below:

```
typedef struct
{
    USART_TypeDef      *Instance; /* USART registers base address */
    USART_InitTypeDef  Init;     /* Usart communication parameters */
    uint8_t            *pTxBuffPtr; /* Pointer to Usart Tx transfer Buffer */
    uint16_t           TxXferSize; /* Usart Tx Transfer size */
    __IO uint16_t      TxXferCount; /* Usart Tx Transfer Counter */
    uint8_t            *pRxBuffPtr; /* Pointer to Usart Rx transfer Buffer */
    uint16_t           RxXferSize; /* Usart Rx Transfer size */
    __IO uint16_t      RxXferCount; /* Usart Rx Transfer Counter */
    DMA_HandleTypeDef   *hdmatx;  /* Usart Tx DMA Handle parameters */
    DMA_HandleTypeDef   *hdmarx;  /* Usart Rx DMA Handle parameters */
    HAL_LockTypeDef     Lock;     /* Locking object */
    __IO HAL_USART_StateTypeDef State; /* Usart communication state */
    __IO HAL_USART_ErrorTypeDef ErrorCode; /* USART Error code */
}USART_HandleTypeDef;
```



1) The multi-instance feature implies that all the APIs used in the application are re-entrant and avoid using global variables because a subroutine can fail to be re-entrant if they rely on a global variable to remain unchanged but that variable is modified when the subroutine is recursively invoked. For this reason, the following rules are respected:

- Re-entrant code does not hold any static (or global) non-constant data: re-entrant functions can work with global data. For example, a re-entrant interrupt service routine can grab a piece of hardware status to work with (e.g. serial port read buffer) which is not only global, but volatile. Still, typical use of static variables and global data is not advised, in the sense that only atomic read-modify-write instructions should be used in these variables. It should not be possible for an interrupt or signal to occur during the execution of such an instruction.
- Reentrant code does not modify its own code.



2) When a peripheral can manage several processes simultaneously using the DMA (full duplex case), the DMA interface handle for each process is added in the PPP_HandleTypeDef.

-  3) For the shared and system peripherals, no handle or instance object is used. The peripherals concerned by this exception are the following:

- GPIO
- SYSTICK
- NVIC
- PWR
- RCC
- FLASH.

2.2.2 Initialization and configuration structure

These structures are defined in the generic driver header file when it is common to all part numbers. When they can change from one part number to another, the structures are defined in the extension header file for each part number.

```
typedef struct
{
    uint32_t BaudRate; /*!< This member configures the UART communication baudrate.*/
    uint32_t WordLength; /*!< Specifies the number of data bits transmitted or received
in a frame.*/
    uint32_t StopBits; /*!< Specifies the number of stop bits transmitted.*/
    uint32_t Parity; /*!< Specifies the parity mode. */
    uint32_t Mode; /*!< Specifies whether the Receive or Transmit mode is enabled or
disabled.*/
    uint32_t HwFlowCtl; /*!< Specifies whether the hardware flow control mode is enabled
or disabled.*/
    uint32_t OverSampling; /*!< Specifies whether the Over sampling 8 is enabled or
disabled,
to achieve higher speed (up to fPCLK/8).*/
}UART_InitTypeDef;
```

 The config structure is used to initialize the sub-modules or sub-instances. See below example:

```
HAL_ADC_ConfigChannel (ADC_HandleTypeDef* hadc, ADC_ChannelConfTypeDef*
sConfig)
```

2.2.3 Specific process structures

The specific process structures are used for specific process (common APIs). They are defined in the generic driver header file.

Example:

```
HAL_PPP_Process (PPP_HandleTypeDef* hadc, PPP_ProcessConfig* sConfig)
```

2.3 API classification

The HAL APIs are classified into three categories:

- **Generic APIs:** common generic APIs applying to all STM32 devices. These APIs are consequently present in the generic HAL drivers files of all STM32 microcontrollers.

```
HAL_StatusTypeDef HAL_ADC_Init(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADC_DeInit(ADC_HandleTypeDef *hadc); HAL_StatusTypeDef
HAL_ADC_Start(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADC_Stop(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADC_Start_IT(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADC_Stop_IT(ADC_HandleTypeDef* hadc); void HAL_ADC_IRQHandler(ADC_HandleTypeDef*
hadc);
```

- **Extension APIs:** This set of API is divided into two sub-categories :
 - **Family specific APIs:** APIs applying to a given family. They are located in the extension HAL driver file (see example below related to the ADC).

```
HAL_StatusTypeDef HAL_ADCEx_InjectedStop(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADCEx_InjectedStop_IT(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADCEx_InjectedStart(ADC_HandleTypeDef* hadc); HAL_StatusTypeDef
HAL_ADCEx_InjectedStart_IT(ADC_HandleTypeDef* hadc);
```

- **Device part number specific APIs:** These APIs are implemented in the extension file and delimited by specific define statements relative to a given part number.

```
#if defined(STM32F427xx) || defined(STM32F437xx) || defined(STM32F429xx) ||
defined(STM32F439xx) HAL_StatusTypeDef HAL_FLASHEx_OB_SelectPCROP(void);
HAL_StatusTypeDef HAL_FLASHEx_OB_DeSelectPCROP(void);
#endif /* STM32F427xx || STM32F437xx || STM32F429xx || STM32F439xx || */
```

- The data structure related to the specific APIs is delimited by the device part number define statement. It is located in the corresponding extension header C file.

The following table summarizes the location of the different categories of HAL APIs in the driver files.

Table 4: APIs classification

	Generic file	Extension file
Common APIs	X	X ⁽¹⁾
Family specific APIs		X
Device specific APIs		X

Notes:

⁽¹⁾In some cases, the implementation for a specific device part number may change . In this case the generic API is declared as weak function in the extension file. The API is implemented again to overwrite the default function



Family specific APIs are only related to a given family. This means that if a specific API is implemented in another family, and the arguments of this latter family are different, additional structures and arguments might need to be added.



The IRQ handlers are used for common and family specific processes.

2.4 Devices supported by HAL drivers

Table 5: List of devices supported by HAL drivers

IP/Module	STM32F405xx	STM32F415xx	STM32F407xx	STM32F417xx	STM32F427xx	STM32F437xx	STM32F429xx	STM32F439xx	STM32F401xC	STM32F401xE	STM32F446xx	STM32F469xx	STM32F479xx	STM32F410xx
stm32f4xx_hal.c	Yes													
stm32f4xx_hal_adc.c	Yes													
stm32f4xx_hal_adc_ex.c	Yes													
stm32f4xx_hal_can.c	Yes	No	No	Yes	Yes	Yes	Yes							
stm32f4xx_hal_cec.c	No	Yes	No	No	No									
stm32f4xx_hal_cortex.c	Yes													
stm32f4xx_hal_crc.c	Yes													
stm32f4xx_hal_cryp.c	No	Yes	No	Yes	No	Yes	No	Yes	No	No	No	No	Yes	No
stm32f4xx_hal_cryp_ex.c	No	Yes	No	Yes	No	Yes	No	Yes	No	No	No	No	Yes	No
stm32f4xx_hal_dac.c	Yes	No	No	Yes	Yes	Yes	Yes							
stm32f4xx_hal_dac_ex.c	Yes	No	No	Yes	Yes	Yes	Yes							
stm32f4xx_hal_dcmi.c	No	No	Yes	Yes	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	No
stm32f4xx_hal_dma.c	Yes													
stm32f4xx_hal_dma2d.c	No	No	No	No	Yes	Yes	Yes	Yes	No	No	No	Yes	Yes	No
stm32f4xx_hal_dma_ex.c	Yes													
stm32f4xx_hal_dsi.c	No	Yes	No											
stm32f4xx_hal_eth.c	No	No	Yes	Yes	Yes	Yes	Yes	Yes	No	No	No	Yes	Yes	No
stm32f4xx_hal_flash.c	Yes													
stm32f4xx_hal_flash_ex.c	No	No	No	No	Yes									
stm32f4xx_hal_fmp12c.c	No	Yes	No	No	Yes									
stm32f4xx_hal_fmp12c_ex.c	No	Yes	No	No	Yes									
stm32f4xx_hal_gpio.c	Yes													
stm32f4xx_hal_hash.c	No	Yes	No	Yes	No	Yes	No	Yes	No	No	No	No	Yes	No
stm32f4xx_hal_hash_ex.c	No	No	No	No	No	Yes	No	Yes	No	No	No	No	No	Yes
stm32f4xx_hal_hcd.c	Yes	No												
stm32f4xx_hal_i2c.c	Yes													
stm32f4xx_hal_i2c_ex.c	No	No	No	No	Yes									
stm32f4xx_hal_i2s.c	Yes													
stm32f4xx_hal_irda.c	Yes													
stm32f4xx_hal_iwdg.c	Yes													
stm32f4xx_hal_lptim.c	No	Yes												
stm32f4xx_hal_ltdc.c	No	No	No	No	No	No	Yes	Yes	No	No	No	Yes	Yes	No
stm32f4xx_hal_ltdc_ex.c	No	Yes	Yes	No										
stm32f4xx_hal_nand.c	Yes	No	No	Yes	Yes	Yes	No							
stm32f4xx_hal_nor.c	Yes	No	No	Yes	Yes	Yes	No							
stm32f4xx_hal_pccard.c	Yes	No	No	No	No	No	No							

IP/Module	STM32F405xx	STM32F415xx	STM32F407xx	STM32F417xx	STM32F427xx	STM32F437xx	STM32F429xx	STM32F439xx	STM32F401xC	STM32F401xE	STM32F446xx	STM32F469xx	STM32F479xx	STM32F410xx
stm32f4xx_hal_pcd.c	Yes	No												
stm32f4xx_hal_pwr.c	Yes													
stm32f4xx_hal_pwr_ex.c	No	No	No	No	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	Yes
stm32f4xx_hal_qspi.c	No	Yes	Yes	Yes	No									
stm32f4xx_hal_rcc.c	Yes													
stm32f4xx_hal_rcc_ex.c	Yes													
stm32f4xx_hal_rng.c	Yes	No	Yes	Yes	Yes									
stm32f4xx_hal_rtc.c	Yes													
stm32f4xx_hal_rtc_ex.c	Yes													
stm32f4xx_hal_sai.c	No	No	No	No	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	No
stm32f4xx_hal_sai_ex.c	No	No	No	No	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	No
stm32f4xx_hal_sd.c	Yes	No												
stm32f4xx_hal_sdram.c	No	No	No	No	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	No
stm32f4xx_hal_smartcard.c	Yes													
stm32f4xx_hal_spdifrx.c	No	Yes	No	No	No									
stm32f4xx_hal_spi.c	Yes													
stm32f4xx_hal_sram.c	Yes	No	No	Yes	Yes	Yes	No							
stm32f4xx_hal_tim.c	Yes													
stm32f4xx_hal_tim_ex.c	Yes													
stm32f4xx_hal_uart.c	Yes													
stm32f4xx_hal_usart.c	Yes													
stm32f4xx_hal_wwdg.c	Yes													
stm32f4xx_ll_fmc.c	No	No	No	No	Yes	Yes	Yes	Yes	No	No	Yes	Yes	Yes	No
stm32f4xx_ll_fsmc.c	Yes	Yes	Yes	Yes	No									
stm32f4xx_ll_sdmmc.c	Yes	No												
stm32f4xx_ll_usb.c	Yes	No												

2.5 HAL drivers rules

2.5.1 HAL API naming rules

The following naming rules are used in HAL drivers:

Table 6: HAL API naming rules

	Generic	Family specific	Device specific
File names	<i>stm32f4xx_hal_ppp (c/h)</i>	<i>stm32f4xx_hal_ppp_ex (c/h)</i>	<i>stm32f4xx_hal_ppp_ex (c/h)</i>
Module name	<i>HAL_PPP_MODULE</i>		
Function name	<i>HAL_PPP_Function</i> <i>HAL_PPP_FeatureFunction_MODE</i>	<i>HAL_PPPEX_Function</i> <i>HAL_PPPEX_FeatureFunction_MODE</i>	<i>HAL_PPPEX_Function</i> <i>HAL_PPPEX_FeatureFunction_MODE</i>
Handle name	<i>PPP_HandleTypeDef</i>	NA	NA
Init structure name	<i>PPP_InitTypeDef</i>	NA	<i>PPP_InitTypeDef</i>
Enum name	<i>HAL_PPP_StructnameTypeDef</i>	NA	NA

- The **PPP** prefix refers to the peripheral functional mode and not to the peripheral itself. For example, if the USART, PPP can be USART, IRDA, UART or SMARTCARD depending on the peripheral mode.
- The constants used in one file are defined within this file. A constant used in several files is defined in a header file. All constants are written in uppercase, except for peripheral driver function parameters.
- typedef variable names should be suffixed with _TypeDef.
- Registers are considered as constants. In most cases, their name is in uppercase and uses the same acronyms as in the STM32F4xx reference manuals.
- Peripheral registers are declared in the PPP_TypeDef structure (e.g. ADC_TypeDef) in stm32f4xxx.h header file. stm32f4xxx.h corresponds to stm32f401xc.h, stm32f401xe.h, stm32f405xx.h, stm32f415xx.h, stm32f407xx.h, stm32f417xx.h, stm32f427xx.h, stm32f437xx.h, stm32f429xx.h, stm32f439xx.h, stm32f446xx.h, stm32f469xx.h, stm32f479xx.h, stm32f410cx.h, stm32f410tx.h or stm32f410rx.h.
- Peripheral function names are prefixed by HAL_, then the corresponding peripheral acronym in uppercase followed by an underscore. The first letter of each word is in uppercase (e.g. HAL_UART_Transmit()). Only one underscore is allowed in a function name to separate the peripheral acronym from the rest of the function name.
- The structure containing the PPP peripheral initialization parameters are named PPP_InitTypeDef (e.g. ADC_InitTypeDef).
- The structure containing the Specific configuration parameters for the PPP peripheral are named PPP_xxxxConfTypeDef (e.g. ADC_ChannelConfTypeDef).
- Peripheral handle structures are named PPP_HandleTypeDef (e.g DMA_HandleTypeDef)
- The functions used to initialize the PPP peripheral according to parameters specified in PPP_InitTypeDef are named HAL_PPP_Init (e.g. HAL_TIM_Init()).

- The functions used to reset the PPP peripheral registers to their default values are named PPP_Delnit, e.g. TIM_Delnit.
- The **MODE** suffix refers to the process mode, which can be polling, interrupt or DMA. As an example, when the DMA is used in addition to the native resources, the function should be called: *HAL_PPP_Function_DMA ()*.
- The **Feature** prefix should refer to the new feature.
Example: *HAL_ADC_InjectionStart()* refers to the injection mode

2.5.2 HAL general naming rules

- For the shared and system peripherals, no handle or instance object is used. This rule applies to the following peripherals:
 - GPIO
 - SYSTICK
 - NVIC
 - RCC
 - FLASH.

Example: The *HAL_GPIO_Init()* requires only the GPIO address and its configuration parameters.

```
HAL_StatusTypeDef HAL_GPIO_Init (GPIO_TypeDef* GPIOx, GPIO_InitTypeDef *Init)
{
/*GPIO Initialization body */
}
```

- The macros that handle interrupts and specific clock configurations are defined in each peripheral/module driver. These macros are exported in the peripheral driver header files so that they can be used by the extension file. The list of these macros is defined below: This list is not exhaustive and other macros related to peripheral features can be added, so that they can be used in the user application.

Table 7: Macros handling interrupts and specific clock configurations

Macros	Description
<code>_HAL_PPP_ENABLE_IT(_HANDLE_, _INTERRUPT_)</code>	Enables a specific peripheral interrupt
<code>_HAL_PPP_DISABLE_IT(_HANDLE_, _INTERRUPT_)</code>	Disables a specific peripheral interrupt
<code>_HAL_PPP_GET_IT (_HANDLE_, _INTERRUPT_)</code>	Gets a specific peripheral interrupt status
<code>_HAL_PPP_CLEAR_IT (_HANDLE_, _INTERRUPT_)</code>	Clears a specific peripheral interrupt status
<code>_HAL_PPP_GET_FLAG (_HANDLE_, _FLAG_)</code>	Gets a specific peripheral flag status
<code>_HAL_PPP_CLEAR_FLAG (_HANDLE_, _FLAG_)</code>	Clears a specific peripheral flag status
<code>_HAL_PPP_ENABLE(_HANDLE_)</code>	Enables a peripheral
<code>_HAL_PPP_DISABLE(_HANDLE_)</code>	Disables a peripheral
<code>_HAL_PPP_XXXX (_HANDLE_, _PARAM_)</code>	Specific PPP HAL driver macro
<code>_HAL_PPP_GET_IT_SOURCE (_HANDLE_, _INTERRUPT_)</code>	Checks the source of specified interrupt

- NVIC and SYSTICK are two ARM Cortex core features. The APIs related to these features are located in the `stm32f4xx_hal_cortex.c` file.
- When a status bit or a flag is read from registers, it is composed of shifted values depending on the number of read values and of their size. In this case, the returned status width is 32 bits. Example : `STATUS = XX | (YY << 16)` or `STATUS=`.
- The PPP handles are valid before using the `HAL_PPP_Init()` API. The init function performs a check before modifying the handle fields.

```
HAL_PPP_Init(PPP_HandleTypeDef) if(hppp == NULL) { return HAL_ERROR; }
```

- The macros defined below are used:
 - Conditional macro:

```
#define ABS(x) (((x) > 0) ? (x) : -(x))
```

- Pseudo-code macro (multiple instructions macro):

```
#define HAL_LINKDMA(_HANDLE_, _PPP_DMA_FIELD_, _DMA_HANDLE_) \ do{ \ \
(_HANDLE_)->_PPP_DMA_FIELD_ = &(_DMA_HANDLE_); \ \
(_DMA_HANDLE_).Parent = \
(_HANDLE_); \ } while(0)
```

2.5.3 HAL interrupt handler and callback functions

Besides the APIs, HAL peripheral drivers include:

- `HAL_PPP_IRQHandler()` peripheral interrupt handler that should be called from `stm32f4xx_it.c`
- User callback functions.

The user callback functions are defined as empty functions with “weak” attribute. They have to be defined in the user code.

There are three types of user callbacks functions:

- Peripheral system level initialization/ de-Initialization callbacks: `HAL_PPP_MspInit()` and `HAL_PPP_MspDeInit()`
- Process complete callbacks : `HAL_PPP_ProcessCpltCallback`
- Error callback: `HAL_PPP_ErrorCallback`.

Table 8: Callback functions

Callback functions	Example
<code>HAL_PPP_MspInit() / _DeInit()</code>	Ex: <code>HAL_USART_MspInit()</code> Called from <code>HAL_PPP_Init()</code> API function to perform peripheral system level initialization (GPIOs, clock, DMA, interrupt)
<code>HAL_PPP_ProcessCpltCallback</code>	Ex: <code>HAL_USART_TxCpltCallback</code> Called by peripheral or DMA interrupt handler when the process completes
<code>HAL_PPP_ErrorCallback</code>	Ex: <code>HAL_USART_ErrorCallback</code> Called by peripheral or DMA interrupt handler when an error occurs

2.6 HAL generic APIs

The generic APIs provide common generic functions applying to all STM32 devices. They are composed of four APIs groups:

- **Initialization and de-initialization functions:** HAL_PPP_Init(), HAL_PPP_DeInit()
- **IO operation functions:** HAL_PPP_Read(), HAL_PPP_Write(), HAL_PPP_Transmit(), HAL_PPP_Receive()
- **Control functions:** HAL_PPP_Set(), HAL_PPP_Get().
- **State and Errors functions:** HAL_PPP_GetState(), HAL_PPP_GetError().

For some peripheral/module drivers, these groups are modified depending on the peripheral/module implementation.

Example: in the timer driver, the API grouping is based on timer features (PWM, OC, IC...).

The initialization and de-initialization functions allow initializing a peripheral and configuring the low-level resources, mainly clocks, GPIO, alternate functions (AF) and possibly DMA and interrupts. The *HAL_DeInit()* function restores the peripheral default state, frees the low-level resources and removes any direct dependency with the hardware.

The IO operation functions perform a row access to the peripheral payload data in write and read modes.

The control functions are used to change dynamically the peripheral configuration and set another operating mode.

The peripheral state and errors functions allow retrieving in runtime the peripheral and data flow states, and identifying the type of errors that occurred. The example below is based on the ADC peripheral. The list of generic APIs is not exhaustive. It is only given as an example.

Table 9: HAL generic APIs

Function Group	Common API Name	Description
<i>Initialization group</i>	<i>HAL_ADC_Init()</i>	This function initializes the peripheral and configures the low -level resources (clocks, GPIO, AF..)
	<i>HAL_ADC_DeInit()</i>	This function restores the peripheral default state, frees the low-level resources and removes any direct dependency with the hardware.
<i>IO operation group</i>	<i>HAL_ADC_Start()</i>	This function starts ADC conversions when the polling method is used
	<i>HAL_ADC_Stop()</i>	This function stops ADC conversions when the polling method is used
	<i>HAL_ADC_PollForConversion()</i>	This function allows waiting for the end of conversions when the polling method is used. In this case, a timeout value is specified by the user according to the application.
	<i>HAL_ADC_Start_IT()</i>	This function starts ADC conversions when the interrupt method is used
	<i>HAL_ADC_Stop_IT()</i>	This function stops ADC conversions when the interrupt method is used
	<i>HAL_ADC_IRQHandler()</i>	This function handles ADC interrupt requests

Function Group	Common API Name	Description
	<code>HAL_ADC_ConvCpltCallback()</code>	Callback function called in the IT subroutine to indicate the end of the current process or when a DMA transfer has completed
	<code>HAL_ADC_ErrorCallback()</code>	Callback function called in the IT subroutine if a peripheral error or a DMA transfer error occurred
<i>Control group</i>	<code>HAL_ADC_ConfigChannel()</code>	This function configures the selected ADC regular channel, the corresponding rank in the sequencer and the sample time
	<code>HAL_ADC_AnalogWDGConfig</code>	This function configures the analog watchdog for the selected ADC
<i>State and Errors group</i>	<code>HAL_ADC_GetState()</code>	This function allows getting in runtime the peripheral and the data flow states.
	<code>HAL_ADC_GetError()</code>	This function allows getting in runtime the error that occurred during IT routine

2.7 HAL extension APIs

2.7.1 HAL extension model overview

The extension APIs provide specific functions or overwrite modified APIs for a specific family (series) or specific part number within the same family.

The extension model consists of an additional file, `stm32f4xx_hal_ppp_ex.c`, that includes all the specific functions and define statements (`stm32f4xx_hal_ppp_ex.h`) for a given part number.

Below an example based on the ADC peripheral:

Table 10: HAL extension APIs

Function Group	Common API Name
<code>HAL_ADCEx_InjectedStart()</code>	This function starts injected channel ADC conversions when the polling method is used
<code>HAL_ADCEx_InjectedStop()</code>	This function stops injected channel ADC conversions when the polling method is used
<code>HAL_ADCEx_InjectedStart_IT()</code>	This function starts injected channel ADC conversions when the interrupt method is used
<code>HAL_ADCEx_InjectedStop_IT()</code>	This function stops injected channel ADC conversions when the interrupt method is used
<code>HAL_ADCEx_InjectedConfigChannel()</code>	This function configures the selected ADC Injected channel (corresponding rank in the sequencer and sample time)


2.7.2 HAL extension model cases

The specific IP features can be handled by the HAL drivers in five different ways. They are described below.

Case1: Adding a part number-specific function

When a new feature specific to a given device is required, the new APIs are added in the `stm32f4xx_hal_ppp_ex.c` extension file. They are named `HAL_PPPEx_Function()`.

Figure 2: Adding device-specific functions




Example: `stm32f4xx_hal_flash_ex.c/h`

```
#if defined(STM32F427xx) || defined(STM32F437xx) || defined(STM32F429xx) ||
defined(STM32F439xx)
HAL_StatusTypeDef HAL_FLASHEx_OB_SelectPCROP(void);
HAL_StatusTypeDef HAL_FLASHEx_OB_DeSelectPCROP(void);
#endif /* STM32F427xx || STM32F437xx || STM32F429xx || STM32F439xx */
```

Case2: Adding a family-specific function

In this case, the API is added in the extension driver C file and named `HAL_PPPEx_Function()`.

Figure 3: Adding family-specific functions



Example: `stm32f4xx_hal_adc_ex.c/h`


```
HAL_StatusTypeDef HAL_ADCEx_InjectedStop(ADC_HandleTypeDef* hadc);
HAL_StatusTypeDef HAL_ADCEx_InjectedStop_IT(ADC_HandleTypeDef* hadc);
HAL_StatusTypeDef HAL_ADCEx_InjectedStart(ADC_HandleTypeDef* hadc);
HAL_StatusTypeDef HAL_ADCEx_InjectedStart_IT(ADC_HandleTypeDef* hadc);
```

Case3 : Adding a new peripheral (specific to a device belonging to a given family)

When a peripheral which is available only in a specific device is required, the APIs corresponding to this new peripheral/module are added in `stm32f4xx_hal_newppp.c`. However the inclusion of this file is selected in the `stm32fxx_hal_conf.h` using the macro:

```
#define HAL_NEWPPP_MODULE_ENABLED
```

Figure 4: Adding new peripherals




Example: `stm32f4xx_hal_sai.c/h`

Case4: Updating existing common APIs

In this case, the routines are defined with the same names in the `stm32f4xx_hal_ppp_ex.c` extension file, while the generic API is defined as *weak*, so that the compiler will overwrite the original routine by the new defined function.

Figure 5: Updating existing APIs



Case5 : Updating existing data structures

The data structure for a specific device part number (e.g. `PPP_InitTypeDef`) can have different fields. In this case, the data structure is defined in the extension header file and delimited by the specific part number define statement.

Example:


```
#if defined (STM32F401xx)
typedef struct
{
(...)

}PPP_InitTypeDef;
#endif /* STM32F401xx */
```

2.8 File inclusion model

The header of the common HAL driver file (stm32f4xx_hal.h) includes the common configurations for the whole HAL library. It is the only header file that is included in the user sources and the HAL C sources files to be able to use the HAL resources.

Figure 6: File inclusion model



A PPP driver is a standalone module which is used in a project. The user must enable the corresponding USE_HAL_PPP_MODULE define statement in the configuration file.

```
/*
 * @file stm32f4xx_hal_conf.h
 * @author MCD Application Team
 * @version VX.Y.Z * @date dd-mm-yyyy
 * @brief This file contains the modules to be used
 */
(...)

#define USE_HAL_USART_MODULE
#define USE_HAL_IRDA_MODULE
#define USE_HAL_DMA_MODULE
#define USE_HAL_RCC_MODULE
(...)
```

2.9 HAL common resources

The common HAL resources, such as common define enumerations, structures and macros, are defined in *stm32f4xx_hal_def.h*. The main common define enumeration is *HAL_StatusTypeDef*.

- HAL Status** The HAL status is used by almost all HAL APIs, except for boolean functions and IRQ handler. It returns the status of the current API operations. It has four possible values as described below:

```
Typedef enum
{ HAL_OK = 0x00, HAL_ERROR = 0x01, HAL_BUSY = 0x02, HAL_TIMEOUT = 0x03
} HAL_StatusTypeDef;
```

- **HAL Locked** The HAL lock is used by all HAL APIs to prevent accessing by accident shared resources.

```
typedef enum
{ HAL_UNLOCKED = 0x00, /*!<Resources unlocked */ HAL_LOCKED = 0x01 /*!< Resources
locked */
} HAL_LockTypeDef;
```

- In addition to common resources, the `stm32f4xx_hal_def.h` file calls the `stm32f4xx.h` file in CMSIS library to get the data structures and the address mapping for all peripherals:
 - Declarations of peripheral registers and bits definition.
 - Macros to access peripheral registers hardware (Write register, Read register...etc.).
- **Common macros**
 - Macro defining `HAL_MAX_DELAY`#define `HAL_MAX_DELAY` 0xFFFFFFFF
 - Macro linking a PPP peripheral to a DMA structure pointer:

```
_HAL_LINKDMA();
#define _HAL_LINKDMA(__HANDLE__, __PPP_DMA_FIELD__, __DMA_HANDLE__) \
do{ \
( __HANDLE__ )-> PPP_DMA_FIELD__ = &( __DMA_HANDLE__ ); \
( __DMA_HANDLE__ ).Parent = ( __HANDLE__ ); \
} while(0)
```

2.10 HAL configuration

The configuration file, `stm32f4xx_hal_conf.h`, allows customizing the drivers for the user application. Modifying this configuration is not mandatory: the application can use the default configuration without any modification.

To configure these parameters, the user should enable, disable or modify some options by uncommenting, commenting or modifying the values of the related define statements as described in the table below:

Table 11: Define statements used for HAL configuration

Configuration item	Description	Default Value
HSE_VALUE	Defines the value of the external oscillator (HSE) expressed in Hz. The user must adjust this define statement when using a different crystal value.	25 000 000 (Hz)
HSE_STARTUP_TIMEOUT	Timeout for HSE start up, expressed in ms	5000
HSI_VALUE	Defines the value of the internal oscillator (HSI) expressed in Hz.	16 000 000 (Hz)
EXTERNAL_CLOCK_VALUE	This value is used by the I2S/SAI HAL module to compute the I2S/SAI clock source frequency, this source is inserted directly through I2S_CKIN pad.	12288000 (Hz)
VDD_VALUE	VDD value	3300 (mV)
USE_RTOs	Enables the use of RTOS	FALSE (for future use)
PREFETCH_ENABLE	Enables prefetch feature	TRUE

Configuration item	Description	Default Value
INSTRUCTION_CACHE_ENABLE	Enables instruction cache	TRUE
DATA_CACHE_ENABLE	Enables data cache	TRUE
USE HAL PPP MODULE	Enables module to be used in the HAL driver	
MAC_ADDRx	Ethernet peripheral configuration : MAC address	
ETH_RX_BUF_SIZE	Ethernet buffer size for receive	ETH_MAX_PACKET_SIZE
ETH_TX_BUF_SIZE	Ethernet buffer size for trasmit	ETH_MAX_PACKET_SIZE
ETH_RXBUFNB	The number of Rx buffers of size ETH_RX_BUF_SIZE	4
ETH_TXBUFNB	The number of Tx buffers of size ETH_RX_BUF_SIZE	4
DP83848_PHY_ADDRESS	DB83848 Ethernet PHY Address	0x01
PHY_RESET_DELAY	PHY Reset delay these values are based on a 1 ms Systick interrupt	0x000000FF
PHY_CONFIG_DELAY	PHY Configuration delay	0x00000FFF
PHY_BCR PHY_BSR	Common PHY Registers	
PHY_SR PHY_MICR PHY_MISR	Extended PHY registers	



The `stm32f4xx_hal_conf_template.h` file is located in the HAL drivers `/Inc` folder. It should be copied to the user folder, renamed and modified as described above.



By default, the values defined in the `stm32f4xx_hal_conf_template.h` file are the same as the ones used for the examples and demonstrations. All HAL include files are enabled so that they can be used in the user code without modifications.

2.11 HAL system peripheral handling

This chapter gives an overview of how the system peripherals are handled by the HAL drivers. The full API list is provided within each peripheral driver description section.

2.11.1 Clock

Two main functions can be used to configure the system clock:

- `HAL_RCC_OscConfig (RCC_OscInitTypeDef *RCC_OscInitStruct)`. This function configures/enables multiple clock sources (HSE, HSI, LSE, LSI, PLL).
- `HAL_RCC_ClockConfig (RCC_ClkInitTypeDef *RCC_ClkInitStruct, uint32_t FLatency)`. This function
 - Selects the system clock source

- Configures AHB, APB1 and APB2 clock dividers
- Configures the number of Flash memory wait states
- Updates the SysTick configuration when HCLK clock changes.

Some peripheral clocks are not derived from the system clock (RTC, SDIO, I2S, SAI, Audio PLL...). In this case, the clock configuration is performed by an extended API defined in `stm32f4xx_hal_ppp_ex.c`: `HAL_RCCEx_PeriphCLKConfig(RCC_PeriphCLKInitTypeDef *PeriphClkInit)`.

Additional RCC HAL driver functions are available:

- `HAL_RCC_DelInit()` Clock de-init function that return clock configuration to reset state
- Get clock functions that allow retrieving various clock configurations (system clock, HCLK, PCLK1, PCLK2, ...)
- MCO and CSS configuration functions

A set of macros are defined in `stm32f4xx_hal_rcc.h`. They allows executing elementary operations on RCC block registers, such as peripherals clock gating/reset control:

- `__PPP_CLK_ENABLE/__PPP_CLK_DISABLE` to enable/disable the peripheral clock
- `__PPP_FORCE_RESET/__PPP_RELEASE_RESET` to force/release peripheral reset
- `__PPP_CLK_SLEEP_ENABLE/__PPP_CLK_SLEEP_DISABLE` to enable/disable the peripheral clock during low power (Sleep) mode.

2.11.2 GPIOs

GPIO HAL APIs are the following:

- `HAL_GPIO_Init()` / `HAL_GPIO_DeInit()`
- `HAL_GPIO_ReadPin()` / `HAL_GPIO_WritePin()`
- `HAL_GPIO_TogglePin ()`.

In addition to standard GPIO modes (input, output, analog), pin mode can be configured as EXTI with interrupt or event generation.

When selecting EXTI mode with interrupt generation, the user must call `HAL_GPIO_EXTI_IRQHandler()` from `stm32f4xx_it.c` and implement `HAL_GPIO_EXTI_Callback()`

The table below describes the `GPIO_InitTypeDef` structure field.

Table 12: Description of `GPIO_InitTypeDef` structure

Structure field	Description
Pin	Specifies the GPIO pins to be configured. Possible values: <code>GPIO_PIN_x</code> or <code>GPIO_PIN_All</code> , where <code>x[0..15]</code>

Structure field	Description
Mode	<p>Specifies the operating mode for the selected pins: GPIO mode or EXTI mode.</p> <p>Possible values are:</p> <ul style="list-style-type: none"> • <u>GPIO mode</u> <ul style="list-style-type: none"> – GPIO_MODE_INPUT : Input Floating – GPIO_MODE_OUTPUT_PP : Output Push Pull – GPIO_MODE_OUTPUT_OD : Output Open Drain – GPIO_MODE_AF_PP : Alternate Function Push Pull – GPIO_MODE_AF_OD : Alternate Function Open Drain – GPIO_MODE_ANALOG : Analog mode • <u>External Interrupt Mode</u> <ul style="list-style-type: none"> – GPIO_MODE_IT_RISING : Rising edge trigger detection – GPIO_MODE_IT_FALLING : Falling edge trigger detection – GPIO_MODE_IT_RISING_FALLING : Rising/Falling edge trigger detection • <u>External Event Mode</u> <ul style="list-style-type: none"> – GPIO_MODE_EVT_RISING : Rising edge trigger detection – GPIO_MODE_EVT_FALLING : Falling edge trigger detection – GPIO_MODE_EVT_RISING_FALLING: Rising/Falling edge trigger detection
Pull	<p>Specifies the Pull-up or Pull-down activation for the selected pins.</p> <p>Possible values are:</p> <p>GPIO_NOPULL GPIO_PULLUP GPIO_PULLDOWN</p>
Speed	<p>Specifies the speed for the selected pins</p> <p>Possible values are:</p> <p>GPIO_SPEED_LOW GPIO_SPEED_MEDIUM GPIO_SPEED_FAST GPIO_SPEED_HIGH</p>
Alternate	<p>Peripheral to be connected to the selected pins.</p> <p>Possible values: GPIO_AFx PPP, where</p> <p>AFx: is the alternate function index</p> <p>PPP: is the peripheral instance</p> <p>Example: use GPIO_AF1_TIM1 to connect TIM1 IOs on AF1.</p> <p>These values are defined in the GPIO extended driver, since the AF mapping may change between product lines.</p> <p></p> <p>Refer to the “Alternate function mapping” table in the datasheets for the detailed description of the system and peripheral I/O alternate functions.</p>

Please find below typical GPIO configuration examples:

- Configuring GPIOs as output push-pull to drive external LEDs

```
GPIO_InitStruct.Pin = GPIO_PIN_12 | GPIO_PIN_13 | GPIO_PIN_14 | GPIO_PIN_15;
GPIO_InitStruct.Mode = GPIO_MODE_OUTPUT_PP;
GPIO_InitStruct.Pull = GPIO_PULLUP;
GPIO_InitStruct.Speed = GPIO_SPEED_FAST;
HAL_GPIO_Init(GPIOD, &GPIO_InitStruct);
```

- Configuring PA0 as external interrupt with falling edge sensitivity:

```
GPIO_InitStructure.Mode = GPIO_MODE_IT_FALLING;
GPIO_InitStructure.Pull = GPIO_NOPULL;
GPIO_InitStructure.Pin = GPIO_PIN_0;
HAL_GPIO_Init(GPIOA, &GPIO_InitStructure);
```

- Configuring USART3 Tx (PC10, mapped on AF7) as alternate function:

```
GPIO_InitStruct.Pin = GPIO_PIN_10;
GPIO_InitStruct.Mode = GPIO_MODE_AF_PP;
GPIO_InitStruct.Pull = GPIO_PULLUP;
GPIO_InitStruct.Speed = GPIO_SPEED_FAST;
GPIO_InitStruct.Alternate = GPIO_AF7_USART3;
HAL_GPIO_Init(GPIOC, &GPIO_InitStruct);
```

2.11.3 Cortex NVIC and SysTick timer

The Cortex HAL driver, `stm32f4xx_hal_cortex.c`, provides APIs to handle NVIC and Systick. The supported APIs include:

- HAL_NVIC_SetPriorityGrouping()
- HAL_NVIC_SetPriority()
- HAL_NVIC_EnableIRQ() / HAL_NVIC_DisableIRQ()
- HAL_NVIC_SystemReset()
- HAL_NVIC_GetPendingIRQ() / HAL_NVIC_SetPendingIRQ() / HAL_NVIC_ClearPendingIRQ()
- HAL_SYSTICK_Config()
- HAL_SYSTICK_CLKSourceConfig()

2.11.4 PWR

The PWR HAL driver handles power management. The features shared between all STM32 Series are listed below:

- PVD configuration, enabling/disabling and interrupt handling
 - HAL_PWR_PVDCfg()
 - HAL_PWR_EnablePVD() / HAL_PWR_DisablePVD()
 - HAL_PWR_PVD_IRQHandler()
 - HAL_PWR_PVDCallback()
- Wakeup pin configuration
 - HAL_PWR_EnableWakeUpPin() / HAL_PWR_DisableWakeUpPin()
- Low power mode entry
 - HAL_PWR_EnterSLEEPMode()
 - HAL_PWR_EnterSTOPMode()
 - HAL_PWR_EnterSTANDBYMode()

Depending on the STM32 Series, extension functions are available in `stm32f4xx_hal_pwr_ex`. Here are a few examples (the list is not exhaustive)

- Backup domain registers enable/disable
 - HAL_PWREx_EnableBkUpReg() / HAL_PWREx_DisableBkUpReg()
- Flash overdrive control and flash power-down, for STM32F429/F439xx only
 - HAL_PWREx_ActivateOverDrive()
 - HAL_PWREx_EnableFlashPowerDown().

2.11.5 EXTI

The EXTI is not considered as a standalone peripheral but rather as a service used by other peripheral. As a result there are no EXTI APIs but each peripheral HAL driver implements the associated EXTI configuration and EXTI function are implemented as macros in its header file.

The first 16 EXTI lines connected to the GPIOs are managed within the GPIO driver. The GPIO_InitTypeDef structure allows configuring an I/O as external interrupt or external event.

The EXTI lines connected internally to the PVD, RTC, USB, and COMP are configured within the HAL drivers of these peripheral through the macros given in the table below. The EXTI internal connections depend on the targeted STM32 microcontroller (refer to the product datasheet for more details):

Table 13: Description of EXTI configuration macros

Macros	Description
PPP_EXTI_LINE_FUNCTION	Defines the EXTI line connected to the internal peripheral. Example: <code>#define PWR_EXTI_LINE_PVD ((uint32_t)0x00010000) /*!<External interrupt line 16 Connected to the PVD EXTI Line */</code>
_HAL_PPP_EXTI_ENABLE_IT(__EXTI_LINE__)	Enables a given EXTI line Example: <code>_HAL_PVD_EXTI_ENABLE_IT(PWR_EXTI_LINE_PVD)</code>
_HAL_PPP_EXTI_DISABLE_IT(__EXTI_LINE__)	Disables a given EXTI line. Example: <code>_HAL_PVD_EXTI_DISABLE_IT(PWR_EXTI_LINE_PVD)</code>
_HAL_PPP_EXTI_GET_FLAG(__EXTI_LINE__)	Gets a given EXTI line interrupt flag pending bit status. Example: <code>_HAL_PVD_EXTI_GET_FLAG(PWR_EXTI_LINE_PVD)</code>
_HAL_PPP_EXTI_CLEAR_FLAG(__EXTI_LINE__)	Clears a given EXTI line interrupt flag pending bit. Example: <code>_HAL_PVD_EXTI_CLEAR_FLAG(PWR_EXTI_LINE_PVD)</code>
_HAL_PPP_EXTI_GENERATE_SWIT (__EXTI_LINE__)	Generates a software interrupt for a given EXTI line. Example: <code>_HAL_PVD_EXTI_GENERATE_SWIT (PWR_EXTI_LINE_PVD)</code>

If the EXTI interrupt mode is selected, the user application must call HAL_PPP_FUNCTION_IRQHandler() (for example HAL_PWR_PVD_IRQHandler()), from stm32f4xx_it.c file, and implement HAL_PPP_FUNCTIONCallback() callback function (for example HAL_PWR_PVDCallback()).

2.11.6 DMA

The DMA HAL driver allows enabling and configuring the peripheral to be connected to the DMA Stream (except for internal SRAM/FLASH memory which do not require any initialization). Refer to the product reference manual for details on the DMA request corresponding to each peripheral.

For a given stream, HAL_DMA_Init() API allows programming the required configuration through the following parameters:

- Transfer Direction
- Source and Destination data formats
- Circular, Normal or peripheral flow control mode
- Stream Priority level
- Source and Destination Increment mode
- FIFO mode and its Threshold (if needed)
- Burst mode for Source and/or Destination (if needed).

Two operating modes are available:

- Polling mode I/O operation
 - a. Use HAL_DMA_Start() to start DMA transfer when the source and destination addresses and the Length of data to be transferred have been configured.
 - b. Use HAL_DMA_PollForTransfer() to poll for the end of current transfer. In this case a fixed timeout can be configured depending on the user application.
- Interrupt mode I/O operation
 - a. Configure the DMA interrupt priority using HAL_NVIC_SetPriority()
 - b. Enable the DMA IRQ handler using HAL_NVIC_EnableIRQ()
 - c. Use HAL_DMA_Start_IT() to start DMA transfer when the source and destination addresses and the length of data to be transferred have been configured. In this case the DMA interrupt is configured.
 - d. Use HAL_DMA_IRQHandler() called under DMA_IRQHandler() Interrupt subroutine
 - e. When data transfer is complete, HAL_DMA_IRQHandler() function is executed and a user function can be called by customizing XferCpltCallback and XferErrorCallback function pointer (i.e. a member of DMA handle structure).

Additional functions and macros are available to ensure efficient DMA management:

- Use HAL_DMA_GetState() function to return the DMA state and HAL_DMA_GetError() in case of error detection.
- Use HAL_DMA_Abort() function to abort the current transfer

The most used DMA HAL driver macros are the following:

- __HAL_DMA_ENABLE: enables the specified DMA Stream.
- __HAL_DMA_DISABLE: disables the specified DMA Stream.
- __HAL_DMA_GET_FS: returns the current DMA Stream FIFO filled level.
- __HAL_DMA_GET_FLAG: gets the DMA Stream pending flags.
- __HAL_DMA_CLEAR_FLAG: clears the DMA Stream pending flags.
- __HAL_DMA_ENABLE_IT: enables the specified DMA Stream interrupts.
- __HAL_DMA_DISABLE_IT: disables the specified DMA Stream interrupts.
- __HAL_DMA_GET_IT_SOURCE: checks whether the specified DMA stream interrupt has occurred or not.



When a peripheral is used in DMA mode, the DMA initialization should be done in the HAL_PPP_MspInit() callback. In addition, the user application should associate the DMA handle to the PPP handle (refer to section “HAL IO operation functions”).



DMA double-buffering feature is handled as an extension API.




DMA channel callbacks need to be initialized by the user application only in case of memory-to-memory transfer. However when peripheral-to-memory transfers are used, these callbacks are automatically initialized by calling a process API function that uses the DMA.

2.12 How to use HAL drivers

2.12.1 HAL usage models

The following figure shows the typical use of the HAL driver and the interaction between the application user, the HAL driver and the interrupts.

Figure 7: HAL driver model



Basically, the HAL driver APIs are called from user files and optionally from interrupt handlers file when the APIs based on the DMA or the PPP peripheral dedicated interrupts are used.

When DMA or PPP peripheral interrupts are used, the PPP process complete callbacks are called to inform the user about the process completion in real-time event mode (interrupts). Note that the same process completion callbacks are used for DMA in interrupt mode.

2.12.2 HAL initialization

2.12.2.1 HAL global initialization

In addition to the peripheral initialization and de-initialization functions, a set of APIs are provided to initialize the HAL core implemented in file `stm32f4xx_hal.c`.

- `HAL_Init()`: this function must be called at application startup to
 - Initialize data/instruction cache and pre-fetch queue
 - Set SysTick timer to generate an interrupt each 1ms (based on HSI clock) with the lowest priority
 - Set priority grouping to 4 preemption bits
 - Call `HAL_MspInit()` user callback function to perform system level initializations (Clock, GPIOs, DMA, interrupts). `HAL_MspInit()` is defined as “weak” empty function in the HAL drivers.
- `HAL_DeInit()`
 - Resets all peripherals
 - Calls function `HAL_MspDeInit()` which is a user callback function to do system level De-Initializations.
- `HAL_GetTick()`: this function gets current SysTick counter value (incremented in SysTick interrupt) used by peripherals drivers to handle timeouts.
- `HAL_Delay()`: this function implements a delay (expressed in milliseconds) using the SysTick timer.

Care must be taken when using `HAL_Delay()` since this function provides an accurate delay (expressed in milliseconds) based on a variable incremented in SysTick ISR.

This means that if `HAL_Delay()` is called from a peripheral ISR, then the SysTick interrupt must have highest priority (numerically lower) than the peripheral interrupt, otherwise the caller ISR will be blocked.



In STM32Cube V1.0 implemented in STM32CubeF2 and STM32CubeF4 first versions, the SysTick timer is used as default timebase. This has been modified to allow implementing user-defined timebases (such as a general-purpose timer), keeping in mind that the timebase duration must be kept at 1 ms since all `PPP_TIMEOUT_VALUES` are defined and handled in milliseconds. This enhancement is implemented in STM32Cube V1.1 that is deployed starting from STM32CubeL0/F0/F3 and later. This modification is backward compatible with STM32Cube V1.0 implementation. Functions affecting timebase configurations are declared as `__Weak` to allow different implementations in the user file.

2.12.2.2 System clock initialization

The clock configuration is done at the beginning of the user code. However the user can change the configuration of the clock in his own code. Please find below the typical Clock configuration sequence:

```
static void SystemClock_Config(void)
{
    RCC_ClkInitTypeDef RCC_ClkInitStruct;
    RCC_OscInitTypeDef RCC_OscInitStruct;
    /* Enable HSE Oscillator and activate PLL with HSE as source */
    RCC_OscInitStruct.OscillatorType = RCC_OSCILLATORTYPE_HSE;
    RCC_OscInitStruct.HSEState = RCC_HSE_ON;
    RCC_OscInitStruct.PLL.PLLState = RCC_PLL_ON;
    RCC_OscInitStruct.PLL.PLLSource = RCC_PLLSOURCE_HSE;
    RCC_OscInitStruct.PLL.PLLM = 25;
    RCC_OscInitStruct.PLL.PLLN = 336;
    RCC_OscInitStruct.PLL.PLLP = RCC_PLLP_DIV2;
    RCC_OscInitStruct.PLL.PLLQ = 7;
    HAL_RCC_OscConfig(&RCC_OscInitStruct);
    /* Select PLL as system clock source and configure the HCLK, PCLK1 and PCLK2 clocks
     * dividers */
    RCC_ClkInitStruct.ClockType = (RCC_CLOCKTYPE_SYSCLK | RCC_CLOCKTYPE_HCLK |
        RCC_CLOCKTYPE_PCLK1 | RCC_CLOCKTYPE_PCLK2);
    RCC_ClkInitStruct.SYSCLKSource = RCC_SYSCLKSOURCE_PLLCLK;
    RCC_ClkInitStruct.AHBCLKDivider = RCC_SYSCLK_DIV1;
    RCC_ClkInitStruct.APB1CLKDivider = RCC_HCLK_DIV4;
    RCC_ClkInitStruct.APB2CLKDivider = RCC_HCLK_DIV2;
    HAL_RCC_ClockConfig(&RCC_ClkInitStruct, FLASH_LATENCY_5); }
```

2.12.2.3 HAL MSP initialization process

The peripheral initialization is done through *HAL_PPP_Init()* while the hardware resources initialization used by a peripheral (PPP) is performed during this initialization by calling MSP callback function *HAL_PPP_MspInit()*.

The MspInit callback performs the low level initialization related to the different additional hardware resources: RCC, GPIO, NVIC and DMA.

All the HAL drivers with handles include two MSP callbacks for initialization and de-initialization:

```
/** 
 * @brief Initializes the PPP MSP.
 * @param hppp: PPP handle
 * @retval None */
void __weak HAL_PPP_MspInit(PPP_HandleTypeDef *hppp) {
/* NOTE : This function Should not be modified, when the callback is needed,
the HAL_PPP_MspInit could be implemented in the user file */
}
/** 
 * @brief DeInitializes PPP MSP.
 * @param hppp: PPP handle
 * @retval None */
void __weak HAL_PPP_MspDeInit(PPP_HandleTypeDef *hppp) {
/* NOTE : This function Should not be modified, when the callback is needed,
the HAL_PPP_MspDeInit could be implemented in the user file */
}
```

The MSP callbacks are declared empty as weak functions in each peripheral driver. The user can use them to set the low level initialization code or omit them and use his own initialization routine.

The HAL MSP callback is implemented inside the *stm32f4xx_hal_msp.c* file in the user folders. An *stm32f4xx_hal_msp.c* file template is located in the HAL folder and should be copied to the user folder. It can be generated automatically by STM32CubeMX tool and

further modified. Note that all the routines are declared as weak functions and could be overwritten or removed to use user low level initialization code.

Stm32f4xx_hal_msp.c file contains the following functions:

Table 14: MSP functions

Routine	Description
void HAL_MspInit()	Global MSP initialization routine
void HAL_MspDeInit()	Global MSP de-initialization routine
void HAL_PPP_MspInit()	PPP MSP initialization routine
void HAL_PPP_MspDeInit()	PPP MSP de-initialization routine

By default, if no peripheral needs to be de-initialized during the program execution, the whole MSP initialization is done in *Hal_MspInit()* and MSP De-Initialization in the *Hal_MspDeInit()*. In this case the *HAL_PPP_MspInit()* and *HAL_PPP_MspDeInit()* are not implemented.

When one or more peripherals needs to be de-initialized in run time and the low level resources of a given peripheral need to be released and used by another peripheral, *HAL_PPP_MspDeInit()* and *HAL_PPP_MspInit()* are implemented for the concerned peripheral and other peripherals initialization and de-Initialization are kept in the global *HAL_MspInit()* and the *HAL_MspDeInit()*.

If there is nothing to be initialized by the global *HAL_MspInit()* and *HAL_MspDeInit()*, the two routines can simply be omitted.

2.12.3 HAL IO operation process

The HAL functions with internal data processing like Transmit, Receive, Write and Read are generally provided with three data processing modes as follows:

- Polling mode
- Interrupt mode
- DMA mode

2.12.3.1 Polling mode

In polling mode, the HAL functions return the process status when the data processing in blocking mode is complete. The operation is considered complete when the function returns the *HAL_OK* status, otherwise an error status is returned. The user can get more information through the *HAL_PPP_GetState()* function. The data processing is handled internally in a loop. A timeout (expressed in ms) is used to prevent process hanging.

The example below shows the typical polling mode processing sequence :

```

HAL_StatusTypeDef HAL_PPP_Transmit ( PPP_HandleTypeDef * phandle, uint8_t
pData,
int16_t tSize,uint32_t tTimeout)
{
if((pData == NULL ) || (Size == 0))
{
return HAL_ERROR;
}
(...) while (data processing is running)
{
if( timeout reached )
{
return HAL_TIMEOUT;
}
}

```

```

    }
    (...)
```

2.12.3.2 Interrupt mode

In Interrupt mode, the HAL function returns the process status after starting the data processing and enabling the appropriate interruption. The end of the operation is indicated by a callback declared as a weak function. It can be customized by the user to be informed in real-time about the process completion. The user can also get the process status through the *HAL_PPP_GetState()* function.

In interrupt mode, four functions are declared in the driver:

- *HAL_PPP_Process_IT()*: launch the process
- *HAL_PPP_IRQHandler()*: the global PPP peripheral interruption
- *__weak HAL_PPP_ProcessCpltCallback ()*: the callback relative to the process completion.
- *__weak HAL_PPP_ProcessErrorCallback()*: the callback relative to the process Error.

To use a process in interrupt mode, *HAL_PPP_Process_IT()* is called in the user file and *HAL_PPP_IRQHandler* in *stm32f4xx_it.c*.

The *HAL_PPP_ProcessCpltCallback()* function is declared as weak function in the driver. This means that the user can declare it again in the application. The function in the driver is not modified.

An example of use is illustrated below:

main.c file:

```

UART_HandleTypeDef UartHandle;
int main(void)
{
/* Set User Parameters */
UartHandle.Init.BaudRate = 9600;
UartHandle.Init.WordLength = UART_DATABITS_8;
UartHandle.Init.StopBits = UART_STOPBITS_1;
UartHandle.Init.Parity = UART_PARITY_NONE;
UartHandle.Init.HwFlowCtl = UART_HWCONTROL_NONE;
UartHandle.Init.Mode = UART_MODE_TX_RX;
UartHandle.Init.Instance = USART3;
HAL_UART_Init(&UartHandle);
HAL_UART_SendIT(&UartHandle, TxBuffer, sizeof(TxBuffer));
while (1);
}
void HAL_UART_TxCpltCallback(UART_HandleTypeDef *huart)
{
}
void HAL_UART_ErrorCallback(UART_HandleTypeDef *huart)
{}
```

stm32f4xx_it.c file:

```

extern UART_HandleTypeDef UartHandle;
void USART3_IRQHandler(void)
{
HAL_UART_IRQHandler(&UartHandle);
}
```

2.12.3.3 DMA mode

In DMA mode, the HAL function returns the process status after starting the data processing through the DMA and after enabling the appropriate DMA interruption. The end of the operation is indicated by a callback declared as a weak function and can be customized by the user to be informed in real-time about the process completion. The user can also get the process status through the *HAL_PPP_GetState()* function. For the DMA mode, three functions are declared in the driver:

- *HAL_PPP_Process_DMA()*: launch the process
- *HAL_PPP_DMA_IRQHandler()*: the DMA interruption used by the PPP peripheral
- *__weak HAL_PPP_ProcessCpltCallback()*: the callback relative to the process completion.
- *__weak HAL_PPP_ErrorCpltCallback()*: the callback relative to the process Error.

To use a process in DMA mode, *HAL_PPP_Process_DMA()* is called in the user file and the *HAL_PPP_DMA_IRQHandler()* is placed in the *stm32f4xx_it.c*. When DMA mode is used, the DMA initialization is done in the *HAL_PPP_MspInit()* callback. The user should also associate the DMA handle to the PPP handle. For this purpose, the handles of all the peripheral drivers that use the DMA must be declared as follows:

```
typedef struct
{
    PPP_TypeDef *Instance; /* Register base address */
    PPP_InitTypeDef Init; /* PPP communication parameters */
    HAL_StateTypeDef State; /* PPP communication state */
    ...
    DMA_HandleTypeDef *hdma; /* associated DMA handle */
} PPP_HandleTypeDef;
```

The initialization is done as follows (UART example):

```
int main(void)
{
    /* Set User Parameters */
    UartHandle.Init.BaudRate = 9600;
    UartHandle.Init.WordLength = UART_DATABITS_8;
    UartHandle.Init.StopBits = UART_STOPBITS_1;
    UartHandle.Init.Parity = UART_PARITY_NONE;
    UartHandle.Init.HwFlowCtl = UART_HWCONTROL_NONE;
    UartHandle.Init.Mode = UART_MODE_TX_RX;
    UartHandle.Init.Instance = USART3;
    HAL_USART_Init(&UartHandle);
    ...
}
void HAL_USART_MspInit (USART_HandleTypeDef * huart)
{
    static DMA_HandleTypeDef hdma_tx;
    static DMA_HandleTypeDef hdma_rx;
    ...
    HAL_LINKDMA(UartHandle, DMA_Handle tx, hdma_tx);
    HAL_LINKDMA(UartHandle, DMA_Handle rx, hdma_rx);
}
```

The *HAL_PPP_ProcessCpltCallback()* function is declared as weak function in the driver that means, the user can declare it again in the application code. The function in the driver should not be modified.

An example of use is illustrated below:

main.c file:

```

UART_HandleTypeDef UartHandle;
int main(void)
{
/* Set User Parameters */
UartHandle.Init.BaudRate = 9600;
UartHandle.Init.WordLength = UART_DATABITS_8;
UartHandle.Init.StopBits = UART_STOPBITS_1;
UartHandle.Init.Parity = UART_PARITY_NONE;
UartHandle.Init.HwFlowCtl = UART_HWCONTROL_NONE;
UartHandle.Init.Mode = UART_MODE_TX_RX;
UartHandle.Instance = USART3;
HAL_UART_Init(&UartHandle);
HAL_UART_Send_DMA(&UartHandle, TxBuffer, sizeof(TxBuffer));
while (1);
}
void HAL_UART_TxCpltCallback(UART_HandleTypeDef *phuart)
{
}
void HAL_UART_ErrorCallback(UART_HandleTypeDef *phuart)
{
}

```

stm32f4xx_it.c file:

```

extern UART_HandleTypeDef UartHandle;
void DMAx_IRQHandler(void)
{
HAL_DMA_IRQHandler(&UartHandle.DMA_Handle.tx);
}

```

HAL_USART_TxCpltCallback() and *HAL_USART_ErrorCallback()* should be linked in the *HAL_PPP_Process_DMA()* function to the DMA transfer complete callback and the DMA transfer Error callback by using the following statement:

```

HAL_PPP_Process_DMA (PPP_HandleTypeDef *hppp, Params...)
{
(...)
hppp->DMA_Handle->XferCpltCallback = HAL_UART_TxCpltCallback ;
hppp->DMA_Handle->XferErrorCallback = HAL_UART_ErrorCallback ;
(... )
}

```

2.12.4 Timeout and error management

2.12.4.1 Timeout management

The timeout is often used for the APIs that operate in polling mode. It defines the delay during which a blocking process should wait till an error is returned. An example is provided below:

```

HAL_StatusTypeDef HAL_DMA_PollForTransfer(DMA_HandleTypeDef *hdma, uint32_t
CompleteLevel, uint32_t Timeout)

```

The timeout possible value are the following:

Table 15: Timeout values

Timeout value	Description
0	No poll : Immediate process check and exit
1 ... (HAL_MAX_DELAY -1) ⁽¹⁾	Timeout in ms
HAL_MAX_DELAY	Infinite poll till process is successful

Notes:

⁽¹⁾HAL_MAX_DELAY is defined in the stm32fxxx_hal_def.h as 0xFFFFFFFF

However, in some cases, a fixed timeout is used for system peripherals or internal HAL driver processes. In these cases, the timeout has the same meaning and is used in the same way, except when it is defined locally in the drivers and cannot be modified or introduced as an argument in the user application.

Example of fixed timeout:

```
#define LOCAL_PROCESS_TIMEOUT 100
HAL_StatusTypeDef HAL_PPP_Process(PPP_HandleTypeDef)
{
    ...
    ...
    timeout = HAL_GetTick() + LOCAL_PROCESS_TIMEOUT;
    ...
    while(ProcessOngoing)
    {
        ...
        if(HAL_GetTick() >= timeout)
        {
            /* Process unlocked */
            __HAL_UNLOCK(hppp);
            hppp->State= HAL PPP STATE TIMEOUT;
            return HAL PPP STATE TIMEOUT;
        }
    }
    ...
}
```

The following example shows how to use the timeout inside the polling functions:

```
HAL_PPP_StateTypeDef HAL_PPP_Poll (PPP_HandleTypeDef *hppp, uint32_t Timeout)
{
    ...
    ...
    timeout = HAL_GetTick() + Timeout;
    ...
    while(ProcessOngoing)
    {
        ...
        if(Timeout != HAL_MAX_DELAY)
        {
            if(HAL_GetTick() >= timeout)
            {
                /* Process unlocked */
                __HAL_UNLOCK(hppp);
                hppp->State= HAL PPP STATE TIMEOUT;
                return hppp->State;
            }
        }
        ...
    }
}
```

2.12.4.2 Error management

The HAL drivers implement a check for the following items:

- Valid parameters: for some process the used parameters should be valid and already defined, otherwise the system can crash or go into an undefined state. These critical parameters are checked before they are used (see example below).

```
HAL_StatusTypeDef HAL_PPP_Process(PPP_HandleTypeDef* hppp, uint32_t *pdata, uint32_t Size)
{
    if ((pData == NULL) || (Size == 0))
    {
        return HAL_ERROR;
    }
}
```

- Valid handle: the PPP peripheral handle is the most important argument since it keeps the PPP driver vital parameters. It is always checked in the beginning of the *HAL_PPP_Init()* function.

```
HAL_StatusTypeDef HAL_PPP_Init(PPP_HandleTypeDef* hppp)
{
    if (hppp == NULL) //the handle should be already allocated
    { return HAL_ERROR;
    }
}
```

- Timeout error: the following statement is used when a timeout error occurs:

```
while (Process_ongoing)
{
    timeout = HAL_GetTick() + Timeout; while (data processing is running)
    {
        if(timeout)
        { return HAL_TIMEOUT;
        }
    }
}
```

When an error occurs during a peripheral process, *HAL_PPP_Process()* returns with a *HAL_ERROR* status. The HAL PPP driver implements the *HAL_PPP_GetError()* to allow retrieving the origin of the error.

```
HAL_PPP_ErrorTypeDef HAL_PPP_GetError (PPP_HandleTypeDef *hppp);
```

In all peripheral handles, a *HAL_PPP_ErrorTypeDef* is defined and used to store the last error code.

```
typedef struct
{
    PPP_TypeDef * Instance; /* PPP registers base address */
    PPP_InitTypeDef Init; /* PPP initialization parameters */
    HAL_LockTypeDef Lock; /* PPP locking object */
    __IO HAL_PPP_StateTypeDef State; /* PPP state */
    __IO HAL_PPP_ErrorTypeDef ErrorCode; /* PPP Error code */
    ...
    /* PPP specific parameters */
}
PPP_HandleTypeDef;
```

The error state and the peripheral global state are always updated before returning an error:

```
PPP->State = HAL_PPP_READY; /* Set the peripheral ready */
PP->ErrorCode = HAL_ERRORCODE ; /* Set the error code */
HAL_UNLOCK(PPP) ; /* Unlock the PPP resources */
return HAL_ERROR; /*return with HAL error */
```

HAL_PPP_GetError() must be used in interrupt mode in the error callback:

```
void HAL_PPP_ProcessCpltCallback(PPP_HandleTypeDef *hspi)
{
    ErrorCode = HAL_PPP_GetError (hppp); /* retreive error code */
}
```

2.12.4.3 Run-time checking

The HAL implements run-time failure detection by checking the input values of all HAL drivers functions. The run-time checking is achieved by using an `assert_param` macro. This macro is used in all the HAL drivers' functions which have an input parameter. It allows verifying that the input value lies within the parameter allowed values.

To enable the run-time checking, use the `assert_param` macro, and leave the define `USE_FULL_ASSERT` uncommented in `stm32f34xx_hal_conf.h` file.

```
void HAL_UART_Init(UART_HandleTypeDef *huart)
{
    (...) /* Check the parameters */
    assert_param(IS_UART_INSTANCE(huart->Instance));
    assert_param(IS_UART_BAUDRATE(huart->Init.BaudRate));
    assert_param(IS_UART_WORD_LENGTH(huart->Init.WordLength));
    assert_param(IS_UART_STOPBITS(huart->Init.StopBits));
    assert_param(IS_UART_PARITY(huart->Init.Parity));
    assert_param(IS_UART_MODE(huart->Init.Mode));
    assert_param(IS_UART_HARDWARE_FLOW_CONTROL(huart->Init.HwFlowCtl));
    (...)

    /** @defgroup UART_Word_Length */
    @{
    /*
     * #define UART_WORDLENGTH_8B ((uint32_t)0x00000000)
     * #define UART_WORDLENGTH_9B ((uint32_t)USART_CR1_M)
     * #define IS_UART_WORD_LENGTH(LENGTH) (((LENGTH) == UART_WORDLENGTH_8B) ||
     * \ ((LENGTH) == UART_WORDLENGTH_9B))
    */
}
```

If the expression passed to the `assert_param` macro is false, the `assert_failed` function is called and returns the name of the source file and the source line number of the call that failed. If the expression is true, no value is returned.

The `assert_param` macro is implemented in `stm32f4xx_hal_conf.h`:

```
/* Exported macro -----*/
#ifndef USE_FULL_ASSERT
/**
 * @brief The assert param macro is used for function's parameters check.
 * @param expr: If expr is false, it calls assert_failed function
 * which reports the name of the source file and the source
 * line number of the call that failed.
 * If expr is true, it returns no value.
 * @retval None */
#define assert_param(expr) ((expr)?(void)0:assert_failed((uint8_t *) FILE ,
LINE_))
/* Exported functions -----*/
void assert_failed(uint8_t* file, uint32_t line);
#endif /* USE_FULL_ASSERT */
```

The `assert_failed` function is implemented in the `main.c` file or in any other user C file:

```
#ifdef USE_FULL_ASSERT /**
 * @brief Reports the name of the source file and the source line number
 * where the assert_param error has occurred.
 * @param file: pointer to the source file name
 * @param line: assert_param error line source number
 * @retval None */
void assert_failed(uint8_t* file, uint32_t line)
{
    /* User can add his own implementation to report the file name and line number,
    ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */
    /* Infinite loop */
    while (1)
{
```

```
}
```



Because of the overhead run-time checking introduces, it is recommended to use it during application code development and debugging, and to remove it from the final application to improve code size and speed.

3 HAL System Driver

3.1 HAL System Driver

3.2 HAL Firmware driver API description

3.2.1 How to use this driver

The common HAL driver contains a set of generic and common APIs that can be used by the PPP peripheral drivers and the user to start using the HAL.

The HAL contains two APIs' categories:

- Common HAL APIs
- Services HAL APIs

3.2.2 Initialization and de-initialization functions

This section provides functions allowing to:

- Initializes the Flash interface the NVIC allocation and initial clock configuration. It initializes the systick also when timeout is needed and the backup domain when enabled.
- de-Initializes common part of the HAL
- Configure The time base source to have 1ms time base with a dedicated Tick interrupt priority.
 - Systick timer is used by default as source of time base, but user can eventually implement his proper time base source (a general purpose timer for example or other time source), keeping in mind that Time base duration should be kept 1ms since PPP_TIMEOUT_VALUES are defined and handled in milliseconds basis.
 - Time base configuration function (HAL_InitTick ()) is called automatically at the beginning of the program after reset by HAL_Init() or at any time when clock is configured, by HAL_RCC_ClockConfig().
 - Source of time base is configured to generate interrupts at regular time intervals. Care must be taken if HAL_Delay() is called from a peripheral ISR process, the Tick interrupt line must have higher priority (numerically lower) than the peripheral interrupt. Otherwise the caller ISR process will be blocked.
 - functions affecting time base configurations are declared as __weak to make override possible in case of other implementations in user file.

This section contains the following APIs:

- [*HAL_Init\(\)*](#)
- [*HAL_DeInit\(\)*](#)
- [*HAL_MspInit\(\)*](#)
- [*HAL_MspDeInit\(\)*](#)
- [*HAL_InitTick\(\)*](#)

3.2.3 HAL Control functions

This section provides functions allowing to:

- Provide a tick value in millisecond
- Provide a blocking delay in millisecond
- Suspend the time base source interrupt
- Resume the time base source interrupt

- Get the HAL API driver version
- Get the device identifier
- Get the device revision identifier
- Enable/Disable Debug module during SLEEP mode
- Enable/Disable Debug module during STOP mode
- Enable/Disable Debug module during STANDBY mode

This section contains the following APIs:

- `HAL_IncTick()`
- `HAL_GetTick()`
- `HAL_Delay()`
- `HAL_SuspendTick()`
- `HAL_ResumeTick()`
- `HAL_GetHalVersion()`
- `HAL_GetREVID()`
- `HAL_GetDEVID()`
- `HAL_DBGMCU_EnableDBGSleepMode()`
- `HAL_DBGMCU_DisableDBGSleepMode()`
- `HAL_DBGMCU_EnableDBGStopMode()`
- `HAL_DBGMCU_DisableDBGStopMode()`
- `HAL_DBGMCU_EnableDBGStandbyMode()`
- `HAL_DBGMCU_DisableDBGStandbyMode()`
- `HAL_EnableCompensationCell()`
- `HAL_DisableCompensationCell()`
- `HAL_EnableMemorySwappingBank()`
- `HAL_DisableMemorySwappingBank()`

3.2.4 HAL_Init

Function Name	HAL_StatusTypeDef HAL_Init (void)
Function Description	This function is used to initialize the HAL Library; it must be the first instruction to be executed in the main program (before to call any other HAL function), it performs the following: Configure the Flash prefetch, instruction and Data caches.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • SysTick is used as time base for the HAL_Delay() function, the application need to ensure that the SysTick time base is always set to 1 millisecond to have correct HAL operation.

3.2.5 HAL_DelInit

Function Name	HAL_StatusTypeDef HAL_DelInit (void)
Function Description	This function de-Initializes common part of the HAL and stops the systick.
Return values	<ul style="list-style-type: none"> • HAL status

3.2.6 HAL_MsplInit

Function Name	void HAL_MsplInit (void)
Function Description	Initializes the MSP.

Return values	<ul style="list-style-type: none"> None
3.2.7 HAL_MspDeInit	
Function Name	void HAL_MspDeInit (void)
Function Description	DeInitializes the MSP.
Return values	<ul style="list-style-type: none"> None
3.2.8 HAL_InitTick	
Function Name	HAL_StatusTypeDef HAL_InitTick (uint32_t TickPriority)
Function Description	This function configures the source of the time base.
Parameters	<ul style="list-style-type: none"> TickPriority: Tick interrupt priority.
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> This function is called automatically at the beginning of program after reset by HAL_Init() or at any time when clock is reconfigured by HAL_RCC_ClockConfig(). In the default implementation, SysTick timer is the source of time base. It is used to generate interrupts at regular time intervals. Care must be taken if HAL_Delay() is called from a peripheral ISR process, The the SysTick interrupt must have higher priority (numerically lower) than the peripheral interrupt. Otherwise the caller ISR process will be blocked. The function is declared as __weak to be overwritten in case of other implementation in user file.
3.2.9 HAL_IncTick	
Function Name	void HAL_IncTick (void)
Function Description	This function is called to increment a global variable "uwTick" used as application time base.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> In the default implementation, this variable is incremented each 1ms in Systick ISR. This function is declared as __weak to be overwritten in case of other implementations in user file.
3.2.10 HAL_GetTick	
Function Name	uint32_t HAL_GetTick (void)
Function Description	Provides a tick value in millisecond.
Return values	<ul style="list-style-type: none"> tick value
Notes	<ul style="list-style-type: none"> This function is declared as __weak to be overwritten in case of other implementations in user file.
3.2.11 HAL_Delay	
Function Name	void HAL_Delay (__IO uint32_t Delay)

Function Description	This function provides accurate delay (in milliseconds) based on variable incremented.
Parameters	<ul style="list-style-type: none"> • Delay: specifies the delay time length, in milliseconds.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • In the default implementation , SysTick timer is the source of time base. It is used to generate interrupts at regular time intervals where uwTick is incremented. • This function is declared as __weak to be overwritten in case of other implementations in user file.

3.2.12 HAL_SuspendTick

Function Name	void HAL_SuspendTick (void)
Function Description	Suspend Tick increment.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • In the default implementation , SysTick timer is the source of time base. It is used to generate interrupts at regular time intervals. Once HAL_SuspendTick() is called, the SysTick interrupt will be disabled and so Tick increment is suspended. • This function is declared as __weak to be overwritten in case of other implementations in user file.

3.2.13 HAL_ResumeTick

Function Name	void HAL_ResumeTick (void)
Function Description	Resume Tick increment.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • In the default implementation , SysTick timer is the source of time base. It is used to generate interrupts at regular time intervals. Once HAL_ResumeTick() is called, the SysTick interrupt will be enabled and so Tick increment is resumed. • This function is declared as __weak to be overwritten in case of other implementations in user file.

3.2.14 HAL_GetHalVersion

Function Name	uint32_t HAL_GetHalVersion (void)
Function Description	Returns the HAL revision.
Return values	<ul style="list-style-type: none"> • version : 0xXYZR (8bits for each decimal, R for RC)

3.2.15 HAL_GetREVID

Function Name	uint32_t HAL_GetREVID (void)
Function Description	Returns the device revision identifier.
Return values	<ul style="list-style-type: none"> • Device revision identifier

3.2.16 HAL_GetDEVID



Function Name	uint32_t HAL_GetDEVID (void)
Function Description	Returns the device identifier.
Return values	<ul style="list-style-type: none"> • Device identifier
3.2.17	HAL_DBGMCU_EnableDBGSleepMode
Function Name	void HAL_DBGMCU_EnableDBGSleepMode (void)
Function Description	Enable the Debug Module during SLEEP mode.
Return values	<ul style="list-style-type: none"> • None
3.2.18	HAL_DBGMCU_DisableDBGSleepMode
Function Name	void HAL_DBGMCU_DisableDBGSleepMode (void)
Function Description	Disable the Debug Module during SLEEP mode.
Return values	<ul style="list-style-type: none"> • None
3.2.19	HAL_DBGMCU_EnableDBGStopMode
Function Name	void HAL_DBGMCU_EnableDBGStopMode (void)
Function Description	Enable the Debug Module during STOP mode.
Return values	<ul style="list-style-type: none"> • None
3.2.20	HAL_DBGMCU_DisableDBGStopMode
Function Name	void HAL_DBGMCU_DisableDBGStopMode (void)
Function Description	Disable the Debug Module during STOP mode.
Return values	<ul style="list-style-type: none"> • None
3.2.21	HAL_DBGMCU_EnableDBGStandbyMode
Function Name	void HAL_DBGMCU_EnableDBGStandbyMode (void)
Function Description	Enable the Debug Module during STANDBY mode.
Return values	<ul style="list-style-type: none"> • None
3.2.22	HAL_DBGMCU_DisableDBGStandbyMode
Function Name	void HAL_DBGMCU_DisableDBGStandbyMode (void)
Function Description	Disable the Debug Module during STANDBY mode.
Return values	<ul style="list-style-type: none"> • None
3.2.23	HAL_EnableCompensationCell
Function Name	void HAL_EnableCompensationCell (void)
Function Description	Enables the I/O Compensation Cell.
Return values	<ul style="list-style-type: none"> • None

Notes	<ul style="list-style-type: none"> The I/O compensation cell can be used only when the device supply voltage ranges from 2.4 to 3.6 V.
-------	---

3.2.24 HAL_DisableCompensationCell

Function Name	void HAL_DisableCompensationCell (void)
Function Description	Power-down the I/O Compensation Cell.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> The I/O compensation cell can be used only when the device supply voltage ranges from 2.4 to 3.6 V.

3.2.25 HAL_EnableMemorySwappingBank

Function Name	void HAL_EnableMemorySwappingBank (void)
Function Description	Enables the Internal FLASH Bank Swapping.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This function can be used only for STM32F42xxx/43xxx devices. Flash Bank2 mapped at 0x08000000 (and aliased @0x00000000) and Flash Bank1 mapped at 0x08100000 (and aliased at 0x00100000)

3.2.26 HAL_DisableMemorySwappingBank

Function Name	void HAL_DisableMemorySwappingBank (void)
Function Description	Disables the Internal FLASH Bank Swapping.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This function can be used only for STM32F42xxx/43xxx devices. The default state : Flash Bank1 mapped at 0x08000000 (and aliased @0x0000 0000) and Flash Bank2 mapped at 0x08100000 (and aliased at 0x00100000)

3.3 HAL Firmware driver defines

3.3.1 HAL

HAL CAN Error Code

HAL_CAN_ERROR_NONE	No error
HAL_CAN_ERROR_EWG	EWG error
HAL_CAN_ERROR_EPV	EPV error
HAL_CAN_ERROR_BOF	BOF error
HAL_CAN_ERROR_STF	Stuff error
HAL_CAN_ERROR_FOR	Form error
HAL_CAN_ERROR_ACK	Acknowledgment error

HAL_CAN_ERROR_BR	Bit recessive
HAL_CAN_ERROR_BD	LEC dominant
HAL_CAN_ERROR_CRC	LEC transfer error

HAL Exported Macros

_HAL_DBGMCU_FREEZE_TIM2
_HAL_DBGMCU_FREEZE_TIM3
_HAL_DBGMCU_FREEZE_TIM4
_HAL_DBGMCU_FREEZE_TIM5
_HAL_DBGMCU_FREEZE_TIM6
_HAL_DBGMCU_FREEZE_TIM7
_HAL_DBGMCU_FREEZE_TIM12
_HAL_DBGMCU_FREEZE_TIM13
_HAL_DBGMCU_FREEZE_TIM14
_HAL_DBGMCU_FREEZE_RTC
_HAL_DBGMCU_FREEZE_WWDG
_HAL_DBGMCU_FREEZE_IWDG
_HAL_DBGMCU_FREEZE_I2C1_TIMEOUT
_HAL_DBGMCU_FREEZE_I2C2_TIMEOUT
_HAL_DBGMCU_FREEZE_I2C3_TIMEOUT
_HAL_DBGMCU_FREEZE_CAN1
_HAL_DBGMCU_FREEZE_CAN2
_HAL_DBGMCU_FREEZE_TIM1
_HAL_DBGMCU_FREEZE_TIM8
_HAL_DBGMCU_FREEZE_TIM9
_HAL_DBGMCU_FREEZE_TIM10
_HAL_DBGMCU_FREEZE_TIM11
_HAL_DBGMCU_UNFREEZE_TIM2
_HAL_DBGMCU_UNFREEZE_TIM3
_HAL_DBGMCU_UNFREEZE_TIM4
_HAL_DBGMCU_UNFREEZE_TIM5
_HAL_DBGMCU_UNFREEZE_TIM6
_HAL_DBGMCU_UNFREEZE_TIM7
_HAL_DBGMCU_UNFREEZE_TIM12
_HAL_DBGMCU_UNFREEZE_TIM13
_HAL_DBGMCU_UNFREEZE_TIM14
_HAL_DBGMCU_UNFREEZE_RTC

```
_HAL_DBGMCU_UNFREEZE_WWDG
_HAL_DBGMCU_UNFREEZE_IWDG
_HAL_DBGMCU_UNFREEZE_I2C1_TIMEOUT
_HAL_DBGMCU_UNFREEZE_I2C2_TIMEOUT
_HAL_DBGMCU_UNFREEZE_I2C3_TIMEOUT
_HAL_DBGMCU_UNFREEZE_CAN1
_HAL_DBGMCU_UNFREEZE_CAN2
_HAL_DBGMCU_UNFREEZE_TIM1
_HAL_DBGMCU_UNFREEZE_TIM8
_HAL_DBGMCU_UNFREEZE_TIM9
_HAL_DBGMCU_UNFREEZE_TIM10
_HAL_DBGMCU_UNFREEZE_TIM11
_HAL_SYSCFG_REMAPMEMORY_FLASH
_HAL_SYSCFG_REMAPMEMORY_SYSTEMFLASH
_HAL_SYSCFG_REMAPMEMORY_SRAM
_HAL_SYSCFG_REMAPMEMORY_FMC
_HAL_SYSCFG_REMAPMEMORY_FMC_SDRAM
```

HAL Private Constants

```
_STM32F4xx_HAL_VERSION_MAIN [31:24] main version
_STM32F4xx_HAL_VERSION_SUB1 [23:16] sub1 version
_STM32F4xx_HAL_VERSION_SUB2 [15:8] sub2 version
_STM32F4xx_HAL_VERSION_RC [7:0] release candidate
_STM32F4xx_HAL_VERSION
IDCODE_DEVID_MASK
SYSCFG_OFFSET
MEMRMP_OFFSET
UFB_MODE_BIT_NUMBER
UFB_MODE_BB
CMPCR_OFFSET
CMP_PD_BIT_NUMBER
CMPCR_CMP_PD_BB
```

4 HAL ADC Generic Driver

4.1 HAL ADC Generic Driver

4.2 ADC Firmware driver registers structures

4.2.1 ADC_InitTypeDef

Data Fields

- *uint32_t ClockPrescaler*
- *uint32_t Resolution*
- *uint32_t DataAlign*
- *uint32_t ScanConvMode*
- *uint32_t EOCSelection*
- *uint32_t ContinuousConvMode*
- *uint32_t DMAContinuousRequests*
- *uint32_t NbrOfConversion*
- *uint32_t DiscontinuousConvMode*
- *uint32_t NbrOfDiscConversion*
- *uint32_t ExternalTrigConv*
- *uint32_t ExternalTrigConvEdge*

Field Documentation

- ***uint32_t ADC_InitTypeDef::ClockPrescaler***
Select the frequency of the clock to the ADC. The clock is common for all the ADCs.
This parameter can be a value of [*ADC_ClockPrescaler*](#)
- ***uint32_t ADC_InitTypeDef::Resolution***
Configures the ADC resolution dual mode. This parameter can be a value of [*ADC_Resolution*](#)
- ***uint32_t ADC_InitTypeDef::DataAlign***
Specifies whether the ADC data alignment is left or right. This parameter can be a value of [*ADC_data_align*](#)
- ***uint32_t ADC_InitTypeDef::ScanConvMode***
Specifies whether the conversion is performed in Scan (multi channels) or Single (one channel) mode. This parameter can be set to ENABLE or DISABLE
- ***uint32_t ADC_InitTypeDef::EOCSelection***
Specifies whether the EOC flag is set at the end of single channel conversion or at the end of all conversions. This parameter can be a value of [*ADC_EOCSelection*](#)
Note: Impact on overrun when not using DMA: When EOCSelection is set to ADC_EOC_SINGLE_CONV, overrun detection is automatically enabled, in this case each conversion data must be read. To perform ADC conversions without having to read all conversion data, this parameter must be set to ADC_EOC_SEQ_CONV
- ***uint32_t ADC_InitTypeDef::ContinuousConvMode***
Specifies whether the conversion is performed in Continuous or Single mode. This parameter can be set to ENABLE or DISABLE.
- ***uint32_t ADC_InitTypeDef::DMAContinuousRequests***
Specifies whether the DMA requests is performed in Continuous or in Single mode. This parameter can be set to ENABLE or DISABLE.

- ***uint32_t ADC_InitTypeDef::NbrOfConversion***
Specifies the number of ADC conversions that will be done using the sequencer for regular channel group. This parameter must be a number between Min_Data = 1 and Max_Data = 16.
- ***uint32_t ADC_InitTypeDef::DiscontinuousConvMode***
Specifies whether the conversion is performed in Discontinuous or not for regular channels. This parameter can be set to ENABLE or DISABLE.
- ***uint32_t ADC_InitTypeDef::NbrOfDiscConversion***
Specifies the number of ADC discontinuous conversions that will be done using the sequencer for regular channel group. This parameter must be a number between Min_Data = 1 and Max_Data = 8.
- ***uint32_t ADC_InitTypeDef::ExternalTrigConv***
Selects the external event used to trigger the conversion start of regular group. If set to ADC_SOFTWARE_START, external triggers are disabled. This parameter can be a value of [**ADC_External_trigger_Source-Regular**](#) Note: This parameter can be modified only if there is no conversion is ongoing.
- ***uint32_t ADC_InitTypeDef::ExternalTrigConvEdge***
Selects the external trigger edge of regular group. If trigger is set to ADC_SOFTWARE_START, this parameter is discarded. This parameter can be a value of [**ADC_External_trigger_edge-Regular**](#) Note: This parameter can be modified only if there is no conversion is ongoing.

4.2.2 ADC_HandleTypeDef

Data Fields

- ***ADC_TypeDef * Instance***
- ***ADC_InitTypeDef Init***
- ***__IO uint32_t NbrOfCurrentConversionRank***
- ***DMA_HandleTypeDef * DMA_Handle***
- ***HAL_LockTypeDef Lock***
- ***__IO HAL_ADC_StateTypeDef State***
- ***__IO uint32_t ErrorCode***

Field Documentation

- ***ADC_TypeDef* ADC_HandleTypeDef::Instance***
Register base address
- ***ADC_InitTypeDef ADC_HandleTypeDef::Init***
ADC required parameters
- ***__IO uint32_t ADC_HandleTypeDef::NbrOfCurrentConversionRank***
ADC number of current conversion rank
- ***DMA_HandleTypeDef* ADC_HandleTypeDef::DMA_Handle***
Pointer DMA Handler
- ***HAL_LockTypeDef ADC_HandleTypeDef::Lock***
ADC locking object
- ***__IO HAL_ADC_StateTypeDef ADC_HandleTypeDef::State***
ADC communication state
- ***__IO uint32_t ADC_HandleTypeDef::ErrorCode***
ADC Error code

4.2.3 ADC_ChannelConfTypeDef

Data Fields

- *uint32_t Channel*
- *uint32_t Rank*
- *uint32_t SamplingTime*
- *uint32_t Offset*

Field Documentation

- ***uint32_t ADC_ChannelConfTypeDef::Channel***
The ADC channel to configure. This parameter can be a value of [ADC_channels](#)
- ***uint32_t ADC_ChannelConfTypeDef::Rank***
The rank in the regular group sequencer. This parameter must be a number between Min_Data = 1 and Max_Data = 16
- ***uint32_t ADC_ChannelConfTypeDef::SamplingTime***
The sample time value to be set for the selected channel. This parameter can be a value of [ADC_sampling_times](#)
- ***uint32_t ADC_ChannelConfTypeDef::Offset***
Reserved for future use, can be set to 0

4.2.4 ADC_AnalogWDGConfTypeDef

Data Fields

- *uint32_t WatchdogMode*
- *uint32_t HighThreshold*
- *uint32_t LowThreshold*
- *uint32_t Channel*
- *uint32_t ITMode*
- *uint32_t WatchdogNumber*

Field Documentation

- ***uint32_t ADC_AnalogWDGConfTypeDef::WatchdogMode***
Configures the ADC analog watchdog mode. This parameter can be a value of [ADC_analog_watchdog_selection](#)
- ***uint32_t ADC_AnalogWDGConfTypeDef::HighThreshold***
Configures the ADC analog watchdog High threshold value. This parameter must be a 12-bit value.
- ***uint32_t ADC_AnalogWDGConfTypeDef::LowThreshold***
Configures the ADC analog watchdog Low threshold value. This parameter must be a 12-bit value.
- ***uint32_t ADC_AnalogWDGConfTypeDef::Channel***
Configures ADC channel for the analog watchdog. This parameter has an effect only if watchdog mode is configured on single channel This parameter can be a value of [ADC_channels](#)

- ***uint32_t ADC_AnalogWDGConfTypeDef::ITMode***
Specifies whether the analog watchdog is configured in interrupt mode or in polling mode. This parameter can be set to ENABLE or DISABLE
- ***uint32_t ADC_AnalogWDGConfTypeDef::WatchdogNumber***
Reserved for future use, can be set to 0

4.3 ADC Firmware driver API description

4.3.1 ADC Peripheral features

1. 12-bit, 10-bit, 8-bit or 6-bit configurable resolution.
2. Interrupt generation at the end of conversion, end of injected conversion, and in case of analog watchdog or overrun events
3. Single and continuous conversion modes.
4. Scan mode for automatic conversion of channel 0 to channel x.
5. Data alignment with in-built data coherency.
6. Channel-wise programmable sampling time.
7. External trigger option with configurable polarity for both regular and injected conversion.
8. Dual/Triple mode (on devices with 2 ADCs or more).
9. Configurable DMA data storage in Dual/Triple ADC mode.
10. Configurable delay between conversions in Dual/Triple interleaved mode.
11. ADC conversion type (refer to the datasheets).
12. ADC supply requirements: 2.4 V to 3.6 V at full speed and down to 1.8 V at slower speed.
13. ADC input range: VREF(minus) = VIN = VREF(plus).
14. DMA request generation during regular channel conversion.

4.3.2 How to use this driver

1. Initialize the ADC low level resources by implementing the HAL_ADC_MspInit():
 - a. Enable the ADC interface clock using `__HAL_RCC_ADC_CLK_ENABLE()`
 - b. ADC pins configuration
 - Enable the clock for the ADC GPIOs using the following function: `__HAL_RCC_GPIOx_CLK_ENABLE()`
 - Configure these ADC pins in analog mode using `HAL_GPIO_Init()`
 - c. In case of using interrupts (e.g. `HAL_ADC_Start_IT()`)
 - Configure the ADC interrupt priority using `HAL_NVIC_SetPriority()`
 - Enable the ADC IRQ handler using `HAL_NVIC_EnableIRQ()`
 - In ADC IRQ handler, call `HAL_ADC_IRQHandler()`
 - d. In case of using DMA to control data transfer (e.g. `HAL_ADC_Start_DMA()`)
 - Enable the DMAx interface clock using `__HAL_RCC_DMAx_CLK_ENABLE()`
 - Configure and enable two DMA streams stream for managing data transfer from peripheral to memory (output stream)
 - Associate the initialized DMA handle to the CRYP DMA handle using `__HAL_LINKDMA()`
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the two DMA Streams. The output stream should have higher priority than the input stream.

Configuration of ADC, groups regular/injected, channels parameters

1. Configure the ADC parameters (resolution, data alignment, ...) and regular group parameters (conversion trigger, sequencer, ...) using function HAL_ADC_Init().
2. Configure the channels for regular group parameters (channel number, channel rank into sequencer, ..., into regular group) using function HAL_ADC_ConfigChannel().
3. Optionally, configure the injected group parameters (conversion trigger, sequencer, ..., of injected group) and the channels for injected group parameters (channel number, channel rank into sequencer, ..., into injected group) using function HAL_ADCEx_InjectedConfigChannel().
4. Optionally, configure the analog watchdog parameters (channels monitored, thresholds, ...) using function HAL_ADC_AnalogWDGConfig().
5. Optionally, for devices with several ADC instances: configure the multimode parameters using function HAL_ADCEx_MultiModeConfigChannel().

Execution of ADC conversions

1. ADC driver can be used among three modes: polling, interruption, transfer by DMA.

Polling mode IO operation

- Start the ADC peripheral using HAL_ADC_Start()
- Wait for end of conversion using HAL_ADC_PollForConversion(), at this stage user can specify the value of timeout according to his end application
- To read the ADC converted values, use the HAL_ADC_GetValue() function.
- Stop the ADC peripheral using HAL_ADC_Stop()

Interrupt mode IO operation

- Start the ADC peripheral using HAL_ADC_Start_IT()
- Use HAL_ADC_IRQHandler() called under ADC_IRQHandler() Interrupt subroutine
- At ADC end of conversion HAL_ADC_ConvCpltCallback() function is executed and user can add his own code by customization of function pointer HAL_ADC_ConvCpltCallback
- In case of ADC Error, HAL_ADC_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_ADC_ErrorCallback
- Stop the ADC peripheral using HAL_ADC_Stop_IT()

DMA mode IO operation

- Start the ADC peripheral using HAL_ADC_Start_DMA(), at this stage the user specify the length of data to be transferred at each end of conversion
- At The end of data transfer by HAL_ADC_ConvCpltCallback() function is executed and user can add his own code by customization of function pointer HAL_ADC_ConvCpltCallback
- In case of transfer Error, HAL_ADC_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_ADC_ErrorCallback
- Stop the ADC peripheral using HAL_ADC_Stop_DMA()

ADC HAL driver macros list

Below the list of most used macros in ADC HAL driver.

- `_HAL_ADC_ENABLE` : Enable the ADC peripheral
- `_HAL_ADC_DISABLE` : Disable the ADC peripheral
- `_HAL_ADC_ENABLE_IT`: Enable the ADC end of conversion interrupt
- `_HAL_ADC_DISABLE_IT`: Disable the ADC end of conversion interrupt
- `_HAL_ADC_GET_IT_SOURCE`: Check if the specified ADC interrupt source is enabled or disabled
- `_HAL_ADC_CLEAR_FLAG`: Clear the ADC's pending flags
- `_HAL_ADC_GET_FLAG`: Get the selected ADC's flag status
- `ADC_GET_RESOLUTION`: Return resolution bits in CR1 register



You can refer to the ADC HAL driver header file for more useful macros

Deinitialization of ADC

1. Disable the ADC interface
 - ADC clock can be hard reset and disabled at RCC top level.
 - Hard reset of ADC peripherals using macro
`_HAL_RCC_ADC_FORCE_RESET()`, `_HAL_RCC_ADC_RELEASE_RESET()`.
 - ADC clock disable using the equivalent macro/functions as configuration step.
 - Example: Into `HAL_ADC_MspDelInit()` (recommended code location) or with other device clock parameters configuration:
 - `HAL_RCC_GetOscConfig(&RCC_OscInitStructure);`
 - `RCC_OscInitStructure.OscillatorType = RCC OSCILLATORTYPE_HSI;`
 - `RCC_OscInitStructure.HSISState = RCC_HSI_OFF;` (if not used for system clock)
 - `HAL_RCC_OscConfig(&RCC_OscInitStructure);`
2. ADC pins configuration
 - Disable the clock for the ADC GPIOs using macro
`_HAL_RCC_GPIOx_CLK_DISABLE()`
3. Optionally, in case of usage of ADC with interruptions:
 - Disable the NVIC for ADC using function `HAL_NVIC_DisableIRQ(ADCx_IRQn)`
4. Optionally, in case of usage of DMA:
 - Deinitialize the DMA using function `HAL_DMA_DeInit()`.
 - Disable the NVIC for DMA using function
`HAL_NVIC_DisableIRQ(DMAx_Channelx_IRQn)`

4.3.3 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize and configure the ADC.
- De-initialize the ADC.

This section contains the following APIs:

- `HAL_ADC_Init\(\)`
- `HAL_ADC_DelInit\(\)`
- `HAL_ADC_MspInit\(\)`

-
- [*HAL_ADC_MspDeInit\(\)*](#)

4.3.4 IO operation functions

This section provides functions allowing to:

- Start conversion of regular channel.
- Stop conversion of regular channel.
- Start conversion of regular channel and enable interrupt.
- Stop conversion of regular channel and disable interrupt.
- Start conversion of regular channel and enable DMA transfer.
- Stop conversion of regular channel and disable DMA transfer.
- Handle ADC interrupt request.

This section contains the following APIs:

- [*HAL_ADC_Start\(\)*](#)
- [*HAL_ADC_Stop\(\)*](#)
- [*HAL_ADC_PollForConversion\(\)*](#)
- [*HAL_ADC_PollForEvent\(\)*](#)
- [*HAL_ADC_Start_IT\(\)*](#)
- [*HAL_ADC_Stop_IT\(\)*](#)
- [*HAL_ADC_IRQHandler\(\)*](#)
- [*HAL_ADC_Start_DMA\(\)*](#)
- [*HAL_ADC_Stop_DMA\(\)*](#)
- [*HAL_ADC_GetValue\(\)*](#)
- [*HAL_ADC_ConvCpltCallback\(\)*](#)
- [*HAL_ADC_ConvHalfCpltCallback\(\)*](#)
- [*HAL_ADC_LevelOutOfWindowCallback\(\)*](#)
- [*HAL_ADC_ErrorCallback\(\)*](#)

4.3.5 Peripheral Control functions

This section provides functions allowing to:

- Configure regular channels.
- Configure injected channels.
- Configure multimode.
- Configure the analog watch dog.

This section contains the following APIs:

- [*HAL_ADC_ConfigChannel\(\)*](#)
- [*HAL_ADC_AnalogWDGConfig\(\)*](#)

4.3.6 Peripheral State and errors functions

This subsection provides functions allowing to

- Check the ADC state
- Check the ADC Error

This section contains the following APIs:

- [*HAL_ADC_GetState\(\)*](#)
- [*HAL_ADC_GetError\(\)*](#)

4.3.7 HAL_ADC_Init

Function Name	HAL_StatusTypeDef HAL_ADC_Init (ADC_HandleTypeDef * hadc)
Function Description	Initializes the ADCx peripheral according to the specified parameters in the ADC_InitStruct and initializes the ADC MSP.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used to configure the global features of the ADC (ClockPrescaler, Resolution, Data Alignment and number of conversion), however, the rest of the configuration parameters are specific to the regular channels group (scan mode activation, continuous mode activation, External trigger source and edge, DMA continuous request after the last transfer and End of conversion selection).

4.3.8 HAL_ADC_DeInit

Function Name	HAL_StatusTypeDef HAL_ADC_DeInit (ADC_HandleTypeDef * hadc)
Function Description	Deinitializes the ADCx peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status

4.3.9 HAL_ADC_MspInit

Function Name	void HAL_ADC_MspInit (ADC_HandleTypeDef * hadc)
Function Description	Initializes the ADC MSP.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • None

4.3.10 HAL_ADC_MspDeInit

Function Name	void HAL_ADC_MspDeInit (ADC_HandleTypeDef * hadc)
Function Description	Deinitializes the ADC MSP.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • None

4.3.11 HAL_ADC_Start

Function Name	HAL_StatusTypeDef HAL_ADC_Start (ADC_HandleTypeDef * hadc)
Function Description	Enables ADC and starts conversion of the regular channels.

Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status

4.3.12 HAL_ADC_Stop

Function Name	HAL_StatusTypeDef HAL_ADC_Stop (ADC_HandleTypeDef * hadc)
Function Description	Disables ADC and stop conversion of regular channels.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status.
Notes	<ul style="list-style-type: none"> • Caution: This function will stop also injected channels.

4.3.13 HAL_ADC_PollForConversion

Function Name	HAL_StatusTypeDef HAL_ADC_PollForConversion (ADC_HandleTypeDef * hadc, uint32_t Timeout)
Function Description	Poll for regular conversion complete.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. • Timeout: Timeout value in millisecond.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • ADC conversion flags EOS (end of sequence) and EOC (end of conversion) are cleared by this function. • This function cannot be used in a particular setup: ADC configured in DMA mode and polling for end of each conversion (ADC init parameter "EOCSelection" set to ADC_EOC_SINGLE_CONV). In this case, DMA resets the flag EOC and polling cannot be performed on each conversion. Nevertheless, polling can still be performed on the complete sequence.

4.3.14 HAL_ADC_PollForEvent

Function Name	HAL_StatusTypeDef HAL_ADC_PollForEvent (ADC_HandleTypeDef * hadc, uint32_t EventType, uint32_t Timeout)
Function Description	Poll for conversion event.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. • EventType: the ADC event type. This parameter can be one of the following values: ADC_AWD_EVENT: ADC Analog watch Dog event. ADC_OVR_EVENT: ADC Overrun event. • Timeout: Timeout value in millisecond.
Return values	<ul style="list-style-type: none"> • HAL status

4.3.15 HAL_ADC_Start_IT

Function Name	HAL_StatusTypeDef HAL_ADC_Start_IT (ADC_HandleTypeDef * hadc)
Function Description	Enables the interrupt and starts ADC conversion of regular channels.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> HAL status.
4.3.16 HAL_ADC_Stop_IT	
Function Name	HAL_StatusTypeDef HAL_ADC_Stop_IT (ADC_HandleTypeDef * hadc)
Function Description	Disables the interrupt and stop ADC conversion of regular channels.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> HAL status.
Notes	<ul style="list-style-type: none"> Caution: This function will stop also injected channels.
4.3.17 HAL_ADC_IRQHandler	
Function Name	void HAL_ADC_IRQHandler (ADC_HandleTypeDef * hadc)
Function Description	Handles ADC interrupt request.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> None
4.3.18 HAL_ADC_Start_DMA	
Function Name	HAL_StatusTypeDef HAL_ADC_Start_DMA (ADC_HandleTypeDef * hadc, uint32_t * pData, uint32_t Length)
Function Description	Enables ADC DMA request after last transfer (Single-ADC mode) and enables ADC peripheral.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. pData: The destination Buffer address. Length: The length of data to be transferred from ADC peripheral to memory.
Return values	<ul style="list-style-type: none"> HAL status
4.3.19 HAL_ADC_Stop_DMA	
Function Name	HAL_StatusTypeDef HAL_ADC_Stop_DMA (ADC_HandleTypeDef * hadc)
Function Description	Disables ADC DMA (Single-ADC mode) and disables ADC peripheral.

Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status
4.3.20 HAL_ADC_GetValue	
Function Name	uint32_t HAL_ADC_GetValue (ADC_HandleTypeDef * hadc)
Function Description	Gets the converted value from data register of regular channel.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • Converted value
4.3.21 HAL_ADC_ConvCpltCallback	
Function Name	void HAL_ADC_ConvCpltCallback (ADC_HandleTypeDef * hadc)
Function Description	Regular conversion complete callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • None
4.3.22 HAL_ADC_ConvHalfCpltCallback	
Function Name	void HAL_ADC_ConvHalfCpltCallback (ADC_HandleTypeDef * hadc)
Function Description	Regular conversion half DMA transfer callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • None
4.3.23 HAL_ADC_LevelOutOfWindowCallback	
Function Name	void HAL_ADC_LevelOutOfWindowCallback (ADC_HandleTypeDef * hadc)
Function Description	Analog watchdog callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • None
4.3.24 HAL_ADC_ErrorCallback	
Function Name	void HAL_ADC_ErrorCallback (ADC_HandleTypeDef * hadc)
Function Description	Error ADC callback.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.

Return values	<ul style="list-style-type: none"> None
4.3.25 HAL_ADC_ConfigChannel	
Function Name	HAL_StatusTypeDef HAL_ADC_ConfigChannel (ADC_HandleTypeDef * hadc, ADC_ChannelConfTypeDef * sConfig)
Function Description	Configures for the selected ADC regular channel its corresponding rank in the sequencer and its sample time.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. sConfig: ADC configuration structure.
Return values	<ul style="list-style-type: none"> HAL status
4.3.26 HAL_ADC_AnalogWDGConfig	
Function Name	HAL_StatusTypeDef HAL_ADC_AnalogWDGConfig (ADC_HandleTypeDef * hadc, ADC_AnalogWDGConfTypeDef * AnalogWDGConfig)
Function Description	Configures the analog watchdog.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. AnalogWDGConfig: : pointer to an ADC_AnalogWDGConfTypeDef structure that contains the configuration information of ADC analog watchdog.
Return values	<ul style="list-style-type: none"> HAL status
4.3.27 HAL_ADC_GetState	
Function Name	HAL_ADC_StateTypeDef HAL_ADC_GetState (ADC_HandleTypeDef * hadc)
Function Description	return the ADC state
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> HAL state
4.3.28 HAL_ADC_GetError	
Function Name	uint32_t HAL_ADC_GetError (ADC_HandleTypeDef * hadc)
Function Description	Return the ADC error code.
Parameters	<ul style="list-style-type: none"> hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> ADC Error Code

4.4 ADC Firmware driver defines

4.4.1 ADC

ADC Analog Watchdog Selection

```
ADC_ANALOGWATCHDOG_SINGLE_REG  
ADC_ANALOGWATCHDOG_SINGLE_INJEC  
ADC_ANALOGWATCHDOG_SINGLE_REGINJEC  
ADC_ANALOGWATCHDOG_ALL_REG  
ADC_ANALOGWATCHDOG_ALL_INJEC  
ADC_ANALOGWATCHDOG_ALL_REGINJEC  
ADC_ANALOGWATCHDOG_NONE
```

ADC Common Channels

```
ADC_CHANNEL_0  
ADC_CHANNEL_1  
ADC_CHANNEL_2  
ADC_CHANNEL_3  
ADC_CHANNEL_4  
ADC_CHANNEL_5  
ADC_CHANNEL_6  
ADC_CHANNEL_7  
ADC_CHANNEL_8  
ADC_CHANNEL_9  
ADC_CHANNEL_10  
ADC_CHANNEL_11  
ADC_CHANNEL_12  
ADC_CHANNEL_13  
ADC_CHANNEL_14  
ADC_CHANNEL_15  
ADC_CHANNEL_16  
ADC_CHANNEL_17  
ADC_CHANNEL_18  
ADC_CHANNEL_VREFINT  
ADC_CHANNEL_VBAT
```

ADC Channels Type

```
ADC_ALL_CHANNELS  
ADC_REGULAR_CHANNELS reserved for future use  
ADC_INJECTED_CHANNELS reserved for future use
```

ADC Clock Prescaler

ADC_CLOCK_SYNC_PCLK_DIV2
ADC_CLOCK_SYNC_PCLK_DIV4
ADC_CLOCK_SYNC_PCLK_DIV6
ADC_CLOCK_SYNC_PCLK_DIV8

ADC Data Align

ADC_DATAALIGN_RIGHT
ADC_DATAALIGN_LEFT

ADC Delay Between 2 Sampling Phases

ADC_TWOSAMPLINGDELAY_5CYCLES
ADC_TWOSAMPLINGDELAY_6CYCLES
ADC_TWOSAMPLINGDELAY_7CYCLES
ADC_TWOSAMPLINGDELAY_8CYCLES
ADC_TWOSAMPLINGDELAY_9CYCLES
ADC_TWOSAMPLINGDELAY_10CYCLES
ADC_TWOSAMPLINGDELAY_11CYCLES
ADC_TWOSAMPLINGDELAY_12CYCLES
ADC_TWOSAMPLINGDELAY_13CYCLES
ADC_TWOSAMPLINGDELAY_14CYCLES
ADC_TWOSAMPLINGDELAY_15CYCLES
ADC_TWOSAMPLINGDELAY_16CYCLES
ADC_TWOSAMPLINGDELAY_17CYCLES
ADC_TWOSAMPLINGDELAY_18CYCLES
ADC_TWOSAMPLINGDELAY_19CYCLES
ADC_TWOSAMPLINGDELAY_20CYCLES

ADC EOC Selection

ADC_EOC_SEQ_CONV
ADC_EOC_SINGLE_CONV
ADC_EOC_SINGLE_SEQ_CONV reserved for future use

ADC Error Code

HAL_ADC_ERROR_NONE No error
HAL_ADC_ERROR_OVR OVR error
HAL_ADC_ERROR_DMA DMA transfer error

ADC Event Type

ADC_AWD_EVENT
ADC_OVR_EVENT

ADC Exported Macros

<code>__HAL_ADC_RESET_HANDLE_STATE</code>	Description:
	<ul style="list-style-type: none"> • Reset ADC handle state.
	Parameters:
	<ul style="list-style-type: none"> • <code>__HANDLE__</code>: ADC handle
	Return value:
	<ul style="list-style-type: none"> • None
<code>__HAL_ADC_ENABLE</code>	Description:
	<ul style="list-style-type: none"> • Enable the ADC peripheral.
	Parameters:
	<ul style="list-style-type: none"> • <code>__HANDLE__</code>: ADC handle
	Return value:
	<ul style="list-style-type: none"> • None
<code>__HAL_ADC_DISABLE</code>	Description:
	<ul style="list-style-type: none"> • Disable the ADC peripheral.
	Parameters:
	<ul style="list-style-type: none"> • <code>__HANDLE__</code>: ADC handle
	Return value:
	<ul style="list-style-type: none"> • None
<code>__HAL_ADC_ENABLE_IT</code>	Description:
	<ul style="list-style-type: none"> • Enable the ADC end of conversion interrupt.
	Parameters:
	<ul style="list-style-type: none"> • <code>__HANDLE__</code>: specifies the ADC Handle. • <code>__INTERRUPT__</code>: ADC Interrupt.
	Return value:
	<ul style="list-style-type: none"> • None
<code>__HAL_ADC_DISABLE_IT</code>	Description:
	<ul style="list-style-type: none"> • Disable the ADC end of conversion interrupt.
	Parameters:
	<ul style="list-style-type: none"> • <code>__HANDLE__</code>: specifies the ADC Handle. • <code>__INTERRUPT__</code>: ADC interrupt.
	Return value:
	<ul style="list-style-type: none"> • None
<code>__HAL_ADC_GET_IT_SOURCE</code>	Description:
	<ul style="list-style-type: none"> • Check if the specified ADC interrupt source is enabled or disabled.

Parameters:

- `_HANDLE_`: specifies the ADC Handle.
- `_INTERRUPT_`: specifies the ADC interrupt source to check.

Return value:

- The: new state of `_IT_` (TRUE or FALSE).

`_HAL_ADC_CLEAR_FLAG`**Description:**

- Clear the ADC's pending flags.

Parameters:

- `_HANDLE_`: specifies the ADC Handle.
- `_FLAG_`: ADC flag.

Return value:

- None

`_HAL_ADC_GET_FLAG`**Description:**

- Get the selected ADC's flag status.

Parameters:

- `_HANDLE_`: specifies the ADC Handle.
- `_FLAG_`: ADC flag.

Return value:

- None

ADC External Trigger Edge Regular

`ADC_EXTERNALTRIGCONVEDGE_NONE`
`ADC_EXTERNALTRIGCONVEDGE_RISING`
`ADC_EXTERNALTRIGCONVEDGE_FALLING`
`ADC_EXTERNALTRIGCONVEDGE_RISINGFALLING`

ADC External Trigger Source Regular

`ADC_EXTERNALTRIGCONV_T1_CC1`
`ADC_EXTERNALTRIGCONV_T1_CC2`
`ADC_EXTERNALTRIGCONV_T1_CC3`
`ADC_EXTERNALTRIGCONV_T2_CC2`
`ADC_EXTERNALTRIGCONV_T2_CC3`
`ADC_EXTERNALTRIGCONV_T2_CC4`
`ADC_EXTERNALTRIGCONV_T2_TRGO`
`ADC_EXTERNALTRIGCONV_T3_CC1`
`ADC_EXTERNALTRIGCONV_T3_TRGO`
`ADC_EXTERNALTRIGCONV_T4_CC4`
`ADC_EXTERNALTRIGCONV_T5_CC1`

ADC_EXTERNALTRIGCONV_T5_CC2
ADC_EXTERNALTRIGCONV_T5_CC3
ADC_EXTERNALTRIGCONV_T8_CC1
ADC_EXTERNALTRIGCONV_T8_TRGO
ADC_EXTERNALTRIGCONV_Ext_IT11
ADC_SOFTWARE_START

ADC Flags Definition

ADC_FLAG_AWD
ADC_FLAG_EOC
ADC_FLAG_JEOC
ADC_FLAG_JSTRT
ADC_FLAG_STRT
ADC_FLAG_OVR

ADC Interrupts Definition

ADC_IT_EOC
ADC_IT_AWD
ADC_IT_JEOC
ADC_IT_OVR

ADC Private Constants

ADC_STAB_DELAY_US
ADC_TEMPSENSOR_DELAY_US

ADC Private Macros

IS_ADC_CLOCKPRESCALER
IS_ADC_SAMPLING_DELAY
IS_ADC_RESOLUTION
IS_ADC_EXT_TRIG_EDGE
IS_ADC_EXT_TRIG
IS_ADC_DATA_ALIGN
IS_ADC_SAMPLE_TIME
IS_ADC_EOCSelection
IS_ADC_EVENT_TYPE
IS_ADC_ANALOG_WATCHDOG
IS_ADC_CHANNELS_TYPE
IS_ADC_THRESHOLD
IS_ADC_REGULAR_LENGTH
IS_ADC_REGULAR_RANK

IS_ADC_REGULAR_DISC_NUMBER

IS_ADC_RANGE

ADC_SQR1

Description:

- Set ADC Regular channel sequence length.

Parameters:

- `_NbrOfConversion_`: Regular channel sequence length.

Return value:

- None

ADC_SMPR1

Description:

- Set the ADC's sample time for channel numbers between 10 and 18.

Parameters:

- `_SAMPLETIME_`: Sample time parameter.
- `_CHANNELNB_`: Channel number.

Return value:

- None

ADC_SMPR2

Description:

- Set the ADC's sample time for channel numbers between 0 and 9.

Parameters:

- `_SAMPLETIME_`: Sample time parameter.
- `_CHANNELNB_`: Channel number.

Return value:

- None

ADC_SQR3_RK

Description:

- Set the selected regular channel rank for rank between 1 and 6.

Parameters:

- `_CHANNELNB_`: Channel number.
- `_RANKNB_`: Rank number.

Return value:

- None

ADC_SQR2_RK

Description:

- Set the selected regular channel rank for rank between 7 and 12.

Parameters:

- `_CHANNELNB_`: Channel number.
- `_RANKNB_`: Rank number.

ADC_SQR1_RK

Return value:

- None

Description:

- Set the selected regular channel rank for rank between 13 and 16.

Parameters:

- _CHANNELNB_: Channel number.
- _RANKNB_: Rank number.

Return value:

- None

ADC_CR2_CONTINUOUS

Description:

- Enable ADC continuous conversion mode.

Parameters:

- _CONTINUOUS_MODE_: Continuous mode.

Return value:

- None

ADC_CR1_DISCONTINUOUS

Description:

- Configures the number of discontinuous conversions for the regular group channels.

Parameters:

- _NBR_DISCONTINUOUSCONV_: Number of discontinuous conversions.

Return value:

- None

ADC_CR1_SCANCONV

Description:

- Enable ADC scan mode.

Parameters:

- _SCANCONV_MODE_: Scan conversion mode.

Return value:

- None

ADC_CR2_EOCSelection

Description:

- Enable the ADC end of conversion selection.

Parameters:

- _EOCSelection_MODE_: End of conversion selection mode.

Return value:

- None

ADC_CR2_DMAContReq	Description: <ul style="list-style-type: none">Enable the ADC DMA continuous request. Parameters: <ul style="list-style-type: none">_DMAContReq_MODE_: DMA continuous request mode. Return value: <ul style="list-style-type: none">None
ADC_GET_RESOLUTION	Description: <ul style="list-style-type: none">Return resolution bits in CR1 register. Parameters: <ul style="list-style-type: none">_HANDLE_: ADC handle Return value: <ul style="list-style-type: none">None

ADC Resolution

ADC_RESOLUTION_12B
ADC_RESOLUTION_10B
ADC_RESOLUTION_8B
ADC_RESOLUTION_6B

ADC Sampling Times

ADC_SAMPLETIME_3CYCLES
ADC_SAMPLETIME_15CYCLES
ADC_SAMPLETIME_28CYCLES
ADC_SAMPLETIME_56CYCLES
ADC_SAMPLETIME_84CYCLES
ADC_SAMPLETIME_112CYCLES
ADC_SAMPLETIME_144CYCLES
ADC_SAMPLETIME_480CYCLES

5 HAL ADC Extension Driver

5.1 HAL ADC Extension Driver

5.2 ADCEx Firmware driver registers structures

5.2.1 ADC_InjectionConfTypeDef

Data Fields

- *uint32_t InjectedChannel*
- *uint32_t InjectedRank*
- *uint32_t InjectedSamplingTime*
- *uint32_t InjectedOffset*
- *uint32_t InjectedNbrOfConversion*
- *uint32_t AutoInjectedConv*
- *uint32_t InjectedDiscontinuousConvMode*
- *uint32_t ExternalTrigInjecConvEdge*
- *uint32_t ExternalTrigInjecConv*

Field Documentation

- ***uint32_t ADC_InjectionConfTypeDef::InjectedChannel***
Configure the ADC injected channel. This parameter can be a value of [**ADC_channels**](#)
- ***uint32_t ADC_InjectionConfTypeDef::InjectedRank***
The rank in the injected group sequencer This parameter must be a number between Min_Data = 1 and Max_Data = 4.
- ***uint32_t ADC_InjectionConfTypeDef::InjectedSamplingTime***
The sample time value to be set for the selected channel. This parameter can be a value of [**ADC_sampling_times**](#)
- ***uint32_t ADC_InjectionConfTypeDef::InjectedOffset***
Defines the offset to be subtracted from the raw converted data when convert injected channels. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0xFFFF.
- ***uint32_t ADC_InjectionConfTypeDef::InjectedNbrOfConversion***
Specifies the number of ADC conversions that will be done using the sequencer for injected channel group. This parameter must be a number between Min_Data = 1 and Max_Data = 4.
- ***uint32_t ADC_InjectionConfTypeDef::AutoInjectedConv***
Enables or disables the selected ADC automatic injected group conversion after regular one
- ***uint32_t ADC_InjectionConfTypeDef::InjectedDiscontinuousConvMode***
Specifies whether the conversion is performed in Discontinuous mode or not for injected channels. This parameter can be set to ENABLE or DISABLE.
- ***uint32_t ADC_InjectionConfTypeDef::ExternalTrigInjecConvEdge***
Select the external trigger edge and enable the trigger of an injected channels. This parameter can be a value of [**ADCEx_External_trigger_edge_Injected**](#)
- ***uint32_t ADC_InjectionConfTypeDef::ExternalTrigInjecConv***
Select the external event used to trigger the start of conversion of a injected

channels. This parameter can be a value of
[**ADCEx_External_trigger_Source_Injected**](#)

5.2.2 ADC_MultiModeTypeDef

Data Fields

- *uint32_t Mode*
- *uint32_t DMAAccessMode*
- *uint32_t TwoSamplingDelay*

Field Documentation

- ***uint32_t ADC_MultiModeTypeDef::Mode***
Configures the ADC to operate in independent or multi mode. This parameter can be a value of [**ADCEx_Common_mode**](#)
- ***uint32_t ADC_MultiModeTypeDef::DMAAccessMode***
Configures the Direct memory access mode for multi ADC mode. This parameter can be a value of [**ADCEx_Direct_memory_access_mode_for_multi_mode**](#)
- ***uint32_t ADC_MultiModeTypeDef::TwoSamplingDelay***
Configures the Delay between 2 sampling phases. This parameter can be a value of [**ADC_delay_between_2_sampling_phases**](#)

5.3 ADCEx Firmware driver API description

5.3.1 How to use this driver

1. Initialize the ADC low level resources by implementing the HAL_ADC_MspInit():
 - a. Enable the ADC interface clock using `__HAL_RCC_ADC_CLK_ENABLE()`
 - b. ADC pins configuration
 - Enable the clock for the ADC GPIOs using the following function:
`__HAL_RCC_GPIOx_CLK_ENABLE()`
 - Configure these ADC pins in analog mode using `HAL_GPIO_Init()`
 - c. In case of using interrupts (e.g. `HAL_ADC_Start_IT()`)
 - Configure the ADC interrupt priority using `HAL_NVIC_SetPriority()`
 - Enable the ADC IRQ handler using `HAL_NVIC_EnableIRQ()`
 - In ADC IRQ handler, call `HAL_ADC_IRQHandler()`
 - d. In case of using DMA to control data transfer (e.g. `HAL_ADC_Start_DMA()`)
 - Enable the DMAx interface clock using
`__HAL_RCC_DMAx_CLK_ENABLE()`
 - Configure and enable two DMA streams stream for managing data transfer from peripheral to memory (output stream)
 - Associate the initialized DMA handle to the ADC DMA handle using
`__HAL_LINKDMA()`
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the two DMA Streams. The output stream should have higher priority than the input stream.
2. Configure the ADC Prescaler, conversion resolution and data alignment using the `HAL_ADC_Init()` function.

-
3. Configure the ADC Injected channels group features, use HAL_ADC_Init() and HAL_ADC_ConfigChannel() functions.
 4. Three operation modes are available within this driver :

Polling mode IO operation

- Start the ADC peripheral using HAL_ADCEx_InjectedStart()
- Wait for end of conversion using HAL_ADC_PollForConversion(), at this stage user can specify the value of timeout according to his end application
- To read the ADC converted values, use the HAL_ADCEx_InjectedGetValue() function.
- Stop the ADC peripheral using HAL_ADCEx_InjectedStop()

Interrupt mode IO operation

- Start the ADC peripheral using HAL_ADCEx_InjectedStart_IT()
- Use HAL_ADC_IRQHandler() called under ADC_IRQHandler() Interrupt subroutine
- At ADC end of conversion HAL_ADCEx_InjectedConvCpltCallback() function is executed and user can add his own code by customization of function pointer HAL_ADCEx_InjectedConvCpltCallback
- In case of ADC Error, HAL_ADCEx_InjectedErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_ADCEx_InjectedErrorCallback
- Stop the ADC peripheral using HAL_ADCEx_InjectedStop_IT()

DMA mode IO operation

- Start the ADC peripheral using HAL_ADCEx_InjectedStart_DMA(), at this stage the user specify the length of data to be transferred at each end of conversion
- At The end of data transfer ba HAL_ADCEx_InjectedConvCpltCallback() function is executed and user can add his own code by customization of function pointer HAL_ADCEx_InjectedConvCpltCallback
- In case of transfer Error, HAL_ADCEx_InjectedErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_ADCEx_InjectedErrorCallback
- Stop the ADC peripheral using HAL_ADCEx_InjectedStop_DMA()

Multi mode ADCs Regular channels configuration

- Select the Multi mode ADC regular channels features (dual or triple mode) and configure the DMA mode using HAL_ADCEx_MultiModeConfigChannel() functions.
- Start the ADC peripheral using HAL_ADCEx_MultiModeStart_DMA(), at this stage the user specify the length of data to be transferred at each end of conversion
- Read the ADCs converted values using the HAL_ADCEx_MultiModeGetValue() function.

5.3.2

Extended features functions

This section provides functions allowing to:

- Start conversion of injected channel.

- Stop conversion of injected channel.
- Start multimode and enable DMA transfer.
- Stop multimode and disable DMA transfer.
- Get result of injected channel conversion.
- Get result of multimode conversion.
- Configure injected channels.
- Configure multimode.

This section contains the following APIs:

- [*HAL_ADCEx_InjectedStart\(\)*](#)
- [*HAL_ADCEx_InjectedStart_IT\(\)*](#)
- [*HAL_ADCEx_InjectedStop\(\)*](#)
- [*HAL_ADCEx_InjectedPollForConversion\(\)*](#)
- [*HAL_ADCEx_InjectedStop_IT\(\)*](#)
- [*HAL_ADCEx_InjectedGetValue\(\)*](#)
- [*HAL_ADCEx_MultiModeStart_DMA\(\)*](#)
- [*HAL_ADCEx_MultiModeStop_DMA\(\)*](#)
- [*HAL_ADCEx_MultiModeGetValue\(\)*](#)
- [*HAL_ADCEx_InjectedConvCpltCallback\(\)*](#)
- [*HAL_ADCEx_InjectedConfigChannel\(\)*](#)
- [*HAL_ADCEx_MultiModeConfigChannel\(\)*](#)

5.3.3 HAL_ADCEx_InjectedStart

Function Name	HAL_StatusTypeDef HAL_ADCEx_InjectedStart (ADC_HandleTypeDef * hadc)
Function Description	Enables the selected ADC software start conversion of the injected channels.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status

5.3.4 HAL_ADCEx_InjectedStart_IT

Function Name	HAL_StatusTypeDef HAL_ADCEx_InjectedStart_IT (ADC_HandleTypeDef * hadc)
Function Description	Enables the interrupt and starts ADC conversion of injected channels.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status.

5.3.5 HAL_ADCEx_InjectedStop

Function Name	HAL_StatusTypeDef HAL_ADCEx_InjectedStop (ADC_HandleTypeDef * hadc)
Function Description	Disables ADC and stop conversion of injected channels.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.

Return values	<ul style="list-style-type: none"> • HAL status.
Notes	<ul style="list-style-type: none"> • Caution: This function will stop also regular channels.
5.3.6 HAL_ADCEx_InjectedPollForConversion	
Function Name	HAL_StatusTypeDef HAL_ADCEx_InjectedPollForConversion (ADC_HandleTypeDef * hadc, uint32_t Timeout)
Function Description	Poll for injected conversion complete.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. • Timeout: Timeout value in millisecond.
Return values	<ul style="list-style-type: none"> • HAL status
5.3.7 HAL_ADCEx_InjectedStop_IT	
Function Name	HAL_StatusTypeDef HAL_ADCEx_InjectedStop_IT (ADC_HandleTypeDef * hadc)
Function Description	Disables the interrupt and stop ADC conversion of injected channels.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	<ul style="list-style-type: none"> • HAL status.
Notes	<ul style="list-style-type: none"> • Caution: This function will stop also regular channels.
5.3.8 HAL_ADCEx_InjectedGetValue	
Function Name	uint32_t HAL_ADCEx_InjectedGetValue (ADC_HandleTypeDef * hadc, uint32_t InjectedRank)
Function Description	Gets the converted value from data register of injected channel.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. • InjectedRank: the ADC injected rank. This parameter can be one of the following values: ADC_INJECTED_RANK_1: Injected Channel1 selectedADC_INJECTED_RANK_2: Injected Channel2 selectedADC_INJECTED_RANK_3: Injected Channel3 selectedADC_INJECTED_RANK_4: Injected Channel4 selected
Return values	<ul style="list-style-type: none"> • None
5.3.9 HAL_ADCEx_MultiModeStart_DMA	
Function Name	HAL_StatusTypeDef HAL_ADCEx_MultiModeStart_DMA (ADC_HandleTypeDef * hadc, uint32_t * pData, uint32_t Length)
Function Description	Enables ADC DMA request after last transfer (Multi-ADC mode) and enables ADC peripheral.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.

- **pData:** Pointer to buffer in which transferred from ADC peripheral to memory will be stored.
- **Length:** The length of data to be transferred from ADC peripheral to memory.

Return values	• HAL status
Notes	• Caution: This function must be used only with the ADC master.

5.3.10 HAL_ADCEx_MultiModeStop_DMA

Function Name	HAL_StatusTypeDef HAL_ADCEx_MultiModeStop_DMA(ADC_HandleTypeDef * hadc)
Function Description	Disables ADC DMA (multi-ADC mode) and disables ADC peripheral.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	• HAL status

5.3.11 HAL_ADCEx_MultiModeGetValue

Function Name	uint32_t HAL_ADCEx_MultiModeGetValue(ADC_HandleTypeDef * hadc)
Function Description	Returns the last ADC1, ADC2 and ADC3 regular conversions results data in the selected multi mode.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	• The converted data value.

5.3.12 HAL_ADCEx_InjectedConvCpltCallback

Function Name	void HAL_ADCEx_InjectedConvCpltCallback(ADC_HandleTypeDef * hadc)
Function Description	Injected conversion complete callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC.
Return values	• None

5.3.13 HAL_ADCEx_InjectedConfigChannel

Function Name	HAL_StatusTypeDef HAL_ADCEx_InjectedConfigChannel(ADC_HandleTypeDef * hadc, ADC_InjectionConfTypeDef * sConfigInjected)
Function Description	Configures for the selected ADC injected channel its corresponding rank in the sequencer and its sample time.
Parameters	<ul style="list-style-type: none"> • hadc: pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. • sConfigInjected: ADC configuration structure for injected

channel.

Return values	<ul style="list-style-type: none"> • None
---------------	--

5.3.14 HAL_ADCEx_MultiModeConfigChannel

Function Name	HAL_StatusTypeDef HAL_ADCEx_MultiModeConfigChannel(ADC_HandleTypeDef * hadc, ADC_MultiModeTypeDef * multimode)
Function Description	Configures the ADC multi-mode.
Parameters	<ul style="list-style-type: none"> • hadc: : pointer to a ADC_HandleTypeDef structure that contains the configuration information for the specified ADC. • multimode: : pointer to an ADC_MultiModeTypeDef structure that contains the configuration information for multimode.
Return values	<ul style="list-style-type: none"> • HAL status

5.4 ADCEx Firmware driver defines

5.4.1 ADCEx

ADC Specific Channels

ADC_CHANNEL_DIFFERENTIATION_TEMPSENSOR_VBAT

ADC_CHANNEL_TEMPSENSOR

ADC Common Mode

ADC_MODE_INDEPENDENT

ADC_DUALMODE_REGSIMULT_INJECSIMULT

ADC_DUALMODE_REGSIMULT.AlterTrig

ADC_DUALMODE_INJECSIMULT

ADC_DUALMODE_REGSIMULT

ADC_DUALMODE_INTERL

ADC_DUALMODE.AlterTrig

ADC_TRIPLEMODE_REGSIMULT_INJECSIMULT

ADC_TRIPLEMODE_REGSIMULT.AlterTrig

ADC_TRIPLEMODE_INJECSIMULT

ADC_TRIPLEMODE_REGSIMULT

ADC_TRIPLEMODE_INTERL

ADC_TRIPLEMODE.AlterTrig

ADC Direct Memory Access Mode For Multi Mode

ADC_DMAACCESSMODE_DISABLED DMA mode disabled

ADC_DMAACCESSMODE_1 DMA mode 1 enabled (2 / 3 half-words one by one - 1 then 2 then 3)

ADC_DMAACCESSMODE_2 DMA mode 2 enabled (2 / 3 half-words by pairs -

2&1 then 1&3 then 3&2)

ADC_DMAACCESSMODE_3 DMA mode 3 enabled (2 / 3 bytes by pairs - 2&1
then 1&3 then 3&2)

ADC External Trigger Edge Injected

ADC_EXTERNALTRIGINJECCONVEDGE_NONE
ADC_EXTERNALTRIGINJECCONVEDGE_RISING
ADC_EXTERNALTRIGINJECCONVEDGE_FALLING
ADC_EXTERNALTRIGINJECCONVEDGE_RISINGFALLING

ADC External Trigger Source Injected

ADC_EXTERNALTRIGINJECCONV_T1_CC4
ADC_EXTERNALTRIGINJECCONV_T1_TRGO
ADC_EXTERNALTRIGINJECCONV_T2_CC1
ADC_EXTERNALTRIGINJECCONV_T2_TRGO
ADC_EXTERNALTRIGINJECCONV_T3_CC2
ADC_EXTERNALTRIGINJECCONV_T3_CC4
ADC_EXTERNALTRIGINJECCONV_T4_CC1
ADC_EXTERNALTRIGINJECCONV_T4_CC2
ADC_EXTERNALTRIGINJECCONV_T4_CC3
ADC_EXTERNALTRIGINJECCONV_T4_TRGO
ADC_EXTERNALTRIGINJECCONV_T5_CC4
ADC_EXTERNALTRIGINJECCONV_T5_TRGO
ADC_EXTERNALTRIGINJECCONV_T8_CC2
ADC_EXTERNALTRIGINJECCONV_T8_CC3
ADC_EXTERNALTRIGINJECCONV_T8_CC4
ADC_EXTERNALTRIGINJECCONV_EXT_IT15
ADC_INJECTED_SOFTWARE_START

ADC Injected Channel Selection

ADC_INJECTED_RANK_1
ADC_INJECTED_RANK_2
ADC_INJECTED_RANK_3
ADC_INJECTED_RANK_4

ADC Private Macros

IS_ADC_CHANNEL
IS_ADC_MODE
IS_ADC_DMA_ACCESS_MODE
IS_ADC_EXT_INJEC_TRIG_EDGE
IS_ADC_EXT_INJEC_TRIG

IS_ADC_INJECTED_LENGTH

IS_ADC_INJECTED_RANK

ADC_JSQR

Description:

- Set the selected injected Channel rank.

Parameters:

- _CHANNELNB_: Channel number.
- _RANKNB_: Rank number.
- _JSQR_JL_: Sequence length.

Return value:

- None

6 HAL CAN Generic Driver

6.1 HAL CAN Generic Driver

6.2 CAN Firmware driver registers structures

6.2.1 CAN_InitTypeDef

Data Fields

- *uint32_t Prescaler*
- *uint32_t Mode*
- *uint32_t SJW*
- *uint32_t BS1*
- *uint32_t BS2*
- *uint32_t TTCM*
- *uint32_t ABOM*
- *uint32_t AWUM*
- *uint32_t NART*
- *uint32_t RFLM*
- *uint32_t TXFP*

Field Documentation

- ***uint32_t CAN_InitTypeDef::Prescaler***
Specifies the length of a time quantum. This parameter must be a number between Min_Data = 1 and Max_Data = 1024
- ***uint32_t CAN_InitTypeDef::Mode***
Specifies the CAN operating mode. This parameter can be a value of [**CAN_operating_mode**](#)
- ***uint32_t CAN_InitTypeDef::SJW***
Specifies the maximum number of time quanta the CAN hardware is allowed to lengthen or shorten a bit to perform resynchronization. This parameter can be a value of [**CAN_synchronisation_jump_width**](#)
- ***uint32_t CAN_InitTypeDef::BS1***
Specifies the number of time quanta in Bit Segment 1. This parameter can be a value of [**CAN_time_quantum_in_bit_segment_1**](#)
- ***uint32_t CAN_InitTypeDef::BS2***
Specifies the number of time quanta in Bit Segment 2. This parameter can be a value of [**CAN_time_quantum_in_bit_segment_2**](#)
- ***uint32_t CAN_InitTypeDef::TTCM***
Enable or disable the time triggered communication mode. This parameter can be set to ENABLE or DISABLE.
- ***uint32_t CAN_InitTypeDef::ABOM***
Enable or disable the automatic bus-off management. This parameter can be set to ENABLE or DISABLE
- ***uint32_t CAN_InitTypeDef::AWUM***
Enable or disable the automatic wake-up mode. This parameter can be set to ENABLE or DISABLE

- ***uint32_t CAN_InitTypeDef::NART***
Enable or disable the non-automatic retransmission mode. This parameter can be set to ENABLE or DISABLE
- ***uint32_t CAN_InitTypeDef::RFLM***
Enable or disable the receive FIFO Locked mode. This parameter can be set to ENABLE or DISABLE
- ***uint32_t CAN_InitTypeDef::TXFP***
Enable or disable the transmit FIFO priority. This parameter can be set to ENABLE or DISABLE

6.2.2 CAN_FilterTypeDef

Data Fields

- ***uint32_t FilterIdHigh***
- ***uint32_t FilterIdLow***
- ***uint32_t FilterMaskIdHigh***
- ***uint32_t FilterMaskIdLow***
- ***uint32_t FilterFIFOAssignment***
- ***uint32_t FilterNumber***
- ***uint32_t FilterMode***
- ***uint32_t FilterScale***
- ***uint32_t FilterActivation***
- ***uint32_t BankNumber***

Field Documentation

- ***uint32_t CAN_FilterTypeDef::FilterIdHigh***
Specifies the filter identification number (MSBs for a 32-bit configuration, first one for a 16-bit configuration). This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF
- ***uint32_t CAN_FilterTypeDef::FilterIdLow***
Specifies the filter identification number (LSBs for a 32-bit configuration, second one for a 16-bit configuration). This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF
- ***uint32_t CAN_FilterTypeDef::FilterMaskIdHigh***
Specifies the filter mask number or identification number, according to the mode (MSBs for a 32-bit configuration, first one for a 16-bit configuration). This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF
- ***uint32_t CAN_FilterTypeDef::FilterMaskIdLow***
Specifies the filter mask number or identification number, according to the mode (LSBs for a 32-bit configuration, second one for a 16-bit configuration). This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF
- ***uint32_t CAN_FilterTypeDef::FilterFIFOAssignment***
Specifies the FIFO (0 or 1) which will be assigned to the filter. This parameter can be a value of [CAN_filter_FIFO](#)
- ***uint32_t CAN_FilterTypeDef::FilterNumber***
Specifies the filter which will be initialized. This parameter must be a number between Min_Data = 0 and Max_Data = 27
- ***uint32_t CAN_FilterTypeDef::FilterMode***
Specifies the filter mode to be initialized. This parameter can be a value of [CAN_filter_mode](#)

- ***uint32_t CAN_FilterTypeDef::FilterScale***
Specifies the filter scale. This parameter can be a value of [CAN_filter_scale](#)
- ***uint32_t CAN_FilterTypeDef::FilterActivation***
Enable or disable the filter. This parameter can be set to ENABLE or DISABLE.
- ***uint32_t CAN_FilterTypeDef::BankNumber***
Select the start slave bank filter. This parameter must be a number between Min_Data = 0 and Max_Data = 28

6.2.3 CanTxMsgTypeDef

Data Fields

- ***uint32_t StdId***
- ***uint32_t ExtId***
- ***uint32_t IDE***
- ***uint32_t RTR***
- ***uint32_t DLC***
- ***uint8_t Data***

Field Documentation

- ***uint32_t CanTxMsgTypeDef::StdId***
Specifies the standard identifier. This parameter must be a number between Min_Data = 0 and Max_Data = 0x7FF
- ***uint32_t CanTxMsgTypeDef::ExtId***
Specifies the extended identifier. This parameter must be a number between Min_Data = 0 and Max_Data = 0xFFFFFFFF
- ***uint32_t CanTxMsgTypeDef::IDE***
Specifies the type of identifier for the message that will be transmitted. This parameter can be a value of [CAN_Identifier_Type](#)
- ***uint32_t CanTxMsgTypeDef::RTR***
Specifies the type of frame for the message that will be transmitted. This parameter can be a value of [CAN_remote_transmission_request](#)
- ***uint32_t CanTxMsgTypeDef::DLC***
Specifies the length of the frame that will be transmitted. This parameter must be a number between Min_Data = 0 and Max_Data = 8
- ***uint8_t CanTxMsgTypeDef::Data[8]***
Contains the data to be transmitted. This parameter must be a number between Min_Data = 0 and Max_Data = 0xFF

6.2.4 CanRxMsgTypeDef

Data Fields

- ***uint32_t StdId***
- ***uint32_t ExtId***
- ***uint32_t IDE***
- ***uint32_t RTR***
- ***uint32_t DLC***

-
- *uint8_t Data*
 - *uint32_t FMI*
 - *uint32_t FIFONumber*

Field Documentation

- ***uint32_t CanRxMsgTypeDef::StdId***
Specifies the standard identifier. This parameter must be a number between Min_Data = 0 and Max_Data = 0x7FF
- ***uint32_t CanRxMsgTypeDef::ExtId***
Specifies the extended identifier. This parameter must be a number between Min_Data = 0 and Max_Data = 0x1FFFFFFF
- ***uint32_t CanRxMsgTypeDef::IDE***
Specifies the type of identifier for the message that will be received. This parameter can be a value of [CAN_Identifier_Type](#)
- ***uint32_t CanRxMsgTypeDef::RTR***
Specifies the type of frame for the received message. This parameter can be a value of [CAN_remote_transmission_request](#)
- ***uint32_t CanRxMsgTypeDef::DLC***
Specifies the length of the frame that will be received. This parameter must be a number between Min_Data = 0 and Max_Data = 8
- ***uint8_t CanRxMsgTypeDef::Data[8]***
Contains the data to be received. This parameter must be a number between Min_Data = 0 and Max_Data = 0xFF
- ***uint32_t CanRxMsgTypeDef::FMI***
Specifies the index of the filter the message stored in the mailbox passes through. This parameter must be a number between Min_Data = 0 and Max_Data = 0xFF
- ***uint32_t CanRxMsgTypeDef::FIFONumber***
Specifies the receive FIFO number. This parameter can be CAN_FIFO0 or CAN_FIFO1

6.2.5 CAN_HandleTypeDef

Data Fields

- ***CAN_TypeDef * Instance***
- ***CAN_InitTypeDef Init***
- ***CanTxMsgTypeDef * pTxMsg***
- ***CanRxMsgTypeDef * pRxMsg***
- ***__IO HAL_CAN_StateTypeDef State***
- ***HAL_LockTypeDef Lock***
- ***__IO uint32_t ErrorCode***

Field Documentation

- ***CAN_TypeDef* CAN_HandleTypeDef::Instance***
Register base address
- ***CAN_InitTypeDef CAN_HandleTypeDef::Init***
CAN required parameters
- ***CanTxMsgTypeDef* CAN_HandleTypeDef::pTxMsg***
Pointer to transmit structure

- ***CanRxMsgTypeDef* CAN_HandleTypeDef::pRxMsg***
Pointer to reception structure
- ***_IO HAL_CAN_StateTypeDef CAN_HandleTypeDef::State***
CAN communication state
- ***HAL_LockTypeDef CAN_HandleTypeDef::Lock***
CAN locking object
- ***_IO uint32_t CAN_HandleTypeDef::ErrorCode***
CAN Error code

6.3 CAN Firmware driver API description

6.3.1 How to use this driver

1. Enable the CAN controller interface clock using `__HAL_RCC_CAN1_CLK_ENABLE()` for CAN1 and `__HAL_RCC_CAN2_CLK_ENABLE()` for CAN2. In case you are using CAN2 only, you have to enable the CAN1 clock.
2. CAN pins configuration
 - Enable the clock for the CAN GPIOs using the following function:
`__GPIOx_CLK_ENABLE()`
 - Connect and configure the involved CAN pins to AF9 using the following function
`HAL_GPIO_Init()`
3. Initialize and configure the CAN using `CAN_Init()` function.
4. Transmit the desired CAN frame using `HAL_CAN_Transmit()` function.
5. Receive a CAN frame using `HAL_CAN_Receive()` function.

Polling mode IO operation

- Start the CAN peripheral transmission and wait the end of this operation using `HAL_CAN_Transmit()`, at this stage user can specify the value of timeout according to his end application
- Start the CAN peripheral reception and wait the end of this operation using `HAL_CAN_Receive()`, at this stage user can specify the value of timeout according to his end application

Interrupt mode IO operation

- Start the CAN peripheral transmission using `HAL_CAN_Transmit_IT()`
- Start the CAN peripheral reception using `HAL_CAN_Receive_IT()`
- Use `HAL_CAN_IRQHandler()` called under the used CAN Interrupt subroutine
- At CAN end of transmission `HAL_CAN_TxCpltCallback()` function is executed and user can add his own code by customization of function pointer
`HAL_CAN_TxCpltCallback`
- In case of CAN Error, `HAL_CAN_ErrorCallback()` function is executed and user can add his own code by customization of function pointer `HAL_CAN_ErrorCallback`

CAN HAL driver macros list

Below the list of most used macros in CAN HAL driver.

- `__HAL_CAN_ENABLE_IT`: Enable the specified CAN interrupts

- `_HAL_CAN_DISABLE_IT`: Disable the specified CAN interrupts
- `_HAL_CAN_GET_IT_SOURCE`: Check if the specified CAN interrupt source is enabled or disabled
- `_HAL_CAN_CLEAR_FLAG`: Clear the CAN's pending flags
- `_HAL_CAN_GET_FLAG`: Get the selected CAN's flag status



You can refer to the CAN HAL driver header file for more useful macros

6.3.2

Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize and configure the CAN.
- De-initialize the CAN.

This section contains the following APIs:

- `HAL_CAN_Init()`
- `HAL_CAN_ConfigFilter()`
- `HAL_CAN_DelInit()`
- `HAL_CAN_MspInit()`
- `HAL_CAN_MspDelInit()`

6.3.3

IO operation functions

This section provides functions allowing to:

- Transmit a CAN frame message.
- Receive a CAN frame message.
- Enter CAN peripheral in sleep mode.
- Wake up the CAN peripheral from sleep mode.

This section contains the following APIs:

- `HAL_CAN_Transmit()`
- `HAL_CAN_Transmit_IT()`
- `HAL_CAN_Receive()`
- `HAL_CAN_Receive_IT()`
- `HAL_CAN_Sleep()`
- `HAL_CAN_WakeUp()`
- `HAL_CAN_IRQHandler()`
- `HAL_CAN_TxCpltCallback()`
- `HAL_CAN_RxCpltCallback()`
- `HAL_CAN_ErrorCallback()`

6.3.4

Peripheral State and Error functions

This subsection provides functions allowing to :

- Check the CAN state.
- Check CAN Errors detected during interrupt process

This section contains the following APIs:

- `HAL_CAN_GetState()`
- `HAL_CAN_GetError()`

6.3.5 HAL_CAN_Init

Function Name	HAL_StatusTypeDef HAL_CAN_Init (CAN_HandleTypeDef * hcan)
Function Description	Initializes the CAN peripheral according to the specified parameters in the CAN_InitStruct.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • HAL status

6.3.6 HAL_CAN_ConfigFilter

Function Name	HAL_StatusTypeDef HAL_CAN_ConfigFilter (CAN_HandleTypeDef * hcan, CAN_FilterConfTypeDef * sFilterConfig)
Function Description	Configures the CAN reception filter according to the specified parameters in the CAN_FilterInitStruct.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN. • sFilterConfig: pointer to a CAN_FilterConfTypeDef structure that contains the filter configuration information.
Return values	<ul style="list-style-type: none"> • None

6.3.7 HAL_CAN_DeInit

Function Name	HAL_StatusTypeDef HAL_CAN_DeInit (CAN_HandleTypeDef * hcan)
Function Description	Deinitializes the CANx peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • HAL status

6.3.8 HAL_CAN_MspInit

Function Name	void HAL_CAN_MspInit (CAN_HandleTypeDef * hcan)
Function Description	Initializes the CAN MSP.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • None

6.3.9 HAL_CAN_MspDeInit

Function Name	void HAL_CAN_MspDeInit (CAN_HandleTypeDef * hcan)
Function Description	Deinitializes the CAN MSP.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.

Return values	<ul style="list-style-type: none"> • None
6.3.10 HAL_CAN_Transmit	
Function Name	HAL_StatusTypeDef HAL_CAN_Transmit (CAN_HandleTypeDef * hcan, uint32_t Timeout)
Function Description	Initiates and transmits a CAN frame message.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN. • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status
6.3.11 HAL_CAN_Transmit_IT	
Function Name	HAL_StatusTypeDef HAL_CAN_Transmit_IT (CAN_HandleTypeDef * hcan)
Function Description	Initiates and transmits a CAN frame message.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • HAL status
6.3.12 HAL_CAN_Receive	
Function Name	HAL_StatusTypeDef HAL_CAN_Receive (CAN_HandleTypeDef * hcan, uint8_t FIFONumber, uint32_t Timeout)
Function Description	Receives a correct CAN frame.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN. • FIFONumber: FIFO Number value • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status
6.3.13 HAL_CAN_Receive_IT	
Function Name	HAL_StatusTypeDef HAL_CAN_Receive_IT (CAN_HandleTypeDef * hcan, uint8_t FIFONumber)
Function Description	Receives a correct CAN frame.
Parameters	<ul style="list-style-type: none"> • hcan: Pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN. • FIFONumber: Specify the FIFO number
Return values	<ul style="list-style-type: none"> • HAL status
6.3.14 HAL_CAN_Sleep	
Function Name	HAL_StatusTypeDef HAL_CAN_Sleep (CAN_HandleTypeDef * hcan)
Function Description	Enters the Sleep (low power) mode.

Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • HAL status.

6.3.15 HAL_CAN_WakeUp

Function Name	HAL_StatusTypeDef HAL_CAN_WakeUp (CAN_HandleTypeDef * hcan)
Function Description	Wakes up the CAN peripheral from sleep mode, after that the CAN peripheral is in the normal mode.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • HAL status.

6.3.16 HAL_CAN_IRQHandler

Function Name	void HAL_CAN_IRQHandler (CAN_HandleTypeDef * hcan)
Function Description	Handles CAN interrupt request.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • None

6.3.17 HAL_CAN_TxCpltCallback

Function Name	void HAL_CAN_TxCpltCallback (CAN_HandleTypeDef * hcan)
Function Description	Transmission complete callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • None

6.3.18 HAL_CAN_RxCpltCallback

Function Name	void HAL_CAN_RxCpltCallback (CAN_HandleTypeDef * hcan)
Function Description	Transmission complete callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • None

6.3.19 HAL_CAN_ErrorCallback

Function Name	void HAL_CAN_ErrorCallback (CAN_HandleTypeDef * hcan)
Function Description	Error CAN callback.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • None

6.3.20 HAL_CAN_GetState

Function Name	<code>HAL_CAN_StateTypeDef HAL_CAN_GetState (CAN_HandleTypeDef * hcan)</code>
Function Description	return the CAN state
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • HAL state

6.3.21 HAL_CAN_GetError

Function Name	<code>uint32_t HAL_CAN_GetError (CAN_HandleTypeDef * hcan)</code>
Function Description	Return the CAN error code.
Parameters	<ul style="list-style-type: none"> • hcan: pointer to a CAN_HandleTypeDef structure that contains the configuration information for the specified CAN.
Return values	<ul style="list-style-type: none"> • CAN Error Code

6.4 CAN Firmware driver defines

6.4.1 CAN

CAN Exported Macros

<code>_HAL_CAN_RESET_HANDLE_STATE</code>	Description:
	<ul style="list-style-type: none"> • Reset CAN handle state.
	Parameters:
	<ul style="list-style-type: none"> • <code>_HANDLE_</code>: specifies the CAN Handle.
<code>_HAL_CAN_ENABLE_IT</code>	Return value:
	<ul style="list-style-type: none"> • None
	Description:
	<ul style="list-style-type: none"> • Enable the specified CAN interrupts.
	Parameters:
	<ul style="list-style-type: none"> • <code>_HANDLE_</code>: CAN handle • <code>_INTERRUPT_</code>: CAN Interrupt
<code>_HAL_CAN_DISABLE_IT</code>	Return value:
	<ul style="list-style-type: none"> • None
	Description:
	<ul style="list-style-type: none"> • Disable the specified CAN interrupts.
	Parameters:
	<ul style="list-style-type: none"> • <code>_HANDLE_</code>: CAN handle • <code>_INTERRUPT_</code>: CAN Interrupt
	Return value:

- None

_HAL_CAN_MSG_PENDING**Description:**

- Return the number of pending received messages.

Parameters:

- _HANDLE_: CAN handle
- _FIFONUMBER_: Receive FIFO number, CAN_FIFO0 or CAN_FIFO1.

Return value:

- The: number of pending message.

_HAL_CAN_GET_FLAG**Description:**

- Check whether the specified CAN flag is set or not.

Parameters:

- _HANDLE_: CAN Handle
- _FLAG_: specifies the flag to check. This parameter can be one of the following values:
 - CAN_TSR_RQCP0: Request MailBox0 Flag
 - CAN_TSR_RQCP1: Request MailBox1 Flag
 - CAN_TSR_RQCP2: Request MailBox2 Flag
 - CAN_FLAG_TXOK0: Transmission OK MailBox0 Flag
 - CAN_FLAG_TXOK1: Transmission OK MailBox1 Flag
 - CAN_FLAG_TXOK2: Transmission OK MailBox2 Flag
 - CAN_FLAG_TME0: Transmit mailbox 0 empty Flag
 - CAN_FLAG_TME1: Transmit mailbox 1 empty Flag
 - CAN_FLAG_TME2: Transmit mailbox 2 empty Flag
 - CAN_FLAG_FMP0: FIFO 0 Message Pending Flag
 - CAN_FLAG_FF0: FIFO 0 Full Flag
 - CAN_FLAG_FOV0: FIFO 0 Overrun Flag
 - CAN_FLAG_FMP1: FIFO 1 Message Pending Flag
 - CAN_FLAG_FF1: FIFO 1 Full Flag
 - CAN_FLAG_FOV1: FIFO 1 Overrun Flag
 - CAN_FLAG_WKU: Wake up Flag
 - CAN_FLAG_SLAK: Sleep acknowledge Flag

- CAN_FLAG_SLAKI: Sleep acknowledge Flag
- CAN_FLAG_EWG: Error Warning Flag
- CAN_FLAG_EPV: Error Passive Flag
- CAN_FLAG_BOF: Bus-Off Flag

Return value:

- The new state of __FLAG__ (TRUE or FALSE).

_HAL_CAN_CLEAR_FLAG**Description:**

- Clear the specified CAN pending flag.

Parameters:

- __HANDLE__: CAN Handle.
- __FLAG__: specifies the flag to check.
This parameter can be one of the following values:
 - CAN_TSR_RQCP0: Request MailBox0 Flag
 - CAN_TSR_RQCP1: Request MailBox1 Flag
 - CAN_TSR_RQCP2: Request MailBox2 Flag
 - CAN_FLAG_TXOK0: Transmission OK MailBox0 Flag
 - CAN_FLAG_TXOK1: Transmission OK MailBox1 Flag
 - CAN_FLAG_TXOK2: Transmission OK MailBox2 Flag
 - CAN_FLAG_TME0: Transmit mailbox 0 empty Flag
 - CAN_FLAG_TME1: Transmit mailbox 1 empty Flag
 - CAN_FLAG_TME2: Transmit mailbox 2 empty Flag
 - CAN_FLAG_FMP0: FIFO 0 Message Pending Flag
 - CAN_FLAG_FF0: FIFO 0 Full Flag
 - CAN_FLAG_FOV0: FIFO 0 Overrun Flag
 - CAN_FLAG_FMP1: FIFO 1 Message Pending Flag
 - CAN_FLAG_FF1: FIFO 1 Full Flag
 - CAN_FLAG_FOV1: FIFO 1 Overrun Flag
 - CAN_FLAG_WKU: Wake up Flag
 - CAN_FLAG_SLAK: Sleep acknowledge Flag
 - CAN_FLAG_SLAKI: Sleep acknowledge Flag
 - CAN_FLAG_EWG: Error Warning Flag

- CAN_FLAG_EPV: Error Passive Flag
- CAN_FLAG_BOF: Bus-Off Flag

Return value:

- The: new state of __FLAG__ (TRUE or FALSE).

_HAL_CAN_GET_IT_SOURCE**Description:**

- Check if the specified CAN interrupt source is enabled or disabled.

Parameters:

- __HANDLE__: CAN Handle
- __INTERRUPT__: specifies the CAN interrupt source to check. This parameter can be one of the following values:
 - CAN_IT_TME: Transmit mailbox empty interrupt enable
 - CAN_IT_FMP0: FIFO0 message pending interrupt enable
 - CAN_IT_FMP1: FIFO1 message pending interrupt enable

Return value:

- The: new state of __IT__ (TRUE or FALSE).

_HAL_CAN_TRANSMIT_STATUS**Description:**

- Check the transmission status of a CAN Frame.

Parameters:

- __HANDLE__: CAN Handle
- __TRANSMITMAILBOX__: the number of the mailbox that is used for transmission.

Return value:

- The: new status of transmission (TRUE or FALSE).

_HAL_CAN_FIFO_RELEASE**Description:**

- Release the specified receive FIFO.

Parameters:

- __HANDLE__: CAN handle
- __FIFONUMBER__: Receive FIFO number, CAN_FIFO0 or CAN_FIFO1.

Return value:

- None

_HAL_CAN_CANCEL_TRANSMIT**Description:**

- Cancel a transmit request.

Parameters:

- HANDLE: CAN Handle
- TRANSMITMAILBOX: the number of the mailbox that is used for transmission.

Return value:

- None

_HAL_CAN_DBG_FREEZE**Description:**

- Enable or disable the DBG Freeze for CAN.

Parameters:

- HANDLE: CAN Handle
- NEWSTATE: new state of the CAN peripheral. This parameter can be: ENABLE (CAN reception/transmission is frozen during debug. Reception FIFOs can still be accessed/controlled normally) or DISABLE (CAN is working during debug).

Return value:

- None

CAN Filter FIFO

CAN_FILTER_FIFO0 Filter FIFO 0 assignment for filter x

CAN_FILTER_FIFO1 Filter FIFO 1 assignment for filter x

CAN Filter Mode

CAN_FILTERMODE_IDMASK Identifier mask mode

CAN_FILTERMODE_IDLIST Identifier list mode

CAN Filter Scale

CAN_FILTERSCALE_16BIT Two 16-bit filters

CAN_FILTERSCALE_32BIT One 32-bit filter

CAN Flags

CAN_FLAG_RQCP0 Request MailBox0 flag

CAN_FLAG_RQCP1 Request MailBox1 flag

CAN_FLAG_RQCP2 Request MailBox2 flag

CAN_FLAG_TXOK0 Transmission OK MailBox0 flag

CAN_FLAG_TXOK1 Transmission OK MailBox1 flag

CAN_FLAG_TXOK2 Transmission OK MailBox2 flag

CAN_FLAG_TME0 Transmit mailbox 0 empty flag

CAN_FLAG_TME1 Transmit mailbox 0 empty flag

CAN_FLAG_TME2 Transmit mailbox 0 empty flag

CAN_FLAG_FF0 FIFO 0 Full flag

CAN_FLAG_FOV0	FIFO 0 Overrun flag
CAN_FLAG_FF1	FIFO 1 Full flag
CAN_FLAG_FOV1	FIFO 1 Overrun flag
CAN_FLAG_WKU	Wake up flag
CAN_FLAG_SLAK	Sleep acknowledge flag
CAN_FLAG_SLAKI	Sleep acknowledge flag
CAN_FLAG_EWG	Error warning flag
CAN_FLAG_EPV	Error passive flag
CAN_FLAG_BOF	Bus-Off flag

CAN Identifier Type

CAN_ID_STD	Standard Id
CAN_ID_EXT	Extended Id

CAN InitStatus

CAN_INITSTATUS_FAILED	CAN initialization failed
CAN_INITSTATUS_SUCCESS	CAN initialization OK

CAN Interrupts

CAN_IT_TME	Transmit mailbox empty interrupt
CAN_IT_FMP0	FIFO 0 message pending interrupt
CAN_IT_FF0	FIFO 0 full interrupt
CAN_IT_FOV0	FIFO 0 overrun interrupt
CAN_IT_FMP1	FIFO 1 message pending interrupt
CAN_IT_FF1	FIFO 1 full interrupt
CAN_IT_FOV1	FIFO 1 overrun interrupt
CAN_IT_WKU	Wake-up interrupt
CAN_IT_SLK	Sleep acknowledge interrupt
CAN_IT_EWG	Error warning interrupt
CAN_IT_EPV	Error passive interrupt
CAN_IT_BOF	Bus-off interrupt
CAN_IT_LEC	Last error code interrupt
CAN_IT_ERR	Error Interrupt

CAN Mailboxes Definition

CAN_TXMAILBOX_0
CAN_TXMAILBOX_1
CAN_TXMAILBOX_2

CAN Operating Mode

CAN_MODE_NORMAL	Normal mode
-----------------	-------------

CAN_MODE_LOOPBACK	Loopback mode
CAN_MODE_SILENT	Silent mode
CAN_MODE_SILENT_LOOPBACK	Loopback combined with silent mode

CAN Private Constants

CAN_TIMEOUT_VALUE	
CAN_TXSTATUS_NOMAILBOX	CAN cell did not provide CAN_TxStatus_NoMailBox
CAN_FLAG_MASK	

CAN Private Macros

IS_CAN_MODE	
IS_CAN_SJW	
IS_CAN_BS1	
IS_CAN_BS2	
IS_CAN_PRESCALER	
IS_CAN_FILTER_NUMBER	
IS_CAN_FILTER_MODE	
IS_CAN_FILTER_SCALE	
IS_CAN_FILTER_FIFO	
IS_CAN_BANKNUMBER	
IS_CAN_TRANSMITMAILBOX	
IS_CAN_STID	
IS_CAN_EXTID	
IS_CAN_DLC	
IS_CAN_IDTYPE	
IS_CAN_RTR	
IS_CAN_FIFO	

CAN Receive FIFO Number Constants

CAN_FIFO0	CAN FIFO 0 used to receive
CAN_FIFO1	CAN FIFO 1 used to receive

CAN Remote Transmission Request

CAN_RTR_DATA	Data frame
CAN_RTR_REMOTE	Remote frame

CAN Synchronisation Jump Width

CAN_SJW_1TQ	1 time quantum
CAN_SJW_2TQ	2 time quantum
CAN_SJW_3TQ	3 time quantum
CAN_SJW_4TQ	4 time quantum

CAN Time Quantum in bit segment 1

CAN_BS1_1TQ	1 time quantum
CAN_BS1_2TQ	2 time quantum
CAN_BS1_3TQ	3 time quantum
CAN_BS1_4TQ	4 time quantum
CAN_BS1_5TQ	5 time quantum
CAN_BS1_6TQ	6 time quantum
CAN_BS1_7TQ	7 time quantum
CAN_BS1_8TQ	8 time quantum
CAN_BS1_9TQ	9 time quantum
CAN_BS1_10TQ	10 time quantum
CAN_BS1_11TQ	11 time quantum
CAN_BS1_12TQ	12 time quantum
CAN_BS1_13TQ	13 time quantum
CAN_BS1_14TQ	14 time quantum
CAN_BS1_15TQ	15 time quantum
CAN_BS1_16TQ	16 time quantum

CAN Time Quantum in bit segment 2

CAN_BS2_1TQ	1 time quantum
CAN_BS2_2TQ	2 time quantum
CAN_BS2_3TQ	3 time quantum
CAN_BS2_4TQ	4 time quantum
CAN_BS2_5TQ	5 time quantum
CAN_BS2_6TQ	6 time quantum
CAN_BS2_7TQ	7 time quantum
CAN_BS2_8TQ	8 time quantum

7 HAL CEC Generic Driver

7.1 HAL CEC Generic Driver

7.2 CEC Firmware driver registers structures

7.2.1 CEC_InitTypeDef

Data Fields

- *uint32_t SignalFreeTime*
- *uint32_t Tolerance*
- *uint32_t BRERxStop*
- *uint32_t BREErrorBitGen*
- *uint32_t LBPEErrorBitGen*
- *uint32_t BroadcastMsgNoErrorBitGen*
- *uint32_t SignalFreeTimeOption*
- *uint32_t OwnAddress*
- *uint32_t ListenMode*
- *uint8_t InitiatorAddress*

Field Documentation

- ***uint32_t CEC_InitTypeDef::SignalFreeTime***
Set SFT field, specifies the Signal Free Time. It can be one of **CEC_Signal_Free_Time** and belongs to the set {0,...,7} where 0x0 is the default configuration else means 0.5 + (SignalFreeTime - 1) nominal data bit periods
- ***uint32_t CEC_InitTypeDef::Tolerance***
Set RXTOL bit, specifies the tolerance accepted on the received waveforms, it can be a value of **CEC_Tolerance**: it is either CEC_STANDARD_TOLERANCE or CEC_EXTENDED_TOLERANCE
- ***uint32_t CEC_InitTypeDef::BRERxStop***
Set BRESTP bit **CEC_BRERxStop**: specifies whether or not a Bit Rising Error stops the reception. CEC_NO_RX_STOP_ON_BRE: reception is not stopped. CEC_RX_STOP_ON_BRE: reception is stopped.
- ***uint32_t CEC_InitTypeDef::BREErrorBitGen***
Set BREGEN bit **CEC_BREErrorBitGen**: specifies whether or not an Error-Bit is generated on the CEC line upon Bit Rising Error detection.
CEC_BRE_ERRORBIT_NO_GENERATION: no error-bit generation.
CEC_BRE_ERRORBIT_GENERATION: error-bit generation if BRESTP is set.
- ***uint32_t CEC_InitTypeDef::LBPEErrorBitGen***
Set LBPEGEN bit **CEC_LBPEErrorBitGen**: specifies whether or not an Error-Bit is generated on the CEC line upon Long Bit Period Error detection.
CEC_LBPE_ERRORBIT_NO_GENERATION: no error-bit generation.
CEC_LBPE_ERRORBIT_GENERATION: error-bit generation.
- ***uint32_t CEC_InitTypeDef::BroadcastMsgNoErrorBitGen***
Set BRDNOGEN bit **CEC_BroadCastMsgErrorBitGen**: allows to avoid an Error-Bit generation on the CEC line upon an error detected on a broadcast message. It supersedes BREGEN and LBPEGEN bits for a broadcast message error handling. It can take two values:1) CEC_BROADCASTERROR_ERRORBIT_GENERATION. a)

- BRE detection: error-bit generation on the CEC line if BRESTP=CEC_RX_STOP_ON_BRE and BREGEN=CEC_BRE_ERRORBIT_NO_GENERATION. b) LBPE detection: error-bit generation on the CEC line if LBPGEN=CEC_LBPE_ERRORBIT_NO_GENERATION.2) CEC_BROADCASTERROR_NO_ERRORBIT_GENERATION. no error-bit generation in case neither a) nor b) are satisfied. Additionally, there is no error-bit generation in case of Short Bit Period Error detection in a broadcast message while LSTN bit is set.
- ***uint32_t CEC_InitTypeDef::SignalFreeTimeOption***
Set SFTOP bit ***CEC_SFT_Option*** : specifies when SFT timer starts.
CEC_SFT_START_ON_TXSOM SFT: timer starts when TXSOM is set by software.
CEC_SFT_START_ON_TX_RX_END: SFT timer starts automatically at the end of message transmission/reception.
 - ***uint32_t CEC_InitTypeDef::OwnAddress***
Set OAR field, specifies CEC device address within a 15-bit long field
 - ***uint32_t CEC_InitTypeDef::ListenMode***
Set LSTN bit ***CEC_Listening_Mode*** : specifies device listening mode. It can take two values:CEC_REDUCED_LISTENING_MODE: CEC peripheral receives only message addressed to its own address (OAR). Messages addressed to different destination are ignored. Broadcast messages are always received.CEC_FULL_LISTENING_MODE: CEC peripheral receives messages addressed to its own address (OAR) with positive acknowledge. Messages addressed to different destination are received, but without interfering with the CEC bus: no acknowledge sent.
 - ***uint8_t CEC_InitTypeDef::InitiatorAddress***

7.2.2 CEC_HandleTypeDef

Data Fields

- ***CEC_TypeDef * Instance***
- ***CEC_InitTypeDef Init***
- ***uint8_t * pTxBuffPtr***
- ***uint16_t TxXferCount***
- ***uint8_t * pRxBuffPtr***
- ***uint16_t RxXferSize***
- ***uint32_t ErrorCode***
- ***HAL_LockTypeDef Lock***
- ***HAL_CEC_StateTypeDef State***

Field Documentation

- ***CEC_TypeDef* CEC_HandleTypeDef::Instance***
- ***CEC_InitTypeDef CEC_HandleTypeDef::Init***
- ***uint8_t* CEC_HandleTypeDef::pTxBuffPtr***
- ***uint16_t CEC_HandleTypeDef::TxXferCount***
- ***uint8_t* CEC_HandleTypeDef::pRxBuffPtr***
- ***uint16_t CEC_HandleTypeDef::RxXferSize***
- ***uint32_t CEC_HandleTypeDef::ErrorCode***
- ***HAL_LockTypeDef CEC_HandleTypeDef::Lock***
- ***HAL_CEC_StateTypeDef CEC_HandleTypeDef::State***

7.3 CEC Firmware driver API description

7.3.1 How to use this driver



The specific CEC interrupts (Transmission complete interrupt, RXNE interrupt and Error Interrupts) will be managed using the macros `_HAL_CEC_ENABLE_IT()` and `_HAL_CEC_DISABLE_IT()` inside the transmit and receive process. (#) Program the Signal Free Time (SFT) and SFT option, Tolerance, reception stop in case of Bit Rising Error, Error-Bit generation conditions, device logical address and Listen mode in the hcec Init structure. (#) Initialize the CEC registers by calling the `HAL_CEC_Init()` API.



This API (`HAL_CEC_Init()`) configures also the low level Hardware GPIO, CLOCK, CORTEX...etc) by calling the customized `HAL_CEC_MspInit()` API.

7.3.2 Initialization and Configuration functions

This subsection provides a set of functions allowing to initialize the CEC

- The following parameters need to be configured:
 - SignalFreeTime
 - Tolerance
 - BRERxStop (RX stopped or not upon Bit Rising Error)
 - BREErrorBitGen (Error-Bit generation in case of Bit Rising Error)
 - LBPEErrorBitGen (Error-Bit generation in case of Long Bit Period Error)
 - BroadcastMsgNoErrorBitGen (Error-bit generation in case of broadcast message error)
 - SignalFreeTimeOption (SFT Timer start definition)
 - OwnAddress (CEC device address)
 - ListenMode

This section contains the following APIs:

- [`HAL_CEC_Init\(\)`](#)
- [`HAL_CEC_DelInit\(\)`](#)
- [`HAL_CEC_MspInit\(\)`](#)
- [`HAL_CEC_MspDelInit\(\)`](#)

7.3.3 IO operation functions

This section contains the following APIs:

- [`HAL_CEC_Transmit\(\)`](#)
- [`HAL_CEC_Receive\(\)`](#)
- [`HAL_CEC_Transmit_IT\(\)`](#)
- [`HAL_CEC_Receive_IT\(\)`](#)
- [`HAL_CEC_GetReceivedFrameSize\(\)`](#)
- [`HAL_CEC_IRQHandler\(\)`](#)
- [`HAL_CEC_TxCpltCallback\(\)`](#)
- [`HAL_CEC_RxCpltCallback\(\)`](#)
- [`HAL_CEC_ErrorCallback\(\)`](#)

7.3.4 Peripheral Control function

This subsection provides a set of functions allowing to control the CEC.

- `HAL_CEC_GetState()` API can be helpful to check in run-time the state of the CEC peripheral.

This section contains the following APIs:

- `HAL_CEC_GetState()`
- `HAL_CEC_GetError()`

7.3.5 HAL_CEC_Init

Function Name	<code>HAL_StatusTypeDef HAL_CEC_Init (CEC_HandleTypeDef * hcec)</code>
Function Description	Initializes the CEC mode according to the specified parameters in the <code>CEC_InitTypeDef</code> and creates the associated handle .
Parameters	<ul style="list-style-type: none"> • <code>hcec</code>: CEC handle
Return values	<ul style="list-style-type: none"> • HAL status

7.3.6 HAL_CEC_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_CEC_DelInit (CEC_HandleTypeDef * hcec)</code>
Function Description	Delinitializes the CEC peripheral.
Parameters	<ul style="list-style-type: none"> • <code>hcec</code>: CEC handle
Return values	<ul style="list-style-type: none"> • HAL status

7.3.7 HAL_CEC_MspInit

Function Name	<code>void HAL_CEC_MspInit (CEC_HandleTypeDef * hcec)</code>
Function Description	CEC MSP Init.
Parameters	<ul style="list-style-type: none"> • <code>hcec</code>: CEC handle
Return values	<ul style="list-style-type: none"> • None

7.3.8 HAL_CEC_MspDelInit

Function Name	<code>void HAL_CEC_MspDelInit (CEC_HandleTypeDef * hcec)</code>
Function Description	CEC MSP DelInit.
Parameters	<ul style="list-style-type: none"> • <code>hcec</code>: CEC handle
Return values	<ul style="list-style-type: none"> • None

7.3.9 HAL_CEC_Transmit

Function Name	<code>HAL_StatusTypeDef HAL_CEC_Transmit (CEC_HandleTypeDef * hcec, uint8_t DestinationAddress, uint8_t * pData, uint32_t Size, uint32_t Timeout)</code>
Function Description	Send data in blocking mode.

Parameters	<ul style="list-style-type: none"> hcec: CEC handle DestinationAddress: destination logical address pData: pointer to input byte data buffer Size: amount of data to be sent in bytes (without counting the header). 0 means only the header is sent (ping operation). Maximum TX size is 15 bytes (1 opcode and up to 14 operands). Timeout: Timeout duration.
Return values	<ul style="list-style-type: none"> HAL status

7.3.10 HAL_CEC_Receive

Function Name	<code>HAL_StatusTypeDef HAL_CEC_Receive (CEC_HandleTypeDef * hcec, uint8_t * pData, uint32_t Timeout)</code>
Function Description	Receive data in blocking mode.
Parameters	<ul style="list-style-type: none"> hcec: CEC handle pData: pointer to received data buffer. Timeout: Timeout duration. Note that the received data size is not known beforehand, the latter is known when the reception is complete and is stored in <code>hcec->RxXferSize</code>. <code>hcec->RxXferSize</code> is the sum of opcodes + operands (0 to 14 operands max). If only a header is received, <code>hcec->RxXferSize = 0</code>
Return values	<ul style="list-style-type: none"> HAL status

7.3.11 HAL_CEC_Transmit_IT

Function Name	<code>HAL_StatusTypeDef HAL_CEC_Transmit_IT (CEC_HandleTypeDef * hcec, uint8_t DestinationAddress, uint8_t * pData, uint32_t Size)</code>
Function Description	Send data in interrupt mode.
Parameters	<ul style="list-style-type: none"> hcec: CEC handle DestinationAddress: destination logical address pData: pointer to input byte data buffer Size: amount of data to be sent in bytes (without counting the header). 0 means only the header is sent (ping operation). Maximum TX size is 15 bytes (1 opcode and up to 14 operands).
Return values	<ul style="list-style-type: none"> HAL status

7.3.12 HAL_CEC_Receive_IT

Function Name	<code>HAL_StatusTypeDef HAL_CEC_Receive_IT (CEC_HandleTypeDef * hcec, uint8_t * pData)</code>
Function Description	Receive data in interrupt mode.
Parameters	<ul style="list-style-type: none"> hcec: CEC handle pData: pointer to received data buffer. Note that the received data size is not known beforehand, the latter is known when the reception is complete and is stored in <code>hcec->RxXferSize</code>. <code>hcec->RxXferSize</code> is the sum of opcodes + operands (0 to 14

operands max). If only a header is received, hcec->RxXferSize = 0

Return values • HAL status

7.3.13 HAL_CEC_GetReceivedFrameSize

Function Name **uint32_t HAL_CEC_GetReceivedFrameSize (CEC_HandleTypeDef * hcec)**

Function Description Get size of the received frame.

Parameters • **hcec:** CEC handle

Return values • Frame size

7.3.14 HAL_CEC_IRQHandler

Function Name **void HAL_CEC_IRQHandler (CEC_HandleTypeDef * hcec)**

Function Description This function handles CEC interrupt requests.

Parameters • **hcec:** CEC handle

Return values • None

7.3.15 HAL_CEC_TxCpltCallback

Function Name **void HAL_CEC_TxCpltCallback (CEC_HandleTypeDef * hcec)**

Function Description Tx Transfer completed callback.

Parameters • **hcec:** CEC handle

Return values • None

7.3.16 HAL_CEC_RxCpltCallback

Function Name **void HAL_CEC_RxCpltCallback (CEC_HandleTypeDef * hcec)**

Function Description Rx Transfer completed callback.

Parameters • **hcec:** CEC handle

Return values • None

7.3.17 HAL_CEC_ErrorCallback

Function Name **void HAL_CEC_ErrorCallback (CEC_HandleTypeDef * hcec)**

Function Description CEC error callbacks.

Parameters • **hcec:** CEC handle

Return values • None

7.3.18 HAL_CEC_GetState

Function Name **HAL_CEC_StateTypeDef HAL_CEC_GetState (CEC_HandleTypeDef * hcec)**

Function Description return the CEC state

Parameters	<ul style="list-style-type: none">• hcec: CEC handle
Return values	<ul style="list-style-type: none">• HAL state

7.3.19 HAL_CEC_GetError

Function Name	uint32_t HAL_CEC_GetError (CEC_HandleTypeDef * hcec)
Function Description	Return the CEC error code.
Parameters	<ul style="list-style-type: none">• hcec: : pointer to a CEC_HandleTypeDef structure that contains the configuration information for the specified CEC.
Return values	<ul style="list-style-type: none">• CEC Error Code

7.4 CEC Firmware driver defines

7.4.1 CEC

CEC all RX or TX errors flags

`CEC_ISR_ALL_ERROR`

CEC Error Bit Generation if Bit Rise Error reported

`CEC_BRE_ERRORBIT_NO_GENERATION`

`CEC_BRE_ERRORBIT_GENERATION`

CEC Reception Stop on Error

`CEC_NO_RX_STOP_ON_BRE`

`CEC_RX_STOP_ON_BRE`

CEC Error Bit Generation on Broadcast message

`CEC_BROADCASTERROR_ERRORBIT_GENERATION`

`CEC_BROADCASTERROR_NO_ERRORBIT_GENERATION`

CEC Error Code

`HAL_CEC_ERROR_NONE` no error

`HAL_CEC_ERROR_RXOVR` CEC Rx-Overrun

`HAL_CEC_ERROR_BRE` CEC Rx Bit Rising Error

`HAL_CEC_ERROR_SBPE` CEC Rx Short Bit period Error

`HAL_CEC_ERROR_LBPE` CEC Rx Long Bit period Error

`HAL_CEC_ERROR_RXACKE` CEC Rx Missing Acknowledge

`HAL_CEC_ERROR_ARBLST` CEC Arbitration Lost

`HAL_CEC_ERROR_TXUDR` CEC Tx-Buffer Underrun

`HAL_CEC_ERROR_TXERR` CEC Tx-Error

`HAL_CEC_ERROR_TXACKE` CEC Tx Missing Acknowledge

CEC Exported Macros

<code>__HAL_CEC_RESET_HANDLE_STATE</code>	Description:
---	---------------------

- Reset CEC handle state.

Parameters:

- HANDLE: CEC handle.

Return value:

- None

_HAL_CEC_GET_FLAG

Description:

- Checks whether or not the specified CEC interrupt flag is set.

Parameters:

- HANDLE: specifies the CEC Handle.
- FLAG: specifies the interrupt to check.
 - CEC_FLAG_TXACKE: Tx Missing acknowledge Error
 - CEC_FLAG_TXERR: Tx Error.
 - CEC_FLAG_TXUDR: Tx-Buffer Underrun.
 - CEC_FLAG_TXEND: End of transmission (successful transmission of the last byte).
 - CEC_FLAG_TXBR: Tx-Byte Request.
 - CEC_FLAG_ARBLST: Arbitration Lost
 - CEC_FLAG_RXACKE: Rx-Missing Acknowledge
 - CEC_FLAG_LBPE: Rx Long period Error
 - CEC_FLAG_SBPE: Rx Short period Error
 - CEC_FLAG_BRE: Rx Bit Rissing Error
 - CEC_FLAG_RXOVR: Rx Overrun.
 - CEC_FLAG_RXEND: End Of Reception.
 - CEC_FLAG_RXBR: Rx-Byte Received.

Return value:

- ITStatus

_HAL_CEC_CLEAR_FLAG

Description:

- Clears the interrupt or status flag when raised (write at 1)

Parameters:

- HANDLE: specifies the CEC Handle.
- FLAG: specifies the interrupt/status flag to clear. This parameter can be one of the following values:
 - CEC_FLAG_TXACKE: Tx Missing acknowledge Error
 - CEC_FLAG_TXERR: Tx Error.
 - CEC_FLAG_TXUDR: Tx-Buffer Underrun.
 - CEC_FLAG_TXEND: End of transmission (successful transmission of the last byte).
 - CEC_FLAG_TXBR: Tx-Byte Request.
 - CEC_FLAG_ARBLST: Arbitration Lost
 - CEC_FLAG_RXACKE: Rx-Missing Acknowledge
 - CEC_FLAG_LBPE: Rx Long period Error
 - CEC_FLAG_SBPE: Rx Short period Error
 - CEC_FLAG_BRE: Rx Bit Rissing Error
 - CEC_FLAG_RXOVR: Rx Overrun.
 - CEC_FLAG_RXEND: End Of Reception.
 - CEC_FLAG_RXBR: Rx-Byte Received.

Return value:

- none

_HAL_CEC_ENABLE_IT

- Enables the specified CEC interrupt.

Parameters:

- HANDLE: specifies the CEC Handle.
- INTERRUPT: specifies the CEC interrupt to enable. This parameter can be one of the following values:
 - CEC_IT_TXACKE: Tx Missing acknowledge Error IT Enable
 - CEC_IT_TXERR: Tx Error

- IT Enable
- CEC_IT_TXUDR: Tx-Buffer Underrun IT Enable
- CEC_IT_TXEND: End of transmission IT Enable
- CEC_IT_TXBR: Tx-Byte Request IT Enable
- CEC_IT_ARBLST: Arbitration Lost IT Enable
- CEC_IT_RXACKE: Rx-Missing Acknowledge IT Enable
- CEC_IT_LBPE: Rx Long period Error IT Enable
- CEC_IT_SBPE: Rx Short period Error IT Enable
- CEC_IT_BRE: Rx Bit Rising Error IT Enable
- CEC_IT_RXOVR: Rx Overrun IT Enable
- CEC_IT_RXEND: End Of Reception IT Enable
- CEC_IT_RXBR: Rx-Byte Received IT Enable

Return value:

- none

_HAL_CEC_DISABLE_IT**Description:**

- Disables the specified CEC interrupt.

Parameters:

- _HANDLE_: specifies the CEC Handle.
- _INTERRUPT_: specifies the CEC interrupt to disable. This parameter can be one of the following values:
 - CEC_IT_TXACKE: Tx Missing acknowledge Error IT Enable
 - CEC_IT_TXERR: Tx Error IT Enable
 - CEC_IT_TXUDR: Tx-Buffer Underrun IT Enable
 - CEC_IT_TXEND: End of transmission IT Enable
 - CEC_IT_TXBR: Tx-Byte Request IT Enable
 - CEC_IT_ARBLST: Arbitration Lost IT Enable
 - CEC_IT_RXACKE: Rx-Missing Acknowledge IT

- Enable
- CEC_IT_LBPE: Rx Long period Error IT Enable
- CEC_IT_SBPE: Rx Short period Error IT Enable
- CEC_IT_BRE: Rx Bit Rising Error IT Enable
- CEC_IT_RXOVR: Rx Overrun IT Enable
- CEC_IT_RXEND: End Of Reception IT Enable
- CEC_IT_RXBR: Rx-Byte Received IT Enable

Return value:

- none

_HAL_CEC_GET_IT_SOURCE**Description:**

- Checks whether or not the specified CEC interrupt is enabled.

Parameters:

- _HANDLE_: specifies the CEC Handle.
- _INTERRUPT_: specifies the CEC interrupt to check. This parameter can be one of the following values:
 - CEC_IT_TXACKE: Tx Missing acknowledge Error IT Enable
 - CEC_IT_TXERR: Tx Error IT Enable
 - CEC_IT_TXUDR: Tx-Buffer Underrun IT Enable
 - CEC_IT_TXEND: End of transmission IT Enable
 - CEC_IT_TXBR: Tx-Byte Request IT Enable
 - CEC_IT_ARBLST: Arbitration Lost IT Enable
 - CEC_IT_RXACKE: Rx-Missing Acknowledge IT Enable
 - CEC_IT_LBPE: Rx Long period Error IT Enable
 - CEC_IT_SBPE: Rx Short period Error IT Enable
 - CEC_IT_BRE: Rx Bit Rising Error IT Enable
 - CEC_IT_RXOVR: Rx Overrun IT Enable
 - CEC_IT_RXEND: End Of

-
- Reception IT Enable
 - CEC_IT_RXBR: Rx-Byte Received IT Enable

Return value:

- FlagStatus

Description:

- Enables the CEC device.

Parameters:

- HANDLE: specifies the CEC Handle.

Return value:

- none

Description:

- Disables the CEC device.

Parameters:

- HANDLE: specifies the CEC Handle.

Return value:

- none

Description:

- Set Transmission Start flag.

Parameters:

- HANDLE: specifies the CEC Handle.

Return value:

- none

Description:

- Set Transmission End flag.

Parameters:

- HANDLE: specifies the CEC Handle.

Return value:

- none: If the CEC message consists of only one byte, TXEOM must be set before of TXSOM.

Description:

- Get Transmission Start flag.

Parameters:

- `__HANDLE__`: specifies the CEC Handle.

Return value:

- FlagStatus

Description:

- Get Transmission End flag.

Parameters:

- `__HANDLE__`: specifies the CEC Handle.

Return value:

- FlagStatus

Description:

- Clear OAR register.

Parameters:

- `__HANDLE__`: specifies the CEC Handle.

Return value:

- none

Description:

- Set OAR register (without resetting previously set address in case of multi-address mode)
To reset OAR,

Parameters:

- `__HANDLE__`: specifies the CEC Handle.
- `__ADDRESS__`: Own Address value (CEC logical address is identified by bit position)

Return value:

- none

CEC Flags definition

CEC_FLAG_TXACKE
 CEC_FLAG_TXERR
 CEC_FLAG_TXUDR
 CEC_FLAG_TXEND
 CEC_FLAG_TXBR
 CEC_FLAG_ARBLST
 CEC_FLAG_RXACKE

CEC_FLAG_LBPE
CEC_FLAG_SBPE
CEC_FLAG_BRE
CEC_FLAG_RXOVR
CEC_FLAG_RXEND
CEC_FLAG_RXBR
CEC all RX errors interrupts enabling flag
CEC_IER_RX_ALL_ERR
CEC all TX errors interrupts enabling flag
CEC_IER_TX_ALL_ERR
CEC Initiator logical address position in message header
CEC_INITIATOR_LSB_POS
CEC Interrupts definition
CEC_IT_TXACKE
CEC_IT_TXERR
CEC_IT_TXUDR
CEC_IT_TXEND
CEC_IT_TXBR
CEC_IT_ARBLST
CEC_IT_RXACKE
CEC_IT_LBPE
CEC_IT_SBPE
CEC_IT_BRE
CEC_IT_RXOVR
CEC_IT_RXEND
CEC_IT_RXBR
CEC Error Bit Generation if Long Bit Period Error reported
CEC_LBPE_ERRORBIT_NO_GENERATION
CEC_LBPE_ERRORBIT_GENERATION
CEC Listening mode option
CEC_REDUCED_LISTENING_MODE
CEC_FULL_LISTENING_MODE
CEC Device Own Address position in CEC CFGR register
CEC_CFGR_OAR_LSB_POS
CEC Private Constants
CEC_CFGR_FIELDS
CEC Private Macros

IS_CEC_SIGNALFREETIME	Description: <ul style="list-style-type: none">Check CEC device Own Address Register (OAR) setting. Parameters: <ul style="list-style-type: none"><u>ADDRESS</u>: CEC own address. Return value: <ul style="list-style-type: none">Test: result (TRUE or FALSE).
IS_CEC_TOLERANCE	Description: <ul style="list-style-type: none">Check CEC initiator or destination logical address setting. Parameters: <ul style="list-style-type: none"><u>ADDRESS</u>: CEC initiator or logical address. Return value: <ul style="list-style-type: none">Test: result (TRUE or FALSE).
IS_CEC_BRERXSTOP	Description: <ul style="list-style-type: none">Check CEC message size. Parameters: <ul style="list-style-type: none"><u>SIZE</u>: CEC message size. Return value: <ul style="list-style-type: none">Test: result
IS_CEC_BREERRORBITGEN	
IS_CEC_LBPERRORBITGEN	
IS_CEC_BROADCASTERROR_NO_ERRORBIT_GENERATION	
IS_CEC_SFTOP	
IS_CEC_LISTENING_MODE	
IS_CEC_OAR_ADDRESS	
IS_CEC_ADDRESS	
IS_CEC_MSGSIZE	

CEC Signal Free Time start option

CEC_SFT_START_ON_TXSOM

CEC_SFT_START_ON_RX_END

CEC Signal Free Time setting parameter

CEC_DEFAULT_SFT

CEC_0_5_BITPERIOD_SFT

CEC_1_5_BITPERIOD_SFT

CEC_2_5_BITPERIOD_SFT

CEC_3_5_BITPERIOD_SFT

CEC_4_5_BITPERIOD_SFT

CEC_5_5_BITPERIOD_SFT

CEC_6_5_BITPERIOD_SFT

CEC Receiver Tolerance

CEC_STANDARD_TOLERANCE

CEC_EXTENDED_TOLERANCE

8 HAL CORTEX Generic Driver

8.1 HAL CORTEX Generic Driver

8.2 CORTEX Firmware driver registers structures

8.2.1 MPU_Region_InitTypeDef

Data Fields

- *uint8_t Enable*
- *uint8_t Number*
- *uint32_t BaseAddress*
- *uint8_t Size*
- *uint8_t SubRegionDisable*
- *uint8_t TypeExtField*
- *uint8_t AccessPermission*
- *uint8_t DisableExec*
- *uint8_t IsShareable*
- *uint8_t IsCacheable*
- *uint8_t IsBufferable*

Field Documentation

- ***uint8_t MPU_Region_InitTypeDef::Enable***
Specifies the status of the region. This parameter can be a value of [**CORTEX MPU Region Enable**](#)
- ***uint8_t MPU_Region_InitTypeDef::Number***
Specifies the number of the region to protect. This parameter can be a value of [**CORTEX MPU Region Number**](#)
- ***uint32_t MPU_Region_InitTypeDef::BaseAddress***
Specifies the base address of the region to protect.
- ***uint8_t MPU_Region_InitTypeDef::Size***
Specifies the size of the region to protect. This parameter can be a value of [**CORTEX MPU Region Size**](#)
- ***uint8_t MPU_Region_InitTypeDef::SubRegionDisable***
Specifies the number of the subregion protection to disable. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF
- ***uint8_t MPU_Region_InitTypeDef::TypeExtField***
Specifies the TEX field level. This parameter can be a value of [**CORTEX MPU TEX Levels**](#)
- ***uint8_t MPU_Region_InitTypeDef::AccessPermission***
Specifies the region access permission type. This parameter can be a value of [**CORTEX MPU Region Permission Attributes**](#)
- ***uint8_t MPU_Region_InitTypeDef::DisableExec***
Specifies the instruction access status. This parameter can be a value of [**CORTEX MPU Instruction Access**](#)
- ***uint8_t MPU_Region_InitTypeDef::IsShareable***
Specifies the shareability status of the protected region. This parameter can be a value of [**CORTEX MPU Access Shareable**](#)

- ***uint8_t MPU_Region_InitTypeDef::IsCacheable***
Specifies the cacheable status of the region protected. This parameter can be a value of **CORTEX_MPUMemoryAccessCacheable**
- ***uint8_t MPU_Region_InitTypeDef::IsBufferable***
Specifies the bufferable status of the protected region. This parameter can be a value of **CORTEX_MPUMemoryAccessBufferable**

8.3 CORTEX Firmware driver API description

8.3.1 How to use this driver

How to configure Interrupts using CORTEX HAL driver

This section provides functions allowing to configure the NVIC interrupts (IRQ). The Cortex-M4 exceptions are managed by CMSIS functions.

1. Configure the NVIC Priority Grouping using HAL_NVIC_SetPriorityGrouping() function according to the following table.
2. Configure the priority of the selected IRQ Channels using HAL_NVIC_SetPriority().
3. Enable the selected IRQ Channels using HAL_NVIC_EnableIRQ().
4. please refer to programing manual for details in how to configure priority. When the NVIC_PRIORITYGROUP_0 is selected, IRQ preemption is no more possible. The pending IRQ priority will be managed only by the sub priority. IRQ priority order (sorted by highest to lowest priority): Lowest preemption priority Lowest sub priority Lowest hardware priority (IRQ number)

How to configure Systick using CORTEX HAL driver

Setup SysTick Timer for time base.

- The HAL_SYSTICK_Config() function calls the SysTick_Config() function which is a CMSIS function that:
 - Configures the SysTick Reload register with value passed as function parameter.
 - Configures the SysTick IRQ priority to the lowest value (0x0F).
 - Resets the SysTick Counter register.
 - Configures the SysTick Counter clock source to be Core Clock Source (HCLK).
 - Enables the SysTick Interrupt.
 - Starts the SysTick Counter.
- You can change the SysTick Clock source to be HCLK_Div8 by calling the macro `__HAL_CORTEX_SYSTICKCLK_CONFIG(SYSTICK_CLKSOURCE_HCLK_DIV8)` just after the HAL_SYSTICK_Config() function call. The `__HAL_CORTEX_SYSTICKCLK_CONFIG()` macro is defined inside the `stm32f4xx_hal_cortex.h` file.
- You can change the SysTick IRQ priority by calling the `HAL_NVIC_SetPriority(SysTick_IRQn,...)` function just after the HAL_SYSTICK_Config() function call. The HAL_NVIC_SetPriority() call the NVIC_SetPriority() function which is a CMSIS function.
- To adjust the SysTick time base, use the following formula: Reload Value = SysTick Counter Clock (Hz) x Desired Time base (s)
 - Reload Value is the parameter to be passed for HAL_SYSTICK_Config() function

-
- Reload Value should not exceed 0xFFFFFFF

8.3.2 Initialization and de-initialization functions

This section provides the CORTEX HAL driver functions allowing to configure Interrupts Systick functionalities

This section contains the following APIs:

- [*HAL_NVIC_SetPriorityGrouping\(\)*](#)
- [*HAL_NVIC_SetPriority\(\)*](#)
- [*HAL_NVIC_EnableIRQ\(\)*](#)
- [*HAL_NVIC_DisableIRQ\(\)*](#)
- [*HAL_NVIC_SystemReset\(\)*](#)
- [*HAL_SYSTICK_Config\(\)*](#)

8.3.3 Peripheral Control functions

This subsection provides a set of functions allowing to control the CORTEX (NVIC, SYSTICK, MPU) functionalities.

This section contains the following APIs:

- [*HAL_MPU_ConfigRegion\(\)*](#)
- [*HAL_NVIC_GetPriorityGrouping\(\)*](#)
- [*HAL_NVIC_GetPriority\(\)*](#)
- [*HAL_NVIC_SetPendingIRQ\(\)*](#)
- [*HAL_NVIC_GetPendingIRQ\(\)*](#)
- [*HAL_NVIC_ClearPendingIRQ\(\)*](#)
- [*HAL_NVIC_GetActive\(\)*](#)
- [*HAL_SYSTICK_CLKSourceConfig\(\)*](#)
- [*HAL_SYSTICK_IRQHandler\(\)*](#)
- [*HAL_SYSTICK_Callback\(\)*](#)

8.3.4 HAL_NVIC_SetPriorityGrouping

Function Name	void HAL_NVIC_SetPriorityGrouping (uint32_t PriorityGroup)
Function Description	Sets the priority grouping field (preemption priority and subpriority) using the required unlock sequence.
Parameters	<ul style="list-style-type: none"> • PriorityGroup: The priority grouping bits length. This parameter can be one of the following values: NVIC_PRIORITYGROUP_0: 0 bits for preemption priority 4 bits for subpriority NVIC_PRIORITYGROUP_1: 1 bits for preemption priority 3 bits for subpriority NVIC_PRIORITYGROUP_2: 2 bits for preemption priority 2 bits for subpriority NVIC_PRIORITYGROUP_3: 3 bits for preemption priority 1 bits for subpriority NVIC_PRIORITYGROUP_4: 4 bits for preemption priority 0 bits for subpriority
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • When the NVIC_PriorityGroup_0 is selected, IRQ preemption is no more possible. The pending IRQ priority will be managed only by the subpriority.

8.3.5 HAL_NVIC_SetPriority

Function Name	void HAL_NVIC_SetPriority (IRQn_Type IRQn, uint32_t PreemptPriority, uint32_t SubPriority)
Function Description	Sets the priority of an interrupt.
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number. This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h)) PreemptPriority: The preemption priority for the IRQn channel. This parameter can be a value between 0 and 15 A lower priority value indicates a higher priority SubPriority: the subpriority level for the IRQ channel. This parameter can be a value between 0 and 15 A lower priority value indicates a higher priority.
Return values	<ul style="list-style-type: none"> None

8.3.6 HAL_NVIC_EnableIRQ

Function Name	void HAL_NVIC_EnableIRQ (IRQn_Type IRQn)
Function Description	Enables a device specific interrupt in the NVIC interrupt controller.
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number. This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h))
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> To configure interrupts priority correctly, the NVIC_PriorityGroupConfig() function should be called before.

8.3.7 HAL_NVIC_DisableIRQ

Function Name	void HAL_NVIC_DisableIRQ (IRQn_Type IRQn)
Function Description	Disables a device specific interrupt in the NVIC interrupt controller.
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number. This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h))
Return values	<ul style="list-style-type: none"> None

8.3.8 HAL_NVIC_SystemReset

Function Name	void HAL_NVIC_SystemReset (void)
Function Description	Initiates a system reset request to reset the MCU.
Return values	<ul style="list-style-type: none"> None

8.3.9 HAL_SYSTICK_Config

Function Name	uint32_t HAL_SYSTICK_Config (uint32_t TicksNumb)
Function Description	Initializes the System Timer and its interrupt, and starts the System

Tick Timer.

Parameters	<ul style="list-style-type: none"> TicksNumb: Specifies the ticks Number of ticks between two interrupts.
Return values	<ul style="list-style-type: none"> status - 0 Function succeeded. 1 Function failed.

8.3.10 HAL_MPU_ConfigRegion

Function Name	void HAL_MPU_ConfigRegion (MPU_Region_InitTypeDef * MPU_Init)
Function Description	Initializes and configures the Region and the memory to be protected.
Parameters	<ul style="list-style-type: none"> MPU_Init: Pointer to a MPU_Region_InitTypeDef structure that contains the initialization and configuration information.
Return values	<ul style="list-style-type: none"> None

8.3.11 HAL_NVIC_GetPriorityGrouping

Function Name	uint32_t HAL_NVIC_GetPriorityGrouping (void)
Function Description	Gets the priority grouping field from the NVIC Interrupt Controller.
Return values	<ul style="list-style-type: none"> Priority grouping field (SCB->AIRCR [10:8] PRIGROUP field)

8.3.12 HAL_NVIC_GetPriority

Function Name	void HAL_NVIC_GetPriority (IRQn_Type IRQn, uint32_t PriorityGroup, uint32_t * pPreemptPriority, uint32_t * pSubPriority)
Function Description	Gets the priority of an interrupt.
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number. This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h)) PriorityGroup: the priority grouping bits length. This parameter can be one of the following values: NVIC_PRIORITYGROUP_0: 0 bits for preemption priority 4 bits for subpriority NVIC_PRIORITYGROUP_1: 1 bits for preemption priority 3 bits for subpriority NVIC_PRIORITYGROUP_2: 2 bits for preemption priority 2 bits for subpriority NVIC_PRIORITYGROUP_3: 3 bits for preemption priority 1 bits for subpriority NVIC_PRIORITYGROUP_4: 4 bits for preemption priority 0 bits for subpriority pPreemptPriority: Pointer on the Preemptive priority value (starting from 0). pSubPriority: Pointer on the Subpriority value (starting from 0).
Return values	<ul style="list-style-type: none"> None

8.3.13 HAL_NVIC_SetPendingIRQ

Function Name	void HAL_NVIC_SetPendingIRQ (IRQn_Type IRQn)
Function Description	Sets Pending bit of an external interrupt.
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h))
Return values	<ul style="list-style-type: none"> None

8.3.14 HAL_NVIC_SetPendingIRQ

Function Name	uint32_t HAL_NVIC_SetPendingIRQ (IRQn_Type IRQn)
Function Description	Gets Pending Interrupt (reads the pending register in the NVIC and returns the pending bit for the specified interrupt).
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number. This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h))
Return values	<ul style="list-style-type: none"> status - 0 Interrupt status is not pending. 1 Interrupt status is pending.

8.3.15 HAL_NVIC_ClearPendingIRQ

Function Name	void HAL_NVIC_ClearPendingIRQ (IRQn_Type IRQn)
Function Description	Clears the pending bit of an external interrupt.
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number. This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h))
Return values	<ul style="list-style-type: none"> None

8.3.16 HAL_NVIC_GetActive

Function Name	uint32_t HAL_NVIC_GetActive (IRQn_Type IRQn)
Function Description	Gets active interrupt (reads the active register in NVIC and returns the active bit).
Parameters	<ul style="list-style-type: none"> IRQn: External interrupt number This parameter can be an enumerator of IRQn_Type enumeration (For the complete STM32 Devices IRQ Channels list, please refer to the appropriate CMSIS device file (stm32f4xxxx.h))
Return values	<ul style="list-style-type: none"> status - 0 Interrupt status is not pending. 1 Interrupt status is pending.

8.3.17 HAL_SYSTICK_CLKSourceConfig

Function Name	void HAL_SYSTICK_CLKSourceConfig (uint32_t CLKSource)
Function Description	Configures the SysTick clock source.
Parameters	<ul style="list-style-type: none"> CLKSource: specifies the SysTick clock source. This

parameter can be one of the following values:
 SYSTICK_CLKSOURCE_HCLK_DIV8: AHB clock divided by 8 selected as SysTick clock source.
 SYSTICK_CLKSOURCE_HCLK: AHB clock selected as SysTick clock source.

Return values • None

8.3.18 HAL_SYSTICK_IRQHandler

Function Name **void HAL_SYSTICK_IRQHandler (void)**
 Function Description This function handles SYSTICK interrupt request.
 Return values • None

8.3.19 HAL_SYSTICK_Callback

Function Name **void HAL_SYSTICK_Callback (void)**
 Function Description SYSTICK callback.
 Return values • None

8.4 CORTEX Firmware driver defines

8.4.1 CORTEX

CORTEX Exported Macros

__HAL_CORTEX_SYSTICKCLK_CON FIG **Description:**
 • Configures the SysTick clock source.
Parameters:
 • **__CLKSRC**: specifies the SysTick clock source. This parameter can be one of the following values:
 – SYSTICK_CLKSOURCE_HCLK_DIV8: AHB clock divided by 8 selected as SysTick clock source.
 – SYSTICK_CLKSOURCE_HCLK: AHB clock selected as SysTick clock source.

Return value:

- None

CORTEX MPU Instruction Access Bufferable

MPU_ACCESS_BUFFERABLE

MPU_ACCESS_NOT_BUFFERABLE

CORTEX MPU Instruction Access Cacheable

MPU_ACCESS_CACHEABLE

MPU_ACCESS_NOT_CACHEABLE

CORTEX MPU Instruction Access Shareable

MPU_ACCESS_SHAREABLE
MPU_ACCESS_NOT_SHAREABLE
MPU_HFNMI and PRIVILEGED Access control
MPU_HFNMI_PRIVDEF_NONE
MPU_HARDFAULT_NMI
MPU_PRIVILEGED_DEFAULT
MPU_HFNMI_PRIVDEF
CORTEX MPU Instruction Access
MPU_INSTRUCTION_ACCESS_ENABLE
MPU_INSTRUCTION_ACCESS_DISABLE
CORTEX MPU Region Enable
MPU_REGION_ENABLE
MPU_REGION_DISABLE
CORTEX MPU Region Number
MPU_REGION_NUMBER0
MPU_REGION_NUMBER1
MPU_REGION_NUMBER2
MPU_REGION_NUMBER3
MPU_REGION_NUMBER4
MPU_REGION_NUMBER5
MPU_REGION_NUMBER6
MPU_REGION_NUMBER7
CORTEX MPU Region Permission Attributes
MPU_REGION_NO_ACCESS
MPU_REGION_PRIV_RW
MPU_REGION_PRIV_RW_URO
MPU_REGION_FULL_ACCESS
MPU_REGION_PRIV_RO
MPU_REGION_PRIV_RO_URO
CORTEX MPU Region Size
MPU_REGION_SIZE_32B
MPU_REGION_SIZE_64B
MPU_REGION_SIZE_128B
MPU_REGION_SIZE_256B
MPU_REGION_SIZE_512B
MPU_REGION_SIZE_1KB

MPU_REGION_SIZE_2KB
MPU_REGION_SIZE_4KB
MPU_REGION_SIZE_8KB
MPU_REGION_SIZE_16KB
MPU_REGION_SIZE_32KB
MPU_REGION_SIZE_64KB
MPU_REGION_SIZE_128KB
MPU_REGION_SIZE_256KB
MPU_REGION_SIZE_512KB
MPU_REGION_SIZE_1MB
MPU_REGION_SIZE_2MB
MPU_REGION_SIZE_4MB
MPU_REGION_SIZE_8MB
MPU_REGION_SIZE_16MB
MPU_REGION_SIZE_32MB
MPU_REGION_SIZE_64MB
MPU_REGION_SIZE_128MB
MPU_REGION_SIZE_256MB
MPU_REGION_SIZE_512MB
MPU_REGION_SIZE_1GB
MPU_REGION_SIZE_2GB
MPU_REGION_SIZE_4GB

MPU TEX Levels

MPU_TEX_LEVEL0
MPU_TEX_LEVEL1
MPU_TEX_LEVEL2

CORTEX Preemption Priority Group

NVIC_PRIORITYGROUP_0	0 bits for pre-emption priority 4 bits for subpriority
NVIC_PRIORITYGROUP_1	1 bits for pre-emption priority 3 bits for subpriority
NVIC_PRIORITYGROUP_2	2 bits for pre-emption priority 2 bits for subpriority
NVIC_PRIORITYGROUP_3	3 bits for pre-emption priority 1 bits for subpriority
NVIC_PRIORITYGROUP_4	4 bits for pre-emption priority 0 bits for subpriority

CORTEX Private Macros

IS_NVIC_PRIORITY_GROUP
IS_NVIC_PREEMPTION_PRIORITY
IS_NVIC_SUB_PRIORITY

IS_NVIC_DEVICE_IRQ
IS_SYSTICK_CLK_SOURCE
IS MPU_REGION_ENABLE
IS MPU_INSTRUCTION_ACCESS
IS MPU_ACCESS_SHAREABLE
IS MPU_ACCESS_CACHEABLE
IS MPU_ACCESS_BUFFERABLE
IS MPU_TEX_LEVEL
IS MPU_REGION_PERMISSION_ATTRIBUTE
IS MPU_REGION_NUMBER
IS MPU_REGION_SIZE
IS MPU_SUB_REGION_DISABLE
CORTEX_SysTick clock source
SYSTICK_CLKSOURCE_HCLK_DIV8
SYSTICK_CLKSOURCE_HCLK

9 HAL CRC Generic Driver

9.1 HAL CRC Generic Driver

9.2 CRC Firmware driver registers structures

9.2.1 CRC_HandleTypeDef

Data Fields

- *CRC_TypeDef * Instance*
- *HAL_LockTypeDef Lock*
- *__IO HAL_CRC_StateTypeDef State*

Field Documentation

- ***CRC_TypeDef* CRC_HandleTypeDef::Instance***
Register base address
- ***HAL_LockTypeDef CRC_HandleTypeDef::Lock***
CRC locking object
- ***__IO HAL_CRC_StateTypeDef CRC_HandleTypeDef::State***
CRC communication state

9.3 CRC Firmware driver API description

9.3.1 How to use this driver

The CRC HAL driver can be used as follows:

1. Enable CRC AHB clock using `__HAL_RCC_CRC_CLK_ENABLE()`;
2. Use `HAL_CRC_Accumulate()` function to compute the CRC value of a 32-bit data buffer using combination of the previous CRC value and the new one.
3. Use `HAL_CRC_Calculate()` function to compute the CRC Value of a new 32-bit data buffer. This function resets the CRC computation unit before starting the computation to avoid getting wrong CRC values.

9.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the CRC according to the specified parameters in the `CRC_InitTypeDef` and create the associated handle
- Deinitialize the CRC peripheral
- Initialize the CRC MSP
- Deinitialize CRC MSP

This section contains the following APIs:

- [`HAL_CRC_Init\(\)`](#)
- [`HAL_CRC_DelInit\(\)`](#)
- [`HAL_CRC_MspInit\(\)`](#)

- [*HAL_CRC_MspDeInit\(\)*](#)

9.3.3 Peripheral Control functions

This section provides functions allowing to:

- Compute the 32-bit CRC value of 32-bit data buffer, using combination of the previous CRC value and the new one.
- Compute the 32-bit CRC value of 32-bit data buffer, independently of the previous CRC value.

This section contains the following APIs:

- [*HAL_CRC_Accumulate\(\)*](#)
- [*HAL_CRC_Calculate\(\)*](#)

9.3.4 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_CRC_GetState\(\)*](#)

9.3.5 HAL_CRC_Init

Function Name	<code>HAL_StatusTypeDef HAL_CRC_Init (CRC_HandleTypeDef * hcrc)</code>
Function Description	Initializes the CRC according to the specified parameters in the <code>CRC_InitTypeDef</code> and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a <code>CRC_HandleTypeDef</code> structure that contains the configuration information for CRC
Return values	<ul style="list-style-type: none"> • HAL status

9.3.6 HAL_CRC_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_CRC_DeInit (CRC_HandleTypeDef * hcrc)</code>
Function Description	Deinitializes the CRC peripheral.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a <code>CRC_HandleTypeDef</code> structure that contains the configuration information for CRC
Return values	<ul style="list-style-type: none"> • HAL status

9.3.7 HAL_CRC_MspInit

Function Name	<code>void HAL_CRC_MspInit (CRC_HandleTypeDef * hcrc)</code>
Function Description	Initializes the CRC MSP.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a <code>CRC_HandleTypeDef</code> structure that contains the configuration information for CRC
Return values	<ul style="list-style-type: none"> • None

9.3.8 HAL_CRC_MspDeInit

Function Name	void HAL_CRC_MspDelInit (CRC_HandleTypeDef * hcrc)
Function Description	Deinitializes the CRC MSP.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a CRC_HandleTypeDef structure that contains the configuration information for CRC
Return values	<ul style="list-style-type: none"> • None

9.3.9 HAL_CRC_Accumulate

Function Name	uint32_t HAL_CRC_Accumulate (CRC_HandleTypeDef * hcrc, uint32_t pBuffer, uint32_t BufferLength)
Function Description	Computes the 32-bit CRC of 32-bit data buffer using combination of the previous CRC value and the new one.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a CRC_HandleTypeDef structure that contains the configuration information for CRC • pBuffer: pointer to the buffer containing the data to be computed • BufferLength: length of the buffer to be computed
Return values	<ul style="list-style-type: none"> • 32-bit CRC

9.3.10 HAL_CRC_Calculate

Function Name	uint32_t HAL_CRC_Calculate (CRC_HandleTypeDef * hcrc, uint32_t pBuffer, uint32_t BufferLength)
Function Description	Computes the 32-bit CRC of 32-bit data buffer independently of the previous CRC value.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a CRC_HandleTypeDef structure that contains the configuration information for CRC • pBuffer: Pointer to the buffer containing the data to be computed • BufferLength: Length of the buffer to be computed
Return values	<ul style="list-style-type: none"> • 32-bit CRC

9.3.11 HAL_CRC_GetState

Function Name	HAL_CRC_StateTypeDef HAL_CRC_GetState (CRC_HandleTypeDef * hcrc)
Function Description	Returns the CRC state.
Parameters	<ul style="list-style-type: none"> • hcrc: pointer to a CRC_HandleTypeDef structure that contains the configuration information for CRC
Return values	<ul style="list-style-type: none"> • HAL state

9.4 CRC Firmware driver defines

9.4.1 CRC

CRC Exported Macros

_HAL_CRC_RESET_HANDLE_STATE Description:

- Resets CRC handle state.

Parameters:

- `__HANDLE__`: CRC handle

Return value:

- None

`__HAL_CRC_DR_RESET`

Description:

- Resets CRC Data Register.

Parameters:

- `__HANDLE__`: CRC handle

Return value:

- None

`__HAL_CRC_SET_IDR`

Description:

- Stores a 8-bit data in the Independent Data(ID) register.

Parameters:

- `__HANDLE__`: CRC handle
- `__VALUE__`: 8-bit value to be stored in the ID register

Return value:

- None

`__HAL_CRC_GET_IDR`

Description:

- Returns the 8-bit data stored in the Independent Data(ID) register.

Parameters:

- `__HANDLE__`: CRC handle

Return value:

- 8-bit: value of the ID register

10 HAL CRYP Generic Driver

10.1 HAL CRYP Generic Driver

10.2 CRYP Firmware driver registers structures

10.2.1 CRYP_InitTypeDef

Data Fields

- *uint32_t DataType*
- *uint32_t KeySize*
- *uint8_t * pKey*
- *uint8_t * pInitVect*
- *uint8_t IVSize*
- *uint8_t TagSize*
- *uint8_t * Header*
- *uint32_t HeaderSize*
- *uint8_t * pScratch*

Field Documentation

- ***uint32_t CRYP_InitTypeDef::DataType***
32-bit data, 16-bit data, 8-bit data or 1-bit string. This parameter can be a value of ***CRYP_Data_Type***
- ***uint32_t CRYP_InitTypeDef::KeySize***
Used only in AES mode only : 128, 192 or 256 bit key length. This parameter can be a value of ***CRYP_Key_Size***
- ***uint8_t* CRYP_InitTypeDef::pKey***
The key used for encryption/decryption
- ***uint8_t* CRYP_InitTypeDef::pInitVect***
The initialization vector used also as initialization counter in CTR mode
- ***uint8_t CRYP_InitTypeDef::IVSize***
The size of initialization vector. This parameter (called nonce size in CCM) is used only in AES-128/192/256 encryption/decryption CCM mode
- ***uint8_t CRYP_InitTypeDef::TagSize***
The size of returned authentication TAG. This parameter is used only in AES-128/192/256 encryption/decryption CCM mode
- ***uint8_t* CRYP_InitTypeDef::Header***
The header used in GCM and CCM modes
- ***uint32_t CRYP_InitTypeDef::HeaderSize***
The size of header buffer in bytes
- ***uint8_t* CRYP_InitTypeDef::pScratch***
Scratch buffer used to append the header. It's size must be equal to header size + 21 bytes. This parameter is used only in AES-128/192/256 encryption/decryption CCM mode

10.2.2 CRYP_HandleTypeDef

Data Fields

- *CRYP_TypeDef * Instance*
- *CRYP_InitTypeDef Init*
- *uint8_t * pCrypInBuffPtr*
- *uint8_t * pCrypOutBuffPtr*
- *_IO uint16_t CrypInCount*
- *_IO uint16_t CrypOutCount*
- *HAL_StatusTypeDef Status*
- *HAL_PhaseTypeDef Phase*
- *DMA_HandleTypeDef * hdmain*
- *DMA_HandleTypeDef * hdmaout*
- *HAL_LockTypeDef Lock*
- *_IO HAL_CRYP_STATETypeDef State*

Field Documentation

- ***CRYP_TypeDef* CRYP_HandleTypeDef::Instance***
CRYP registers base address
- ***CRYP_InitTypeDef CRYP_HandleTypeDef::Init***
CRYP required parameters
- ***uint8_t* CRYP_HandleTypeDef::pCrypInBuffPtr***
Pointer to CRYP processing (encryption, decryption,...) buffer
- ***uint8_t* CRYP_HandleTypeDef::pCrypOutBuffPtr***
Pointer to CRYP processing (encryption, decryption,...) buffer
- ***_IO uint16_t CRYP_HandleTypeDef::CrypInCount***
Counter of inputed data
- ***_IO uint16_t CRYP_HandleTypeDef::CrypOutCount***
Counter of outputted data
- ***HAL_StatusTypeDef CRYP_HandleTypeDef::Status***
CRYP peripheral status
- ***HAL_PhaseTypeDef CRYP_HandleTypeDef::Phase***
CRYP peripheral phase
- ***DMA_HandleTypeDef* CRYP_HandleTypeDef::hdmain***
CRYP In DMA handle parameters
- ***DMA_HandleTypeDef* CRYP_HandleTypeDef::hdmaout***
CRYP Out DMA handle parameters
- ***HAL_LockTypeDef CRYP_HandleTypeDef::Lock***
CRYP locking object
- ***_IO HAL_CRYP_STATETypeDef CRYP_HandleTypeDef::State***
CRYP peripheral state

10.3 CRYP Firmware driver API description

10.3.1 How to use this driver

The CRYP HAL driver can be used as follows:

1. Initialize the CRYP low level resources by implementing the HAL_CRYP_MspInit():
 - a. Enable the CRYP interface clock using __HAL_RCC_CRYP_CLK_ENABLE()

- b. In case of using interrupts (e.g. HAL_CRYP_AESECB_Encrypt_IT())
 - Configure the CRYP interrupt priority using HAL_NVIC_SetPriority()
 - Enable the CRYP IRQ handler using HAL_NVIC_EnableIRQ()
 - In CRYP IRQ handler, call HAL_CRYP_IRQHandler()
 - c. In case of using DMA to control data transfer (e.g. HAL_CRYP_AESECB_Encrypt_DMA())
 - Enable the DMAx interface clock using __DMAx_CLK_ENABLE()
 - Configure and enable two DMA streams one for managing data transfer from memory to peripheral (input stream) and another stream for managing data transfer from peripheral to memory (output stream)
 - Associate the initialized DMA handle to the CRYP DMA handle using __HAL_LINKDMA()
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the two DMA Streams. The output stream should have higher priority than the input stream HAL_NVIC_SetPriority() and HAL_NVIC_EnableIRQ()
2. Initialize the CRYP HAL using HAL_CRYP_Init(). This function configures mainly:
- a. The data type: 1-bit, 8-bit, 16-bit and 32-bit
 - b. The key size: 128, 192 and 256. This parameter is relevant only for AES
 - c. The encryption/decryption key. Its size depends on the algorithm used for encryption/decryption
 - d. The initialization vector (counter). It is not used ECB mode.
3. Three processing (encryption/decryption) functions are available:
- a. Polling mode: encryption and decryption APIs are blocking functions i.e. they process the data and wait till the processing is finished, e.g. HAL_CRYP_AESCBC_Encrypt()
 - b. Interrupt mode: encryption and decryption APIs are not blocking functions i.e. they process the data under interrupt, e.g. HAL_CRYP_AESCBC_Encrypt_IT()
 - c. DMA mode: encryption and decryption APIs are not blocking functions i.e. the data transfer is ensured by DMA, e.g. HAL_CRYP_AESCBC_Encrypt_DMA()
4. When the processing function is called at first time after HAL_CRYP_Init() the CRYP peripheral is initialized and processes the buffer in input. At second call, the processing function performs an append of the already processed buffer. When a new data block is to be processed, call HAL_CRYP_Init() then the processing function.
5. Call HAL_CRYP_DeInit() to deinitialize the CRYP peripheral.

10.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the CRYP according to the specified parameters in the CRYP_InitTypeDef and creates the associated handle
- DeInitialize the CRYP peripheral
- Initialize the CRYP MSP
- DeInitialize CRYP MSP

This section contains the following APIs:

- [**HAL_CRYP_Init\(\)**](#)
- [**HAL_CRYP_DeInit\(\)**](#)
- [**HAL_CRYP_MspInit\(\)**](#)
- [**HAL_CRYP_MspDeInit\(\)**](#)

10.3.3 AES processing functions

This section provides functions allowing to:

-
- Encrypt plaintext using AES-128/192/256 using chaining modes
 - Decrypt ciphertext using AES-128/192/256 using chaining modes

Three processing functions are available:

- Polling mode
- Interrupt mode
- DMA mode

This section contains the following APIs:

- [*HAL_CRYP_AESECB_Encrypt\(\)*](#)
- [*HAL_CRYP_AESCBC_Encrypt\(\)*](#)
- [*HAL_CRYP_AESCTR_Encrypt\(\)*](#)
- [*HAL_CRYP_AESECB_Decrypt\(\)*](#)
- [*HAL_CRYP_AESCBC_Decrypt\(\)*](#)
- [*HAL_CRYP_AESCTR_Decrypt\(\)*](#)
- [*HAL_CRYP_AESECB_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_AESCBC_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_AESCTR_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_AESECB_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_AESCBC_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_AESCTR_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_AESECB_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_AESCBC_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_AESCTR_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_AESECB_Decrypt_DMA\(\)*](#)
- [*HAL_CRYP_AESCBC_Decrypt_DMA\(\)*](#)
- [*HAL_CRYP_AESCTR_Decrypt_DMA\(\)*](#)

10.3.4 DES processing functions

This section provides functions allowing to:

- Encrypt plaintext using DES using ECB or CBC chaining modes
- Decrypt ciphertext using ECB or CBC chaining modes

Three processing functions are available:

- Polling mode
- Interrupt mode
- DMA mode

This section contains the following APIs:

- [*HAL_CRYP_DESECB_Encrypt\(\)*](#)
- [*HAL_CRYP_DESECB_Decrypt\(\)*](#)
- [*HAL_CRYP_DESCBC_Encrypt\(\)*](#)
- [*HAL_CRYP_DESCBC_Decrypt\(\)*](#)
- [*HAL_CRYP_DESECB_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_DESCBC_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_DESECB_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_DESCBC_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_DESECB_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_DESCBC_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_DESECB_Decrypt_DMA\(\)*](#)
- [*HAL_CRYP_DESCBC_Decrypt_DMA\(\)*](#)

10.3.5 TDES processing functions

This section provides functions allowing to:

- Encrypt plaintext using TDES based on ECB or CBC chaining modes
- Decrypt ciphertext using TDES based on ECB or CBC chaining modes

Three processing functions are available:

- Polling mode
- Interrupt mode
- DMA mode

This section contains the following APIs:

- [*HAL_CRYP_TDESECB_Encrypt\(\)*](#)
- [*HAL_CRYP_TDESECB_Decrypt\(\)*](#)
- [*HAL_CRYP_TDESCBC_Encrypt\(\)*](#)
- [*HAL_CRYP_TDESCBC_Decrypt\(\)*](#)
- [*HAL_CRYP_TDESECB_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_TDESCBC_Encrypt_IT\(\)*](#)
- [*HAL_CRYP_TDESECB_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_TDESCBC_Decrypt_IT\(\)*](#)
- [*HAL_CRYP_TDESECB_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_TDESCBC_Encrypt_DMA\(\)*](#)
- [*HAL_CRYP_TDESECB_Decrypt_DMA\(\)*](#)
- [*HAL_CRYP_TDESCBC_Decrypt_DMA\(\)*](#)

10.3.6 DMA callback functions

This section provides DMA callback functions:

- DMA Input data transfer complete
- DMA Output data transfer complete
- DMA error

This section contains the following APIs:

- [*HAL_CRYP_InCpltCallback\(\)*](#)
- [*HAL_CRYP_OutCpltCallback\(\)*](#)
- [*HAL_CRYP_ErrorCallback\(\)*](#)

10.3.7 CRYP IRQ handler management

This section provides CRYP IRQ handler function.

This section contains the following APIs:

- [*HAL_CRYP_IRQHandler\(\)*](#)

10.3.8 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral.

This section contains the following APIs:

- [*HAL_CRYP_GetState\(\)*](#)

10.3.9 HAL_CRYP_Init

Function Name **HAL_StatusTypeDef HAL_CRYP_Init (CRYP_HandleTypeDef **hCRYP*)**

hcryp)

Function Description	Initializes the CRYP according to the specified parameters in the CRYP_InitTypeDef and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> • HAL status

10.3.10 HAL_CRYP_DelInit

Function Name	HAL_StatusTypeDef HAL_CRYP_DelInit (CRYP_HandleTypeDef * hcryp)
Function Description	Deinitializes the CRYP peripheral.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> • HAL status

10.3.11 HAL_CRYP_MspInit

Function Name	void HAL_CRYP_MspInit (CRYP_HandleTypeDef * hcryp)
Function Description	Initializes the CRYP MSP.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> • None

10.3.12 HAL_CRYP_MspDelInit

Function Name	void HAL_CRYP_MspDelInit (CRYP_HandleTypeDef * hcryp)
Function Description	Deinitializes CRYP MSP.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> • None

10.3.13 HAL_CRYP_AESECB_Encrypt

Function Name	HAL_StatusTypeDef HAL_CRYP_AESECB_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in AES ECB encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.14 HAL_CRYP_AESCBC_Encrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESCBC_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in AES CBC encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.15 HAL_CRYP_AESCTR_Encrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESCTR_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in AES CTR encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.16 HAL_CRYP_AESECB_Decrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESECB_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in AES ECB decryption mode then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pPlainData: Pointer to the plaintext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.17 HAL_CRYP_AESCBC_Decrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESCBC_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData,</code>
---------------	--

uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)

Function Description	Initializes the CRYP peripheral in AES ECB decryption mode then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pPlainData: Pointer to the plaintext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.18 HAL_CRYP_AESCTR_Decrypt

Function Name	HAL_StatusTypeDef HAL_CRYP_AESCTR_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in AES CTR decryption mode then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pPlainData: Pointer to the plaintext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.19 HAL_CRYP_AESECB_Encrypt_IT

Function Name	HAL_StatusTypeDef HAL_CRYP_AESECB_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in AES ECB encryption mode using Interrupt.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 bytes • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.20 HAL_CRYP_AESCBC_Encrypt_IT

Function Name	HAL_StatusTypeDef HAL_CRYP_AESCBC_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in AES CBC encryption mode using Interrupt.

Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 16 bytes pCypherData: Pointer to the ciphertext buffer
Return values	HAL status
10.3.21 HAL_CRYP_AESCTR_Encrypt_IT	
Function Name	HAL_StatusTypeDef HAL_CRYP_AESCTR_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in AES CTR encryption mode using Interrupt.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 16 bytes pCypherData: Pointer to the ciphertext buffer
Return values	HAL status
10.3.22 HAL_CRYP_AESECB_Decrypt_IT	
Function Name	HAL_StatusTypeDef HAL_CRYP_AESECB_Decrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES ECB decryption mode using Interrupt.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pCypherData: Pointer to the ciphertext buffer Size: Length of the plaintext buffer, must be a multiple of 16. pPlainData: Pointer to the plaintext buffer
Return values	HAL status
10.3.23 HAL_CRYP_AESCBC_Decrypt_IT	
Function Name	HAL_StatusTypeDef HAL_CRYP_AESCBC_Decrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES CBC decryption mode using IT.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pCypherData: Pointer to the ciphertext buffer Size: Length of the plaintext buffer, must be a multiple of 16 pPlainData: Pointer to the plaintext buffer

Return values	<ul style="list-style-type: none"> • HAL status
10.3.24 HAL_CRYP_AESCTR_Decrypt_IT	
Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESCTR_Decrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)</code>
Function Description	Initializes the CRYP peripheral in AES CTR decryption mode using Interrupt.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> • HAL status
10.3.25 HAL_CRYP_AESECB_Encrypt_DMA	
Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESECB_Encrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)</code>
Function Description	Initializes the CRYP peripheral in AES ECB encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 bytes • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status
10.3.26 HAL_CRYP_AESCBC_Encrypt_DMA	
Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESCBC_Encrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)</code>
Function Description	Initializes the CRYP peripheral in AES CBC encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status
10.3.27 HAL_CRYP_AESCTR_Encrypt_DMA	
Function Name	<code>HAL_StatusTypeDef HAL_CRYP_AESCTR_Encrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t</code>

Size, uint8_t * pCypherData)

Function Description	Initializes the CRYP peripheral in AES CTR encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16. • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.28 HAL_CRYP_AESECB_Decrypt_DMA

Function Name	HAL_StatusTypeDef HAL_CRYP_AESECB_Decrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES ECB decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 bytes • pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.29 HAL_CRYP_AESCBC_Decrypt_DMA

Function Name	HAL_StatusTypeDef HAL_CRYP_AESCBC_Decrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES CBC encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 bytes • pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.30 HAL_CRYP_AESCTR_Decrypt_DMA

Function Name	HAL_StatusTypeDef HAL_CRYP_AESCTR_Decrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES CTR decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module

- **pCypherData:** Pointer to the ciphertext buffer
- **Size:** Length of the plaintext buffer, must be a multiple of 16
- **pPlainData:** Pointer to the plaintext buffer
- HAL status

Return values

10.3.31 HAL_CRYP_DESECB_Encrypt

Function Name	HAL_StatusTypeDef HAL_CRYP_DESECB_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in DES ECB encryption mode.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.32 HAL_CRYP_DESECB_Decrypt

Function Name	HAL_StatusTypeDef HAL_CRYP_DESECB_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in DES ECB decryption mode.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.33 HAL_CRYP_DESCBC_Encrypt

Function Name	HAL_StatusTypeDef HAL_CRYP_DESCBC_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in DES CBC encryption mode.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.34 HAL_CRYP_DESCBC_Decrypt

Function Name	HAL_StatusTypeDef HAL_CRYP_DESCBC_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in DES ECB decryption mode.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 8 pCypherData: Pointer to the ciphertext buffer Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> HAL status
10.3.35 HAL_CRYP_DESECB_Encrypt_IT	
Function Name	HAL_StatusTypeDef HAL_CRYP_DESECB_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in DES ECB encryption mode using IT.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 8 pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> HAL status
10.3.36 HAL_CRYP_DESCBC_Encrypt_IT	
Function Name	HAL_StatusTypeDef HAL_CRYP_DESCBC_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in DES CBC encryption mode using interrupt.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 8 pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> HAL status
10.3.37 HAL_CRYP_DESECB_Decrypt_IT	
Function Name	HAL_StatusTypeDef HAL_CRYP_DESECB_Decrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in DES ECB decryption mode using IT.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that

- contains the configuration information for CRYP module
- **pPlainData:** Pointer to the plaintext buffer
 - **Size:** Length of the plaintext buffer, must be a multiple of 8
 - **pCypherData:** Pointer to the ciphertext buffer
- Return values**
- HAL status

10.3.38 HAL_CRYP_DESCBC_Decrypt_IT

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_DESCBC_Decrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)</code>
Function Description	Initializes the CRYP peripheral in DES ECB decryption mode using interrupt.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.39 HAL_CRYP_DESECB_Encrypt_DMA

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_DESECB_Encrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)</code>
Function Description	Initializes the CRYP peripheral in DES ECB encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.40 HAL_CRYP_DESCBC_Encrypt_DMA

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_DESCBC_Encrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)</code>
Function Description	Initializes the CRYP peripheral in DES CBC encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.41 HAL_CRYP_DESECB_Decrypt_DMA

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_DESECB_Decrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)</code>
Function Description	Initializes the CRYP peripheral in DES ECB decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.42 HAL_CRYP_DESCBC_Decrypt_DMA

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_DESCBC_Decrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)</code>
Function Description	Initializes the CRYP peripheral in DES ECB decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.43 HAL_CRYP_TDESECB_Encrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_TDESECB_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in TDES ECB encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

10.3.44 HAL_CRYP_TDESECB_Decrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_TDESECB_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in TDES ECB decryption mode

then decrypted pCypherData.

Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 8 pCypherData: Pointer to the ciphertext buffer Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> HAL status

10.3.45 HAL_CRYP_TDESCBC_Encrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_TDESCBC_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in TDES CBC encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 8 pCypherData: Pointer to the ciphertext buffer Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> HAL status

10.3.46 HAL_CRYP_TDESCBC_Decrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_TDESCBC_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in TDES CBC decryption mode then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pCypherData: Pointer to the ciphertext buffer Size: Length of the plaintext buffer, must be a multiple of 8 pPlainData: Pointer to the plaintext buffer Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> HAL status

10.3.47 HAL_CRYP_TDESECB_Encrypt_IT

Function Name	<code>HAL_StatusTypeDef HAL_CRYP_TDESECB_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)</code>
Function Description	Initializes the CRYP peripheral in TDES ECB encryption mode using interrupt.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer

- **Size:** Length of the plaintext buffer, must be a multiple of 8
- **pCypherData:** Pointer to the ciphertext buffer
- HAL status

Return values

10.3.48 HAL_CRYP_TDESCBC_Encrypt_IT

Function Name **HAL_StatusTypeDef HAL_CRYP_TDESCBC_Encrypt_IT
(CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t
Size, uint8_t * pCypherData)**

Function Description Initializes the CRYP peripheral in TDES CBC encryption mode.

- Parameters
- **hcryp:** pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
 - **pPlainData:** Pointer to the plaintext buffer
 - **Size:** Length of the plaintext buffer, must be a multiple of 8
 - **pCypherData:** Pointer to the ciphertext buffer

Return values

- HAL status

10.3.49 HAL_CRYP_TDESECB_Decrypt_IT

Function Name **HAL_StatusTypeDef HAL_CRYP_TDESECB_Decrypt_IT
(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData,
uint16_t Size, uint8_t * pPlainData)**

Function Description Initializes the CRYP peripheral in TDES ECB decryption mode.

- Parameters
- **hcryp:** pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
 - **pPlainData:** Pointer to the plaintext buffer
 - **Size:** Length of the plaintext buffer, must be a multiple of 8
 - **pCypherData:** Pointer to the ciphertext buffer

Return values

- HAL status

10.3.50 HAL_CRYP_TDESCBC_Decrypt_IT

Function Name **HAL_StatusTypeDef HAL_CRYP_TDESCBC_Decrypt_IT
(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData,
uint16_t Size, uint8_t * pPlainData)**

Function Description Initializes the CRYP peripheral in TDES CBC decryption mode.

- Parameters
- **hcryp:** pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
 - **pCypherData:** Pointer to the ciphertext buffer
 - **Size:** Length of the plaintext buffer, must be a multiple of 8
 - **pPlainData:** Pointer to the plaintext buffer

Return values

- HAL status

10.3.51 HAL_CRYP_TDESECB_Encrypt_DMA

Function Name **HAL_StatusTypeDef HAL_CRYP_TDESECB_Encrypt_DMA
(CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t
Size, uint8_t * pCypherData)**

Function Description	Initializes the CRYP peripheral in TDES ECB encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.52 HAL_CRYP_TDESCBC_Encrypt_DMA

Function Name	HAL_StatusTypeDef HAL_CRYP_TDESCBC_Encrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in TDES CBC encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.53 HAL_CRYP_TDESECB_Decrypt_DMA

Function Name	HAL_StatusTypeDef HAL_CRYP_TDESECB_Decrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in TDES ECB decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 8 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

10.3.54 HAL_CRYP_TDESCBC_Decrypt_DMA

Function Name	HAL_StatusTypeDef HAL_CRYP_TDESCBC_Decrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in TDES CBC decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 8

Return values	<ul style="list-style-type: none"> pPlainData: Pointer to the plaintext buffer HAL status
---------------	--

10.3.55 HAL_CRYP_InCpltCallback

Function Name	void HAL_CRYP_InCpltCallback (CRYP_HandleTypeDef * hcryp)
Function Description	Input FIFO transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> None

10.3.56 HAL_CRYP_OutCpltCallback

Function Name	void HAL_CRYP_OutCpltCallback (CRYP_HandleTypeDef * hcryp)
Function Description	Output FIFO transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> None

10.3.57 HAL_CRYP_ErrorCallback

Function Name	void HAL_CRYP_ErrorCallback (CRYP_HandleTypeDef * hcryp)
Function Description	CRYP error callbacks.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> None

10.3.58 HAL_CRYP_IRQHandler

Function Name	void HAL_CRYP_IRQHandler (CRYP_HandleTypeDef * hcryp)
Function Description	This function handles CRYP interrupt request.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none"> None

10.3.59 HAL_CRYP_GetState

Function Name	HAL_CRYP_STATETypeDef HAL_CRYP_GetState (CRYP_HandleTypeDef * hcryp)
Function Description	Returns the CRYP state.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module

10.4 CRYP Firmware driver defines

10.4.1 CRYP

CRYP Data Type

CRYP_DATATYPE_32B
CRYP_DATATYPE_16B
CRYP_DATATYPE_8B
CRYP_DATATYPE_1B

CRYP CRYP_AlgoModeDirection

CRYP_CR_ALGOMODE_DIRECTION
CRYP_CR_ALGOMODE_TDES_ECB_ENCRYPT
CRYP_CR_ALGOMODE_TDES_ECB_DECRYPT
CRYP_CR_ALGOMODE_TDES_CBC_ENCRYPT
CRYP_CR_ALGOMODE_TDES_CBC_DECRYPT
CRYP_CR_ALGOMODE DES_ECB_ENCRYPT
CRYP_CR_ALGOMODE DES_ECB_DECRYPT
CRYP_CR_ALGOMODE DES_CBC_ENCRYPT
CRYP_CR_ALGOMODE DES_CBC_DECRYPT
CRYP_CR_ALGOMODE AES_ECB_ENCRYPT
CRYP_CR_ALGOMODE AES_ECB_DECRYPT
CRYP_CR_ALGOMODE AES_CBC_ENCRYPT
CRYP_CR_ALGOMODE AES_CBC_DECRYPT
CRYP_CR_ALGOMODE AES_CTR_ENCRYPT
CRYP_CR_ALGOMODE AES_CTR_DECRYPT

CRYP CRYP Interrupt

CRYP_IT_INI Input FIFO Interrupt
CRYP_IT_OUTI Output FIFO Interrupt

CRYP CRYP Flags

CRYP_FLAG_BUSY	The CRYP core is currently processing a block of data or a key preparation (for AES decryption).
CRYP_FLAG_IFEM	Input FIFO is empty
CRYP_FLAG_IFNF	Input FIFO is not Full
CRYP_FLAG_OFNE	Output FIFO is not empty
CRYP_FLAG_OFFU	Output FIFO is Full
CRYP_FLAG_OUTRIS	Output FIFO service raw interrupt status

`CRYP_FLAG_INRIS` Input FIFO service raw interrupt status

CRYP Exported Macros

`_HAL_CRYP_RESET_HANDLE_STATE` **Description:**

- Reset CRYP handle state.

Parameters:

- `_HANDLE__`: specifies the CRYP handle.

Return value:

- None

`_HAL_CRYP_ENABLE`

Description:

- Enable/Disable the CRYP peripheral.

Parameters:

- `_HANDLE__`: specifies the CRYP handle.

Return value:

- None

`_HAL_CRYP_DISABLE`

`_HAL_CRYP_FIFO_FLUSH`

Description:

- Flush the data FIFO.

Parameters:

- `_HANDLE__`: specifies the CRYP handle.

Return value:

- None

`_HAL_CRYP_SET_MODE`

Description:

- Set the algorithm mode: AES-ECB, AES-CBC, AES-CTR, DES-ECB, DES-CBC.

Parameters:

- `_HANDLE__`: specifies the CRYP handle.
- MODE: The algorithm mode.

Return value:

- None

`_HAL_CRYP_GET_FLAG`

Description:

- Check whether the specified CRYP flag is set or not.

Parameters:

- `_HANDLE__`: specifies the CRYP handle.

- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - CRYP_FLAG_BUSY: The CRYP core is currently processing a block of data or a key preparation (for AES decryption).
 - CRYP_FLAG_IFEM: Input FIFO is empty
 - CRYP_FLAG_INNF: Input FIFO is not full
 - CRYP_FLAG_INRIS: Input FIFO service raw interrupt is pending
 - CRYP_FLAG_OFNE: Output FIFO is not empty
 - CRYP_FLAG_OFU: Output FIFO is full
 - CRYP_FLAG_OUTRIS: Input FIFO service raw interrupt is pending

Return value:

- The: new state of __FLAG__ (TRUE or FALSE).

[__HAL_CRYP_GET_IT](#)**Description:**

- Check whether the specified CRYP interrupt is set or not.

Parameters:

- __HANDLE__: specifies the CRYP handle.
- __INTERRUPT__: specifies the interrupt to check. This parameter can be one of the following values:
 - CRYP_IT_INRIS: Input FIFO service raw interrupt is pending
 - CRYP_IT_OUTRIS: Output FIFO service raw interrupt is pending

Return value:

- The: new state of __INTERRUPT__ (TRUE or FALSE).

[__HAL_CRYP_ENABLE_IT](#)**Description:**

- Enable the CRYP interrupt.

Parameters:

- __HANDLE__: specifies the CRYP handle.
- __INTERRUPT__: CRYP Interrupt.

Return value:

- None

[__HAL_CRYP_DISABLE_IT](#)**Description:**

- Disable the CRYP interrupt.

Parameters:

- [__HANDLE__](#): specifies the CRYP handle.
- [__INTERRUPT__](#): CRYP interrupt.

Return value:

- None

CRYP Key Size

[CRYP_KEYSIZE_128B](#)

[CRYP_KEYSIZE_192B](#)

[CRYP_KEYSIZE_256B](#)

CRYP Private Constants

[CRYP_FLAG_MASK](#)

CRYP_Private_define

[CRYP_TIMEOUT_VALUE](#)

CRYP Private Macros

[IS_CRYP_KEYSIZE](#)

[IS_CRYP_DATATYPE](#)

11 HAL CRYP Extension Driver

11.1 HAL CRYP Extension Driver

11.2 CRYPEx Firmware driver API description

11.2.1 How to use this driver

The CRYP Extension HAL driver can be used as follows:

1. Initialize the CRYP low level resources by implementing the HAL_CRYP_MspInit():
 - a. Enable the CRYP interface clock using __HAL_RCC_CRYP_CLK_ENABLE()
 - b. In case of using interrupts (e.g. HAL_CRYPEx_AESGCM_Encrypt_IT())
 - Configure the CRYP interrupt priority using HAL_NVIC_SetPriority()
 - Enable the CRYP IRQ handler using HAL_NVIC_EnableIRQ()
 - In CRYP IRQ handler, call HAL_CRYP_IRQHandler()
 - c. In case of using DMA to control data transfer (e.g. HAL_AES_ECB_Encrypt_DMA())
 - Enable the DMAx interface clock using __DMAx_CLK_ENABLE()
 - Configure and enable two DMA streams one for managing data transfer from memory to peripheral (input stream) and another stream for managing data transfer from peripheral to memory (output stream)
 - Associate the initialized DMA handle to the CRYP DMA handle using __HAL_LINKDMA()
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the two DMA Streams. The output stream should have higher priority than the input stream HAL_NVIC_SetPriority() and HAL_NVIC_EnableIRQ()
2. Initialize the CRYP HAL using HAL_CRYP_Init(). This function configures mainly:
 - a. The data type: 1-bit, 8-bit, 16-bit and 32-bit
 - b. The key size: 128, 192 and 256. This parameter is relevant only for AES
 - c. The encryption/decryption key. Its size depends on the algorithm used for encryption/decryption
 - d. The initialization vector (counter). It is not used ECB mode.
3. Three processing (encryption/decryption) functions are available:
 - a. Polling mode: encryption and decryption APIs are blocking functions i.e. they process the data and wait till the processing is finished e.g. HAL_CRYPEx_AESGCM_Encrypt()
 - b. Interrupt mode: encryption and decryption APIs are not blocking functions i.e. they process the data under interrupt e.g. HAL_CRYPEx_AESGCM_Encrypt_IT()
 - c. DMA mode: encryption and decryption APIs are not blocking functions i.e. the data transfer is ensured by DMA e.g. HAL_CRYPEx_AESGCM_Encrypt_DMA()
4. When the processing function is called at first time after HAL_CRYP_Init() the CRYP peripheral is initialized and processes the buffer in input. At second call, the processing function performs an append of the already processed buffer. When a new data block is to be processed, call HAL_CRYP_Init() then the processing function.
5. In AES-GCM and AES-CCM modes are an authenticated encryption algorithms which provide authentication messages. HAL_AES_GCM_Finish() and HAL_AES_CCM_Finish() are used to provide those authentication messages. Call those functions after the processing ones (polling, interrupt or DMA). e.g. in AES-CCM mode call HAL_CRYPEx_AESCCM_Encrypt() to encrypt the plain data then call HAL_CRYPEx_AESCCM_Finish() to get the authentication message. For CCM

- Encrypt/Decrypt API's, only DataType = 8-bit is supported by this version. The HAL_CRYPEX_AESGCM_xxxx() implementation is limited to 32bits inputs data length (Plain/Ciphertext, Header) compared with GCM standards specifications (800-38D).
6. Call HAL_CRYP_DeInit() to deinitialize the CRYP peripheral.

11.2.2 Extended AES processing functions

This section provides functions allowing to:

- Encrypt plaintext using AES-128/192/256 using GCM and CCM chaining modes
- Decrypt ciphertext using AES-128/192/256 using GCM and CCM chaining modes
- Finish the processing. This function is available only for GCM and CCM

Three processing methods are available:

- Polling mode
- Interrupt mode
- DMA mode

This section contains the following APIs:

- [`HAL_CRYPEX_AESCCM_Encrypt\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Encrypt\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Decrypt\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Finish\(\)`](#)
- [`HAL_CRYPEX_AESCCM_Finish\(\)`](#)
- [`HAL_CRYPEX_AESCCM_Decrypt\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Encrypt_IT\(\)`](#)
- [`HAL_CRYPEX_AESCCM_Encrypt_IT\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Decrypt_IT\(\)`](#)
- [`HAL_CRYPEX_AESCCM_Decrypt_IT\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Encrypt_DMA\(\)`](#)
- [`HAL_CRYPEX_AESCCM_Encrypt_DMA\(\)`](#)
- [`HAL_CRYPEX_AESGCM_Decrypt_DMA\(\)`](#)
- [`HAL_CRYPEX_AESCCM_Decrypt_DMA\(\)`](#)

11.2.3 CRYPEX IRQ handler management

This section provides CRYPEX IRQ handler function.

This section contains the following APIs:

- [`HAL_CRYPEX_GCMCCM_IRQHandler\(\)`](#)

11.2.4 HAL_CRYPEX_AESCCM_Encrypt

Function Name	<code>HAL_StatusTypeDef HAL_CRYPEX_AESCCM_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)</code>
Function Description	Initializes the CRYP peripheral in AES CCM encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pCypherData: Pointer to the ciphertext buffer • Timeout: Timeout duration

Return values	<ul style="list-style-type: none"> • HAL status
11.2.5 HAL_CRYPEx_AESGCM_Encrypt	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESGCM_Encrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in AES GCM encryption mode then encrypt pPlainData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pCypherData: Pointer to the ciphertext buffer • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
11.2.6 HAL_CRYPEx_AESGCM_Decrypt	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESGCM_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in AES GCM decryption mode then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the ciphertext buffer, must be a multiple of 16 • pPlainData: Pointer to the plaintext buffer • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
11.2.7 HAL_CRYPEx_AESGCM_Finish	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESGCM_Finish (CRYP_HandleTypeDef * hcryp, uint32_t Size, uint8_t * AuthTag, uint32_t Timeout)
Function Description	Computes the authentication TAG.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • Size: Total length of the plain/ciphertext buffer • AuthTag: Pointer to the authentication buffer • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
11.2.8 HAL_CRYPEx_AESCCM_Finish	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESCCM_Finish

(CRYP_HandleTypeDef * hcryp, uint8_t * AuthTag, uint32_t Timeout)

Function Description	Computes the authentication TAG for AES CCM mode.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • AuthTag: Pointer to the authentication buffer • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This API is called after HAL_AES_CCM_Encrypt() / HAL_AES_CCM_Decrypt()

11.2.9 HAL_CRYPEEx_AESCCM_Decrypt

Function Name	HAL_StatusTypeDef HAL_CRYPEEx_AESCCM_Decrypt (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData, uint32_t Timeout)
Function Description	Initializes the CRYP peripheral in AES CCM decryption mode then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pCypherData: Pointer to the ciphertext buffer • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

11.2.10 HAL_CRYPEEx_AESGCM_Encrypt_IT

Function Name	HAL_StatusTypeDef HAL_CRYPEEx_AESGCM_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in AES GCM encryption mode using IT.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status

11.2.11 HAL_CRYPEEx_AESCCM_Encrypt_IT

Function Name	HAL_StatusTypeDef HAL_CRYPEEx_AESCCM_Encrypt_IT (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in AES CCM encryption mode using interrupt.

Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 16 pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> HAL status

11.2.12 HAL_CRYPEEx_AESGCM_Decrypt_IT

Function Name	<code>HAL_StatusTypeDef HAL_CRYPEEx_AESGCM_Decrypt_IT(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)</code>
Function Description	Initializes the CRYP peripheral in AES GCM decryption mode using IT.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pCypherData: Pointer to the ciphertext buffer Size: Length of the ciphertext buffer, must be a multiple of 16 pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> HAL status

11.2.13 HAL_CRYPEEx_AESCCM_Decrypt_IT

Function Name	<code>HAL_StatusTypeDef HAL_CRYPEEx_AESCCM_Decrypt_IT(CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)</code>
Function Description	Initializes the CRYP peripheral in AES CCM decryption mode using interrupt then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pCypherData: Pointer to the ciphertext buffer Size: Length of the plaintext buffer, must be a multiple of 16 pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> HAL status

11.2.14 HAL_CRYPEEx_AESGCM_Encrypt_DMA

Function Name	<code>HAL_StatusTypeDef HAL_CRYPEEx_AESGCM_Encrypt_DMA(CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)</code>
Function Description	Initializes the CRYP peripheral in AES GCM encryption mode using DMA.
Parameters	<ul style="list-style-type: none"> hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module pPlainData: Pointer to the plaintext buffer Size: Length of the plaintext buffer, must be a multiple of 16 pCypherData: Pointer to the ciphertext buffer

Return values	<ul style="list-style-type: none"> • HAL status
11.2.15 HAL_CRYPEx_AESCCM_Encrypt_DMA	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESCCM_Encrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pPlainData, uint16_t Size, uint8_t * pCypherData)
Function Description	Initializes the CRYP peripheral in AES CCM encryption mode using interrupt.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pPlainData: Pointer to the plaintext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pCypherData: Pointer to the ciphertext buffer
Return values	<ul style="list-style-type: none"> • HAL status
11.2.16 HAL_CRYPEx_AESGCM_Decrypt_DMA	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESGCM_Decrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES GCM decryption mode using DMA.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer. • Size: Length of the ciphertext buffer, must be a multiple of 16 • pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> • HAL status
11.2.17 HAL_CRYPEx_AESCCM_Decrypt_DMA	
Function Name	HAL_StatusTypeDef HAL_CRYPEx_AESCCM_Decrypt_DMA (CRYP_HandleTypeDef * hcryp, uint8_t * pCypherData, uint16_t Size, uint8_t * pPlainData)
Function Description	Initializes the CRYP peripheral in AES CCM decryption mode using DMA then decrypted pCypherData.
Parameters	<ul style="list-style-type: none"> • hcryp: pointer to a CRYP_HandleTypeDef structure that contains the configuration information for CRYP module • pCypherData: Pointer to the ciphertext buffer • Size: Length of the plaintext buffer, must be a multiple of 16 • pPlainData: Pointer to the plaintext buffer
Return values	<ul style="list-style-type: none"> • HAL status
11.2.18 HAL_CRYPEx_GCMCCM_IRQHandler	
Function Name	void HAL_CRYPEx_GCMCCM_IRQHandler (CRYP_HandleTypeDef * hcryp)

Function Description	This function handles CRYPEEx interrupt request.
Parameters	<ul style="list-style-type: none">• hcryp: pointer to a CRYPEEx_HandleTypeDef structure that contains the configuration information for CRYP module
Return values	<ul style="list-style-type: none">• None

11.3 CRYPEEx Firmware driver defines

11.3.1 CRYPEEx

CRYP AlgoModeDirection

CRYP_CR_ALGOMODE_AES_GCM_ENCRYPT
CRYP_CR_ALGOMODE_AES_GCM_DECRYPT
CRYP_CR_ALGOMODE_AES_CCM_ENCRYPT
CRYP_CR_ALGOMODE_AES_CCM_DECRYPT

CRYP PhaseConfig

CRYP_PHASE_INIT
CRYP_PHASE_HEADER
CRYP_PHASE_PAYLOAD
CRYP_PHASE_FINAL

CRYP Exported Macros

__HAL_CRYP_SET_PHASE **Description:**

- Set the phase: Init, header, payload, final.

Parameters:

- __HANDLE__: specifies the CRYP handle.
- __PHASE__: The phase.

Return value:

- None

CRYPEEx_Private_define

CRYPEEx_TIMEOUT_VALUE

12 HAL DAC Generic Driver

12.1 HAL DAC Generic Driver

12.2 DAC Firmware driver registers structures

12.2.1 DAC_HandleTypeDef

Data Fields

- *DAC_TypeDef * Instance*
- *_IO HAL_DAC_StateTypeDef State*
- *HAL_LockTypeDef Lock*
- *DMA_HandleTypeDef * DMA_Handle1*
- *DMA_HandleTypeDef * DMA_Handle2*
- *_IO uint32_t ErrorCode*

Field Documentation

- ***DAC_TypeDef* DAC_HandleTypeDef::Instance***
Register base address
- ***_IO HAL_DAC_StateTypeDef DAC_HandleTypeDef::State***
DAC communication state
- ***HAL_LockTypeDef DAC_HandleTypeDef::Lock***
DAC locking object
- ***DMA_HandleTypeDef* DAC_HandleTypeDef::DMA_Handle1***
Pointer DMA handler for channel 1
- ***DMA_HandleTypeDef* DAC_HandleTypeDef::DMA_Handle2***
Pointer DMA handler for channel 2
- ***_IO uint32_t DAC_HandleTypeDef::ErrorCode***
DAC Error code

12.2.2 DAC_ChannelConfTypeDef

Data Fields

- *uint32_t DAC_Trigger*
- *uint32_t DAC_OutputBuffer*

Field Documentation

- ***uint32_t DAC_ChannelConfTypeDef::DAC_Trigger***
Specifies the external trigger for the selected DAC channel. This parameter can be a value of [DAC_trigger_selection](#)
- ***uint32_t DAC_ChannelConfTypeDef::DAC_OutputBuffer***
Specifies whether the DAC channel output buffer is enabled or disabled. This parameter can be a value of [DAC_output_buffer](#)

12.3 DAC Firmware driver API description

12.3.1 DAC Peripheral features

DAC Channels

The device integrates two 12-bit Digital Analog Converters that can be used independently or simultaneously (dual mode):

1. DAC channel1 with DAC_OUT1 (PA4) as output
2. DAC channel2 with DAC_OUT2 (PA5) as output

DAC Triggers

Digital to Analog conversion can be non-triggered using DAC_TRIGGER_NONE and DAC_OUT1/DAC_OUT2 is available once writing to DHRx register.

Digital to Analog conversion can be triggered by:

1. External event: EXTI Line 9 (any GPIOx_Pin9) using DAC_TRIGGER_EXT_IT9. The used pin (GPIOx_Pin9) must be configured in input mode.
2. Timers TRGO: TIM2, TIM4, TIM5, TIM6, TIM7 and TIM8 (DAC_TRIGGER_T2_TRGO, DAC_TRIGGER_T4_TRGO...)
3. Software using DAC_TRIGGER_SOFTWARE

DAC Buffer mode feature

Each DAC channel integrates an output buffer that can be used to reduce the output impedance, and to drive external loads directly without having to add an external operational amplifier. To enable, the output buffer use sConfig.DAC_OutputBuffer = DAC_OUTPUTBUFFER_ENABLE;



Refer to the device datasheet for more details about output impedance value with and without output buffer.

DAC wave generation feature

Both DAC channels can be used to generate

1. Noise wave
2. Triangle wave

DAC data format

The DAC data format can be:

1. 8-bit right alignment using DAC_ALIGN_8B_R
2. 12-bit left alignment using DAC_ALIGN_12B_L
3. 12-bit right alignment using DAC_ALIGN_12B_R

DAC data value to voltage correspondence

The analog output voltage on each DAC channel pin is determined by the following equation: $DAC_OUTx = VREF+ * DOR / 4095$ with DOR is the Data Output Register VEF+ is the input voltage reference (refer to the device datasheet) e.g. To set DAC_OUT1 to 0.7V, use Assuming that $VREF+ = 3.3V$, $DAC_OUT1 = (3.3 * 868) / 4095 = 0.7V$

DMA requests

A DMA1 request can be generated when an external trigger (but not a software trigger) occurs if DMA1 requests are enabled using HAL_DAC_Start_DMA()

DMA1 requests are mapped as following:

1. DAC channel1 : mapped on DMA1 Stream5 channel7 which must be already configured
2. DAC channel2 : mapped on DMA1 Stream6 channel7 which must be already configured For Dual mode and specific signal (Triangle and noise) generation please refer to Extension Features Driver description

12.3.2 How to use this driver

- DAC APB clock must be enabled to get write access to DAC registers using HAL_DAC_Init()
- Configure DAC_OUTx (DAC_OUT1: PA4, DAC_OUT2: PA5) in analog mode.
- Configure the DAC channel using HAL_DAC_ConfigChannel() function.
- Enable the DAC channel using HAL_DAC_Start() or HAL_DAC_Start_DMA functions

Polling mode IO operation

- Start the DAC peripheral using HAL_DAC_Start()
- To read the DAC last data output value, use the HAL_DAC_GetValue() function.
- Stop the DAC peripheral using HAL_DAC_Stop()

DMA mode IO operation

- Start the DAC peripheral using HAL_DAC_Start_DMA(), at this stage the user specify the length of data to be transferred at each end of conversion
- At The end of data transfer HAL_DAC_ConvCpltCallbackCh1() or HAL_DAC_ConvCpltCallbackCh2() function is executed and user can add his own code by customization of function pointer HAL_DAC_ConvCpltCallbackCh1 or HAL_DAC_ConvCpltCallbackCh2
- In case of transfer Error, HAL_DAC_ErrorCallbackCh1() function is executed and user can add his own code by customization of function pointer HAL_DAC_ErrorCallbackCh1
- Stop the DAC peripheral using HAL_DAC_Stop_DMA()

DAC HAL driver macros list

Below the list of most used macros in DAC HAL driver.

- __HAL_DAC_ENABLE : Enable the DAC peripheral
- __HAL_DAC_DISABLE : Disable the DAC peripheral
- __HAL_DAC_CLEAR_FLAG: Clear the DAC's pending flags

- `_HAL_DAC_GET_FLAG`: Get the selected DAC's flag status



You can refer to the DAC HAL driver header file for more useful macros

12.3.3 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize and configure the DAC.
- De-initialize the DAC.

This section contains the following APIs:

- `HAL_DAC_Init()`
- `HAL_DAC_DeInit()`
- `HAL_DAC_MspInit()`
- `HAL_DAC_MspDeInit()`

12.3.4 IO operation functions

This section provides functions allowing to:

- Start conversion.
- Stop conversion.
- Start conversion and enable DMA transfer.
- Stop conversion and disable DMA transfer.
- Get result of conversion.

This section contains the following APIs:

- `HAL_DAC_Start()`
- `HAL_DAC_Stop()`
- `HAL_DAC_Start_DMA()`
- `HAL_DAC_Stop_DMA()`
- `HAL_DAC_GetValue()`
- `HAL_DAC_IRQHandler()`
- `HAL_DAC_ConvCpltCallbackCh1()`
- `HAL_DAC_ConvHalfCpltCallbackCh1()`
- `HAL_DAC_ErrorCallbackCh1()`
- `HAL_DAC_DMAUnderrunCallbackCh1()`

12.3.5 Peripheral Control functions

This section provides functions allowing to:

- Configure channels.
- Set the specified data holding register value for DAC channel.

This section contains the following APIs:

- `HAL_DAC_ConfigChannel()`
- `HAL_DAC_SetValue()`

12.3.6 Peripheral State and Errors functions

This subsection provides functions allowing to

- Check the DAC state.
- Check the DAC Errors.

This section contains the following APIs:

- `HAL_DAC_GetState()`
- `HAL_DAC_GetError()`
- `HAL_DAC_IRQHandler()`
- `HAL_DAC_ConvCpltCallbackCh1()`
- `HAL_DAC_ConvHalfCpltCallbackCh1()`
- `HAL_DAC_ErrorCallbackCh1()`
- `HAL_DAC_DMAUnderrunCallbackCh1()`

12.3.7 HAL_DAC_Init

Function Name	<code>HAL_StatusTypeDef HAL_DAC_Init (DAC_HandleTypeDef * hdac)</code>
Function Description	Initializes the DAC peripheral according to the specified parameters in the DAC_InitStruct.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • HAL status

12.3.8 HAL_DAC_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_DAC_DeInit (DAC_HandleTypeDef * hdac)</code>
Function Description	Deinitializes the DAC peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • HAL status

12.3.9 HAL_DAC_MspInit

Function Name	<code>void HAL_DAC_MspInit (DAC_HandleTypeDef * hdac)</code>
Function Description	Initializes the DAC MSP.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.10 HAL_DAC_MspDeInit

Function Name	<code>void HAL_DAC_MspDeInit (DAC_HandleTypeDef * hdac)</code>
Function Description	Deinitializes the DAC MSP.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.11 HAL_DAC_Start

Function Name	HAL_StatusTypeDef HAL_DAC_Start (DAC_HandleTypeDef *hdac, uint32_t Channel)
Function Description	Enables DAC and starts conversion of channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2 selected
Return values	<ul style="list-style-type: none"> • HAL status

12.3.12 HAL_DAC_Stop

Function Name	HAL_StatusTypeDef HAL_DAC_Stop (DAC_HandleTypeDef *hdac, uint32_t Channel)
Function Description	Disables DAC and stop conversion of channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2 selected
Return values	<ul style="list-style-type: none"> • HAL status

12.3.13 HAL_DAC_Start_DMA

Function Name	HAL_StatusTypeDef HAL_DAC_Start_DMA (DAC_HandleTypeDef *hdac, uint32_t Channel, uint32_t *pData, uint32_t Length, uint32_t Alignment)
Function Description	Enables DAC and starts conversion of channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2 selected • pData: The destination peripheral Buffer address. • Length: The length of data to be transferred from memory to DAC peripheral • Alignment: Specifies the data alignment for DAC channel. This parameter can be one of the following values: DAC_ALIGN_8B_R: 8bit right data alignment selectedDAC_ALIGN_12B_L: 12bit left data alignment selectedDAC_ALIGN_12B_R: 12bit right data alignment selected
Return values	<ul style="list-style-type: none"> • HAL status

12.3.14 HAL_DAC_Stop_DMA



Function Name	HAL_StatusTypeDef HAL_DAC_Stop_DMA (DAC_HandleTypeDef * hdac, uint32_t Channel)
Function Description	Disables DAC and stop conversion of channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2 selected
Return values	<ul style="list-style-type: none"> • HAL status

12.3.15 HAL_DAC_GetValue

Function Name	uint32_t HAL_DAC_GetValue (DAC_HandleTypeDef * hdac, uint32_t Channel)
Function Description	Returns the last data output value of the selected DAC channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2 selected
Return values	<ul style="list-style-type: none"> • The selected DAC channel data output value.

12.3.16 HAL_DAC_IRQHandler

Function Name	void HAL_DAC_IRQHandler (DAC_HandleTypeDef * hdac)
Function Description	Handles DAC interrupt request.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.17 HAL_DAC_ConvCpltCallbackCh1

Function Name	void HAL_DAC_ConvCpltCallbackCh1 (DAC_HandleTypeDef * hdac)
Function Description	Conversion complete callback in non blocking mode for Channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.18 HAL_DAC_ConvHalfCpltCallbackCh1

Function Name	void HAL_DAC_ConvHalfCpltCallbackCh1 (DAC_HandleTypeDef * hdac)
Function Description	Conversion half DMA transfer callback in non blocking mode for Channel1.

Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.19 HAL_DAC_ErrorCallbackCh1

Function Name	<code>void HAL_DAC_ErrorCallbackCh1 (DAC_HandleTypeDef * hdac)</code>
Function Description	Error DAC callback for Channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.20 HAL_DAC_DMADebugCallbackCh1

Function Name	<code>void HAL_DAC_DMADebugCallbackCh1 (DAC_HandleTypeDef * hdac)</code>
Function Description	DMA debug DAC callback for channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.21 HAL_DAC_ConfigChannel

Function Name	<code>HAL_StatusTypeDef HAL_DAC_ConfigChannel (DAC_HandleTypeDef * hdac, DAC_ChannelConfTypeDef * sConfig, uint32_t Channel)</code>
Function Description	Configures the selected DAC channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • sConfig: DAC configuration structure. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2 selected
Return values	<ul style="list-style-type: none"> • HAL status

12.3.22 HAL_DAC_SetValue

Function Name	<code>HAL_StatusTypeDef HAL_DAC_SetValue (DAC_HandleTypeDef * hdac, uint32_t Channel, uint32_t Alignment, uint32_t Data)</code>
Function Description	Set the specified data holding register value for DAC channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1: DAC Channel1 selectedDAC_CHANNEL_2: DAC Channel2

- selected
 - **Alignment:** Specifies the data alignment. This parameter can be one of the following values: DAC_ALIGN_8B_R: 8bit right data alignment selectedDAC_ALIGN_12B_L: 12bit left data alignment selectedDAC_ALIGN_12B_R: 12bit right data alignment selected
 - **Data:** Data to be loaded in the selected data holding register.
- Return values**
- HAL status

12.3.23 HAL_DAC_GetState

Function Name	HAL_DAC_StateTypeDef HAL_DAC_GetState (DAC_HandleTypeDef * hdac)
Function Description	return the DAC state
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • HAL state

12.3.24 HAL_DAC_GetError

Function Name	uint32_t HAL_DAC_GetError (DAC_HandleTypeDef * hdac)
Function Description	Return the DAC error code.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • DAC Error Code

12.3.25 HAL_DAC_IRQHandler

Function Name	void HAL_DAC_IRQHandler (DAC_HandleTypeDef * hdac)
Function Description	Handles DAC interrupt request.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.26 HAL_DAC_ConvCpltCallbackCh1

Function Name	void HAL_DAC_ConvCpltCallbackCh1 (DAC_HandleTypeDef * hdac)
Function Description	Conversion complete callback in non blocking mode for Channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.27 HAL_DAC_ConvHalfCpltCallbackCh1

Function Name	void HAL_DAC_ConvHalfCpltCallbackCh1 (DAC_HandleTypeDef * hdac)
---------------	--

Function Description	Conversion half DMA transfer callback in non blocking mode for Channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.28 HAL_DAC_ErrorCallbackCh1

Function Name	void HAL_DAC_ErrorCallbackCh1 (DAC_HandleTypeDef * hdac)
Function Description	Error DAC callback for Channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.3.29 HAL_DAC_DMAUnderrunCallbackCh1

Function Name	void HAL_DAC_DMAUnderrunCallbackCh1 (DAC_HandleTypeDef * hdac)
Function Description	DMA underrun DAC callback for channel1.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

12.4 DAC Firmware driver defines

12.4.1 DAC

DAC Channel Selection

DAC_CHANNEL_1

DAC_CHANNEL_2

DAC Data Alignment

DAC_ALIGN_12B_R

DAC_ALIGN_12B_L

DAC_ALIGN_8B_R

DAC Error Code

HAL_DAC_ERROR_NONE No error

HAL_DAC_ERROR_DMAUNDERUNCH1 DAC channel1 DAM underrun error

HAL_DAC_ERROR_DMAUNDERUNCH2 DAC channel2 DAM underrun error

HAL_DAC_ERROR_DMA DMA error

DAC Exported Macros

__HAL_DAC_RESET_HANDLE_STATE **Description:**

- Reset DAC handle state.

Parameters:

- `__HANDLE__`: specifies the DAC handle.

Return value:

- None

`__HAL_DAC_ENABLE`**Description:**

- Enable the DAC channel.

Parameters:

- `__HANDLE__`: specifies the DAC handle.
- `__DAC_Channel__`: specifies the DAC channel

Return value:

- None

`__HAL_DAC_DISABLE`**Description:**

- Disable the DAC channel.

Parameters:

- `__HANDLE__`: specifies the DAC handle
- `__DAC_Channel__`: specifies the DAC channel.

Return value:

- None

`__HAL_DAC_ENABLE_IT`**Description:**

- Enable the DAC interrupt.

Parameters:

- `__HANDLE__`: specifies the DAC handle
- `__INTERRUPT__`: specifies the DAC interrupt.

Return value:

- None

`__HAL_DAC_DISABLE_IT`**Description:**

- Disable the DAC interrupt.

Parameters:

- `__HANDLE__`: specifies the DAC handle
- `__INTERRUPT__`: specifies the DAC interrupt.

Return value:

- None

`__HAL_DAC_GET_IT_SOURCE`**Description:**

- Checks if the specified DAC interrupt

source is enabled or disabled.

Parameters:

- `__HANDLE__`: DAC handle
- `__INTERRUPT__`: DAC interrupt source to check This parameter can be any combination of the following values:
 - `DAC_IT_DMAUDR1`: DAC channel 1 DMA underrun interrupt
 - `DAC_IT_DMAUDR2`: DAC channel 2 DMA underrun interrupt

Return value:

- State: of interruption (SET or RESET)

Description:

- Get the selected DAC's flag status.

Parameters:

- `__HANDLE__`: specifies the DAC handle.
- `__FLAG__`: specifies the flag to clear. This parameter can be any combination of the following values:
 - `DAC_FLAG_DMAUDR1`: DMA underrun 1 flag
 - `DAC_FLAG_DMAUDR2`: DMA underrun 2 flag

Return value:

- None

`__HAL_DAC_CLEAR_FLAG`

Description:

- Clear the DAC's flag.

Parameters:

- `__HANDLE__`: specifies the DAC handle.
- `__FLAG__`: specifies the flag to clear. This parameter can be any combination of the following values:
 - `DAC_FLAG_DMAUDR1`: DMA underrun 1 flag
 - `DAC_FLAG_DMAUDR2`: DMA underrun 2 flag

Return value:

- None

DAC Flags Definition

`DAC_FLAG_DMAUDR1`

`DAC_FLAG_DMAUDR2`

DAC IT Definition

`DAC_IT_DMAUDR1`

DAC_IT_DMAUDR2

DAC Output Buffer

DAC_OUTPUTBUFFER_ENABLE

DAC_OUTPUTBUFFER_DISABLE

DAC Private Macros

IS_DAC_DATA

IS_DAC_ALIGN

IS_DAC_CHANNEL

IS_DAC_OUTPUT_BUFFER_STATE

IS_DAC_TRIGGER

DAC_DHR12R1_ALIGNMENT

Description:

- Set DHR12R1 alignment.

Parameters:

- ALIGNMENT: specifies the DAC alignment

Return value:

- None

DAC_DHR12R2_ALIGNMENT

Description:

- Set DHR12R2 alignment.

Parameters:

- ALIGNMENT: specifies the DAC alignment

Return value:

- None

DAC_DHR12RD_ALIGNMENT

Description:

- Set DHR12RD alignment.

Parameters:

- ALIGNMENT: specifies the DAC alignment

Return value:

- None

DAC Trigger Selection

DAC_TRIGGER_NONE

Conversion is automatic once the DAC1_DHRxxxx register has been loaded, and not by external trigger

DAC_TRIGGER_T2_TRGO

TIM2 TRGO selected as external conversion trigger for DAC channel

DAC_TRIGGER_T4_TRGO

TIM4 TRGO selected as external conversion trigger for DAC channel

DAC_TRIGGER_T5_TRGO	TIM5 TRGO selected as external conversion trigger for DAC channel
DAC_TRIGGER_T6_TRGO	TIM6 TRGO selected as external conversion trigger for DAC channel
DAC_TRIGGER_T7_TRGO	TIM7 TRGO selected as external conversion trigger for DAC channel
DAC_TRIGGER_T8_TRGO	TIM8 TRGO selected as external conversion trigger for DAC channel
DAC_TRIGGER_EXT_IT9	EXTI Line9 event selected as external conversion trigger for DAC channel
DAC_TRIGGER_SOFTWARE	Conversion started by software trigger for DAC channel

13 HAL DAC Extension Driver

13.1 HAL DAC Extension Driver

13.2 DACEx Firmware driver API description

13.2.1 How to use this driver

- When Dual mode is enabled (i.e DAC Channel1 and Channel2 are used simultaneously) : Use HAL_DACEx_DualGetValue() to get digital data to be converted and use HAL_DACEx_DualSetValue() to set digital value to converted simultaneously in Channel 1 and Channel 2.
- Use HAL_DACEx_TriangleWaveGenerate() to generate Triangle signal.
- Use HAL_DACEx_NoiseWaveGenerate() to generate Noise signal.

13.2.2 Extended features functions

This section provides functions allowing to:

- Start conversion.
- Stop conversion.
- Start conversion and enable DMA transfer.
- Stop conversion and disable DMA transfer.
- Get result of conversion.
- Get result of dual mode conversion.

This section contains the following APIs:

- [*HAL_DACEx_DualGetValue\(\)*](#)
- [*HAL_DACEx_TriangleWaveGenerate\(\)*](#)
- [*HAL_DACEx_NoiseWaveGenerate\(\)*](#)
- [*HAL_DACEx_DualSetValue\(\)*](#)
- [*HAL_DACEx_ConvCpltCallbackCh2\(\)*](#)
- [*HAL_DACEx_ConvHalfCpltCallbackCh2\(\)*](#)
- [*HAL_DACEx_ErrorCallbackCh2\(\)*](#)
- [*HAL_DACEx_DMAUnderrunCallbackCh2\(\)*](#)

13.2.3 HAL_DACEx_DualGetValue

Function Name `uint32_t HAL_DACEx_DualGetValue (DAC_HandleTypeDef * hdac)`

Function Description Returns the last data output value of the selected DAC channel.

Parameters

- **hdac:** pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.

Return values

- The selected DAC channel data output value.

13.2.4 HAL_DACEx_TriangleWaveGenerate

Function Name `HAL_StatusTypeDef HAL_DACEx_TriangleWaveGenerate (DAC_HandleTypeDef * hdac, uint32_t Channel, uint32_t`

Amplitude)	
Function Description	Enables or disables the selected DAC channel wave generation.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1 / DAC_CHANNEL_2 • Amplitude: Select max triangle amplitude. This parameter can be one of the following values: DAC_TRIANGLEAMPLITUDE_1: Select max triangle amplitude of 1DAC_TRIANGLEAMPLITUDE_3: Select max triangle amplitude of 3DAC_TRIANGLEAMPLITUDE_7: Select max triangle amplitude of 7DAC_TRIANGLEAMPLITUDE_15: Select max triangle amplitude of 15DAC_TRIANGLEAMPLITUDE_31: Select max triangle amplitude of 31DAC_TRIANGLEAMPLITUDE_63: Select max triangle amplitude of 63DAC_TRIANGLEAMPLITUDE_127: Select max triangle amplitude of 127DAC_TRIANGLEAMPLITUDE_255: Select max triangle amplitude of 255DAC_TRIANGLEAMPLITUDE_511: Select max triangle amplitude of 511DAC_TRIANGLEAMPLITUDE_1023: Select max triangle amplitude of 1023DAC_TRIANGLEAMPLITUDE_2047: Select max triangle amplitude of 2047DAC_TRIANGLEAMPLITUDE_4095: Select max triangle amplitude of 4095
Return values	<ul style="list-style-type: none"> • HAL status

13.2.5 HAL_DACEx_NoiseWaveGenerate

Function Name	HAL_StatusTypeDef HAL_DACEx_NoiseWaveGenerate (DAC_HandleTypeDef * hdac, uint32_t Channel, uint32_t Amplitude)
Function Description	Enables or disables the selected DAC channel wave generation.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Channel: The selected DAC channel. This parameter can be one of the following values: DAC_CHANNEL_1 / DAC_CHANNEL_2 • Amplitude: Unmask DAC channel LFSR for noise wave generation. This parameter can be one of the following values: DAC_LFSRUNMASK_BIT0: Unmask DAC channel LFSR bit0 for noise wave generationDAC_LFSRUNMASK_BITS1_0: Unmask DAC channel LFSR bit[1:0] for noise wave generationDAC_LFSRUNMASK_BITS2_0: Unmask DAC channel LFSR bit[2:0] for noise wave generationDAC_LFSRUNMASK_BITS3_0: Unmask DAC channel LFSR bit[3:0] for noise wave generationDAC_LFSRUNMASK_BITS4_0: Unmask DAC channel LFSR bit[4:0] for noise wave generationDAC_LFSRUNMASK_BITS5_0: Unmask DAC

channel LFSR bit[5:0] for noise wave
 generationDAC_LFSRUNMASK_BITS6_0: Unmask DAC channel LFSR bit[6:0] for noise wave
 generationDAC_LFSRUNMASK_BITS7_0: Unmask DAC channel LFSR bit[7:0] for noise wave
 generationDAC_LFSRUNMASK_BITS8_0: Unmask DAC channel LFSR bit[8:0] for noise wave
 generationDAC_LFSRUNMASK_BITS9_0: Unmask DAC channel LFSR bit[9:0] for noise wave
 generationDAC_LFSRUNMASK_BITS10_0: Unmask DAC channel LFSR bit[10:0] for noise wave
 generationDAC_LFSRUNMASK_BITS11_0: Unmask DAC channel LFSR bit[11:0] for noise wave generation

- Return values
- HAL status

13.2.6 HAL_DACEx_DualSetValue

Function Name	HAL_StatusTypeDef HAL_DACEx_DualSetValue (DAC_HandleTypeDef * hdac, uint32_t Alignment, uint32_t Data1, uint32_t Data2)
Function Description	Set the specified data holding register value for dual DAC channel.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC. • Alignment: Specifies the data alignment for dual channel DAC. This parameter can be one of the following values: DAC_ALIGN_8B_R: 8bit right data alignment selected DAC_ALIGN_12B_L: 12bit left data alignment selected DAC_ALIGN_12B_R: 12bit right data alignment selected • Data1: Data for DAC Channel2 to be loaded in the selected data holding register. • Data2: Data for DAC Channel1 to be loaded in the selected data holding register.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	In dual mode, a unique register access is required to write in both DAC channels at the same time.

13.2.7 HAL_DACEx_ConvCpltCallbackCh2

Function Name	void HAL_DACEx_ConvCpltCallbackCh2 (DAC_HandleTypeDef * hdac)
Function Description	Conversion complete callback in non blocking mode for Channel2.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

13.2.8 HAL_DACEx_ConvHalfCpltCallbackCh2

Function Name	void HAL_DACEx_ConvHalfCpltCallbackCh2 (DAC_HandleTypeDef * hdac)
---------------	--

Function Description	Conversion half DMA transfer callback in non blocking mode for Channel2.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

13.2.9 HAL_DACEx_ErrorCallbackCh2

Function Name	void HAL_DACEx_ErrorCallbackCh2 (DAC_HandleTypeDef * hdac)
Function Description	Error DAC callback for Channel2.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

13.2.10 HAL_DACEx_DMAUnderrunCallbackCh2

Function Name	void HAL_DACEx_DMAUnderrunCallbackCh2 (DAC_HandleTypeDef * hdac)
Function Description	DMA underrun DAC callback for channel2.
Parameters	<ul style="list-style-type: none"> • hdac: pointer to a DAC_HandleTypeDef structure that contains the configuration information for the specified DAC.
Return values	<ul style="list-style-type: none"> • None

13.3 DACEx Firmware driver defines

13.3.1 DACEx

DAC LFS Run Mask Triangle Amplitude

DAC_LFSRUNMASK_BIT0	Unmask DAC channel LFSR bit0 for noise wave generation
DAC_LFSRUNMASK_BITS1_0	Unmask DAC channel LFSR bit[1:0] for noise wave generation
DAC_LFSRUNMASK_BITS2_0	Unmask DAC channel LFSR bit[2:0] for noise wave generation
DAC_LFSRUNMASK_BITS3_0	Unmask DAC channel LFSR bit[3:0] for noise wave generation
DAC_LFSRUNMASK_BITS4_0	Unmask DAC channel LFSR bit[4:0] for noise wave generation
DAC_LFSRUNMASK_BITS5_0	Unmask DAC channel LFSR bit[5:0] for noise wave generation
DAC_LFSRUNMASK_BITS6_0	Unmask DAC channel LFSR bit[6:0] for noise wave generation
DAC_LFSRUNMASK_BITS7_0	Unmask DAC channel LFSR bit[7:0] for noise wave generation

DAC_LFSRUNMASK_BITS8_0	Unmask DAC channel LFSR bit[8:0] for noise wave generation
DAC_LFSRUNMASK_BITS9_0	Unmask DAC channel LFSR bit[9:0] for noise wave generation
DAC_LFSRUNMASK_BITS10_0	Unmask DAC channel LFSR bit[10:0] for noise wave generation
DAC_LFSRUNMASK_BITS11_0	Unmask DAC channel LFSR bit[11:0] for noise wave generation
DAC_TRIANGLEAMPLITUDE_1	Select max triangle amplitude of 1
DAC_TRIANGLEAMPLITUDE_3	Select max triangle amplitude of 3
DAC_TRIANGLEAMPLITUDE_7	Select max triangle amplitude of 7
DAC_TRIANGLEAMPLITUDE_15	Select max triangle amplitude of 15
DAC_TRIANGLEAMPLITUDE_31	Select max triangle amplitude of 31
DAC_TRIANGLEAMPLITUDE_63	Select max triangle amplitude of 63
DAC_TRIANGLEAMPLITUDE_127	Select max triangle amplitude of 127
DAC_TRIANGLEAMPLITUDE_255	Select max triangle amplitude of 255
DAC_TRIANGLEAMPLITUDE_511	Select max triangle amplitude of 511
DAC_TRIANGLEAMPLITUDE_1023	Select max triangle amplitude of 1023
DAC_TRIANGLEAMPLITUDE_2047	Select max triangle amplitude of 2047
DAC_TRIANGLEAMPLITUDE_4095	Select max triangle amplitude of 4095

DAC Private Macros

IS_DAC_LFSR_UNMASK_TRIANGLE_AMPLITUDE

14 HAL DCMI Generic Driver

14.1 HAL DCMI Generic Driver

14.2 DCMI Firmware driver registers structures

14.2.1 DCMI_HandleTypeDef

Data Fields

- *DCMI_TypeDef * Instance*
- *DCMI_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_DCMI_StateTypeDef State*
- *__IO uint32_t XferCount*
- *__IO uint32_t XferSize*
- *uint32_t XferTransferNumber*
- *uint32_t pBuffPtr*
- *DMA_HandleTypeDef * DMA_Handle*
- *__IO uint32_t ErrorCode*

Field Documentation

- ***DCMI_TypeDef* DCMI_HandleTypeDef::Instance***
DCMI Register base address
- ***DCMI_InitTypeDef DCMI_HandleTypeDef::Init***
DCMI parameters
- ***HAL_LockTypeDef DCMI_HandleTypeDef::Lock***
DCMI locking object
- ***__IO HAL_DCMI_StateTypeDef DCMI_HandleTypeDef::State***
DCMI state
- ***__IO uint32_t DCMI_HandleTypeDef::XferCount***
DMA transfer counter
- ***__IO uint32_t DCMI_HandleTypeDef::XferSize***
DMA transfer size
- ***uint32_t DCMI_HandleTypeDef::XferTransferNumber***
DMA transfer number
- ***uint32_t DCMI_HandleTypeDef::pBuffPtr***
Pointer to DMA output buffer
- ***DMA_HandleTypeDef* DCMI_HandleTypeDef::DMA_Handle***
Pointer to the DMA handler
- ***__IO uint32_t DCMI_HandleTypeDef::ErrorCode***
DCMI Error code

14.3 DCMI Firmware driver API description

14.3.1 How to use this driver

The sequence below describes how to use this driver to capture image from a camera module connected to the DCMI Interface. This sequence does not take into account the configuration of the camera module, which should be made before to configure and enable the DCMI to capture images.

1. Program the required configuration through following parameters: horizontal and vertical polarity, pixel clock polarity, Capture Rate, Synchronization Mode, code of the frame delimiter and data width using HAL_DCMI_Init() function.
2. Configure the DMA2_Stream1 channel1 to transfer Data from DCMI DR register to the destination memory buffer.
3. Program the required configuration through following parameters: DCMI mode, destination memory Buffer address and the data length and enable capture using HAL_DCMI_Start_DMA() function.
4. Optionally, configure and Enable the CROP feature to select a rectangular window from the received image using HAL_DCMI_ConfigCrop() and HAL_DCMI_EnableCROP() functions
5. The capture can be stopped using HAL_DCMI_Stop() function.
6. To control DCMI state you can use the function HAL_DCMI_GetState().

DCMI HAL driver macros list

Below the list of most used macros in DCMI HAL driver.

- `_HAL_DCMI_ENABLE`: Enable the DCMI peripheral.
- `_HAL_DCMI_DISABLE`: Disable the DCMI peripheral.
- `_HAL_DCMI_GET_FLAG`: Get the DCMI pending flags.
- `_HAL_DCMI_CLEAR_FLAG`: Clear the DCMI pending flags.
- `_HAL_DCMI_ENABLE_IT`: Enable the specified DCMI interrupts.
- `_HAL_DCMI_DISABLE_IT`: Disable the specified DCMI interrupts.
- `_HAL_DCMI_GET_IT_SOURCE`: Check whether the specified DCMI interrupt has occurred or not.



You can refer to the DCMI HAL driver header file for more useful macros

14.3.2 Initialization and Configuration functions

This section provides functions allowing to:

- Initialize and configure the DCMI
- De-initialize the DCMI

This section contains the following APIs:

- `HAL_DCMI_Init\(\)`
- `HAL_DCMI_DeInit\(\)`
- `HAL_DCMI_MspInit\(\)`
- `HAL_DCMI_MspDeInit\(\)`

14.3.3 IO operation functions

This section provides functions allowing to:

- Configure destination address and data length and Enables DCMI DMA request and enables DCMI capture
- Stop the DCMI capture.
- Handles DCMI interrupt request.

This section contains the following APIs:

- [*HAL_DCMI_Start_DMA\(\)*](#)
- [*HAL_DCMI_Stop\(\)*](#)
- [*HAL_DCMI_IRQHandler\(\)*](#)
- [*HAL_DCMI_ErrorCallback\(\)*](#)
- [*HAL_DCMI_LineEventCallback\(\)*](#)
- [*HAL_DCMI_VsyncEventCallback\(\)*](#)
- [*HAL_DCMI_FrameEventCallback\(\)*](#)

14.3.4 Peripheral Control functions

This section provides functions allowing to:

- Configure the CROP feature.
- Enable/Disable the CROP feature.

This section contains the following APIs:

- [*HAL_DCMI_ConfigCROP\(\)*](#)
- [*HAL_DCMI_DisableCROP\(\)*](#)
- [*HAL_DCMI_EnableCROP\(\)*](#)

14.3.5 Peripheral State and Errors functions

This subsection provides functions allowing to

- Check the DCMI state.
- Get the specific DCMI error flag.

This section contains the following APIs:

- [*HAL_DCMI_GetState\(\)*](#)
- [*HAL_DCMI_GetError\(\)*](#)

14.3.6 HAL_DCMI_Init

Function Name	<code>HAL_StatusTypeDef HAL_DCMI_Init (DCMI_HandleTypeDef *hdcmi)</code>
Function Description	Initializes the DCMI according to the specified parameters in the <code>DCMI_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a <code>DCMI_HandleTypeDef</code> structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL status

14.3.7 HAL_DCMI_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_DCMI_DelInit (DCMI_HandleTypeDef *hdcmi)</code>
Function Description	Deinitializes the DCMI peripheral registers to their default reset values.

Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL status

14.3.8 HAL_DCMI_MspInit

Function Name	void HAL_DCMI_MspInit (DCMI_HandleTypeDef * hdcmi)
Function Description	Initializes the DCMI MSP.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • None

14.3.9 HAL_DCMI_MspDeInit

Function Name	void HAL_DCMI_MspDeInit (DCMI_HandleTypeDef * hdcmi)
Function Description	Deinitializes the DCMI MSP.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • None

14.3.10 HAL_DCMI_Start_DMA

Function Name	HAL_StatusTypeDef HAL_DCMI_Start_DMA (DCMI_HandleTypeDef * hdcmi, uint32_t DCMI_Mode, uint32_t pData, uint32_t Length)
Function Description	Enables DCMI DMA request and enables DCMI capture.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI. • DCMI_Mode: DCMI capture mode snapshot or continuous grab. • pData: The destination memory Buffer address (LCD Frame buffer). • Length: The length of capture to be transferred.
Return values	<ul style="list-style-type: none"> • HAL status

14.3.11 HAL_DCMI_Stop

Function Name	HAL_StatusTypeDef HAL_DCMI_Stop (DCMI_HandleTypeDef * hdcmi)
Function Description	Disable DCMI DMA request and Disable DCMI capture.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL status

14.3.12 HAL_DCMI_IRQHandler

Function Name	void HAL_DCMI_IRQHandler (DCMI_HandleTypeDef * hdcmi)
---------------	--

Function Description	Handles DCMI interrupt request.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for the DCMI.
Return values	<ul style="list-style-type: none"> • None

14.3.13 HAL_DCMI_ErrorCallback

Function Name	void HAL_DCMI_ErrorCallback (DCMI_HandleTypeDef * hdcmi)
Function Description	Error DCMI callback.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.

Return values	<ul style="list-style-type: none"> • None
---------------	--

14.3.14 HAL_DCMI_LineEventCallback

Function Name	void HAL_DCMI_LineEventCallback (DCMI_HandleTypeDef * hdcmi)
Function Description	Line Event callback.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.

Return values	<ul style="list-style-type: none"> • None
---------------	--

14.3.15 HAL_DCMI_VsyncEventCallback

Function Name	void HAL_DCMI_VsyncEventCallback (DCMI_HandleTypeDef * hdcmi)
Function Description	VSYNC Event callback.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.

Return values	<ul style="list-style-type: none"> • None
---------------	--

14.3.16 HAL_DCMI_FrameEventCallback

Function Name	void HAL_DCMI_FrameEventCallback (DCMI_HandleTypeDef * hdcmi)
Function Description	Frame Event callback.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.

Return values	<ul style="list-style-type: none"> • None
---------------	--

14.3.17 HAL_DCMI_ConfigCROP

Function Name	HAL_StatusTypeDef HAL_DCMI_ConfigCROP (DCMI_HandleTypeDef * hdcmi, uint32_t X0, uint32_t Y0, uint32_t XSize, uint32_t YSize)
---------------	---

Function Description	Configure the DCMI CROP coordinate.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI. • X0: DCMI window X offset • Y0: DCMI window Y offset • XSize: DCMI Pixel per line • YSize: DCMI Line number
Return values	<ul style="list-style-type: none"> • HAL status

14.3.18 HAL_DCMI_DisableCROP

Function Name	HAL_StatusTypeDef HAL_DCMI_DisableCROP (DCMI_HandleTypeDef * hdcmi)
Function Description	Disable the Crop feature.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL status

14.3.19 HAL_DCMI_EnableCROP

Function Name	HAL_StatusTypeDef HAL_DCMI_EnableCROP (DCMI_HandleTypeDef * hdcmi)
Function Description	Enable the Crop feature.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL status

14.3.20 HAL_DCMI_GetState

Function Name	HAL_DCMI_StateTypeDef HAL_DCMI_GetState (DCMI_HandleTypeDef * hdcmi)
Function Description	Return the DCMI state.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL state

14.3.21 HAL_DCMI_GetError

Function Name	uint32_t HAL_DCMI_GetError (DCMI_HandleTypeDef * hdcmi)
Function Description	Return the DCMI error code.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • DCMI Error Code

14.4 DCMI Firmware driver defines

14.4.1 DCMI

DCMI Capture Mode

`DCMI_MODE_CONTINUOUS` The received data are transferred continuously into the destination memory through the DMA

`DCMI_MODE_SNAPSHOT` Once activated, the interface waits for the start of frame and then transfers a single frame through the DMA

DCMI Capture Rate

`DCMI_CR_ALL_FRAME` All frames are captured

`DCMI_CR_ALTERNATE_2_FRAME` Every alternate frame captured

`DCMI_CR_ALTERNATE_4_FRAME` One frame in 4 frames captured

DCMI Error Code

`HAL_DCMI_ERROR_NONE` No error

`HAL_DCMI_ERROR_OVF` Overflow error

`HAL_DCMI_ERROR_SYNC` Synchronization error

`HAL_DCMI_ERROR_TIMEOUT` Timeout error

DCMI Exported Macros

`_HAL_DCMI_RESET_HANDLE_STATE` **Description:**

- Reset DCMI handle state.

Parameters:

- `_HANDLE_`: specifies the DCMI handle.

Return value:

- None

`_HAL_DCMI_ENABLE`

Description:

- Enable the DCMI.

Parameters:

- `_HANDLE_`: DCMI handle

Return value:

- None

`_HAL_DCMI_DISABLE`

Description:

- Disable the DCMI.

Parameters:

- `_HANDLE_`: DCMI handle

Return value:

- None

[__HAL_DCMI_GET_FLAG](#)**Description:**

- Get the DCMI pending flags.

Parameters:

- [__HANDLE__](#): DCMI handle
- [__FLAG__](#): Get the specified flag. This parameter can be any combination of the following values:
 - DCMI_FLAG_FRAMERI: Frame capture complete flag mask
 - DCMI_FLAG_OVFRI: Overflow flag mask
 - DCMI_FLAG_ERRRI: Synchronization error flag mask
 - DCMI_FLAG_VSYNCRI: VSYNC flag mask
 - DCMI_FLAG_LINERI: Line flag mask

Return value:

- The state of FLAG.

[__HAL_DCMI_CLEAR_FLAG](#)**Description:**

- Clear the DCMI pending flags.

Parameters:

- [__HANDLE__](#): DCMI handle
- [__FLAG__](#): specifies the flag to clear. This parameter can be any combination of the following values:
 - DCMI_FLAG_FRAMERI: Frame capture complete flag mask
 - DCMI_FLAG_OVFRI: Overflow flag mask
 - DCMI_FLAG_ERRRI: Synchronization error flag mask
 - DCMI_FLAG_VSYNCRI: VSYNC flag mask
 - DCMI_FLAG_LINERI: Line flag mask

Return value:

- None

[__HAL_DCMI_ENABLE_IT](#)**Description:**

- Enable the specified DCMI interrupts.

Parameters:

- [__HANDLE__](#): DCMI handle
- [__INTERRUPT__](#): specifies the DCMI interrupt sources to be enabled. This parameter can be any combination of the following values:
 - DCMI_IT_FRAME: Frame capture complete interrupt mask

- DCMI_IT_OVF: Overflow interrupt mask
- DCMI_IT_ERR: Synchronization error interrupt mask
- DCMI_IT_VSYNC: VSYNC interrupt mask
- DCMI_IT_LINE: Line interrupt mask

Return value:

- None

_HAL_DCMI_DISABLE_IT

- Disable the specified DCMI interrupts.

Parameters:

- _HANDLE_: DCMI handle
- _INTERRUPT_: specifies the DCMI interrupt sources to be enabled. This parameter can be any combination of the following values:
 - DCMI_IT_FRAME: Frame capture complete interrupt mask
 - DCMI_IT_OVF: Overflow interrupt mask
 - DCMI_IT_ERR: Synchronization error interrupt mask
 - DCMI_IT_VSYNC: VSYNC interrupt mask
 - DCMI_IT_LINE: Line interrupt mask

Return value:

- None

_HAL_DCMI_GET_IT_SOURCE

- Check whether the specified DCMI interrupt has occurred or not.

Parameters:

- _HANDLE_: DCMI handle
- _INTERRUPT_: specifies the DCMI interrupt source to check. This parameter can be one of the following values:
 - DCMI_IT_FRAME: Frame capture complete interrupt mask
 - DCMI_IT_OVF: Overflow interrupt mask
 - DCMI_IT_ERR: Synchronization error interrupt mask
 - DCMI_IT_VSYNC: VSYNC interrupt mask
 - DCMI_IT_LINE: Line interrupt mask

Return value:

- The: state of INTERRUPT.

DCMI Extended Data Mode

DCMI_EXTEND_DATA_8B	Interface captures 8-bit data on every pixel clock
DCMI_EXTEND_DATA_10B	Interface captures 10-bit data on every pixel clock
DCMI_EXTEND_DATA_12B	Interface captures 12-bit data on every pixel clock
DCMI_EXTEND_DATA_14B	Interface captures 14-bit data on every pixel clock

DCMI Flags

DCMI_FLAG_HSYNC
DCMI_FLAG_VSYNC
DCMI_FLAG_FNE
DCMI_FLAG_FRAMERI
DCMI_FLAG_OVFRI
DCMI_FLAG_ERRRI
DCMI_FLAG_VSYNCRI
DCMI_FLAG_LINERI
DCMI_FLAG_FRAMEMI
DCMI_FLAG_OVFM
DCMI_FLAG_ERRM
DCMI_FLAG_VSYNCMI
DCMI_FLAG_LINEMI

DCMI HSYNC Polarity

DCMI_HSPOLARITY_LOW	Horizontal synchronization active Low
DCMI_HSPOLARITY_HIGH	Horizontal synchronization active High

DCMI interrupt sources

DCMI_IT_FRAME
DCMI_IT_OVF
DCMI_IT_ERR
DCMI_IT_VSYNC
DCMI_IT_LINE

DCMI MODE JPEG

DCMI_JPEG_DISABLE	Mode JPEG Disabled
DCMI_JPEG_ENABLE	Mode JPEG Enabled

DCMI PIXCK Polarity

DCMI_PCKPOLARITY_FALLING	Pixel clock active on Falling edge
DCMI_PCKPOLARITY_RISING	Pixel clock active on Rising edge

DCMI Private Macros

IS_DCMI_CAPTURE_MODE
IS_DCMI_SYNCHRO
IS_DCMI_PCKPOLARITY
IS_DCMI_VSPOLARITY
IS_DCMI_HSPOLARITY
IS_DCMI_MODE_JPEG
IS_DCMI_CAPTURE_RATE
IS_DCMI_EXTENDED_DATA
IS_DCMI_WINDOW_COORDINATE
IS_DCMI_WINDOW_HEIGHT

DCMI Synchronization Mode

DCMI_SYNCHRO_HARDWARE	Hardware synchronization data capture (frame/line start/stop) is synchronized with the HSYNC/VSYNC signals
DCMI_SYNCHRO_EMBEDDED	Embedded synchronization data capture is synchronized with synchronization codes embedded in the data flow

DCMI VSYNC Polarity

DCMI_VSPOLARITY_LOW	Vertical synchronization active Low
DCMI_VSPOLARITY_HIGH	Vertical synchronization active High

DCMI Window Coordinate

DCMI_WINDOW_COORDINATE	Window coordinate
------------------------	-------------------

DCMI Window Height

DCMI_WINDOW_HEIGHT	Window Height
--------------------	---------------

15 HAL DCMI Extension Driver

15.1 HAL DCMI Extension Driver

15.2 DCMIEx Firmware driver registers structures

15.2.1 DCMI_CodesInitTypeDef

Data Fields

- *uint8_t FrameStartCode*
- *uint8_t LineStartCode*
- *uint8_t LineEndCode*
- *uint8_t FrameEndCode*

Field Documentation

- ***uint8_t DCMI_CodesInitTypeDef::FrameStartCode***
Specifies the code of the frame start delimiter.
- ***uint8_t DCMI_CodesInitTypeDef::LineStartCode***
Specifies the code of the line start delimiter.
- ***uint8_t DCMI_CodesInitTypeDef::LineEndCode***
Specifies the code of the line end delimiter.
- ***uint8_t DCMI_CodesInitTypeDef::FrameEndCode***
Specifies the code of the frame end delimiter.

15.2.2 DCMI_InitTypeDef

Data Fields

- *uint32_t SynchroMode*
- *uint32_t PCKPolarity*
- *uint32_t VSPolarity*
- *uint32_t HSPolarity*
- *uint32_t CaptureRate*
- *uint32_t ExtendedDataMode*
- *DCMI_CodesInitTypeDef SyncroCode*
- *uint32_t JPEGMode*
- *uint32_t ByteSelectMode*
- *uint32_t ByteSelectStart*
- *uint32_t LineSelectMode*
- *uint32_t LineSelectStart*

Field Documentation

- **`uint32_t DCMI_InitTypeDef::SynchroMode`**
Specifies the Synchronization Mode: Hardware or Embedded. This parameter can be a value of `DCMI_Synchronization_Mode`
- **`uint32_t DCMI_InitTypeDef::PCKPolarity`**
Specifies the Pixel clock polarity: Falling or Rising. This parameter can be a value of `DCMI_PIXCK_Polarity`
- **`uint32_t DCMI_InitTypeDef::VSPolarity`**
Specifies the Vertical synchronization polarity: High or Low. This parameter can be a value of `DCMI_VSYNC_Polarity`
- **`uint32_t DCMI_InitTypeDef::HSPolarity`**
Specifies the Horizontal synchronization polarity: High or Low. This parameter can be a value of `DCMI_HSYNC_Polarity`
- **`uint32_t DCMI_InitTypeDef::CaptureRate`**
Specifies the frequency of frame capture: All, 1/2 or 1/4. This parameter can be a value of `DCMI_Capture_Rate`
- **`uint32_t DCMI_InitTypeDef::ExtendedDataMode`**
Specifies the data width: 8-bit, 10-bit, 12-bit or 14-bit. This parameter can be a value of `DCMI_Extended_Data_Mode`
- **`DCMI_CodesInitTypeDef DCMI_InitTypeDef::SyncroCode`**
Specifies the code of the frame start delimiter.
- **`uint32_t DCMI_InitTypeDef::JPEGMode`**
Enable or Disable the JPEG mode. This parameter can be a value of `DCMI_MODE_JPEG`
- **`uint32_t DCMI_InitTypeDef::ByteSelectMode`**
Specifies the data to be captured by the interface This parameter can be a value of `DCMIE_Ex_Byte_Select_Mode`
- **`uint32_t DCMI_InitTypeDef::ByteSelectStart`**
Specifies if the data to be captured by the interface is even or odd This parameter can be a value of `DCMIE_Ex_Byte_Select_Start`
- **`uint32_t DCMI_InitTypeDef::LineSelectMode`**
Specifies the line of data to be captured by the interface This parameter can be a value of `DCMIE_Ex_Line_Select_Mode`
- **`uint32_t DCMI_InitTypeDef::LineSelectStart`**
Specifies if the line of data to be captured by the interface is even or odd This parameter can be a value of `DCMIE_Ex_Line_Select_Start`

15.3 DCMIEx Firmware driver API description

15.3.1 DCMI peripheral extension features

Comparing to other previous devices, the DCMI interface for STM32F446xx devices contains the following additional features :

- Support of Black and White cameras

15.3.2 How to use this driver

This driver provides functions to manage the Black and White feature

15.3.3 Initialization and Configuration functions

This section provides functions allowing to:

- Initialize and configure the DCMI
- De-initialize the DCMI

This section contains the following APIs:

- ***HAL_DCMI_Init()***

15.3.4 **HAL_DCMI_Init**

Function Name	HAL_StatusTypeDef HAL_DCMI_Init (DCMI_HandleTypeDef *hdcmi)
Function Description	Initializes the DCMI according to the specified parameters in the DCMI_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hdcmi: pointer to a DCMI_HandleTypeDef structure that contains the configuration information for DCMI.
Return values	<ul style="list-style-type: none"> • HAL status

15.4 DCMIEx Firmware driver defines

15.4.1 DCMIEx

DCMI Byte Select Mode

DCMI_BSM_ALL	Interface captures all received data
DCMI_BSM_OTHER	Interface captures every other byte from the received data
DCMI_BSM_ALTERNATE_4	Interface captures one byte out of four
DCMI_BSM_ALTERNATE_2	Interface captures two bytes out of four

DCMI Byte Select Start

DCMI_OEBS_ODD	Interface captures first data from the frame/line start, second one being dropped
DCMI_OEBS_EVEN	Interface captures second data from the frame/line start, first one being dropped

DCMI Line Select Mode

DCMI_LSM_ALL	Interface captures all received lines
DCMI_LSM_ALTERNATE_2	Interface captures one line out of two

DCMI Line Select Start

DCMI_OELS_ODD	Interface captures first line from the frame start, second one being dropped
DCMI_OELS_EVEN	Interface captures second line from the frame start, first one being dropped

DCMI Extended Private Macros

IS_DCMI_BYTE_SELECT_MODE	
IS_DCMI_BYTE_SELECT_START	
IS_DCMI_LINE_SELECT_MODE	
IS_DCMI_LINE_SELECT_START	

16 HAL DMA2D Generic Driver

16.1 HAL DMA2D Generic Driver

16.2 DMA2D Firmware driver registers structures

16.2.1 DMA2D_ColorTypeDef

Data Fields

- *uint32_t Blue*
- *uint32_t Green*
- *uint32_t Red*

Field Documentation

- ***uint32_t DMA2D_ColorTypeDef::Blue***
Configures the blue value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint32_t DMA2D_ColorTypeDef::Green***
Configures the green value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint32_t DMA2D_ColorTypeDef::Red***
Configures the red value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.

16.2.2 DMA2D_CLUTCfgTypeDef

Data Fields

- *uint32_t * pCLUT*
- *uint32_t CLUTColorMode*
- *uint32_t Size*

Field Documentation

- ***uint32_t* DMA2D_CLUTCfgTypeDef::pCLUT***
Configures the DMA2D CLUT memory address.
- ***uint32_t DMA2D_CLUTCfgTypeDef::CLUTColorMode***
configures the DMA2D CLUT color mode. This parameter can be one value of **DMA2D_CLUT_CM**
- ***uint32_t DMA2D_CLUTCfgTypeDef::Size***
configures the DMA2D CLUT size. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.

16.2.3 DMA2D_InitTypeDef

Data Fields

- *uint32_t Mode*
- *uint32_t ColorMode*
- *uint32_t OutputOffset*

Field Documentation

- ***uint32_t DMA2D_InitTypeDef::Mode***
configures the DMA2D transfer mode. This parameter can be one value of **DMA2D_Mode**
- ***uint32_t DMA2D_InitTypeDef::ColorMode***
configures the color format of the output image. This parameter can be one value of **DMA2D_Color_Mode**
- ***uint32_t DMA2D_InitTypeDef::OutputOffset***
Specifies the Offset value. This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0x3FFF.

16.2.4 DMA2D_LayerCfgTypeDef

Data Fields

- *uint32_t InputOffset*
- *uint32_t InputColorMode*
- *uint32_t AlphaMode*
- *uint32_t InputAlpha*

Field Documentation

- ***uint32_t DMA2D_LayerCfgTypeDef::InputOffset***
configures the DMA2D foreground offset. This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0x3FFF.
- ***uint32_t DMA2D_LayerCfgTypeDef::InputColorMode***
configures the DMA2D foreground color mode . This parameter can be one value of **DMA2D_Input_Color_Mode**
- ***uint32_t DMA2D_LayerCfgTypeDef::AlphaMode***
configures the DMA2D foreground alpha mode. This parameter can be one value of **DMA2D_ALPHA_MODE**
- ***uint32_t DMA2D_LayerCfgTypeDef::InputAlpha***
Specifies the DMA2D foreground alpha value and color value in case of A8 or A4 color mode. This parameter must be a number between Min_Data = 0x00000000 and Max_Data = 0xFFFFFFFF in case of A8 or A4 color mode (ARGB). Otherwise, This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.

16.2.5 __DMA2D_HandleTypeDef

Data Fields

- *DMA2D_TypeDef * Instance*
- *DMA2D_InitTypeDef Init*
- *void(* XferCpltCallback*
- *void(* XferErrorCallback*
- *DMA2D_LayerCfgTypeDef LayerCfg*
- *HAL_LockTypeDef Lock*
- *__IO HAL_DMA2D_StateTypeDef State*
- *__IO uint32_t ErrorCode*

Field Documentation

- ***DMA2D_TypeDef* __DMA2D_HandleTypeDef::Instance***
DMA2D Register base address
- ***DMA2D_InitTypeDef __DMA2D_HandleTypeDef::Init***
DMA2D communication parameters
- ***void(* __DMA2D_HandleTypeDef::XferCpltCallback)(struct __DMA2D_HandleTypeDef *hdma2d)***
DMA2D transfer complete callback
- ***void(* __DMA2D_HandleTypeDef::XferErrorCallback)(struct __DMA2D_HandleTypeDef *hdma2d)***
DMA2D transfer error callback
- ***DMA2D_LayerCfgTypeDef __DMA2D_HandleTypeDef::LayerCfg[MAX_DMA2D_LAYER]***
DMA2D Layers parameters
- ***HAL_LockTypeDef __DMA2D_HandleTypeDef::Lock***
DMA2D Lock
- ***__IO HAL_DMA2D_StateTypeDef __DMA2D_HandleTypeDef::State***
DMA2D transfer state
- ***__IO uint32_t __DMA2D_HandleTypeDef::ErrorCode***
DMA2D Error code

16.3 DMA2D Firmware driver API description

16.3.1 How to use this driver

1. Program the required configuration through following parameters: the Transfer Mode, the output color mode and the output offset using HAL_DMA2D_Init() function.
2. Program the required configuration through following parameters: the input color mode, the input color, input alpha value, alpha mode and the input offset using HAL_DMA2D_ConfigLayer() function for foreground or/and background layer.

Polling mode IO operation

- Configure the pdata, Destination and data length and Enable the transfer using HAL_DMA2D_Start()
- Wait for end of transfer using HAL_DMA2D_PollForTransfer(), at this stage user can specify the value of timeout according to his end application.

Interrupt mode IO operation

1. Configure the pdata, Destination and data length and Enable the transfer using HAL_DMA2D_Start_IT()
2. Use HAL_DMA2D_IRQHandler() called under DMA2D_IRQHandler() Interrupt subroutine
3. At the end of data transfer HAL_DMA2D_IRQHandler() function is executed and user can add his own function by customization of function pointer XferCpltCallback and XferErrorCallback (i.e a member of DMA2D handle structure). In Register-to-Memory transfer mode, the pdata parameter is the register color, in Memory-to-memory or memory-to-memory with pixel format conversion the pdata is the source address. Configure the foreground source address, the background source address, the Destination and data length and Enable the transfer using HAL_DMA2D_BlendingStart() in polling mode and HAL_DMA2D_BlendingStart_IT() in interrupt mode. HAL_DMA2D_BlendingStart() and HAL_DMA2D_BlendingStart_IT() functions are used if the memory to memory with blending transfer mode is selected.
4. Optionally, configure and enable the CLUT using HAL_DMA2D_ConfigCLUT() HAL_DMA2D_EnableCLUT() functions.
5. Optionally, configure and enable LineInterrupt using the following function: HAL_DMA2D_ProgramLineEvent().
6. The transfer can be suspended, continued and aborted using the following functions: HAL_DMA2D_Suspend(), HAL_DMA2D_Resume(), HAL_DMA2D_Abort().
7. To control DMA2D state you can use the following function: HAL_DMA2D_GetState()

DMA2D HAL driver macros list

Below the list of most used macros in DMA2D HAL driver :

- __HAL_DMA2D_ENABLE: Enable the DMA2D peripheral.
- __HAL_DMA2D_DISABLE: Disable the DMA2D peripheral.
- __HAL_DMA2D_GET_FLAG: Get the DMA2D pending flags.
- __HAL_DMA2D_CLEAR_FLAG: Clear the DMA2D pending flags.
- __HAL_DMA2D_ENABLE_IT: Enable the specified DMA2D interrupts.
- __HAL_DMA2D_DISABLE_IT: Disable the specified DMA2D interrupts.
- __HAL_DMA2D_GET_IT_SOURCE: Check whether the specified DMA2D interrupt has occurred or not.



You can refer to the DMA2D HAL driver header file for more useful macros

16.3.2 Initialization and Configuration functions

This section provides functions allowing to:

- Initialize and configure the DMA2D
- De-initialize the DMA2D

This section contains the following APIs:

- [**HAL_DMA2D_Init\(\)**](#)
- [**HAL_DMA2D_DelInit\(\)**](#)
- [**HAL_DMA2D_MspInit\(\)**](#)
- [**HAL_DMA2D_MspDelInit\(\)**](#)

16.3.3 IO operation functions

This section provides functions allowing to:

- Configure the pdata, destination address and data size and Start DMA2D transfer.
- Configure the source for foreground and background, destination address and data size and Start MultiBuffer DMA2D transfer.
- Configure the pdata, destination address and data size and Start DMA2D transfer with interrupt.
- Configure the source for foreground and background, destination address and data size and Start MultiBuffer DMA2D transfer with interrupt.
- Abort DMA2D transfer.
- Suspend DMA2D transfer.
- Continue DMA2D transfer.
- Poll for transfer complete.
- handle DMA2D interrupt request.

This section contains the following APIs:

- [*HAL_DMA2D_Start\(\)*](#)
- [*HAL_DMA2D_Start_IT\(\)*](#)
- [*HAL_DMA2D_BlendingStart\(\)*](#)
- [*HAL_DMA2D_BlendingStart_IT\(\)*](#)
- [*HAL_DMA2D_Abort\(\)*](#)
- [*HAL_DMA2D_Suspend\(\)*](#)
- [*HAL_DMA2D_Resume\(\)*](#)
- [*HAL_DMA2D_PollForTransfer\(\)*](#)
- [*HAL_DMA2D_IRQHandler\(\)*](#)

16.3.4 Peripheral Control functions

This section provides functions allowing to:

- Configure the DMA2D foreground or/and background parameters.
- Configure the DMA2D CLUT transfer.
- Enable DMA2D CLUT.
- Disable DMA2D CLUT.
- Configure the line watermark

This section contains the following APIs:

- [*HAL_DMA2D_ConfigLayer\(\)*](#)
- [*HAL_DMA2D_ConfigCLUT\(\)*](#)
- [*HAL_DMA2D_EnableCLUT\(\)*](#)
- [*HAL_DMA2D_DisableCLUT\(\)*](#)
- [*HAL_DMA2D_ProgramLineEvent\(\)*](#)

16.3.5 Peripheral State and Errors functions

This subsection provides functions allowing to :

- Check the DMA2D state
- Get error code

This section contains the following APIs:

- [*HAL_DMA2D_GetState\(\)*](#)
- [*HAL_DMA2D_GetError\(\)*](#)

16.3.6 HAL_DMA2D_Init

Function Name	HAL_StatusTypeDef HAL_DMA2D_Init (DMA2D_HandleTypeDef * hdma2d)
Function Description	Initializes the DMA2D according to the specified parameters in the DMA2D_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.7 HAL_DMA2D_DeInit

Function Name	HAL_StatusTypeDef HAL_DMA2D_DeInit (DMA2D_HandleTypeDef * hdma2d)
Function Description	Deinitializes the DMA2D peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • None

16.3.8 HAL_DMA2D_MspInit

Function Name	void HAL_DMA2D_MspInit (DMA2D_HandleTypeDef * hdma2d)
Function Description	Initializes the DMA2D MSP.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • None

16.3.9 HAL_DMA2D_MspDeInit

Function Name	void HAL_DMA2D_MspDeInit (DMA2D_HandleTypeDef * hdma2d)
Function Description	Deinitializes the DMA2D MSP.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • None

16.3.10 HAL_DMA2D_Start

Function Name	HAL_StatusTypeDef HAL_DMA2D_Start (DMA2D_HandleTypeDef * hdma2d, uint32_t pdata, uint32_t DstAddress, uint32_t Width, uint32_t Height)
Function Description	Start the DMA2D Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • pdata: Configure the source memory Buffer address if the

memory to memory or memory to memory with pixel format conversion DMA2D mode is selected, and configure the color value if register to memory DMA2D mode is selected.

- **DstAddress:** The destination memory Buffer address.
- **Width:** The width of data to be transferred from source to destination.
- **Height:** The height of data to be transferred from source to destination.

Return values

- HAL status

16.3.11 HAL_DMA2D_Start_IT

Function Name	<code>HAL_StatusTypeDef HAL_DMA2D_Start_IT (DMA2D_HandleTypeDef * hdma2d, uint32_t pdata, uint32_t DstAddress, uint32_t Width, uint32_t Height)</code>
Function Description	Start the DMA2D Transfer with interrupt enabled.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • pdata: Configure the source memory Buffer address if the memory to memory or memory to memory with pixel format conversion DMA2D mode is selected, and configure the color value if register to memory DMA2D mode is selected. • DstAddress: The destination memory Buffer address. • Width: The width of data to be transferred from source to destination. • Height: The height of data to be transferred from source to destination.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.12 HAL_DMA2D_BlendingStart

Function Name	<code>HAL_StatusTypeDef HAL_DMA2D_BlendingStart (DMA2D_HandleTypeDef * hdma2d, uint32_t SrcAddress1, uint32_t SrcAddress2, uint32_t DstAddress, uint32_t Width, uint32_t Height)</code>
Function Description	Start the multi-source DMA2D Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • SrcAddress1: The source memory Buffer address of the foreground layer. • SrcAddress2: The source memory Buffer address of the background layer. • DstAddress: The destination memory Buffer address • Width: The width of data to be transferred from source to destination. • Height: The height of data to be transferred from source to destination.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.13 HAL_DMA2D_BlendingStart_IT

Function Name	HAL_StatusTypeDef HAL_DMA2D_BlendingStart_IT (DMA2D_HandleTypeDef * hdma2d, uint32_t SrcAddress1, uint32_t SrcAddress2, uint32_t DstAddress, uint32_t Width, uint32_t Height)
Function Description	Start the multi-source DMA2D Transfer with interrupt enabled.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • SrcAddress1: The source memory Buffer address of the foreground layer. • SrcAddress2: The source memory Buffer address of the background layer. • DstAddress: The destination memory Buffer address. • Width: The width of data to be transferred from source to destination. • Height: The height of data to be transferred from source to destination.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.14 HAL_DMA2D_Abort

Function Name	HAL_StatusTypeDef HAL_DMA2D_Abort (DMA2D_HandleTypeDef * hdma2d)
Function Description	Abort the DMA2D Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: : pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.15 HAL_DMA2D_Suspend

Function Name	HAL_StatusTypeDef HAL_DMA2D_Suspend (DMA2D_HandleTypeDef * hdma2d)
Function Description	Suspend the DMA2D Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.16 HAL_DMA2D_Resume

Function Name	HAL_StatusTypeDef HAL_DMA2D_Resume (DMA2D_HandleTypeDef * hdma2d)
Function Description	Resume the DMA2D Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.17 HAL_DMA2D_PollForTransfer

Function Name	HAL_StatusTypeDef HAL_DMA2D_PollForTransfer
---------------	--

(DMA2D_HandleTypeDef * hdma2d, uint32_t Timeout)

Function Description	Polling for transfer complete or CLUT loading.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

16.3.18 HAL_DMA2D_IRQHandler

Function Name	void HAL_DMA2D_IRQHandler (DMA2D_HandleTypeDef * hdma2d)
Function Description	Handles DMA2D interrupt request.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • HAL status

16.3.19 HAL_DMA2D_ConfigLayer

Function Name	HAL_StatusTypeDef HAL_DMA2D_ConfigLayer (DMA2D_HandleTypeDef * hdma2d, uint32_t LayerIdx)
Function Description	Configure the DMA2D Layer according to the specified parameters in the DMA2D_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • LayerIdx: DMA2D Layer index. This parameter can be one of the following values: 0(background) / 1(foreground)
Return values	<ul style="list-style-type: none"> • HAL status

16.3.20 HAL_DMA2D_ConfigCLUT

Function Name	HAL_StatusTypeDef HAL_DMA2D_ConfigCLUT (DMA2D_HandleTypeDef * hdma2d, DMA2D_CLUTCfgTypeDef CLUTCfg, uint32_t LayerIdx)
Function Description	Configure the DMA2D CLUT Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • CLUTCfg: pointer to a DMA2D_CLUTCfgTypeDef structure that contains the configuration information for the color look up table. • LayerIdx: DMA2D Layer index. This parameter can be one of the following values: 0(background) / 1(foreground)
Return values	<ul style="list-style-type: none"> • HAL status

16.3.21 HAL_DMA2D_EnableCLUT

Function Name	HAL_StatusTypeDef HAL_DMA2D_EnableCLUT (DMA2D_HandleTypeDef * hdma2d, uint32_t LayerIdx)
---------------	---

Function Description	Enable the DMA2D CLUT Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • LayerIdx: DMA2D Layer index. This parameter can be one of the following values: 0(background) / 1(foreground)
Return values	<ul style="list-style-type: none"> • HAL status
16.3.22 HAL_DMA2D_DisableCLUT	
Function Name	HAL_StatusTypeDef HAL_DMA2D_DisableCLUT (DMA2D_HandleTypeDef * hdma2d, uint32_t LayerIdx)
Function Description	Disable the DMA2D CLUT Transfer.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • LayerIdx: DMA2D Layer index. This parameter can be one of the following values: 0(background) / 1(foreground)
Return values	<ul style="list-style-type: none"> • HAL status
16.3.23 HAL_DMA2D_ProgramLineEvent	
Function Name	HAL_StatusTypeDef HAL_DMA2D_ProgramLineEvent (DMA2D_HandleTypeDef * hdma2d, uint32_t Line)
Function Description	Define the configuration of the line watermark .
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D. • Line: Line Watermark configuration.
Return values	<ul style="list-style-type: none"> • HAL status
16.3.24 HAL_DMA2D_GetState	
Function Name	HAL_DMA2D_StateTypeDef HAL_DMA2D_GetState (DMA2D_HandleTypeDef * hdma2d)
Function Description	Return the DMA2D state.
Parameters	<ul style="list-style-type: none"> • hdma2d: pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for the DMA2D.
Return values	<ul style="list-style-type: none"> • HAL state
16.3.25 HAL_DMA2D_GetError	
Function Name	uint32_t HAL_DMA2D_GetError (DMA2D_HandleTypeDef * hdma2d)
Function Description	Return the DMA2D error code.
Parameters	<ul style="list-style-type: none"> • hdma2d: : pointer to a DMA2D_HandleTypeDef structure that contains the configuration information for DMA2D.
Return values	<ul style="list-style-type: none"> • DMA2D Error Code

16.4 DMA2D Firmware driver defines

16.4.1 DMA2D

DMA2D ALPHA MODE

DMA2D_NO_MODIF_ALPHA	No modification of the alpha channel value
DMA2D_REPLACE_ALPHA	Replace original alpha channel value by programmed alpha value
DMA2D_COMBINE_ALPHA	Replace original alpha channel value by programmed alpha value with original alpha channel value

DMA2D CLUT CM

DMA2D_CCM_ARGB8888	ARGB8888 DMA2D C-LUT color mode
DMA2D_CCM_RGB888	RGB888 DMA2D C-LUT color mode

DMA2D Color Mode

DMA2D_ARGB8888	ARGB8888 DMA2D color mode
DMA2D_RGB888	RGB888 DMA2D color mode
DMA2D_RGB565	RGB565 DMA2D color mode
DMA2D_ARGB1555	ARGB1555 DMA2D color mode
DMA2D_ARGB4444	ARGB4444 DMA2D color mode

DMA2D COLOR VALUE

COLOR_VALUE	color value mask
-------------	------------------

DMA2D DeadTime

LINE_WATERMARK

DMA2D Error Code

HAL_DMA2D_ERROR_NONE	No error
HAL_DMA2D_ERROR_TE	Transfer error
HAL_DMA2D_ERROR_CE	Configuration error
HAL_DMA2D_ERROR_TIMEOUT	Timeout error

DMA2D Exported Macros

`_HAL_DMA2D_RESET_HANDLE_STATE` **Description:**

- Reset DMA2D handle state.

Parameters:

- `_HANDLE_`: specifies the DMA2D handle.

Return value:

- None

Description:

- Enable the DMA2D.

Parameters:

- `__HANDLE__`: DMA2D handle

Return value:

- None.

`__HAL_DMA2D_DISABLE`**Description:**

- Disable the DMA2D.

Parameters:

- `__HANDLE__`: DMA2D handle

Return value:

- None.

`__HAL_DMA2D_GET_FLAG`**Description:**

- Get the DMA2D pending flags.

Parameters:

- `__HANDLE__`: DMA2D handle
- `__FLAG__`: Get the specified flag. This parameter can be any combination of the following values:
 - DMA2D_FLAG_CE: Configuration error flag
 - DMA2D_FLAG_CTC: C-LUT transfer complete flag
 - DMA2D_FLAG_CAE: C-LUT access error flag
 - DMA2D_FLAG_TW: Transfer Watermark flag
 - DMA2D_FLAG_TC: Transfer complete flag
 - DMA2D_FLAG_TE: Transfer error flag

Return value:

- The state of FLAG.

`__HAL_DMA2D_CLEAR_FLAG`**Description:**

- Clears the DMA2D pending flags.

Parameters:

- `__HANDLE__`: DMA2D handle
- `__FLAG__`: specifies the flag to clear. This parameter can be any combination of the following values:
 - DMA2D_FLAG_CE: Configuration error flag
 - DMA2D_FLAG_CTC: C-LUT transfer complete flag
 - DMA2D_FLAG_CAE: C-LUT access error flag
 - DMA2D_FLAG_TW: Transfer Watermark flag

- DMA2D_FLAG_TC: Transfer complete flag
- DMA2D_FLAG_TE: Transfer error flag

Return value:

- None

_HAL_DMA2D_ENABLE_IT**Description:**

- Enables the specified DMA2D interrupts.

Parameters:

- __HANDLE__: DMA2D handle
- __INTERRUPT__: specifies the DMA2D interrupt sources to be enabled. This parameter can be any combination of the following values:
 - DMA2D_IT_CE: Configuration error interrupt mask
 - DMA2D_IT_CTC: C-LUT transfer complete interrupt mask
 - DMA2D_IT_CAE: C-LUT access error interrupt mask
 - DMA2D_IT_TW: Transfer Watermark interrupt mask
 - DMA2D_IT_TC: Transfer complete interrupt mask
 - DMA2D_IT_TE: Transfer error interrupt mask

Return value:

- None

_HAL_DMA2D_DISABLE_IT**Description:**

- Disables the specified DMA2D interrupts.

Parameters:

- __HANDLE__: DMA2D handle
- __INTERRUPT__: specifies the DMA2D interrupt sources to be disabled. This parameter can be any combination of the following values:
 - DMA2D_IT_CE: Configuration error interrupt mask
 - DMA2D_IT_CTC: C-LUT transfer complete interrupt mask
 - DMA2D_IT_CAE: C-LUT access error interrupt mask
 - DMA2D_IT_TW: Transfer Watermark interrupt mask
 - DMA2D_IT_TC: Transfer complete interrupt mask

- DMA2D_IT_TE: Transfer error interrupt mask

Return value:

- None

`_HAL_DMA2D_GET_IT_SOURCE`**Description:**

- Checks whether the specified DMA2D interrupt has occurred or not.

Parameters:

- `_HANDLE_`: DMA2D handle
- `_INTERRUPT_`: specifies the DMA2D interrupt source to check. This parameter can be one of the following values:
 - DMA2D_IT_CE: Configuration error interrupt mask
 - DMA2D_IT_CTC: C-LUT transfer complete interrupt mask
 - DMA2D_IT_CAE: C-LUT access error interrupt mask
 - DMA2D_IT_TW: Transfer Watermark interrupt mask
 - DMA2D_IT_TC: Transfer complete interrupt mask
 - DMA2D_IT_TE: Transfer error interrupt mask

Return value:

- The state of INTERRUPT.

DMA2D Exported Types`MAX_DMA2D_LAYER`**DMA2D Flag**

<code>DMA2D_FLAG_CE</code>	Configuration Error Interrupt Flag
<code>DMA2D_FLAG_CTC</code>	C-LUT Transfer Complete Interrupt Flag
<code>DMA2D_FLAG_CAE</code>	C-LUT Access Error Interrupt Flag
<code>DMA2D_FLAG_TW</code>	Transfer Watermark Interrupt Flag
<code>DMA2D_FLAG_TC</code>	Transfer Complete Interrupt Flag
<code>DMA2D_FLAG_TE</code>	Transfer Error Interrupt Flag

DMA2D Input Color Mode

<code>CM_ARGB8888</code>	ARGB8888 color mode
<code>CM_RGB888</code>	RGB888 color mode
<code>CM_RGB565</code>	RGB565 color mode
<code>CM_ARGB1555</code>	ARGB1555 color mode
<code>CM_ARGB4444</code>	ARGB4444 color mode

CM_L8	L8 color mode
CM_AL44	AL44 color mode
CM_AL88	AL88 color mode
CM_L4	L4 color mode
CM_A8	A8 color mode
CM_A4	A4 color mode
DMA2D Interrupts	
DMA2D_IT_CE	Configuration Error Interrupt
DMA2D_IT_CTC	C-LUT Transfer Complete Interrupt
DMA2D_IT_CAE	C-LUT Access Error Interrupt
DMA2D_IT_TW	Transfer Watermark Interrupt
DMA2D_IT_TC	Transfer Complete Interrupt
DMA2D_IT_TE	Transfer Error Interrupt
DMA2D Mode	
DMA2D_M2M	DMA2D memory to memory transfer mode
DMA2D_M2M_PFC	DMA2D memory to memory with pixel format conversion transfer mode
DMA2D_M2M_BLEND	DMA2D memory to memory with blending transfer mode
DMA2D_R2M	DMA2D register to memory transfer mode
DMA2D Offset	
DMA2D_OFFSET	Line Offset
DMA2D Private Defines	
HAL_TIMEOUT_DMA2D_ABORT	
HAL_TIMEOUT_DMA2D_SUSPEND	
DMA2D Private Macros	
IS_DMA2D_LAYER	
IS_DMA2D_MODE	
IS_DMA2D_CMODE	
IS_DMA2D_COLOR	
IS_DMA2D_LINE	
IS_DMA2D_PIXEL	
IS_DMA2D_OFFSET	
IS_DMA2D_INPUT_COLOR_MODE	
IS_DMA2D_ALPHA_MODE	
IS_DMA2D_CLUT_CM	
IS_DMA2D_CLUT_SIZE	
IS_DMA2D_LineWatermark	

DMA2D SIZE

DMA2D_PIXEL DMA2D pixel per line
DMA2D_LINE DMA2D number of line

DMA2D Size Clut

DMA2D_CLUT_SIZE DMA2D C-LUT size

17 HAL DMA Generic Driver

17.1 HAL DMA Generic Driver

17.2 DMA Firmware driver registers structures

17.2.1 DMA_InitTypeDef

Data Fields

- *uint32_t Channel*
- *uint32_t Direction*
- *uint32_t PeriphInc*
- *uint32_t MemInc*
- *uint32_t PeriphDataAlignment*
- *uint32_t MemDataAlignment*
- *uint32_t Mode*
- *uint32_t Priority*
- *uint32_t FIFOMode*
- *uint32_t FIFOThreshold*
- *uint32_t MemBurst*
- *uint32_t PeriphBurst*

Field Documentation

- ***uint32_t DMA_InitTypeDef::Channel***
Specifies the channel used for the specified stream. This parameter can be a value of [**DMA_Channel_selection**](#)
 - ***uint32_t DMA_InitTypeDef::Direction***
Specifies if the data will be transferred from memory to peripheral, from memory to memory or from peripheral to memory. This parameter can be a value of [**DMA_Data_transfer_direction**](#)
 - ***uint32_t DMA_InitTypeDef::PeriphInc***
Specifies whether the Peripheral address register should be incremented or not. This parameter can be a value of [**DMA_Peripheral_incremented_mode**](#)
 - ***uint32_t DMA_InitTypeDef::MemInc***
Specifies whether the memory address register should be incremented or not. This parameter can be a value of [**DMA_Memory_incremented_mode**](#)
 - ***uint32_t DMA_InitTypeDef::PeriphDataAlignment***
Specifies the Peripheral data width. This parameter can be a value of [**DMA_Peripheral_data_size**](#)
 - ***uint32_t DMA_InitTypeDef::MemDataAlignment***
Specifies the Memory data width. This parameter can be a value of [**DMA_Memory_data_size**](#)
 - ***uint32_t DMA_InitTypeDef::Mode***
Specifies the operation mode of the DMAy Streamx. This parameter can be a value of [**DMA_mode**](#)
- Note:**The circular buffer mode cannot be used if the memory-to-memory data transfer is configured on the selected Stream

- **`uint32_t DMA_InitTypeDef::Priority`**
Specifies the software priority for the DMAy Streamx. This parameter can be a value of **DMA_Priority_level**
- **`uint32_t DMA_InitTypeDef::FIFOMode`**
Specifies if the FIFO mode or Direct mode will be used for the specified stream. This parameter can be a value of **DMA_FIFO_direct_mode**
Note:The Direct mode (FIFO mode disabled) cannot be used if the memory-to-memory data transfer is configured on the selected stream
- **`uint32_t DMA_InitTypeDef::FIFOThreshold`**
Specifies the FIFO threshold level. This parameter can be a value of **DMA_FIFO_threshold_level**
- **`uint32_t DMA_InitTypeDef::MemBurst`**
Specifies the Burst transfer configuration for the memory transfers. It specifies the amount of data to be transferred in a single non interruptible transaction. This parameter can be a value of **DMA_Memory_burst**
Note:The burst mode is possible only if the address Increment mode is enabled.
- **`uint32_t DMA_InitTypeDef::PeriphBurst`**
Specifies the Burst transfer configuration for the peripheral transfers. It specifies the amount of data to be transferred in a single non interruptable transaction. This parameter can be a value of **DMA_Peripheral_burst**
Note:The burst mode is possible only if the address Increment mode is enabled.

17.2.2 `__DMA_HandleTypeDef`

Data Fields

- **`DMA_Stream_TypeDef * Instance`**
- **`DMA_InitTypeDef Init`**
- **`HAL_LockTypeDef Lock`**
- **`__IO HAL_DMA_StateTypeDef State`**
- **`void * Parent`**
- **`void(* XferCpltCallback`**
- **`void(* XferHalfCpltCallback`**
- **`void(* XferM1CpltCallback`**
- **`void(* XferErrorCallback`**
- **`__IO uint32_t ErrorCode`**
- **`uint32_t StreamBaseAddress`**
- **`uint32_t StreamIndex`**

Field Documentation

- **`DMA_Stream_TypeDef* __DMA_HandleTypeDef::Instance`**
Register base address
- **`DMA_InitTypeDef __DMA_HandleTypeDef::Init`**
DMA communication parameters
- **`HAL_LockTypeDef __DMA_HandleTypeDef::Lock`**
DMA locking object
- **`__IO HAL_DMA_StateTypeDef __DMA_HandleTypeDef::State`**
DMA transfer state
- **`void* __DMA_HandleTypeDef::Parent`**
Parent object state

- `void(* __DMA_HandleTypeDefDef::XferCpltCallback)(struct __DMA_HandleTypeDefDef *hdma)`
DMA transfer complete callback
- `void(* __DMA_HandleTypeDefDef::XferHalfCpltCallback)(struct __DMA_HandleTypeDefDef *hdma)`
DMA Half transfer complete callback
- `void(* __DMA_HandleTypeDefDef::XferM1CpltCallback)(struct __DMA_HandleTypeDefDef *hdma)`
DMA transfer complete Memory1 callback
- `void(* __DMA_HandleTypeDefDef::XferErrorCallback)(struct __DMA_HandleTypeDefDef *hdma)`
DMA transfer error callback
- `_IO uint32_t __DMA_HandleTypeDefDef::ErrorCode`
DMA Error code
- `uint32_t __DMA_HandleTypeDefDef::StreamBaseAddress`
DMA Stream Base Address
- `uint32_t __DMA_HandleTypeDefDef::StreamIndex`
DMA Stream Index

17.3 DMA Firmware driver API description

17.3.1 How to use this driver

1. Enable and configure the peripheral to be connected to the DMA Stream (except for internal SRAM/FLASH memories: no initialization is necessary) please refer to Reference manual for connection between peripherals and DMA requests .
2. For a given Stream, program the required configuration through the following parameters: Transfer Direction, Source and Destination data formats, Circular, Normal or peripheral flow control mode, Stream Priority level, Source and Destination Increment mode, FIFO mode and its Threshold (if needed), Burst mode for Source and/or Destination (if needed) using HAL_DMA_Init() function.

Polling mode IO operation

- Use HAL_DMA_Start() to start DMA transfer after the configuration of Source address and destination address and the Length of data to be transferred
- Use HAL_DMA_PollForTransfer() to poll for the end of current transfer, in this case a fixed Timeout can be configured by User depending from his application.

Interrupt mode IO operation

- Configure the DMA interrupt priority using HAL_NVIC_SetPriority()
- Enable the DMA IRQ handler using HAL_NVIC_EnableIRQ()
- Use HAL_DMA_Start_IT() to start DMA transfer after the configuration of Source address and destination address and the Length of data to be transferred. In this case the DMA interrupt is configured
- Use HAL_DMA_IRQHandler() called under DMA_IRQHandler() Interrupt subroutine

- At the end of data transfer HAL_DMA_IRQHandler() function is executed and user can add his own function by customization of function pointer XferCpltCallback and XferErrorCallback (i.e a member of DMA handle structure).
 1. Use HAL_DMA_GetState() function to return the DMA state and HAL_DMA_GetError() in case of error detection.
 2. Use HAL_DMA_Abort() function to abort the current transfer. In Memory-to-Memory transfer mode, Circular mode is not allowed. The FIFO is used mainly to reduce bus usage and to allow data packing/unpacking: it is possible to set different Data Sizes for the Peripheral and the Memory (ie. you can set Half-Word data size for the peripheral to access its data register and set Word data size for the Memory to gain in access time. Each two half words will be packed and written in a single access to a Word in the Memory). When FIFO is disabled, it is not allowed to configure different Data Sizes for Source and Destination. In this case the Peripheral Data Size will be applied to both Source and Destination.

DMA HAL driver macros list

Below the list of most used macros in DMA HAL driver.

- __HAL_DMA_ENABLE: Enable the specified DMA Stream.
- __HAL_DMA_DISABLE: Disable the specified DMA Stream.
- __HAL_DMA_GET_FS: Return the current DMA Stream FIFO filled level.
- __HAL_DMA_GET_FLAG: Get the DMA Stream pending flags.
- __HAL_DMA_CLEAR_FLAG: Clear the DMA Stream pending flags.
- __HAL_DMA_ENABLE_IT: Enable the specified DMA Stream interrupts.
- __HAL_DMA_DISABLE_IT: Disable the specified DMA Stream interrupts.
- __HAL_DMA_GET_IT_SOURCE: Check whether the specified DMA Stream interrupt has occurred or not.



You can refer to the DMA HAL driver header file for more useful macros

17.3.2 Initialization and de-initialization functions

This section provides functions allowing to initialize the DMA Stream source and destination addresses, incrementation and data sizes, transfer direction, circular/normal mode selection, memory-to-memory mode selection and Stream priority value.

The HAL_DMA_Init() function follows the DMA configuration procedures as described in reference manual.

This section contains the following APIs:

- [**HAL_DMA_Init\(\)**](#)
- [**HAL_DMA_DelInit\(\)**](#)

17.3.3 IO operation functions

This section provides functions allowing to:

- Configure the source, destination address and data length and Start DMA transfer
- Configure the source, destination address and data length and Start DMA transfer with interrupt
- Abort DMA transfer

- Poll for transfer complete
- Handle DMA interrupt request

This section contains the following APIs:

- [*HAL_DMA_Start\(\)*](#)
- [*HAL_DMA_Start_IT\(\)*](#)
- [*HAL_DMA_Abort\(\)*](#)
- [*HAL_DMA_PollForTransfer\(\)*](#)
- [*HAL_DMA_IRQHandler\(\)*](#)

17.3.4 State and Errors functions

This subsection provides functions allowing to

- Check the DMA state
- Get error code

This section contains the following APIs:

- [*HAL_DMA_GetState\(\)*](#)
- [*HAL_DMA_GetError\(\)*](#)

17.3.5 HAL_DMA_Init

Function Name	<code>HAL_StatusTypeDef HAL_DMA_Init (DMA_HandleTypeDef *hdma)</code>
Function Description	Initializes the DMA according to the specified parameters in the <code>DMA_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hdma: Pointer to a <code>DMA_HandleTypeDef</code> structure that contains the configuration information for the specified DMA Stream.
Return values	<ul style="list-style-type: none"> • HAL status

17.3.6 HAL_DMA_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_DMA_DeInit (DMA_HandleTypeDef *hdma)</code>
Function Description	DeInitializes the DMA peripheral.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a <code>DMA_HandleTypeDef</code> structure that contains the configuration information for the specified DMA Stream.

- HAL status

17.3.7 HAL_DMA_Start

Function Name	<code>HAL_StatusTypeDef HAL_DMA_Start (DMA_HandleTypeDef *hdma, uint32_t SrcAddress, uint32_t DstAddress, uint32_t DataLength)</code>
Function Description	Starts the DMA Transfer.
Parameters	<ul style="list-style-type: none"> • hdma: : pointer to a <code>DMA_HandleTypeDef</code> structure that contains the configuration information for the specified DMA Stream.

- **SrcAddress:** The source memory Buffer address
- **DstAddress:** The destination memory Buffer address
- **DataLength:** The length of data to be transferred from source to destination

Return values • HAL status

17.3.8 HAL_DMA_Start_IT

Function Name **HAL_StatusTypeDef HAL_DMA_Start_IT (DMA_HandleTypeDef * hdma, uint32_t SrcAddress, uint32_t DstAddress, uint32_t DataLength)**

Function Description Start the DMA Transfer with interrupt enabled.

- Parameters
- **hdma:** pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream.
 - **SrcAddress:** The source memory Buffer address
 - **DstAddress:** The destination memory Buffer address
 - **DataLength:** The length of data to be transferred from source to destination

Return values • HAL status

17.3.9 HAL_DMA_Abort

Function Name **HAL_StatusTypeDef HAL_DMA_Abort (DMA_HandleTypeDef * hdma)**

Function Description Aborts the DMA Transfer.

- Parameters
- **hdma:** : pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream.

Return values • HAL status

- Notes
- After disabling a DMA Stream, a check for wait until the DMA Stream is effectively disabled is added. If a Stream is disabled while a data transfer is ongoing, the current data will be transferred and the Stream will be effectively disabled only after the transfer of this single data is finished.

17.3.10 HAL_DMA_PollForTransfer

Function Name **HAL_StatusTypeDef HAL_DMA_PollForTransfer (DMA_HandleTypeDef * hdma, uint32_t CompleteLevel, uint32_t Timeout)**

Function Description Polling for transfer complete.

- Parameters
- **hdma:** pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream.
 - **CompleteLevel:** Specifies the DMA level complete.
 - **Timeout:** Timeout duration.

Return values • HAL status

17.3.11 HAL_DMA_IRQHandler

Function Name	void HAL_DMA_IRQHandler (DMA_HandleTypeDef * hdma)
Function Description	Handles DMA interrupt request.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream.
Return values	<ul style="list-style-type: none"> • None

17.3.12 HAL_DMA_GetState

Function Name	HAL_DMA_StateTypeDef HAL_DMA_GetState (DMA_HandleTypeDef * hdma)
Function Description	Returns the DMA state.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream.
Return values	<ul style="list-style-type: none"> • HAL state

17.3.13 HAL_DMA_GetError

Function Name	uint32_t HAL_DMA_GetError (DMA_HandleTypeDef * hdma)
Function Description	Return the DMA error code.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream.
Return values	<ul style="list-style-type: none"> • DMA Error Code

17.4 DMA Firmware driver defines

17.4.1 DMA

DMA Channel selection

DMA_CHANNEL_0	DMA Channel 0
DMA_CHANNEL_1	DMA Channel 1
DMA_CHANNEL_2	DMA Channel 2
DMA_CHANNEL_3	DMA Channel 3
DMA_CHANNEL_4	DMA Channel 4
DMA_CHANNEL_5	DMA Channel 5
DMA_CHANNEL_6	DMA Channel 6
DMA_CHANNEL_7	DMA Channel 7

DMA Data transfer direction

DMA_PERIPH_TO_MEMORY	Peripheral to memory direction
DMA_MEMORY_TO_PERIPH	Memory to peripheral direction

DMA_MEMORY_TO_MEMORY Memory to memory direction

DMA Error Code

HAL_DMA_ERROR_NONE	No error
HAL_DMA_ERROR_TE	Transfer error
HAL_DMA_ERROR_FE	FIFO error
HAL_DMA_ERROR_DME	Direct Mode error
HAL_DMA_ERROR_TIMEOUT	Timeout error

DMA FIFO direct mode

DMA_FIFOMODE_DISABLE	FIFO mode disable
DMA_FIFOMODE_ENABLE	FIFO mode enable

DMA FIFO threshold level

DMA_FIFO_THRESHOLD_1QUARTERFULL	FIFO threshold 1 quart full configuration
DMA_FIFO_THRESHOLD_HALFFULL	FIFO threshold half full configuration
DMA_FIFO_THRESHOLD_3QUARTERSFULL	FIFO threshold 3 quarts full configuration
DMA_FIFO_THRESHOLD_FULL	FIFO threshold full configuration

DMA flag definitions

DMA_FLAG_FEIF0_4
DMA_FLAG_DMEIF0_4
DMA_FLAG_TEIF0_4
DMA_FLAG_Htif0_4
DMA_FLAG_TCIF0_4
DMA_FLAG_FEIF1_5
DMA_FLAG_DMEIF1_5
DMA_FLAG_TEIF1_5
DMA_FLAG_Htif1_5
DMA_FLAG_TCIF1_5
DMA_FLAG_FEIF2_6
DMA_FLAG_DMEIF2_6
DMA_FLAG_TEIF2_6
DMA_FLAG_Htif2_6
DMA_FLAG_TCIF2_6
DMA_FLAG_FEIF3_7
DMA_FLAG_DMEIF3_7
DMA_FLAG_TEIF3_7
DMA_FLAG_Htif3_7
DMA_FLAG_TCIF3_7

DMA Handle index

TIM_DMA_ID_UPDATE	Index of the DMA handle used for Update DMA requests
TIM_DMA_ID_CC1	Index of the DMA handle used for Capture/Compare 1 DMA requests
TIM_DMA_ID_CC2	Index of the DMA handle used for Capture/Compare 2 DMA requests
TIM_DMA_ID_CC3	Index of the DMA handle used for Capture/Compare 3 DMA requests
TIM_DMA_ID_CC4	Index of the DMA handle used for Capture/Compare 4 DMA requests
TIM_DMA_ID_COMMUTATION	Index of the DMA handle used for Commutation DMA requests
TIM_DMA_ID_TRIGGER	Index of the DMA handle used for Trigger DMA requests
DMA interrupt enable definitions	
DMA_IT_TC	
DMA_IT_HT	
DMA_IT_TE	
DMA_IT_DME	
DMA_IT_FE	
DMA Memory burst	
DMA_MBURST_SINGLE	
DMA_MBURST_INC4	
DMA_MBURST_INC8	
DMA_MBURST_INC16	
DMA Memory data size	
DMA_MDATAALIGN_BYTE	Memory data alignment: Byte
DMA_MDATAALIGN_HALFWORD	Memory data alignment: HalfWord
DMA_MDATAALIGN_WORD	Memory data alignment: Word
DMA Memory incremented mode	
DMA_MINC_ENABLE	Memory increment mode enable
DMA_MINC_DISABLE	Memory increment mode disable
DMA mode	
DMA_NORMAL	Normal mode
DMA_CIRCULAR	Circular mode
DMA_PFCTRL	Peripheral flow control mode
DMA Peripheral burst	
DMA_PBURST_SINGLE	
DMA_PBURST_INC4	
DMA_PBURST_INC8	

DMA_PBURST_INC16

DMA Peripheral data size

DMA_PDATAALIGN_BYTE	Peripheral data alignment: Byte
DMA_PDATAALIGN_HALFWORD	Peripheral data alignment: HalfWord
DMA_PDATAALIGN_WORD	Peripheral data alignment: Word

DMA Peripheral incremented mode

DMA_PINC_ENABLE	Peripheral increment mode enable
DMA_PINC_DISABLE	Peripheral increment mode disable

DMA Priority level

DMA_PRIORITY_LOW	Priority level: Low
DMA_PRIORITY_MEDIUM	Priority level: Medium
DMA_PRIORITY_HIGH	Priority level: High
DMA_PRIORITY VERY HIGH	Priority level: Very High

DMA Private Constants

HAL_TIMEOUT_DMA_ABORT

DMA Private Macros

IS_DMA_CHANNEL	
IS_DMA_DIRECTION	
IS_DMA_BUFFER_SIZE	
IS_DMA_PERIPHERAL_INC_STATE	
IS_DMA_MEMORY_INC_STATE	
IS_DMA_PERIPHERAL_DATA_SIZE	
IS_DMA_MEMORY_DATA_SIZE	
IS_DMA_MODE	
IS_DMA_PRIORITY	
IS_DMA_FIFO_MODE_STATE	
IS_DMA_FIFO_THRESHOLD	
IS_DMA_MEMORY_BURST	
IS_DMA_PERIPHERAL_BURST	

18 HAL DMA Extension Driver

18.1 HAL DMA Extension Driver

18.2 DMAEx Firmware driver API description

18.2.1 How to use this driver

The DMA Extension HAL driver can be used as follows:

1. Start a multi buffer transfer using the HAL_DMA_MultiBufferStart() function for polling mode or HAL_DMA_MultiBufferStart_IT() for interrupt mode. In Memory-to-Memory transfer mode, Multi (Double) Buffer mode is not allowed. When Multi (Double) Buffer mode is enabled the, transfer is circular by default. In Multi (Double) buffer mode, it is possible to update the base address for the AHB memory port on the fly (DMA_SxM0AR or DMA_SxM1AR) when the stream is enabled.

18.2.2 Extended features functions

This section provides functions allowing to:

- Configure the source, destination address and data length and Start MultiBuffer DMA transfer
- Configure the source, destination address and data length and Start MultiBuffer DMA transfer with interrupt
- Change on the fly the memory0 or memory1 address.

This section contains the following APIs:

- [**HAL_DMAEx_MultiBufferStart\(\)**](#)
- [**HAL_DMAEx_MultiBufferStart_IT\(\)**](#)
- [**HAL_DMAEx_ChangeMemory\(\)**](#)

18.2.3 HAL_DMAEx_MultiBufferStart

Function Name	<code>HAL_StatusTypeDef HAL_DMAEx_MultiBufferStart (DMA_HandleTypeDef * hdma, uint32_t SrcAddress, uint32_t DstAddress, uint32_t SecondMemAddress, uint32_t DataLength)</code>
Function Description	Starts the multi_buffer DMA Transfer.
Parameters	<ul style="list-style-type: none"> • hdma: : pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream. • SrcAddress: The source memory Buffer address • DstAddress: The destination memory Buffer address • SecondMemAddress: The second memory Buffer address in case of multi buffer Transfer • DataLength: The length of data to be transferred from source to destination
Return values	<ul style="list-style-type: none"> • HAL status

18.2.4 HAL_DMAEx_MultiBufferStart_IT



Function Name	HAL_StatusTypeDef HAL_DMAEx_MultiBufferStart_IT (DMA_HandleTypeDef * hdma, uint32_t SrcAddress, uint32_t DstAddress, uint32_t SecondMemAddress, uint32_t DataLength)
Function Description	Starts the multi_buffer DMA Transfer with interrupt enabled.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream. • SrcAddress: The source memory Buffer address • DstAddress: The destination memory Buffer address • SecondMemAddress: The second memory Buffer address in case of multi buffer Transfer • DataLength: The length of data to be transferred from source to destination
Return values	<ul style="list-style-type: none"> • HAL status

18.2.5 HAL_DMAEx_ChangeMemory

Function Name	HAL_StatusTypeDef HAL_DMAEx_ChangeMemory (DMA_HandleTypeDef * hdma, uint32_t Address, HAL_DMA_MemoryTypeDef memory)
Function Description	Change the memory0 or memory1 address on the fly.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA Stream. • Address: The new address • memory: the memory to be changed, This parameter can be one of the following values: MEMORY0 / MEMORY1
Return values	<ul style="list-style-type: none"> • HAL status

Notes

- The MEMORY0 address can be changed only when the current transfer use MEMORY1 and the MEMORY1 address can be changed only when the current transfer use MEMORY0.

18.3 DMAEx Firmware driver defines

18.3.1 DMAEx

19 HAL DSI Generic Driver

19.1 HAL DSI Generic Driver

19.2 DSI Firmware driver registers structures

19.2.1 DSI_InitTypeDef

Data Fields

- *uint32_t AutomaticClockLaneControl*
- *uint32_t TXEscapeCkdiv*
- *uint32_t NumberOfLanes*

Field Documentation

- *uint32_t DSI_InitTypeDef::AutomaticClockLaneControl*
Automatic clock lane control This parameter can be any value of [*DSI_Automatic_Clk_Lane_Control*](#)
- *uint32_t DSI_InitTypeDef::TXEscapeCkdiv*
TX Escape clock division The values 0 and 1 stop the TX_ESC clock generation
- *uint32_t DSI_InitTypeDef::NumberOfLanes*
Number of lanes This parameter can be any value of [*DSI_Number_Of_Lanes*](#)

19.2.2 DSI_PLLInitTypeDef

Data Fields

- *uint32_t PLLNDIV*
- *uint32_t PLLIDF*
- *uint32_t PLLODF*

Field Documentation

- *uint32_t DSI_PLLInitTypeDef::PLLNDIV*
PLL Loop Division Factor This parameter must be a value between 10 and 125
- *uint32_t DSI_PLLInitTypeDef::PLLIDF*
PLL Input Division Factor This parameter can be any value of [*DSI_PLL_IDF*](#)
- *uint32_t DSI_PLLInitTypeDef::PLLODF*
PLL Output Division Factor This parameter can be any value of [*DSI_PLL_ODF*](#)

19.2.3 DSI_VidCfgTypeDef

Data Fields

- *uint32_t VirtualChannelID*

- *uint32_t ColorCoding*
- *uint32_t LooselyPacked*
- *uint32_t Mode*
- *uint32_t PacketSize*
- *uint32_t NumberOfChunks*
- *uint32_t NullPacketSize*
- *uint32_t HSPolarity*
- *uint32_t VSPolarity*
- *uint32_t DEPolarity*
- *uint32_t HorizontalSyncActive*
- *uint32_t HorizontalBackPorch*
- *uint32_t HorizontalLine*
- *uint32_t VerticalSyncActive*
- *uint32_t VerticalBackPorch*
- *uint32_t VerticalFrontPorch*
- *uint32_t VerticalActive*
- *uint32_t LPCommandEnable*
- *uint32_t LPLargestPacketSize*
- *uint32_t LPVACTLargestPacketSize*
- *uint32_t LPHorizontalFrontPorchEnable*
- *uint32_t LPHorizontalBackPorchEnable*
- *uint32_t LPVerticalActiveEnable*
- *uint32_t LPVerticalFrontPorchEnable*
- *uint32_t LPVerticalBackPorchEnable*
- *uint32_t LPVerticalSyncActiveEnable*
- *uint32_t FrameBTAAcknowledgeEnable*

Field Documentation

- *uint32_t DSI_VidCfgTypeDef::VirtualChannelID*
Virtual channel ID
- *uint32_t DSI_VidCfgTypeDef::ColorCoding*
Color coding for LTDC interface This parameter can be any value of [**DSI_Color_Coding**](#)
- *uint32_t DSI_VidCfgTypeDef::LooselyPacked*
Enable or disable loosely packed stream (needed only when using 18-bit configuration). This parameter can be any value of [**DSI_LoSelyPacked**](#)
- *uint32_t DSI_VidCfgTypeDef::Mode*
Video mode type This parameter can be any value of [**DSI_Video_Mode_Type**](#)
- *uint32_t DSI_VidCfgTypeDef::PacketSize*
Video packet size
- *uint32_t DSI_VidCfgTypeDef::NumberOfChunks*
Number of chunks
- *uint32_t DSI_VidCfgTypeDef::NullPacketSize*
Null packet size
- *uint32_t DSI_VidCfgTypeDef::HSPolarity*
HSYNC pin polarity This parameter can be any value of [**DSI_HSYNC_Polarity**](#)
- *uint32_t DSI_VidCfgTypeDef::VSPolarity*
VSYNC pin polarity This parameter can be any value of [**DSI_VSYNC_Polarity**](#)
- *uint32_t DSI_VidCfgTypeDef::DEPolarity*
Data Enable pin polarity This parameter can be any value of [**DSI_DATA_ENABLE_Polarity**](#)

- ***uint32_t DSI_VidCfgTypeDef::HorizontalSyncActive***
Horizontal synchronism active duration (in lane byte clock cycles)
- ***uint32_t DSI_VidCfgTypeDef::HorizontalBackPorch***
Horizontal back-porch duration (in lane byte clock cycles)
- ***uint32_t DSI_VidCfgTypeDef::HorizontalLine***
Horizontal line duration (in lane byte clock cycles)
- ***uint32_t DSI_VidCfgTypeDef::VerticalSyncActive***
Vertical synchronism active duration
- ***uint32_t DSI_VidCfgTypeDef::VerticalBackPorch***
Vertical back-porch duration
- ***uint32_t DSI_VidCfgTypeDef::VerticalFrontPorch***
Vertical front-porch duration
- ***uint32_t DSI_VidCfgTypeDef::VerticalActive***
Vertical active duration
- ***uint32_t DSI_VidCfgTypeDef::LPCommandEnable***
Low-power command enable This parameter can be any value of [**DSI_LP_Command**](#)
- ***uint32_t DSI_VidCfgTypeDef::LPLargestPacketSize***
The size, in bytes, of the low power largest packet that can fit in a line during VSA, VBP and VFP regions
- ***uint32_t DSI_VidCfgTypeDef::LPVACTLargestPacketSize***
The size, in bytes, of the low power largest packet that can fit in a line during VACT region
- ***uint32_t DSI_VidCfgTypeDef::LPHorizontalFrontPorchEnable***
Low-power horizontal front-porch enable This parameter can be any value of [**DSI_LP_HFP**](#)
- ***uint32_t DSI_VidCfgTypeDef::LPHorizontalBackPorchEnable***
Low-power horizontal back-porch enable This parameter can be any value of [**DSI_LP_HBP**](#)
- ***uint32_t DSI_VidCfgTypeDef::LPVerticalActiveEnable***
Low-power vertical active enable This parameter can be any value of [**DSI_LP_VACT**](#)
- ***uint32_t DSI_VidCfgTypeDef::LPVerticalFrontPorchEnable***
Low-power vertical front-porch enable This parameter can be any value of [**DSI_LP_VFP**](#)
- ***uint32_t DSI_VidCfgTypeDef::LPVerticalBackPorchEnable***
Low-power vertical back-porch enable This parameter can be any value of [**DSI_LP_VBP**](#)
- ***uint32_t DSI_VidCfgTypeDef::LPVerticalSyncActiveEnable***
Low-power vertical sync active enable This parameter can be any value of [**DSI_LP_VSYNC**](#)
- ***uint32_t DSI_VidCfgTypeDef::FrameBTAAcknowledgeEnable***
Frame bus-turn-around acknowledge enable This parameter can be any value of [**DSI_FBTA_acknowledge**](#)

19.2.4 DSI_CmdCfgTypeDef

Data Fields

- ***uint32_t VirtualChannelID***
- ***uint32_t ColorCoding***
- ***uint32_t CommandSize***
- ***uint32_t TearingEffectSource***

-
- *uint32_t TearingEffectPolarity*
 - *uint32_t HSPolarity*
 - *uint32_t VSPolarity*
 - *uint32_t DEPolarity*
 - *uint32_t VSyncPol*
 - *uint32_t AutomaticRefresh*
 - *uint32_t TEAcknowledgeRequest*

Field Documentation

- ***uint32_t DSI_CmdCfgTypeDef::VirtualChannelID***
Virtual channel ID
- ***uint32_t DSI_CmdCfgTypeDef::ColorCoding***
Color coding for LTDC interface This parameter can be any value of [**DSI_Color_Coding**](#)
- ***uint32_t DSI_CmdCfgTypeDef::CommandSize***
Maximum allowed size for an LTDC write memory command, measured in pixels.
This parameter can be any value between 0x00 and 0xFFFF
- ***uint32_t DSI_CmdCfgTypeDef::TearingEffectSource***
Tearing effect source This parameter can be any value of [**DSI_TearingEffectSource**](#)
- ***uint32_t DSI_CmdCfgTypeDef::TearingEffectPolarity***
Tearing effect pin polarity This parameter can be any value of [**DSI_TearingEffectPolarity**](#)
- ***uint32_t DSI_CmdCfgTypeDef::HSPolarity***
HSYNC pin polarity This parameter can be any value of [**DSI_HSYNC_Polarity**](#)
- ***uint32_t DSI_CmdCfgTypeDef::VSPolarity***
VSYNC pin polarity This parameter can be any value of [**DSI_VSYNC_Polarity**](#)
- ***uint32_t DSI_CmdCfgTypeDef::DEPolarity***
Data Enable pin polarity This parameter can be any value of [**DSI_DATA_ENABLE_Polarity**](#)
- ***uint32_t DSI_CmdCfgTypeDef::VSyncPol***
VSync edge on which the LTDC is halted This parameter can be any value of [**DSI_VSYNC_Polarity**](#)
- ***uint32_t DSI_CmdCfgTypeDef::AutomaticRefresh***
Automatic refresh mode This parameter can be any value of [**DSI_AutomaticRefresh**](#)
- ***uint32_t DSI_CmdCfgTypeDef::TEAcknowledgeRequest***
Tearing Effect Acknowledge Request Enable This parameter can be any value of [**DSI_TE_AcknowledgeRequest**](#)

19.2.5 DSI_LPCmdTypeDef

Data Fields

- *uint32_t LPGenShortWriteNoP*
- *uint32_t LPGenShortWriteOneP*
- *uint32_t LPGenShortWriteTwoP*
- *uint32_t LPGenShortReadNoP*
- *uint32_t LPGenShortReadOneP*
- *uint32_t LPGenShortReadTwoP*
- *uint32_t LPGenLongWrite*
- *uint32_t LPDcsShortWriteNoP*

- *uint32_t LPDcsShortWriteOneP*
- *uint32_t LPDcsShortReadNoP*
- *uint32_t LPDcsLongWrite*
- *uint32_t LPMaxReadPacket*
- *uint32_t AcknowledgeRequest*

Field Documentation

- *uint32_t DSI_LPCmdTypeDef::LPGenShortWriteNoP*
Generic Short Write Zero parameters Transmission This parameter can be any value of *DSI_LP_LPGenShortWriteNoP*
- *uint32_t DSI_LPCmdTypeDef::LPGenShortWriteOneP*
Generic Short Write One parameter Transmission This parameter can be any value of *DSI_LP_LPGenShortWriteOneP*
- *uint32_t DSI_LPCmdTypeDef::LPGenShortWriteTwoP*
Generic Short Write Two parameters Transmission This parameter can be any value of *DSI_LP_LPGenShortWriteTwoP*
- *uint32_t DSI_LPCmdTypeDef::LPGenShortReadNoP*
Generic Short Read Zero parameters Transmission This parameter can be any value of *DSI_LP_LPGenShortReadNoP*
- *uint32_t DSI_LPCmdTypeDef::LPGenShortReadOneP*
Generic Short Read One parameter Transmission This parameter can be any value of *DSI_LP_LPGenShortReadOneP*
- *uint32_t DSI_LPCmdTypeDef::LPGenShortReadTwoP*
Generic Short Read Two parameters Transmission This parameter can be any value of *DSI_LP_LPGenShortReadTwoP*
- *uint32_t DSI_LPCmdTypeDef::LPGenLongWrite*
Generic Long Write Transmission This parameter can be any value of *DSI_LP_LPGenLongWrite*
- *uint32_t DSI_LPCmdTypeDef::LPDcsShortWriteNoP*
DCS Short Write Zero parameters Transmission This parameter can be any value of *DSI_LP_LPDCsShortWriteNoP*
- *uint32_t DSI_LPCmdTypeDef::LPDcsShortWriteOneP*
DCS Short Write One parameter Transmission This parameter can be any value of *DSI_LP_LPDCsShortWriteOneP*
- *uint32_t DSI_LPCmdTypeDef::LPDcsShortReadNoP*
DCS Short Read Zero parameters Transmission This parameter can be any value of *DSI_LP_LPDCsShortReadNoP*
- *uint32_t DSI_LPCmdTypeDef::LPDcsLongWrite*
DCS Long Write Transmission This parameter can be any value of *DSI_LP_LPDCsLongWrite*
- *uint32_t DSI_LPCmdTypeDef::LPMaxReadPacket*
Maximum Read Packet Size Transmission This parameter can be any value of *DSI_LP_LPMaxReadPacket*
- *uint32_t DSI_LPCmdTypeDef::AcknowledgeRequest*
Acknowledge Request Enable This parameter can be any value of *DSI_AcknowledgeRequest*

19.2.6 DSI_PHY_TimerTypeDef

Data Fields

-
- *uint32_t ClockLaneHS2LPTime*
 - *uint32_t ClockLaneLP2HSTime*
 - *uint32_t DataLaneHS2LPTime*
 - *uint32_t DataLaneLP2HSTime*
 - *uint32_t DataLaneMaxReadTime*
 - *uint32_t StopWaitTime*

Field Documentation

- ***uint32_t DSI_PHY_TimerTypeDef::ClockLaneHS2LPTime***
The maximum time that the D-PHY clock lane takes to go from high-speed to low-power transmission
- ***uint32_t DSI_PHY_TimerTypeDef::ClockLaneLP2HSTime***
The maximum time that the D-PHY clock lane takes to go from low-power to high-speed transmission
- ***uint32_t DSI_PHY_TimerTypeDef::DataLaneHS2LPTime***
The maximum time that the D-PHY data lanes takes to go from high-speed to low-power transmission
- ***uint32_t DSI_PHY_TimerTypeDef::DataLaneLP2HSTime***
The maximum time that the D-PHY data lanes takes to go from low-power to high-speed transmission
- ***uint32_t DSI_PHY_TimerTypeDef::DataLaneMaxReadTime***
The maximum time required to perform a read command
- ***uint32_t DSI_PHY_TimerTypeDef::StopWaitTime***
The minimum wait period to request a High-Speed transmission after the Stop state

19.2.7 DSI_HOST_TimeoutTypeDef

Data Fields

- *uint32_t TimeoutCkdiv*
- *uint32_t HighSpeedTransmissionTimeout*
- *uint32_t LowPowerReceptionTimeout*
- *uint32_t HighSpeedReadTimeout*
- *uint32_t LowPowerReadTimeout*
- *uint32_t HighSpeedWriteTimeout*
- *uint32_t HighSpeedWritePrespMode*
- *uint32_t LowPowerWriteTimeout*
- *uint32_t BTATimeout*

Field Documentation

- ***uint32_t DSI_HOST_TimeoutTypeDef::TimeoutCkdiv***
Time-out clock division
- ***uint32_t DSI_HOST_TimeoutTypeDef::HighSpeedTransmissionTimeout***
High-speed transmission time-out
- ***uint32_t DSI_HOST_TimeoutTypeDef::LowPowerReceptionTimeout***
Low-power reception time-out
- ***uint32_t DSI_HOST_TimeoutTypeDef::HighSpeedReadTimeout***
High-speed read time-out

- *uint32_t DSI_HOST_TimeoutTypeDef::LowPowerReadTimeout*
Low-power read time-out
- *uint32_t DSI_HOST_TimeoutTypeDef::HighSpeedWriteTimeout*
High-speed write time-out
- *uint32_t DSI_HOST_TimeoutTypeDef::HighSpeedWritePrespMode*
High-speed write presp mode This parameter can be any value of [DSI_HS_PrespMode](#)
- *uint32_t DSI_HOST_TimeoutTypeDef::LowPowerWriteTimeout*
Low-speed write time-out
- *uint32_t DSI_HOST_TimeoutTypeDef::BTATimeout*
BTA time-out

19.2.8 DSI_HandleTypeDef

Data Fields

- *DSI_TypeDef * Instance*
- *DSI_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_DSI_StateTypeDef State*
- *__IO uint32_t ErrorCode*
- *uint32_t ErrorMsk*

Field Documentation

- ***DSI_TypeDef* DSI_HandleTypeDef::Instance***
Register base address
- ***DSI_InitTypeDef DSI_HandleTypeDef::Init***
DSI required parameters
- ***HAL_LockTypeDef DSI_HandleTypeDef::Lock***
DSI peripheral status
- ***__IO HAL_DSI_StateTypeDef DSI_HandleTypeDef::State***
DSI communication state
- ***__IO uint32_t DSI_HandleTypeDef::ErrorCode***
DSI Error code
- ***uint32_t DSI_HandleTypeDef::ErrorMsk***
DSI Error monitoring mask

19.3 DSI Firmware driver API description

19.3.1 Initialization and Configuration functions

This section provides functions allowing to:

- Initialize and configure the DSI
- De-initialize the DSI

This section contains the following APIs:

- [*HAL_DSI_Init\(\)*](#)
- [*HAL_DSI_DeInit\(\)*](#)

- `HAL_DSI_GetError()`
- `HAL_DSI_ConfigErrorMonitor()`
- `HAL_DSI_MspInit()`
- `HAL_DSI_MspDeInit()`

19.3.2 IO operation functions

This section provides function allowing to:

- Handle DSI interrupt request

This section contains the following APIs:

- `HAL_DSI_IRQHandler()`
- `HAL_DSI_TearingEffectCallback()`
- `HAL_DSI_EndOfRefreshCallback()`
- `HAL_DSI_ErrorCallback()`

19.3.3 Peripheral Control functions

This section provides functions allowing to:

-
-
-

This section contains the following APIs:

- `HAL_DSI_SetGenericVCID()`
- `HAL_DSI_ConfigVideoMode()`
- `HAL_DSI_ConfigAdaptedCommandMode()`
- `HAL_DSI_ConfigCommand()`
- `HAL_DSI_ConfigFlowControl()`
- `HAL_DSI_ConfigPhyTimer()`
- `HAL_DSI_ConfigHostTimeouts()`
- `HAL_DSI_Start()`
- `HAL_DSI_Stop()`
- `HAL_DSI_Refresh()`
- `HAL_DSI_ColorMode()`
- `HAL_DSI_Shutdown()`
- `HAL_DSI_ShortWrite()`
- `HAL_DSI_LongWrite()`
- `HAL_DSI_Read()`
- `HAL_DSI_EnterULPMDData()`
- `HAL_DSI_ExitULPMDData()`
- `HAL_DSI_EnterULPM()`
- `HAL_DSI_ExitULPM()`
- `HAL_DSI_PatternGeneratorStart()`
- `HAL_DSI_PatternGeneratorStop()`
- `HAL_DSI_SetSlewRateAndDelayTuning()`
- `HAL_DSI_SetLowPowerRXFilter()`
- `HAL_DSI_SetSDD()`
- `HAL_DSI_SetLanePinsConfiguration()`
- `HAL_DSI_SetPHYTimings()`
- `HAL_DSI_ForceTXStopMode()`
- `HAL_DSI_ForceRXLowPower()`
- `HAL_DSI_ForceDataLanesInRX()`

- [*HAL_DSI_SetPullDown\(\)*](#)
- [*HAL_DSI_SetContentionDetectionOff\(\)*](#)

19.3.4 Peripheral State and Errors functions

This subsection provides functions allowing to

- Check the DSI state.
- Get error code.

This section contains the following APIs:

- [*HAL_DSI_GetState\(\)*](#)

19.3.5 HAL_DSI_Init

Function Name	HAL_StatusTypeDef HAL_DSI_Init (DSI_HandleTypeDef * hdsi, DSI_PLLInitTypeDef * PLLInit)
Function Description	Initializes the DSI according to the specified parameters in the DSI_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • PLLInit: pointer to a DSI_PLLInitTypeDef structure that contains the PLL Clock structure definition for the DSI.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.6 HAL_DSI_DeInit

Function Name	HAL_StatusTypeDef HAL_DSI_DeInit (DSI_HandleTypeDef * hdsi)
Function Description	De-initializes the DSI peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.7 HAL_DSI_GetError

Function Name	uint32_t HAL_DSI_GetError (DSI_HandleTypeDef * hdsi)
Function Description	Return the DSI error code.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> • DSI Error Code

19.3.8 HAL_DSI_ConfigErrorMonitor

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigErrorMonitor (DSI_HandleTypeDef * hdsi, uint32_t ActiveErrors)
Function Description	Enable the error monitor flags.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

- **ActiveErrors:** indicates which error interrupts will be enabled. This parameter can be any combination of DSI Error Data Type.

Return values • HAL status

19.3.9 HAL_DSI_MspInit

Function Name **void HAL_DSI_MspInit (DSI_HandleTypeDef * hdsi)**

Function Description Initializes the DSI MSP.

Parameters • **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values • None

19.3.10 HAL_DSI_MspDelInit

Function Name **void HAL_DSI_MspDelInit (DSI_HandleTypeDef * hdsi)**

Function Description De-initializes the DSI MSP.

Parameters • **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values • None

19.3.11 HAL_DSI_IRQHandler

Function Name **void HAL_DSI_IRQHandler (DSI_HandleTypeDef * hdsi)**

Function Description Handles DSI interrupt request.

Parameters • **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values • HAL status

19.3.12 HAL_DSI_TearingEffectCallback

Function Name **void HAL_DSI_TearingEffectCallback (DSI_HandleTypeDef * hdsi)**

Function Description Tearing Effect DSI callback.

Parameters • **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values • None

19.3.13 HAL_DSI_EndOfRefreshCallback

Function Name **void HAL_DSI_EndOfRefreshCallback (DSI_HandleTypeDef * hdsi)**

Function Description End of Refresh DSI callback.

Parameters • **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values	<ul style="list-style-type: none"> None
---------------	--

19.3.14 HAL_DSI_ErrorCallback

Function Name	void HAL_DSI_ErrorCallback (DSI_HandleTypeDef * hdsi)
Function Description	Operation Error DSI callback.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> None

19.3.15 HAL_DSI_SetGenericVCID

Function Name	HAL_StatusTypeDef HAL_DSI_SetGenericVCID (DSI_HandleTypeDef * hdsi, uint32_t VirtualChannelID)
Function Description	Configure the Generic interface read-back Virtual Channel ID.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. VirtualChannelID: Virtual channel ID
Return values	<ul style="list-style-type: none"> HAL status

19.3.16 HAL_DSI_ConfigVideoMode

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigVideoMode (DSI_HandleTypeDef * hdsi, DSI_VidCfgTypeDef * VidCfg)
Function Description	Select video mode and configure the corresponding parameters.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. VidCfg: pointer to a DSI_VidCfgTypeDef structure that contains the DSI video mode configuration parameters
Return values	<ul style="list-style-type: none"> HAL status

19.3.17 HAL_DSI_ConfigAdaptedCommandMode

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigAdaptedCommandMode (DSI_HandleTypeDef * hdsi, DSI_CmdCfgTypeDef * CmdCfg)
Function Description	Select adapted command mode and configure the corresponding parameters.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. CmdCfg: pointer to a DSI_CmdCfgTypeDef structure that contains the DSI command mode configuration parameters
Return values	<ul style="list-style-type: none"> HAL status

19.3.18 HAL_DSI_ConfigCommand

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigCommand (DSI_HandleTypeDef * hdsi, DSI_LPCmdTypeDef * LPCmd)
---------------	---

Function Description	Configure command transmission mode: High-speed or Low-power and enable/disable acknowledge request after packet transmission.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • LPCmd: pointer to a DSI_LPCmdTypeDef structure that contains the DSI command transmission mode configuration parameters
Return values	<ul style="list-style-type: none"> • HAL status

19.3.19 HAL_DSI_ConfigFlowControl

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigFlowControl (DSI_HandleTypeDef * hdsi, uint32_t FlowControl)
Function Description	Configure the flow control parameters.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • FlowControl: flow control feature(s) to be enabled. This parameter can be any combination of DSI Flow Control.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.20 HAL_DSI_ConfigPhyTimer

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigPhyTimer (DSI_HandleTypeDef * hdsi, DSI_PHY_TimerTypeDef * PhyTimings)
Function Description	Configure the DSI PHY timer parameters.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • PhyTimings: DSI_PHY_TimerTypeDef structure that contains the DSI PHY timing parameters
Return values	<ul style="list-style-type: none"> • HAL status

19.3.21 HAL_DSI_ConfigHostTimeouts

Function Name	HAL_StatusTypeDef HAL_DSI_ConfigHostTimeouts (DSI_HandleTypeDef * hdsi, DSI_HOST_TimeoutTypeDef * HostTimeouts)
Function Description	Configure the DSI HOST timeout parameters.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • HostTimeouts: DSI_HOST_TimeoutTypeDef structure that contains the DSI host timeout parameters
Return values	<ul style="list-style-type: none"> • HAL status

19.3.22 HAL_DSI_Start

Function Name	HAL_StatusTypeDef HAL_DSI_Start (DSI_HandleTypeDef *
---------------	---

hdsi)

Function Description	Start the DSI module.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.23 HAL_DSI_Stop

Function Name	HAL_StatusTypeDef HAL_DSI_Stop (DSI_HandleTypeDef * hdsi)
Function Description	Stop the DSI module.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.24 HAL_DSI_Refresh

Function Name	HAL_StatusTypeDef HAL_DSI_Refresh (DSI_HandleTypeDef * hdsi)
Function Description	Refresh the display in command mode.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.25 HAL_DSI_ColorMode

Function Name	HAL_StatusTypeDef HAL_DSI_ColorMode (DSI_HandleTypeDef * hdsi, uint32_t ColorMode)
Function Description	Controls the display color mode in Video mode.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • ColorMode: Color mode (full or 8-colors). This parameter can be any value of DSI Color Mode
Return values	<ul style="list-style-type: none"> • HAL status

19.3.26 HAL_DSI_Shutdown

Function Name	HAL_StatusTypeDef HAL_DSI_Shutdown (DSI_HandleTypeDef * hdsi, uint32_t Shutdown)
Function Description	Control the display shutdown in Video mode.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • Shutdown: Shut-down (Display-ON or Display-OFF). This parameter can be any value of DSI ShutDown
Return values	<ul style="list-style-type: none"> • HAL status

19.3.27 HAL_DSI_ShortWrite

Function Name	<code>HAL_StatusTypeDef HAL_DSI_ShortWrite (DSI_HandleTypeDef * hdsi, uint32_t ChannelID, uint32_t Mode, uint32_t Param1, uint32_t Param2)</code>
Function Description	DCS or Generic short write command.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • ChannelID: Virtual channel ID. • Mode: DSI short packet data type. This parameter can be any value of DSI SHORT WRITE PKT Data Type. • Param1: DSC command or first generic parameter. This parameter can be any value of DSI DCS Command or a generic command code. • Param2: DSC parameter or second generic parameter.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.28 HAL_DSI_LongWrite

Function Name	<code>HAL_StatusTypeDef HAL_DSI_LongWrite (DSI_HandleTypeDef * hdsi, uint32_t ChannelID, uint32_t Mode, uint32_t Nbparams, uint32_t Param1, uint8_t * ParametersTable)</code>
Function Description	DCS or Generic long write command.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • ChannelID: Virtual channel ID. • Mode: DSI long packet data type. This parameter can be any value of DSI LONG WRITE PKT Data Type. • NbParams: Number of parameters. • Param1: DSC command or first generic parameter. This parameter can be any value of DSI DCS Command or a generic command code • ParametersTable: Pointer to parameter values table.
Return values	<ul style="list-style-type: none"> • HAL status

19.3.29 HAL_DSI_Read

Function Name	<code>HAL_StatusTypeDef HAL_DSI_Read (DSI_HandleTypeDef * hdsi, uint32_t ChannelNbr, uint8_t * Array, uint32_t Size, uint32_t Mode, uint32_t DCSCmd, uint8_t * ParametersTable)</code>
Function Description	Read command (DCS or generic)
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • ChannelNbr: Virtual channel ID • Array: pointer to a buffer to store the payload of a read back operation. • Size: Data size to be read (in byte). • Mode: DSI read packet data type. This parameter can be any value of DSI SHORT READ PKT Data Type.

- **DCSCmd:** DCS get/read command.
- **ParametersTable:** Pointer to parameter values table.
- HAL status

Return values

19.3.30 HAL_DSI_EnterULPMDATA

Function Name

**HAL_StatusTypeDef HAL_DSI_EnterULPMDATA
(DSI_HandleTypeDef * hdsi)**

Function Description

Enter the ULPM (Ultra Low Power Mode) with the D-PHY PLL running (only data lanes are in ULPM)

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values

- HAL status

19.3.31 HAL_DSI_ExitULPMDATA

Function Name

**HAL_StatusTypeDef HAL_DSI_ExitULPMDATA
(DSI_HandleTypeDef * hdsi)**

Function Description

Exit the ULPM (Ultra Low Power Mode) with the D-PHY PLL running (only data lanes are in ULPM)

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values

- HAL status

19.3.32 HAL_DSI_EnterULPM

Function Name

**HAL_StatusTypeDef HAL_DSI_EnterULPM
(DSI_HandleTypeDef * hdsi)**

Function Description

Enter the ULPM (Ultra Low Power Mode) with the D-PHY PLL turned off (both data and clock lanes are in ULPM)

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values

- HAL status

19.3.33 HAL_DSI_ExitULPM

Function Name

**HAL_StatusTypeDef HAL_DSI_ExitULPM (DSI_HandleTypeDef
* hdsi)**

Function Description

Exit the ULPM (Ultra Low Power Mode) with the D-PHY PLL turned off (both data and clock lanes are in ULPM)

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values

- HAL status

19.3.34 HAL_DSI_PatternGeneratorStart

Function Name

**HAL_StatusTypeDef HAL_DSI_PatternGeneratorStart
(DSI_HandleTypeDef * hdsi, uint32_t Mode, uint32_t**

Orientation)

Function Description	Start test pattern generation.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • Mode: Pattern generator mode This parameter can be one of the following values: 0 : Color bars (horizontal or vertical) 1 : BER pattern (vertical only) • Orientation: Pattern generator orientation This parameter can be one of the following values: 0 : Vertical color bars 1 : Horizontal color bars
Return values	<ul style="list-style-type: none"> • HAL status

19.3.35 HAL_DSI_PatternGeneratorStop

Function Name	HAL_StatusTypeDef HAL_DSI_PatternGeneratorStop (DSI_HandleTypeDef * hdsi)
Function Description	Stop test pattern generation.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

19.3.36 HAL_DSI_SetSlewRateAndDelayTuning

Function Name	HAL_StatusTypeDef HAL_DSI_SetSlewRateAndDelayTuning (DSI_HandleTypeDef * hdsi, uint32_t CommDelay, uint32_t Lane, uint32_t Value)
Function Description	Set Slew-Rate And Delay Tuning.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • CommDelay: Communication delay to be adjusted. This parameter can be any value of DSI Communication Delay • Lane: select between clock or data lanes. This parameter can be any value of DSI Lane Group • Value: Custom value of the slew-rate or delay
Return values	<ul style="list-style-type: none"> • HAL status

19.3.37 HAL_DSI_SetLowPowerRXFilter

Function Name	HAL_StatusTypeDef HAL_DSI_SetLowPowerRXFilter (DSI_HandleTypeDef * hdsi, uint32_t Frequency)
Function Description	Low-Power Reception Filter Tuning.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. • Frequency: cutoff frequency of low-pass filter at the input of LPRX
Return values	<ul style="list-style-type: none"> • HAL status

19.3.38 HAL_DSI_SetSDD

Function Name	HAL_StatusTypeDef HAL_DSI_SetSDD (DSI_HandleTypeDef * hdsi, FunctionalState State)
Function Description	Activate an additional current path on all lanes to meet the SDDTx parameter defined in the MIPI D-PHY specification.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. State: ENABLE or DISABLE
Return values	<ul style="list-style-type: none"> HAL status

19.3.39 HAL_DSI_SetLanePinsConfiguration

Function Name	HAL_StatusTypeDef HAL_DSI_SetLanePinsConfiguration (DSI_HandleTypeDef * hdsi, uint32_t CustomLane, uint32_t Lane, FunctionalState State)
Function Description	Custom lane pins configuration.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. CustomLane: Function to be applied on selected lane. This parameter can be any value of DSI CustomLane Lane: select between clock or data lane 0 or data lane 1. This parameter can be any value of DSI Lane Select State: ENABLE or DISABLE
Return values	<ul style="list-style-type: none"> HAL status

19.3.40 HAL_DSI_SetPHYTimings

Function Name	HAL_StatusTypeDef HAL_DSI_SetPHYTimings (DSI_HandleTypeDef * hdsi, uint32_t Timing, FunctionalState State, uint32_t Value)
Function Description	Set custom timing for the PHY.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. Timing: PHY timing to be adjusted. This parameter can be any value of DSI PHY Timing State: ENABLE or DISABLE Value: Custom value of the timing
Return values	<ul style="list-style-type: none"> HAL status

19.3.41 HAL_DSI_ForceTXStopMode

Function Name	HAL_StatusTypeDef HAL_DSI_ForceTXStopMode (DSI_HandleTypeDef * hdsi, uint32_t Lane, FunctionalState State)
Function Description	Force the Clock/Data Lane in TX Stop Mode.
Parameters	<ul style="list-style-type: none"> hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI. Lane: select between clock or data lanes. This parameter can be any value of DSI Lane Group

- **State:** ENABLE or DISABLE

Return values • HAL status

19.3.42 HAL_DSI_ForceRXLowPower

Function Name **HAL_StatusTypeDef HAL_DSI_ForceRXLowPower
(DSI_HandleTypeDef * hdsi, FunctionalState State)**

Function Description Forces LP Receiver in Low-Power Mode.

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
- **State:** ENABLE or DISABLE

Return values • HAL status

19.3.43 HAL_DSI_ForceDataLanesInRX

Function Name **HAL_StatusTypeDef HAL_DSI_ForceDataLanesInRX
(DSI_HandleTypeDef * hdsi, FunctionalState State)**

Function Description Force Data Lanes in RX Mode after a BTA.

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
- **State:** ENABLE or DISABLE

Return values • HAL status

19.3.44 HAL_DSI_SetPullDown

Function Name **HAL_StatusTypeDef HAL_DSI_SetPullDown
(DSI_HandleTypeDef * hdsi, FunctionalState State)**

Function Description Enable a pull-down on the lanes to prevent from floating states when unused.

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
- **State:** ENABLE or DISABLE

Return values • HAL status

19.3.45 HAL_DSI_SetContentionDetectionOff

Function Name **HAL_StatusTypeDef HAL_DSI_SetContentionDetectionOff
(DSI_HandleTypeDef * hdsi, FunctionalState State)**

Function Description Switch off the contention detection on data lanes.

Parameters

- **hdsi:** pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
- **State:** ENABLE or DISABLE

Return values • HAL status

19.3.46 HAL_DSI_GetState

Function Name **HAL_DSI_StateTypeDef HAL_DSI_GetState**

(DSI_HandleTypeDef * hdsi)

Function Description	Return the DSI state.
Parameters	<ul style="list-style-type: none"> • hdsi: pointer to a DSI_HandleTypeDef structure that contains the configuration information for the DSI.
Return values	<ul style="list-style-type: none"> • HAL state

19.4 DSI Firmware driver defines

19.4.1 DSI

DSI Acknowledge Request

DSI_ACKNOWLEDGE_DISABLE

DSI_ACKNOWLEDGE_ENABLE

DSI Automatic Refresh

DSI_AR_DISABLE

DSI_AR_ENABLE

DSI Automatic Clk Lane Control

DSI_AUTO_CLK_LANE_CTRL_DISABLE

DSI_AUTO_CLK_LANE_CTRL_ENABLE

DSI Color Coding

DSI_RGB565 The values 0x00000001 and 0x00000002 can also be used for the RGB565 color mode configuration

DSI_RGB666 The value 0x00000004 can also be used for the RGB666 color mode configuration

DSI_RGB888

DSI Color Mode

DSI_COLOR_MODE_FULL

DSI_COLOR_MODE_EIGHT

DSI Communication Delay

DSI_SLEW_RATE_HSTX

DSI_SLEW_RATE_LPTX

DSI_HS_DELAY

DSI CustomLane

DSI_SWAP_LANE_PINS

DSI_INVERT_HS_SIGNAL

DSI DATA ENABLE Polarity

DSI_DATA_ENABLE_ACTIVE_HIGH

DSI_DATA_ENABLE_ACTIVE_LOW

DSI DCS Command

DSI_ENTER_IDLE_MODE
DSI_ENTER_INVERT_MODE
DSI_ENTER_NORMAL_MODE
DSI_ENTER_PARTIAL_MODE
DSI_ENTER_SLEEP_MODE
DSI_EXIT_IDLE_MODE
DSI_EXIT_INVERT_MODE
DSI_EXIT_SLEEP_MODE
DSI_GET_3D_CONTROL
DSI_GET_ADDRESS_MODE
DSI_GET_BLUE_CHANNEL
DSI_GET_DIAGNOSTIC_RESULT
DSI_GET_DISPLAY_MODE
DSI_GET_GREEN_CHANNEL
DSI_GET_PIXEL_FORMAT
DSI_GET_POWER_MODE
DSI_GET_RED_CHANNEL
DSI_GET_SCANLINE
DSI_GET_SIGNAL_MODE
DSI_NOP
DSI_READ_DDB_CONTINUE
DSI_READ_DDB_START
DSI_READ_MEMORY_CONTINUE
DSI_READ_MEMORY_START
DSI_SET_3D_CONTROL
DSI_SET_ADDRESS_MODE
DSI_SET_COLUMN_ADDRESS
DSI_SET_DISPLAY_OFF
DSI_SET_DISPLAY_ON
DSI_SET_GAMMA_CURVE
DSI_SET_PAGE_ADDRESS
DSI_SET_PARTIAL_COLUMNS
DSI_SET_PARTIAL_ROWS
DSI_SET_PIXEL_FORMAT
DSI_SET_SCROLL_AREA
DSI_SET_SCROLL_START

DSI_SET_TEAR_OFF
DSI_SET_TEAR_ON
DSI_SET_TEAR_SCANLINE
DSI_SET_VSYNC_TIMING
DSI_SOFT_RESET
DSI_WRITE_LUT
DSI_WRITE_MEMORY_CONTINUE
DSI_WRITE_MEMORY_START

DSI Error Data Type

HAL_DSI_ERROR_NONE	
HAL_DSI_ERROR_ACK	acknowledge errors
HAL_DSI_ERROR_PHY	PHY related errors
HAL_DSI_ERROR_TX	transmission error
HAL_DSI_ERROR_RX	reception error
HAL_DSI_ERROR_ECC	ECC errors
HAL_DSI_ERROR_CRC	CRC error
HAL_DSI_ERROR_PSE	Packet Size error
HAL_DSI_ERROR_EOT	End Of Transmission error
HAL_DSI_ERROR_OVF	FIFO overflow error
HAL_DSI_ERROR_GEN	Generic FIFO related errors

DSI FBTA Acknowledge

DSI_FBTAA_DISABLE
DSI_FBTAA_ENABLE

DSI Flags

DSI_FLAG_TE
DSI_FLAG_ER
DSI_FLAG_BUSY
DSI_FLAG_PLLS
DSI_FLAG_PLLL
DSI_FLAG_PLLU
DSI_FLAG_RRS
DSI_FLAG_RR

DSI Flow Control

DSI_FLOW_CONTROL_CRC_RX
DSI_FLOW_CONTROL_ECC_RX
DSI_FLOW_CONTROL_BTA

DSI_FLOW_CONTROL_EOTP_RX
DSI_FLOW_CONTROL_EOTP_TX
DSI_FLOW_CONTROL_ALL
DSI HSYNC Polarity
DSI_HSYNC_ACTIVE_HIGH
DSI_HSYNC_ACTIVE_LOW
DSI HS Presp Mode
DSI_HS_PM_DISABLE
DSI_HS_PM_ENABLE
DSI Interrupts
DSI_IT_TE
DSI_IT_ER
DSI_IT_PLLL
DSI_IT_PLLU
DSI_IT_RR
DSI Lane Group
DSI_CLOCK_LANE
DSI_CLOCK_LANE
DSI_DATA_LANES
DSI Lane Select
DSI_DATA_LANE0
DSI_DATA_LANE1
DSI LONG WRITE PKT Data Type
DSI_DCS_LONG_PKT_WRITE DCS long write
DSI_GEN_LONG_PKT_WRITE Generic long write
DSI Loosely Packed
DSI_LOOSELY_PACKED_ENABLE
DSI_LOOSELY_PACKED_DISABLE
DSI LP Command
DSI_LP_COMMAND_DISABLE
DSI_LP_COMMAND_ENABLE
DSI LP HBP
DSI_LP_HBP_DISABLE
DSI_LP_HBP_ENABLE
DSI LP HFP
DSI_LP_HFP_DISABLE

DSI_LP_HFP_ENABLE
DSI LP LPDcs Long Write
DSI_LP_DLW_DISABLE
DSI_LP_DLW_ENABLE
DSI LP LPDcs Short Read NoP
DSI_LP_DSR0P_DISABLE
DSI_LP_DSR0P_ENABLE
DSI LP LPDcs Short Write NoP
DSI_LP_DSW0P_DISABLE
DSI_LP_DSW0P_ENABLE
DSI LP LPDcs Short Write OneP
DSI_LP_DSW1P_DISABLE
DSI_LP_DSW1P_ENABLE
DSI LP LPGen LongWrite
DSI_LP_GLW_DISABLE
DSI_LP_GLW_ENABLE
DSI LP LPGen Short Read NoP
DSI_LP_GSR0P_DISABLE
DSI_LP_GSR0P_ENABLE
DSI LP LPGen Short Read OneP
DSI_LP_GSR1P_DISABLE
DSI_LP_GSR1P_ENABLE
DSI LP LPGen Short Read TwoP
DSI_LP_GSR2P_DISABLE
DSI_LP_GSR2P_ENABLE
DSI LP LPGen Short Write NoP
DSI_LP_GSW0P_DISABLE
DSI_LP_GSW0P_ENABLE
DSI LP LPGen Short Write OneP
DSI_LP_GSW1P_DISABLE
DSI_LP_GSW1P_ENABLE
DSI LP LPGen Short Write TwoP
DSI_LP_GSW2P_DISABLE
DSI_LP_GSW2P_ENABLE
DSI LP LPMax Read Packet
DSI_LP_MRDP_DISABLE

DSI_LP_MRDP_ENABLE
DSI LP VACT
DSI_LP_VACT_DISABLE
DSI_LP_VACT_ENABLE
DSI LP VBP
DSI_LP_VBP_DISABLE
DSI_LP_VBP_ENABLE
DSI LP VFP
DSI_LP_VFP_DISABLE
DSI_LP_VFP_ENABLE
DSI LP VSYNC
DSI_LP_VSYNC_DISABLE
DSI_LP_VSYNC_ENABLE
DSI Number Of Lanes
DSI_ONE_DATA_LANE
DSI_TWO_DATA_LANES
DSI PHY Timing
DSI_TCLK_POST
DSI_TLPX_CLK
DSI_THS_EXIT
DSI_TLPX_DATA
DSI_THS_ZERO
DSI_THS_TRAIL
DSI_THS_PREPARE
DSI_TCLK_ZERO
DSI_TCLK_PREPARE
DSI PLL IDF
DSI_PLL_IN_DIV1
DSI_PLL_IN_DIV2
DSI_PLL_IN_DIV3
DSI_PLL_IN_DIV4
DSI_PLL_IN_DIV5
DSI_PLL_IN_DIV6
DSI_PLL_IN_DIV7
DSI PLL ODF
DSI_PLL_OUT_DIV1

DSI_PLL_OUT_DIV2
DSI_PLL_OUT_DIV4
DSI_PLL_OUT_DIV8
DSI Private Constants
DSI_TIMEOUT_VALUE
DSI_ERROR_ACK_MASK
DSI_ERROR_PHY_MASK
DSI_ERROR_TX_MASK
DSI_ERROR_RX_MASK
DSI_ERROR_ECC_MASK
DSI_ERROR_CRC_MASK
DSI_ERROR_PSE_MASK
DSI_ERROR_EOT_MASK
DSI_ERROR_OVF_MASK
DSI_ERROR_GEN_MASK
DSI_MAX_RETURN_PKT_SIZE Maximum return packet configuration
DSI Private Macros
IS_DSI_PLL_NDIV
IS_DSI_PLL_IDF
IS_DSI_PLL_ODF
IS_DSI_AUTO_CLKLANE_CONTROL
IS_DSI_NUMBER_OF_LANES
IS_DSI_FLOW_CONTROL
IS_DSI_COLOR_CODING
IS_DSI_LOOSELY_PACKED
IS_DSI_DE_POLARITY
IS_DSI_VSYNC_POLARITY
IS_DSI_HSYNC_POLARITY
IS_DSI_VIDEO_MODE_TYPE
IS_DSI_COLOR_MODE
IS_DSI_SHUT_DOWN
IS_DSI_LP_COMMAND
IS_DSI_LP_HFP
IS_DSI_LP_HBP
IS_DSI_LP_VACTIVE
IS_DSI_LP_VFP

IS_DSI_LP_VBP
 IS_DSI_LP_VSYNC
 IS_DSI_FBTAA
 IS_DSI_TE_SOURCE
 IS_DSI_TE_POLARITY
 IS_DSI_AUTOMATIC_REFRESH
 IS_DSI_VS_POLARITY
 IS_DSI_TE_ACK_REQUEST
 IS_DSI_ACK_REQUEST
 IS_DSI_LP_GSW0P
 IS_DSI_LP_GSW1P
 IS_DSI_LP_GSW2P
 IS_DSI_LP_GSR0P
 IS_DSI_LP_GSR1P
 IS_DSI_LP_GSR2P
 IS_DSI_LP_GLW
 IS_DSI_LP_DSW0P
 IS_DSI_LP_DSW1P
 IS_DSI_LP_DSR0P
 IS_DSI_LP_DLW
 IS_DSI_LP_MRDP
 IS_DSI_SHORT_WRITE_PACKET_TYPE
 IS_DSI_LONG_WRITE_PACKET_TYPE
 IS_DSI_READ_PACKET_TYPE
 IS_DSI_COMMUNICATION_DELAY
 IS_DSI_LANE_GROUP
 IS_DSI_CUSTOM_LANE
 IS_DSI_LANE
 IS_DSI_PHY_TIMING

DSI SHORT READ PKT Data Type

DSI_DCS_SHORT_PKT_READ	DCS short read
DSI_GEN_SHORT_PKT_READ_P0	Generic short read, no parameters
DSI_GEN_SHORT_PKT_READ_P1	Generic short read, one parameter
DSI_GEN_SHORT_PKT_READ_P2	Generic short read, two parameters

DSI SHORT WRITE PKT Data Type

DSI_DCS_SHORT_PKT_WRITE_P0	DCS short write, no parameters
----------------------------	--------------------------------

DSI_DCS_SHORT_PKT_WRITE_P1	DCS short write, one parameter
DSI_GEN_SHORT_PKT_WRITE_P0	Generic short write, no parameters
DSI_GEN_SHORT_PKT_WRITE_P1	Generic short write, one parameter
DSI_GEN_SHORT_PKT_WRITE_P2	Generic short write, two parameters
<i>DSI ShutDown</i>	
DSI_DISPLAY_ON	
DSI_DISPLAY_OFF	
<i>DSI Tearing Effect Polarity</i>	
DSI_TE_RISING_EDGE	
DSI_TE_FALLING_EDGE	
<i>DSI Tearing Effect Source</i>	
DSI_TE_DSILINK	
DSI_TE_EXTERNAL	
<i>DSI TE Acknowledge Request</i>	
DSI_TE_ACKNOWLEDGE_DISABLE	
DSI_TE_ACKNOWLEDGE_ENABLE	
<i>DSI Video Mode Type</i>	
DSI_VID_MODE_NB_PULSES	
DSI_VID_MODE_NB_EVENTS	
DSI_VID_MODE_BURST	
<i>DSI VSYNC Polarity</i>	
DSI_VSYNC_ACTIVE_HIGH	
DSI_VSYNC_ACTIVE_LOW	

20 HAL ETH Generic Driver

20.1 HAL ETH Generic Driver

20.2 ETH Firmware driver registers structures

20.2.1 ETH_InitTypeDef

Data Fields

- *uint32_t AutoNegotiation*
- *uint32_t Speed*
- *uint32_t DuplexMode*
- *uint16_t PhyAddress*
- *uint8_t * MACAddr*
- *uint32_t RxMode*
- *uint32_t ChecksumMode*
- *uint32_t MedialInterface*

Field Documentation

- ***uint32_t ETH_InitTypeDef::AutoNegotiation***
Selects or not the AutoNegotiation mode for the external PHY. The AutoNegotiation allows an automatic setting of the Speed (10/100Mbps) and the mode (half/full-duplex). This parameter can be a value of [*ETH_AutoNegotiation*](#)
- ***uint32_t ETH_InitTypeDef::Speed***
Sets the Ethernet speed: 10/100 Mbps. This parameter can be a value of [*ETH_Speed*](#)
- ***uint32_t ETH_InitTypeDef::DuplexMode***
Selects the MAC duplex mode: Half-Duplex or Full-Duplex mode. This parameter can be a value of [*ETH_Duplex_Mode*](#)
- ***uint16_t ETH_InitTypeDef::PhyAddress***
Ethernet PHY address. This parameter must be a number between Min_Data = 0 and Max_Data = 32
- ***uint8_t* ETH_InitTypeDef::MACAddr***
MAC Address of used Hardware: must be pointer on an array of 6 bytes
- ***uint32_t ETH_InitTypeDef::RxMode***
Selects the Ethernet Rx mode: Polling mode, Interrupt mode. This parameter can be a value of [*ETH_Rx_Mode*](#)
- ***uint32_t ETH_InitTypeDef::ChecksumMode***
Selects if the checksum is check by hardware or by software. This parameter can be a value of [*ETH_Checksum_Mode*](#)
- ***uint32_t ETH_InitTypeDef::MedialInterface***
Selects the media-independent interface or the reduced media-independent interface. This parameter can be a value of [*ETH_Media_Interface*](#)

20.2.2 ETH_MACInitTypeDef

Data Fields

- *uint32_t Watchdog*
- *uint32_t Jabber*
- *uint32_t InterFrameGap*
- *uint32_t CarrierSense*
- *uint32_t ReceiveOwn*
- *uint32_t LoopbackMode*
- *uint32_t ChecksumOffload*
- *uint32_t RetryTransmission*
- *uint32_t AutomaticPadCRCStrip*
- *uint32_t BackOffLimit*
- *uint32_t DeferralCheck*
- *uint32_t ReceiveAll*
- *uint32_t SourceAddrFilter*
- *uint32_t PassControlFrames*
- *uint32_t BroadcastFramesReception*
- *uint32_t DestinationAddrFilter*
- *uint32_t PromiscuousMode*
- *uint32_t MulticastFramesFilter*
- *uint32_t UnicastFramesFilter*
- *uint32_t HashTableHigh*
- *uint32_t HashTableLow*
- *uint32_t PauseTime*
- *uint32_t ZeroQuantaPause*
- *uint32_t PauseLowThreshold*
- *uint32_t UnicastPauseFrameDetect*
- *uint32_t ReceiveFlowControl*
- *uint32_t TransmitFlowControl*
- *uint32_t VLANTagComparison*
- *uint32_t VLANTagIdentifier*

Field Documentation

- ***uint32_t ETH_MACInitTypeDef::Watchdog***
Selects or not the Watchdog timer When enabled, the MAC allows no more than 2048 bytes to be received. When disabled, the MAC can receive up to 16384 bytes. This parameter can be a value of [*ETH_Watchdog*](#)
- ***uint32_t ETH_MACInitTypeDef::Jabber***
Selects or not Jabber timer When enabled, the MAC allows no more than 2048 bytes to be sent. When disabled, the MAC can send up to 16384 bytes. This parameter can be a value of [*ETH_Jabber*](#)
- ***uint32_t ETH_MACInitTypeDef::InterFrameGap***
Selects the minimum IFG between frames during transmission. This parameter can be a value of [*ETH_Inter_Frame_Gap*](#)
- ***uint32_t ETH_MACInitTypeDef::CarrierSense***
Selects or not the Carrier Sense. This parameter can be a value of [*ETH_Carrier_Sense*](#)
- ***uint32_t ETH_MACInitTypeDef::ReceiveOwn***
Selects or not the ReceiveOwn, ReceiveOwn allows the reception of frames when the TX_EN signal is asserted in Half-Duplex mode. This parameter can be a value of [*ETH_Receive_Own*](#)

- ***uint32_t ETH_MACInitTypeDef::LoopbackMode***
Selects or not the internal MAC MII Loopback mode. This parameter can be a value of [**ETH_Loop_Back_Mode**](#)
- ***uint32_t ETH_MACInitTypeDef::ChecksumOffload***
Selects or not the IPv4 checksum checking for received frame payloads' TCP/UDP/ICMP headers. This parameter can be a value of [**ETH_Checksum_Offload**](#)
- ***uint32_t ETH_MACInitTypeDef::RetryTransmission***
Selects or not the MAC attempt retries transmission, based on the settings of BL, when a collision occurs (Half-Duplex mode). This parameter can be a value of [**ETH_Retry_Transmission**](#)
- ***uint32_t ETH_MACInitTypeDef::AutomaticPadCRCStrip***
Selects or not the Automatic MAC Pad/CRC Stripping. This parameter can be a value of [**ETH_Automatic_Pad_CRC_Strip**](#)
- ***uint32_t ETH_MACInitTypeDef::BackOffLimit***
Selects the BackOff limit value. This parameter can be a value of [**ETH_Back_Off_Limit**](#)
- ***uint32_t ETH_MACInitTypeDef::DeferralCheck***
Selects or not the deferral check function (Half-Duplex mode). This parameter can be a value of [**ETH_Deferral_Check**](#)
- ***uint32_t ETH_MACInitTypeDef::ReceiveAll***
Selects or not all frames reception by the MAC (No filtering). This parameter can be a value of [**ETH_Receive_All**](#)
- ***uint32_t ETH_MACInitTypeDef::SourceAddrFilter***
Selects the Source Address Filter mode. This parameter can be a value of [**ETH_Source_Addr_Filter**](#)
- ***uint32_t ETH_MACInitTypeDef::PassControlFrames***
Sets the forwarding mode of the control frames (including unicast and multicast PAUSE frames) This parameter can be a value of [**ETH_Pass_Control_Frames**](#)
- ***uint32_t ETH_MACInitTypeDef::BroadcastFramesReception***
Selects or not the reception of Broadcast Frames. This parameter can be a value of [**ETH_Broadcast_Frames_Reception**](#)
- ***uint32_t ETH_MACInitTypeDef::DestinationAddrFilter***
Sets the destination filter mode for both unicast and multicast frames. This parameter can be a value of [**ETH_Destination_Addr_Filter**](#)
- ***uint32_t ETH_MACInitTypeDef::PromiscuousMode***
Selects or not the Promiscuous Mode This parameter can be a value of [**ETH_Promiscuous_Mode**](#)
- ***uint32_t ETH_MACInitTypeDef::MulticastFramesFilter***
Selects the Multicast Frames filter mode:
None/HashTableFilter/PerfectFilter/PerfectHashTableFilter. This parameter can be a value of [**ETH_Multicast_Frames_Filter**](#)
- ***uint32_t ETH_MACInitTypeDef::UnicastFramesFilter***
Selects the Unicast Frames filter mode:
HashTableFilter/PerfectFilter/PerfectHashTableFilter. This parameter can be a value of [**ETH_Uncast_Frames_Filter**](#)
- ***uint32_t ETH_MACInitTypeDef::HashTableHigh***
This field holds the higher 32 bits of Hash table. This parameter must be a number between Min_Data = 0x0 and Max_Data = 0xFFFFFFFF
- ***uint32_t ETH_MACInitTypeDef::HashTableLow***
This field holds the lower 32 bits of Hash table. This parameter must be a number between Min_Data = 0x0 and Max_Data = 0xFFFFFFFF
- ***uint32_t ETH_MACInitTypeDef::PauseTime***
This field holds the value to be used in the Pause Time field in the transmit control frame. This parameter must be a number between Min_Data = 0x0 and Max_Data = 0xFFFF

- **`uint32_t ETH_MACInitTypeDef::ZeroQuantaPause`**
Selects or not the automatic generation of Zero-Quanta Pause Control frames. This parameter can be a value of [`ETH_Zero_Quanta_Pause`](#)
- **`uint32_t ETH_MACInitTypeDef::PauseLowThreshold`**
This field configures the threshold of the PAUSE to be checked for automatic retransmission of PAUSE Frame. This parameter can be a value of [`ETH_Pause_Low_Threshold`](#)
- **`uint32_t ETH_MACInitTypeDef::UnicastPauseFrameDetect`**
Selects or not the MAC detection of the Pause frames (with MAC Address0 unicast address and unique multicast address). This parameter can be a value of [`ETH_Uncast_Pause_Frame_Detect`](#)
- **`uint32_t ETH_MACInitTypeDef::ReceiveFlowControl`**
Enables or disables the MAC to decode the received Pause frame and disable its transmitter for a specified time (Pause Time) This parameter can be a value of [`ETH_Receive_Flow_Control`](#)
- **`uint32_t ETH_MACInitTypeDef::TransmitFlowControl`**
Enables or disables the MAC to transmit Pause frames (Full-Duplex mode) or the MAC back-pressure operation (Half-Duplex mode) This parameter can be a value of [`ETH_Transmit_Flow_Control`](#)
- **`uint32_t ETH_MACInitTypeDef::VLANTagComparison`**
Selects the 12-bit VLAN identifier or the complete 16-bit VLAN tag for comparison and filtering. This parameter can be a value of [`ETH_VLAN_Tag_Comparison`](#)
- **`uint32_t ETH_MACInitTypeDef::VLANTagIdentifier`**
Holds the VLAN tag identifier for receive frames

20.2.3 ETH_DMAInitTypeDef

Data Fields

- **`uint32_t DropTCPIPChecksumErrorFrame`**
- **`uint32_t ReceiveStoreForward`**
- **`uint32_t FlushReceivedFrame`**
- **`uint32_t TransmitStoreForward`**
- **`uint32_t TransmitThresholdControl`**
- **`uint32_t ForwardErrorFrames`**
- **`uint32_t ForwardUndersizedGoodFrames`**
- **`uint32_t ReceiveThresholdControl`**
- **`uint32_t SecondFrameOperate`**
- **`uint32_t AddressAlignedBeats`**
- **`uint32_t FixedBurst`**
- **`uint32_t RxDMABurstLength`**
- **`uint32_t TxDMABurstLength`**
- **`uint32_t EnhancedDescriptorFormat`**
- **`uint32_t DescriptorSkipLength`**
- **`uint32_t DMAArbitration`**

Field Documentation

- **`uint32_t ETH_DMAInitTypeDef::DropTCPIPChecksumErrorFrame`**
Selects or not the Dropping of TCP/IP Checksum Error Frames. This parameter can be a value of [`ETH_Drop_TCP_IP_Checksum_Error_Frame`](#)

- ***uint32_t ETH_DMADescTypeDef::ReceiveStoreForward***
Enables or disables the Receive store and forward mode. This parameter can be a value of ***ETH_Receive_Store_Fwd***
- ***uint32_t ETH_DMADescTypeDef::FlushReceivedFrame***
Enables or disables the flushing of received frames. This parameter can be a value of ***ETH_Flush_Received_Frame***
- ***uint32_t ETH_DMADescTypeDef::TransmitStoreForward***
Enables or disables Transmit store and forward mode. This parameter can be a value of ***ETH_Transmit_Store_Fwd***
- ***uint32_t ETH_DMADescTypeDef::TransmitThresholdControl***
Selects or not the Transmit Threshold Control. This parameter can be a value of ***ETH_Transmit_Threshold_Control***
- ***uint32_t ETH_DMADescTypeDef::ForwardErrorFrames***
Selects or not the forward to the DMA of erroneous frames. This parameter can be a value of ***ETH_Forward_Error_Frames***
- ***uint32_t ETH_DMADescTypeDef::ForwardUndersizedGoodFrames***
Enables or disables the Rx FIFO to forward Undersized frames (frames with no Error and length less than 64 bytes) including pad-bytes and CRC) This parameter can be a value of ***ETH_Forward_Undersized_Good_Frames***
- ***uint32_t ETH_DMADescTypeDef::ReceiveThresholdControl***
Selects the threshold level of the Receive FIFO. This parameter can be a value of ***ETH_Receive_Threshold_Control***
- ***uint32_t ETH_DMADescTypeDef::SecondFrameOperate***
Selects or not the Operate on second frame mode, which allows the DMA to process a second frame of Transmit data even before obtaining the status for the first frame. This parameter can be a value of ***ETH_Second_Frame_Operate***
- ***uint32_t ETH_DMADescTypeDef::AddressAlignedBeats***
Enables or disables the Address Aligned Beats. This parameter can be a value of ***ETH_Address_Aligned_Beats***
- ***uint32_t ETH_DMADescTypeDef::FixedBurst***
Enables or disables the AHB Master interface fixed burst transfers. This parameter can be a value of ***ETH_Fixed_Burst***
- ***uint32_t ETH_DMADescTypeDef::RxDMAburstLength***
Indicates the maximum number of beats to be transferred in one Rx DMA transaction. This parameter can be a value of ***ETH_Rx_DMA_Burst_Length***
- ***uint32_t ETH_DMADescTypeDef::TxDMAburstLength***
Indicates the maximum number of beats to be transferred in one Tx DMA transaction. This parameter can be a value of ***ETH_Tx_DMA_Burst_Length***
- ***uint32_t ETH_DMADescTypeDef::EnhancedDescriptorFormat***
Enables the enhanced descriptor format. This parameter can be a value of ***ETH_DMA_Enhanced_descriptor_format***
- ***uint32_t ETH_DMADescTypeDef::DescriptorSkipLength***
Specifies the number of word to skip between two unchained descriptors (Ring mode) This parameter must be a number between Min_Data = 0 and Max_Data = 32
- ***uint32_t ETH_DMADescTypeDef::DMAArbitration***
Selects the DMA Tx/Rx arbitration. This parameter can be a value of ***ETH_DMA_Arbitration***

20.2.4 ETH_DMADescTypeDef

Data Fields

- `__IO uint32_t Status`
- `uint32_t ControlBufferSize`
- `uint32_t Buffer1Addr`
- `uint32_t Buffer2NextDescAddr`
- `uint32_t ExtendedStatus`
- `uint32_t Reserved1`
- `uint32_t TimeStampLow`
- `uint32_t TimeStampHigh`

Field Documentation

- `__IO uint32_t ETH_DMADescTypeDef::Status`
Status
- `uint32_t ETH_DMADescTypeDef::ControlBufferSize`
Control and Buffer1, Buffer2 lengths
- `uint32_t ETH_DMADescTypeDef::Buffer1Addr`
Buffer1 address pointer
- `uint32_t ETH_DMADescTypeDef::Buffer2NextDescAddr`
Buffer2 or next descriptor address pointer Enhanced ETHERNET DMA PTP Descriptors
- `uint32_t ETH_DMADescTypeDef::ExtendedStatus`
Extended status for PTP receive descriptor
- `uint32_t ETH_DMADescTypeDef::Reserved1`
Reserved
- `uint32_t ETH_DMADescTypeDef::TimeStampLow`
Time Stamp Low value for transmit and receive
- `uint32_t ETH_DMADescTypeDef::TimeStampHigh`
Time Stamp High value for transmit and receive

20.2.5 ETH_DMARxFrameInfos

Data Fields

- `ETH_DMADescTypeDef * FSRxDesc`
- `ETH_DMADescTypeDef * LSRxDesc`
- `uint32_t SegCount`
- `uint32_t length`
- `uint32_t buffer`

Field Documentation

- `ETH_DMADescTypeDef* ETH_DMARxFrameInfos::FSRxDesc`
First Segment Rx Desc
- `ETH_DMADescTypeDef* ETH_DMARxFrameInfos::LSRxDesc`
Last Segment Rx Desc
- `uint32_t ETH_DMARxFrameInfos::SegCount`
Segment count
- `uint32_t ETH_DMARxFrameInfos::length`
Frame length
- `uint32_t ETH_DMARxFrameInfos::buffer`
Frame buffer

20.2.6 ETH_HandleTypeDef

Data Fields

- *ETH_TypeDef * Instance*
- *ETH_InitTypeDef Init*
- *uint32_t LinkStatus*
- *ETH_DMADescTypeDef * RxDesc*
- *ETH_DMADescTypeDef * TxDesc*
- *ETH_DMARxFrameInfos RxFrameInfos*
- *__IO HAL_ETH_StateTypeDef State*
- *HAL_LockTypeDef Lock*

Field Documentation

- ***ETH_TypeDef* ETH_HandleTypeDef::Instance***
Register base address
- ***ETH_InitTypeDef ETH_HandleTypeDef::Init***
Ethernet Init Configuration
- ***uint32_t ETH_HandleTypeDef::LinkStatus***
Ethernet link status
- ***ETH_DMADescTypeDef* ETH_HandleTypeDef::RxDesc***
Rx descriptor to Get
- ***ETH_DMADescTypeDef* ETH_HandleTypeDef::TxDesc***
Tx descriptor to Set
- ***ETH_DMARxFrameInfos ETH_HandleTypeDef::RxFrameInfos***
last Rx frame infos
- ***__IO HAL_ETH_StateTypeDef ETH_HandleTypeDef::State***
ETH communication state
- ***HAL_LockTypeDef ETH_HandleTypeDef::Lock***
ETH Lock

20.3 ETH Firmware driver API description

20.3.1 How to use this driver

1. Declare a ETH_HandleTypeDef handle structure, for example: ETH_HandleTypeDef heth;
2. Fill parameters of Init structure in heth handle
3. Call HAL_ETH_Init() API to initialize the Ethernet peripheral (MAC, DMA, ...)
4. Initialize the ETH low level resources through the HAL_ETH_MspInit() API:
 - a. Enable the Ethernet interface clock using
 - `__HAL_RCC_ETHMAC_CLK_ENABLE();`
 - `__HAL_RCC_ETHMACTX_CLK_ENABLE();`
 - `__HAL_RCC_ETHMACRX_CLK_ENABLE();`
 - b. Initialize the related GPIO clocks
 - c. Configure Ethernet pin-out
 - d. Configure Ethernet NVIC interrupt (IT mode)

-
5. Initialize Ethernet DMA Descriptors in chain mode and point to allocated buffers:
 - a. HAL_ETH_DMATxDescListInit(); for Transmission process
 - b. HAL_ETH_DMARxDescListInit(); for Reception process
 6. Enable MAC and DMA transmission and reception:
 - a. HAL_ETH_Start();
 7. Prepare ETH DMA TX Descriptors and give the hand to ETH DMA to transfer the frame to MAC TX FIFO:
 - a. HAL_ETH_TransmitFrame();
 8. Poll for a received frame in ETH RX DMA Descriptors and get received frame parameters
 - a. HAL_ETH_GetReceivedFrame(); (should be called into an infinite loop)
 9. Get a received frame when an ETH RX interrupt occurs:
 - a. HAL_ETH_GetReceivedFrame_IT(); (called in IT mode only)
 10. Communicate with external PHY device:
 - a. Read a specific register from the PHY HAL_ETH_ReadPHYRegister();
 - b. Write data to a specific RHY register: HAL_ETH_WritePHYRegister();
 11. Configure the Ethernet MAC after ETH peripheral initialization
HAL_ETH_ConfigMAC(); all MAC parameters should be filled.
 12. Configure the Ethernet DMA after ETH peripheral initialization
HAL_ETH_ConfigDMA(); all DMA parameters should be filled. The PTP protocol and the DMA descriptors ring mode are not supported in this driver

20.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize and configure the Ethernet peripheral
- De-initialize the Ethernet peripheral

This section contains the following APIs:

- [***HAL_ETH_Init\(\)***](#)
- [***HAL_ETH_DeInit\(\)***](#)
- [***HAL_ETH_DMATxDescListInit\(\)***](#)
- [***HAL_ETH_DMARxDescListInit\(\)***](#)
- [***HAL_ETH_MspInit\(\)***](#)
- [***HAL_ETH_MspDeInit\(\)***](#)

20.3.3 IO operation functions

This section provides functions allowing to:

- Transmit a frame HAL_ETH_TransmitFrame();
- Receive a frame HAL_ETH_GetReceivedFrame();
HAL_ETH_GetReceivedFrame_IT();
- Read from an External PHY register HAL_ETH_ReadPHYRegister();
- Write to an External PHY register HAL_ETH_WritePHYRegister();

This section contains the following APIs:

- [***HAL_ETH_TransmitFrame\(\)***](#)
- [***HAL_ETH_GetReceivedFrame\(\)***](#)
- [***HAL_ETH_GetReceivedFrame_IT\(\)***](#)
- [***HAL_ETH_IRQHandler\(\)***](#)
- [***HAL_ETH_TxCpltCallback\(\)***](#)
- [***HAL_ETH_RxCpltCallback\(\)***](#)
- [***HAL_ETH_ErrorCallback\(\)***](#)
- [***HAL_ETH_ReadPHYRegister\(\)***](#)

- [*HAL_ETH_WritePHYRegister\(\)*](#)

20.3.4 Peripheral Control functions

This section provides functions allowing to:

- Enable MAC and DMA transmission and reception. `HAL_ETH_Start()`;
- Disable MAC and DMA transmission and reception. `HAL_ETH_Stop()`;
- Set the MAC configuration in runtime mode `HAL_ETH_ConfigMAC()`;
- Set the DMA configuration in runtime mode `HAL_ETH_ConfigDMA()`;

This section contains the following APIs:

- [*HAL_ETH_Start\(\)*](#)
- [*HAL_ETH_Stop\(\)*](#)
- [*HAL_ETH_ConfigMAC\(\)*](#)
- [*HAL_ETH_ConfigDMA\(\)*](#)

20.3.5 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

- Get the ETH handle state: `HAL_ETH_GetState()`;

This section contains the following APIs:

- [*HAL_ETH_GetState\(\)*](#)

20.3.6 HAL_ETH_Init

Function Name	<code>HAL_StatusTypeDef HAL_ETH_Init (ETH_HandleTypeDef * heth)</code>
Function Description	Initializes the Ethernet MAC and DMA according to default parameters.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a <code>ETH_HandleTypeDef</code> structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL status

20.3.7 HAL_ETH_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_ETH_DelInit (ETH_HandleTypeDef * heth)</code>
Function Description	De-Initializes the ETH peripheral.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a <code>ETH_HandleTypeDef</code> structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL status

20.3.8 HAL_ETH_DMATxDescListInit

Function Name	<code>HAL_StatusTypeDef HAL_ETH_DMATxDescListInit (ETH_HandleTypeDef * heth, ETH_DMADescTypeDef * DMATxDescTab, uint8_t * TxBuff, uint32_t TxBuffCount)</code>
Function Description	Initializes the DMA Tx descriptors in chain mode.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a <code>ETH_HandleTypeDef</code> structure that

-
- contains the configuration information for ETHERNET module
- **DMATxDescTab:** Pointer to the first Tx desc list
 - **TxBuff:** Pointer to the first TxBuffer list
 - **TxBuffCount:** Number of the used Tx desc in the list
- Return values**
- HAL status

20.3.9 HAL_ETH_DMARxDescListInit

Function Name	HAL_StatusTypeDef HAL_ETH_DMARxDescListInit (ETH_HandleTypeDef * heth, ETH_DMADescTypeDef * DMARxDescTab, uint8_t * RxBuff, uint32_t RxBuffCount)
Function Description	Initializes the DMA Rx descriptors in chain mode.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module • DMARxDescTab: Pointer to the first Rx desc list • RxBuff: Pointer to the first RxBuffer list • RxBuffCount: Number of the used Rx desc in the list
Return values	<ul style="list-style-type: none"> • HAL status

20.3.10 HAL_ETH_MspInit

Function Name	void HAL_ETH_MspInit (ETH_HandleTypeDef * heth)
Function Description	Initializes the ETH MSP.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • None

20.3.11 HAL_ETH_MspDelInit

Function Name	void HAL_ETH_MspDelInit (ETH_HandleTypeDef * heth)
Function Description	Deinitializes ETH MSP.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • None

20.3.12 HAL_ETH_TransmitFrame

Function Name	HAL_StatusTypeDef HAL_ETH_TransmitFrame (ETH_HandleTypeDef * heth, uint32_t FrameLength)
Function Description	Sends an Ethernet frame.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module • FrameLength: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

20.3.13 HAL_ETH_GetReceivedFrame

Function Name	HAL_StatusTypeDef HAL_ETH_GetReceivedFrame (ETH_HandleTypeDef * heth)
Function Description	Checks for received frames.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL status
20.3.14 HAL_ETH_GetReceivedFrame_IT	
Function Name	HAL_StatusTypeDef HAL_ETH_GetReceivedFrame_IT (ETH_HandleTypeDef * heth)
Function Description	Gets the Received frame in interrupt mode.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL status
20.3.15 HAL_ETH_IRQHandler	
Function Name	void HAL_ETH_IRQHandler (ETH_HandleTypeDef * heth)
Function Description	This function handles ETH interrupt request.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL status
20.3.16 HAL_ETH_TxCpltCallback	
Function Name	void HAL_ETH_TxCpltCallback (ETH_HandleTypeDef * heth)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • None
20.3.17 HAL_ETH_RxCpltCallback	
Function Name	void HAL_ETH_RxCpltCallback (ETH_HandleTypeDef * heth)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • None
20.3.18 HAL_ETH_ErrorCallback	
Function Name	void HAL_ETH_ErrorCallback (ETH_HandleTypeDef * heth)
Function Description	Ethernet transfer error callbacks.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that

contains the configuration information for ETHERNET module

Return values	<ul style="list-style-type: none"> None
---------------	--

20.3.19 HAL_ETH_ReadPHYRegister

Function Name	HAL_StatusTypeDef HAL_ETH_ReadPHYRegister (ETH_HandleTypeDef * heth, uint16_t PHYReg, uint32_t * RegValue)
Function Description	Reads a PHY register.
Parameters	<ul style="list-style-type: none"> heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module PHYReg: PHY register address, is the index of one of the 32 PHY register. This parameter can be one of the following values: PHY_BCR: Transceiver Basic Control Register, PHY_BSR: Transceiver Basic Status Register. More PHY register could be read depending on the used PHY RegValue: PHY register value
Return values	<ul style="list-style-type: none"> HAL status

20.3.20 HAL_ETH_WritePHYRegister

Function Name	HAL_StatusTypeDef HAL_ETH_WritePHYRegister (ETH_HandleTypeDef * heth, uint16_t PHYReg, uint32_t RegValue)
Function Description	Writes to a PHY register.
Parameters	<ul style="list-style-type: none"> heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module PHYReg: PHY register address, is the index of one of the 32 PHY register. This parameter can be one of the following values: PHY_BCR: Transceiver Control Register. More PHY register could be written depending on the used PHY RegValue: the value to write
Return values	<ul style="list-style-type: none"> HAL status

20.3.21 HAL_ETH_Start

Function Name	HAL_StatusTypeDef HAL_ETH_Start (ETH_HandleTypeDef * heth)
Function Description	Enables Ethernet MAC and DMA reception/transmission.
Parameters	<ul style="list-style-type: none"> heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> HAL status

20.3.22 HAL_ETH_Stop

Function Name	HAL_StatusTypeDef HAL_ETH_Stop (ETH_HandleTypeDef * heth)
Function Description	Stop Ethernet MAC and DMA reception/transmission.

Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL status

20.3.23 HAL_ETH_ConfigMAC

Function Name	HAL_StatusTypeDef HAL_ETH_ConfigMAC (ETH_HandleTypeDef * heth, ETH_MACInitTypeDef * macconf)
Function Description	Set ETH MAC Configuration.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module • macconf: MAC Configuration structure
Return values	<ul style="list-style-type: none"> • HAL status

20.3.24 HAL_ETH_ConfigDMA

Function Name	HAL_StatusTypeDef HAL_ETH_ConfigDMA (ETH_HandleTypeDef * heth, ETH_DMAInitTypeDef * dmaconf)
Function Description	Sets ETH DMA Configuration.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module • dmaconf: DMA Configuration structure
Return values	<ul style="list-style-type: none"> • HAL status

20.3.25 HAL_ETH_GetState

Function Name	HAL_ETH_StateTypeDef HAL_ETH_GetState (ETH_HandleTypeDef * heth)
Function Description	Return the ETH HAL state.
Parameters	<ul style="list-style-type: none"> • heth: pointer to a ETH_HandleTypeDef structure that contains the configuration information for ETHERNET module
Return values	<ul style="list-style-type: none"> • HAL state

20.4 ETH Firmware driver defines

20.4.1 ETH

ETH Address Aligned Beats

ETH_ADDRESSALIGNEDBEATS_ENABLE

ETH_ADDRESSALIGNEDBEATS_DISABLE

ETH Automatic Pad CRC Strip

ETH_AUTOMATICPADCRCSTRIP_ENABLE

ETH_AUTOMATICPADCRCSTRIP_DISABLE

ETH AutoNegotiation

ETH_AUTONEGOTIATION_ENABLE

ETH_AUTONEGOTIATION_DISABLE	
<i>ETH Back Off Limit</i>	
ETH_BACKOFFLIMIT_10	
ETH_BACKOFFLIMIT_8	
ETH_BACKOFFLIMIT_4	
ETH_BACKOFFLIMIT_1	
<i>ETH Broadcast Frames Reception</i>	
ETH_BROADCASTFRAMESRECEPTION_ENABLE	
ETH_BROADCASTFRAMESRECEPTION_DISABLE	
<i>ETH Buffers setting</i>	
ETH_MAX_PACKET_SIZE	ETH_HEADER + ETH_EXTRA + ETH_VLAN_TAG + ETH_MAX_ETH_PAYLOAD + ETH_CRC
ETH_HEADER	6 byte Dest addr, 6 byte Src addr, 2 byte length/type
ETH_CRC	Ethernet CRC
ETH_EXTRA	Extra bytes in some cases
ETH_VLAN_TAG	optional 802.1q VLAN Tag
ETH_MIN_ETH_PAYLOAD	Minimum Ethernet payload size
ETH_MAX_ETH_PAYLOAD	Maximum Ethernet payload size
ETH_JUMBO_FRAME_PAYLOAD	Jumbo frame payload size
ETH_RX_BUF_SIZE	
ETH_RXBUFN	
ETH_TX_BUF_SIZE	
ETH_TXBUFN	
<i>ETH Carrier Sense</i>	
ETH_CARRIERSENCE_ENABLE	
ETH_CARRIERSENCE_DISABLE	
<i>ETH Checksum Mode</i>	
ETH_CHECKSUM_BY_HARDWARE	
ETH_CHECKSUM_BY_SOFTWARE	
<i>ETH Checksum Offload</i>	
ETH_CHECKSUMOFFLOAD_ENABLE	
ETH_CHECKSUMOFFLOAD_DISABLE	
<i>ETH Deferral Check</i>	
ETH_DEFERRALCHECK_ENABLE	
ETH_DEFERRALCHECK_DISABLE	
<i>ETH Destination Addr Filter</i>	
ETH_DESTINATIONADDRFILTER_NORMAL	

ETH_DESTINATIONADDRFILTER_INVERSE

ETH DMA Arbitration

ETH_DMAARBITRATION_ROUNDROBIN_RXTX_1_1
 ETH_DMAARBITRATION_ROUNDROBIN_RXTX_2_1
 ETH_DMAARBITRATION_ROUNDROBIN_RXTX_3_1
 ETH_DMAARBITRATION_ROUNDROBIN_RXTX_4_1
 ETH_DMAARBITRATION_RXPRIORTX

ETH DMA Enhanced descriptor format

ETH_DMAENHANCEDDESCRIPTOR_ENABLE
 ETH_DMAENHANCEDDESCRIPTOR_DISABLE

ETH DMA Flags

ETH_DMA_FLAG_TST	Time-stamp trigger interrupt (on DMA)
ETH_DMA_FLAG_PMT	PMT interrupt (on DMA)
ETH_DMA_FLAG_MMC	MMC interrupt (on DMA)
ETH_DMA_FLAG_DATATRANSFERERROR	Error bits 0-Rx DMA, 1-Tx DMA
ETH_DMA_FLAG_READWRITEERROR	Error bits 0-write transfer, 1-read transfer
ETH_DMA_FLAG_ACCESSERROR	Error bits 0-data buffer, 1-desc. access
ETH_DMA_FLAG_NIS	Normal interrupt summary flag
ETH_DMA_FLAG_AIS	Abnormal interrupt summary flag
ETH_DMA_FLAG_ER	Early receive flag
ETH_DMA_FLAG_FBE	Fatal bus error flag
ETH_DMA_FLAG_ET	Early transmit flag
ETH_DMA_FLAG_RWT	Receive watchdog timeout flag
ETH_DMA_FLAG_RPS	Receive process stopped flag
ETH_DMA_FLAG_RBU	Receive buffer unavailable flag
ETH_DMA_FLAG_R	Receive flag
ETH_DMA_FLAG_TU	Underflow flag
ETH_DMA_FLAG_RO	Overflow flag
ETH_DMA_FLAG_TJT	Transmit jabber timeout flag
ETH_DMA_FLAG_TBU	Transmit buffer unavailable flag
ETH_DMA_FLAG_TPS	Transmit process stopped flag
ETH_DMA_FLAG_T	Transmit flag

ETH DMA Interrupts

ETH_DMA_IT_TST	Time-stamp trigger interrupt (on DMA)
ETH_DMA_IT_PMT	PMT interrupt (on DMA)
ETH_DMA_IT_MMC	MMC interrupt (on DMA)

ETH_DMA_IT_NIS	Normal interrupt summary
ETH_DMA_IT_AIS	Abnormal interrupt summary
ETH_DMA_IT_ER	Early receive interrupt
ETH_DMA_IT_FBE	Fatal bus error interrupt
ETH_DMA_IT_ET	Early transmit interrupt
ETH_DMA_IT_RWT	Receive watchdog timeout interrupt
ETH_DMA_IT_RPS	Receive process stopped interrupt
ETH_DMA_IT_RBU	Receive buffer unavailable interrupt
ETH_DMA_IT_R	Receive interrupt
ETH_DMA_IT_TU	Underflow interrupt
ETH_DMA_IT_RO	Overflow interrupt
ETH_DMA_IT_TJT	Transmit jabber timeout interrupt
ETH_DMA_IT_TBU	Transmit buffer unavailable interrupt
ETH_DMA_IT_TPS	Transmit process stopped interrupt
ETH_DMA_IT_T	Transmit interrupt

ETH DMA overflow

ETH_DMA_OVERFLOW_RXFIFOCOUNTER	Overflow bit for FIFO overflow counter
ETH_DMA_OVERFLOW_MISSEDFRAMECOUNTER	Overflow bit for missed frame counter

ETH DMA receive process state

ETH_DMA_RECEIVEPROCESS_STOPPED	Stopped - Reset or Stop Rx Command issued
ETH_DMA_RECEIVEPROCESS_FETCHING	Running - fetching the Rx descriptor
ETH_DMA_RECEIVEPROCESS_WAITING	Running - waiting for packet
ETH_DMA_RECEIVEPROCESS_SUSPENDED	Suspended - Rx Descriptor unavailable
ETH_DMA_RECEIVEPROCESS_CLOSING	Running - closing descriptor
ETH_DMA_RECEIVEPROCESS_QUEUEING	Running - queuing the receive frame into host memory

ETH DMA RX Descriptor

ETH_DMARXDESC_OWN	OWN bit: descriptor is owned by DMA engine
ETH_DMARXDESC_AFM	DA Filter Fail for the rx frame
ETH_DMARXDESC_FL	Receive descriptor frame length
ETH_DMARXDESC_ES	Error summary:

	OR of the following bits: DE OE IPC LC RWT RE CE
ETH_DMARXDESC_DE	Descriptor error: no more descriptors for receive frame
ETH_DMARXDESC_SAF	SA Filter Fail for the received frame
ETH_DMARXDESC_LE	Frame size not matching with length field
ETH_DMARXDESC_OE	Overflow Error: Frame was damaged due to buffer overflow
ETH_DMARXDESC_VLAN	VLAN Tag: received frame is a VLAN frame
ETH_DMARXDESC_FS	First descriptor of the frame
ETH_DMARXDESC_LS	Last descriptor of the frame
ETH_DMARXDESC_IPV4HCE	IPC Checksum Error: Rx Ipv4 header checksum error
ETH_DMARXDESC_LC	Late collision occurred during reception
ETH_DMARXDESC_FT	Frame type - Ethernet, otherwise 802.3
ETH_DMARXDESC_RWT	Receive Watchdog Timeout: watchdog timer expired during reception
ETH_DMARXDESC_RE	Receive error: error reported by MII interface
ETH_DMARXDESC_DBE	Dribble bit error: frame contains non int multiple

	of 8 bits
ETH_DMARXDESC_CE	CRC error
ETH_DMARXDESC_MAMPCE	Rx MAC Address/Payload Checksum Error: Rx MAC address matched/ Rx Payload Checksum Error
ETH_DMARXDESC_DIC	Disable Interrupt on Completion
ETH_DMARXDESC_RBS2	Receive Buffer2 Size
ETH_DMARXDESC_RER	Receive End of Ring
ETH_DMARXDESC_RCH	Second Address Chained
ETH_DMARXDESC_RBS1	Receive Buffer1 Size
ETH_DMARXDESC_B1AP	Buffer1 Address Pointer
ETH_DMARXDESC_B2AP	Buffer2 Address Pointer
ETH_DMAPTPRXDESC_PTPV	
ETH_DMAPTPRXDESC_PTPFT	
ETH_DMAPTPRXDESC_PTPMT	
ETH_DMAPTPRXDESC_PTPMT_SYNC	
ETH_DMAPTPRXDESC_PTPMT_FOLLOWUP	
ETH_DMAPTPRXDESC_PTPMT_DELAYREQ	
ETH_DMAPTPRXDESC_PTPMT_DELAYRESP	
ETH_DMAPTPRXDESC_PTPMT_PDELAYREQ_ANNOUNCE	
ETH_DMAPTPRXDESC_PTPMT_PDELAYRESP_MANAG	
ETH_DMAPTPRXDESC_PTPMT_PDELAYRESPFOLLOWUP_SIGNAL	
ETH_DMAPTPRXDESC_IPV6PR	
ETH_DMAPTPRXDESC_IPV4PR	
ETH_DMAPTPRXDESC_IPCB	
ETH_DMAPTPRXDESC_IPPE	
ETH_DMAPTPRXDESC_IPHE	
ETH_DMAPTPRXDESC_IPPT	

ETH_DMADPTPRXDESC_IPPT_UDP
 ETH_DMADPTPRXDESC_IPPT_TCP
 ETH_DMADPTPRXDESC_IPPT_ICMP
 ETH_DMADPTPRXDESC_RTSL
 ETH_DMADPTPRXDESC_RTSH

ETH DMA Rx descriptor buffers

ETH_DMARXDESC_BUFFER1 DMA Rx Desc Buffer1
 ETH_DMARXDESC_BUFFER2 DMA Rx Desc Buffer2

ETH DMA transmit process state

ETH_DMA_TRANSMITPROCESS_STOPPED	Stopped - Reset or Stop Tx Command issued
ETH_DMA_TRANSMITPROCESS_FETCHING	Running - fetching the Tx descriptor
ETH_DMA_TRANSMITPROCESS_WAITING	Running - waiting for status
ETH_DMA_TRANSMITPROCESS_READING	Running - reading the data from host memory
ETH_DMA_TRANSMITPROCESS_SUSPENDED	Suspended - Tx Descriptor unavailable
ETH_DMA_TRANSMITPROCESS_CLOSING	Running - closing Rx descriptor

ETH DMA TX Descriptor

ETH_DMATXDESC_OWN	OWN bit: descriptor is owned by DMA engine
ETH_DMATXDESC_IC	Interrupt on Completion
ETH_DMATXDESC_LS	Last Segment
ETH_DMATXDESC_FS	First Segment
ETH_DMATXDESC_DC	Disable CRC
ETH_DMATXDESC_DP	Disable Padding
ETH_DMATXDESC_TTSE	Transmit Time Stamp Enable
ETH_DMATXDESC_CIC	Checksum Insertion Control: 4 cases
ETH_DMATXDESC_CIC_BYPASS	Do Nothing: Checksum Engine is bypassed
ETH_DMATXDESC_CIC_IPV4HEADER	IPV4 header Checksum Insertion
ETH_DMATXDESC_CIC_TCPUDPICMP_SEGMENT	TCP/UDP/ICMP Checksum Insertion calculated over segment only
ETH_DMATXDESC_CIC_TCPUDPICMP_FULL	TCP/UDP/ICMP Checksum Insertion fully calculated
ETH_DMATXDESC_TER	Transmit End of Ring
ETH_DMATXDESC_TCH	Second Address Chained

ETH_DMATXDESC_TTSS	Tx Time Stamp Status
ETH_DMATXDESC_IHE	IP Header Error
ETH_DMATXDESC_ES	Error summary: OR of the following bits: UE ED EC LCO NC LCA FF JT
ETH_DMATXDESC_JT	Jabber Timeout
ETH_DMATXDESC_FF	Frame Flushed: DMA/MTL flushed the frame due to SW flush
ETH_DMATXDESC_PCE	Payload Checksum Error
ETH_DMATXDESC_LCA	Loss of Carrier: carrier lost during transmission
ETH_DMATXDESC_NC	No Carrier: no carrier signal from the transceiver
ETH_DMATXDESC_LCO	Late Collision: transmission aborted due to collision
ETH_DMATXDESC_EC	Excessive Collision: transmission aborted after 16 collisions
ETH_DMATXDESC_VF	VLAN Frame
ETH_DMATXDESC_CC	Collision Count
ETH_DMATXDESC_ED	Excessive Deferral
ETH_DMATXDESC_UF	Underflow Error: late data arrival from the memory
ETH_DMATXDESC_DB	Deferred Bit
ETH_DMATXDESC_TBS2	Transmit Buffer2 Size
ETH_DMATXDESC_TBS1	Transmit Buffer1 Size
ETH_DMATXDESC_B1AP	Buffer1 Address Pointer
ETH_DMATXDESC_B2AP	Buffer2 Address Pointer
ETH_DMAPTPTXDESC_TTSL	
ETH_DMAPTPTXDESC_TTSH	
<i>ETH DMA Tx descriptor Checksum Insertion Control</i>	
ETH_DMATXDESC_CHECKSUMBYPASS	Checksum engine bypass
ETH_DMATXDESC_CHECKSUMIPV4HEADER	IPv4 header checksum insertion
ETH_DMATXDESC_CHECKSUMTCPUDPICMPSEGMENT	TCP/UDP/ICMP checksum insertion. Pseudo header checksum is assumed to be present
ETH_DMATXDESC_CHECKSUMTCPUDPICMPFULL	TCP/UDP/ICMP checksum fully in hardware including pseudo header

ETH DMA Tx descriptor segment

`ETH_DMATXDESC_LASTSEGMENTS` Last Segment

`ETH_DMATXDESC_FIRSTSEGMENT` First Segment

ETH Drop TCP IP Checksum Error Frame

`ETH_DROPTCIPCHECKSUMERRORFRAME_ENABLE`

`ETH_DROPTCIPCHECKSUMERRORFRAME_DISABLE`

ETH Duplex Mode

`ETH_MODE_FULLDUPLEX`

`ETH_MODE_HALFDUPLEX`

ETH Exported Macros

`_HAL_ETH_RESET_HANDLE_STATE`

Description:

- Reset ETH handle state.

Parameters:

- `_HANDLE_`: specifies the ETH handle.

Return value:

- None

`_HAL_ETH_DMATXDESC_GET_FLAG`

Description:

- Checks whether the specified ETHERNET DMA Tx Desc flag is set or not.

Parameters:

- `_HANDLE_`: ETH Handle
- `_FLAG_`: specifies the flag of TDES0 to check.

Return value:

- the: `ETH_DMATxDescFlag` (SET or RESET).

`_HAL_ETH_DMARXDESC_GET_FLAG`

Description:

- Checks whether the specified ETHERNET DMA Rx Desc flag is set or not.

Parameters:

- `_HANDLE_`: ETH Handle
- `_FLAG_`: specifies the flag of RDES0 to check.

Return value:

- the: `ETH_DMATxDescFlag` (SET or RESET).

`_HAL_ETH_DMARXDESC_ENABLE_IT`

Description:

- Enables the specified DMA Rx Desc

receive interrupt.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_DMARXDESC_DISABLE_IT`

Description:

- Disables the specified DMA Rx Desc receive interrupt.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_DMARXDESC_SET_OWN_BIT`

Description:

- Set the specified DMA Rx Desc Own bit.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_DMATXDESC_GET_COLLISION_COUNT`

Description:

- Returns the specified ETHERNET DMA Tx Desc collision count.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- The: Transmit descriptor collision counter value.

`__HAL_ETH_DMATXDESC_SET_OWN_BIT`

Description:

- Set the specified DMA Tx Desc Own bit.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_DMATXDESC_ENABLE_IT`

Description:

- Enables the specified DMA Tx Desc Transmit interrupt.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

[__HAL_ETH_DMATXDESC_DISABLE_IT](#)**Description:**

- Disables the specified DMA Tx Desc Transmit interrupt.

Parameters:

- [__HANDLE__](#): ETH Handle

Return value:

- None

[__HAL_ETH_DMATXDESC_CHECKSUM_INSERTION](#)**Description:**

- Selects the specified ETHERNET DMA Tx Desc Checksum Insertion.

Parameters:

- [__HANDLE__](#): ETH Handle
- [__CHECKSUM__](#): specifies is the DMA Tx desc checksum insertion. This parameter can be one of the following values:
 - [ETH_DMATXDESC_CHECKSUMBYPASS](#) : Checksum bypass
 - [ETH_DMATXDESC_CHECKSUMIPV4HEADER](#) : IPv4 header checksum
 - [ETH_DMATXDESC_CHECKSUMTCPUDPICMPSEGMENT](#) : TCP/UDP/ICMP checksum. Pseudo header checksum is assumed to be present
 - [ETH_DMATXDESC_CHECKSUMTCPUDPICMPFULL](#) : TCP/UDP/ICMP checksum fully in hardware including pseudo header

Return value:

- None

[__HAL_ETH_DMATXDESC_CRC_ENABLE](#)**Description:**

- Enables the DMA Tx Desc CRC.

Parameters:

- [__HANDLE__](#): ETH Handle

Return value:

- None

[__HAL_ETH_DMATXDESC_CRC_DISABLE](#)**Description:**

- Disables the DMA Tx Desc CRC.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_DMATXDESC_SHORT_FRA
ME_PADDING_ENABLE`

Description:

- Enables the DMA Tx Desc padding for frame shorter than 64 bytes.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_DMATXDESC_SHORT_FRA
ME_PADDING_DISABLE`

Description:

- Disables the DMA Tx Desc padding for frame shorter than 64 bytes.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_MAC_ENABLE_IT`

Description:

- Enables the specified ETHERNET MAC interrupts.

Parameters:

- `__HANDLE__`: ETH Handle
- `__INTERRUPT__`: specifies the ETHERNET MAC interrupt sources to be enabled or disabled. This parameter can be any combination of the following values:
 - `ETH_MAC_IT_TST` : Time stamp trigger interrupt
 - `ETH_MAC_IT_PMT` : PMT interrupt

Return value:

- None

`__HAL_ETH_MAC_DISABLE_IT`

Description:

- Disables the specified ETHERNET MAC interrupts.

Parameters:

- `__HANDLE__`: ETH Handle
- `__INTERRUPT__`: specifies the ETHERNET MAC interrupt sources to be enabled or disabled. This parameter can be any combination of the following values:

- ETH_MAC_IT_TST : Time stamp trigger interrupt
- ETH_MAC_IT_PMT : PMT interrupt

Return value:

- None

`__HAL_ETH_INITIATE_PAUSE_CONTRO
L_FRAME`

Description:

- Initiate a Pause Control Frame (Full-duplex only).

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_GET_FLOW_CONTROL_BU
SY_STATUS`

Description:

- Checks whether the ETHERNET flow control busy bit is set or not.

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- The: new state of flow control busy status bit (SET or RESET).

`__HAL_ETH_BACK_PRESSURE_ACTIVA
TION_ENABLE`

Description:

- Enables the MAC Back Pressure operation activation (Half-duplex only).

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_BACK_PRESSURE_ACTIVA
TION_DISABLE`

Description:

- Disables the MAC BackPressure operation activation (Half-duplex only).

Parameters:

- `__HANDLE__`: ETH Handle

Return value:

- None

`__HAL_ETH_MAC_GET_FLAG`

Description:

- Checks whether the specified ETHERNET MAC flag is set or not.

Parameters:

- `__HANDLE__`: ETH Handle

- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - ETH_MAC_FLAG_TST : Time stamp trigger flag
 - ETH_MAC_FLAG_MMCT : MMC transmit flag
 - ETH_MAC_FLAG_MMCR : MMC receive flag
 - ETH_MAC_FLAG_MMCI : MMC flag
 - ETH_MAC_FLAG_PMT : PMT flag

Return value:

- The state of ETHERNET MAC flag.

[__HAL_ETH_DMA_ENABLE_IT](#)**Description:**

- Enables the specified ETHERNET DMA interrupts.

Parameters:

- __HANDLE__: : ETH Handle
- __INTERRUPT__: specifies the ETHERNET DMA interrupt sources to be enabled

Return value:

- None

[__HAL_ETH_DMA_DISABLE_IT](#)**Description:**

- Disables the specified ETHERNET DMA interrupts.

Parameters:

- __HANDLE__: : ETH Handle
- __INTERRUPT__: specifies the ETHERNET DMA interrupt sources to be disabled.

Return value:

- None

[__HAL_ETH_DMA_CLEAR_IT](#)**Description:**

- Clears the ETHERNET DMA IT pending bit.

Parameters:

- __HANDLE__: : ETH Handle
- __INTERRUPT__: specifies the interrupt pending bit to clear.

Return value:

- None

[__HAL_ETH_DMA_GET_FLAG](#)**Description:**

- Checks whether the specified ETHERNET DMA flag is set or not.

Parameters:

- [__HANDLE__](#): ETH Handle
- [__FLAG__](#): specifies the flag to check.

Return value:

- The: new state of ETH_DMA_FLAG (SET or RESET).

[__HAL_ETH_DMA_CLEAR_FLAG](#)**Description:**

- Checks whether the specified ETHERNET DMA flag is set or not.

Parameters:

- [__HANDLE__](#): ETH Handle
- [__FLAG__](#): specifies the flag to clear.

Return value:

- The: new state of ETH_DMA_FLAG (SET or RESET).

[__HAL_ETH_GET_DMA_OVERFLOW_STATUS](#)**Description:**

- Checks whether the specified ETHERNET DMA overflow flag is set or not.

Parameters:

- [__HANDLE__](#): ETH Handle
- [__OVERFLOW__](#): specifies the DMA overflow flag to check. This parameter can be one of the following values:
 - [ETH_DMA_OVERFLOW_RXFIFO_COUNTER](#) : Overflow for FIFO Overflows Counter
 - [ETH_DMA_OVERFLOW_MISSED_FRAMECOUNTER](#) : Overflow for Buffer Unavailable Missed Frame Counter

Return value:

- The: state of ETHERNET DMA overflow Flag (SET or RESET).

[__HAL_ETH_SET_RECEIVE_WATCHDOG_TIMER](#)**Description:**

- Set the DMA Receive status watchdog timer register value.

Parameters:

- [__HANDLE__](#): ETH Handle
- [__VALUE__](#): DMA Receive status

watchdog timer register value

Return value:

- None

`__HAL_ETH_GLOBAL_UNICAST_WAKEUP_ENABLE`

Description:

- Enables any unicast packet filtered by the MAC address recognition to be a wake-up frame.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_GLOBAL_UNICAST_WAKEUP_DISABLE`

Description:

- Disables any unicast packet filtered by the MAC address recognition to be a wake-up frame.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_WAKEUP_FRAME_DETECTION_ENABLE`

Description:

- Enables the MAC Wake-Up Frame Detection.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_WAKEUP_FRAME_DETECTION_DISABLE`

Description:

- Disables the MAC Wake-Up Frame Detection.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_MAGIC_PACKET_DETECTITION_ENABLE`

Description:

- Enables the MAC Magic Packet Detection.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

**__HAL_ETH_MAGIC_PACKET_DETECTI
ON_DISABLE****Description:**

- Disables the MAC Magic Packet Detection.

Parameters:

- __HANDLE__: ETH Handle.

Return value:

- None

__HAL_ETH_POWER_DOWN_ENABLE**Description:**

- Enables the MAC Power Down.

Parameters:

- __HANDLE__: ETH Handle

Return value:

- None

__HAL_ETH_POWER_DOWN_DISABLE**Description:**

- Disables the MAC Power Down.

Parameters:

- __HANDLE__: ETH Handle

Return value:

- None

__HAL_ETH_GET_PMT_FLAG_STATUS**Description:**

- Checks whether the specified ETHERNET PMT flag is set or not.

Parameters:

- __HANDLE__: ETH Handle.
- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - ETH_PMT_FLAG_WUFRPR : Wake-Up Frame Filter Register Pointer Reset
 - ETH_PMT_FLAG_WUFR : Wake-Up Frame Received
 - ETH_PMT_FLAG_MPR : Magic Packet Received

Return value:

- The: new state of ETHERNET PMT Flag (SET or RESET).

__HAL_ETH_MM_COUNTER_FULL_PR**Description:**

ESET

- Preset and Initialize the MMC counters to almost-full value: 0xFFFF_FFF0 (full - 16)

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_MMC_COUNTER_HALF_PR`
ESET

Description:

- Preset and Initialize the MMC counters to almost-half value: 0x7FFF_FFF0 (half - 16)

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_MMC_COUNTER_FREEZE_`
ENABLE

Description:

- Enables the MMC Counter Freeze.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_MMC_COUNTER_FREEZE_`
DISABLE

Description:

- Disables the MMC Counter Freeze.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_ETH_MMC_RESET_ONREA`
D_ENABLE

Description:

- Enables the MMC Reset On Read.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_ETH_MMC_RESET_ONREA`
D_DISABLE

Description:

- Disables the MMC Reset On Read.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_ETH_MM_COUNTER_RO
LLOVER_ENABLE`

Description:

- Enables the MMC Counter Stop Rollover.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_ETH_MM_COUNTER_RO
LLOVER_DISABLE`

Description:

- Disables the MMC Counter Stop Rollover.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_MM_COUNTERS_RESET`

Description:

- Resets the MMC Counters.

Parameters:

- `__HANDLE__`: ETH Handle.

Return value:

- None

`__HAL_ETH_MM_RX_IT_ENABLE`

Description:

- Enables the specified ETHERNET MMC Rx interrupts.

Parameters:

- `__HANDLE__`: ETH Handle.
- `__INTERRUPT__`: specifies the ETHERNET MMC interrupt sources to be enabled or disabled. This parameter can be one of the following values:
 - `ETH_MM_IT_RGUF` : When Rx good unicast frames counter reaches half the maximum value
 - `ETH_MM_IT_RFAE` : When Rx alignment error counter reaches half the maximum value
 - `ETH_MM_IT_RFCE` : When Rx crc error counter reaches half the maximum value

Return value:

- None

_HAL_ETH_MMC_RX_IT_DISABLE**Description:**

- Disables the specified ETHERNET MMC Rx interrupts.

Parameters:

- HANDLE: ETH Handle.
- INTERRUPT: specifies the ETHERNET MMC interrupt sources to be enabled or disabled. This parameter can be one of the following values:
 - ETH_MMC_IT_RGUF : When Rx good unicast frames counter reaches half the maximum value
 - ETH_MMC_IT_RFAE : When Rx alignment error counter reaches half the maximum value
 - ETH_MMC_IT_RFCE : When Rx crc error counter reaches half the maximum value

Return value:

- None

_HAL_ETH_MMC_TX_IT_ENABLE**Description:**

- Enables the specified ETHERNET MMC Tx interrupts.

Parameters:

- HANDLE: ETH Handle.
- INTERRUPT: specifies the ETHERNET MMC interrupt sources to be enabled or disabled. This parameter can be one of the following values:
 - ETH_MMC_IT_TGF : When Tx good frame counter reaches half the maximum value
 - ETH_MMC_IT_TGFMSC: When Tx good multi col counter reaches half the maximum value
 - ETH_MMC_IT_TGFSC : When Tx good single col counter reaches half the maximum value

Return value:

- None

_HAL_ETH_MMC_TX_IT_DISABLE**Description:**

- Disables the specified ETHERNET MMC Tx interrupts.

Parameters:

- HANDLE: ETH Handle.

- __INTERRUPT__: specifies the ETHERNET MMC interrupt sources to be enabled or disabled. This parameter can be one of the following values:
 - ETH_MMC_IT_TGF : When Tx good frame counter reaches half the maximum value
 - ETH_MMC_IT_TGFMSC: When Tx good multi col counter reaches half the maximum value
 - ETH_MMC_IT_TGFSC : When Tx good single col counter reaches half the maximum value

Return value:

- None

Description:

- Enables the ETH External interrupt line.

Return value:

- None

Description:

- Disables the ETH External interrupt line.

Return value:

- None

Description:

- Enable event on ETH External event line.

Return value:

- None.

Description:

- Disable event on ETH External event line.

Return value:

- None.

Description:

- Get flag of the ETH External interrupt line.

Return value:

- None

Description:

- Clear flag of the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_ENABLE_R
ISING_EDGE_TRIGGER`

Description:

- Enables rising edge trigger to the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_DISABLE_
RISING_EDGE_TRIGGER`

Description:

- Disables the rising edge trigger to the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_ENABLE_F
ALLING_EDGE_TRIGGER`

Description:

- Enables falling edge trigger to the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_DISABLE_
FALLING_EDGE_TRIGGER`

Description:

- Disables falling edge trigger to the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_ENABLE_F
ALLINGRISING_TRIGGER`

Description:

- Enables rising/falling edge trigger to the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_DISABLE_
FALLINGRISING_TRIGGER`

Description:

- Disables rising/falling edge trigger to the ETH External interrupt line.

Return value:

- None

`__HAL_ETH_WAKEUP_EXTI_GENERAT
E_SWIT`

Description:

- Generate a Software interrupt on selected EXTI line.

Return value:

- None.

ETH EXTI LINE WAKEUP

`ETH_EXTI_LINE_WAKEUP` External interrupt line 19 Connected to the ETH EXTI Line

ETH Fixed Burst

`ETH_FIXEDBURST_ENABLE`

`ETH_FIXEDBURST_DISABLE`

ETH Flush Received Frame

`ETH_FLUSHRECEIVEDFRAME_ENABLE`

`ETH_FLUSHRECEIVEDFRAME_DISABLE`

ETH Forward Error Frames

`ETH_FORWARDERRORFRAMES_ENABLE`

`ETH_FORWARDERRORFRAMES_DISABLE`

ETH Forward Undersized Good Frames

`ETH_FORWARDUNDERSIZEDGOODFRAMES_ENABLE`

`ETH_FORWARDUNDERSIZEDGOODFRAMES_DISABLE`

ETH Inter Frame Gap

`ETH_INTERFRAMEGAP_96BIT` minimum IFG between frames during transmission is 96Bit

`ETH_INTERFRAMEGAP_88BIT` minimum IFG between frames during transmission is 88Bit

`ETH_INTERFRAMEGAP_80BIT` minimum IFG between frames during transmission is 80Bit

`ETH_INTERFRAMEGAP_72BIT` minimum IFG between frames during transmission is 72Bit

`ETH_INTERFRAMEGAP_64BIT` minimum IFG between frames during transmission is 64Bit

`ETH_INTERFRAMEGAP_56BIT` minimum IFG between frames during transmission is 56Bit

`ETH_INTERFRAMEGAP_48BIT` minimum IFG between frames during transmission is 48Bit

`ETH_INTERFRAMEGAP_40BIT` minimum IFG between frames during transmission is 40Bit

ETH Jabber

`ETH_JABBER_ENABLE`

`ETH_JABBER_DISABLE`

ETH Loop Back Mode

`ETH_LOOPBACKMODE_ENABLE`

`ETH_LOOPBACKMODE_DISABLE`

ETH MAC addresses

`ETH_MAC_ADDRESS0`

`ETH_MAC_ADDRESS1`

ETH_MAC_ADDRESS2

ETH_MAC_ADDRESS3

ETH MAC addresses filter Mask bytes

ETH_MAC_ADDRESSMASK_BYTE6 Mask MAC Address high reg bits [15:8]

ETH_MAC_ADDRESSMASK_BYTE5 Mask MAC Address high reg bits [7:0]

ETH_MAC_ADDRESSMASK_BYTE4 Mask MAC Address low reg bits [31:24]

ETH_MAC_ADDRESSMASK_BYTE3 Mask MAC Address low reg bits [23:16]

ETH_MAC_ADDRESSMASK_BYTE2 Mask MAC Address low reg bits [15:8]

ETH_MAC_ADDRESSMASK_BYTE1 Mask MAC Address low reg bits [7:0]

ETH MAC addresses filter SA DA

ETH_MAC_ADDRESSFILTER_SA

ETH_MAC_ADDRESSFILTER_DA

ETH MAC Debug flags

ETH_MAC_TXFIFO_FULL

ETH_MAC_TXFIFONOT_EMPTY

ETH_MAC_TXFIFO_WRITE_ACTIVE

ETH_MAC_TXFIFO_IDLE

ETH_MAC_TXFIFO_READ

ETH_MAC_TXFIFO_WAITING

ETH_MAC_TXFIFO_WRITING

ETH_MAC_TRANSMISSION_PAUSE

ETH_MAC_TRANSMITFRAMECONTROLLER_IDLE

ETH_MAC_TRANSMITFRAMECONTROLLER_WAITING

ETH_MAC_TRANSMITFRAMECONTROLLER_GENRATING_PCF

ETH_MAC_TRANSMITFRAMECONTROLLER_TRANSFERRING

ETH_MAC_MII_TRANSMIT_ACTIVE

ETH_MAC_RXFIFO_EMPTY

ETH_MAC_RXFIFO_BELOW_THRESHOLD

ETH_MAC_RXFIFO_ABOVE_THRESHOLD

ETH_MAC_RXFIFO_FULL

ETH_MAC_READCONTROLLER_IDLE

ETH_MAC_READCONTROLLER_READING_DATA

ETH_MAC_READCONTROLLER_READING_STATUS

ETH_MAC_READCONTROLLER_FLUSHING

ETH_MAC_RXFIFO_WRITE_ACTIVE

ETH_MAC_SMALL_FIFO_NOTACTIVE

ETH_MAC_SMALL_FIFO_READ_ACTIVE
 ETH_MAC_SMALL_FIFO_WRITE_ACTIVE
 ETH_MAC_SMALL_FIFO_RW_ACTIVE
 ETH_MAC_MII_RECEIVE_PROTOCOL_ACTIVE

ETH MAC Flags

ETH_MAC_FLAG_TST	Time stamp trigger flag (on MAC)
ETH_MAC_FLAG_MMCT	MMC transmit flag
ETH_MAC_FLAG_MMCR	MMC receive flag
ETH_MAC_FLAG_MMCI	MMC flag (on MAC)
ETH_MAC_FLAG_PMT	PMT flag (on MAC)

ETH MAC Interrupts

ETH_MAC_IT_TST	Time stamp trigger interrupt (on MAC)
ETH_MAC_IT_MMCT	MMC transmit interrupt
ETH_MAC_IT_MMCR	MMC receive interrupt
ETH_MAC_IT_MMCI	MMC interrupt (on MAC)
ETH_MAC_IT_PMT	PMT interrupt (on MAC)

ETH Media Interface

ETH_MEDIA_INTERFACE_MII
 ETH_MEDIA_INTERFACE_RMII

ETH MMC Rx Interrupts

ETH_MMCI_IT_RGUF	When Rx good unicast frames counter reaches half the maximum value
ETH_MMCI_IT_RFAE	When Rx alignment error counter reaches half the maximum value
ETH_MMCI_IT_RFCE	When Rx crc error counter reaches half the maximum value

ETH MMC Tx Interrupts

ETH_MMCI_IT_TGF	When Tx good frame counter reaches half the maximum value
ETH_MMCI_IT_TGFMSC	When Tx good multi col counter reaches half the maximum value
ETH_MMCI_IT_TGFSC	When Tx good single col counter reaches half the maximum value

ETH Multicast Frames Filter

ETH_MULTICASTFRAMESFILTER_PERFECTHASHTABLE
 ETH_MULTICASTFRAMESFILTER_HASHTABLE
 ETH_MULTICASTFRAMESFILTER_PERFECT
 ETH_MULTICASTFRAMESFILTER_NONE

ETH Pass Control Frames

ETH_PASSCONTROLFRAMES_BLOCKALL	MAC filters all control frames from
--------------------------------	-------------------------------------

		reaching the application
ETH_PASSCONTROLFRAMES_FORWARDALL		MAC forwards all control frames to application even if they fail the Address Filter
ETH_PASSCONTROLFRAMES_FORWARDPASSEDADDRFILTER		MAC forwards control frames that pass the Address Filter.

ETH Pause Low Threshold

ETH_PAUSELOWTHRESHOLD_MINUS4	Pause time minus 4 slot times
ETH_PAUSELOWTHRESHOLD_MINUS28	Pause time minus 28 slot times
ETH_PAUSELOWTHRESHOLD_MINUS144	Pause time minus 144 slot times
ETH_PAUSELOWTHRESHOLD_MINUS256	Pause time minus 256 slot times

ETH PMT Flags

ETH_PMT_FLAG_WUFFRPR	Wake-Up Frame Filter Register Pointer Reset
ETH_PMT_FLAG_WUFR	Wake-Up Frame Received
ETH_PMT_FLAG_MPR	Magic Packet Received

ETH Private Constants

LINKED_STATE_TIMEOUT_VALUE
AUTONEGO_COMPLETED_TIMEOUT_VALUE

ETH_Private_Defines

ETH_REG_WRITE_DELAY
ETH_SUCCESS
ETH_ERROR
ETH_DMATXDESC_COLLISION_COUNTSHIFT
ETH_DMATXDESC_BUFFER2_SIZESSHIFT
ETH_DMARXDESC_FRAME_LENGTHSHIFT
ETH_DMARXDESC_BUFFER2_SIZESSHIFT
ETH_DMARXDESC_FRAMELENGTHSHIFT
ETH_MAC_ADDR_HBASE
ETH_MAC_ADDR_LBASE
ETH_MACIIAR_CR_MASK
ETH_MACCR_CLEAR_MASK
ETH_MACFCR_CLEAR_MASK
ETH_DMAOMR_CLEAR_MASK
ETH_WAKEUP_REGISTER_LENGTH

ETH_DMA_RX_OVERFLOW_MISSEDFRAMES_COUNTERSHIFT

ETH_Private_Macros

IS_ETH_PHY_ADDRESS
IS_ETH_AUTONEGOTIATION
IS_ETH_SPEED
IS_ETH_DUPLEX_MODE
IS_ETH_RX_MODE
IS_ETH_CHECKSUM_MODE
IS_ETH_MEDIA_INTERFACE
IS_ETH_WATCHDOG
IS_ETH_JABBER
IS_ETH_INTER_FRAME_GAP
IS_ETH_CARRIER_SENSE
IS_ETH_RECEIVE_OWN
IS_ETH_LOOPBACK_MODE
IS_ETH_CHECKSUM_OFFLOAD
IS_ETH_RETRY_TRANSMISSION
IS_ETH_AUTOMATIC_PADCRC_STRIP
IS_ETH_BACKOFF_LIMIT
IS_ETH_DEFERRAL_CHECK
IS_ETH_RECEIVE_ALL
IS_ETH_SOURCE_ADDR_FILTER
IS_ETH_CONTROL_FRAMES
IS_ETH_BROADCAST_FRAMES_RECEPTION
IS_ETH_DESTINATION_ADDR_FILTER
IS_ETH_PROMISCUOUS_MODE
IS_ETH_MULTICAST_FRAMES_FILTER
IS_ETH_UNICAST_FRAMES_FILTER
IS_ETH_PAUSE_TIME
IS_ETH_ZEROQUANTA_PAUSE
IS_ETH_PAUSE_LOW_THRESHOLD
IS_ETH_UNICAST_PAUSE_FRAME_DETECT
IS_ETH_RECEIVE_FLOWCONTROL
IS_ETH_TRANSMIT_FLOWCONTROL
IS_ETH_VLAN_TAG_COMPARISON
IS_ETH_VLAN_TAG_IDENTIFIER

IS_ETH_MAC_ADDRESS0123
IS_ETH_MAC_ADDRESS123
IS_ETH_MAC_ADDRESS_FILTER
IS_ETH_MAC_ADDRESS_MASK
IS_ETH_DROP_TCPIP_CHECKSUM_FRAME
IS_ETH_RECEIVE_STORE_FORWARD
IS_ETH_FLUSH_RECEIVE_FRAME
IS_ETH_TRANSMIT_STORE_FORWARD
IS_ETH_TRANSMIT_THRESHOLD_CONTROL
IS_ETH_FORWARD_ERROR_FRAMES
IS_ETH_FORWARD_UNDERSIZED_GOOD_FRAMES
IS_ETH_RECEIVE_THRESHOLD_CONTROL
IS_ETH_SECOND_FRAME_OPERATE
IS_ETH_ADDRESS_ALIGNED_BEATS
IS_ETH_FIXED_BURST
IS_ETH_RXDMA_BURST_LENGTH
IS_ETH_TXDMA_BURST_LENGTH
IS_ETH_DMA_DESC_SKIP_LENGTH
IS_ETH_DMA_ARBITRATION_ROUNDROBIN_RXTX
IS_ETH_DMATXDESC_GET_FLAG
IS_ETH_DMA_TXDESC_SEGMENT
IS_ETH_DMA_TXDESC_CHECKSUM
IS_ETH_DMATXDESC_BUFFER_SIZE
IS_ETH_DMARXDESC_GET_FLAG
IS_ETH_DMA_RXDESC_BUFFER
IS_ETH_PMT_GET_FLAG
IS_ETH_DMA_FLAG
IS_ETH_DMA_GET_FLAG
IS_ETH_MAC_IT
IS_ETH_MAC_GET_IT
IS_ETH_MAC_GET_FLAG
IS_ETH_DMA_IT
IS_ETH_DMA_GET_IT
IS_ETH_DMA_GET_OVERFLOW
IS_ETH_MMC_IT
IS_ETH_MMC_GET_IT

IS_ETH_ENHANCED_DESCRIPTOR_FORMAT

ETH Promiscuous Mode

ETH_PROMISCUOUS_MODE_ENABLE

ETH_PROMISCUOUS_MODE_DISABLE

ETH Receive All

ETH_RECEIVEALL_ENABLE

ETH_RECEIVEALL_DISABLE

ETH Receive Flow Control

ETH_RECEIVEFLOWCONTROL_ENABLE

ETH_RECEIVEFLOWCONTROL_DISABLE

ETH Receive Own

ETH_RECEIVEOWN_ENABLE

ETH_RECEIVEOWN_DISABLE

ETH Receive Store Forward

ETH_RECEIVESTOREFORWARD_ENABLE

ETH_RECEIVESTOREFORWARD_DISABLE

ETH Receive Threshold Control

ETH_RECEIVEDTHRESHOLDCONTROL_64BYTES threshold level of the MTL Receive FIFO is 64 Bytes

ETH_RECEIVEDTHRESHOLDCONTROL_32BYTES threshold level of the MTL Receive FIFO is 32 Bytes

ETH_RECEIVEDTHRESHOLDCONTROL_96BYTES threshold level of the MTL Receive FIFO is 96 Bytes

ETH_RECEIVEDTHRESHOLDCONTROL_128BYTES threshold level of the MTL Receive FIFO is 128 Bytes

ETH Retry Transmission

ETH_RETRYTRANSMISSION_ENABLE

ETH_RETRYTRANSMISSION_DISABLE

ETH Rx DMA Burst Length

ETH_RXDMABURSTLENGTH_1BEAT maximum number of beats to be transferred in one RxDMA transaction is 1

ETH_RXDMABURSTLENGTH_2BEAT maximum number of beats to be transferred in one RxDMA transaction is 2

ETH_RXDMABURSTLENGTH_4BEAT maximum number of beats to be transferred in one RxDMA transaction is 4

ETH_RXDMABURSTLENGTH_8BEAT maximum number of beats to be transferred in one RxDMA transaction

	is 8
ETH_RXDMABURSTLENGTH_16BEAT	maximum number of beats to be transferred in one RxDMA transaction is 16
ETH_RXDMABURSTLENGTH_32BEAT	maximum number of beats to be transferred in one RxDMA transaction is 32
ETH_RXDMABURSTLENGTH_4XPBL_4BEAT	maximum number of beats to be transferred in one RxDMA transaction is 4
ETH_RXDMABURSTLENGTH_4XPBL_8BEAT	maximum number of beats to be transferred in one RxDMA transaction is 8
ETH_RXDMABURSTLENGTH_4XPBL_16BEAT	maximum number of beats to be transferred in one RxDMA transaction is 16
ETH_RXDMABURSTLENGTH_4XPBL_32BEAT	maximum number of beats to be transferred in one RxDMA transaction is 32
ETH_RXDMABURSTLENGTH_4XPBL_64BEAT	maximum number of beats to be transferred in one RxDMA transaction is 64
ETH_RXDMABURSTLENGTH_4XPBL_128BEAT	maximum number of beats to be transferred in one RxDMA transaction is 128

ETH Rx Mode

ETH_RXPOLLING_MODE

ETH_RXINTERRUPT_MODE

ETH Second Frame Operate

ETH_SECONDFRAMEOPERARTE_ENABLE

ETH_SECONDFRAMEOPERARTE_DISABLE

ETH Source Addr Filter

ETH_SOURCEADDRFILTER_NORMAL_ENABLE

ETH_SOURCEADDRFILTER_INVERSE_ENABLE

ETH_SOURCEADDRFILTER_DISABLE

ETH Speed

ETH_SPEED_10M

ETH_SPEED_100M

ETH Transmit Flow Control

ETH_TRANSMITFLOWCONTROL_ENABLE

ETH_TRANSMITFLOWCONTROL_DISABLE

ETH Transmit Store Forward

ETH_TRANSMITSTOREFORWARD_ENABLE
ETH_TRANSMITSTOREFORWARD_DISABLE

ETH Transmit Threshold Control

ETH_TRANSMITTHRESHOLDCONTROL_64BYTES	threshold level of the MTL Transmit FIFO is 64 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_128BYTES	threshold level of the MTL Transmit FIFO is 128 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_192BYTES	threshold level of the MTL Transmit FIFO is 192 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_256BYTES	threshold level of the MTL Transmit FIFO is 256 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_40BYTES	threshold level of the MTL Transmit FIFO is 40 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_32BYTES	threshold level of the MTL Transmit FIFO is 32 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_24BYTES	threshold level of the MTL Transmit FIFO is 24 Bytes
ETH_TRANSMITTHRESHOLDCONTROL_16BYTES	threshold level of the MTL Transmit FIFO is 16 Bytes

ETH Tx DMA Burst Length

ETH_TXDMABURSTLENGTH_1BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 1
ETH_TXDMABURSTLENGTH_2BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 2
ETH_TXDMABURSTLENGTH_4BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 4
ETH_TXDMABURSTLENGTH_8BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 8
ETH_TXDMABURSTLENGTH_16BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 16
ETH_TXDMABURSTLENGTH_32BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 32
ETH_TXDMABURSTLENGTH_4XPBL_4BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 4
ETH_TXDMABURSTLENGTH_4XPBL_8BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 8
ETH_TXDMABURSTLENGTH_4XPBL_16BEAT	maximum number of beats to be

ETH_TXDMABURSTLENGTH_4XPBL_32BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 16
ETH_TXDMABURSTLENGTH_4XPBL_64BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 32
ETH_TXDMABURSTLENGTH_4XPBL_128BEAT	maximum number of beats to be transferred in one TxDMA (or both) transaction is 64

ETH Unicast Frames Filter

ETH_UNICASTFRAMESFILTER_PERFECTHASHTABLE
ETH_UNICASTFRAMESFILTER_HASHTABLE
ETH_UNICASTFRAMESFILTER_PERFECT

ETH Unicast Pause Frame Detect

ETH_UNICASTPAUSEFRAMEDETECT_ENABLE
ETH_UNICASTPAUSEFRAMEDETECT_DISABLE

ETH VLAN Tag Comparison

ETH_VLANTAGCOMPARISON_12BIT
ETH_VLANTAGCOMPARISON_16BIT

ETH Watchdog

ETH_WATCHDOG_ENABLE
ETH_WATCHDOG_DISABLE

ETH Zero Quanta Pause

ETH_ZEROQUANTAPAUSE_ENABLE
ETH_ZEROQUANTAPAUSE_DISABLE

21 HAL FLASH Generic Driver

21.1 HAL FLASH Generic Driver

21.2 FLASH Firmware driver registers structures

21.2.1 FLASH_ProcessTypeDef

Data Fields

- `__IO FLASH_ProcedureTypeDef ProcedureOnGoing`
- `__IO uint32_t NbSectorsToErase`
- `__IO uint8_t VoltageForErase`
- `__IO uint32_t Sector`
- `__IO uint32_t Bank`
- `__IO uint32_t Address`
- `HAL_LockTypeDef Lock`
- `__IO uint32_t ErrorCode`

Field Documentation

- `__IO FLASH_ProcedureTypeDef FLASH_ProcessTypeDef::ProcedureOnGoing`
- `__IO uint32_t FLASH_ProcessTypeDef::NbSectorsToErase`
- `__IO uint8_t FLASH_ProcessTypeDef::VoltageForErase`
- `__IO uint32_t FLASH_ProcessTypeDef::Sector`
- `__IO uint32_t FLASH_ProcessTypeDef::Bank`
- `__IO uint32_t FLASH_ProcessTypeDef::Address`
- `HAL_LockTypeDef FLASH_ProcessTypeDef::Lock`
- `__IO uint32_t FLASH_ProcessTypeDef::ErrorCode`

21.3 FLASH Firmware driver API description

21.3.1 FLASH peripheral features

The Flash memory interface manages CPU AHB I-Code and D-Code accesses to the Flash memory. It implements the erase and program Flash memory operations and the read and write protection mechanisms.

The Flash memory interface accelerates code execution with a system of instruction prefetch and cache lines.

The FLASH main features are:

- Flash memory read operations
- Flash memory program/erase operations
- Read / write protections
- Prefetch on I-Code
- 64 cache lines of 128 bits on I-Code
- 8 cache lines of 128 bits on D-Code

21.3.2 How to use this driver

This driver provides functions and macros to configure and program the FLASH memory of all STM32F4xx devices.

1. FLASH Memory IO Programming functions:
 - Lock and Unlock the FLASH interface using HAL_FLASH_Unlock() and HAL_FLASH_Lock() functions
 - Program functions: byte, half word, word and double word
 - There Two modes of programming :
 - Polling mode using HAL_FLASH_Program() function
 - Interrupt mode using HAL_FLASH_Program_IT() function
2. Interrupts and flags management functions :
 - Handle FLASH interrupts by calling HAL_FLASH_IRQHandler()
 - Wait for last FLASH operation according to its status
 - Get error flag status by calling HAL_SetErrorCode()

In addition to these functions, this driver includes a set of macros allowing to handle the following operations:

- Set the latency
- Enable/Disable the prefetch buffer
- Enable/Disable the Instruction cache and the Data cache
- Reset the Instruction cache and the Data cache
- Enable/Disable the FLASH interrupts
- Monitor the FLASH flags status

21.3.3 Programming operation functions

This subsection provides a set of functions allowing to manage the FLASH program operations.

This section contains the following APIs:

- [`HAL_FLASH_Program\(\)`](#)
- [`HAL_FLASH_Program_IT\(\)`](#)
- [`HAL_FLASH_IRQHandler\(\)`](#)
- [`HAL_FLASH_EndOfOperationCallback\(\)`](#)
- [`HAL_FLASH_OperationErrorCallback\(\)`](#)

21.3.4 Peripheral Control functions

This subsection provides a set of functions allowing to control the FLASH memory operations.

This section contains the following APIs:

- [`HAL_FLASH_Unlock\(\)`](#)
- [`HAL_FLASH_Lock\(\)`](#)
- [`HAL_FLASH_OB_Unlock\(\)`](#)
- [`HAL_FLASH_OB_Lock\(\)`](#)
- [`HAL_FLASH_OB_Launch\(\)`](#)

21.3.5 Peripheral Errors functions

This subsection permits to get in run-time Errors of the FLASH peripheral.

This section contains the following APIs:

- [`HAL_FLASH_GetError\(\)`](#)

-
- ***FLASH_WaitForLastOperation()***

21.3.6 HAL_FLASH_Program

Function Name	HAL_StatusTypeDef HAL_FLASH_Program (uint32_t TypeProgram, uint32_t Address, uint64_t Data)
Function Description	Program byte, halfword, word or double word at a specified address.
Parameters	<ul style="list-style-type: none"> • TypeProgram: Indicate the way to program at a specified address. This parameter can be a value of FLASH Type Program • Address: specifies the address to be programmed. • Data: specifies the data to be programmed
Return values	• HAL_StatusTypeDef HAL Status

21.3.7 HAL_FLASH_Program_IT

Function Name	HAL_StatusTypeDef HAL_FLASH_Program_IT (uint32_t TypeProgram, uint32_t Address, uint64_t Data)
Function Description	Program byte, halfword, word or double word at a specified address with interrupt enabled.
Parameters	<ul style="list-style-type: none"> • TypeProgram: Indicate the way to program at a specified address. This parameter can be a value of FLASH Type Program • Address: specifies the address to be programmed. • Data: specifies the data to be programmed
Return values	• HAL Status

21.3.8 HAL_FLASH_IRQHandler

Function Name	void HAL_FLASH_IRQHandler (void)
Function Description	This function handles FLASH interrupt request.
Return values	<ul style="list-style-type: none"> • None

21.3.9 HAL_FLASH_EndOfOperationCallback

Function Name	void HAL_FLASH_EndOfOperationCallback (uint32_t ReturnValue)
Function Description	FLASH end of operation interrupt callback.
Parameters	<ul style="list-style-type: none"> • ReturnValue: The value saved in this parameter depends on the ongoing procedure Mass Erase: Bank number which has been requested to erase Sectors Erase: Sector which has been erased (if 0xFFFFFFFF, it means that all the selected sectors have been erased) Program: Address which was selected for data program
Return values	<ul style="list-style-type: none"> • None

21.3.10 HAL_FLASH_OperationErrorHandler

Function Name	void HAL_FLASH_OperationErrorCallback (uint32_t ReturnValue)
Function Description	FLASH operation error interrupt callback.
Parameters	<ul style="list-style-type: none"> ReturnValue: The value saved in this parameter depends on the ongoing procedure Mass Erase: Bank number which has been requested to erase Sectors Erase: Sector number which returned an error Program: Address which was selected for data program
Return values	<ul style="list-style-type: none"> None

21.3.11 HAL_FLASH_Unlock

Function Name	HAL_StatusTypeDef HAL_FLASH_Unlock (void)
Function Description	Unlock the FLASH control register access.
Return values	<ul style="list-style-type: none"> HAL Status

21.3.12 HAL_FLASH_Lock

Function Name	HAL_StatusTypeDef HAL_FLASH_Lock (void)
Function Description	Locks the FLASH control register access.
Return values	<ul style="list-style-type: none"> HAL Status

21.3.13 HAL_FLASH_OB_Unlock

Function Name	HAL_StatusTypeDef HAL_FLASH_OB_Unlock (void)
Function Description	Unlock the FLASH Option Control Registers access.
Return values	<ul style="list-style-type: none"> HAL Status

21.3.14 HAL_FLASH_OB_Lock

Function Name	HAL_StatusTypeDef HAL_FLASH_OB_Lock (void)
Function Description	Lock the FLASH Option Control Registers access.
Return values	<ul style="list-style-type: none"> HAL Status

21.3.15 HAL_FLASH_OB_Launch

Function Name	HAL_StatusTypeDef HAL_FLASH_OB_Launch (void)
Function Description	Launch the option byte loading.
Return values	<ul style="list-style-type: none"> HAL Status

21.3.16 HAL_FLASH_GetError

Function Name	uint32_t HAL_FLASH_GetError (void)
Function Description	Get the specific FLASH error flag.
Return values	<ul style="list-style-type: none"> FLASH_ErrorCode The returned value can be a combination of: HAL_FLASH_ERROR_RD: FLASH Read Protection error flag (PCROP) HAL_FLASH_ERROR_PGS: FLASH

Programming Sequence error flag
 HAL_FLASH_ERROR_PGP: FLASH Programming
 Parallelism error flag HAL_FLASH_ERROR_PGA: FLASH
 Programming Alignment error flag
 HAL_FLASH_ERROR_WRP: FLASH Write protected error
 flag HAL_FLASH_ERROR_OPERATION: FLASH operation
 Error flag

21.3.17 **FLASH_WaitForLastOperation**

Function Name	HAL_StatusTypeDef FLASH_WaitForLastOperation (uint32_t Timeout)
Function Description	Wait for a FLASH operation to complete.
Parameters	<ul style="list-style-type: none"> • Timeout: maximum flash operation timeout
Return values	<ul style="list-style-type: none"> • HAL Status

21.4 **FLASH Firmware driver defines**

21.4.1 **FLASH**

FLASH Error Code

HAL_FLASH_ERROR_NONE	No error
HAL_FLASH_ERROR_RD	Read Protection error
HAL_FLASH_ERROR_PGS	Programming Sequence error
HAL_FLASH_ERROR_PGP	Programming Parallelism error
HAL_FLASH_ERROR_PGA	Programming Alignment error
HAL_FLASH_ERROR_WRP	Write protection error
HAL_FLASH_ERROR_OPERATION	Operation Error

FLASH Exported Macros

_HAL_FLASH_SET_LATENCY	Description: <ul style="list-style-type: none"> • Set the FLASH Latency. Parameters: <ul style="list-style-type: none"> • _LATENCY_: FLASH Latency The value of this parameter depend on device used within the same series Return value: <ul style="list-style-type: none"> • none
_HAL_FLASH_GET_LATENCY	Description: <ul style="list-style-type: none"> • Get the FLASH Latency. Return value: <ul style="list-style-type: none"> • FLASH: Latency The value of this parameter depend on device

used within the same series

`_HAL_FLASH_PREFETCH_BUFFER_ENABLE`

Description:

- Enable the FLASH prefetch buffer.

Return value:

- none

`_HAL_FLASH_PREFETCH_BUFFER_DISABLE`

Description:

- Disable the FLASH prefetch buffer.

Return value:

- none

`_HAL_FLASH_INSTRUCTION_CACHE_ENABLE`

Description:

- Enable the FLASH instruction cache.

Return value:

- none

`_HAL_FLASH_INSTRUCTION_CACHE_DISABLE`

Description:

- Disable the FLASH instruction cache.

Return value:

- none

`_HAL_FLASH_DATA_CACHE_ENABLE`

Description:

- Enable the FLASH data cache.

Return value:

- none

`_HAL_FLASH_DATA_CACHE_DISABLE`

Description:

- Disable the FLASH data cache.

Return value:

- none

`_HAL_FLASH_INSTRUCTION_CACHE_RESET`

Description:

- Resets the FLASH instruction Cache.

Return value:

- None

Notes:

- This function must be used only when the Instruction Cache is disabled.

[__HAL_FLASH_DATA_CACHE_RESET](#)**Description:**

- Resets the FLASH data Cache.

Return value:

- None

Notes:

- This function must be used only when the data Cache is disabled.

[__HAL_FLASH_ENABLE_IT](#)**Description:**

- Enable the specified FLASH interrupt.

Parameters:

- [__INTERRUPT__](#): : FLASH interrupt This parameter can be any combination of the following values:
 - FLASH_IT_EOP: End of FLASH Operation Interrupt
 - FLASH_IT_ERR: Error Interrupt

Return value:

- none

[__HAL_FLASH_DISABLE_IT](#)**Description:**

- Disable the specified FLASH interrupt.

Parameters:

- [__INTERRUPT__](#): : FLASH interrupt This parameter can be any combination of the following values:
 - FLASH_IT_EOP: End of FLASH Operation Interrupt
 - FLASH_IT_ERR: Error Interrupt

Return value:

- none

[__HAL_FLASH_GET_FLAG](#)**Description:**

- Get the specified FLASH flag status.

Parameters:

- [__FLAG__](#): specifies the FLASH flag to check. This parameter can be one of the following values:
 - FLASH_FLAG_EOP : FLASH End of Operation flag

- FLASH_FLAG_OPERR : FLASH operation Error flag
- FLASH_FLAG_WRPERR: FLASH Write protected error flag
- FLASH_FLAG_PGAERR: FLASH Programming Alignment error flag
- FLASH_FLAG_PGPERR: FLASH Programming Parallelism error flag
- FLASH_FLAG_PGSERR: FLASH Programming Sequence error flag
- FLASH_FLAG_RDERR : FLASH Read Protection error flag (PCROP)
- FLASH_FLAG_BSY : FLASH Busy flag

Return value:

- The new state of __FLAG__ (SET or RESET).

[__HAL_FLASH_CLEAR_FLAG](#)**Description:**

- Clear the specified FLASH flag.

Parameters:

- __FLAG__: specifies the FLASH flags to clear. This parameter can be any combination of the following values:
 - FLASH_FLAG_EOP : FLASH End of Operation flag
 - FLASH_FLAG_OPERR : FLASH operation Error flag
 - FLASH_FLAG_WRPERR: FLASH Write protected error flag
 - FLASH_FLAG_PGAERR: FLASH Programming Alignment error flag
 - FLASH_FLAG_PGPERR: FLASH Programming Parallelism error flag
 - FLASH_FLAG_PGSERR: FLASH Programming Sequence error flag
 - FLASH_FLAG_RDERR : FLASH Read Protection error flag (PCROP)

Return value:

- none

FLASH Flag definition

FLASH_FLAG_EOP	FLASH End of Operation flag
FLASH_FLAG_OPERR	FLASH operation Error flag
FLASH_FLAG_WRPERR	FLASH Write protected error flag
FLASH_FLAG_PGAERR	FLASH Programming Alignment error flag
FLASH_FLAG_PGPERR	FLASH Programming Parallelism error flag
FLASH_FLAG_PGSERR	FLASH Programming Sequence error flag
FLASH_FLAG_RDERR	Read Protection error flag (PCROP)
FLASH_FLAG_BSY	FLASH Busy flag

FLASH Interrupt definition

FLASH_IT_EOP	End of FLASH Operation Interrupt source
FLASH_IT_ERR	Error Interrupt source

FLASH Private macros to check input parameters

IS_FLASH_TYPEPROGRAM

FLASH Keys

RDP_KEY	
FLASH_KEY1	
FLASH_KEY2	
FLASH_OPT_KEY1	
FLASH_OPT_KEY2	

FLASH Latency

FLASH_LATENCY_0	FLASH Zero Latency cycle
FLASH_LATENCY_1	FLASH One Latency cycle
FLASH_LATENCY_2	FLASH Two Latency cycles
FLASH_LATENCY_3	FLASH Three Latency cycles
FLASH_LATENCY_4	FLASH Four Latency cycles
FLASH_LATENCY_5	FLASH Five Latency cycles
FLASH_LATENCY_6	FLASH Six Latency cycles
FLASH_LATENCY_7	FLASH Seven Latency cycles
FLASH_LATENCY_8	FLASH Eight Latency cycles
FLASH_LATENCY_9	FLASH Nine Latency cycles
FLASH_LATENCY_10	FLASH Ten Latency cycles
FLASH_LATENCY_11	FLASH Eleven Latency cycles
FLASH_LATENCY_12	FLASH Twelve Latency cycles
FLASH_LATENCY_13	FLASH Thirteen Latency cycles
FLASH_LATENCY_14	FLASH Fourteen Latency cycles

FLASH_LATENCY_15 FLASH Fifteen Latency cycles

FLASH Private Constants

FLASH_TIMEOUT_VALUE

ACR_BYTE0_ADDRESS

OPTCR_BYTE0_ADDRESS

OPTCR_BYTE1_ADDRESS

OPTCR_BYTE2_ADDRESS

OPTCR_BYTE3_ADDRESS

FLASH Program Parallelism

FLASH_PSIZE_BYTE

FLASH_PSIZE_HALF_WORD

FLASH_PSIZE_WORD

FLASH_PSIZE_DOUBLE_WORD

CR_PSIZE_MASK

FLASH Type Program

FLASH_TYPEPROGRAM_BYTE Program byte (8-bit) at a specified address

FLASH_TYPEPROGRAM_HALFWORD Program a half-word (16-bit) at a specified address

FLASH_TYPEPROGRAM_WORD Program a word (32-bit) at a specified address

FLASH_TYPEPROGRAM_DOUBLEWORD Program a double word (64-bit) at a specified address

22 HAL FLASH Extension Driver

22.1 HAL FLASH Extension Driver

22.2 FLASHEx Firmware driver registers structures

22.2.1 FLASH_EraselInitTypeDef

Data Fields

- *uint32_t TypeErase*
- *uint32_t Banks*
- *uint32_t Sector*
- *uint32_t NbSectors*
- *uint32_t VoltageRange*

Field Documentation

- ***uint32_t FLASH_EraselInitTypeDef::TypeErase***
Mass erase or sector Erase. This parameter can be a value of [**FLASHEx_Type_Erase**](#)
- ***uint32_t FLASH_EraselInitTypeDef::Banks***
Select banks to erase when Mass erase is enabled. This parameter must be a value of [**FLASHEx_Banks**](#)
- ***uint32_t FLASH_EraselInitTypeDef::Sector***
Initial FLASH sector to erase when Mass erase is disabled This parameter must be a value of [**FLASHEx_Sectors**](#)
- ***uint32_t FLASH_EraselInitTypeDef::NbSectors***
Number of sectors to be erased. This parameter must be a value between 1 and (max number of sectors - value of Initial sector)
- ***uint32_t FLASH_EraselInitTypeDef::VoltageRange***
The device voltage range which defines the erase parallelism This parameter must be a value of [**FLASHEx_Voltage_Range**](#)

22.2.2 FLASH_OBProgramInitTypeDef

Data Fields

- *uint32_t OptionType*
- *uint32_t WRPState*
- *uint32_t WRPSector*
- *uint32_t Banks*
- *uint32_t RDPLevel*
- *uint32_t BORLevel*
- *uint8_t USERConfig*

Field Documentation

- ***uint32_t FLASH_OBProgramInitTypeDef::OptionType***
Option byte to be configured. This parameter can be a value of ***FLASHEx_Option_Type***
- ***uint32_t FLASH_OBProgramInitTypeDef::WRPState***
Write protection activation or deactivation. This parameter can be a value of ***FLASHEx_WRP_State***
- ***uint32_t FLASH_OBProgramInitTypeDef::WRPSector***
Specifies the sector(s) to be write protected. The value of this parameter depend on device used within the same series
- ***uint32_t FLASH_OBProgramInitTypeDef::Banks***
Select banks for WRP activation/deactivation of all sectors. This parameter must be a value of ***FLASHEx_Banks***
- ***uint32_t FLASH_OBProgramInitTypeDef::RDPLevel***
Set the read protection level. This parameter can be a value of ***FLASHEx_Option_Bytes_Read_Protection***
- ***uint32_t FLASH_OBProgramInitTypeDef::BORLevel***
Set the BOR Level. This parameter can be a value of ***FLASHEx_BOR_Reset_Level***
- ***uint8_t FLASH_OBProgramInitTypeDef::USERConfig***
Program the FLASH User Option Byte: IWDG_SW / RST_STOP / RST_STDBY.

22.2.3 **FLASH_AdvOBProgramInitTypeDef**

Data Fields

- ***uint32_t OptionType***
- ***uint32_t PCROPState***
- ***uint32_t Banks***
- ***uint16_t SectorsBank1***
- ***uint16_t SectorsBank2***
- ***uint8_t BootConfig***

Field Documentation

- ***uint32_t FLASH_AdvOBProgramInitTypeDef::OptionType***
Option byte to be configured for extension. This parameter can be a value of ***FLASHEx_Advanced_Option_Type***
- ***uint32_t FLASH_AdvOBProgramInitTypeDef::PCROPState***
PCROP activation or deactivation. This parameter can be a value of ***FLASHEx_PCROP_State***
- ***uint32_t FLASH_AdvOBProgramInitTypeDef::Banks***
Select banks for PCROP activation/deactivation of all sectors. This parameter must be a value of ***FLASHEx_Banks***
- ***uint16_t FLASH_AdvOBProgramInitTypeDef::SectorsBank1***
Specifies the sector(s) set for PCROP for Bank1. This parameter can be a value of ***FLASHEx_Option_Bytes_PC_ReadWrite_Protection***
- ***uint16_t FLASH_AdvOBProgramInitTypeDef::SectorsBank2***
Specifies the sector(s) set for PCROP for Bank2. This parameter can be a value of ***FLASHEx_Option_Bytes_PC_ReadWrite_Protection***
- ***uint8_t FLASH_AdvOBProgramInitTypeDef::BootConfig***
Specifies Option bytes for boot config. This parameter can be a value of ***FLASHEx_Dual_Boot***

22.3 FLASHEx Firmware driver API description

22.3.1 Flash Extension features

Comparing to other previous devices, the FLASH interface for STM32F427xx/437xx and STM32F429xx/439xx devices contains the following additional features

- Capacity up to 2 Mbyte with dual bank architecture supporting read-while-write capability (RWW)
- Dual bank memory organization
- PCROP protection for all banks

22.3.2 How to use this driver

This driver provides functions to configure and program the FLASH memory of all STM32F427xx/437xx, STM32F429xx/439xx, STM32F469xx/479xx and STM32F446xx devices. It includes

1. FLASH Memory Erase functions:
 - Lock and Unlock the FLASH interface using HAL_FLASH_Unlock() and HAL_FLASH_Lock() functions
 - Erase function: Erase sector, erase all sectors
 - There are two modes of erase :
 - Polling Mode using HAL_FLASHEx_Erase()
 - Interrupt Mode using HAL_FLASHEx_Erase_IT()
2. Option Bytes Programming functions: Use HAL_FLASHEx_OBProgram() to :
 - Set/Reset the write protection
 - Set the Read protection Level
 - Set the BOR level
 - Program the user Option Bytes
3. Advanced Option Bytes Programming functions: Use HAL_FLASHEx_AdvOBProgram() to :
 - Extended space (bank 2) erase function
 - Full FLASH space (2 Mo) erase (bank 1 and bank 2)
 - Dual Boot activation
 - Write protection configuration for bank 2
 - PCROP protection configuration and control for both banks

22.3.3 Extended programming operation functions

This subsection provides a set of functions allowing to manage the Extension FLASH programming operations.

This section contains the following APIs:

- [`HAL_FLASHEx_Erase\(\)`](#)
- [`HAL_FLASHEx_Erase_IT\(\)`](#)
- [`HAL_FLASHEx_OBProgram\(\)`](#)
- [`HAL_FLASHEx_OBGetConfig\(\)`](#)
- [`HAL_FLASHEx_AdvOBProgram\(\)`](#)
- [`HAL_FLASHEx_AdvOBGetConfig\(\)`](#)
- [`HAL_FLASHEx_OB_SelectPCROP\(\)`](#)
- [`HAL_FLASHEx_OB_DeSelectPCROP\(\)`](#)
- [`HAL_FLASHEx_OB_GetBank2WRP\(\)`](#)

22.3.4 HAL_FLASHEx_Erase

Function Name	<code>HAL_StatusTypeDef HAL_FLASHEx_Erase (FLASH_EraselTypeDef * pEraselInit, uint32_t * SectorError)</code>
Function Description	Perform a mass erase or erase the specified FLASH memory sectors.
Parameters	<ul style="list-style-type: none"> • pEraselInit: pointer to an FLASH_EraselTypeDef structure that contains the configuration information for the erasing. • SectorError: pointer to variable that contains the configuration information on faulty sector in case of error (0xFFFFFFFF means that all the sectors have been correctly erased)
Return values	<ul style="list-style-type: none"> • HAL Status

22.3.5 HAL_FLASHEx_Erase_IT

Function Name	<code>HAL_StatusTypeDef HAL_FLASHEx_Erase_IT (FLASH_EraselTypeDef * pEraselInit)</code>
Function Description	Perform a mass erase or erase the specified FLASH memory sectors with interrupt enabled.
Parameters	<ul style="list-style-type: none"> • pEraselInit: pointer to an FLASH_EraselTypeDef structure that contains the configuration information for the erasing.
Return values	<ul style="list-style-type: none"> • HAL Status

22.3.6 HAL_FLASHEx_OBProgram

Function Name	<code>HAL_StatusTypeDef HAL_FLASHEx_OBProgram (FLASH_OBProgramInitTypeDef * pOBInit)</code>
Function Description	Program option bytes.
Parameters	<ul style="list-style-type: none"> • pOBInit: pointer to an FLASH_OBInitStruct structure that contains the configuration information for the programming.
Return values	<ul style="list-style-type: none"> • HAL Status

22.3.7 HAL_FLASHEx_OBGetConfig

Function Name	<code>void HAL_FLASHEx_OBGetConfig (FLASH_OBProgramInitTypeDef * pOBInit)</code>
Function Description	Get the Option byte configuration.
Parameters	<ul style="list-style-type: none"> • pOBInit: pointer to an FLASH_OBInitStruct structure that contains the configuration information for the programming.
Return values	<ul style="list-style-type: none"> • None

22.3.8 HAL_FLASHEx_AdvOBProgram

Function Name	<code>HAL_StatusTypeDef HAL_FLASHEx_AdvOBProgram (FLASH_AdvOBProgramInitTypeDef * pAdvOBInit)</code>
Function Description	Program option bytes.

Parameters	<ul style="list-style-type: none"> pAdvOBInit: pointer to an FLASH_AdvOBProgramInitTypeDef structure that contains the configuration information for the programming.
Return values	<ul style="list-style-type: none"> HAL Status

22.3.9 HAL_FLASHEx_AdvOBGetConfig

Function Name	void HAL_FLASHEx_AdvOBGetConfig (FLASH_AdvOBProgramInitTypeDef * pAdvOBInit)
Function Description	Get the OBEX byte configuration.
Parameters	<ul style="list-style-type: none"> pAdvOBInit: pointer to an FLASH_AdvOBProgramInitTypeDef structure that contains the configuration information for the programming.
Return values	<ul style="list-style-type: none"> None

22.3.10 HAL_FLASHEx_OB_SelectPCROP

Function Name	HAL_StatusTypeDef HAL_FLASHEx_OB_SelectPCROP (void)
Function Description	Select the Protection Mode.
Return values	<ul style="list-style-type: none"> HAL Status
Notes	<ul style="list-style-type: none"> After PCROP activated Option Byte modification NOT POSSIBLE! excepted Global Read Out Protection modification (from level1 to level0) Once SPRMOD bit is active unprotection of a protected sector is not possible Read a protected sector will set RDERR Flag and write a protected sector will set WRPERR Flag This function can be used only for STM32F42xxx/STM32F43xxx/STM32F401xx/STM32F411xx/STM32F446xx/ STM32F469xx/STM32F479xx/STM32F412xG devices.

22.3.11 HAL_FLASHEx_OB_DeSelectPCROP

Function Name	HAL_StatusTypeDef HAL_FLASHEx_OB_DeSelectPCROP (void)
Function Description	Deselect the Protection Mode.
Return values	<ul style="list-style-type: none"> HAL Status
Notes	<ul style="list-style-type: none"> After PCROP activated Option Byte modification NOT POSSIBLE! excepted Global Read Out Protection modification (from level1 to level0) Once SPRMOD bit is active unprotection of a protected sector is not possible Read a protected sector will set RDERR Flag and write a protected sector will set WRPERR Flag

- This function can be used only for STM32F42xxx/STM32F43xxx/STM32F401xx/STM32F411xx/STM32F446xx/ STM32F469xx/STM32F479xx/STM32F412xG devices.

22.3.12 HAL_FLASHEx_OB_GetBank2WRP

Function Name	<code>uint16_t HAL_FLASHEx_OB_GetBank2WRP (void)</code>
Function Description	Returns the FLASH Write Protection Option Bytes value for Bank 2.
Return values	<ul style="list-style-type: none"> • The FLASH Write Protection Option Bytes value
Notes	<ul style="list-style-type: none"> • This function can be used only for STM32F42xxx/STM32F43xxx/STM32F469xx/STM32F479xx devices.

22.4 FLASHEx Firmware driver defines

22.4.1 FLASHEx

FLASH Advanced Option Type

<code>OPTIONBYTE_PCROP</code>	PCROP option byte configuration
<code>OPTIONBYTE_BOOTCONFIG</code>	BOOTConfig option byte configuration

FLASH Banks

<code>FLASH_BANK_1</code>	Bank 1
<code>FLASH_BANK_2</code>	Bank 2
<code>FLASH_BANK_BOTH</code>	Bank1 and Bank2

FLASH BOR Reset Level

<code>OB_BOR_LEVEL3</code>	Supply voltage ranges from 2.70 to 3.60 V
<code>OB_BOR_LEVEL2</code>	Supply voltage ranges from 2.40 to 2.70 V
<code>OB_BOR_LEVEL1</code>	Supply voltage ranges from 2.10 to 2.40 V
<code>OB_BOR_OFF</code>	Supply voltage ranges from 1.62 to 2.10 V

FLASH Dual Boot

<code>OB_DUAL_BOOT_ENABLE</code>	Dual Bank Boot Enable
<code>OB_DUAL_BOOT_DISABLE</code>	Dual Bank Boot Disable, always boot on User Flash

FLASH Private macros to check input parameters

<code>IS_FLASH_TYPEERASE</code>
<code>IS_VOLTAGERANGE</code>
<code>IS_WRPSTATE</code>
<code>IS_OPTIONBYTE</code>
<code>IS_OB_RDP_LEVEL</code>
<code>IS_OB_IWDG_SOURCE</code>
<code>IS_OB_STOP_SOURCE</code>

IS_OB_STDBY_SOURCE
 IS_OB_BOR_LEVEL
 IS_PCROPSTATE
 IS_OBEX
 IS_FLASH_LATENCY
 IS_FLASH_BANK
 IS_FLASH_SECTOR
 IS_FLASH_ADDRESS
 IS_FLASH_NBSECTORS
 IS_OB_WRP_SECTOR
 IS_OB_PCROP
 IS_OB_BOOT
 IS_OB_PCROP_SELECT

FLASH Mass Erase bit

FLASH_MER_BIT 2 MER bits here to clear

FLASH Option Bytes IWatchdog

OB_IWDG_SW	Software IWDG selected
OB_IWDG_HW	Hardware IWDG selected

FLASH Option Bytes nRST_STDBY

OB_STDBY_NO_RST	No reset generated when entering in STANDBY
OB_STDBY_RST	Reset generated when entering in STANDBY

FLASH Option Bytes nRST_STOP

OB_STOP_NO_RST	No reset generated when entering in STOP
OB_STOP_RST	Reset generated when entering in STOP

FLASH Option Bytes PC ReadWrite Protection

OB_PCROP_SECTOR_0	PC Read/Write protection of Sector0
OB_PCROP_SECTOR_1	PC Read/Write protection of Sector1
OB_PCROP_SECTOR_2	PC Read/Write protection of Sector2
OB_PCROP_SECTOR_3	PC Read/Write protection of Sector3
OB_PCROP_SECTOR_4	PC Read/Write protection of Sector4
OB_PCROP_SECTOR_5	PC Read/Write protection of Sector5
OB_PCROP_SECTOR_6	PC Read/Write protection of Sector6
OB_PCROP_SECTOR_7	PC Read/Write protection of Sector7
OB_PCROP_SECTOR_8	PC Read/Write protection of Sector8
OB_PCROP_SECTOR_9	PC Read/Write protection of Sector9
OB_PCROP_SECTOR_10	PC Read/Write protection of Sector10

OB_PCROP_SECTOR_11	PC Read/Write protection of Sector11
OB_PCROP_SECTOR_12	PC Read/Write protection of Sector12
OB_PCROP_SECTOR_13	PC Read/Write protection of Sector13
OB_PCROP_SECTOR_14	PC Read/Write protection of Sector14
OB_PCROP_SECTOR_15	PC Read/Write protection of Sector15
OB_PCROP_SECTOR_16	PC Read/Write protection of Sector16
OB_PCROP_SECTOR_17	PC Read/Write protection of Sector17
OB_PCROP_SECTOR_18	PC Read/Write protection of Sector18
OB_PCROP_SECTOR_19	PC Read/Write protection of Sector19
OB_PCROP_SECTOR_20	PC Read/Write protection of Sector20
OB_PCROP_SECTOR_21	PC Read/Write protection of Sector21
OB_PCROP_SECTOR_22	PC Read/Write protection of Sector22
OB_PCROP_SECTOR_23	PC Read/Write protection of Sector23
OB_PCROP_SECTOR_All	PC Read/Write protection of all Sectors

FLASH Option Bytes Read Protection

OB_RDP_LEVEL_0	
OB_RDP_LEVEL_1	
OB_RDP_LEVEL_2	Warning: When enabling read protection level 2 it's no more possible to go back to level 1 or 0

FLASH Option Bytes Write Protection

OB_WRP_SECTOR_0	Write protection of Sector0
OB_WRP_SECTOR_1	Write protection of Sector1
OB_WRP_SECTOR_2	Write protection of Sector2
OB_WRP_SECTOR_3	Write protection of Sector3
OB_WRP_SECTOR_4	Write protection of Sector4
OB_WRP_SECTOR_5	Write protection of Sector5
OB_WRP_SECTOR_6	Write protection of Sector6
OB_WRP_SECTOR_7	Write protection of Sector7
OB_WRP_SECTOR_8	Write protection of Sector8
OB_WRP_SECTOR_9	Write protection of Sector9
OB_WRP_SECTOR_10	Write protection of Sector10
OB_WRP_SECTOR_11	Write protection of Sector11
OB_WRP_SECTOR_12	Write protection of Sector12
OB_WRP_SECTOR_13	Write protection of Sector13
OB_WRP_SECTOR_14	Write protection of Sector14
OB_WRP_SECTOR_15	Write protection of Sector15
OB_WRP_SECTOR_16	Write protection of Sector16

OB_WRP_SECTOR_17	Write protection of Sector17
OB_WRP_SECTOR_18	Write protection of Sector18
OB_WRP_SECTOR_19	Write protection of Sector19
OB_WRP_SECTOR_20	Write protection of Sector20
OB_WRP_SECTOR_21	Write protection of Sector21
OB_WRP_SECTOR_22	Write protection of Sector22
OB_WRP_SECTOR_23	Write protection of Sector23
OB_WRP_SECTOR_ALL	Write protection of all Sectors

FLASH Option Type

OPTIONBYTE_WRP	WRP option byte configuration
OPTIONBYTE_RDP	RDP option byte configuration
OPTIONBYTE_USER	USER option byte configuration
OPTIONBYTE_BOR	BOR option byte configuration

FLASH PCROP State

OB_PCROP_STATE_DISABLE	Disable PCROP
OB_PCROP_STATE_ENABLE	Enable PCROP

FLASH Private Constants

FLASH_TIMEOUT_VALUE	
FLASH_SECTOR_TOTAL	
OPTCR1_BYTE2_ADDRESS	

FLASH Sectors

FLASH_SECTOR_0	Sector Number 0
FLASH_SECTOR_1	Sector Number 1
FLASH_SECTOR_2	Sector Number 2
FLASH_SECTOR_3	Sector Number 3
FLASH_SECTOR_4	Sector Number 4
FLASH_SECTOR_5	Sector Number 5
FLASH_SECTOR_6	Sector Number 6
FLASH_SECTOR_7	Sector Number 7
FLASH_SECTOR_8	Sector Number 8
FLASH_SECTOR_9	Sector Number 9
FLASH_SECTOR_10	Sector Number 10
FLASH_SECTOR_11	Sector Number 11
FLASH_SECTOR_12	Sector Number 12
FLASH_SECTOR_13	Sector Number 13
FLASH_SECTOR_14	Sector Number 14

FLASH_SECTOR_15	Sector Number 15
FLASH_SECTOR_16	Sector Number 16
FLASH_SECTOR_17	Sector Number 17
FLASH_SECTOR_18	Sector Number 18
FLASH_SECTOR_19	Sector Number 19
FLASH_SECTOR_20	Sector Number 20
FLASH_SECTOR_21	Sector Number 21
FLASH_SECTOR_22	Sector Number 22
FLASH_SECTOR_23	Sector Number 23

FLASH Selection Protection Mode

OB_PCROP_DESELECTED	Disabled PcROP, nWPRi bits used for Write Protection on sector i
OB_PCROP_SELECTED	Enable PcROP, nWPRi bits used for PCRoP Protection on sector i

FLASH Type Erase

FLASH_TYPEERASE_SECTORS	Sectors erase only
FLASH_TYPEERASE_MASSERASE	Flash Mass erase activation

FLASH Voltage Range

FLASH_VOLTAGE_RANGE_1	Device operating range: 1.8V to 2.1V
FLASH_VOLTAGE_RANGE_2	Device operating range: 2.1V to 2.7V
FLASH_VOLTAGE_RANGE_3	Device operating range: 2.7V to 3.6V
FLASH_VOLTAGE_RANGE_4	Device operating range: 2.7V to 3.6V + External Vpp

FLASH WRP State

OB_WRPSTATE_DISABLE	Disable the write protection of the desired bank 1 sectors
OB_WRPSTATE_ENABLE	Enable the write protection of the desired bank 1 sectors

23 HAL FLASH__RAMFUNC Generic Driver

23.1 HAL FLASH__RAMFUNC Generic Driver

23.2 FLASH__RAMFUNC Firmware driver API description

23.2.1 APIs executed from Internal RAM

ARM Compiler

RAM functions are defined using the toolchain options. Functions that are to be executed in RAM should reside in a separate source module. Using the 'Options for File' dialog you can simply change the 'Code / Const' area of a module to a memory space in physical RAM. Available memory areas are declared in the 'Target' tab of the Options for Target dialog.

ICCARM Compiler

RAM functions are defined using a specific toolchain keyword "`__ramfunc`".

GNU Compiler

RAM functions are defined using a specific toolchain attribute
`"__attribute__((section(".RamFunc")))"`.

23.2.2 ramfunc functions

This subsection provides a set of functions that should be executed from RAM transfers.

This section contains the following APIs:

- `HAL_FLASHEx_StopFlashInterfaceClk()`
- `HAL_FLASHEx_StartFlashInterfaceClk()`
- `HAL_FLASHEx_EnableFlashSleepMode()`
- `HAL_FLASHEx_DisableFlashSleepMode()`

23.2.3 HAL_FLASHEx_StopFlashInterfaceClk

Function Name `__RAM_FUNC HAL_FLASHEx_StopFlashInterfaceClk (void)`

Function Description Stop the flash interface while System Run.

Return values

- None

Notes

- This mode is only available for STM32F41xxx/STM32F446xx devices.
- This mode couldn't be set while executing with the flash itself. It should be done with specific routine executed from RAM.

23.2.4 HAL_FLASHEx_StartFlashInterfaceClk

Function Name `__RAM_FUNC HAL_FLASHEx_StartFlashInterfaceClk (void)`

Function Description Start the flash interface while System Run.

Return values	<ul style="list-style-type: none">None
Notes	<ul style="list-style-type: none">This mode is only available for STM32F411xx/STM32F446xx devices.This mode couldn't be set while executing with the flash itself. It should be done with specific routine executed from RAM.

23.2.5 HAL_FLASHEx_EnableFlashSleepMode

Function Name	<code>__RAM_FUNC HAL_FLASHEx_EnableFlashSleepMode (void)</code>
Function Description	Enable the flash sleep while System Run.
Return values	<ul style="list-style-type: none">None
Notes	<ul style="list-style-type: none">This mode is only available for STM32F41xxx/STM32F446xx devices.This mode could n't be set while executing with the flash itself. It should be done with specific routine executed from RAM.

23.2.6 HAL_FLASHEx_DisableFlashSleepMode

Function Name	<code>__RAM_FUNC HAL_FLASHEx_DisableFlashSleepMode (void)</code>
Function Description	Disable the flash sleep while System Run.
Return values	<ul style="list-style-type: none">None
Notes	<ul style="list-style-type: none">This mode is only available for STM32F41xxx/STM32F446xx devices.This mode couldn't be set while executing with the flash itself. It should be done with specific routine executed from RAM.

23.3 FLASH__RAMFUNC Firmware driver defines

23.3.1 FLASH__RAMFUNC

24 HAL FMPI2C Generic Driver

24.1 HAL FMPI2C Generic Driver

24.2 FMPI2C Firmware driver registers structures

24.2.1 FMPI2C_InitTypeDef

Data Fields

- *uint32_t Timing*
- *uint32_t OwnAddress1*
- *uint32_t AddressingMode*
- *uint32_t DualAddressMode*
- *uint32_t OwnAddress2*
- *uint32_t OwnAddress2Masks*
- *uint32_t GeneralCallMode*
- *uint32_t NoStretchMode*

Field Documentation

- ***uint32_t FMPI2C_InitTypeDef::Timing***
Specifies the FMPI2C_TIMINGR_register value. This parameter calculated by referring to FMPI2C initialization section in Reference manual
- ***uint32_t FMPI2C_InitTypeDef::OwnAddress1***
Specifies the first device own address. This parameter can be a 7-bit or 10-bit address.
- ***uint32_t FMPI2C_InitTypeDef::AddressingMode***
Specifies if 7-bit or 10-bit addressing mode is selected. This parameter can be a value of [**FMPI2C_addressing_mode**](#)
- ***uint32_t FMPI2C_InitTypeDef::DualAddressMode***
Specifies if dual addressing mode is selected. This parameter can be a value of [**FMPI2C_dual_addressing_mode**](#)
- ***uint32_t FMPI2C_InitTypeDef::OwnAddress2***
Specifies the second device own address if dual addressing mode is selected. This parameter can be a 7-bit address.
- ***uint32_t FMPI2C_InitTypeDef::OwnAddress2Masks***
Specifies the acknowledge mask address second device own address if dual addressing mode is selected. This parameter can be a value of [**FMPI2C_own_address2_masks**](#)
- ***uint32_t FMPI2C_InitTypeDef::GeneralCallMode***
Specifies if general call mode is selected. This parameter can be a value of [**FMPI2C_general_call_addressing_mode**](#)
- ***uint32_t FMPI2C_InitTypeDef::NoStretchMode***
Specifies if nostretch mode is selected. This parameter can be a value of [**FMPI2C_nostretch_mode**](#)

24.2.2 FMPI2C_HandleTypeDef

Data Fields

- *FMPI2C_TypeDef * Instance*
- *FMPI2C_InitTypeDef Init*
- *uint8_t * pBuffPtr*
- *uint16_t XferSize*
- *_IO uint16_t XferCount*
- *DMA_HandleTypeDef * hdmatx*
- *DMA_HandleTypeDef * hdmarx*
- *HAL_LockTypeDef Lock*
- *_IO HAL_FMPI2C_StateTypeDef State*
- *_IO HAL_FMPI2C_ErrorTypeDef ErrorCode*

Field Documentation

- ***FMPI2C_TypeDef* FMPI2C_HandleTypeDef::Instance***
FMPI2C registers base address
- ***FMPI2C_InitTypeDef FMPI2C_HandleTypeDef::Init***
FMPI2C communication parameters
- ***uint8_t* FMPI2C_HandleTypeDef::pBuffPtr***
Pointer to FMPI2C transfer buffer
- ***uint16_t FMPI2C_HandleTypeDef::XferSize***
FMPI2C transfer size
- ***_IO uint16_t FMPI2C_HandleTypeDef::XferCount***
FMPI2C transfer counter
- ***DMA_HandleTypeDef* FMPI2C_HandleTypeDef::hdmatx***
FMPI2C Tx DMA handle parameters
- ***DMA_HandleTypeDef* FMPI2C_HandleTypeDef::hdmarx***
FMPI2C Rx DMA handle parameters
- ***HAL_LockTypeDef FMPI2C_HandleTypeDef::Lock***
FMPI2C locking object
- ***_IO HAL_FMPI2C_StateTypeDef FMPI2C_HandleTypeDef::State***
FMPI2C communication state
- ***_IO HAL_FMPI2C_ErrorTypeDef FMPI2C_HandleTypeDef::ErrorCode***

24.3 FMPI2C Firmware driver API description

24.3.1 Initialization and de-initialization functions

This subsection provides a set of functions allowing to initialize and de-initialize the FMPI2Cx peripheral:

- User must Implement HAL_FMPI2C_MspInit() function in which he configures all related peripherals resources (CLOCK, GPIO, DMA, IT and NVIC).
- Call the function HAL_FMPI2C_Init() to configure the selected device with the selected configuration:
 - Clock Timing
 - Own Address 1
 - Addressing mode (Master, Slave)
 - Dual Addressing mode

- Own Address 2
- Own Address 2 Mask
- General call mode
- Nostretch mode
- Call the function HAL_FMPI2C_DelInit() to restore the default configuration of the selected FMPI2Cx periperal.

This section contains the following APIs:

- [***HAL_FMPI2C_Init\(\)***](#)
- [***HAL_FMPI2C_DelInit\(\)***](#)
- [***HAL_FMPI2C_MspInit\(\)***](#)
- [***HAL_FMPI2C_MspDelInit\(\)***](#)

24.3.2 IO operation functions

This subsection provides a set of functions allowing to manage the FMPI2C data transfers.

1. There is two mode of transfer:
 - Blocking mode : The communication is performed in the polling mode. The status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode : The communication is performed using Interrupts or DMA. These functions return the status of the transfer startup. The end of the data processing will be indicated through the dedicated FMPI2C IRQ when using Interrupt mode or the DMA IRQ when using DMA mode.
2. Blocking mode functions are :
 - HAL_FMPI2C_Master_Transmit()
 - HAL_FMPI2C_Master_Receive()
 - HAL_FMPI2C_Slave_Transmit()
 - HAL_FMPI2C_Slave_Receive()
 - HAL_FMPI2C_Mem_Write()
 - HAL_FMPI2C_Mem_Read()
 - HAL_FMPI2C_IsDeviceReady()
3. No-Blocking mode functions with Interrupt are :
 - HAL_FMPI2C_Master_Transmit_IT()
 - HAL_FMPI2C_Master_Receive_IT()
 - HAL_FMPI2C_Slave_Transmit_IT()
 - HAL_FMPI2C_Slave_Receive_IT()
 - HAL_FMPI2C_Mem_Write_IT()
 - HAL_FMPI2C_Mem_Read_IT()
4. No-Blocking mode functions with DMA are :
 - HAL_FMPI2C_Master_Transmit_DMA()
 - HAL_FMPI2C_Master_Receive_DMA()
 - HAL_FMPI2C_Slave_Transmit_DMA()
 - HAL_FMPI2C_Slave_Receive_DMA()
 - HAL_FMPI2C_Mem_Write_DMA()
 - HAL_FMPI2C_Mem_Read_DMA()
5. A set of Transfer Complete Callbacks are provided in No_Blocking mode:
 - HAL_FMPI2C_MemTxCpltCallback()
 - HAL_FMPI2C_MemRxCpltCallback()
 - HAL_FMPI2C_MasterTxCpltCallback()
 - HAL_FMPI2C_MasterRxCpltCallback()
 - HAL_FMPI2C_SlaveTxCpltCallback()
 - HAL_FMPI2C_SlaveRxCpltCallback()

-
- HAL_FMPI2C_ErrorCallback()

This section contains the following APIs:

- [***HAL_FMPI2C_Master_Transmit\(\)***](#)
- [***HAL_FMPI2C_Master_Receive\(\)***](#)
- [***HAL_FMPI2C_Slave_Transmit\(\)***](#)
- [***HAL_FMPI2C_Slave_Receive\(\)***](#)
- [***HAL_FMPI2C_Master_Transmit_IT\(\)***](#)
- [***HAL_FMPI2C_Master_Receive_IT\(\)***](#)
- [***HAL_FMPI2C_Slave_Transmit_IT\(\)***](#)
- [***HAL_FMPI2C_Slave_Receive_IT\(\)***](#)
- [***HAL_FMPI2C_Master_Transmit_DMA\(\)***](#)
- [***HAL_FMPI2C_Master_Receive_DMA\(\)***](#)
- [***HAL_FMPI2C_Slave_Transmit_DMA\(\)***](#)
- [***HAL_FMPI2C_Slave_Receive_DMA\(\)***](#)
- [***HAL_FMPI2C_Mem_Write\(\)***](#)
- [***HAL_FMPI2C_Mem_Read\(\)***](#)
- [***HAL_FMPI2C_Mem_Write_IT\(\)***](#)
- [***HAL_FMPI2C_Mem_Read_IT\(\)***](#)
- [***HAL_FMPI2C_Mem_Write_DMA\(\)***](#)
- [***HAL_FMPI2C_Mem_Read_DMA\(\)***](#)
- [***HAL_FMPI2C_IsDeviceReady\(\)***](#)
- [***HAL_FMPI2C_EV_IRQHandler\(\)***](#)
- [***HAL_FMPI2C_ER_IRQHandler\(\)***](#)
- [***HAL_FMPI2C_MasterTxCpltCallback\(\)***](#)
- [***HAL_FMPI2C_MasterRxCpltCallback\(\)***](#)
- [***HAL_FMPI2C_SlaveTxCpltCallback\(\)***](#)
- [***HAL_FMPI2C_SlaveRxCpltCallback\(\)***](#)
- [***HAL_FMPI2C_MemTxCpltCallback\(\)***](#)
- [***HAL_FMPI2C_MemRxCpltCallback\(\)***](#)
- [***HAL_FMPI2C_ErrorCallback\(\)***](#)

24.3.3 Peripheral State and Errors functions

This subsection permit to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [***HAL_FMPI2C_GetState\(\)***](#)
- [***HAL_FMPI2C_GetError\(\)***](#)

24.3.4 HAL_FMPI2C_Init

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2C_Init (FMPI2C_HandleTypeDef * hfmpi2c)</code>
Function Description	Initializes the FMPI2C according to the specified parameters in the FMPI2C_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> • HAL status

24.3.5 HAL_FMPI2C_DelInit

Function Name	HAL_StatusTypeDef HAL_FMPI2C_DelInit (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	DeInitializes the FMPI2C peripheral.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> HAL status

24.3.6 HAL_FMPI2C_MspInit

Function Name	void HAL_FMPI2C_MspInit (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	FMPI2C MSP Init.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.7 HAL_FMPI2C_MspDelInit

Function Name	void HAL_FMPI2C_MspDelInit (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	FMPI2C MSP DelInit.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.8 HAL_FMPI2C_Master_Transmit

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Master_Transmit (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmits in master mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. DevAddress: Target device address pData: Pointer to data buffer Size: Amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

24.3.9 HAL_FMPI2C_Master_Receive

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Master_Receive (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size, uint32_t Timeout)
---------------	--

Function Description	Receives in master mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	• HAL status

24.3.10 HAL_FMPI2C_Slave_Transmit

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Slave_Transmit (FMPI2C_HandleTypeDef * hfmpi2c, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmits in slave mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	• HAL status

24.3.11 HAL_FMPI2C_Slave_Receive

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Slave_Receive (FMPI2C_HandleTypeDef * hfmpi2c, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receive in slave mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	• HAL status

24.3.12 HAL_FMPI2C_Master_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Master_Transmit_IT (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size)
Function Description	Transmit in master mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address

Return values	<ul style="list-style-type: none"> • pData: Pointer to data buffer • Size: Amount of data to be sent • HAL status
---------------	--

24.3.13 HAL_FMPI2C_Master_Receive_IT

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Master_Receive_IT (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size)
Function Description	Receive in master mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.14 HAL_FMPI2C_Slave_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Slave_Transmit_IT (FMPI2C_HandleTypeDef * hfmpi2c, uint8_t * pData, uint16_t Size)
Function Description	Transmit in slave mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.15 HAL_FMPI2C_Slave_Receive_IT

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Slave_Receive_IT (FMPI2C_HandleTypeDef * hfmpi2c, uint8_t * pData, uint16_t Size)
Function Description	Receive in slave mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.16 HAL_FMPI2C_Master_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Master_Transmit_DMA (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size)
Function Description	Transmit in master mode an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.17 HAL_FMPI2C_Master_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Master_Receive_DMA (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size)
Function Description	Receive in master mode an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.18 HAL_FMPI2C_Slave_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Slave_Transmit_DMA (FMPI2C_HandleTypeDef * hfmpi2c, uint8_t * pData, uint16_t Size)
Function Description	Transmit in slave mode an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.19 HAL_FMPI2C_Slave_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Slave_Receive_DMA (FMPI2C_HandleTypeDef * hfmpi2c, uint8_t * pData, uint16_t Size)
Function Description	Receive in slave mode an amount of data in no-blocking mode with DMA.

Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. pData: Pointer to data buffer Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status

24.3.20 HAL_FMPI2C_Mem_Write

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2C_Mem_Write (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size, uint32_t Timeout)</code>
Function Description	Write an amount of data in blocking mode to a specific memory address.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. DevAddress: Target device address MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

24.3.21 HAL_FMPI2C_Mem_Read

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2C_Mem_Read (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size, uint32_t Timeout)</code>
Function Description	Read an amount of data in blocking mode from a specific memory address.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. DevAddress: Target device address MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

24.3.22 HAL_FMPI2C_Mem_Write_IT

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2C_Mem_Write_IT (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData,</code>
---------------	---

uint16_t Size)

Function Description	Write an amount of data in no-blocking mode with Interrupt to a specific memory address.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • MemAddress: Internal memory address • MemAddSize: Size of internal memory address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.23 HAL_FMPI2C_Mem_Read_IT

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Mem_Read_IT (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)
Function Description	Read an amount of data in no-blocking mode with Interrupt from a specific memory address.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • MemAddress: Internal memory address • MemAddSize: Size of internal memory address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.24 HAL_FMPI2C_Mem_Write_DMA

Function Name	HAL_StatusTypeDef HAL_FMPI2C_Mem_Write_DMA (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)
Function Description	Write an amount of data in no-blocking mode with DMA to a specific memory address.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • MemAddress: Internal memory address • MemAddSize: Size of internal memory address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

24.3.25 HAL_FMPI2C_Mem_Read_DMA

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2C_Mem_Read_DMA (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)</code>
Function Description	Reads an amount of data in no-blocking mode with DMA from a specific memory address.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • MemAddress: Internal memory address • MemAddSize: Size of internal memory address • pData: Pointer to data buffer • Size: Amount of data to be read
Return values	<ul style="list-style-type: none"> • HAL status

24.3.26 HAL_FMPI2C_IsDeviceReady

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2C_IsDeviceReady (FMPI2C_HandleTypeDef * hfmpi2c, uint16_t DevAddress, uint32_t Trials, uint32_t Timeout)</code>
Function Description	Checks if target device is ready for communication.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C. • DevAddress: Target device address • Trials: Number of trials • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used with Memory devices

24.3.27 HAL_FMPI2C_EV_IRQHandler

Function Name	<code>void HAL_FMPI2C_EV_IRQHandler (FMPI2C_HandleTypeDef * hfmpi2c)</code>
Function Description	This function handles FMPI2C event interrupt request.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> • None

24.3.28 HAL_FMPI2C_ER_IRQHandler

Function Name	<code>void HAL_FMPI2C_ER_IRQHandler (FMPI2C_HandleTypeDef * hfmpi2c)</code>
Function Description	This function handles FMPI2C error interrupt request.

Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.29 HAL_FMPI2C_MasterTxCpltCallback

Function Name	void HAL_FMPI2C_MasterTxCpltCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Master Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.30 HAL_FMPI2C_MasterRxCpltCallback

Function Name	void HAL_FMPI2C_MasterRxCpltCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Master Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.31 HAL_FMPI2C_SlaveTxCpltCallback

Function Name	void HAL_FMPI2C_SlaveTxCpltCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Slave Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.32 HAL_FMPI2C_SlaveRxCpltCallback

Function Name	void HAL_FMPI2C_SlaveRxCpltCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Slave Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> None

24.3.33 HAL_FMPI2C_MemTxCpltCallback

Function Name	void HAL_FMPI2C_MemTxCpltCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Memory Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> • None

24.3.34 HAL_FMPI2C_MemRxCpltCallback

Function Name	void HAL_FMPI2C_MemRxCpltCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Memory Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> • None

24.3.35 HAL_FMPI2C_ErrorCallback

Function Name	void HAL_FMPI2C_ErrorCallback (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	FMPI2C error callbacks.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : Pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> • None

24.3.36 HAL_FMPI2C_GetState

Function Name	HAL_FMPI2C_StateTypeDef HAL_FMPI2C_GetState (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Returns the FMPI2C state.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : FMPI2C handle
Return values	<ul style="list-style-type: none"> • HAL state

24.3.37 HAL_FMPI2C_GetError

Function Name	uint32_t HAL_FMPI2C_GetError (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Return the FMPI2C error code.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2C.
Return values	<ul style="list-style-type: none"> • FMPI2C Error Code

24.4 FMPI2C Firmware driver defines

24.4.1 FMPI2C

FMPI2C addressing mode

FMPI2C_ADDRESSINGMODE_7BIT

FMPI2C_ADDRESSINGMODE_10BIT

FMPI2C dual addressing mode

FMPI2C_DUALADDRESS_DISABLE

FMPI2C_DUALADDRESS_ENABLE

FMPI2C Exported Macros

`__HAL_FMPI2C_RESET_HANDLE_STATE` **Description:**

- Reset FMPI2C handle state.

Parameters:

- `__HANDLE__`: specifies the FMPI2C Handle. This parameter can be FMPI2C where x: 1 or 2 to select the FMPI2C peripheral.

Return value:

- None

`__HAL_FMPI2C_ENABLE_IT` **Description:**

- Enables or disables the specified FMPI2C interrupts.

Parameters:

- `__HANDLE__`: specifies the FMPI2C Handle. This parameter can be FMPI2C where x: 1 or 2 to select the FMPI2C peripheral.
- `__INTERRUPT__`: specifies the interrupt source to enable or disable. This parameter can be one of the following values:
 - FMPI2C_IT_ERRI: Errors interrupt enable
 - FMPI2C_IT_TCI: Transfer complete interrupt enable
 - FMPI2C_IT_STOPI: STOP detection interrupt enable
 - FMPI2C_IT_NACKI: NACK received interrupt enable
 - FMPI2C_IT_ADDRI: Address match interrupt enable
 - FMPI2C_IT_RXI: RX interrupt enable
 - FMPI2C_IT_TXI: TX interrupt enable

`__HAL_FMPI2C_DISABLE_IT`
`__HAL_FMPI2C_GET_IT_SOURCE`

Return value:

- None

Description:

- Checks if the specified FMPI2C interrupt source is enabled or disabled.

Parameters:

- `__HANDLE__`: specifies the FMPI2C Handle. This parameter can be FMPI2C where x: 1 or 2 to select the FMPI2C peripheral.
- `__INTERRUPT__`: specifies the FMPI2C interrupt source to check. This parameter can be one of the following values:
 - `FMPI2C_IT_ERRI`: Errors interrupt enable
 - `FMPI2C_IT_TCI`: Transfer complete interrupt enable
 - `FMPI2C_IT_STOPI`: STOP detection interrupt enable
 - `FMPI2C_IT_NACKI`: NACK received interrupt enable
 - `FMPI2C_IT_ADDRI`: Address match interrupt enable
 - `FMPI2C_IT_RXI`: RX interrupt enable
 - `FMPI2C_IT_TXI`: TX interrupt enable

Return value:

- The new state of `__IT__` (TRUE or FALSE).

`__HAL_FMPI2C_GET_FLAG`

Description:

- Checks whether the specified FMPI2C flag is set or not.

Parameters:

- `__HANDLE__`: specifies the FMPI2C Handle. This parameter can be FMPI2C where x: 1 or 2 to select the FMPI2C peripheral.
- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `FMPI2C_FLAG_TXE`: Transmit data register empty
 - `FMPI2C_FLAG_TXIS`: Transmit interrupt status
 - `FMPI2C_FLAG_RXNE`: Receive

- data register not empty
- FMPI2C_FLAG_ADDR: Address matched (slave mode)
- FMPI2C_FLAG_AF: Acknowledge failure received flag
- FMPI2C_FLAG_STOPF: STOP detection flag
- FMPI2C_FLAG_TC: Transfer complete (master mode)
- FMPI2C_FLAG_TCR: Transfer complete reload
- FMPI2C_FLAG_BERR: Bus error
- FMPI2C_FLAG_ARLO: Arbitration lost
- FMPI2C_FLAG_OVR: Overrun/Underrun
- FMPI2C_FLAG_PECERR: PEC error in reception
- FMPI2C_FLAG_TIMEOUT: Timeout or Tlow detection flag
- FMPI2C_FLAG_ALERT: SMBus alert
- FMPI2C_FLAG_BUSY: Bus busy
- FMPI2C_FLAG_DIR: Transfer direction (slave mode)

Return value:

- The new state of __FLAG__ (TRUE or FALSE).

__HAL_FMPI2C_CLEAR_FLAG

Description:

- Clears the FMPI2C pending flags which are cleared by writing 1 in a specific bit.

Parameters:

- __HANDLE__: specifies the FMPI2C Handle. This parameter can be FMPI2C where x: 1 or 2 to select the FMPI2C peripheral.
- __FLAG__: specifies the flag to clear. This parameter can be any combination of the following values:
 - FMPI2C_FLAG_ADDR: Address matched (slave mode)
 - FMPI2C_FLAG_AF: Acknowledge failure received flag
 - FMPI2C_FLAG_STOPF: STOP detection flag
 - FMPI2C_FLAG_BERR: Bus error
 - FMPI2C_FLAG_ARLO: Arbitration lost
 - FMPI2C_FLAG_OVR: Overrun/Underrun
 - FMPI2C_FLAG_PECERR: PEC

- error in reception
- FMPI2C_FLAG_TIMEOUT:
Timeout or Tlow detection flag
- FMPI2C_FLAG_ALERT: SMBus
alert

Return value:

- None

`_HAL_FMPI2C_ENABLE`
`_HAL_FMPI2C_DISABLE`
`_HAL_FMPI2C_RESET_CR2`
`_HAL_FMPI2C_MEM_ADD_MSB`
`_HAL_FMPI2C_MEM_ADD_LSB`
`_HAL_FMPI2C_GENERATE_START`
`IS_FMPI2C_OWN_ADDRESS1`
`IS_FMPI2C_OWN_ADDRESS2`

FMPI2C Flag definition

`FMPI2C_FLAG_TXE`
`FMPI2C_FLAG_TXIS`
`FMPI2C_FLAG_RXNE`
`FMPI2C_FLAG_ADDR`
`FMPI2C_FLAG_AF`
`FMPI2C_FLAG_STOPF`
`FMPI2C_FLAG_TC`
`FMPI2C_FLAG_TCR`
`FMPI2C_FLAG_BERR`
`FMPI2C_FLAG_ARLO`
`FMPI2C_FLAG_OVR`
`FMPI2C_FLAG_PECERR`
`FMPI2C_FLAG_TIMEOUT`
`FMPI2C_FLAG_ALERT`
`FMPI2C_FLAG_BUSY`
`FMPI2C_FLAG_DIR`

FMPI2C general call addressing mode

`FMPI2C_GENERALCALL_DISABLE`
`FMPI2C_GENERALCALL_ENABLE`

FMPI2C Interrupt configuration definition

`FMPI2C_IT_ERRI`
`FMPI2C_IT_TCI`

FMPI2C_IT_STOPI

FMPI2C_IT_NACKI

FMPI2C_IT_ADDRI

FMPI2C_IT_RXI

FMPI2C_IT_TXI

FMPI2C Memory Address Size

FMPI2C_MEMADD_SIZE_8BIT

FMPI2C_MEMADD_SIZE_16BIT

FMPI2C nostretch mode

FMPI2C_NOSTRETCH_DISABLE

FMPI2C_NOSTRETCH_ENABLE

FMPI2C own address2 masks

FMPI2C_OA2_NOMASK

FMPI2C_OA2_MASK01

FMPI2C_OA2_MASK02

FMPI2C_OA2_MASK03

FMPI2C_OA2_MASK04

FMPI2C_OA2_MASK05

FMPI2C_OA2_MASK06

FMPI2C_OA2_MASK07

FMPI2C Private Constants

TIMING_CLEAR_MASK

FMPI2C_TIMEOUT_ADDR

FMPI2C_TIMEOUT_BUSY

FMPI2C_TIMEOUT_DIR

FMPI2C_TIMEOUT_RXNE

FMPI2C_TIMEOUT_STOPF

FMPI2C_TIMEOUT_TC

FMPI2C_TIMEOUT_TCR

FMPI2C_TIMEOUT_TXIS

FMPI2C_TIMEOUT_FLAG

FMPI2C_FLAG_MASK

FMPI2C Private Macros

IS_FMPI2C_ADDRESSING_MODE

IS_FMPI2C_DUAL_ADDRESS

IS_FMPI2C_own_ADDRESS2_MASK

IS_FMPI2C_GENERAL_CALL

IS_FMPI2C_NO_STRETCH

IS_FMPI2C_MEMADD_SIZE

IS_TRANSFER_MODE

IS_TRANSFER_REQUEST

FMPI2C ReloadEndMode definition

FMPI2C_RELOAD_MODE

FMPI2C_AUTOEND_MODE

FMPI2C_SOFTEND_MODE

FMPI2C StartStopMode definition

FMPI2C_NO_STARTSTOP

FMPI2C_GENERATE_STOP

FMPI2C_GENERATE_START_READ

FMPI2C_GENERATE_START_WRITE

25 HAL FMPI2C Extension Driver

25.1 HAL FMPI2C Extension Driver

25.2 FMPI2CEx Firmware driver API description

25.2.1 Extension features functions

This section provides functions allowing to:

- Configure Noise Filters

This section contains the following APIs:

- [*HAL_FMPI2CEx_AnalogFilter_Config\(\)*](#)
- [*HAL_FMPI2CEx_DigitalFilter_Config\(\)*](#)
- [*HAL_FMPI2CEx_EnableWakeUp\(\)*](#)
- [*HAL_FMPI2CEx_DisableWakeUp\(\)*](#)
- [*HAL_FMPI2CEx_EnableFastModePlus\(\)*](#)
- [*HAL_FMPI2CEx_DisableFastModePlus\(\)*](#)

25.2.2 HAL_FMPI2CEx_AnalogFilter_Config

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2CEx_AnalogFilter_Config(FMPI2C_HandleTypeDef * hfmpi2c, uint32_t AnalogFilter)</code>
Function Description	Configures FMPI2C Analog noise filter.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2Cx peripheral. • AnalogFilter: : new state of the Analog filter.
Return values	<ul style="list-style-type: none"> • HAL status

25.2.3 HAL_FMPI2CEx_DigitalFilter_Config

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2CEx_DigitalFilter_Config(FMPI2C_HandleTypeDef * hfmpi2c, uint32_t DigitalFilter)</code>
Function Description	Configures FMPI2C Digital noise filter.
Parameters	<ul style="list-style-type: none"> • hfmpi2c: : pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2Cx peripheral. • DigitalFilter: : Coefficient of digital noise filter between 0x00 and 0x0F.
Return values	<ul style="list-style-type: none"> • HAL status

25.2.4 HAL_FMPI2CEx_EnableWakeUp

Function Name	<code>HAL_StatusTypeDef HAL_FMPI2CEx_EnableWakeUp(FMPI2C_HandleTypeDef * hfmpi2c)</code>
Function Description	Enables FMPI2C wakeup from stop mode.

Parameters	<ul style="list-style-type: none"> hfmpi2c: : pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2Cx peripheral.
Return values	<ul style="list-style-type: none"> HAL status
25.2.5 HAL_FMPI2CEx_DisableWakeUp	
Function Name	HAL_StatusTypeDef HAL_FMPI2CEx_DisableWakeUp (FMPI2C_HandleTypeDef * hfmpi2c)
Function Description	Disables FMPI2C wakeup from stop mode.
Parameters	<ul style="list-style-type: none"> hfmpi2c: : pointer to a FMPI2C_HandleTypeDef structure that contains the configuration information for the specified FMPI2Cx peripheral.
Return values	<ul style="list-style-type: none"> HAL status
25.2.6 HAL_FMPI2CEx_EnableFastModePlus	
Function Name	void HAL_FMPI2CEx_EnableFastModePlus (uint32_t ConfigFastModePlus)
Function Description	Enable the FMPI2C1 fast mode plus driving capability.
Parameters	<ul style="list-style-type: none"> ConfigFastModePlus: selects the pin. This parameter can be one of the FMPI2C Fast Mode Plus values
Return values	<ul style="list-style-type: none"> None
25.2.7 HAL_FMPI2CEx_DisableFastModePlus	
Function Name	void HAL_FMPI2CEx_DisableFastModePlus (uint32_t ConfigFastModePlus)
Function Description	Disable the FMPI2C1 fast mode plus driving capability.
Parameters	<ul style="list-style-type: none"> ConfigFastModePlus: selects the pin. This parameter can be one of the FMPI2C Fast Mode Plus values
Return values	<ul style="list-style-type: none"> None
25.3 FMPI2CEx Firmware driver defines	
25.3.1 FMPI2CEx	
<i>FMPI2C Analog Filter</i>	
FMPI2C_ANALOGFILTER_ENABLE	
FMPI2C_ANALOGFILTER_DISABLE	
<i>FMPI2C Fast Mode Plus</i>	
FMPI2C_FASTMODEPLUS_SCL	Enable Fast Mode Plus on FMPI2C1 SCL pins
FMPI2C_FASTMODEPLUS_SDA	Enable Fast Mode Plus on FMPI2C1 SDA pins

26 HAL GPIO Generic Driver

26.1 HAL GPIO Generic Driver

26.2 GPIO Firmware driver registers structures

26.2.1 GPIO_InitTypeDef

Data Fields

- *uint32_t Pin*
- *uint32_t Mode*
- *uint32_t Pull*
- *uint32_t Speed*
- *uint32_t Alternate*

Field Documentation

- ***uint32_t GPIO_InitTypeDef::Pin***
Specifies the GPIO pins to be configured. This parameter can be any value of [*GPIO_pins_define*](#)
- ***uint32_t GPIO_InitTypeDef::Mode***
Specifies the operating mode for the selected pins. This parameter can be a value of [*GPIO_mode_define*](#)
- ***uint32_t GPIO_InitTypeDef::Pull***
Specifies the Pull-up or Pull-Down activation for the selected pins. This parameter can be a value of [*GPIO_pull_define*](#)
- ***uint32_t GPIO_InitTypeDef::Speed***
Specifies the speed for the selected pins. This parameter can be a value of [*GPIO_speed_define*](#)
- ***uint32_t GPIO_InitTypeDef::Alternate***
Peripheral to be connected to the selected pins. This parameter can be a value of [*GPIO_Alternate_function_selection*](#)

26.3 GPIO Firmware driver API description

26.3.1 GPIO Peripheral features

Subject to the specific hardware characteristics of each I/O port listed in the datasheet, each port bit of the General Purpose IO (GPIO) Ports, can be individually configured by software in several modes:

- Input mode
- Analog mode
- Output mode
- Alternate function mode
- External interrupt/event lines

During and just after reset, the alternate functions and external interrupt lines are not active and the I/O ports are configured in input floating mode.

All GPIO pins have weak internal pull-up and pull-down resistors, which can be activated or not.

In Output or Alternate mode, each IO can be configured on open-drain or push-pull type and the IO speed can be selected depending on the VDD value.

All ports have external interrupt/event capability. To use external interrupt lines, the port must be configured in input mode. All available GPIO pins are connected to the 16 external interrupt/event lines from EXTI0 to EXTI15.

The external interrupt/event controller consists of up to 23 edge detectors (16 lines are connected to GPIO) for generating event/interrupt requests (each input line can be independently configured to select the type (interrupt or event) and the corresponding trigger event (rising or falling or both). Each line can also be masked independently.

26.3.2 How to use this driver

1. Enable the GPIO AHB clock using the following function:
`_HAL_RCC_GPIOx_CLK_ENABLE()`.
2. Configure the GPIO pin(s) using `HAL_GPIO_Init()`.
 - Configure the IO mode using "Mode" member from `GPIO_InitTypeDef` structure
 - Activate Pull-up, Pull-down resistor using "Pull" member from `GPIO_InitTypeDef` structure.
 - In case of Output or alternate function mode selection: the speed is configured through "Speed" member from `GPIO_InitTypeDef` structure.
 - In alternate mode is selection, the alternate function connected to the IO is configured through "Alternate" member from `GPIO_InitTypeDef` structure.
 - Analog mode is required when a pin is to be used as ADC channel or DAC output.
 - In case of external interrupt/event selection the "Mode" member from `GPIO_InitTypeDef` structure select the type (interrupt or event) and the corresponding trigger event (rising or falling or both).
3. In case of external interrupt/event mode selection, configure NVIC IRQ priority mapped to the EXTI line using `HAL_NVIC_SetPriority()` and enable it using `HAL_NVIC_EnableIRQ()`.
4. To get the level of a pin configured in input mode use `HAL_GPIO_ReadPin()`.
5. To set/reset the level of a pin configured in output mode use `HAL_GPIO_WritePin()`/`HAL_GPIO_TogglePin()`.
6. To lock pin configuration until next reset use `HAL_GPIO_LockPin()`.
7. During and just after reset, the alternate functions are not active and the GPIO pins are configured in input floating mode (except JTAG pins).
8. The LSE oscillator pins OSC32_IN and OSC32_OUT can be used as general purpose (PC14 and PC15, respectively) when the LSE oscillator is off. The LSE has priority over the GPIO function.
9. The HSE oscillator pins OSC_IN/OSC_OUT can be used as general purpose PH0 and PH1, respectively, when the HSE oscillator is off. The HSE has priority over the GPIO function.

26.3.3 Initialization and de-initialization functions

This section provides functions allowing to initialize and de-initialize the GPIOs to be ready for use.

This section contains the following APIs:

- [*HAL_GPIO_Init\(\)*](#)
- [*HAL_GPIO_DeInit\(\)*](#)

26.3.4 IO operation functions

This section contains the following APIs:

- [*HAL_GPIO_ReadPin\(\)*](#)
- [*HAL_GPIO_WritePin\(\)*](#)
- [*HAL_GPIO_TogglePin\(\)*](#)
- [*HAL_GPIO_LockPin\(\)*](#)
- [*HAL_GPIO_EXTI_IRQHandler\(\)*](#)
- [*HAL_GPIO_EXTI_Callback\(\)*](#)

26.3.5 HAL_GPIO_Init

Function Name	<code>void HAL_GPIO_Init (GPIO_TypeDef * GPIOx, GPIO_InitTypeDef * GPIO_InitStruct)</code>
Function Description	Initializes the GPIOx peripheral according to the specified parameters in the <code>GPIO_InitStruct</code> .
Parameters	<ul style="list-style-type: none"> • GPIOx: where x can be (A..K) to select the GPIO peripheral for STM32F429X device or x can be (A..I) to select the GPIO peripheral for STM32F40XX and STM32F427X devices. • GPIO_InitStruct: pointer to a <code>GPIO_InitTypeDef</code> structure that contains the configuration information for the specified GPIO peripheral.
Return values	<ul style="list-style-type: none"> • None

26.3.6 HAL_GPIO_DeInit

Function Name	<code>void HAL_GPIO_DeInit (GPIO_TypeDef * GPIOx, uint32_t GPIO_Pin)</code>
Function Description	De-initializes the GPIOx peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • GPIOx: where x can be (A..K) to select the GPIO peripheral for STM32F429X device or x can be (A..I) to select the GPIO peripheral for STM32F40XX and STM32F427X devices. • GPIO_Pin: specifies the port bit to be written. This parameter can be one of <code>GPIO_PIN_x</code> where x can be (0..15).
Return values	<ul style="list-style-type: none"> • None

26.3.7 HAL_GPIO_ReadPin

Function Name	<code>GPIO_PinState HAL_GPIO_ReadPin (GPIO_TypeDef * GPIOx, uint16_t GPIO_Pin)</code>
Function Description	Reads the specified input port pin.
Parameters	<ul style="list-style-type: none"> • GPIOx: where x can be (A..K) to select the GPIO peripheral for STM32F429X device or x can be (A..I) to select the GPIO peripheral for STM32F40XX and STM32F427X devices. • GPIO_Pin: specifies the port bit to read. This parameter can be <code>GPIO_PIN_x</code> where x can be (0..15).

Return values	<ul style="list-style-type: none"> The input port pin value.
26.3.8 HAL_GPIO_WritePin	
Function Name	void HAL_GPIO_WritePin (GPIO_TypeDef * GPIOx, uint16_t GPIO_Pin, GPIO_PinState PinState)
Function Description	Sets or clears the selected data port bit.
Parameters	<ul style="list-style-type: none"> GPIOx: where x can be (A..K) to select the GPIO peripheral for STM32F429X device or x can be (A..I) to select the GPIO peripheral for STM32F40XX and STM32F427X devices. GPIO_Pin: specifies the port bit to be written. This parameter can be one of GPIO_PIN_x where x can be (0..15). PinState: specifies the value to be written to the selected bit. This parameter can be one of the GPIO_PinState enum values: GPIO_PIN_RESET: to clear the port pinGPIO_PIN_SET: to set the port pin
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This function uses GPIOx_BSRR register to allow atomic read/modify accesses. In this way, there is no risk of an IRQ occurring between the read and the modify access.
26.3.9 HAL_GPIO_TogglePin	
Function Name	void HAL_GPIO_TogglePin (GPIO_TypeDef * GPIOx, uint16_t GPIO_Pin)
Function Description	Toggles the specified GPIO pins.
Parameters	<ul style="list-style-type: none"> GPIOx: Where x can be (A..K) to select the GPIO peripheral for STM32F429X device or x can be (A..I) to select the GPIO peripheral for STM32F40XX and STM32F427X devices. GPIO_Pin: Specifies the pins to be toggled.
Return values	<ul style="list-style-type: none"> None
26.3.10 HAL_GPIO_LockPin	
Function Name	HAL_StatusTypeDef HAL_GPIO_LockPin (GPIO_TypeDef * GPIOx, uint16_t GPIO_Pin)
Function Description	Locks GPIO Pins configuration registers.
Parameters	<ul style="list-style-type: none"> GPIOx: where x can be (A..F) to select the GPIO peripheral for STM32F4 family GPIO_Pin: specifies the port bit to be locked. This parameter can be any combination of GPIO_PIN_x where x can be (0..15).
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> The locked registers are GPIOx_MODER, GPIOx_OTYPER, GPIOx_OSPEEDR, GPIOx_PUPDR, GPIOx_AFRL and GPIOx_AFRH. The configuration of the locked GPIO pins can no longer be modified until the next reset.

26.3.11 HAL_GPIO_EXTI_IRQHandler

Function Name	void HAL_GPIO_EXTI_IRQHandler (uint16_t GPIO_Pin)
Function Description	This function handles EXTI interrupt request.
Parameters	<ul style="list-style-type: none">• GPIO_Pin: Specifies the pins connected EXTI line
Return values	<ul style="list-style-type: none">• None

26.3.12 HAL_GPIO_EXTI_Callback

Function Name	void HAL_GPIO_EXTI_Callback (uint16_t GPIO_Pin)
Function Description	EXTI line detection callbacks.
Parameters	<ul style="list-style-type: none">• GPIO_Pin: Specifies the pins connected EXTI line
Return values	<ul style="list-style-type: none">• None

26.4 GPIO Firmware driver defines

26.4.1 GPIO

GPIO Alternate Function Selection

GPIO_AF0_RTC_50Hz
GPIO_AF0_MCO
GPIO_AF0_TAMPER
GPIO_AF0_SWJ
GPIO_AF0_TRACE
GPIO_AF1_TIM1
GPIO_AF1_TIM2
GPIO_AF2_TIM3
GPIO_AF2_TIM4
GPIO_AF2_TIM5
GPIO_AF3_TIM8
GPIO_AF3_TIM9
GPIO_AF3_TIM10
GPIO_AF3_TIM11
GPIO_AF4_I2C1
GPIO_AF4_I2C2
GPIO_AF4_I2C3
GPIO_AF5_SPI1
GPIO_AF5_SPI2
GPIO_AF5_SPI3
GPIO_AF5_SPI4

GPIO_AF5_SPI5
GPIO_AF5_SPI6
GPIO_AF5_I2S3ext
GPIO_AF6_SPI3
GPIO_AF6_I2S2ext
GPIO_AF6_SAI1
GPIO_AF7_USART1
GPIO_AF7_USART2
GPIO_AF7_USART3
GPIO_AF7_I2S3ext
GPIO_AF8_UART4
GPIO_AF8_UART5
GPIO_AF8_USART6
GPIO_AF8_UART7
GPIO_AF8_UART8
GPIO_AF9_CAN1
GPIO_AF9_CAN2
GPIO_AF9_TIM12
GPIO_AF9_TIM13
GPIO_AF9_TIM14
GPIO_AF9_LTDC
GPIO_AF9_QSPI
GPIO_AF10_OTG_FS
GPIO_AF10_OTG_HS
GPIO_AF10_QSPI
GPIO_AF11_ETH
GPIO_AF12_FMC
GPIO_AF12_OTG_HS_FS
GPIO_AF12_SDIO
GPIO_AF13_DCMI
GPIO_AF13_DSI
GPIO_AF14_LTDC
GPIO_AF15_EVENTOUT

GPIO Exported Macros

`__HAL_GPIO_EXTI_GET_FLAG`

Description:

- Checks whether the specified EXTI line flag is set or not.

Parameters:

- `__EXTI_LINE__`: specifies the EXTI line flag to check. This parameter can be `GPIO_PIN_x` where x can be(0..15)

Return value:

- The: new state of `__EXTI_LINE__` (SET or RESET).

`__HAL_GPIO_EXTI_CLEAR_FLAG`**Description:**

- Clears the EXTI's line pending flags.

Parameters:

- `__EXTI_LINE__`: specifies the EXTI lines flags to clear. This parameter can be any combination of `GPIO_PIN_x` where x can be (0..15)

Return value:

- None

`__HAL_GPIO_EXTI_GET_IT`**Description:**

- Checks whether the specified EXTI line is asserted or not.

Parameters:

- `__EXTI_LINE__`: specifies the EXTI line to check. This parameter can be `GPIO_PIN_x` where x can be(0..15)

Return value:

- The: new state of `__EXTI_LINE__` (SET or RESET).

`__HAL_GPIO_EXTI_CLEAR_IT`**Description:**

- Clears the EXTI's line pending bits.

Parameters:

- `__EXTI_LINE__`: specifies the EXTI lines to clear. This parameter can be any combination of `GPIO_PIN_x` where x can be (0..15)

Return value:

- None

`__HAL_GPIO_EXTI_GENERATE_SWIT`**Description:**

- Generates a Software interrupt on selected EXTI line.

Parameters:

- `__EXTI_LINE__`: specifies the EXTI line to check. This parameter can be

GPIO_PIN_x where x can be(0..15)

Return value:

- None

GPIO mode define

GPIO_MODE_INPUT	Input Floating Mode
GPIO_MODE_OUTPUT_PP	Output Push Pull Mode
GPIO_MODE_OUTPUT_OD	Output Open Drain Mode
GPIO_MODE_AF_PP	Alternate Function Push Pull Mode
GPIO_MODE_AF_OD	Alternate Function Open Drain Mode
GPIO_MODE_ANALOG	Analog Mode
GPIO_MODE_IT_RISING	External Interrupt Mode with Rising edge trigger detection
GPIO_MODE_IT_FALLING	External Interrupt Mode with Falling edge trigger detection
GPIO_MODE_IT_RISING_FALLING	External Interrupt Mode with Rising/Falling edge trigger detection
GPIO_MODE_EVT_RISING	External Event Mode with Rising edge trigger detection
GPIO_MODE_EVT_FALLING	External Event Mode with Falling edge trigger detection
GPIO_MODE_EVT_RISING_FALLING	External Event Mode with Rising/Falling edge trigger detection

GPIO pins define

GPIO_PIN_0
GPIO_PIN_1
GPIO_PIN_2
GPIO_PIN_3
GPIO_PIN_4
GPIO_PIN_5
GPIO_PIN_6
GPIO_PIN_7
GPIO_PIN_8
GPIO_PIN_9
GPIO_PIN_10
GPIO_PIN_11
GPIO_PIN_12
GPIO_PIN_13
GPIO_PIN_14

GPIO_PIN_15
GPIO_PIN_All
GPIO_PIN_MASK
GPIO Private Constants

GPIO_MODE
EXTI_MODE
GPIO_MODE_IT
GPIO_MODE_EVT
RISING_EDGE
FALLING_EDGE
GPIO_OUTPUT_TYPE
GPIO_NUMBER

GPIO Private Macros

IS_GPIO_PIN_ACTION
IS_GPIO_PIN
IS_GPIO_MODE
IS_GPIO_SPEED
IS_GPIO_PULL

GPIO pull define

GPIO_NOPULL	No Pull-up or Pull-down activation
GPIO_PULLUP	Pull-up activation
GPIO_PULLDOWN	Pull-down activation

GPIO speed define

GPIO_SPEED_FREQ_LOW	IO works at 2 MHz, please refer to the product datasheet
GPIO_SPEED_FREQ_MEDIUM	range 12,5 MHz to 50 MHz, please refer to the product datasheet
GPIO_SPEED_FREQ_HIGH	range 25 MHz to 100 MHz, please refer to the product datasheet
GPIO_SPEED_FREQ VERY HIGH	range 50 MHz to 200 MHz, please refer to the product datasheet

27 HAL GPIO Extension Driver

27.1 HAL GPIO Extension Driver

27.2 GPIOEx Firmware driver defines

27.2.1 GPIOEx

GPIO Get Port Index

`GPIO_GET_INDEX`

GPIO Check Alternate Function

`IS_GPIO_AF`

28 HAL HASH Generic Driver

28.1 HAL HASH Generic Driver

28.2 HASH Firmware driver registers structures

28.2.1 HASH_InitTypeDef

Data Fields

- `uint32_t DataType`
- `uint32_t KeySize`
- `uint8_t * pKey`

Field Documentation

- `uint32_t HASH_InitTypeDef::DataType`
32-bit data, 16-bit data, 8-bit data or 1-bit string. This parameter can be a value of `HASH_Data_Type`
- `uint32_t HASH_InitTypeDef::KeySize`
The key size is used only in HMAC operation
- `uint8_t* HASH_InitTypeDef::pKey`
The key is used only in HMAC operation

28.2.2 HASH_HandleTypeDef

Data Fields

- `HASH_InitTypeDef Init`
- `uint8_t * pHASHInBuffPtr`
- `uint8_t * pHASHOutBuffPtr`
- `_IO uint32_t HashBuffSize`
- `_IO uint32_t HashInCount`
- `_IO uint32_t HashITCounter`
- `HAL_StatusTypeDef Status`
- `HAL_HASHPhaseTypeDef Phase`
- `DMA_HandleTypeDef * hdmain`
- `HAL_LockTypeDef Lock`
- `_IO HAL_HASH_STATETypeDef State`

Field Documentation

- `HASH_InitTypeDef HASH_HandleTypeDef::Init`
HASH required parameters
- `uint8_t* HASH_HandleTypeDef::pHashInBuffPtr`
Pointer to input buffer

- ***uint8_t* HASH_HandleTypeDef::pHashOutBuffPtr***
Pointer to input buffer
- ***_IO uint32_t HASH_HandleTypeDef::HashBuffSize***
Size of buffer to be processed
- ***_IO uint32_t HASH_HandleTypeDef::HashInCount***
Counter of inputed data
- ***_IO uint32_t HASH_HandleTypeDef::HashITCounter***
Counter of issued interrupts
- ***HAL_StatusTypeDef HASH_HandleTypeDef::Status***
HASH peripheral status
- ***HAL_HASHPhaseTypeDef HASH_HandleTypeDef::Phase***
HASH peripheral phase
- ***DMA_HandleTypeDef* HASH_HandleTypeDef::hdmain***
HASH In DMA handle parameters
- ***HAL_LockTypeDef HASH_HandleTypeDef::Lock***
HASH locking object
- ***_IO HAL_HASH_STATETypeDef HASH_HandleTypeDef::State***
HASH peripheral state

28.3 HASH Firmware driver API description

28.3.1 How to use this driver

The HASH HAL driver can be used as follows:

1. Initialize the HASH low level resources by implementing the HAL_HASH_MspInit():
 - a. Enable the HASH interface clock using `_HAL_RCC_HASH_CLK_ENABLE()`
 - b. In case of using processing APIs based on interrupts (e.g. `HAL_HMAC_SHA1_Start_IT()`)
 - Configure the HASH interrupt priority using `HAL_NVIC_SetPriority()`
 - Enable the HASH IRQ handler using `HAL_NVIC_EnableIRQ()`
 - In HASH IRQ handler, call `HAL_HASH_IRQHandler()`
 - c. In case of using DMA to control data transfer (e.g. `HAL_HMAC_SHA1_Start_DMA()`)
 - Enable the DMAx interface clock using `_DMAx_CLK_ENABLE()`
 - Configure and enable one DMA stream one for managing data transfer from memory to peripheral (input stream). Managing data transfer from peripheral to memory can be performed only using CPU
 - Associate the initialized DMA handle to the HASH DMA handle using `_HAL_LINKDMA()`
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Stream using `HAL_NVIC_SetPriority()` and `HAL_NVIC_EnableIRQ()`
2. Initialize the HASH HAL using `HAL_HASH_Init()`. This function configures mainly:
 - a. The data type: 1-bit, 8-bit, 16-bit and 32-bit.
 - b. For HMAC, the encryption key.
 - c. For HMAC, the key size used for encryption.
3. Three processing functions are available:
 - a. Polling mode: processing APIs are blocking functions i.e. they process the data and wait till the digest computation is finished e.g. `HAL_HASH_SHA1_Start()`
 - b. Interrupt mode: encryption and decryption APIs are not blocking functions i.e. they process the data under interrupt e.g. `HAL_HASH_SHA1_Start_IT()`

- c. DMA mode: processing APIs are not blocking functions and the CPU is not used for data transfer i.e. the data transfer is ensured by DMA e.g.
`HAL_HASH_SHA1_Start_DMA()`
- 4. When the processing function is called at first time after `HAL_HASH_Init()` the HASH peripheral is initialized and processes the buffer in input. After that, the digest computation is started. When processing multi-buffer use the accumulate function to write the data in the peripheral without starting the digest computation. In last buffer use the start function to input the last buffer and start the digest computation.
 - a. e.g. `HAL_HASH_SHA1_Accumulate()` : write 1st data buffer in the peripheral without starting the digest computation
 - b. write (n-1)th data buffer in the peripheral without starting the digest computation
 - c. `HAL_HASH_SHA1_Start()` : write (n)th data buffer in the peripheral and start the digest computation
- 5. In HMAC mode, there is no Accumulate API. Only Start API is available.
- 6. In case of using DMA, call the DMA start processing e.g.
`HAL_HASH_SHA1_Start_DMA()`. After that, call the finish function in order to get the digest value e.g. `HAL_HASH_SHA1_Finish()`
- 7. Call `HAL_HASH_DeInit()` to deinitialize the HASH peripheral.

28.3.2 HASH processing using polling mode functions

This section provides functions allowing to calculate in polling mode the hash value using one of the following algorithms:

- MD5
- SHA1

This section contains the following APIs:

- `HAL_HASH_MD5_Start()`
- `HAL_HASH_MD5_Accumulate()`
- `HAL_HASH_SHA1_Start()`
- `HAL_HASH_SHA1_Accumulate()`

28.3.3 HASH processing using interrupt mode functions

This section provides functions allowing to calculate in interrupt mode the hash value using one of the following algorithms:

- MD5
- SHA1

This section contains the following APIs:

- `HAL_HASH_MD5_Start_IT()`
- `HAL_HASH_SHA1_Start_IT()`
- `HAL_HASH_IRQHandler()`
- `HAL_HMAC_SHA1_Start()`
- `HAL_HMAC_MD5_Start()`

28.3.4 HASH processing using DMA mode functions

This section provides functions allowing to calculate in DMA mode the hash value using one of the following algorithms:

- MD5
- SHA1

This section contains the following APIs:

-
- [`HAL_HASH_MD5_Start_DMA\(\)`](#)
 - [`HAL_HASH_MD5_Finish\(\)`](#)
 - [`HAL_HASH_SHA1_Start_DMA\(\)`](#)
 - [`HAL_HASH_SHA1_Finish\(\)`](#)
 - [`HAL_HASH_SHA1_Start_IT\(\)`](#)
 - [`HAL_HASH_MD5_Start_IT\(\)`](#)

28.3.5 HMAC processing using polling mode functions

This section provides functions allowing to calculate in polling mode the HMAC value using one of the following algorithms:

- MD5
- SHA1

This section contains the following APIs:

- [`HAL_HMAC_MD5_Start\(\)`](#)
- [`HAL_HMAC_SHA1_Start\(\)`](#)
- [`HAL_HASH_SHA1_Start_DMA\(\)`](#)
- [`HAL_HASH_SHA1_Finish\(\)`](#)
- [`HAL_HASH_MD5_Start_DMA\(\)`](#)
- [`HAL_HASH_MD5_Finish\(\)`](#)

28.3.6 HMAC processing using DMA mode functions

This section provides functions allowing to calculate in DMA mode the HMAC value using one of the following algorithms:

- MD5
- SHA1

This section contains the following APIs:

- [`HAL_HMAC_MD5_Start_DMA\(\)`](#)
- [`HAL_HMAC_SHA1_Start_DMA\(\)`](#)

28.3.7 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral.

This section contains the following APIs:

- [`HAL_HASH_GetState\(\)`](#)
- [`HAL_HASH_IRQHandler\(\)`](#)

28.3.8 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the HASH according to the specified parameters in the HASH_InitTypeDef and creates the associated handle.
- DeInitialize the HASH peripheral.
- Initialize the HASH MSP.
- DeInitialize HASH MSP.

This section contains the following APIs:

- [`HAL_HASH_Init\(\)`](#)
- [`HAL_HASH_DelInit\(\)`](#)
- [`HAL_HASH_MspInit\(\)`](#)

- `HAL_HASH_MspDeInit()`
- `HAL_HASH_InCpltCallback()`
- `HAL_HASH_ErrorCallback()`
- `HAL_HASH_DgstCpltCallback()`

28.3.9 HAL_HASH_MD5_Start

Function Name	<code>HAL_StatusTypeDef HAL_HASH_MD5_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Initializes the HASH peripheral in MD5 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is multiple of 64 bytes, appending the input buffer is possible. If the Size is not multiple of 64 bytes, the padding is managed by hardware and appending the input buffer is no more possible. • pOutBuffer: Pointer to the computed digest. Its size must be 16 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

28.3.10 HAL_HASH_MD5_Accumulate

Function Name	<code>HAL_StatusTypeDef HAL_HASH_MD5_Accumulate (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)</code>
Function Description	Initializes the HASH peripheral in MD5 mode then writes the pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is multiple of 64 bytes, appending the input buffer is possible. If the Size is not multiple of 64 bytes, the padding is managed by hardware and appending the input buffer is no more possible.
Return values	<ul style="list-style-type: none"> • HAL status

28.3.11 HAL_HASH_SHA1_Start

Function Name	<code>HAL_StatusTypeDef HAL_HASH_SHA1_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Initializes the HASH peripheral in SHA1 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not

	<ul style="list-style-type: none"> multiple of 64 bytes, the padding is managed by hardware.
	<ul style="list-style-type: none"> pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes.
	<ul style="list-style-type: none"> Timeout: Timeout value

Return values • HAL status

28.3.12 HAL_HASH_SHA1_Accumulate

Function Name	HAL_StatusTypeDef HAL_HASH_SHA1_Accumulate (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA1 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	• HAL status
Notes	<ul style="list-style-type: none"> Input buffer size in bytes must be a multiple of 4 otherwise the digest computation is corrupted.

28.3.13 HAL_HASH_MD5_Start_IT

Function Name	HAL_StatusTypeDef HAL_HASH_MD5_Start_IT (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer)
Function Description	Initializes the HASH peripheral in MD5 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. pOutBuffer: Pointer to the computed digest. Its size must be 16 bytes.
Return values	• HAL status

28.3.14 HAL_HASH_SHA1_Start_IT

Function Name	HAL_StatusTypeDef HAL_HASH_SHA1_Start_IT (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer)
Function Description	Initializes the HASH peripheral in SHA1 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not

- multiple of 64 bytes, the padding is managed by hardware.
- **pOutBuffer:** Pointer to the computed digest. Its size must be 20 bytes.
 - HAL status

Return values

28.3.15 HAL_HASH_IRQHandler

Function Name	void HAL_HASH_IRQHandler (HASH_HandleTypeDef * hhash)
Function Description	This function handles HASH interrupt request.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.16 HAL_HMAC_SHA1_Start

Function Name	HAL_StatusTypeDef HAL_HMAC_SHA1_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in HMAC SHA1 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

28.3.17 HAL_HMAC_MD5_Start

Function Name	HAL_StatusTypeDef HAL_HMAC_MD5_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in HMAC MD5 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

28.3.18 HAL_HASH_MD5_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASH_MD5_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in MD5 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

28.3.19 HAL_HASH_MD5_Finish

Function Name	HAL_StatusTypeDef HAL_HASH_MD5_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Returns the computed digest in MD5 mode.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pOutBuffer: Pointer to the computed digest. Its size must be 16 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

28.3.20 HAL_HASH_SHA1_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASH_SHA1_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA1 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

28.3.21 HAL_HASH_SHA1_Finish

Function Name	HAL_StatusTypeDef HAL_HASH_SHA1_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Returns the computed digest in SHA1 mode.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes.

- **Timeout:** Timeout value

Return values • HAL status

28.3.22 HAL_HASH_SHA1_Start_IT

Function Name	<code>HAL_StatusTypeDef HAL_HASH_SHA1_Start_IT (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer)</code>
Function Description	Initializes the HASH peripheral in SHA1 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes.
Return values	• HAL status

28.3.23 HAL_HASH_MD5_Start_IT

Function Name	<code>HAL_StatusTypeDef HAL_HASH_MD5_Start_IT (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer)</code>
Function Description	Initializes the HASH peripheral in MD5 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 16 bytes.
Return values	• HAL status

28.3.24 HAL_HMAC_MD5_Start

Function Name	<code>HAL_StatusTypeDef HAL_HMAC_MD5_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Initializes the HASH peripheral in HMAC MD5 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes.

- **Timeout:** Timeout value
- HAL status

28.3.25 HAL_HMAC_SHA1_Start

Function Name	<code>HAL_StatusTypeDef HAL_HMAC_SHA1_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Initializes the HASH peripheral in HMAC SHA1 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

28.3.26 HAL_HASH_SHA1_Start_DMA

Function Name	<code>HAL_StatusTypeDef HAL_HASH_SHA1_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)</code>
Function Description	Initializes the HASH peripheral in SHA1 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

28.3.27 HAL_HASH_SHA1_Finish

Function Name	<code>HAL_StatusTypeDef HAL_HASH_SHA1_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Returns the computed digest in SHA1 mode.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

28.3.28 HAL_HASH_MD5_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASH_MD5_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in MD5 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status
28.3.29 HAL_HASH_MD5_Finish	
Function Name	HAL_StatusTypeDef HAL_HASH_MD5_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Returns the computed digest in MD5 mode.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pOutBuffer: Pointer to the computed digest. Its size must be 16 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status
28.3.30 HAL_HMAC_MD5_Start_DMA	
Function Name	HAL_StatusTypeDef HAL_HMAC_MD5_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in HMAC MD5 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status
28.3.31 HAL_HMAC_SHA1_Start_DMA	
Function Name	HAL_StatusTypeDef HAL_HMAC_SHA1_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in HMAC SHA1 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed).

- **Size:** Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.

Return values • HAL status

28.3.32 HAL_HASH_GetState

Function Name **HAL_HASH_STATETypeDef HAL_HASH_GetState (HASH_HandleTypeDef * hhash)**

Function Description return the HASH state

Parameters • **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

Return values • HAL state

28.3.33 HAL_HASH_IRQHandler

Function Name **void HAL_HASH_IRQHandler (HASH_HandleTypeDef * hhash)**

Function Description This function handles HASH interrupt request.

Parameters • **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

Return values • None

28.3.34 HAL_HASH_Init

Function Name **HAL_StatusTypeDef HAL_HASH_Init (HASH_HandleTypeDef * hhash)**

Function Description Initializes the HASH according to the specified parameters in the HASH_HandleTypeDef and creates the associated handle.

Parameters • **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

Return values • HAL status

28.3.35 HAL_HASH_DeInit

Function Name **HAL_StatusTypeDef HAL_HASH_DeInit (HASH_HandleTypeDef * hhash)**

Function Description DeInitializes the HASH peripheral.

Parameters • **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

Return values • HAL status

Notes • This API must be called before starting a new processing.

28.3.36 HAL_HASH_MspInit

Function Name **void HAL_HASH_MspInit (HASH_HandleTypeDef * hhash)**

Function Description Initializes the HASH MSP.

Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.37 HAL_HASH_MspDeInit

Function Name	void HAL_HASH_MspDeInit (HASH_HandleTypeDef * hhash)
Function Description	DeInitializes HASH MSP.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.38 HAL_HASH_InCpltCallback

Function Name	void HAL_HASH_InCpltCallback (HASH_HandleTypeDef * hhash)
Function Description	Input data transfer complete callback.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.39 HAL_HASH_ErrorCallback

Function Name	void HAL_HASH_ErrorCallback (HASH_HandleTypeDef * hhash)
Function Description	Data transfer Error callback.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.40 HAL_HASH_DgstCpltCallback

Function Name	void HAL_HASH_DgstCpltCallback (HASH_HandleTypeDef * hhash)
Function Description	Digest computation complete callback.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • This callback is not relevant with DMA.

28.3.41 HAL_HASH_GetState

Function Name	HAL_HASH_STATETypeDef HAL_HASH_GetState (HASH_HandleTypeDef * hhash)
Function Description	return the HASH state

Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • HAL state

28.3.42 HAL_HASH_MspInit

Function Name	void HAL_HASH_MspInit (HASH_HandleTypeDef * hhash)
Function Description	Initializes the HASH MSP.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.43 HAL_HASH_MspDeInit

Function Name	void HAL_HASH_MspDeInit (HASH_HandleTypeDef * hhash)
Function Description	Deinitializes HASH MSP.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.44 HAL_HASH_InCpltCallback

Function Name	void HAL_HASH_InCpltCallback (HASH_HandleTypeDef * hhash)
Function Description	Input data transfer complete callback.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

28.3.45 HAL_HASH_DgstCpltCallback

Function Name	void HAL_HASH_DgstCpltCallback (HASH_HandleTypeDef * hhash)
Function Description	Digest computation complete callback.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none"> • None

Notes

- This callback is not relevant with DMA.

28.3.46 HAL_HASH_ErrorCallback

Function Name	void HAL_HASH_ErrorCallback (HASH_HandleTypeDef * hhash)
Function Description	Data transfer Error callback.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that

Return values • None

28.4 HASH Firmware driver defines

28.4.1 HASH

HASH Data Type

- HASH_DATATYPE_32B 32-bit data. No swapping
- HASH_DATATYPE_16B 16-bit data. Each half word is swapped
- HASH_DATATYPE_8B 8-bit data. All bytes are swapped
- HASH_DATATYPE_1B 1-bit data. In the word all bits are swapped

HASH Algorithm Selection

- HASH_ALGOSELECTION_SHA1 HASH function is SHA1
- HASH_ALGOSELECTION_SHA224 HASH function is SHA224
- HASH_ALGOSELECTION_SHA256 HASH function is SHA256
- HASH_ALGOSELECTION_MD5 HASH function is MD5

HASH Algorithm Mode

- HASH_ALGOMODE_HASH Algorithm is HASH
- HASH_ALGOMODE_HMAC Algorithm is HMAC

HASH HMAC Long key

- HASH_HMAC_KEYTYPE_SHORTKEY HMAC Key is <= 64 bytes
- HASH_HMAC_KEYTYPE_LONGKEY HMAC Key is > 64 bytes

HASH Flags definition

- HASH_FLAG_DINIS 16 locations are free in the DIN : A new block can be entered into the input buffer
- HASH_FLAG_DCIS Digest calculation complete
- HASH_FLAG_DMAS DMA interface is enabled (DMAE=1) or a transfer is ongoing
- HASH_FLAG_BUSY The hash core is Busy : processing a block of data
- HASH_FLAG_DINNE DIN not empty : The input buffer contains at least one word of data

HASH Interrupts definition

- HASH_IT_DINI A new block can be entered into the input buffer (DIN)
- HASH_IT_DCI Digest calculation complete

HASH Exported Macros

`_HAL_HASH_RESET_HANDLE_STATE` **Description:**

- Reset HASH handle state.

Parameters:

- `_HANDLE_`: specifies the HASH handle.

Return value:

- None

[__HAL_HASH_GET_FLAG](#)**Description:**

- Check whether the specified HASH flag is set or not.

Parameters:

- [__FLAG__](#): specifies the flag to check. This parameter can be one of the following values:
 - HASH_FLAG_DINIS: A new block can be entered into the input buffer.
 - HASH_FLAG_DCIS: Digest calculation complete
 - HASH_FLAG_DMAS: DMA interface is enabled (DMAE=1) or a transfer is ongoing
 - HASH_FLAG_BUSY: The hash core is Busy : processing a block of data
 - HASH_FLAG_DINNE: DIN not empty : The input buffer contains at least one word of data

Return value:

- The: new state of [__FLAG__](#) (TRUE or FALSE).

[__HAL_HASH_SET_MDMAT](#)**Description:**

- Enable the multiple DMA mode.

Return value:

- None

[__HAL_HASH_RESET_MDMAT](#)**Description:**

- Disable the multiple DMA mode.

Return value:

- None

[__HAL_HASH_START_DIGEST](#)**Description:**

- Start the digest computation.

Return value:

- None

[__HAL_HASH_SET_NBVALIDBITS](#)**Description:**

- Set the number of valid bits in last word written in Data register.

Parameters:

- SIZE: size in byte of last data written in Data register.

Return value:

- None

HASH Private Macros

IS_HASH_ALGOSELECTION
IS_HASH_ALGOMODE
IS_HASH_DATATYPE
IS_HASH_HMAC_KEYTYPE
IS_HASH_SHA1_BUFFER_SIZE

29 HAL HASH Extension Driver

29.1 HAL HASH Extension Driver

29.2 HASHEx Firmware driver API description

29.2.1 How to use this driver

The HASH HAL driver can be used as follows:

1. Initialize the HASH low level resources by implementing the HAL_HASH_MspInit():
 - a. Enable the HASH interface clock using __HAL_RCC_HASH_CLK_ENABLE()
 - b. In case of using processing APIs based on interrupts (e.g.
HAL_HMACEx_SHA224_Start())
 - Configure the HASH interrupt priority using HAL_NVIC_SetPriority()
 - Enable the HASH IRQ handler using HAL_NVIC_EnableIRQ()
 - In HASH IRQ handler, call HAL_HASH_IRQHandler()
 - c. In case of using DMA to control data transfer (e.g.
HAL_HMACEx_SH224_Start_DMA())
 - Enable the DMAx interface clock using __DMAx_CLK_ENABLE()
 - Configure and enable one DMA stream one for managing data transfer from memory to peripheral (input stream). Managing data transfer from peripheral to memory can be performed only using CPU
 - Associate the initialized DMA handle to the HASH DMA handle using __HAL_LINKDMA()
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Stream: HAL_NVIC_SetPriority() and HAL_NVIC_EnableIRQ()
2. Initialize the HASH HAL using HAL_HASH_Init(). This function configures mainly:
 - a. The data type: 1-bit, 8-bit, 16-bit and 32-bit.
 - b. For HMAC, the encryption key.
 - c. For HMAC, the key size used for encryption.
3. Three processing functions are available:
 - a. Polling mode: processing APIs are blocking functions i.e. they process the data and wait till the digest computation is finished e.g.
HAL_HASHEx_SHA224_Start()
 - b. Interrupt mode: encryption and decryption APIs are not blocking functions i.e. they process the data under interrupt e.g. HAL_HASHEx_SHA224_Start_IT()
 - c. DMA mode: processing APIs are not blocking functions and the CPU is not used for data transfer i.e. the data transfer is ensured by DMA e.g.
HAL_HASHEx_SHA224_Start_DMA()
4. When the processing function is called at first time after HAL_HASH_Init() the HASH peripheral is initialized and processes the buffer in input. After that, the digest computation is started. When processing multi-buffer use the accumulate function to write the data in the peripheral without starting the digest computation. In last buffer use the start function to input the last buffer and start the digest computation.
 - a. e.g. HAL_HASHEx_SHA224_Accumulate() : write 1st data buffer in the peripheral without starting the digest computation
 - b. write (n-1)th data buffer in the peripheral without starting the digest computation
 - c. HAL_HASHEx_SHA224_Start() : write (n)th data buffer in the peripheral and start the digest computation
5. In HMAC mode, there is no Accumulate API. Only Start API is available.

-
6. In case of using DMA, call the DMA start processing e.g.
`HAL_HASHEx_SHA224_Start_DMA()`. After that, call the finish function in order to get
the digest value e.g. `HAL_HASHEx_SHA224_Finish()`
 7. Call `HAL_HASH_DeInit()` to deinitialize the HASH peripheral.

29.2.2 HASH processing using polling mode functions

This section provides functions allowing to calculate in polling mode the hash value using one of the following algorithms:

- SHA224
- SHA256

This section contains the following APIs:

- `HAL_HASHEx_SHA224_Start()`
- `HAL_HASHEx_SHA256_Start()`
- `HAL_HASHEx_SHA224_Accumulate()`
- `HAL_HASHEx_SHA256_Accumulate()`

29.2.3 HMAC processing using polling mode functions

This section provides functions allowing to calculate in polling mode the HMAC value using one of the following algorithms:

- SHA224
- SHA256

This section contains the following APIs:

- `HAL_HMACEx_SHA224_Start()`
- `HAL_HMACEx_SHA256_Start()`

29.2.4 HASH processing using interrupt functions

This section provides functions allowing to calculate in interrupt mode the hash value using one of the following algorithms:

- SHA224
- SHA256

This section contains the following APIs:

- `HAL_HASHEx_SHA224_Start_IT()`
- `HAL_HASHEx_SHA256_Start_IT()`
- `HAL_HASHEx_IRQHandler()`

29.2.5 HASH processing using DMA functions

This section provides functions allowing to calculate in DMA mode the hash value using one of the following algorithms:

- SHA224
- SHA256

This section contains the following APIs:

- `HAL_HASHEx_SHA224_Start_DMA()`
- `HAL_HASHEx_SHA224_Finish()`
- `HAL_HASHEx_SHA256_Start_DMA()`
- `HAL_HASHEx_SHA256_Finish()`

29.2.6 HMAC processing using DMA functions

This section provides functions allowing to calculate in DMA mode the HMAC value using one of the following algorithms:

- SHA224
- SHA256

This section contains the following APIs:

- [*HAL_HMACEEx_SHA224_Start_DMA\(\)*](#)
- [*HAL_HMACEEx_SHA256_Start_DMA\(\)*](#)

29.2.7 HAL_HASHEx_SHA224_Start

Function Name	<code>HAL_StatusTypeDef HAL_HASHEx_SHA224_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Initializes the HASH peripheral in SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 28 bytes. • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

29.2.8 HAL_HASHEx_SHA256_Start

Function Name	<code>HAL_StatusTypeDef HAL_HASHEx_SHA256_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Initializes the HASH peripheral in SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 32 bytes. • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

29.2.9 HAL_HASHEx_SHA224_Accumulate

Function Name	<code>HAL_StatusTypeDef HAL_HASHEx_SHA224_Accumulate (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)</code>
---------------	--

Function Description	Initializes the HASH peripheral in SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> HAL status

29.2.10 HAL_HASHEx_SHA256_Accumulate

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Accumulate(HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> HAL status

29.2.11 HAL_HMACEx_SHA224_Start

Function Name	HAL_StatusTypeDef HAL_HMACEx_SHA224_Start(HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in HMAC SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. Timeout: Timeout value
Return values	<ul style="list-style-type: none"> HAL status

29.2.12 HAL_HMACEx_SHA256_Start

Function Name	HAL_StatusTypeDef HAL_HMACEx_SHA256_Start(HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in HMAC SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

- **pInBuffer:** Pointer to the input buffer (buffer to be hashed).
- **Size:** Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
- **pOutBuffer:** Pointer to the computed digest. Its size must be 20 bytes.
- **Timeout:** Timeout value

Return values

- HAL status

29.2.13 HAL_HASHEx_SHA224_Start_IT

Function Name

**HAL_StatusTypeDef HAL_HASHEx_SHA224_Start_IT
(HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t
Size, uint8_t * pOutBuffer)**

Function Description

Initializes the HASH peripheral in SHA224 mode then processes pInBuffer.

Parameters

- **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
- **pInBuffer:** Pointer to the input buffer (buffer to be hashed).
- **Size:** Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
- **pOutBuffer:** Pointer to the computed digest. Its size must be 20 bytes.

Return values

- HAL status

29.2.14 HAL_HASHEx_SHA256_Start_IT

Function Name

**HAL_StatusTypeDef HAL_HASHEx_SHA256_Start_IT
(HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t
Size, uint8_t * pOutBuffer)**

Function Description

Initializes the HASH peripheral in SHA256 mode then processes pInBuffer.

Parameters

- **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
- **pInBuffer:** Pointer to the input buffer (buffer to be hashed).
- **Size:** Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
- **pOutBuffer:** Pointer to the computed digest. Its size must be 20 bytes.

Return values

- HAL status

29.2.15 HAL_HASHEx_IRQHandler

Function Name

**void HAL_HASHEx_IRQHandler (HASH_HandleTypeDef *
hhash)**

Function Description

This function handles HASH interrupt request.

Parameters

- **hhash:** pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

Return values

- None

29.2.16 HAL_HASHEx_SHA224_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA224 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.17 HAL_HASHEx_SHA224_Finish

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Returns the computed digest in SHA224.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pOutBuffer: Pointer to the computed digest. Its size must be 28 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

29.2.18 HAL_HASHEx_SHA256_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA256 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.19 HAL_HASHEx_SHA256_Finish

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Returns the computed digest in SHA256.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module

- **pOutBuffer:** Pointer to the computed digest. Its size must be 32 bytes.
- **Timeout:** Timeout value
- HAL status

Return values

29.2.20 HAL_HMACEx_SHA224_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HMACEx_SHA224_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in HMAC SHA224 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.21 HAL_HMACEx_SHA256_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HMACEx_SHA256_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in HMAC SHA256 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.22 HAL_HASHEx_SHA224_Start

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 28 bytes. • Timeout: Specify Timeout value

Return values	<ul style="list-style-type: none"> • HAL status
29.2.23 HAL_HASHEx_SHA256_Start	
Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 32 bytes. • Timeout: Specify Timeout value
Return values	<ul style="list-style-type: none"> • HAL status
29.2.24 HAL_HASHEx_SHA224_Accumulate	
Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Accumulate (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status
29.2.25 HAL_HASHEx_SHA256_Accumulate	
Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Accumulate (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status
29.2.26 HAL_HMACEx_SHA224_Start	

Function Name	HAL_StatusTypeDef HAL_HMACEx_SHA224_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in HMAC SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

29.2.27 HAL_HMACEx_SHA256_Start

Function Name	HAL_StatusTypeDef HAL_HMACEx_SHA256_Start (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Initializes the HASH peripheral in HMAC SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

29.2.28 HAL_HASHEx_SHA224_Start_IT

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Start_IT (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer)
Function Description	Initializes the HASH peripheral in SHA224 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.29 HAL_HASHEx_SHA256_Start_IT

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Start_IT (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size, uint8_t * pOutBuffer)
Function Description	Initializes the HASH peripheral in SHA256 mode then processes pInBuffer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware. • pOutBuffer: Pointer to the computed digest. Its size must be 20 bytes.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.30 HAL_HASHEx_SHA224_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA224 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pInBuffer: Pointer to the input buffer (buffer to be hashed). • Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> • HAL status

29.2.31 HAL_HASHEx_SHA224_Finish

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA224_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)
Function Description	Returns the computed digest in SHA224.
Parameters	<ul style="list-style-type: none"> • hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module • pOutBuffer: Pointer to the computed digest. Its size must be 28 bytes. • Timeout: Timeout value
Return values	<ul style="list-style-type: none"> • HAL status

29.2.32 HAL_HASHEx_SHA256_Start_DMA

Function Name	HAL_StatusTypeDef HAL_HASHEx_SHA256_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)
Function Description	Initializes the HASH peripheral in SHA256 mode then enables DMA to control data transfer.

Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> HAL status

29.2.33 HAL_HASHEx_SHA256_Finish

Function Name	<code>HAL_StatusTypeDef HAL_HASHEx_SHA256_Finish (HASH_HandleTypeDef * hhash, uint8_t * pOutBuffer, uint32_t Timeout)</code>
Function Description	Returns the computed digest in SHA256.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pOutBuffer: Pointer to the computed digest. Its size must be 32 bytes. Timeout: Timeout value
Return values	<ul style="list-style-type: none"> HAL status

29.2.34 HAL_HMACEx_SHA224_Start_DMA

Function Name	<code>HAL_StatusTypeDef HAL_HMACEx_SHA224_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)</code>
Function Description	Initializes the HASH peripheral in HMAC SHA224 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> HAL status

29.2.35 HAL_HMACEx_SHA256_Start_DMA

Function Name	<code>HAL_StatusTypeDef HAL_HMACEx_SHA256_Start_DMA (HASH_HandleTypeDef * hhash, uint8_t * pInBuffer, uint32_t Size)</code>
Function Description	Initializes the HASH peripheral in HMAC SHA256 mode then enables DMA to control data transfer.
Parameters	<ul style="list-style-type: none"> hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module pInBuffer: Pointer to the input buffer (buffer to be hashed). Size: Length of the input buffer in bytes. If the Size is not multiple of 64 bytes, the padding is managed by hardware.
Return values	<ul style="list-style-type: none"> HAL status

29.2.36 HAL_HASHEx_IRQHandler

Function Name	<code>void HAL_HASHEx_IRQHandler (HASH_HandleTypeDef * hhash)</code>
Function Description	This function handles HASH interrupt request.
Parameters	<ul style="list-style-type: none">• hhash: pointer to a HASH_HandleTypeDef structure that contains the configuration information for HASH module
Return values	<ul style="list-style-type: none">• None

29.3 HASHEx Firmware driver defines**29.3.1 HASHEx**

30 HAL HCD Generic Driver

30.1 HAL HCD Generic Driver

30.2 HCD Firmware driver registers structures

30.2.1 HCD_HandleTypeDef

Data Fields

- *HCD_TypeDef * Instance*
- *HCD_InitTypeDef Init*
- *HCD_HCTypedef hc*
- *HAL_LockTypeDef Lock*
- *__IO HCD_StateTypeDef State*
- *void * pData*

Field Documentation

- ***HCD_TypeDef* HCD_HandleTypeDef::Instance***
Register base address
- ***HCD_InitTypeDef HCD_HandleTypeDef::Init***
HCD required parameters
- ***HCD_HCTypedef HCD_HandleTypeDef::hc[15]***
Host channels parameters
- ***HAL_LockTypeDef HCD_HandleTypeDef::Lock***
HCD peripheral status
- ***__IO HCD_StateTypeDef HCD_HandleTypeDef::State***
HCD communication state
- ***void* HCD_HandleTypeDef::pData***
Pointer Stack Handler

30.3 HCD Firmware driver API description

30.3.1 How to use this driver

1. Declare a HCD_HandleTypeDef handle structure, for example: `HCD_HandleTypeDef hhcd;`
2. Fill parameters of Init structure in HCD handle
3. Call `HAL_HCD_Init()` API to initialize the HCD peripheral (Core, Host core, ...)
4. Initialize the HCD low level resources through the `HAL_HCD_MspInit()` API:
 - a. Enable the HCD/USB Low Level interface clock using the following macros
 - `__HAL_RCC_USB_OTG_FS_CLK_ENABLE();`
 - `__HAL_RCC_USB_OTG_HS_CLK_ENABLE();` (For High Speed Mode)
 - `__HAL_RCC_USB_OTG_HS_ULPI_CLK_ENABLE();` (For High Speed Mode)
 - b. Initialize the related GPIO clocks

- c. Configure HCD pin-out
 - d. Configure HCD NVIC interrupt

5. Associate the Upper USB Host stack to the HAL HCD Driver:

 - a. `hhcd.pData = phost;`

6. Enable HCD transmission and reception:

 - a. `HAL_HCD_Start();`

30.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

This section contains the following APIs:

- `HAL_HCD_Init()`
 - `HAL_HCD_HC_Init()`
 - `HAL_HCD_HC_Halt()`
 - `HAL_HCD_DelInit()`
 - `HAL_HCD_MspInit()`
 - `HAL_HCD_MspDelInit()`

30.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the USB Host Data Transfer

This section contains the following APIs:

- `HAL_HCD_HC_SubmitRequest()`
 - `HAL_HCD_IRQHandler()`
 - `HAL_HCD_SOF_Callback()`
 - `HAL_HCD_Connect_Callback()`
 - `HAL_HCD_Disconnect_Callback()`
 - `HAL_HCD_HC_NotifyURBChange_Callback()`

30.3.4 Peripheral Control functions

This subsection provides a set of functions allowing to control the HCD data transfers.

This section contains the following APIs:

- *HAL_HCD_Start()*
 - *HAL_HCD_Stop()*
 - *HAL_HCD_ResetPort()*

30.3.5 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- `HAL_HCD_GetState()`
 - `HAL_HCD_HC_GetURBState()`
 - `HAL_HCD_HC_GetXferCount()`
 - `HAL_HCD_HC_GetState()`
 - `HAL_HCD_GetCurrentFrame()`
 - `HAL_HCD_GetCurrentSpeed()`

30.3.6 HAI HCD Init

Function Name HAL_StatusTypeDef HAL_HCD_Init (HCD_HandleTypeDef **hcd*)

hhcd)

Function Description	Initialize the host driver.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • HAL status

30.3.7 HAL_HCD_HC_Init

Function Name	HAL_StatusTypeDef HAL_HCD_HC_Init (HCD_HandleTypeDef * hhcd, uint8_t ch_num, uint8_t epnum, uint8_t dev_address, uint8_t speed, uint8_t ep_type, uint16_t mps)
Function Description	Initialize a host channel.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • ch_num: Channel number. This parameter can be a value from 1 to 15 • epnum: Endpoint number. This parameter can be a value from 1 to 15 • dev_address: : Current device address This parameter can be a value from 0 to 255 • speed: Current device speed. This parameter can be one of these values: HCD_SPEED_HIGH: High speed mode, HCD_SPEED_FULL: Full speed mode, HCD_SPEED_LOW: Low speed mode • ep_type: Endpoint Type. This parameter can be one of these values: EP_TYPE_CTRL: Control type, EP_TYPE_ISOC: Isochronous type, EP_TYPE_BULK: Bulk type, EP_TYPE_INTR: Interrupt type • mps: Max Packet Size. This parameter can be a value from 0 to32K
Return values	<ul style="list-style-type: none"> • HAL status

30.3.8 HAL_HCD_HC_Halt

Function Name	HAL_StatusTypeDef HAL_HCD_HC_Halt (HCD_HandleTypeDef * hhcd, uint8_t ch_num)
Function Description	Halt a host channel.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • ch_num: Channel number. This parameter can be a value from 1 to 15

Return values

- HAL status

30.3.9 HAL_HCD_DelInit

Function Name	HAL_StatusTypeDef HAL_HCD_DelInit (HCD_HandleTypeDef * hhcd)
Function Description	DeInitialize the host driver.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • HAL status

30.3.10 HAL_HCD_MspInit

Function Name	void HAL_HCD_MspInit (HCD_HandleTypeDef * hhcd)
Function Description	Initialize the HCD MSP.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • None

30.3.11 HAL_HCD_MspDeInit

Function Name	void HAL_HCD_MspDeInit (HCD_HandleTypeDef * hhcd)
Function Description	Deinitialize the HCD MSP.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • None

30.3.12 HAL_HCD_HC_SubmitRequest

Function Name	HAL_StatusTypeDef HAL_HCD_HC_SubmitRequest (HCD_HandleTypeDef * hhcd, uint8_t ch_num, uint8_t direction, uint8_t ep_type, uint8_t token, uint8_t * pbuff, uint16_t length, uint8_t do_ping)
Function Description	Submit a new URB for processing.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • ch_num: Channel number. This parameter can be a value from 1 to 15 • direction: Channel number. This parameter can be one of these values: 0 : Output / 1 : Input • ep_type: Endpoint Type. This parameter can be one of these values: EP_TYPE_CTRL: Control type/ EP_TYPE_ISOC: Isochronous type/ EP_TYPE_BULK: Bulk type/ EP_TYPE_INTR: Interrupt type/ • token: Endpoint Type. This parameter can be one of these values: 0: HC_PID_SETUP / 1: HC_PID_DATA1 • pbuff: pointer to URB data • length: Length of URB data • do_ping: activate do ping protocol (for high speed only). This parameter can be one of these values: 0 : do ping inactive / 1 : do ping active
Return values	<ul style="list-style-type: none"> • HAL status

30.3.13 HAL_HCD_IRQHandler

Function Name	void HAL_HCD_IRQHandler (HCD_HandleTypeDef * hhcd)
Function Description	Handle HCD interrupt request.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • None

30.3.14 HAL_HCD_SOF_Callback

Function Name	void HAL_HCD_SOF_Callback (HCD_HandleTypeDef * hhcd)
Function Description	SOF callback.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • None

30.3.15 HAL_HCD_Connect_Callback

Function Name	void HAL_HCD_Connect_Callback (HCD_HandleTypeDef * hhcd)
Function Description	Connection Event callback.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • None

30.3.16 HAL_HCD_Disconnect_Callback

Function Name	void HAL_HCD_Disconnect_Callback (HCD_HandleTypeDef * hhcd)
Function Description	Disconnection Event callback.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • None

30.3.17 HAL_HCD_HC_NotifyURBChange_Callback

Function Name	void HAL_HCD_HC_NotifyURBChange_Callback (HCD_HandleTypeDef * hhcd, uint8_t chnum, HCD_URBStateTypeDef urb_state)
Function Description	Notify URB state change callback.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • chnum: Channel number. This parameter can be a value from 1 to 15 • urb_state: This parameter can be one of these values: URB_IDLE/ URB_DONE/ URB_NOTREADY/ URB_NYET/ URB_ERROR/ URB_STALL/
Return values	<ul style="list-style-type: none"> • None

30.3.18 HAL_HCD_Start

Function Name	HAL_StatusTypeDef HAL_HCD_Start (HCD_HandleTypeDef * hhcd)
Function Description	Start the host driver.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • HAL status

30.3.19 HAL_HCD_Stop

Function Name	HAL_StatusTypeDef HAL_HCD_Stop (HCD_HandleTypeDef * hhcd)
---------------	--

hhcd)

Function Description	Stop the host driver.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • HAL status

30.3.20 HAL_HCD_ResetPort

Function Name	HAL_StatusTypeDef HAL_HCD_ResetPort (HCD_HandleTypeDef * hhcd)
Function Description	Reset the host port.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • HAL status

30.3.21 HAL_HCD_GetState

Function Name	HCD_StateTypeDef HAL_HCD_GetState (HCD_HandleTypeDef * hhcd)
Function Description	Return the HCD handle state.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • HAL state

30.3.22 HAL_HCD_HC_GetURBState

Function Name	HCD_URBStateTypeDef HAL_HCD_HC_GetURBState (HCD_HandleTypeDef * hhcd, uint8_t chnum)
Function Description	Return URB state for a channel.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • chnum: Channel number. This parameter can be a value from 1 to 15
Return values	<ul style="list-style-type: none"> • URB state. This parameter can be one of these values: URB_IDLE/ URB_DONE/ URB_NOTREADY/ URB_NYET/ URB_ERROR/ URB_STALL

30.3.23 HAL_HCD_HC_GetXferCount

Function Name	uint32_t HAL_HCD_HC_GetXferCount (HCD_HandleTypeDef * hhcd, uint8_t chnum)
Function Description	Return the last host transfer size.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • chnum: Channel number. This parameter can be a value from 1 to 15
Return values	<ul style="list-style-type: none"> • last transfer size in byte

30.3.24 HAL_HCD_HC_GetState

Function Name	HCD_HCStateTypeDef HAL_HCD_HC_GetState
---------------	---

(HCD_HandleTypeDef * hhcd, uint8_t chnum)

Function Description	Return the Host Channel state.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle • chnum: Channel number. This parameter can be a value from 1 to 15
Return values	<ul style="list-style-type: none"> • Host channel state This parameter can be one of these values: HC_IDLE/ HC_XFRC/ HC_HALTED/ HC_NYET/ HC_NAK/ HC_STALL/ HC_XACTERR/ HC_BBLERR/ HC_DATATGLERR

30.3.25 HAL_HCD_GetCurrentFrame

Function Name	uint32_t HAL_HCD_GetCurrentFrame (HCD_HandleTypeDef * hhcd)
Function Description	Return the current Host frame number.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • Current Host frame number

30.3.26 HAL_HCD_GetCurrentSpeed

Function Name	uint32_t HAL_HCD_GetCurrentSpeed (HCD_HandleTypeDef * hhcd)
Function Description	Return the Host enumeration speed.
Parameters	<ul style="list-style-type: none"> • hhcd: HCD handle
Return values	<ul style="list-style-type: none"> • Enumeration speed

30.4 HCD Firmware driver defines

30.4.1 HCD

HCD Exported Macros

```

__HAL_HCD_ENABLE
__HAL_HCD_DISABLE
__HAL_HCD_GET_FLAG
__HAL_HCD_CLEAR_FLAG
__HAL_HCD_IS_INVALID_INTERRUPT
__HAL_HCD_CLEAR_HC_INT
__HAL_HCD_MASK_HALT_HC_INT
__HAL_HCD_UNMASK_HALT_HC_INT
__HAL_HCD_MASK_ACK_HC_INT
__HAL_HCD_UNMASK_ACK_HC_INT

```

HCD Instance definition

```
IS_HCD_ALL_INSTANCE
```

HCD PHY Module

HCD_PHY_ULPI

HCD_PHY_EMBEDDED

HCD Speed

HCD_SPEED_HIGH

HCD_SPEED_LOW

HCD_SPEED_FULL

31 HAL I2C Generic Driver

31.1 HAL I2C Generic Driver

31.2 I2C Firmware driver registers structures

31.2.1 I2C_InitTypeDef

Data Fields

- *uint32_t ClockSpeed*
- *uint32_t DutyCycle*
- *uint32_t OwnAddress1*
- *uint32_t AddressingMode*
- *uint32_t DualAddressMode*
- *uint32_t OwnAddress2*
- *uint32_t GeneralCallMode*
- *uint32_t NoStretchMode*

Field Documentation

- ***uint32_t I2C_InitTypeDef::ClockSpeed***
Specifies the clock frequency. This parameter must be set to a value lower than 400kHz
- ***uint32_t I2C_InitTypeDef::DutyCycle***
Specifies the I2C fast mode duty cycle. This parameter can be a value of *I2C_duty_cycle_in_fast_mode*
- ***uint32_t I2C_InitTypeDef::OwnAddress1***
Specifies the first device own address. This parameter can be a 7-bit or 10-bit address.
- ***uint32_t I2C_InitTypeDef::AddressingMode***
Specifies if 7-bit or 10-bit addressing mode is selected. This parameter can be a value of *I2C_addressing_mode*
- ***uint32_t I2C_InitTypeDef::DualAddressMode***
Specifies if dual addressing mode is selected. This parameter can be a value of *I2C_dual_addressing_mode*
- ***uint32_t I2C_InitTypeDef::OwnAddress2***
Specifies the second device own address if dual addressing mode is selected. This parameter can be a 7-bit address.
- ***uint32_t I2C_InitTypeDef::GeneralCallMode***
Specifies if general call mode is selected. This parameter can be a value of *I2C_general_call_addressing_mode*
- ***uint32_t I2C_InitTypeDef::NoStretchMode***
Specifies if nostretch mode is selected. This parameter can be a value of *I2C_nostretch_mode*

31.2.2 I2C_HandleTypeDefDef

Data Fields

- *I2C_TypeDef * Instance*
- *I2C_InitTypeDef Init*
- *uint8_t * pBuffPtr*
- *uint16_t XferSize*
- *__IO uint16_t XferCount*
- *DMA_HandleTypeDef * hdmatx*
- *DMA_HandleTypeDef * hdmarx*
- *HAL_LockTypeDef Lock*
- *__IO HAL_I2C_StateTypeDef State*
- *__IO uint32_t ErrorCode*

Field Documentation

- ***I2C_TypeDef* I2C_HandleTypeDef::Instance***
I2C registers base address
- ***I2C_InitTypeDef I2C_HandleTypeDef::Init***
I2C communication parameters
- ***uint8_t* I2C_HandleTypeDef::pBuffPtr***
Pointer to I2C transfer buffer
- ***uint16_t I2C_HandleTypeDef::XferSize***
I2C transfer size
- ***__IO uint16_t I2C_HandleTypeDef::XferCount***
I2C transfer counter
- ***DMA_HandleTypeDef* I2C_HandleTypeDef::hdmatx***
I2C Tx DMA handle parameters
- ***DMA_HandleTypeDef* I2C_HandleTypeDef::hdmarx***
I2C Rx DMA handle parameters
- ***HAL_LockTypeDef I2C_HandleTypeDef::Lock***
I2C locking object
- ***__IO HAL_I2C_StateTypeDef I2C_HandleTypeDef::State***
I2C communication state
- ***__IO uint32_t I2C_HandleTypeDef::ErrorCode***
I2C Error code

31.3 I2C Firmware driver API description

31.3.1 How to use this driver

The I2C HAL driver can be used as follows:

1. Declare a I2C_HandleTypeDef handle structure, for example: I2C_HandleTypeDef hi2c;
2. Initialize the I2C low level resources by implement the HAL_I2C_MspInit() API:
 - a. Enable the I2Cx interface clock
 - b. I2C pins configuration
 - Enable the clock for the I2C GPIOs
 - Configure I2C pins as alternate function open-drain
 - c. NVIC configuration if you need to use interrupt process
 - Configure the I2Cx interrupt priority
 - Enable the NVIC I2C IRQ Channel
 - d. DMA Configuration if you need to use DMA process

- Declare a DMA_HandleTypeDef handle structure for the transmit or receive stream
 - Enable the DMAx interface clock using
 - Configure the DMA handle parameters
 - Configure the DMA Tx or Rx Stream
 - Associate the initialized DMA handle to the hi2c DMA Tx or Rx handle
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx or Rx Stream
3. Configure the Communication Speed, Duty cycle, Addressing mode, Own Address1, Dual Addressing mode, Own Address2, General call and Nostretch mode in the hi2c Init structure.
 4. Initialize the I2C registers by calling the HAL_I2C_Init(), configures also the low level Hardware (GPIO, CLOCK, NVIC...etc) by calling the customized HAL_I2C_MspInit(&hi2c) API.
 5. To check if target device is ready for communication, use the function HAL_I2C_IsDeviceReady()
 6. For I2C IO and IO MEM operations, three operation modes are available within this driver :

Polling mode IO operation

- Transmit in master mode an amount of data in blocking mode using HAL_I2C_Master_Transmit()
- Receive in master mode an amount of data in blocking mode using HAL_I2C_Master_Receive()
- Transmit in slave mode an amount of data in blocking mode using HAL_I2C_Slave_Transmit()
- Receive in slave mode an amount of data in blocking mode using HAL_I2C_Slave_Receive()

Polling mode IO MEM operation

- Write an amount of data in blocking mode to a specific memory address using HAL_I2C_Mem_Write()
- Read an amount of data in blocking mode from a specific memory address using HAL_I2C_Mem_Read()

Interrupt mode IO operation

- Transmit in master mode an amount of data in non blocking mode using HAL_I2C_Master_Transmit_IT()
- At transmission end of transfer HAL_I2C_MasterTxCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MasterTxCallback
- Receive in master mode an amount of data in non blocking mode using HAL_I2C_Master_Receive_IT()
- At reception end of transfer HAL_I2C_MasterRxCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MasterRxCallback
- Transmit in slave mode an amount of data in non blocking mode using HAL_I2C_Slave_Transmit_IT()

- At transmission end of transfer HAL_I2C_SlaveTxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_SlaveTxCpltCallback
- Receive in slave mode an amount of data in non blocking mode using HAL_I2C_Slave_Receive_IT()
- At reception end of transfer HAL_I2C_SlaveRxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_SlaveRxCpltCallback
- In case of transfer Error, HAL_I2C_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2C_ErrorCallback

Interrupt mode IO MEM operation

- Write an amount of data in no-blocking mode with Interrupt to a specific memory address using HAL_I2C_Mem_Write_IT()
- At MEM end of write transfer HAL_I2C_MemTxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MemTxCpltCallback
- Read an amount of data in no-blocking mode with Interrupt from a specific memory address using HAL_I2C_Mem_Read_IT()
- At MEM end of read transfer HAL_I2C_MemRxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MemRxCpltCallback
- In case of transfer Error, HAL_I2C_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2C_ErrorCallback

DMA mode IO operation

- Transmit in master mode an amount of data in non blocking mode (DMA) using HAL_I2C_Master_Transmit_DMA()
- At transmission end of transfer HAL_I2C_MasterTxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MasterTxCpltCallback
- Receive in master mode an amount of data in non blocking mode (DMA) using HAL_I2C_Master_Receive_DMA()
- At reception end of transfer HAL_I2C_MasterRxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MasterRxCpltCallback
- Transmit in slave mode an amount of data in non blocking mode (DMA) using HAL_I2C_Slave_Transmit_DMA()
- At transmission end of transfer HAL_I2C_SlaveTxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_SlaveTxCpltCallback
- Receive in slave mode an amount of data in non blocking mode (DMA) using HAL_I2C_Slave_Receive_DMA()
- At reception end of transfer HAL_I2C_SlaveRxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_SlaveRxCpltCallback
- In case of transfer Error, HAL_I2C_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2C_ErrorCallback

DMA mode IO MEM operation

- Write an amount of data in no-blocking mode with DMA to a specific memory address using HAL_I2C_Mem_Write_DMA()

- At MEM end of write transfer HAL_I2C_MemTxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MemTxCpltCallback
- Read an amount of data in no-blocking mode with DMA from a specific memory address using HAL_I2C_Mem_Read_DMA()
- At MEM end of read transfer HAL_I2C_MemRxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2C_MemRxCpltCallback
- In case of transfer Error, HAL_I2C_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2C_ErrorCallback

I2C HAL driver macros list

Below the list of most used macros in I2C HAL driver.

- __HAL_I2C_ENABLE: Enable the I2C peripheral
- __HAL_I2C_DISABLE: Disable the I2C peripheral
- __HAL_I2C_GET_FLAG : Checks whether the specified I2C flag is set or not
- __HAL_I2C_CLEAR_FLAG : Clear the specified I2C pending flag
- __HAL_I2C_ENABLE_IT: Enable the specified I2C interrupt
- __HAL_I2C_DISABLE_IT: Disable the specified I2C interrupt



You can refer to the I2C HAL driver header file for more useful macros

31.3.2 Initialization and de-initialization functions

This subsection provides a set of functions allowing to initialize and de-initialize the I2Cx peripheral:

- User must Implement HAL_I2C_MspInit() function in which he configures all related peripherals resources (CLOCK, GPIO, DMA, IT and NVIC).
- Call the function HAL_I2C_Init() to configure the selected device with the selected configuration:
 - Communication Speed
 - Duty cycle
 - Addressing mode
 - Own Address 1
 - Dual Addressing mode
 - Own Address 2
 - General call mode
 - Nostretch mode
- Call the function HAL_I2C_DelInit() to restore the default configuration of the selected I2Cx peripheral.

This section contains the following APIs:

- [***HAL_I2C_Init\(\)***](#)
- [***HAL_I2C_DelInit\(\)***](#)
- [***HAL_I2C_MspInit\(\)***](#)
- [***HAL_I2C_MspDelInit\(\)***](#)

31.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the I2C data transfers.

1. There are two modes of transfer:

- Blocking mode : The communication is performed in the polling mode. The status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode : The communication is performed using Interrupts or DMA. These functions return the status of the transfer startup. The end of the data processing will be indicated through the dedicated I2C IRQ when using Interrupt mode or the DMA IRQ when using DMA mode.
2. Blocking mode functions are :
- HAL_I2C_Master_Transmit()
 - HAL_I2C_Master_Receive()
 - HAL_I2C_Slave_Transmit()
 - HAL_I2C_Slave_Receive()
 - HAL_I2C_Mem_Write()
 - HAL_I2C_Mem_Read()
 - HAL_I2C_IsDeviceReady()
3. No-Blocking mode functions with Interrupt are :
- HAL_I2C_Master_Transmit_IT()
 - HAL_I2C_Master_Receive_IT()
 - HAL_I2C_Slave_Transmit_IT()
 - HAL_I2C_Slave_Receive_IT()
 - HAL_I2C_Mem_Write_IT()
 - HAL_I2C_Mem_Read_IT()
4. No-Blocking mode functions with DMA are :
- HAL_I2C_Master_Transmit_DMA()
 - HAL_I2C_Master_Receive_DMA()
 - HAL_I2C_Slave_Transmit_DMA()
 - HAL_I2C_Slave_Receive_DMA()
 - HAL_I2C_Mem_Write_DMA()
 - HAL_I2C_Mem_Read_DMA()
5. A set of Transfer Complete Callbacks are provided in non Blocking mode:
- HAL_I2C_MemTxCpltCallback()
 - HAL_I2C_MemRxCpltCallback()
 - HAL_I2C_MasterTxCpltCallback()
 - HAL_I2C_MasterRxCpltCallback()
 - HAL_I2C_SlaveTxCpltCallback()
 - HAL_I2C_SlaveRxCpltCallback()
 - HAL_I2C_ErrorCallback()

This section contains the following APIs:

- [**HAL_I2C_Master_Transmit\(\)**](#)
- [**HAL_I2C_Master_Receive\(\)**](#)
- [**HAL_I2C_Slave_Transmit\(\)**](#)
- [**HAL_I2C_Slave_Receive\(\)**](#)
- [**HAL_I2C_Master_Transmit_IT\(\)**](#)
- [**HAL_I2C_Master_Receive_IT\(\)**](#)
- [**HAL_I2C_Slave_Transmit_IT\(\)**](#)
- [**HAL_I2C_Slave_Receive_IT\(\)**](#)
- [**HAL_I2C_Master_Transmit_DMA\(\)**](#)
- [**HAL_I2C_Master_Receive_DMA\(\)**](#)
- [**HAL_I2C_Slave_Transmit_DMA\(\)**](#)
- [**HAL_I2C_Slave_Receive_DMA\(\)**](#)
- [**HAL_I2C_Mem_Write\(\)**](#)
- [**HAL_I2C_Mem_Read\(\)**](#)

- `HAL_I2C_Mem_Write_IT()`
- `HAL_I2C_Mem_Read_IT()`
- `HAL_I2C_Mem_Write_DMA()`
- `HAL_I2C_Mem_Read_DMA()`
- `HAL_I2C_IsDeviceReady()`
- `HAL_I2C_EV_IRQHandler()`
- `HAL_I2C_ER_IRQHandler()`
- `HAL_I2C_MasterTxCpltCallback()`
- `HAL_I2C_MasterRxCpltCallback()`
- `HAL_I2C_SlaveTxCpltCallback()`
- `HAL_I2C_SlaveRxCpltCallback()`
- `HAL_I2C_MemTxCpltCallback()`
- `HAL_I2C_MemRxCpltCallback()`
- `HAL_I2C_ErrorCallback()`

31.3.4 Peripheral State and Errors functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- `HAL_I2C_GetState()`
- `HAL_I2C_GetError()`

31.3.5 HAL_I2C_Init

Function Name	<code>HAL_StatusTypeDef HAL_I2C_Init (I2C_HandleTypeDef * hi2c)</code>
Function Description	Initializes the I2C according to the specified parameters in the I2C_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • <code>hi2c</code>: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • HAL status

31.3.6 HAL_I2C_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_I2C_DeInit (I2C_HandleTypeDef * hi2c)</code>
Function Description	DeInitializes the I2C peripheral.
Parameters	<ul style="list-style-type: none"> • <code>hi2c</code>: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • HAL status

31.3.7 HAL_I2C_MspInit

Function Name	<code>void HAL_I2C_MspInit (I2C_HandleTypeDef * hi2c)</code>
Function Description	I2C MSP Init.
Parameters	<ul style="list-style-type: none"> • <code>hi2c</code>: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.8 HAL_I2C_MspDeInit

Function Name	void HAL_I2C_MspDelInit (I2C_HandleTypeDef * hi2c)
Function Description	I2C MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.9 HAL_I2C_Master_Transmit

Function Name	HAL_StatusTypeDef HAL_I2C_Master_Transmit (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmits in master mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

31.3.10 HAL_I2C_Master_Receive

Function Name	HAL_StatusTypeDef HAL_I2C_Master_Receive (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receives in master mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

31.3.11 HAL_I2C_Slave_Transmit

Function Name	HAL_StatusTypeDef HAL_I2C_Slave_Transmit (I2C_HandleTypeDef * hi2c, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmits in slave mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

31.3.12 HAL_I2C_Slave_Receive

Function Name	HAL_StatusTypeDef HAL_I2C_Slave_Receive (I2C_HandleTypeDef * hi2c, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receive in slave mode an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

31.3.13 HAL_I2C_Master_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_I2C_Master_Transmit_IT (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size)
Function Description	Transmit in master mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

31.3.14 HAL_I2C_Master_Receive_IT

Function Name	HAL_StatusTypeDef HAL_I2C_Master_Receive_IT (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint8_t * pData, uint16_t Size)
Function Description	Receive in master mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • DevAddress: Target device address • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

31.3.15 HAL_I2C_Slave_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_I2C_Slave_Transmit_IT (I2C_HandleTypeDef * hi2c, uint8_t * pData, uint16_t Size)
Function Description	Transmit in slave mode an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module

- **pData:** Pointer to data buffer
- **Size:** Amount of data to be sent
- HAL status

Return values

31.3.16 HAL_I2C_Slave_Receive_IT

Function Name

**HAL_StatusTypeDef HAL_I2C_Slave_Receive_IT
(I2C_HandleTypeDef * hi2c, uint8_t * pData, uint16_t Size)**

Function Description

Receive in slave mode an amount of data in no-blocking mode with Interrupt.

Parameters

- **hi2c:** pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
- **pData:** Pointer to data buffer
- **Size:** Amount of data to be sent

Return values

- HAL status

31.3.17 HAL_I2C_Master_Transmit_DMA

Function Name

**HAL_StatusTypeDef HAL_I2C_Master_Transmit_DMA
(I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint8_t *
pData, uint16_t Size)**

Function Description

Transmit in master mode an amount of data in no-blocking mode with DMA.

Parameters

- **hi2c:** pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
- **DevAddress:** Target device address
- **pData:** Pointer to data buffer
- **Size:** Amount of data to be sent

Return values

- HAL status

31.3.18 HAL_I2C_Master_Receive_DMA

Function Name

**HAL_StatusTypeDef HAL_I2C_Master_Receive_DMA
(I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint8_t *
pData, uint16_t Size)**

Function Description

Receive in master mode an amount of data in no-blocking mode with DMA.

Parameters

- **hi2c:** pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
- **DevAddress:** Target device address
- **pData:** Pointer to data buffer
- **Size:** Amount of data to be sent

Return values

- HAL status

31.3.19 HAL_I2C_Slave_Transmit_DMA

Function Name

**HAL_StatusTypeDef HAL_I2C_Slave_Transmit_DMA
(I2C_HandleTypeDef * hi2c, uint8_t * pData, uint16_t Size)**

Function Description	Transmit in slave mode an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

31.3.20 HAL_I2C_Slave_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_I2C_Slave_Receive_DMA(I2C_HandleTypeDef * hi2c, uint8_t * pData, uint16_t Size)
Function Description	Receive in slave mode an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

31.3.21 HAL_I2C_Mem_Write

Function Name	HAL_StatusTypeDef HAL_I2C_Mem_Write(I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Write an amount of data in blocking mode to a specific memory address.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • DevAddress: Target device address • MemAddress: Internal memory address • MemAddSize: Size of internal memory address • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

31.3.22 HAL_I2C_Mem_Read

Function Name	HAL_StatusTypeDef HAL_I2C_Mem_Read(I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Read an amount of data in blocking mode from a specific memory address.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module • DevAddress: Target device address

	<ul style="list-style-type: none"> MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

31.3.23 HAL_I2C_Mem_Write_IT

Function Name	<code>HAL_StatusTypeDef HAL_I2C_Mem_Write_IT (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)</code>
Function Description	Write an amount of data in no-blocking mode with Interrupt to a specific memory address.
Parameters	<ul style="list-style-type: none"> hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module DevAddress: Target device address MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status

31.3.24 HAL_I2C_Mem_Read_IT

Function Name	<code>HAL_StatusTypeDef HAL_I2C_Mem_Read_IT (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)</code>
Function Description	Read an amount of data in no-blocking mode with Interrupt from a specific memory address.
Parameters	<ul style="list-style-type: none"> hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module DevAddress: Target device address MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status

31.3.25 HAL_I2C_Mem_Write_DMA

Function Name	<code>HAL_StatusTypeDef HAL_I2C_Mem_Write_DMA (I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)</code>
Function Description	Write an amount of data in no-blocking mode with DMA to a specific memory address.

Parameters	<ul style="list-style-type: none"> hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module DevAddress: Target device address MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status

31.3.26 HAL_I2C_Mem_Read_DMA

Function Name	<code>HAL_StatusTypeDef HAL_I2C_Mem_Read_DMA(I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint16_t MemAddress, uint16_t MemAddSize, uint8_t * pData, uint16_t Size)</code>
Function Description	Reads an amount of data in no-blocking mode with DMA from a specific memory address.
Parameters	<ul style="list-style-type: none"> hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module DevAddress: Target device address MemAddress: Internal memory address MemAddSize: Size of internal memory address pData: Pointer to data buffer Size: Amount of data to be read
Return values	<ul style="list-style-type: none"> HAL status

31.3.27 HAL_I2C_IsDeviceReady

Function Name	<code>HAL_StatusTypeDef HAL_I2C_IsDeviceReady(I2C_HandleTypeDef * hi2c, uint16_t DevAddress, uint32_t Trials, uint32_t Timeout)</code>
Function Description	Checks if target device is ready for communication.
Parameters	<ul style="list-style-type: none"> hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module DevAddress: Target device address Trials: Number of trials Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status
Notes	This function is used with Memory devices

31.3.28 HAL_I2C_EV_IRQHandler

Function Name	<code>void HAL_I2C_EV_IRQHandler(I2C_HandleTypeDef * hi2c)</code>
Function Description	This function handles I2C event interrupt request.
Parameters	<ul style="list-style-type: none"> hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> HAL status

31.3.29 HAL_I2C_ER_IRQHandler

Function Name	void HAL_I2C_ER_IRQHandler (I2C_HandleTypeDef * hi2c)
Function Description	This function handles I2C error interrupt request.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • HAL status

31.3.30 HAL_I2C_MasterTxCpltCallback

Function Name	void HAL_I2C_MasterTxCpltCallback (I2C_HandleTypeDef * hi2c)
Function Description	Master Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.31 HAL_I2C_MasterRxCpltCallback

Function Name	void HAL_I2C_MasterRxCpltCallback (I2C_HandleTypeDef * hi2c)
Function Description	Master Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.32 HAL_I2C_SlaveTxCpltCallback

Function Name	void HAL_I2C_SlaveTxCpltCallback (I2C_HandleTypeDef * hi2c)
Function Description	Slave Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.33 HAL_I2C_SlaveRxCpltCallback

Function Name	void HAL_I2C_SlaveRxCpltCallback (I2C_HandleTypeDef * hi2c)
Function Description	Slave Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.34 HAL_I2C_MemTxCpltCallback

Function Name	void HAL_I2C_MemTxCpltCallback (I2C_HandleTypeDef * hi2c)
Function Description	Memory Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.35 HAL_I2C_MemRxCpltCallback

Function Name	void HAL_I2C_MemRxCpltCallback (I2C_HandleTypeDef * hi2c)
Function Description	Memory Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.36 HAL_I2C_ErrorCallback

Function Name	void HAL_I2C_ErrorCallback (I2C_HandleTypeDef * hi2c)
Function Description	I2C error callbacks.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • None

31.3.37 HAL_I2C_GetState

Function Name	HAL_I2C_StateTypeDef HAL_I2C_GetState (I2C_HandleTypeDef * hi2c)
Function Description	Returns the I2C state.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for I2C module
Return values	<ul style="list-style-type: none"> • HAL state

31.3.38 HAL_I2C_GetError

Function Name	uint32_t HAL_I2C_GetError (I2C_HandleTypeDef * hi2c)
Function Description	Return the I2C error code.
Parameters	<ul style="list-style-type: none"> • hi2c: : pointer to a I2C_HandleTypeDef structure that contains the configuration information for the specified I2C.
Return values	<ul style="list-style-type: none"> • I2C Error Code

31.4 I2C Firmware driver defines

31.4.1 I2C

I2C addressing mode

I2C_ADDRESSINGMODE_7BIT
I2C_ADDRESSINGMODE_10BIT

I2C dual addressing mode

I2C_DUALADDRESS_DISABLE
I2C_DUALADDRESS_ENABLE

I2C duty cycle in fast mode

I2C_DUTYCYCLE_2
I2C_DUTYCYCLE_16_9

I2C Error Code

HAL_I2C_ERROR_NONE	No error
HAL_I2C_ERROR_BERR	BERR error
HAL_I2C_ERROR_ARLO	ARLO error
HAL_I2C_ERROR_AF	AF error
HAL_I2C_ERROR_OVR	OVR error
HAL_I2C_ERROR_DMA	DMA transfer error
HAL_I2C_ERROR_TIMEOUT	Timeout Error

I2C Exported Macros

__HAL_I2C_RESET_HANDLE_STATE **Description:**

- Reset I2C handle state.

Parameters:

- __HANDLE__: specifies the I2C Handle. This parameter can be I2C where x: 1, 2, or 3 to select the I2C peripheral.

Return value:

- None

__HAL_I2C_ENABLE_IT **Description:**

- Enable or disable the specified I2C interrupts.

Parameters:

- __HANDLE__: specifies the I2C Handle. This parameter can be I2C where x: 1, 2, or 3 to select the I2C peripheral.
- __INTERRUPT__: specifies the interrupt source to enable or disable. This parameter can be one of the following values:
 - I2C_IT_BUF: Buffer interrupt enable
 - I2C_IT_EVT: Event interrupt enable
 - I2C_IT_ERR: Error interrupt enable

Return value:

- None

`__HAL_I2C_DISABLE_IT`
`__HAL_I2C_GET_IT_SOURCE`

Description:

- Checks if the specified I2C interrupt source is enabled or disabled.

Parameters:

- `__HANDLE__`: specifies the I2C Handle. This parameter can be I2Cx where x: 1, 2, or 3 to select the I2C peripheral.
- `__INTERRUPT__`: specifies the I2C interrupt source to check. This parameter can be one of the following values:
 - `I2C_IT_BUF`: Buffer interrupt enable
 - `I2C_IT_EVT`: Event interrupt enable
 - `I2C_IT_ERR`: Error interrupt enable

Return value:

- The new state of `__INTERRUPT__` (TRUE or FALSE).

`__HAL_I2C_GET_FLAG`

Description:

- Checks whether the specified I2C flag is set or not.

Parameters:

- `__HANDLE__`: specifies the I2C Handle. This parameter can be I2Cx where x: 1, 2, or 3 to select the I2C peripheral.
- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `I2C_FLAG_SMBALERT`: SMBus Alert flag
 - `I2C_FLAG_TIMEOUT`: Timeout or Tlow error flag
 - `I2C_FLAG_PECERR`: PEC error in reception flag
 - `I2C_FLAG_OVR`: Overrun/Underrun flag
 - `I2C_FLAG_AF`: Acknowledge failure flag
 - `I2C_FLAG_ARLO`: Arbitration lost flag
 - `I2C_FLAG_BERR`: Bus error flag
 - `I2C_FLAG_TXE`: Data register empty flag
 - `I2C_FLAG_RXNE`: Data register not empty flag
 - `I2C_FLAG_STOPF`: Stop detection flag
 - `I2C_FLAG_ADD10`: 10-bit header sent flag
 - `I2C_FLAG_BTF`: Byte transfer finished flag
 - `I2C_FLAG_ADDR`: Address sent flag

- Address matched flag
- I2C_FLAG_SB: Start bit flag
- I2C_FLAG_DUALF: Dual flag
- I2C_FLAG_SMBHOST: SMBus host header
- I2C_FLAG_SMBDEFAULT: SMBus default header
- I2C_FLAG_GENCALL: General call header flag
- I2C_FLAG_TRA: Transmitter/Receiver flag
- I2C_FLAG_BUSY: Bus busy flag
- I2C_FLAG_MSL: Master/Slave flag

Return value:

- The new state of __FLAG__ (TRUE or FALSE).

[__HAL_I2C_CLEAR_FLAG](#)**Description:**

- Clears the I2C pending flags which are cleared by writing 0 in a specific bit.

Parameters:

- __HANDLE__: specifies the I2C Handle. This parameter can be I2C where x: 1, 2, or 3 to select the I2C peripheral.
- __FLAG__: specifies the flag to clear. This parameter can be any combination of the following values:
 - I2C_FLAG_SMBALERT: SMBus Alert flag
 - I2C_FLAG_TIMEOUT: Timeout or Tlow error flag
 - I2C_FLAG_PECERR: PEC error in reception flag
 - I2C_FLAG_OVR: Overrun/Underrun flag (Slave mode)
 - I2C_FLAG_AF: Acknowledge failure flag
 - I2C_FLAG_ARLO: Arbitration lost flag (Master mode)
 - I2C_FLAG_BERR: Bus error flag

Return value:

- None

[__HAL_I2C_CLEAR_ADDRFLAG](#)**Description:**

- Clears the I2C ADDR pending flag.

Parameters:

- __HANDLE__: specifies the I2C Handle. This parameter can be I2C where x: 1, 2, or 3 to select the I2C peripheral.

Return value:

- None

`__HAL_I2C_CLEAR_STOPFLAG`

Description:

- Clears the I2C STOPF pending flag.

Parameters:

- `__HANDLE__`: specifies the I2C Handle.
This parameter can be I2C where x: 1, 2, or 3 to select the I2C peripheral.

Return value:

- None

`__HAL_I2C_ENABLE`

`__HAL_I2C_DISABLE`

I2C Flag definition

`I2C_FLAG_SMBALERT`

`I2C_FLAG_TIMEOUT`

`I2C_FLAG_PECERR`

`I2C_FLAG_OVR`

`I2C_FLAG_AF`

`I2C_FLAG_ARLO`

`I2C_FLAG_BERR`

`I2C_FLAG_TXE`

`I2C_FLAG_RXNE`

`I2C_FLAG_STOPF`

`I2C_FLAG_ADD10`

`I2C_FLAG_BTF`

`I2C_FLAG_ADDR`

`I2C_FLAG_SB`

`I2C_FLAG_DUALF`

`I2C_FLAG_SMBHOST`

`I2C_FLAG_SMBDEFAULT`

`I2C_FLAG_GENCALL`

`I2C_FLAG_TRA`

`I2C_FLAG_BUSY`

`I2C_FLAG_MSL`

I2C general call addressing mode

`I2C_GENERALCALL_DISABLE`

`I2C_GENERALCALL_ENABLE`

I2C Interrupt configuration definition

I2C_IT_BUF
I2C_IT_EVT
I2C_IT_ERR

I2C Private macros to check input parameters

IS_I2C_DUTY_CYCLE
IS_I2C_ADDRESSING_MODE
IS_I2C_DUAL_ADDRESS
IS_I2C_GENERAL_CALL
IS_I2C_NO_STRETCH
IS_I2C_MEMADD_SIZE
IS_I2C_CLOCK_SPEED
IS_I2C_OWN_ADDRESS1
IS_I2C_OWN_ADDRESS2

I2C Memory Address Size

I2C_MEMADD_SIZE_8BIT
I2C_MEMADD_SIZE_16BIT

I2C nostretch mode

I2C_NOSTRETCH_DISABLE
I2C_NOSTRETCH_ENABLE

I2C Private Constants

I2C_TIMEOUT_FLAG
I2C_TIMEOUT_ADDR_SLAVE
I2C_TIMEOUT_BUSY_FLAG
I2C_FLAG_MASK

I2C Private Macros

I2C_FREQRANGE
I2C_RISE_TIME
I2C_SPEED_STANDARD
I2C_SPEED_FAST
I2C_SPEED
I2C_7BIT_ADD_WRITE
I2C_7BIT_ADD_READ
I2C_10BIT_ADDRESS
I2C_10BIT_HEADER_WRITE
I2C_10BIT_HEADER_READ

I2C_MEM_ADD_MSB

I2C_MEM_ADD_LSB

32 HAL I2C Extension Driver

32.1 HAL I2C Extension Driver

32.2 I2CEx Firmware driver API description

32.2.1 I2C peripheral extension features

Comparing to other previous devices, the I2C interface for STM32F427xx/437xx/429xx/439xx devices contains the following additional features :

- Possibility to disable or enable Analog Noise Filter
- Use of a configured Digital Noise Filter

32.2.2 How to use this driver

This driver provides functions to configure Noise Filter

1. Configure I2C Analog noise filter using the function `HAL_I2C_ConfigAnalogFilter()`
2. Configure I2C Digital noise filter using the function `HAL_I2C_ConfigDigitalFilter()`

32.2.3 Extension features functions

This section provides functions allowing to:

- Configure Noise Filters

This section contains the following APIs:

- `HAL_I2CEx_ConfigAnalogFilter\(\)`
- `HAL_I2CEx_ConfigDigitalFilter\(\)`

32.2.4 HAL_I2CEx_ConfigAnalogFilter

Function Name	<code>HAL_StatusTypeDef HAL_I2CEx_ConfigAnalogFilter(I2C_HandleTypeDef * hi2c, uint32_t AnalogFilter)</code>
Function Description	Configures I2C Analog noise filter.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for the specified I2Cx peripheral. • AnalogFilter: new state of the Analog filter.
Return values	<ul style="list-style-type: none"> • HAL status

32.2.5 HAL_I2CEx_ConfigDigitalFilter

Function Name	<code>HAL_StatusTypeDef HAL_I2CEx_ConfigDigitalFilter(I2C_HandleTypeDef * hi2c, uint32_t DigitalFilter)</code>
Function Description	Configures I2C Digital noise filter.
Parameters	<ul style="list-style-type: none"> • hi2c: pointer to a I2C_HandleTypeDef structure that contains the configuration information for the specified I2Cx peripheral. • DigitalFilter: Coefficient of digital noise filter between 0x00 and 0x0F.
Return values	<ul style="list-style-type: none"> • HAL status

32.3 I2CEx Firmware driver defines

32.3.1 I2CEx

I2C Analog Filter

I2C_ANALOGFILTER_ENABLE

I2C_ANALOGFILTER_DISABLE

I2C Private Macros

IS_I2C_ANALOG_FILTER

IS_I2C_DIGITAL_FILTER

33 HAL I2S Generic Driver

33.1 HAL I2S Generic Driver

33.2 I2S Firmware driver registers structures

33.2.1 I2S_InitTypeDef

Data Fields

- *uint32_t Mode*
- *uint32_t Standard*
- *uint32_t DataFormat*
- *uint32_t MCLKOutput*
- *uint32_t AudioFreq*
- *uint32_t CPOL*
- *uint32_t ClockSource*
- *uint32_t FullDuplexMode*

Field Documentation

- ***uint32_t I2S_InitTypeDef::Mode***
Specifies the I2S operating mode. This parameter can be a value of [*I2S_Mode*](#)
- ***uint32_t I2S_InitTypeDef::Standard***
Specifies the standard used for the I2S communication. This parameter can be a value of [*I2S_Standard*](#)
- ***uint32_t I2S_InitTypeDef::DataFormat***
Specifies the data format for the I2S communication. This parameter can be a value of [*I2S_Data_Format*](#)
- ***uint32_t I2S_InitTypeDef::MCLKOutput***
Specifies whether the I2S MCLK output is enabled or not. This parameter can be a value of [*I2S_MCLK_Output*](#)
- ***uint32_t I2S_InitTypeDef::AudioFreq***
Specifies the frequency selected for the I2S communication. This parameter can be a value of [*I2S_Audio_Frequency*](#)
- ***uint32_t I2S_InitTypeDef::CPOL***
Specifies the idle state of the I2S clock. This parameter can be a value of [*I2S_Clock_Polarity*](#)
- ***uint32_t I2S_InitTypeDef::ClockSource***
Specifies the I2S Clock Source. This parameter can be a value of [*I2S_Clock_Source*](#)
- ***uint32_t I2S_InitTypeDef::FullDuplexMode***
Specifies the I2S FullDuplex mode. This parameter can be a value of [*I2S_FullDuplex_Mode*](#)

33.2.2 I2S_HandleTypeDef

Data Fields

-
- *SPI_TypeDef * Instance*
 - *I2S_InitTypeDef Init*
 - *uint16_t * pTxBuffPtr*
 - *_IO uint16_t TxXferSize*
 - *_IO uint16_t TxXferCount*
 - *uint16_t * pRxBuffPtr*
 - *_IO uint16_t RxXferSize*
 - *_IO uint16_t RxXferCount*
 - *DMA_HandleTypeDef * hdmatx*
 - *DMA_HandleTypeDef * hdmarx*
 - *_IO HAL_LockTypeDef Lock*
 - *_IO HAL_I2S_StateTypeDef State*
 - *_IO uint32_t ErrorCode*

Field Documentation

- *SPI_TypeDef* I2S_HandleTypeDef::Instance*
- *I2S_InitTypeDef I2S_HandleTypeDef::Init*
- *uint16_t* I2S_HandleTypeDef::pTxBuffPtr*
- *_IO uint16_t I2S_HandleTypeDef::TxXferSize*
- *_IO uint16_t I2S_HandleTypeDef::TxXferCount*
- *uint16_t* I2S_HandleTypeDef::pRxBuffPtr*
- *_IO uint16_t I2S_HandleTypeDef::RxXferSize*
- *_IO uint16_t I2S_HandleTypeDef::RxXferCount*
- *DMA_HandleTypeDef* I2S_HandleTypeDef::hdmatx*
- *DMA_HandleTypeDef* I2S_HandleTypeDef::hdmarx*
- *_IO HAL_LockTypeDef I2S_HandleTypeDef::Lock*
- *_IO HAL_I2S_StateTypeDef I2S_HandleTypeDef::State*
- *_IO uint32_t I2S_HandleTypeDef::ErrorCode*

33.3 I2S Firmware driver API description

33.3.1 How to use this driver

The I2S HAL driver can be used as follow:

1. Declare a I2S_HandleTypeDef handle structure.
2. Initialize the I2S low level resources by implement the HAL_I2S_MspInit() API:
 - a. Enable the SPIx interface clock.
 - b. I2S pins configuration:
 - Enable the clock for the I2S GPIOs.
 - Configure these I2S pins as alternate function pull-up.
 - c. NVIC configuration if you need to use interrupt process (HAL_I2S_Transmit_IT() and HAL_I2S_Receive_IT() APIs).
 - Configure the I2Sx interrupt priority.
 - Enable the NVIC I2S IRQ handle.
 - d. DMA Configuration if you need to use DMA process (HAL_I2S_Transmit_DMA() and HAL_I2S_Receive_DMA() APIs):
 - Declare a DMA handle structure for the Tx/Rx stream.
 - Enable the DMAx interface clock.
 - Configure the declared DMA handle structure with the required Tx/Rx parameters.

- Configure the DMA Tx/Rx Stream.
 - Associate the initialized DMA handle to the I2S DMA Tx/Rx handle.
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx/Rx Stream.
3. Program the Mode, Standard, Data Format, MCLK Output, Audio frequency and Polarity using HAL_I2S_Init() function. The specific I2S interrupts (Transmission complete interrupt, RXNE interrupt and Error Interrupts) will be managed using the macros __I2S_ENABLE_IT() and __I2S_DISABLE_IT() inside the transmit and receive process. Make sure that either: I2S PLL is configured or External clock source is configured after setting correctly the define constant EXTERNAL_CLOCK_VALUE in the stm32f4xx_hal_conf.h file.
4. Three operation modes are available within this driver :

Polling mode IO operation

- Send an amount of data in blocking mode using HAL_I2S_Transmit()
- Receive an amount of data in blocking mode using HAL_I2S_Receive()

Interrupt mode IO operation

- Send an amount of data in non blocking mode using HAL_I2S_Transmit_IT()
- At transmission end of half transfer HAL_I2S_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxHalfCpltCallback
- At transmission end of transfer HAL_I2S_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxCpltCallback
- Receive an amount of data in non blocking mode using HAL_I2S_Receive_IT()
- At reception end of half transfer HAL_I2S_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxHalfCpltCallback
- At reception end of transfer HAL_I2S_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxCpltCallback
- In case of transfer Error, HAL_I2S_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2S_ErrorCallback

DMA mode IO operation

- Send an amount of data in non blocking mode (DMA) using HAL_I2S_Transmit_DMA()
- At transmission end of half transfer HAL_I2S_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxHalfCpltCallback
- At transmission end of transfer HAL_I2S_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxCpltCallback
- Receive an amount of data in non blocking mode (DMA) using HAL_I2S_Receive_DMA()
- At reception end of half transfer HAL_I2S_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxHalfCpltCallback
- At reception end of transfer HAL_I2S_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxCpltCallback

- In case of transfer Error, HAL_I2S_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2S_ErrorCallback
- Pause the DMA Transfer using HAL_I2S_DMAPause()
- Resume the DMA Transfer using HAL_I2S_DMAResume()
- Stop the DMA Transfer using HAL_I2S_DMAStop()

I2S HAL driver macros list

Below the list of most used macros in USART HAL driver.

- __HAL_I2S_ENABLE: Enable the specified SPI peripheral (in I2S mode)
- __HAL_I2S_DISABLE: Disable the specified SPI peripheral (in I2S mode)
- __HAL_I2S_ENABLE_IT : Enable the specified I2S interrupts
- __HAL_I2S_DISABLE_IT : Disable the specified I2S interrupts
- __HAL_I2S_GET_FLAG: Check whether the specified I2S flag is set or not



You can refer to the I2S HAL driver header file for more useful macros

33.3.2

Initialization and de-initialization functions

This subsection provides a set of functions allowing to initialize and de-initialize the I2Sx peripheral in simplex mode:

- User must Implement HAL_I2S_MspInit() function in which he configures all related peripherals resources (CLOCK, GPIO, DMA, IT and NVIC).
- Call the function HAL_I2S_Init() to configure the selected device with the selected configuration:
 - Mode
 - Standard
 - Data Format
 - MCLK Output
 - Audio frequency
 - Polarity
- Call the function HAL_I2S_DelInit() to restore the default configuration of the selected I2Sx peripheral.

This section contains the following APIs:

- [**HAL_I2S_Init\(\)**](#)
- [**HAL_I2S_DelInit\(\)**](#)
- [**HAL_I2S_MspInit\(\)**](#)
- [**HAL_I2S_MspDelInit\(\)**](#)

33.3.3

IO operation functions

This subsection provides a set of functions allowing to manage the I2S data transfers.

1. There are two modes of transfer:
 - Blocking mode : The communication is performed in the polling mode. The status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode : The communication is performed using Interrupts or DMA. These functions return the status of the transfer startup. The end of the data

processing will be indicated through the dedicated I2S IRQ when using Interrupt mode or the DMA IRQ when using DMA mode.

2. Blocking mode functions are :
 - `HAL_I2S_Transmit()`
 - `HAL_I2S_Receive()`
3. No-Blocking mode functions with Interrupt are :
 - `HAL_I2S_Transmit_IT()`
 - `HAL_I2S_Receive_IT()`
4. No-Blocking mode functions with DMA are :
 - `HAL_I2S_Transmit_DMA()`
 - `HAL_I2S_Receive_DMA()`
5. A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - `HAL_I2S_TxCpltCallback()`
 - `HAL_I2S_RxCpltCallback()`
 - `HAL_I2S_ErrorCallback()`

This section contains the following APIs:

- `HAL_I2S_Transmit()`
- `HAL_I2S_Receive()`
- `HAL_I2S_Transmit_IT()`
- `HAL_I2S_Receive_IT()`
- `HAL_I2S_Transmit_DMA()`
- `HAL_I2S_Receive_DMA()`
- `HAL_I2S_DMAPause()`
- `HAL_I2S_DMAResume()`
- `HAL_I2S_DMAStop()`
- `HAL_I2S_IRQHandler()`
- `HAL_I2S_TxHalfCpltCallback()`
- `HAL_I2S_TxCpltCallback()`
- `HAL_I2S_RxHalfCpltCallback()`
- `HAL_I2S_RxCpltCallback()`
- `HAL_I2S_ErrorCallback()`
- `HAL_I2S_GetState()`
- `HAL_I2S_GetError()`

33.3.4 Peripheral State and Errors functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- `HAL_I2S_GetState()`
- `HAL_I2S_GetError()`

33.3.5 HAL_I2S_Init

Function Name	<code>HAL_StatusTypeDef HAL_I2S_Init (I2S_HandleTypeDef * hi2s)</code>
Function Description	Initializes the I2S according to the specified parameters in the <code>I2S_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a <code>I2S_HandleTypeDef</code> structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

33.3.6 HAL_I2S_DelInit

Function Name	HAL_StatusTypeDef HAL_I2S_DelInit (I2S_HandleTypeDef * hi2s)
Function Description	DeInitializes the I2S peripheral.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

33.3.7 HAL_I2S_MspInit

Function Name	void HAL_I2S_MspInit (I2S_HandleTypeDef * hi2s)
Function Description	I2S MSP Init.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • None

33.3.8 HAL_I2S_MspDelInit

Function Name	void HAL_I2S_MspDelInit (I2S_HandleTypeDef * hi2s)
Function Description	I2S MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • None

33.3.9 HAL_I2S_Transmit

Function Name	HAL_StatusTypeDef HAL_I2S_Transmit (I2S_HandleTypeDef * hi2s, uint16_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmit an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pData: a 16-bit pointer to data buffer. • Size: number of data sample to be sent: • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. • The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

33.3.10 HAL_I2S_Receive

Function Name	HAL_StatusTypeDef HAL_I2S_Receive(I2S_HandleTypeDef *hi2s, uint16_t *pData, uint16_t Size, uint32_t Timeout)
Function Description	Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pData: a 16-bit pointer to data buffer. • Size: number of data sample to be sent: • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. • The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming). • In I2S Master Receiver mode, just after enabling the peripheral the clock will be generate in continuous way and as the I2S is not disabled at the end of the I2S transaction.

33.3.11 HAL_I2S_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_I2S_Transmit_IT(I2S_HandleTypeDef *hi2s, uint16_t *pData, uint16_t Size)
Function Description	Transmit an amount of data in non-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pData: a 16-bit pointer to data buffer. • Size: number of data sample to be sent:
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. • The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

33.3.12 HAL_I2S_Receive_IT

Function Name	HAL_StatusTypeDef HAL_I2S_Receive_IT(I2S_HandleTypeDef *hi2s, uint16_t *pData, uint16_t Size)
Function Description	Receive an amount of data in non-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module

- **pData:** a 16-bit pointer to the Receive data buffer.
 - **Size:** number of data sample to be sent:
- Return values
- HAL status
- Notes
- When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length.
 - The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).
 - It is recommended to use DMA for the I2S receiver to avoid de-synchronisation between Master and Slave otherwise the I2S interrupt should be optimized.

33.3.13 HAL_I2S_Transmit_DMA

- | | |
|----------------------|---|
| Function Name | HAL_StatusTypeDef HAL_I2S_Transmit_DMA
(I2S_HandleTypeDef * hi2s, uint16_t * pData, uint16_t Size) |
| Function Description | Transmit an amount of data in non-blocking mode with DMA. |
| Parameters | <ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pData: a 16-bit pointer to the Transmit data buffer. • Size: number of data sample to be sent: |
| Return values | <ul style="list-style-type: none"> • HAL status |
| Notes | <ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. • The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming). |

33.3.14 HAL_I2S_Receive_DMA

- | | |
|----------------------|--|
| Function Name | HAL_StatusTypeDef HAL_I2S_Receive_DMA
(I2S_HandleTypeDef * hi2s, uint16_t * pData, uint16_t Size) |
| Function Description | Receive an amount of data in non-blocking mode with DMA. |
| Parameters | <ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pData: a 16-bit pointer to the Receive data buffer. • Size: number of data sample to be sent: |
| Return values | <ul style="list-style-type: none"> • HAL status |
| Notes | <ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the |

transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length.

- The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

33.3.15 HAL_I2S_DMAPause

Function Name	HAL_StatusTypeDef HAL_I2S_DMADelayed (I2S_HandleTypeDef * hi2s)
Function Description	Pauses the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

33.3.16 HAL_I2S_DMAResume

Function Name	HAL_StatusTypeDef HAL_I2S_DMAResume (I2S_HandleTypeDef * hi2s)
Function Description	Resumes the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

33.3.17 HAL_I2S_DMAShort

Function Name	HAL_StatusTypeDef HAL_I2S_DMAShort (I2S_HandleTypeDef * hi2s)
Function Description	Resumes the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

33.3.18 HAL_I2S_IRQHandler

Function Name	void HAL_I2S_IRQHandler (I2S_HandleTypeDef * hi2s)
Function Description	This function handles I2S interrupt request.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • None

33.3.19 HAL_I2S_TxHalfCpltCallback

Function Name	void HAL_I2S_TxHalfCpltCallback (I2S_HandleTypeDef * hi2s)
Function Description	Tx Transfer Half completed callbacks.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains

the configuration information for I2S module

Return values	<ul style="list-style-type: none"> None
---------------	--

33.3.20 HAL_I2S_TxCpltCallback

Function Name	void HAL_I2S_TxCpltCallback (I2S_HandleTypeDef * hi2s)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> None

33.3.21 HAL_I2S_RxHalfCpltCallback

Function Name	void HAL_I2S_RxHalfCpltCallback (I2S_HandleTypeDef * hi2s)
Function Description	Rx Transfer half completed callbacks.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> None

33.3.22 HAL_I2S_RxCpltCallback

Function Name	void HAL_I2S_RxCpltCallback (I2S_HandleTypeDef * hi2s)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> None

33.3.23 HAL_I2S_ErrorCallback

Function Name	void HAL_I2S_ErrorCallback (I2S_HandleTypeDef * hi2s)
Function Description	I2S error callbacks.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> None

33.3.24 HAL_I2S_GetState

Function Name	HAL_I2S_StateTypeDef HAL_I2S_GetState (I2S_HandleTypeDef * hi2s)
Function Description	Return the I2S state.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> HAL state

33.3.25 HAL_I2S_GetError

Function Name	uint32_t HAL_I2S_GetError (I2S_HandleTypeDef * hi2s)
Function Description	Return the I2S error code.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • I2S Error Code

33.3.26 HAL_I2S_GetState

Function Name	HAL_I2S_StateTypeDef HAL_I2S_GetState (I2S_HandleTypeDef * hi2s)
Function Description	Return the I2S state.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL state

33.3.27 HAL_I2S_GetError

Function Name	uint32_t HAL_I2S_GetError (I2S_HandleTypeDef * hi2s)
Function Description	Return the I2S error code.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • I2S Error Code

33.4 I2S Firmware driver defines

33.4.1 I2S

I2S Audio Frequency

I2S_AUDIOFREQ_192K
 I2S_AUDIOFREQ_96K
 I2S_AUDIOFREQ_48K
 I2S_AUDIOFREQ_44K
 I2S_AUDIOFREQ_32K
 I2S_AUDIOFREQ_22K
 I2S_AUDIOFREQ_16K
 I2S_AUDIOFREQ_11K
 I2S_AUDIOFREQ_8K
 I2S_AUDIOFREQ_DEFAULT

I2S Clock Polarity

I2S_CPOL_LOW
 I2S_CPOL_HIGH

I2S Clock Source

`I2S_CLOCK_PLL``I2S_CLOCK_EXTERNAL`***I2S Data Format***`I2S_DATAFORMAT_16B``I2S_DATAFORMAT_16B_EXTENDED``I2S_DATAFORMAT_24B``I2S_DATAFORMAT_32B`***I2S Error Code***`HAL_I2S_ERROR_NONE` No error`HAL_I2S_ERROR_UDR` I2S Underrun error`HAL_I2S_ERROR_OVR` I2S Overrun error`HAL_I2SEX_ERROR_UDR` I2S extended Underrun error`HAL_I2SEX_ERROR_OVR` I2S extended Overrun error`HAL_I2S_ERROR_FRE` I2S Frame format error`HAL_I2S_ERROR_DMA` DMA transfer error***I2S Exported Macros***`_HAL_I2S_RESET_HANDLE_STATE` **Description:**

- Reset I2S handle state.

Parameters:

- `_HANDLE_`: specifies the I2S Handle.

Return value:

- None

`_HAL_I2S_ENABLE` **Description:**

- Enable or disable the specified SPI peripheral (in I2S mode).

Parameters:

- `_HANDLE_`: specifies the I2S Handle.

Return value:

- None

`_HAL_I2S_DISABLE` **Description:**`_HAL_I2S_ENABLE_IT` **Description:****Description:**

- Enable or disable the specified I2S interrupts.

Parameters:

- `_HANDLE_`: specifies the I2S Handle.
- `_INTERRUPT_`: specifies the interrupt source to enable or disable. This parameter can be one of the following values:

- I2S_IT_TXE: Tx buffer empty interrupt enable
- I2S_IT_RXNE: RX buffer not empty interrupt enable
- I2S_IT_ERR: Error interrupt enable

Return value:

- None

`_HAL_I2S_DISABLE_IT`
`_HAL_I2S_GET_IT_SOURCE`

Description:

- Checks if the specified I2S interrupt source is enabled or disabled.

Parameters:

- `_HANDLE_`: specifies the I2S Handle. This parameter can be I2S where x: 1, 2, or 3 to select the I2S peripheral.
- `_INTERRUPT_`: specifies the I2S interrupt source to check. This parameter can be one of the following values:
 - I2S_IT_TXE: Tx buffer empty interrupt enable
 - I2S_IT_RXNE: RX buffer not empty interrupt enable
 - I2S_IT_ERR: Error interrupt enable

Return value:

- The: new state of `_IT_` (TRUE or FALSE).

`_HAL_I2S_GET_FLAG`

Description:

- Checks whether the specified I2S flag is set or not.

Parameters:

- `_HANDLE_`: specifies the I2S Handle.
- `_FLAG_`: specifies the flag to check. This parameter can be one of the following values:
 - I2S_FLAG_RXNE: Receive buffer not empty flag
 - I2S_FLAG_TXE: Transmit buffer empty flag
 - I2S_FLAG_UDR: Underrun flag
 - I2S_FLAG_OVR: Overrun flag
 - I2S_FLAG_FRE: Frame error flag
 - I2S_FLAG_CHSIDE: Channel Side flag
 - I2S_FLAG_BSY: Busy flag

Return value:

- The: new state of `_FLAG_` (TRUE or FALSE).

`__HAL_I2S_CLEAR_OVRFLAG`**Description:**

- Clears the I2S OVR pending flag.

Parameters:

- `__HANDLE__`: specifies the I2S Handle.

Return value:

- None

`__HAL_I2S_CLEAR_UDRFLAG`**Description:**

- Clears the I2S UDR pending flag.

Parameters:

- `__HANDLE__`: specifies the I2S Handle.

Return value:

- None

I2S Flags Definition`I2S_FLAG_TXE``I2S_FLAG_RXNE``I2S_FLAG_UDR``I2S_FLAG_OVR``I2S_FLAG_FRE``I2S_FLAG_CHSIDE``I2S_FLAG_BSY`***I2S FullDuplex Mode***`I2S_FULLDUPLEXMODE_DISABLE``I2S_FULLDUPLEXMODE_ENABLE`***I2S Interrupts Definition***`I2S_IT_TXE``I2S_IT_RXNE``I2S_IT_ERR`***I2S Mclk Output***`I2S_MCLKOUTPUT_ENABLE``I2S_MCLKOUTPUT_DISABLE`***I2S Mode***`I2S_MODE_SLAVE_TX``I2S_MODE_SLAVE_RX``I2S_MODE_MASTER_TX``I2S_MODE_MASTER_RX`***I2S Private Macros***

IS_I2S_MODE
IS_I2S_STANDARD
IS_I2S_DATA_FORMAT
IS_I2S_MCLK_OUTPUT
IS_I2S_AUDIO_FREQ
IS_I2S_FULLDUPLEX_MODE
IS_I2S_CPOL
I2S Standard
I2S_STANDARD_PHILIPS
I2S_STANDARD_MSB
I2S_STANDARD_LSB
I2S_STANDARD_PCM_SHORT
I2S_STANDARD_PCM_LONG

34 HAL I2S Extension Driver

34.1 HAL I2S Extension Driver

34.2 I2SEEx Firmware driver API description

34.2.1 I2S Extension features

1. In I2S full duplex mode, each SPI peripheral is able to manage sending and receiving data simultaneously using two data lines. Each SPI peripheral has an extended block called I2Sxext (i.e I2S2ext for SPI2 and I2S3ext for SPI3).
2. The extension block is not a full SPI IP, it is used only as I2S slave to implement full duplex mode. The extension block uses the same clock sources as its master.
3. Both I2Sx and I2Sx_ext can be configured as transmitters or receivers.



Only I2Sx can deliver SCK and WS to I2Sx_ext in full duplex mode, where I2Sx can be I2S2 or I2S3.

34.2.2 How to use this driver

Three operation modes are available within this driver :

Polling mode IO operation

- Send and receive in the same time an amount of data in blocking mode using HAL_I2S_TransmitReceive()

Interrupt mode IO operation

- Send and receive in the same time an amount of data in non blocking mode using HAL_I2S_TransmitReceive_IT()
- At transmission end of half transfer HAL_I2S_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxHalfCpltCallback
- At transmission end of transfer HAL_I2S_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxCpltCallback
- At reception end of half transfer HAL_I2S_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxHalfCpltCallback
- At reception end of transfer HAL_I2S_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxCpltCallback
- In case of transfer Error, HAL_I2S_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2S_ErrorCallback

DMA mode IO operation

- Send and receive an amount of data in non blocking mode (DMA) using HAL_I2S_TransmitReceive_DMA()
- At transmission end of half transfer HAL_I2S_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxHalfCpltCallback
- At transmission end of transfer HAL_I2S_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_TxCpltCallback
- At reception end of half transfer HAL_I2S_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxHalfCpltCallback
- At reception end of transfer HAL_I2S_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_I2S_RxCpltCallback
- In case of transfer Error, HAL_I2S_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_I2S_ErrorCallback
- Pause the DMA Transfer using HAL_I2S_DMAPause()
- Resume the DMA Transfer using HAL_I2S_DMAResume()
- Stop the DMA Transfer using HAL_I2S_DMAStop()

34.2.3

Extension features Functions

This subsection provides a set of functions allowing to manage the I2S data transfers.

1. There are two modes of transfer:
 - Blocking mode : The communication is performed in the polling mode. The status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode : The communication is performed using Interrupts or DMA. These functions return the status of the transfer startup. The end of the data processing will be indicated through the dedicated I2S IRQ when using Interrupt mode or the DMA IRQ when using DMA mode.
2. Blocking mode functions are :
 - HAL_I2S_TransmitReceive()
3. No-Blocking mode functions with Interrupt are :
 - HAL_I2S_TransmitReceive_IT()
4. No-Blocking mode functions with DMA are :
 - HAL_I2S_TransmitReceive_DMA()
5. A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - HAL_I2S_TxCpltCallback()
 - HAL_I2S_RxCpltCallback()
 - HAL_I2S_ErrorCallback()

This section contains the following APIs:

- [***HAL_I2S_Init\(\)***](#)
- [***HAL_I2SEx_TransmitReceive\(\)***](#)
- [***HAL_I2SEx_TransmitReceive_IT\(\)***](#)
- [***HAL_I2SEx_TransmitReceive_DMA\(\)***](#)
- [***HAL_I2S_DMAPause\(\)***](#)
- [***HAL_I2S_DMAResume\(\)***](#)
- [***HAL_I2S_DMAStop\(\)***](#)
- [***HAL_I2S_IRQHandler\(\)***](#)

34.2.4

HAL_I2S_Init



Function Name	HAL_StatusTypeDef HAL_I2S_Init (I2S_HandleTypeDef * hi2s)
Function Description	Initializes the I2S according to the specified parameters in the I2S_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

34.2.5 HAL_I2SEEx_TransmitReceive

Function Name	HAL_StatusTypeDef HAL_I2SEEx_TransmitReceive (I2S_HandleTypeDef * hi2s, uint16_t * pTxData, uint16_t * pRxData, uint16_t Size, uint32_t Timeout)
Function Description	Full-Duplex Transmit/Receive data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pTxData: a 16-bit pointer to the Transmit data buffer. • pRxData: a 16-bit pointer to the Receive data buffer. • Size: number of data sample to be sent: • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. • The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

34.2.6 HAL_I2SEEx_TransmitReceive_IT

Function Name	HAL_StatusTypeDef HAL_I2SEEx_TransmitReceive_IT (I2S_HandleTypeDef * hi2s, uint16_t * pTxData, uint16_t * pRxData, uint16_t Size)
Function Description	Full-Duplex Transmit/Receive data in non-blocking mode using Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pTxData: a 16-bit pointer to the Transmit data buffer. • pRxData: a 16-bit pointer to the Receive data buffer. • Size: number of data sample to be sent:
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length.

- The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

34.2.7 HAL_I2SEx_TransmitReceive_DMA

Function Name	HAL_StatusTypeDef HAL_I2SEx_TransmitReceive_DMA (I2S_HandleTypeDef * hi2s, uint16_t * pTxData, uint16_t * pRxData, uint16_t Size)
Function Description	Full-Duplex Transmit/Receive data in non-blocking mode using DMA.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module pTxData: a 16-bit pointer to the Transmit data buffer. pRxData: a 16-bit pointer to the Receive data buffer. Size: number of data sample to be sent:
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

34.2.8 HAL_I2S_DMAPause

Function Name	HAL_StatusTypeDef HAL_I2S_DM_PAUSE (I2S_HandleTypeDef * hi2s)
Function Description	Pauses the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> HAL status

34.2.9 HAL_I2S_DMAResume

Function Name	HAL_StatusTypeDef HAL_I2S_DMAResume (I2S_HandleTypeDef * hi2s)
Function Description	Resumes the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> HAL status

34.2.10 HAL_I2S_DMAStop

Function Name	HAL_StatusTypeDef HAL_I2S_DMAStop (I2S_HandleTypeDef * hi2s)
---------------	---

Function Description	Resumes the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • HAL status

34.2.11 HAL_I2S_IRQHandler

Function Name	void HAL_I2S_IRQHandler (I2S_HandleTypeDef * hi2s)
Function Description	This function handles I2S interrupt request.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module
Return values	<ul style="list-style-type: none"> • None

34.2.12 HAL_I2SEx_TransmitReceive

Function Name	HAL_StatusTypeDef HAL_I2SEx_TransmitReceive (I2S_HandleTypeDef * hi2s, uint16_t * pTxData, uint16_t * pRxData, uint16_t Size, uint32_t Timeout)
Function Description	Full-Duplex Transmit/Receive data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pTxData: a 16-bit pointer to the Transmit data buffer. • pRxData: a 16-bit pointer to the Receive data buffer. • Size: number of data sample to be sent: • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. • The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

34.2.13 HAL_I2SEx_TransmitReceive_IT

Function Name	HAL_StatusTypeDef HAL_I2SEx_TransmitReceive_IT (I2S_HandleTypeDef * hi2s, uint16_t * pTxData, uint16_t * pRxData, uint16_t Size)
Function Description	Full-Duplex Transmit/Receive data in non-blocking mode using Interrupt.
Parameters	<ul style="list-style-type: none"> • hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module • pTxData: a 16-bit pointer to the Transmit data buffer. • pRxData: a 16-bit pointer to the Receive data buffer. • Size: number of data sample to be sent:

Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

34.2.14 HAL_I2SEEx_TransmitReceive_DMA

Function Name	<code>HAL_StatusTypeDef HAL_I2SEEx_TransmitReceive_DMA(I2S_HandleTypeDef * hi2s, uint16_t * pTxData, uint16_t * pRxData, uint16_t Size)</code>
Function Description	Full-Duplex Transmit/Receive data in non-blocking mode using DMA.
Parameters	<ul style="list-style-type: none"> hi2s: pointer to a I2S_HandleTypeDef structure that contains the configuration information for I2S module pTxData: a 16-bit pointer to the Transmit data buffer. pRxData: a 16-bit pointer to the Receive data buffer. Size: number of data sample to be sent:
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> When a 16-bit data frame or a 16-bit data frame extended is selected during the I2S configuration phase, the Size parameter means the number of 16-bit data length in the transaction and when a 24-bit data frame or a 32-bit data frame is selected the Size parameter means the number of 16-bit data length. The I2S is kept enabled at the end of transaction to avoid the clock de-synchronization between Master and Slave(example: audio streaming).

34.3 I2SEEx Firmware driver defines

34.3.1 I2SEEx

I2S Private Macros

`IS_I2S_CLOCKSOURCE`

`I2SxEXT`

35 HAL IRDA Generic Driver

35.1 HAL IRDA Generic Driver

35.2 IRDA Firmware driver registers structures

35.2.1 IRDA_InitTypeDef

Data Fields

- *uint32_t BaudRate*
- *uint32_t WordLength*
- *uint32_t Parity*
- *uint32_t Mode*
- *uint8_t Prescaler*
- *uint32_t IrDAMode*

Field Documentation

- ***uint32_t IRDA_InitTypeDef::BaudRate***
This member configures the IRDA communication baud rate. The baud rate is computed using the following formula:

$$\text{IntegerDivider} = ((\text{PCLKx}) / (8 * (\text{hirda->Init.BaudRate})))$$

$$\text{FractionalDivider} = ((\text{IntegerDivider} - ((\text{uint32_t}) \text{ IntegerDivider})) * 8) + 0.5$$
- ***uint32_t IRDA_InitTypeDef::WordLength***
Specifies the number of data bits transmitted or received in a frame. This parameter can be a value of [*IRDA_Word_Length*](#)
- ***uint32_t IRDA_InitTypeDef::Parity***
Specifies the parity mode. This parameter can be a value of [*IRDA_Parity*](#)
Note:When parity is enabled, the computed parity is inserted at the MSB position of the transmitted data (9th bit when the word length is set to 9 data bits; 8th bit when the word length is set to 8 data bits).
- ***uint32_t IRDA_InitTypeDef::Mode***
Specifies whether the Receive or Transmit mode is enabled or disabled. This parameter can be a value of [*IRDA_Mode*](#)
- ***uint8_t IRDA_InitTypeDef::Prescaler***
Specifies the Prescaler
- ***uint32_t IRDA_InitTypeDef::IrDAMode***
Specifies the IrDA mode This parameter can be a value of [*IRDA_Low_Power*](#)

35.2.2 IRDA_HandleTypeDef

Data Fields

- *USART_TypeDef * Instance*
- *IRDA_InitTypeDef Init*
- *uint8_t * pTxBuffPtr*
- *uint16_t TxXferSize*

- *uint16_t TxXferCount*
- *uint8_t * pRxBuffPtr*
- *uint16_t RxXferSize*
- *uint16_t RxXferCount*
- *DMA_HandleTypeDef * hdmatx*
- *DMA_HandleTypeDef * hdmarx*
- *HAL_LockTypeDef Lock*
- *__IO HAL_IRDA_StateTypeDef State*
- *__IO uint32_t ErrorCode*

Field Documentation

- *USART_TypeDef* IRDA_HandleTypeDef::Instance*
- *IRDA_InitTypeDef IRDA_HandleTypeDef::Init*
- *uint8_t* IRDA_HandleTypeDef::pTxBuffPtr*
- *uint16_t IRDA_HandleTypeDef::TxXferSize*
- *uint16_t IRDA_HandleTypeDef::TxXferCount*
- *uint8_t* IRDA_HandleTypeDef::pRxBuffPtr*
- *uint16_t IRDA_HandleTypeDef::RxXferSize*
- *uint16_t IRDA_HandleTypeDef::RxXferCount*
- *DMA_HandleTypeDef* IRDA_HandleTypeDef::hdmatx*
- *DMA_HandleTypeDef* IRDA_HandleTypeDef::hdmarx*
- *HAL_LockTypeDef IRDA_HandleTypeDef::Lock*
- *__IO HAL_IRDA_StateTypeDef IRDA_HandleTypeDef::State*
- *__IO uint32_t IRDA_HandleTypeDef::ErrorCode*

35.3 IRDA Firmware driver API description

35.3.1 How to use this driver

The IRDA HAL driver can be used as follows:

1. Declare a IRDA_HandleTypeDef handle structure.
2. Initialize the IRDA low level resources by implementing the HAL_IRDA_MspInit() API:
 - a. Enable the USARTx interface clock.
 - b. IRDA pins configuration:
 - Enable the clock for the IRDA GPIOs.
 - Configure these IRDA pins as alternate function pull-up.
 - c. NVIC configuration if you need to use interrupt process (HAL_IRDA_Transmit_IT() and HAL_IRDA_Receive_IT() APIs):
 - Configure the USARTx interrupt priority.
 - Enable the NVIC USART IRQ handle.
 - d. DMA Configuration if you need to use DMA process (HAL_IRDA_Transmit_DMA() and HAL_IRDA_Receive_DMA() APIs):
 - Declare a DMA handle structure for the Tx/Rx stream.
 - Enable the DMAx interface clock.
 - Configure the declared DMA handle structure with the required Tx/Rx parameters.
 - Configure the DMA Tx/Rx Stream.
 - Associate the initialized DMA handle to the IRDA DMA Tx/Rx handle.
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx/Rx Stream.

3. Program the Baud Rate, Word Length, Parity, IrDA Mode, Prescaler and Mode(Receiver/Transmitter) in the hirda Init structure.
4. Initialize the IRDA registers by calling the HAL_IRDA_Init() API:
 - This API configures also the low level Hardware GPIO, CLOCK, CORTEX...etc) by calling the customized HAL_IRDA_MspInit() API. The specific IRDA interrupts (Transmission complete interrupt, RXNE interrupt and Error Interrupts) will be managed using the macros __HAL_IRDA_ENABLE_IT() and __HAL_IRDA_DISABLE_IT() inside the transmit and receive process.
5. Three operation modes are available within this driver :

Polling mode IO operation

- Send an amount of data in blocking mode using HAL_IRDA_Transmit()
- Receive an amount of data in blocking mode using HAL_IRDA_Receive()

Interrupt mode IO operation

- Send an amount of data in non blocking mode using HAL_IRDA_Transmit_IT()
- At transmission end of transfer HAL_IRDA_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_IRDA_TxCpltCallback
- Receive an amount of data in non blocking mode using HAL_IRDA_Receive_IT()
- At reception end of transfer HAL_IRDA_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_IRDA_RxCpltCallback
- In case of transfer Error, HAL_IRDA_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_IRDA_ErrorCallback

DMA mode IO operation

- Send an amount of data in non blocking mode (DMA) using HAL_IRDA_Transmit_DMA()
- At transmission end of transfer HAL_IRDA_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_IRDA_TxCpltCallback
- Receive an amount of data in non blocking mode (DMA) using HAL_IRDA_Receive_DMA()
- At reception end of transfer HAL_IRDA_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_IRDA_RxCpltCallback
- In case of transfer Error, HAL_IRDA_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_IRDA_ErrorCallback

IRDA HAL driver macros list



You can refer to the IRDA HAL driver header file for more useful macros

35.3.2 Initialization and Configuration functions

This subsection provides a set of functions allowing to initialize the USARTx or the UARTy in IrDA mode.

- For the asynchronous mode only these parameters can be configured:
 - BaudRate
 - WordLength
 - Parity: If the parity is enabled, then the MSB bit of the data written in the data register is transmitted but is changed by the parity bit. Depending on the frame length defined by the M bit (8-bits or 9-bits), please refer to Reference manual for possible IRDA frame formats.
 - Prescaler: A pulse of width less than two and greater than one PSC period(s) may or may not be rejected. The receiver set up time should be managed by software. The IrDA physical layer specification specifies a minimum of 10 ms delay between transmission and reception (IrDA is a half duplex protocol).
 - Mode: Receiver/transmitter modes
 - IrDAMode: the IrDA can operate in the Normal mode or in the Low power mode.

The HAL_IRDA_Init() API follows IRDA configuration procedures (details for the procedures are available in reference manual).

This section contains the following APIs:

- [**HAL_IRDA_Init\(\)**](#)
- [**HAL_IRDA_DeInit\(\)**](#)
- [**HAL_IRDA_MspInit\(\)**](#)
- [**HAL_IRDA_MspDeInit\(\)**](#)

35.3.3 IO operation functions

IrDA is a half duplex communication protocol. If the Transmitter is busy, any data on the IrDA receive line will be ignored by the IrDA decoder and if the Receiver is busy, data on the TX from the USART to IrDA will not be encoded by IrDA. While receiving data, transmission should be avoided as the data to be transmitted could be corrupted.

1. There are two modes of transfer:
 - Blocking mode: The communication is performed in polling mode. The HAL status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode: The communication is performed using Interrupts or DMA, These APIs return the HAL status. The end of the data processing will be indicated through the dedicated IRDA IRQ when using Interrupt mode or the DMA IRQ when using DMA mode. The HAL_IRDA_TxCpltCallback(), HAL_IRDA_RxCpltCallback() user callbacks will be executed respectively at the end of the transmit or Receive process The HAL_IRDA_ErrorCallback() user callback will be executed when a communication error is detected
2. Blocking mode API's are :
 - [**HAL_IRDA_Transmit\(\)**](#)
 - [**HAL_IRDA_Receive\(\)**](#)
3. Non Blocking mode APIs with Interrupt are :
 - [**HAL_IRDA_Transmit_IT\(\)**](#)
 - [**HAL_IRDA_Receive_IT\(\)**](#)
 - [**HAL_IRDA_IRQHandler\(\)**](#)
4. Non Blocking mode functions with DMA are :
 - [**HAL_IRDA_Transmit_DMA\(\)**](#)
 - [**HAL_IRDA_Receive_DMA\(\)**](#)
5. A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - [**HAL_IRDA_TxCpltCallback\(\)**](#)
 - [**HAL_IRDA_RxCpltCallback\(\)**](#)
 - [**HAL_IRDA_ErrorCallback\(\)**](#)

This section contains the following APIs:

- [`HAL_IRDA_Transmit\(\)`](#)
- [`HAL_IRDA_Receive\(\)`](#)
- [`HAL_IRDA_Transmit_IT\(\)`](#)
- [`HAL_IRDA_Receive_IT\(\)`](#)
- [`HAL_IRDA_Transmit_DMA\(\)`](#)
- [`HAL_IRDA_Receive_DMA\(\)`](#)
- [`HAL_IRDA_DMAPause\(\)`](#)
- [`HAL_IRDA_DMAResume\(\)`](#)
- [`HAL_IRDA_DMAStop\(\)`](#)
- [`HAL_IRDA IRQHandler\(\)`](#)
- [`HAL_IRDA_TxCpltCallback\(\)`](#)
- [`HAL_IRDA_TxHalfCpltCallback\(\)`](#)
- [`HAL_IRDA_RxCpltCallback\(\)`](#)
- [`HAL_IRDA_RxHalfCpltCallback\(\)`](#)
- [`HAL_IRDA_ErrorCallback\(\)`](#)

35.3.4 Peripheral State and Errors functions

This subsection provides a set of functions allowing to return the State of IrDA communication process and also return Peripheral Errors occurred during communication process

- `HAL_IRDA_GetState()` API can be helpful to check in run-time the state of the IrDA peripheral.
- `HAL_IRDA_GetError()` check in run-time errors that could be occurred during communication.

This section contains the following APIs:

- [`HAL_IRDA_GetState\(\)`](#)
- [`HAL_IRDA_GetError\(\)`](#)

35.3.5 HAL_IRDA_Init

Function Name	<code>HAL_StatusTypeDef HAL_IRDA_Init (IRDA_HandleTypeDef * hirda)</code>
Function Description	Initializes the IRDA mode according to the specified parameters in the <code>IRDA_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a <code>IRDA_HandleTypeDef</code> structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • HAL status

35.3.6 HAL_IRDA_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_IRDA_DeInit (IRDA_HandleTypeDef * hirda)</code>
Function Description	DeInitializes the IRDA peripheral.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a <code>IRDA_HandleTypeDef</code> structure that contains the configuration information for the specified IRDA module.

Return values	<ul style="list-style-type: none"> • HAL status
35.3.7 HAL_IRDA_MsplInit	
Function Name	void HAL_IRDA_MsplInit (IRDA_HandleTypeDef * hirda)
Function Description	IRDA MSP Init.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • None
35.3.8 HAL_IRDA_MspDeInit	
Function Name	void HAL_IRDA_MspDeInit (IRDA_HandleTypeDef * hirda)
Function Description	IRDA MSP DeInit.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • None
35.3.9 HAL_IRDA_Transmit	
Function Name	HAL_StatusTypeDef HAL_IRDA_Transmit (IRDA_HandleTypeDef * hirda, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Sends an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module. • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Specify timeout value
Return values	<ul style="list-style-type: none"> • HAL status
35.3.10 HAL_IRDA_Receive	
Function Name	HAL_StatusTypeDef HAL_IRDA_Receive (IRDA_HandleTypeDef * hirda, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module. • pData: Pointer to data buffer • Size: Amount of data to be received • Timeout: Specify timeout value
Return values	<ul style="list-style-type: none"> • HAL status

35.3.11 HAL_IRDA_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_IRDA_Transmit_IT (IRDA_HandleTypeDef * hirda, uint8_t * pData, uint16_t Size)
Function Description	Send an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

35.3.12 HAL_IRDA_Receive_IT

Function Name	HAL_StatusTypeDef HAL_IRDA_Receive_IT (IRDA_HandleTypeDef * hirda, uint8_t * pData, uint16_t Size)
Function Description	Receives an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module. • pData: Pointer to data buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status

35.3.13 HAL_IRDA_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_IRDA_Transmit_DMA (IRDA_HandleTypeDef * hirda, uint8_t * pData, uint16_t Size)
Function Description	Sends an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

35.3.14 HAL_IRDA_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_IRDA_Receive_DMA (IRDA_HandleTypeDef * hirda, uint8_t * pData, uint16_t Size)
Function Description	Receives an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module. • pData: Pointer to data buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status

Notes	<ul style="list-style-type: none"> When the IRDA parity is enabled (PCE = 1) the data received contain the parity bit.
-------	---

35.3.15 HAL_IRDA_DMAPause

Function Name	HAL_StatusTypeDef HAL_IRDA_DMAPause (IRDA_HandleTypeDef * hirda)
Function Description	Pauses the DMA Transfer.
Parameters	<ul style="list-style-type: none"> hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> HAL status

35.3.16 HAL_IRDA_DMAResume

Function Name	HAL_StatusTypeDef HAL_IRDA_DMAResume (IRDA_HandleTypeDef * hirda)
Function Description	Resumes the DMA Transfer.
Parameters	<ul style="list-style-type: none"> hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> HAL status

35.3.17 HAL_IRDA_DMAStop

Function Name	HAL_StatusTypeDef HAL_IRDA_DMAStop (IRDA_HandleTypeDef * hirda)
Function Description	Stops the DMA Transfer.
Parameters	<ul style="list-style-type: none"> hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> HAL status

35.3.18 HAL_IRDA_IRQHandler

Function Name	void HAL_IRDA_IRQHandler (IRDA_HandleTypeDef * hirda)
Function Description	This function handles IRDA interrupt request.
Parameters	<ul style="list-style-type: none"> hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> None

35.3.19 HAL_IRDA_TxCpltCallback

Function Name	void HAL_IRDA_TxCpltCallback (IRDA_HandleTypeDef * hirda)
Function Description	Tx Transfer complete callbacks.

Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • None

35.3.20 HAL_IRDA_TxHalfCpltCallback

Function Name	void HAL_IRDA_TxHalfCpltCallback (IRDA_HandleTypeDef * hirda)
Function Description	Tx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

35.3.21 HAL_IRDA_RxCpltCallback

Function Name	void HAL_IRDA_RxCpltCallback (IRDA_HandleTypeDef * hirda)
Function Description	Rx Transfer complete callbacks.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • None

35.3.22 HAL_IRDA_RxHalfCpltCallback

Function Name	void HAL_IRDA_RxHalfCpltCallback (IRDA_HandleTypeDef * hirda)
Function Description	Rx Half Transfer complete callbacks.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • None

35.3.23 HAL_IRDA_ErrorCallback

Function Name	void HAL_IRDA_ErrorCallback (IRDA_HandleTypeDef * hirda)
Function Description	IRDA error callbacks.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • None

35.3.24 HAL_IRDA_GetState

Function Name	HAL_IRDA_StateTypeDef HAL_IRDA_GetState
---------------	--

(IRDA_HandleTypeDef * hirda)

Function Description	Returns the IRDA state.
Parameters	<ul style="list-style-type: none"> • hirda: pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA module.
Return values	<ul style="list-style-type: none"> • HAL state

35.3.25 HAL_IRDA_GetError

Function Name	uint32_t HAL_IRDA_GetError (IRDA_HandleTypeDef * hirda)
Function Description	Return the IARDA error code.
Parameters	<ul style="list-style-type: none"> • hirda: : pointer to a IRDA_HandleTypeDef structure that contains the configuration information for the specified IRDA.
Return values	<ul style="list-style-type: none"> • IRDA Error Code

35.4 IRDA Firmware driver defines**35.4.1 IRDA*****IRDA Error Code***

HAL_IRDA_ERROR_NONE	No error
HAL_IRDA_ERROR_PE	Parity error
HAL_IRDA_ERROR_NE	Noise error
HAL_IRDA_ERROR_FE	Frame error
HAL_IRDA_ERROR_ORE	Overrun error
HAL_IRDA_ERROR_DMA	DMA transfer error

IRDA Exported Macros

_HAL_IRDA_RESET_HANDLE_STATE	Description: <ul style="list-style-type: none"> • Reset IRDA handle state. Parameters: <ul style="list-style-type: none"> • _HANDLE_: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral. Return value: <ul style="list-style-type: none"> • None
_HAL_IRDA_FLUSH_DRREGISTER	Description: <ul style="list-style-type: none"> • Flushes the IRDA DR register. Parameters: <ul style="list-style-type: none"> • _HANDLE_: specifies the USART Handle. This parameter can be

USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

__HAL_IRDA_GET_FLAG

Description:

- Checks whether the specified IRDA flag is set or not.

Parameters:

- __HANDLE__: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - IRDA_FLAG_TXE: Transmit data register empty flag
 - IRDA_FLAG_TC: Transmission Complete flag
 - IRDA_FLAG_RXNE: Receive data register not empty flag
 - IRDA_FLAG_IDLE: Idle Line detection flag
 - IRDA_FLAG_ORE: OverRun Error flag
 - IRDA_FLAG_NE: Noise Error flag
 - IRDA_FLAG_FE: Framing Error flag
 - IRDA_FLAG_PE: Parity Error flag

Return value:

- The: new state of __FLAG__ (TRUE or FALSE).

__HAL_IRDA_CLEAR_FLAG

Description:

- Clears the specified IRDA pending flag.

Parameters:

- __HANDLE__: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- __FLAG__: specifies the flag to check. This parameter can be any combination of the following values:
 - IRDA_FLAG_TC: Transmission Complete flag.
 - IRDA_FLAG_RXNE: Receive

data register not empty flag.

Return value:

- None

Notes:

- PE (Parity error), FE (Framing error), NE (Noise error), ORE (OverRun error) and IDLE (Idle line detected) flags are cleared by software sequence: a read operation to USART_SR register followed by a read operation to USART_DR register. RXNE flag can be also cleared by a read to the USART_DR register. TC flag can be also cleared by software sequence: a read operation to USART_SR register followed by a write operation to USART_DR register. TXE flag is cleared only by a write to the USART_DR register.

`__HAL_IRDA_CLEAR_PEFLAG`

Description:

- Clear the IRDA PE pending flag.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`__HAL_IRDA_CLEAR_FEFLAG`

Description:

- Clear the IRDA FE pending flag.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`__HAL_IRDA_CLEAR_NEFLAG`

Description:

- Clear the IRDA NE pending flag.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be

USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`_HAL_IRDA_CLEAR_OREFLAG`

- Clear the IRDA ORE pending flag.

Parameters:

- `_HANDLE_`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`_HAL_IRDA_CLEAR_IDLEFLAG`

- Clear the IRDA IDLE pending flag.

Parameters:

- `_HANDLE_`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`_HAL_IRDA_ENABLE_IT`

- Enables or disables the specified IRDA interrupt.

Parameters:

- `_HANDLE_`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- `_INTERRUPT_`: specifies the IRDA interrupt source to check. This parameter can be one of the following values:
 - `IRDA_IT_TXE`: Transmit Data Register empty interrupt
 - `IRDA_IT_TC`: Transmission complete interrupt
 - `IRDA_IT_RXNE`: Receive Data register not empty interrupt
 - `IRDA_IT_IDLE`: Idle line

- detection interrupt
- IRDA_IT_PE: Parity Error interrupt
- IRDA_IT_ERR: Error interrupt(Frame error, noise error, overrun error)

Return value:

- None

`__HAL_IRDA_DISABLE_IT`
`__HAL_IRDA_GET_IT_SOURCE`

Description:

- Checks whether the specified IRDA interrupt has occurred or not.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- `__IT__`: specifies the IRDA interrupt source to check. This parameter can be one of the following values:
 - IRDA_IT_TXE: Transmit Data Register empty interrupt
 - IRDA_IT_TC: Transmission complete interrupt
 - IRDA_IT_RXNE: Receive Data register not empty interrupt
 - IRDA_IT_IDLE: Idle line detection interrupt
 - USART_IT_ERR: Error interrupt
 - IRDA_IT_PE: Parity Error interrupt

Return value:

- The new state of `__IT__` (TRUE or FALSE).

`__HAL_IRDA_ONE_BIT_SAMPLE_ENABLE`

Description:

- Macro to enable the IRDA's one bit sample method.

Parameters:

- `__HANDLE__`: specifies the IRDA Handle.

Return value:

- None

`__HAL_IRDA_ONE_BIT_SAMPLE_DISABLE`

Description:

- Macro to disable the IRDA's one bit

sample method.

Parameters:

- `__HANDLE__`: specifies the IRDA Handle.

Return value:

- None

`__HAL_IRDA_ENABLE`

Description:

- Enable UART/USART associated to IRDA Handle.

Parameters:

- `__HANDLE__`: specifies the IRDA Handle. IRDA Handle selects the USARTx or UARTy peripheral (USART,UART availability and x,y values depending on device).

Return value:

- None

`__HAL_IRDA_DISABLE`

Description:

- Disable UART/USART associated to IRDA Handle.

Parameters:

- `__HANDLE__`: specifies the IRDA Handle. IRDA Handle selects the USARTx or UARTy peripheral (USART,UART availability and x,y values depending on device).

Return value:

- None

IRDA Flags

`IRDA_FLAG_TXE`

`IRDA_FLAG_TC`

`IRDA_FLAG_RXNE`

`IRDA_FLAG_IDLE`

`IRDA_FLAG_ORE`

`IRDA_FLAG_NE`

`IRDA_FLAG_FE`

`IRDA_FLAG_PE`

IRDA Interrupt Definitions

`IRDA_IT_PE`

`IRDA_IT_TXE`

IRDA_IT_TC
IRDA_IT_RXNE
IRDA_IT_IDLE
IRDA_IT_LBD
IRDA_IT_CTS
IRDA_IT_ERR
IRDA Low Power
IRDA_POWERMODE_LOWPOWER
IRDA_POWERMODE_NORMAL
IRDA Transfer Mode
IRDA_MODE_RX
IRDA_MODE_TX
IRDA_MODE_TX_RX
IRDA Parity
IRDA_PARITY_NONE
IRDA_PARITY_EVEN
IRDA_PARITY_ODD
IRDA Private Constants
IRDA_TIMEOUT_VALUE
IRDA_IT_MASK
IRDA_CR1_REG_INDEX
IRDA_CR2_REG_INDEX
IRDA_CR3_REG_INDEX
IRDA Private Macros
IS_IRDA_WORD_LENGTH
IS_IRDA_PARITY
IS_IRDA_MODE
IS_IRDA_POWERMODE
IS_IRDA_BAUDRATE
IRDA_DIV
IRDA_DIVMANT
IRDA_DIVFRAQ
IRDA_BRR
IRDA Word Length
IRDA_WORDLENGTH_8B
IRDA_WORDLENGTH_9B

36 HAL IWDG Generic Driver

36.1 HAL IWDG Generic Driver

36.2 IWDG Firmware driver registers structures

36.2.1 IWDG_InitTypeDef

Data Fields

- *uint32_t Prescaler*
- *uint32_t Reload*

Field Documentation

- *uint32_t IWDG_InitTypeDef::Prescaler*
Select the prescaler of the IWDG. This parameter can be a value of [*IWDG_Prescaler*](#)
- *uint32_t IWDG_InitTypeDef::Reload*
Specifies the IWDG down-counter reload value. This parameter must be a number between Min_Data = 0 and Max_Data = 0x0FFF

36.2.2 IWDG_HandleTypeDefDef

Data Fields

- *IWDG_TypeDef * Instance*
- *IWDG_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_IWDG_StateTypeDef State*

Field Documentation

- *IWDG_TypeDef* IWDG_HandleTypeDefDef::Instance*
Register base address
- *IWDG_InitTypeDef IWDG_HandleTypeDefDef::Init*
IWDG required parameters
- *HAL_LockTypeDef IWDG_HandleTypeDefDef::Lock*
IWDG Locking object
- *__IO HAL_IWDG_StateTypeDef IWDG_HandleTypeDefDef::State*
IWDG communication state

36.3 IWDG Firmware driver API description

36.3.1 IWDG Specific features

- The IWDG can be started by either software or hardware (configurable through option byte).
- The IWDG is clocked by its own dedicated Low-Speed clock (LSI) and thus stays active even if the main clock fails. Once the IWDG is started, the LSI is forced ON and cannot be disabled (LSI cannot be disabled too), and the counter starts counting down from the reset value of 0xFFFF. When it reaches the end of count value (0x000) a system reset is generated.
- The IWDG counter should be refreshed at regular intervals, otherwise the watchdog generates an MCU reset when the counter reaches 0.
- The IWDG is implemented in the VDD voltage domain that is still functional in STOP and STANDBY mode (IWDG reset can wake-up from STANDBY). IWDGRST flag in RCC_CSR register can be used to inform when an IWDG reset occurs.
- Min-max timeout value @32KHz (LSI): ~125us / ~32.7s The IWDG timeout may vary due to LSI frequency dispersion. STM32F4xx devices provide the capability to measure the LSI frequency (LSI clock connected internally to TIM5 CH4 input capture). The measured value can be used to have an IWDG timeout with an acceptable accuracy.

36.3.2 How to use this driver

If Window option is disabled

- Use IWDG using HAL_IWDG_Init() function to :
 - Enable write access to IWDG_PR, IWDG_RLR.
 - Configure the IWDG prescaler, counter reload value. This reload value will be loaded in the IWDG counter each time the counter is reloaded, then the IWDG will start counting down from this value.
- Use IWDG using HAL_IWDG_Start() function to :
 - Reload IWDG counter with value defined in the IWDG_RLR register.
 - Start the IWDG, when the IWDG is used in software mode (no need to enable the LSI, it will be enabled by hardware).
- Then the application program must refresh the IWDG counter at regular intervals during normal operation to prevent an MCU reset, using HAL_IWDG_Refresh() function.

if Window option is enabled:

- Use IWDG using HAL_IWDG_Start() function to enable IWDG downcounter
- Use IWDG using HAL_IWDG_Init() function to :
 - Enable write access to IWDG_PR, IWDG_RLR and IWDG_WINR registers.
 - Configure the IWDG prescaler, reload value and window value.
- Then the application program must refresh the IWDG counter at regular intervals during normal operation to prevent an MCU reset, using HAL_IWDG_Refresh() function.

IWDG HAL driver macros list

Below the list of most used macros in IWDG HAL driver.

- __HAL_IWDG_START: Enable the IWDG peripheral
- __HAL_IWDG_RELOAD_COUNTER: Reloads IWDG counter with value defined in the reload register
- __HAL_IWDG_GET_FLAG: Get the selected IWDG's flag status

36.3.3 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the IWDG according to the specified parameters in the IWDG_InitTypeDef and create the associated handle
- Initialize the IWDG MSP
- Deinitialize IWDG MSP

This section contains the following APIs:

- [*HAL_IWDG_Init\(\)*](#)
- [*HAL_IWDG_MspInit\(\)*](#)

36.3.4 IO operation functions

This section provides functions allowing to:

- Start the IWDG.
- Refresh the IWDG.

This section contains the following APIs:

- [*HAL_IWDG_Start\(\)*](#)
- [*HAL_IWDG_Refresh\(\)*](#)

36.3.5 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_IWDG_GetState\(\)*](#)

36.3.6 HAL_IWDG_Init

Function Name	<code>HAL_StatusTypeDef HAL_IWDG_Init (IWDG_HandleTypeDef * hiwdg)</code>
Function Description	Initializes the IWDG according to the specified parameters in the IWDG_InitTypeDef and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hiwdg: pointer to a IWDG_HandleTypeDef structure that contains the configuration information for the specified IWDG module.
Return values	<ul style="list-style-type: none"> • HAL status

36.3.7 HAL_IWDG_MspInit

Function Name	<code>void HAL_IWDG_MspInit (IWDG_HandleTypeDef * hiwdg)</code>
Function Description	Initializes the IWDG MSP.
Parameters	<ul style="list-style-type: none"> • hiwdg: pointer to a IWDG_HandleTypeDef structure that contains the configuration information for the specified IWDG module.
Return values	<ul style="list-style-type: none"> • None

36.3.8 HAL_IWDG_Start

Function Name	HAL_StatusTypeDef HAL_IWDG_Start (IWDG_HandleTypeDef * hiwdg)
Function Description	Starts the IWDG.
Parameters	<ul style="list-style-type: none"> • hiwdg: pointer to a IWDG_HandleTypeDef structure that contains the configuration information for the specified IWDG module.
Return values	<ul style="list-style-type: none"> • HAL status

36.3.9 HAL_IWDG_Refresh

Function Name	HAL_StatusTypeDef HAL_IWDG_Refresh (IWDG_HandleTypeDef * hiwdg)
Function Description	Refreshes the IWDG.
Parameters	<ul style="list-style-type: none"> • hiwdg: pointer to a IWDG_HandleTypeDef structure that contains the configuration information for the specified IWDG module.
Return values	<ul style="list-style-type: none"> • HAL status

36.3.10 HAL_IWDG_GetState

Function Name	HAL_IWDG_StateTypeDef HAL_IWDG_GetState (IWDG_HandleTypeDef * hiwdg)
Function Description	Returns the IWDG state.
Parameters	<ul style="list-style-type: none"> • hiwdg: pointer to a IWDG_HandleTypeDef structure that contains the configuration information for the specified IWDG module.
Return values	<ul style="list-style-type: none"> • HAL state

36.4 IWDG Firmware driver defines

36.4.1 IWDG

IWDG Exported Macros

<u>_HAL_IWDG_RESET_HANDLE_STATE</u>	Description:
	<ul style="list-style-type: none"> • Reset IWDG handle state.
	Parameters:
	<ul style="list-style-type: none"> • <u>_HANDLE__</u>: IWDG handle.
	Return value:
	<ul style="list-style-type: none"> • None
<u>_HAL_IWDG_START</u>	Description:
	<ul style="list-style-type: none"> • Enables the IWDG peripheral.
	Parameters:
	<ul style="list-style-type: none"> • <u>_HANDLE__</u>: IWDG handle

Return value:

- None

`_HAL_IWDG_RELOAD_COUNTER`**Description:**

- Reloads IWDG counter with value defined in the reload register (write access to IWDG_PR and IWDG_RLR registers disabled).

Parameters:

- `_HANDLE_`: IWDG handle

Return value:

- None

`_HAL_IWDG_GET_FLAG`**Description:**

- Gets the selected IWDG's flag status.

Parameters:

- `_HANDLE_`: IWDG handle
- `_FLAG_`: specifies the flag to check. This parameter can be one of the following values:
 - IWDG_FLAG_PVU: Watchdog counter reload value update flag
 - IWDG_FLAG_RVU: Watchdog counter prescaler value flag

Return value:

- The: new state of `_FLAG_` (TRUE or FALSE).

IWDG Flag definition`IWDG_FLAG_PVU` Watchdog counter prescaler value update Flag`IWDG_FLAG_RVU` Watchdog counter reload value update Flag***IWDG Prescaler***

<code>IWDG_PRESCALER_4</code>	IWDG prescaler set to 4
<code>IWDG_PRESCALER_8</code>	IWDG prescaler set to 8
<code>IWDG_PRESCALER_16</code>	IWDG prescaler set to 16
<code>IWDG_PRESCALER_32</code>	IWDG prescaler set to 32
<code>IWDG_PRESCALER_64</code>	IWDG prescaler set to 64
<code>IWDG_PRESCALER_128</code>	IWDG prescaler set to 128
<code>IWDG_PRESCALER_256</code>	IWDG prescaler set to 256

IWDG Private Constants`IWDG_TIMEOUT_FLAG`***IWDG Private Macros***`IWDG_ENABLE_WRITE_ACCESS` **Description:**

- Enables write access to IWDG_PR and IWDG_RLR registers.

Parameters:

- `__HANDLE__`: IWDG handle

Return value:

- None

IWDG_DISABLE_WRITE_ACCESS**Description:**

- Disables write access to IWDG_PR and IWDG_RLR registers.

Parameters:

- `__HANDLE__`: IWDG handle

Return value:

- None

IS_IWDG_PRESCALER**IS_IWDG_RELOAD*****IWDG Registers BitMask***

IWDG_KEY_RELOAD	IWDG Reload Counter Enable
IWDG_KEY_ENABLE	IWDG Peripheral Enable
IWDG_KEY_WRITE_ACCESS_ENABLE	IWDG KR Write Access Enable
IWDG_KEY_WRITE_ACCESS_DISABLE	IWDG KR Write Access Disable

37 HAL LPTIM Generic Driver

37.1 HAL LPTIM Generic Driver

37.2 LPTIM Firmware driver registers structures

37.2.1 LPTIM_ClockConfigTypeDef

Data Fields

- *uint32_t Source*
- *uint32_t Prescaler*

Field Documentation

- *uint32_t LPTIM_ClockConfigTypeDef::Source*
Selects the clock source. This parameter can be a value of [LPTIM_Clock_Source](#)
- *uint32_t LPTIM_ClockConfigTypeDef::Prescaler*
Specifies the counter clock Prescaler. This parameter can be a value of [LPTIM_Clock_Prescaler](#)

37.2.2 LPTIM_ULPClockConfigTypeDef

Data Fields

- *uint32_t Polarity*
- *uint32_t SampleTime*

Field Documentation

- *uint32_t LPTIM_ULPClockConfigTypeDef::Polarity*
Selects the polarity of the active edge for the counter unit if the ULPTIM input is selected. Note: This parameter is used only when Ultra low power clock source is used. Note: If the polarity is configured on 'both edges', an auxiliary clock (one of the Low power oscillator) must be active. This parameter can be a value of [LPTIM_Clock_Polarity](#)
- *uint32_t LPTIM_ULPClockConfigTypeDef::SampleTime*
Selects the clock sampling time to configure the clock glitch filter. Note: This parameter is used only when Ultra low power clock source is used. This parameter can be a value of [LPTIM_Clock_Sample_Time](#)

37.2.3 LPTIM_TriggerConfigTypeDef

Data Fields

- `uint32_t Source`
- `uint32_t ActiveEdge`
- `uint32_t SampleTime`

Field Documentation

- `uint32_t LPTIM_TriggerConfigTypeDef::Source`
Selects the Trigger source. This parameter can be a value of `LPTIM_Trigger_Source`
- `uint32_t LPTIM_TriggerConfigTypeDef::ActiveEdge`
Selects the Trigger active edge. Note: This parameter is used only when an external trigger is used. This parameter can be a value of `LPTIM_External_Trigger_Polarity`
- `uint32_t LPTIM_TriggerConfigTypeDef::SampleTime`
Selects the trigger sampling time to configure the clock glitch filter. Note: This parameter is used only when an external trigger is used. This parameter can be a value of `LPTIM_Trigger_Sample_Time`

37.2.4 LPTIM_InitTypeDef

Data Fields

- `LPTIM_ClockConfigTypeDef Clock`
- `LPTIM_ULPClockConfigTypeDef UltraLowPowerClock`
- `LPTIM_TriggerConfigTypeDef Trigger`
- `uint32_t OutputPolarity`
- `uint32_t UpdateMode`
- `uint32_t CounterSource`

Field Documentation

- `LPTIM_ClockConfigTypeDef LPTIM_InitTypeDef::Clock`
Specifies the clock parameters
- `LPTIM_ULPClockConfigTypeDef LPTIM_InitTypeDef::UltraLowPowerClock`
Specifies the Ultra Low Power clock parameters
- `LPTIM_TriggerConfigTypeDef LPTIM_InitTypeDef::Trigger`
Specifies the Trigger parameters
- `uint32_t LPTIM_InitTypeDef::OutputPolarity`
Specifies the Output polarity. This parameter can be a value of `LPTIM_Output_Polarity`
- `uint32_t LPTIM_InitTypeDef::UpdateMode`
Specifies whether the update of the autoreload and the compare values is done immediately or after the end of current period. This parameter can be a value of `LPTIM Updating_Mode`
- `uint32_t LPTIM_InitTypeDef::CounterSource`
Specifies whether the counter is incremented each internal event or each external event. This parameter can be a value of `LPTIM_Counter_Source`

37.2.5 LPTIM_HandleTypeDef

Data Fields

- *LPTIM_TypeDef * Instance*
- *LPTIM_InitTypeDef Init*
- *HAL_StatusTypeDef Status*
- *HAL_LockTypeDef Lock*
- *__IO HAL_LPTIM_StateTypeDef State*

Field Documentation

- *LPTIM_TypeDef* LPTIM_HandleTypeDef::Instance*
Register base address
- *LPTIM_InitTypeDef LPTIM_HandleTypeDef::Init*
LPTIM required parameters
- *HAL_StatusTypeDef LPTIM_HandleTypeDef::Status*
LPTIM peripheral status
- *HAL_LockTypeDef LPTIM_HandleTypeDef::Lock*
LPTIM locking object
- *__IO HAL_LPTIM_StateTypeDef LPTIM_HandleTypeDef::State*
LPTIM peripheral state

37.3 LPTIM Firmware driver API description

37.3.1 How to use this driver

The LPTIM HAL driver can be used as follows:

1. Initialize the LPTIM low level resources by implementing the HAL_LPTIM_MspInit():
 - a. Enable the LPTIM interface clock using `__LPTIMx_CLK_ENABLE()`.
 - b. In case of using interrupts (e.g. HAL_LPTIM_PWM_Start_IT()):
 - Configure the LPTIM interrupt priority using `HAL_NVIC_SetPriority()`.
 - Enable the LPTIM IRQ handler using `HAL_NVIC_EnableIRQ()`.
 - In LPTIM IRQ handler, call `HAL_LPTIM_IRQHandler()`.
2. Initialize the LPTIM HAL using `HAL_LPTIM_Init()`. This function configures mainly:
 - a. The instance: LPTIM1.
 - b. Clock: the counter clock.
 - Source : it can be either the ULPTIM input (IN1) or one of the internal clock; (APB, LSE, LSI or MSI).
 - Prescaler: select the clock divider.
 - c. UltraLowPowerClock : To be used only if the ULPTIM is selected as counter clock source.
 - Polarity: polarity of the active edge for the counter unit if the ULPTIM input is selected.
 - SampleTime: clock sampling time to configure the clock glitch filter.
 - d. Trigger: How the counter start.
 - Source: trigger can be software or one of the hardware triggers.
 - ActiveEdge : only for hardware trigger.
 - SampleTime : trigger sampling time to configure the trigger glitch filter.
 - e. OutputPolarity : 2 opposite polarities are possible.
 - f. UpdateMode: specifies whether the update of the autoreload and the compare values is done immediately or after the end of current period.
3. Six modes are available:

- a. PWM Mode: To generate a PWM signal with specified period and pulse, call HAL_LPTIM_PWM_Start() or HAL_LPTIM_PWM_Start_IT() for interruption mode.
 - b. One Pulse Mode: To generate pulse with specified width in response to a stimulus, call HAL_LPTIM_OnePulse_Start() or HAL_LPTIM_OnePulse_Start_IT() for interruption mode.
 - c. Set once Mode: In this mode, the output changes the level (from low level to high level if the output polarity is configured high, else the opposite) when a compare match occurs. To start this mode, call HAL_LPTIM_SetOnce_Start() or HAL_LPTIM_SetOnce_Start_IT() for interruption mode.
 - d. Encoder Mode: To use the encoder interface call HAL_LPTIM_Encoder_Start() or HAL_LPTIM_Encoder_Start_IT() for interruption mode.
 - e. Time out Mode: an active edge on one selected trigger input rests the counter. The first trigger event will start the timer, any successive trigger event will reset the counter and the timer will restart. To start this mode call HAL_LPTIM_TimeOut_Start_IT() or HAL_LPTIM_TimeOut_Start_IT() for interruption mode.
 - f. Counter Mode: counter can be used to count external events on the LPTIM Input1 or it can be used to count internal clock cycles. To start this mode, call HAL_LPTIM_Counter_Start() or HAL_LPTIM_Counter_Start_IT() for interruption mode.
4. User can stop any process by calling the corresponding API: HAL_LPTIM_Xxx_Stop() or HAL_LPTIM_Xxx_Stop_IT() if the process is already started in interruption mode.
5. Call HAL_LPTIM_DeInit() to deinitialize the LPTIM peripheral.

37.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the LPTIM according to the specified parameters in the LPTIM_InitTypeDef and creates the associated handle.
- DeInitialize the LPTIM peripheral.
- Initialize the LPTIM MSP.
- DeInitialize LPTIM MSP.

This section contains the following APIs:

- [***HAL_LPTIM_Init\(\)***](#)
- [***HAL_LPTIM_DeInit\(\)***](#)
- [***HAL_LPTIM_MspInit\(\)***](#)
- [***HAL_LPTIM_MspDeInit\(\)***](#)

37.3.3 LPTIM Start Stop operation functions

This section provides functions allowing to:

- Start the PWM mode.
- Stop the PWM mode.
- Start the One pulse mode.
- Stop the One pulse mode.
- Start the Set once mode.
- Stop the Set once mode.
- Start the Encoder mode.
- Stop the Encoder mode.
- Start the Timeout mode.
- Stop the Timeout mode.
- Start the Counter mode.

-
- Stop the Counter mode.

This section contains the following APIs:

- `HAL_LPTIM_PWM_Start()`
- `HAL_LPTIM_PWM_Stop()`
- `HAL_LPTIM_PWM_Start_IT()`
- `HAL_LPTIM_PWM_Stop_IT()`
- `HAL_LPTIM_OnePulse_Start()`
- `HAL_LPTIM_OnePulse_Stop()`
- `HAL_LPTIM_OnePulse_Start_IT()`
- `HAL_LPTIM_OnePulse_Stop_IT()`
- `HAL_LPTIM_SetOnce_Start()`
- `HAL_LPTIM_SetOnce_Stop()`
- `HAL_LPTIM_SetOnce_Start_IT()`
- `HAL_LPTIM_SetOnce_Stop_IT()`
- `HAL_LPTIM_Encoder_Start()`
- `HAL_LPTIM_Encoder_Stop()`
- `HAL_LPTIM_Encoder_Start_IT()`
- `HAL_LPTIM_Encoder_Stop_IT()`
- `HAL_LPTIM_TimeOut_Start()`
- `HAL_LPTIM_TimeOut_Stop()`
- `HAL_LPTIM_TimeOut_Start_IT()`
- `HAL_LPTIM_TimeOut_Stop_IT()`
- `HAL_LPTIM_Counter_Start()`
- `HAL_LPTIM_Counter_Stop()`
- `HAL_LPTIM_Counter_Start_IT()`
- `HAL_LPTIM_Counter_Stop_IT()`

37.3.4 LPTIM Read operation functions

This section provides LPTIM Reading functions.

- Read the counter value.
- Read the period (Auto-reload) value.
- Read the pulse (Compare) value.

This section contains the following APIs:

- `HAL_LPTIM_ReadCounter()`
- `HAL_LPTIM_ReadAutoReload()`
- `HAL_LPTIM_ReadCompare()`

37.3.5 LPTIM IRQ handler

This section provides LPTIM IRQ handler function.

This section contains the following APIs:

- `HAL_LPTIM_IRQHandler()`
- `HAL_LPTIM_CompareMatchCallback()`
- `HAL_LPTIM_AutoReloadMatchCallback()`
- `HAL_LPTIM_TriggerCallback()`
- `HAL_LPTIM_CompareWriteCallback()`
- `HAL_LPTIM_AutoReloadWriteCallback()`
- `HAL_LPTIM_DirectionUpCallback()`
- `HAL_LPTIM_DirectionDownCallback()`

37.3.6 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral.

This section contains the following APIs:

- [**HAL_LPTIM_GetState\(\)**](#)

37.3.7 HAL_LPTIM_Init

Function Name	HAL_StatusTypeDef HAL_LPTIM_Init (LPTIM_HandleTypeDef * hltim)
Function Description	Initializes the LPTIM according to the specified parameters in the LPTIM_InitTypeDef and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status

37.3.8 HAL_LPTIM_DeInit

Function Name	HAL_StatusTypeDef HAL_LPTIM_DeInit (LPTIM_HandleTypeDef * hltim)
Function Description	Deinitializes the LPTIM peripheral.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status

37.3.9 HAL_LPTIM_MspInit

Function Name	void HAL_LPTIM_MspInit (LPTIM_HandleTypeDef * hltim)
Function Description	Initializes the LPTIM MSP.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • None

37.3.10 HAL_LPTIM_MspDeInit

Function Name	void HAL_LPTIM_MspDeInit (LPTIM_HandleTypeDef * hltim)
Function Description	Deinitializes LPTIM MSP.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • None

37.3.11 HAL_LPTIM_PWM_Start

Function Name	HAL_StatusTypeDef HAL_LPTIM_PWM_Start (LPTIM_HandleTypeDef * hltim, uint32_t Period, uint32_t Pulse)
Function Description	Starts the LPTIM PWM generation.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF. • Pulse: : Specifies the compare value. This parameter must

be a value between 0x0000 and 0xFFFF.

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

37.3.12 HAL_LPTIM_PWM_Stop

Function Name	HAL_StatusTypeDef HAL_LPTIM_PWM_Stop (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the LPTIM PWM generation.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status

37.3.13 HAL_LPTIM_PWM_Start_IT

Function Name	HAL_StatusTypeDef HAL_LPTIM_PWM_Start_IT (LPTIM_HandleTypeDef * hltim, uint32_t Period, uint32_t Pulse)
Function Description	Starts the LPTIM PWM generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF • Pulse: : Specifies the compare value. This parameter must be a value between 0x0000 and 0xFFFF
Return values	<ul style="list-style-type: none"> • HAL status

37.3.14 HAL_LPTIM_PWM_Stop_IT

Function Name	HAL_StatusTypeDef HAL_LPTIM_PWM_Stop_IT (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the LPTIM PWM generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status

37.3.15 HAL_LPTIM_OnePulse_Start

Function Name	HAL_StatusTypeDef HAL_LPTIM_OnePulse_Start (LPTIM_HandleTypeDef * hltim, uint32_t Period, uint32_t Pulse)
Function Description	Starts the LPTIM One pulse generation.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF. • Pulse: : Specifies the compare value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status

37.3.16 HAL_LPTIM_OnePulse_Stop

Function Name	HAL_StatusTypeDef HAL_LPTIM_OnePulse_Stop (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the LPTIM One pulse generation.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status
37.3.17 HAL_LPTIM_OnePulse_Start_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_OnePulse_Start_IT (LPTIM_HandleTypeDef * hltim, uint32_t Period, uint32_t Pulse)
Function Description	Starts the LPTIM One pulse generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF. • Pulse: : Specifies the compare value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status
37.3.18 HAL_LPTIM_OnePulse_Stop_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_OnePulse_Stop_IT (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the LPTIM One pulse generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status
37.3.19 HAL_LPTIM_SetOnce_Start	
Function Name	HAL_StatusTypeDef HAL_LPTIM_SetOnce_Start (LPTIM_HandleTypeDef * hltim, uint32_t Period, uint32_t Pulse)
Function Description	Starts the LPTIM in Set once mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF. • Pulse: : Specifies the compare value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status
37.3.20 HAL_LPTIM_SetOnce_Stop	
Function Name	HAL_StatusTypeDef HAL_LPTIM_SetOnce_Stop (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the LPTIM Set once mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle

Return values	<ul style="list-style-type: none"> • HAL status
37.3.21 HAL_LPTIM_SetOnce_Start_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_SetOnce_Start_IT (LPTIM_HandleTypeDef * hltim, uint32_t Period, uint32_t Pulse)
Function Description	Starts the LPTIM Set once mode in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF. • Pulse: : Specifies the compare value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status
37.3.22 HAL_LPTIM_SetOnce_Stop_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_SetOnce_Stop_IT (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the LPTIM Set once mode in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status
37.3.23 HAL_LPTIM_Encoder_Start	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Encoder_Start (LPTIM_HandleTypeDef * hltim, uint32_t Period)
Function Description	Starts the Encoder interface.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status
37.3.24 HAL_LPTIM_Encoder_Stop	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Encoder_Stop (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the Encoder interface.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status
37.3.25 HAL_LPTIM_Encoder_Start_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Encoder_Start_IT (LPTIM_HandleTypeDef * hltim, uint32_t Period)
Function Description	Starts the Encoder interface in interrupt mode.

Parameters	<ul style="list-style-type: none"> hlptim: : LPTIM handle Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> HAL status

37.3.26 HAL_LPTIM_Encoder_Stop_IT

Function Name **HAL_StatusTypeDef HAL_LPTIM_Encoder_Stop_IT
(LPTIM_HandleTypeDef * hlptim)**

Function Description Stops the Encoder interface in interrupt mode.

Parameters

- hlptim:** : LPTIM handle

Return values

- HAL status

37.3.27 HAL_LPTIM_TimeOut_Start

Function Name **HAL_StatusTypeDef HAL_LPTIM_TimeOut_Start
(LPTIM_HandleTypeDef * hlptim, uint32_t Period, uint32_t
Timeout)**

Function Description Starts the Timeout function.

Parameters

- hlptim:** : LPTIM handle
- Period:** : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF.
- Timeout:** : Specifies the TimeOut value to rest the counter. This parameter must be a value between 0x0000 and 0xFFFF.

Return values

- HAL status

37.3.28 HAL_LPTIM_TimeOut_Stop

Function Name **HAL_StatusTypeDef HAL_LPTIM_TimeOut_Stop
(LPTIM_HandleTypeDef * hlptim)**

Function Description Stops the Timeout function.

Parameters

- hlptim:** : LPTIM handle

Return values

- HAL status

37.3.29 HAL_LPTIM_TimeOut_Start_IT

Function Name **HAL_StatusTypeDef HAL_LPTIM_TimeOut_Start_IT
(LPTIM_HandleTypeDef * hlptim, uint32_t Period, uint32_t
Timeout)**

Function Description Starts the Timeout function in interrupt mode.

Parameters

- hlptim:** : LPTIM handle
- Period:** : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF.
- Timeout:** : Specifies the TimeOut value to rest the counter. This parameter must be a value between 0x0000 and 0xFFFF.

Return values	<ul style="list-style-type: none"> • HAL status
37.3.30 HAL_LPTIM_TimeOut_Stop_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_TimeOut_Stop_IT (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the Timeout function in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status
37.3.31 HAL_LPTIM_Counter_Start	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Counter_Start (LPTIM_HandleTypeDef * hltim, uint32_t Period)
Function Description	Starts the Counter mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status
37.3.32 HAL_LPTIM_Counter_Stop	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Counter_Stop (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the Counter mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status
37.3.33 HAL_LPTIM_Counter_Start_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Counter_Start_IT (LPTIM_HandleTypeDef * hltim, uint32_t Period)
Function Description	Starts the Counter mode in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle • Period: : Specifies the Autoreload value. This parameter must be a value between 0x0000 and 0xFFFF.
Return values	<ul style="list-style-type: none"> • HAL status
37.3.34 HAL_LPTIM_Counter_Stop_IT	
Function Name	HAL_StatusTypeDef HAL_LPTIM_Counter_Stop_IT (LPTIM_HandleTypeDef * hltim)
Function Description	Stops the Counter mode in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL status

37.3.35 HAL_LPTIM_ReadCounter

Function Name	<code>uint32_t HAL_LPTIM_ReadCounter (LPTIM_HandleTypeDef * hltim)</code>
Function Description	This function returns the current counter value.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • Counter value.

37.3.36 HAL_LPTIM_ReadAutoReload

Function Name	<code>uint32_t HAL_LPTIM_ReadAutoReload (LPTIM_HandleTypeDef * hltim)</code>
Function Description	This function return the current Autoreload (Period) value.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • Autoreload value.

37.3.37 HAL_LPTIM_ReadCompare

Function Name	<code>uint32_t HAL_LPTIM_ReadCompare (LPTIM_HandleTypeDef * hltim)</code>
Function Description	This function return the current Compare (Pulse) value.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • Compare value.

37.3.38 HAL_LPTIM_IRQHandler

Function Name	<code>void HAL_LPTIM_IRQHandler (LPTIM_HandleTypeDef * hltim)</code>
Function Description	This function handles LPTIM interrupt request.
Parameters	<ul style="list-style-type: none"> • hltim: LPTIM handle
Return values	<ul style="list-style-type: none"> • None

37.3.39 HAL_LPTIM_CompareMatchCallback

Function Name	<code>void HAL_LPTIM_CompareMatchCallback (LPTIM_HandleTypeDef * hltim)</code>
Function Description	Compare match callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hltim: : LPTIM handle
Return values	<ul style="list-style-type: none"> • None

37.3.40 HAL_LPTIM_AutoReloadMatchCallback

Function Name	<code>void HAL_LPTIM_AutoReloadMatchCallback (LPTIM_HandleTypeDef * hltim)</code>
Function Description	Autoreload match callback in non blocking mode.

Parameters	<ul style="list-style-type: none">• hlptim: : LPTIM handle
Return values	<ul style="list-style-type: none">• None

37.3.41 HAL_LPTIM_TriggerCallback

Function Name	void HAL_LPTIM_TriggerCallback (LPTIM_HandleTypeDef * hlptim)
Function Description	Trigger detected callback in non blocking mode.
Parameters	<ul style="list-style-type: none">• hlptim: : LPTIM handle
Return values	<ul style="list-style-type: none">• None

37.3.42 HAL_LPTIM_CompareWriteCallback

Function Name	void HAL_LPTIM_CompareWriteCallback (LPTIM_HandleTypeDef * hlptim)
Function Description	Compare write callback in non blocking mode.
Parameters	<ul style="list-style-type: none">• hlptim: : LPTIM handle
Return values	<ul style="list-style-type: none">• None

37.3.43 HAL_LPTIM_AutoReloadWriteCallback

Function Name	void HAL_LPTIM_AutoReloadWriteCallback (LPTIM_HandleTypeDef * hlptim)
Function Description	Autoreload write callback in non blocking mode.
Parameters	<ul style="list-style-type: none">• hlptim: : LPTIM handle
Return values	<ul style="list-style-type: none">• None

37.3.44 HAL_LPTIM_DirectionUpCallback

Function Name	void HAL_LPTIM_DirectionUpCallback (LPTIM_HandleTypeDef * hlptim)
Function Description	Direction counter changed from Down to Up callback in non blocking mode.
Parameters	<ul style="list-style-type: none">• hlptim: : LPTIM handle
Return values	<ul style="list-style-type: none">• None

37.3.45 HAL_LPTIM_DirectionDownCallback

Function Name	void HAL_LPTIM_DirectionDownCallback (LPTIM_HandleTypeDef * hlptim)
Function Description	Direction counter changed from Up to Down callback in non blocking mode.
Parameters	<ul style="list-style-type: none">• hlptim: : LPTIM handle
Return values	<ul style="list-style-type: none">• None

37.3.46 HAL_LPTIM_GetState

Function Name	<code>HAL_LPTIM_StateTypeDef HAL_LPTIM_GetState (LPTIM_HandleTypeDef * hltim)</code>
Function Description	Returns the LPTIM state.
Parameters	<ul style="list-style-type: none"> • <code>hltim</code>: LPTIM handle
Return values	<ul style="list-style-type: none"> • HAL state

37.4 LPTIM Firmware driver defines

37.4.1 LPTIM

LPTIM Clock Polarity

`LPTIM_CLOCKPOLARITY_RISING`
`LPTIM_CLOCKPOLARITY_FALLING`
`LPTIM_CLOCKPOLARITY_RISING_FALLING`

LPTIM Clock Prescaler

`LPTIM_PRESCALER_DIV1`
`LPTIM_PRESCALER_DIV2`
`LPTIM_PRESCALER_DIV4`
`LPTIM_PRESCALER_DIV8`
`LPTIM_PRESCALER_DIV16`
`LPTIM_PRESCALER_DIV32`
`LPTIM_PRESCALER_DIV64`
`LPTIM_PRESCALER_DIV128`

LPTIM Clock Sample Time

`LPTIM_CLOCKSAMPLETIME_DIRECTTRANSITION`
`LPTIM_CLOCKSAMPLETIME_2TRANSITIONS`
`LPTIM_CLOCKSAMPLETIME_4TRANSITIONS`
`LPTIM_CLOCKSAMPLETIME_8TRANSITIONS`

LPTIM Clock Source

`LPTIM_CLOCKSOURCE_APBCLOCK_LPOSC`
`LPTIM_CLOCKSOURCE_ULPTIM`

LPTIM Counter Source

`LPTIM_COUNTERSOURCE_INTERNAL`
`LPTIM_COUNTERSOURCE_EXTERNAL`

LPTIM Exported Macros

<code>_HAL_LPTIM_RESET_HANDLE_STATE</code>	Description:
	<ul style="list-style-type: none"> • Reset LPTIM handle

state.

Parameters:

- `__HANDLE__`: LPTIM handle

Return value:

- None

Description:

- Enable/Disable the LPTIM peripheral.

Parameters:

- `__HANDLE__`: LPTIM handle

Return value:

- None

`__HAL_LPTIM_ENABLE`

`__HAL_LPTIM_DISABLE`

`__HAL_LPTIM_START_CONTINUOUS`

Description:

- Starts the LPTIM peripheral in Continuous or in single mode.

Parameters:

- `__HANDLE__`: DMA handle

Return value:

- None

`__HAL_LPTIM_START_SINGLE`

`__HAL_LPTIM_AUTORELOAD_SET`

Description:

- Writes the passed parameter in the Autoreload register.

Parameters:

- `__HANDLE__`: LPTIM handle
- `__VALUE__`: Autoreload value

Return value:

- None

`__HAL_LPTIM_COMPARE_SET`

Description:

- Writes the passed parameter in the Compare register.

Parameters:

- `__HANDLE__`: LPTIM handle
- `__VALUE__`: Compare value

Return value:

- None

Description:

- Checks whether the specified LPTIM flag is set or not.

Parameters:

- `__HANDLE__`: LPTIM handle
- `__FLAG__`: LPTIM flag to check This parameter can be a value of:
 - `LPTIM_FLAG_DO_WN` : Counter direction change up Flag.
 - `LPTIM_FLAG_UP` : Counter direction change down to up Flag.
 - `LPTIM_FLAG_ARR_OK` : Autoreload register update OK Flag.
 - `LPTIM_FLAG_CMP_OK` : Compare register update OK Flag.
 - `LPTIM_FLAG_EXT_TRIG` : External trigger edge event Flag.
 - `LPTIM_FLAG_ARR_M` : Autoreload match Flag.
 - `LPTIM_FLAG_CMP_M` : Compare match Flag.

Return value:

- The state of the specified flag (SET or RESET).

`__HAL_LPTIM_CLEAR_FLAG`**Description:**

- Clears the specified

LPTIM flag.

Parameters:

- `__HANDLE__`: LPTIM handle.
- `__FLAG__`: LPTIM flag to clear. This parameter can be a value of:
 - `LPTIM_FLAG_DO_WN` : Counter direction change up Flag.
 - `LPTIM_FLAG_UP` : Counter direction change down to up Flag.
 - `LPTIM_FLAG_ARR_OK` : Autoreload register update OK Flag.
 - `LPTIM_FLAG_CMP_OK` : Compare register update OK Flag.
 - `LPTIM_FLAG_EXT_TRIG` : External trigger edge event Flag.
 - `LPTIM_FLAG_ARR_M` : Autoreload match Flag.
 - `LPTIM_FLAG_CMP_M` : Compare match Flag.

Return value:

- None.

`__HAL_LPTIM_ENABLE_IT`

Description:

- Enable the specified LPTIM interrupt.

Parameters:

- `__HANDLE__`: LPTIM handle.
- `__INTERRUPT__`: LPTIM interrupt to set. This parameter can be a value of:
 - `LPTIM_IT_DOWN` : Counter direction change up Interrupt.
 - `LPTIM_IT_UP` : Counter direction

- change down to up Interrupt.
- LPTIM_IT_ARROK : Autoreload register update OK Interrupt.
- LPTIM_IT_CMPOK : Compare register update OK Interrupt.
- LPTIM_IT_EXTTRIG : External trigger edge event Interrupt.
- LPTIM_IT_ARRM : Autoreload match Interrupt.
- LPTIM_IT_CMPM : Compare match Interrupt.

Return value:

- None.

__HAL_LPTIM_DISABLE_IT**Description:**

- Disable the specified LPTIM interrupt.

Parameters:

- __HANDLE__: LPTIM handle.
- __INTERRUPT__: LPTIM interrupt to set. This parameter can be a value of:
 - LPTIM_IT_DOWN : Counter direction change up Interrupt.
 - LPTIM_IT_UP : Counter direction change down to up Interrupt.
 - LPTIM_IT_ARROK : Autoreload register update OK Interrupt.
 - LPTIM_IT_CMPOK : Compare register update OK Interrupt.
 - LPTIM_IT_EXTTRIG : External trigger edge event Interrupt.
 - LPTIM_IT_ARRM :

- Autoreload match Interrupt.
- LPTIM_IT_CMPPM : Compare match Interrupt.

Return value:

- None.

`_HAL_LPTIM_GET_IT_SOURCE`

Description:

- Checks whether the specified LPTIM interrupt is set or not.

Parameters:

- `_HANDLE_` : LPTIM handle.
- `_INTERRUPT_` : LPTIM interrupt to check. This parameter can be a value of:
 - LPTIM_IT_DOWN : Counter direction change up Interrupt.
 - LPTIM_IT_UP : Counter direction change down to up Interrupt.
 - LPTIM_IT_ARROK : Autoreload register update OK Interrupt.
 - LPTIM_IT_CMPOK : Compare register update OK Interrupt.
 - LPTIM_IT_EXTTRIG : External trigger edge event Interrupt.
 - LPTIM_IT_ARRM : Autoreload match Interrupt.
 - LPTIM_IT_CMPPM : Compare match Interrupt.

Return value:

- Interrupt: status.

`_HAL_LPTIM_OPTR_CONFIG`

Description:

- LPTIM Option Register.

Parameters:

- `__HANDLE__`: LPTIM handle
- `__VALUE__`: This parameter can be a value of :
 - `LPTIM_OP_PAD_A_F`
 - `LPTIM_OP_PAD_P_A4`
 - `LPTIM_OP_PAD_P_B9`
 - `LPTIM_OP_TIM_D_AC`

Return value:

- None

Description:

- Enable interrupt on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None

Description:

- Disable interrupt on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None

Description:

- Enable event on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable event on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Enable falling edge trigger on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable falling edge trigger on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Enable rising edge trigger on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable rising edge trigger on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Enable rising & falling edge trigger on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable rising & falling edge trigger on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Check whether the LPTIM Wake-up Timer associated Exti line interrupt flag is set or

not.

Return value:

- Line: Status.

`__HAL_LPTIM_WAKEUPTIMER_EXTI_CLEAR_FLAG`

Description:

- Clear the LPTIM Wake-up Timer associated Exti line flag.

Return value:

- None.

`__HAL_LPTIM_WAKEUPTIMER_EXTI_GENERATE_SWI`

Description:

- Generate a Software interrupt on the LPTIM Wake-up Timer associated Exti line.

Return value:

- None.

LPTIM External Trigger Polarity

`LPTIM_ACTIVEEDGE_RISING`

`LPTIM_ACTIVEEDGE_FALLING`

`LPTIM_ACTIVEEDGE_RISING_FALLING`

LPTIM Flag Definition

`LPTIM_FLAG_DOWN`

`LPTIM_FLAG_UP`

`LPTIM_FLAG_ARROK`

`LPTIM_FLAG_CMPOK`

`LPTIM_FLAG_EXTTRIG`

`LPTIM_FLAG_ARRM`

`LPTIM_FLAG_CMPM`

LPTIM Interrupts Definition

`LPTIM_IT_DOWN`

`LPTIM_IT_UP`

`LPTIM_IT_ARROK`

`LPTIM_IT_CMPOK`

`LPTIM_IT_EXTTRIG`

`LPTIM_IT_ARRM`

`LPTIM_IT_CMPM`

Register Definition

`LPTIM_OP_PAD_AF`

LPTIM_OP_PAD_PA4
LPTIM_OP_PAD_PB9
LPTIM_OP_TIM_DAC
LPTIM Output Polarity
LPTIM_OUTPUTPOLARITY_HIGH
LPTIM_OUTPUTPOLARITY_LOW
LPTIM Private Macros
IS_LPTIM_CLOCK_SOURCE
IS_LPTIM_CLOCK_PRESCALER
IS_LPTIM_CLOCK_PRESCALERDIV1
IS_LPTIM_OUTPUT_POLARITY
IS_LPTIM_CLOCK_SAMPLE_TIME
IS_LPTIM_CLOCK_POLARITY
IS_LPTIM_TRG_SOURCE
IS_LPTIM_EXT_TRG_POLARITY
IS_LPTIM_TRIG_SAMPLE_TIME
IS_LPTIM_UPDATE_MODE
IS_LPTIM_COUNTER_SOURCE
IS_LPTIM_AUTORELOAD
IS_LPTIM_COMPARE
IS_LPTIM_PERIOD
IS_LPTIM_PULSE
LPTIM Trigger Sample Time
LPTIM_TRIGSAMPLETIME_DIRECTTRANSITION
LPTIM_TRIGSAMPLETIME_2TRANSITIONS
LPTIM_TRIGSAMPLETIME_4TRANSITIONS
LPTIM_TRIGSAMPLETIME_8TRANSITIONS
LPTIM Trigger Source
LPTIM_TRIGSOURCE_SOFTWARE
LPTIM_TRIGSOURCE_0
LPTIM_TRIGSOURCE_1
LPTIM_TRIGSOURCE_2
LPTIM_TRIGSOURCE_3
LPTIM_TRIGSOURCE_4
LPTIM_TRIGSOURCE_5
LPTIM Updating Mode

LPTIM_UPDATE_IMMEDIATE

LPTIM_UPDATE_ENDOFPERIOD

LPTIM WAKEUP Timer EXTI Line

LPTIM_EXTI_LINE_WAKEUPTIMER_EVENT External interrupt line 23 Connected to the
LPTIM EXTI Line

38 HAL LTDC Generic Driver

38.1 HAL LTDC Generic Driver

38.2 LTDC Firmware driver registers structures

38.2.1 LTDC_ColorTypeDef

Data Fields

- *uint8_t Blue*
- *uint8_t Green*
- *uint8_t Red*
- *uint8_t Reserved*

Field Documentation

- ***uint8_t LTDC_ColorTypeDef::Blue***
Configures the blue value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint8_t LTDC_ColorTypeDef::Green***
Configures the green value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint8_t LTDC_ColorTypeDef::Red***
Configures the red value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint8_t LTDC_ColorTypeDef::Reserved***
Reserved 0xFF

38.2.2 LTDC_InitTypeDef

Data Fields

- *uint32_t HSPolarity*
- *uint32_t VSPolarity*
- *uint32_t DEPolarity*
- *uint32_t PCPPolarity*
- *uint32_t HorizontalSync*
- *uint32_t VerticalSync*
- *uint32_t AccumulatedHBP*
- *uint32_t AccumulatedVBP*
- *uint32_t AccumulatedActiveW*
- *uint32_t AccumulatedActiveH*
- *uint32_t TotalWidth*
- *uint32_t TotalHeigh*
- *LTDC_ColorTypeDef Backcolor*

Field Documentation

- ***uint32_t LTDC_InitTypeDef::HSPolarity***
configures the horizontal synchronization polarity. This parameter can be one value of ***LTDC_HS_POLARITY***
- ***uint32_t LTDC_InitTypeDef::VSPolarity***
configures the vertical synchronization polarity. This parameter can be one value of ***LTDC_VS_POLARITY***
- ***uint32_t LTDC_InitTypeDef::DEPolarity***
configures the data enable polarity. This parameter can be one of value of ***LTDC_DE_POLARITY***
- ***uint32_t LTDC_InitTypeDef::PCPolarity***
configures the pixel clock polarity. This parameter can be one of value of ***LTDC_PC_POLARITY***
- ***uint32_t LTDC_InitTypeDef::HorizontalSync***
configures the number of Horizontal synchronization width. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0xFFFF.
- ***uint32_t LTDC_InitTypeDef::VerticalSync***
configures the number of Vertical synchronization height. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0x7FF.
- ***uint32_t LTDC_InitTypeDef::AccumulatedHBP***
configures the accumulated horizontal back porch width. This parameter must be a number between Min_Data = LTDC_HorizontalSync and Max_Data = 0xFFFF.
- ***uint32_t LTDC_InitTypeDef::AccumulatedVBP***
configures the accumulated vertical back porch height. This parameter must be a number between Min_Data = LTDC_VerticalSync and Max_Data = 0x7FF.
- ***uint32_t LTDC_InitTypeDef::AccumulatedActiveW***
configures the accumulated active width. This parameter must be a number between Min_Data = LTDC_AccumulatedHBP and Max_Data = 0xFFFF.
- ***uint32_t LTDC_InitTypeDef::AccumulatedActiveH***
configures the accumulated active height. This parameter must be a number between Min_Data = LTDC_AccumulatedVBP and Max_Data = 0x7FF.
- ***uint32_t LTDC_InitTypeDef::TotalWidth***
configures the total width. This parameter must be a number between Min_Data = LTDC_AccumulatedActiveW and Max_Data = 0xFFFF.
- ***uint32_t LTDC_InitTypeDef::TotalHeight***
configures the total height. This parameter must be a number between Min_Data = LTDC_AccumulatedActiveH and Max_Data = 0x7FF.
- ***LTDC_ColorTypeDef LTDC_InitTypeDef::Backcolor***
Configures the background color.

38.2.3 LTDC_LayerCfgTypeDef

Data Fields

- ***uint32_t WindowX0***
- ***uint32_t WindowX1***
- ***uint32_t WindowY0***
- ***uint32_t WindowY1***
- ***uint32_t PixelFormat***
- ***uint32_t Alpha***
- ***uint32_t Alpha0***
- ***uint32_t BlendingFactor1***

-
- *uint32_t BlendingFactor2*
 - *uint32_t FBStartAdress*
 - *uint32_t ImageWidth*
 - *uint32_t ImageHeight*
 - *LTDC_ColorTypeDef Backcolor*

Field Documentation

- ***uint32_t LTDC_LayerCfgTypeDef::WindowX0***
Configures the Window Horizontal Start Position. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0xFFFF.
- ***uint32_t LTDC_LayerCfgTypeDef::WindowX1***
Configures the Window Horizontal Stop Position. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0xFFFF.
- ***uint32_t LTDC_LayerCfgTypeDef::WindowY0***
Configures the Window vertical Start Position. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0xFFFF.
- ***uint32_t LTDC_LayerCfgTypeDef::WindowY1***
Configures the Window vertical Stop Position. This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF.
- ***uint32_t LTDC_LayerCfgTypeDef::PixelFormat***
Specifies the pixel format. This parameter can be one of value of [**LTDC_Pixelformat**](#)
- ***uint32_t LTDC_LayerCfgTypeDef::Alpha***
Specifies the constant alpha used for blending. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint32_t LTDC_LayerCfgTypeDef::Alpha0***
Configures the default alpha value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
- ***uint32_t LTDC_LayerCfgTypeDef::BlendingFactor1***
Select the blending factor 1. This parameter can be one of value of [**LTDC_BlendingFactor1**](#)
- ***uint32_t LTDC_LayerCfgTypeDef::BlendingFactor2***
Select the blending factor 2. This parameter can be one of value of [**LTDC_BlendingFactor2**](#)
- ***uint32_t LTDC_LayerCfgTypeDef::FBStartAdress***
Configures the color frame buffer address
- ***uint32_t LTDC_LayerCfgTypeDef::ImageWidth***
Configures the color frame buffer line length. This parameter must be a number between Min_Data = 0x0000 and Max_Data = 0x1FFF.
- ***uint32_t LTDC_LayerCfgTypeDef::ImageHeight***
Specifies the number of line in frame buffer. This parameter must be a number between Min_Data = 0x000 and Max_Data = 0x7FF.
- ***LTDC_ColorTypeDef LTDC_LayerCfgTypeDef::Backcolor***
Configures the layer background color.

38.2.4 LTDC_HandleTypeDef

Data Fields

- *LTDC_TypeDef * Instance*
- *LTDC_InitTypeDef Init*
- *LTDC_LayerCfgTypeDef LayerCfg*

-
- ***HAL_LockTypeDef Lock***
 - ***_IO HAL_LTDC_StateTypeDef State***
 - ***_IO uint32_t ErrorCode***

Field Documentation

- ***LTDC_TypeDef* LTDC_HandleTypeDef::Instance***
LTDC Register base address
- ***LTDC_InitTypeDef LTDC_HandleTypeDef::Init***
LTDC parameters
- ***LTDC_LayerCfgTypeDef LTDC_HandleTypeDef::LayerCfg[MAX_LAYER]***
LTDC Layers parameters
- ***HAL_LockTypeDef LTDC_HandleTypeDef::Lock***
LTDC Lock
- ***_IO HAL_LTDC_StateTypeDef LTDC_HandleTypeDef::State***
LTDC state
- ***_IO uint32_t LTDC_HandleTypeDef::ErrorCode***
LTDC Error code

38.3 LTDC Firmware driver API description

38.3.1 How to use this driver

1. Program the required configuration through the following parameters: the LTDC timing, the horizontal and vertical polarity, the pixel clock polarity, Data Enable polarity and the LTDC background color value using `HAL_LTDC_Init()` function
2. Program the required configuration through the following parameters: the pixel format, the blending factors, input alpha value, the window size and the image size using `HAL_LTDC_ConfigLayer()` function for foreground or/and background layer.
3. Optionally, configure and enable the CLUT using `HAL_LTDC_ConfigCLUT()` and `HAL_LTDC_EnableCLUT` functions.
4. Optionally, enable the Dither using `HAL_LTDC_EnableDither()`.
5. Optionally, configure and enable the Color keying using `HAL_LTDC_ConfigColorKeying()` and `HAL_LTDC_EnableColorKeying` functions.
6. Optionally, configure LineInterrupt using `HAL_LTDC_ProgramLineEvent()` function
7. If needed, reconfigure and change the pixel format value, the alpha value value, the window size, the window position and the layer start address for foreground or/and background layer using respectively the following functions:
`HAL_LTDC_SetPixelFormat()`, `HAL_LTDC_SetAlpha()`,
`HAL_LTDC_SetWindowSize()`, `HAL_LTDC_SetWindowPosition()`,
`HAL_LTDC_SetAddress`.
8. To control LTDC state you can use the following function: `HAL_LTDC_GetState()`

LTDC HAL driver macros list

Below the list of most used macros in LTDC HAL driver.

- `_HAL_LTDC_ENABLE`: Enable the LTDC.
- `_HAL_LTDC_DISABLE`: Disable the LTDC.
- `_HAL_LTDC_LAYER_ENABLE`: Enable the LTDC Layer.
- `_HAL_LTDC_LAYER_DISABLE`: Disable the LTDC Layer.
- `_HAL_LTDC_RELOAD_CONFIG`: Reload Layer Configuration.

- `_HAL_LTDC_GET_FLAG`: Get the LTDC pending flags.
- `_HAL_LTDC_CLEAR_FLAG`: Clear the LTDC pending flags.
- `_HAL_LTDC_ENABLE_IT`: Enable the specified LTDC interrupts.
- `_HAL_LTDC_DISABLE_IT`: Disable the specified LTDC interrupts.
- `_HAL_LTDC_GET_IT_SOURCE`: Check whether the specified LTDC interrupt has occurred or not.



You can refer to the LTDC HAL driver header file for more useful macros

38.3.2 Initialization and Configuration functions

This section provides functions allowing to:

- Initialize and configure the LTDC
- De-initialize the LTDC

This section contains the following APIs:

- `HAL_LTDC_Init()`
- `HAL_LTDC_DelInit()`
- `HAL_LTDC_MspInit()`
- `HAL_LTDC_MspDelInit()`
- `HAL_LTDC_ErrorCallback()`
- `HAL_LTDC_LineEventCallback()`

38.3.3 IO operation functions

This section provides function allowing to:

- Handle LTDC interrupt request

This section contains the following APIs:

- `HAL_LTDC_IRQHandler()`
- `HAL_LTDC_ErrorCallback()`
- `HAL_LTDC_LineEventCallback()`

38.3.4 Peripheral Control functions

This section provides functions allowing to:

- Configure the LTDC foreground or/and background parameters.
- Set the active layer.
- Configure the color keying.
- Configure the C-LUT.
- Enable / Disable the color keying.
- Enable / Disable the C-LUT.
- Update the layer position.
- Update the layer size.
- Update pixel format on the fly.
- Update transparency on the fly.
- Update address on the fly.

This section contains the following APIs:

- `HAL_LTDC_ConfigLayer()`

- `HAL_LTDC_ConfigColorKeying()`
- `HAL_LTDC_ConfigCLUT()`
- `HAL_LTDC_EnableColorKeying()`
- `HAL_LTDC_DisableColorKeying()`
- `HAL_LTDC_EnableCLUT()`
- `HAL_LTDC_DisableCLUT()`
- `HAL_LTDC_EnableDither()`
- `HAL_LTDC_DisableDither()`
- `HAL_LTDC_SetWindowSize()`
- `HAL_LTDC_SetWindowPosition()`
- `HAL_LTDC_SetPixelFormat()`
- `HAL_LTDC_SetAlpha()`
- `HAL_LTDC_SetAddress()`
- `HAL_LTDC_SetPitch()`
- `HAL_LTDC_ProgramLineEvent()`

38.3.5 Peripheral State and Errors functions

This subsection provides functions allowing to

- Check the LTDC state.
- Get error code.

This section contains the following APIs:

- `HAL_LTDC_GetState()`
- `HAL_LTDC_GetError()`

38.3.6 HAL_LTDC_Init

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_Init (LTDC_HandleTypeDef * hltc)</code>
Function Description	Initializes the LTDC according to the specified parameters in the <code>LTDC_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a <code>LTDC_HandleTypeDef</code> structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • HAL status

38.3.7 HAL_LTDC_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_DelInit (LTDC_HandleTypeDef * hltc)</code>
Function Description	Deinitializes the LTDC peripheral registers to their default reset values.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a <code>LTDC_HandleTypeDef</code> structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.8 HAL_LTDC_MspInit

Function Name	<code>void HAL_LTDC_MspInit (LTDC_HandleTypeDef * hltc)</code>
Function Description	Initializes the LTDC MSP.

Parameters	<ul style="list-style-type: none"> • hltc: : pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.9 HAL_LTDC_MspDeInit

Function Name	void HAL_LTDC_MspDeInit (LTDC_HandleTypeDef * hltc)
Function Description	DeInitializes the LTDC MSP.
Parameters	<ul style="list-style-type: none"> • hltc: : pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.10 HAL_LTDC_ErrorCallback

Function Name	void HAL_LTDC_ErrorCallback (LTDC_HandleTypeDef * hltc)
Function Description	Error LTDC callback.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.11 HAL_LTDC_LineEventCallback

Function Name	void HAL_LTDC_LineEventCallback (LTDC_HandleTypeDef * hltc)
Function Description	Line Event callback.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.12 HAL_LTDC_IRQHandler

Function Name	void HAL_LTDC_IRQHandler (LTDC_HandleTypeDef * hltc)
Function Description	Handles LTDC interrupt request.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • HAL status

38.3.13 HAL_LTDC_ErrorCallback

Function Name	void HAL_LTDC_ErrorCallback (LTDC_HandleTypeDef * hltc)
Function Description	Error LTDC callback.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.14 HAL_LTDC_LineEventCallback

Function Name	<code>void HAL_LTDC_LineEventCallback (LTDC_HandleTypeDef * hltc)</code>
Function Description	Line Event callback.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • None

38.3.15 HAL_LTDC_ConfigLayer

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_ConfigLayer (LTDC_HandleTypeDef * hltc, LTDC_LayerCfgTypeDef * pLayerCfg, uint32_t LayerIdx)</code>
Function Description	Configure the LTDC Layer according to the specified parameters in the LTDC_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • pLayerCfg: pointer to a LTDC_LayerCfgTypeDef structure that contains the configuration information for the Layer. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.16 HAL_LTDC_ConfigColorKeying

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_ConfigColorKeying (LTDC_HandleTypeDef * hltc, uint32_t RGBValue, uint32_t LayerIdx)</code>
Function Description	Configure the color keying.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • RGBValue: the color key value • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.17 HAL_LTDC_ConfigCLUT

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_ConfigCLUT (LTDC_HandleTypeDef * hltc, uint32_t * pCLUT, uint32_t CLUTSize, uint32_t LayerIdx)</code>
Function Description	Load the color lookup table.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • pCLUT: pointer to the color lookup table address. • CLUTSize: the color lookup table size. • LayerIdx: LTDC Layer index. This parameter can be one of

the following values: 0 or 1

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

38.3.18 HAL_LTDC_EnableColorKeying

Function Name	HAL_StatusTypeDef HAL_LTDC_EnableColorKeying (LTDC_HandleTypeDef * hltc, uint32_t LayerIdx)
Function Description	Enable the color keying.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.19 HAL_LTDC_DisableColorKeying

Function Name	HAL_StatusTypeDef HAL_LTDC_DisableColorKeying (LTDC_HandleTypeDef * hltc, uint32_t LayerIdx)
Function Description	Disable the color keying.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.20 HAL_LTDC_EnableCLUT

Function Name	HAL_StatusTypeDef HAL_LTDC_EnableCLUT (LTDC_HandleTypeDef * hltc, uint32_t LayerIdx)
Function Description	Enable the color lookup table.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.21 HAL_LTDC_DisableCLUT

Function Name	HAL_StatusTypeDef HAL_LTDC_DisableCLUT (LTDC_HandleTypeDef * hltc, uint32_t LayerIdx)
Function Description	Disable the color lookup table.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.22 HAL_LTDC_EnableDither

Function Name	HAL_StatusTypeDef HAL_LTDC_EnableDither (LTDC_HandleTypeDef * hltc)
Function Description	Enables Dither.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • HAL status

38.3.23 HAL_LTDC_DisableDither

Function Name	HAL_StatusTypeDef HAL_LTDC_DisableDither (LTDC_HandleTypeDef * hltc)
Function Description	Disables Dither.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
Return values	<ul style="list-style-type: none"> • HAL status

38.3.24 HAL_LTDC_SetWindowSize

Function Name	HAL_StatusTypeDef HAL_LTDC_SetWindowSize (LTDC_HandleTypeDef * hltc, uint32_t XSize, uint32_t YSize, uint32_t LayerIdx)
Function Description	Set the LTDC window size.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • XSize: LTDC Pixel per line • YSize: LTDC Line number • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.25 HAL_LTDC_SetWindowPosition

Function Name	HAL_StatusTypeDef HAL_LTDC_SetWindowPosition (LTDC_HandleTypeDef * hltc, uint32_t X0, uint32_t Y0, uint32_t LayerIdx)
Function Description	Set the LTDC window position.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • X0: LTDC window X offset • Y0: LTDC window Y offset • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.26 HAL_LTDC_SetPixelFormat

Function Name	HAL_StatusTypeDef HAL_LTDC_SetPixelFormat (LTDC_HandleTypeDef * hltc, uint32_t Pixelformat, uint32_t LayerIdx)
Function Description	Reconfigure the pixel format.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • Pixelformat: new pixel format value. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1.
Return values	<ul style="list-style-type: none"> • HAL status

38.3.27 HAL_LTDC_SetAlpha

Function Name	HAL_StatusTypeDef HAL_LTDC_SetAlpha (LTDC_HandleTypeDef * hltc, uint32_t Alpha, uint32_t LayerIdx)
Function Description	Reconfigure the layer alpha value.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • Alpha: new alpha value. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1
Return values	<ul style="list-style-type: none"> • HAL status

38.3.28 HAL_LTDC_SetAddress

Function Name	HAL_StatusTypeDef HAL_LTDC_SetAddress (LTDC_HandleTypeDef * hltc, uint32_t Address, uint32_t LayerIdx)
Function Description	Reconfigure the frame buffer Address.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • Address: new address value. • LayerIdx: LTDC Layer index. This parameter can be one of the following values: 0 or 1.
Return values	<ul style="list-style-type: none"> • HAL status

38.3.29 HAL_LTDC_SetPitch

Function Name	HAL_StatusTypeDef HAL_LTDC_SetPitch (LTDC_HandleTypeDef * hltc, uint32_t LinePitchInPixels, uint32_t LayerIdx)
Function Description	Function used to reconfigure the pitch for specific cases where the attached LayerIdx buffer have a width that is larger than the one intended to be displayed on screen.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • LinePitchInPixels: New line pitch in pixels to configure for LTDC layer 'LayerIdx'.

- **LayerIdx:** LTDC layer index concerned by the modification of line pitch.

Return values • HAL status

38.3.30 HAL_LTDC_ProgramLineEvent

Function Name **HAL_StatusTypeDef HAL_LTDC_ProgramLineEvent (LTDC_HandleTypeDef * hltc, uint32_t Line)**

Function Description Define the position of the line interrupt .

Parameters

- **hltc:** pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.
- **Line:** Line Interrupt Position.

Return values • HAL status

38.3.31 HAL_LTDC_GetState

Function Name **HAL_LTDC_StateTypeDef HAL_LTDC_GetState (LTDC_HandleTypeDef * hltc)**

Function Description Return the LTDC state.

Parameters

- **hltc:** pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.

Return values • HAL state

38.3.32 HAL_LTDC_GetError

Function Name **uint32_t HAL_LTDC_GetError (LTDC_HandleTypeDef * hltc)**

Function Description Return the LTDC error code.

Parameters

- **hltc:** : pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC.

Return values • LTDC Error Code

38.4 LTDC Firmware driver defines

38.4.1 LTDC

LTDC Alpha

LTDC_ALPHA LTDC Cte Alpha mask

LTDC BACK COLOR

LTDC_COLOR Color mask

LTDC Blending Factor1

LTDC_BLENDING_FACTOR1_CA Blending factor : Cte Alpha

LTDC_BLENDING_FACTOR1_PAxCA Blending factor : Cte Alpha x Pixel Alpha

LTDC Blending Factor2

LTDC_BLENDING_FACTOR2_CA Blending factor : Cte Alpha

LTDC_BLENDING_FACTOR2_PAxCA Blending factor : Cte Alpha x Pixel Alpha

LTDC DE POLARITY

LTDC_DEPOLARITY_AL Data Enable, is active low.

LTDC_DEPOLARITY_AH Data Enable, is active high.

LTDC Error Code

HAL_LTDC_ERROR_NONE LTDC No error

HAL_LTDC_ERROR_TE LTDC Transfer error

HAL_LTDC_ERROR_FU LTDC FIFO Underrun

HAL_LTDC_ERROR_TIMEOUT LTDC Timeout error

LTDC Exported Macros

_HAL_LTDC_RESET_HANDLE_STATE **Description:**

- Reset LTDC handle state.

Parameters:

- **_HANDLE_**: specifies the LTDC handle.

Return value:

- None

_HAL_LTDC_ENABLE

Description:

- Enable the LTDC.

Parameters:

- **_HANDLE_**: LTDC handle

Return value:

- None.

_HAL_LTDC_DISABLE

Description:

- Disable the LTDC.

Parameters:

- **_HANDLE_**: LTDC handle

Return value:

- None.

_HAL_LTDC_LAYER_ENABLE

Description:

- Enable the LTDC Layer.

Parameters:

- **_HANDLE_**: LTDC handle
- **_LAYER_**: Specify the layer to be enabled This parameter can be 0 or 1

Return value:

- None.

[__HAL_LTDC_LAYER_DISABLE](#)**Description:**

- Disable the LTDC Layer.

Parameters:

- [__HANDLE__](#): LTDC handle
- [__LAYER__](#): Specify the layer to be disabled This parameter can be 0 or 1

Return value:

- None.

[__HAL_LTDC_RELOAD_CONFIG](#)**Description:**

- Reload Layer Configuration.

Parameters:

- [__HANDLE__](#): LTDC handle

Return value:

- None.

[__HAL_LTDC_GET_FLAG](#)**Description:**

- Get the LTDC pending flags.

Parameters:

- [__HANDLE__](#): LTDC handle
- [__FLAG__](#): Get the specified flag. This parameter can be any combination of the following values:
 - [LTDC_FLAG_LI](#): Line Interrupt flag
 - [LTDC_FLAG_FU](#): FIFO Underrun Interrupt flag
 - [LTDC_FLAG_TE](#): Transfer Error interrupt flag
 - [LTDC_FLAG_RR](#): Register Reload Interrupt Flag

Return value:

- The state of FLAG (SET or RESET).

[__HAL_LTDC_CLEAR_FLAG](#)**Description:**

- Clears the LTDC pending flags.

Parameters:

- [__HANDLE__](#): LTDC handle
- [__FLAG__](#): specifies the flag to clear. This parameter can be any combination of the following values:
 - [LTDC_FLAG_LI](#): Line Interrupt flag
 - [LTDC_FLAG_FU](#): FIFO Underrun Interrupt flag
 - [LTDC_FLAG_TE](#): Transfer Error interrupt flag
 - [LTDC_FLAG_RR](#): Register Reload

Interrupt Flag**Return value:**

- None

_HAL_LTDC_ENABLE_IT

- Enables the specified LTDC interrupts.

Parameters:

- HANDLE: LTDC handle
- INTERRUPT: specifies the LTDC interrupt sources to be enabled. This parameter can be any combination of the following values:
 - LTDC_IT_LI: Line Interrupt flag
 - LTDC_IT_FU: FIFO Underrun Interrupt flag
 - LTDC_IT_TE: Transfer Error interrupt flag
 - LTDC_IT_RR: Register Reload Interrupt Flag

Return value:

- None

_HAL_LTDC_DISABLE_IT

- Disables the specified LTDC interrupts.

Parameters:

- HANDLE: LTDC handle
- INTERRUPT: specifies the LTDC interrupt sources to be disabled. This parameter can be any combination of the following values:
 - LTDC_IT_LI: Line Interrupt flag
 - LTDC_IT_FU: FIFO Underrun Interrupt flag
 - LTDC_IT_TE: Transfer Error interrupt flag
 - LTDC_IT_RR: Register Reload Interrupt Flag

Return value:

- None

_HAL_LTDC_GET_IT_SOURCE

- Checks whether the specified LTDC interrupt has occurred or not.

Parameters:

- HANDLE: LTDC handle
- INTERRUPT: specifies the LTDC interrupt source to check. This parameter can be one of the following values:

- LTDC_IT_LI: Line Interrupt flag
- LTDC_IT_FU: FIFO Underrun Interrupt flag
- LTDC_IT_TE: Transfer Error interrupt flag
- LTDC_IT_RR: Register Reload Interrupt Flag

Return value:

- The state of INTERRUPT (SET or RESET).

LTDC Exported Types

MAX_LAYER

LTDC Flag

LTDC_FLAG_LI

LTDC_FLAG_FU

LTDC_FLAG_TE

LTDC_FLAG_RR

LTDC HS POLARITY

LTDC_HSPOLARITY_AL Horizontal Synchronization is active low.

LTDC_HSPOLARITY_AH Horizontal Synchronization is active high.

LTDC Interrupts

LTDC_IT_LI

LTDC_IT_FU

LTDC_IT_TE

LTDC_IT_RR

LTDC LAYER Config

LTDC_STOPPOSITION LTDC Layer stop position

LTDC_STARTPOSITION LTDC Layer start position

LTDC_COLOR_FRAME_BUFFER LTDC Layer Line length

LTDC_LINE_NUMBER LTDC Layer Line number

LTDC PC POLARITY

LTDC_PCPOLARITY_IPC input pixel clock.

LTDC_PCPOLARITY_IIPC inverted input pixel clock.

LTDC Pixel format

LTDC_PIXEL_FORMAT_ARGB8888 ARGB8888 LTDC pixel format

LTDC_PIXEL_FORMAT_RGB888 RGB888 LTDC pixel format

LTDC_PIXEL_FORMAT_RGB565 RGB565 LTDC pixel format

LTDC_PIXEL_FORMAT_ARGB1555 ARGB1555 LTDC pixel format

LTDC_PIXEL_FORMAT_ARGB4444 ARGB4444 LTDC pixel format

LTDC_PIXEL_FORMAT_L8	L8 LTDC pixel format
LTDC_PIXEL_FORMAT_AL44	AL44 LTDC pixel format
LTDC_PIXEL_FORMAT_AL88	AL88 LTDC pixel format

LTDC Private Macros

LTDC_LAYER
 IS_LTDC_LAYER
 IS_LTDC_HSPOL
 IS_LTDC_VSPOL
 IS_LTDC_DEPOL
 IS_LTDC_PCPOL
 IS_LTDC_HSYNC
 IS_LTDC_VSYNC
 IS_LTDC_AHBP
 IS_LTDC_AVBP
 IS_LTDC_AAW
 IS_LTDC_AAH
 IS_LTDC_TOTALW
 IS_LTDC_TOTALH
 IS_LTDC_BLUEVALUE
 IS_LTDC_GREENVALUE
 IS_LTDC_REDVALUE
 IS_LTDC_BLENDING_FACTOR1
 IS_LTDC_BLENDING_FACTOR2
 IS_LTDC_PIXEL_FORMAT
 IS_LTDC_ALPHA
 IS_LTDC_HCONFIGST
 IS_LTDC_HCONFIGSP
 IS_LTDC_VCONFIGST
 IS_LTDC_VCONFIGSP
 IS_LTDC_CFBP
 IS_LTDC_CFBLL
 IS_LTDC_CFBLNBR
 IS_LTDC_LIPOS

LTDC SYNC

LTDC_HORIZONTALSYNC Horizontal synchronization width.
 LTDC_VERTICALSYNC Vertical synchronization height.

LTDC VS POLARITY

LTDC_VSPOLARITY_AL Vertical Synchronization is active low.

LTDC_VSPOLARITY_AH Vertical Synchronization is active high.

39 HAL LTDC Extension Driver

39.1 HAL LTDC Extension Driver

39.2 LTDCEEx Firmware driver API description

39.2.1 Initialization and Configuration functions

This section provides functions allowing to:

- Initialize and configure the LTDC

This section contains the following APIs:

- [*HAL_LTDC_StructInitFromVideoConfig\(\)*](#)
- [*HAL_LTDC_StructInitFromAdaptedCommandConfig\(\)*](#)

39.2.2 HAL_LTDC_StructInitFromVideoConfig

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_StructInitFromVideoConfig (LTDC_HandleTypeDef * hltc, DSI_VidCfgTypeDef * VidCfg)</code>
Function Description	Retrieve common parameters from DSI Video mode configuration structure.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • VidCfg: pointer to a DSI_VidCfgTypeDef structure that contains the DSI video mode configuration parameters
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • The implementation of this function is taking into account the LTDC polarities inversion as described in the current LTDC specification

39.2.3 HAL_LTDC_StructInitFromAdaptedCommandConfig

Function Name	<code>HAL_StatusTypeDef HAL_LTDC_StructInitFromAdaptedCommandConfig (LTDC_HandleTypeDef * hltc, DSI_CmdCfgTypeDef * CmdCfg)</code>
Function Description	Retrieve common parameters from DSI Adapted command mode configuration structure.
Parameters	<ul style="list-style-type: none"> • hltc: pointer to a LTDC_HandleTypeDef structure that contains the configuration information for the LTDC. • CmdCfg: pointer to a DSI_CmdCfgTypeDef structure that contains the DSI command mode configuration parameters
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • The implementation of this function is taking into account the LTDC polarities inversion as described in the current LTDC specification

39.3 LTDCEx Firmware driver defines

40 HAL NAND Generic Driver

40.1 HAL NAND Generic Driver

40.2 NAND Firmware driver registers structures

40.2.1 NAND_IDTypeDef

Data Fields

- *uint8_t Maker_Id*
- *uint8_t Device_Id*
- *uint8_t Third_Id*
- *uint8_t Fourth_Id*

Field Documentation

- *uint8_t NAND_IDTypeDef::Maker_Id*
- *uint8_t NAND_IDTypeDef::Device_Id*
- *uint8_t NAND_IDTypeDef::Third_Id*
- *uint8_t NAND_IDTypeDef::Fourth_Id*

40.2.2 NAND_AddressTypeDef

Data Fields

- *uint16_t Page*
- *uint16_t Zone*
- *uint16_t Block*

Field Documentation

- *uint16_t NAND_AddressTypeDef::Page*
NAND memory Page address
- *uint16_t NAND_AddressTypeDef::Zone*
NAND memory Zone address
- *uint16_t NAND_AddressTypeDef::Block*
NAND memory Block address

40.2.3 NAND_InfoTypeDef

Data Fields

- *uint32_t PageSize*
- *uint32_t SpareAreaSize*

- *uint32_t BlockSize*
- *uint32_t BlockNbr*
- *uint32_t ZoneSize*

Field Documentation

- *uint32_t NAND_InfoTypeDef::PageSize*
NAND memory page (without spare area) size measured in K. bytes
- *uint32_t NAND_InfoTypeDef::SpareAreaSize*
NAND memory spare area size measured in K. bytes
- *uint32_t NAND_InfoTypeDef::BlockSize*
NAND memory block size number of pages
- *uint32_t NAND_InfoTypeDef::BlockNbr*
NAND memory number of blocks
- *uint32_t NAND_InfoTypeDef::ZoneSize*
NAND memory zone size measured in number of blocks

40.2.4 NAND_HandleTypeDef

Data Fields

- *FMC_NAND_TypeDef * Instance*
- *FMC_NAND_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_NAND_StateTypeDef State*
- *NAND_InfoTypeDef Info*

Field Documentation

- *FMC_NAND_TypeDef* NAND_HandleTypeDef::Instance*
Register base address
- *FMC_NAND_InitTypeDef NAND_HandleTypeDef::Init*
NAND device control configuration parameters
- *HAL_LockTypeDef NAND_HandleTypeDef::Lock*
NAND locking object
- *__IO HAL_NAND_StateTypeDef NAND_HandleTypeDef::State*
NAND device access state
- *NAND_InfoTypeDef NAND_HandleTypeDef::Info*
NAND characteristic information structure

40.3 NAND Firmware driver API description

40.3.1 How to use this driver

This driver is a generic layered driver which contains a set of APIs used to control NAND flash memories. It uses the FMC/FSMC layer functions to interface with NAND devices. This driver is used as follows:

- NAND flash memory configuration sequence using the function HAL_NAND_Init() with control and timing parameters for both common and attribute spaces.

- Read NAND flash memory maker and device IDs using the function `HAL_NAND_Read_ID()`. The read information is stored in the `NAND_ID_TypeDef` structure declared by the function caller.
- Access NAND flash memory by read/write operations using the functions `HAL_NAND_Read_Page()`/`HAL_NAND_Read_SpareArea()`, `HAL_NAND_Write_Page()`/`HAL_NAND_Write_SpareArea()` to read/write page(s)/spare area(s). These functions use specific device information (Block, page size..) predefined by the user in the `HAL_NAND_Info_TypeDef` structure. The read/write address information is contained by the `Nand_Address_Typedef` structure passed as parameter.
- Perform NAND flash Reset chip operation using the function `HAL_NAND_Reset()`.
- Perform NAND flash erase block operation using the function `HAL_NAND_Erase_Block()`. The erase block address information is contained in the `Nand_Address_Typedef` structure passed as parameter.
- Read the NAND flash status operation using the function `HAL_NAND_Read_Status()`.
- You can also control the NAND device by calling the control APIs `HAL_NAND_ECC_Enable()`/`HAL_NAND_ECC_Disable()` to respectively enable/disable the ECC code correction feature or the function `HAL_NAND_GetECC()` to get the ECC correction code.
- You can monitor the NAND device HAL state by calling the function `HAL_NAND_GetState()`



This driver is a set of generic APIs which handle standard NAND flash operations. If a NAND flash device contains different operations and/or implementations, it should be implemented separately.

40.3.2 NAND Initialization and de-initialization functions

This section provides functions allowing to initialize/de-initialize the NAND memory

This section contains the following APIs:

- `HAL_NAND_Init()`
- `HAL_NAND_DeInit()`
- `HAL_NAND_MspInit()`
- `HAL_NAND_MspDeInit()`
- `HAL_NAND_IRQHandler()`
- `HAL_NAND_ITCallback()`

40.3.3 NAND Input and Output functions

This section provides functions allowing to use and control the NAND memory

This section contains the following APIs:

- `HAL_NAND_Read_ID()`
- `HAL_NAND_Reset()`
- `HAL_NAND_Read_Page()`
- `HAL_NAND_Write_Page()`
- `HAL_NAND_Read_SpareArea()`
- `HAL_NAND_Write_SpareArea()`
- `HAL_NAND_Erase_Block()`
- `HAL_NAND_Read_Status()`
- `HAL_NAND_Address_Inc()`

40.3.4 NAND Control functions

This subsection provides a set of functions allowing to control dynamically the NAND interface.

This section contains the following APIs:

- [*HAL_NAND_ECC_Enable\(\)*](#)
- [*HAL_NAND_ECC_Disable\(\)*](#)
- [*HAL_NAND_GetECC\(\)*](#)

40.3.5 NAND State functions

This subsection permits to get in run-time the status of the NAND controller and the data flow.

This section contains the following APIs:

- [*HAL_NAND_GetState\(\)*](#)
- [*HAL_NAND_Read_Status\(\)*](#)

40.3.6 HAL_NAND_Init

Function Name	<code>HAL_StatusTypeDef HAL_NAND_Init (NAND_HandleTypeDef * hnand, FMC_NAND_PCC_TimingTypeDef * ComSpace_Timing, FMC_NAND_PCC_TimingTypeDef * AttSpace_Timing)</code>
Function Description	Perform NAND memory Initialization sequence.
Parameters	<ul style="list-style-type: none"> • hnand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. • ComSpace_Timing: pointer to Common space timing structure • AttSpace_Timing: pointer to Attribute space timing structure
Return values	HAL status

40.3.7 HAL_NAND_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_NAND_DelInit (NAND_HandleTypeDef * hnand)</code>
Function Description	Perform NAND memory De-Initialization sequence.
Parameters	<ul style="list-style-type: none"> • hnand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.

Return values

• HAL status

40.3.8 HAL_NAND_MspInit

Function Name	<code>void HAL_NAND_MspInit (NAND_HandleTypeDef * hnand)</code>
Function Description	NAND MSP Init.
Parameters	<ul style="list-style-type: none"> • hnand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	• None

40.3.9 HAL_NAND_MspDeInit

Function Name	void HAL_NAND_MspDeInit (NAND_HandleTypeDef * hhand)
Function Description	NAND MSP DeInit.
Parameters	<ul style="list-style-type: none"> • hhand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • None

40.3.10 HAL_NAND_IRQHandler

Function Name	void HAL_NAND_IRQHandler (NAND_HandleTypeDef * hhand)
Function Description	This function handles NAND device interrupt request.
Parameters	<ul style="list-style-type: none"> • hhand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • HAL status

40.3.11 HAL_NAND_ITCallback

Function Name	void HAL_NAND_ITCallback (NAND_HandleTypeDef * hhand)
Function Description	NAND interrupt feature callback.
Parameters	<ul style="list-style-type: none"> • hhand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • None

40.3.12 HAL_NAND_Read_ID

Function Name	HAL_StatusTypeDef HAL_NAND_Read_ID (NAND_HandleTypeDef * hhand, NAND_IDTypeDef * pNAND_ID)
Function Description	Read the NAND memory electronic signature.
Parameters	<ul style="list-style-type: none"> • hhand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. • pNAND_ID: NAND ID structure
Return values	<ul style="list-style-type: none"> • HAL status

40.3.13 HAL_NAND_Reset

Function Name	HAL_StatusTypeDef HAL_NAND_Reset (NAND_HandleTypeDef * hhand)
Function Description	NAND memory reset.
Parameters	<ul style="list-style-type: none"> • hhand: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • HAL status

40.3.14 HAL_NAND_Read_Page

Function Name	HAL_StatusTypeDef HAL_NAND_Read_Page (NAND_HandleTypeDef * hNAND, NAND_AddressTypeDef * pAddress, uint8_t * pBuffer, uint32_t NumPageToRead)
Function Description	Read Page(s) from NAND memory block.
Parameters	<ul style="list-style-type: none"> hNAND: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. pAddress: : pointer to NAND address structure pBuffer: : pointer to destination read buffer NumPageToRead: : number of pages to read from block
Return values	<ul style="list-style-type: none"> HAL status

40.3.15 HAL_NAND_Write_Page

Function Name	HAL_StatusTypeDef HAL_NAND_Write_Page (NAND_HandleTypeDef * hNAND, NAND_AddressTypeDef * pAddress, uint8_t * pBuffer, uint32_t NumPageToWrite)
Function Description	Write Page(s) to NAND memory block.
Parameters	<ul style="list-style-type: none"> hNAND: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. pAddress: : pointer to NAND address structure pBuffer: : pointer to source buffer to write NumPageToWrite: : number of pages to write to block
Return values	<ul style="list-style-type: none"> HAL status

40.3.16 HAL_NAND_Read_SpareArea

Function Name	HAL_StatusTypeDef HAL_NAND_Read_SpareArea (NAND_HandleTypeDef * hNAND, NAND_AddressTypeDef * pAddress, uint8_t * pBuffer, uint32_t NumSpareAreaToRead)
Function Description	Read Spare area(s) from NAND memory.
Parameters	<ul style="list-style-type: none"> hNAND: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. pAddress: : pointer to NAND address structure pBuffer: pointer to source buffer to write NumSpareAreaToRead: Number of spare area to read
Return values	<ul style="list-style-type: none"> HAL status

40.3.17 HAL_NAND_Write_SpareArea

Function Name	HAL_StatusTypeDef HAL_NAND_Write_SpareArea (NAND_HandleTypeDef * hNAND, NAND_AddressTypeDef * pAddress, uint8_t * pBuffer, uint32_t NumSpareAreaTowrite)
Function Description	Write Spare area(s) to NAND memory.
Parameters	<ul style="list-style-type: none"> hNAND: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. pAddress: : pointer to NAND address structure pBuffer: : pointer to source buffer to write NumSpareAreaTowrite: : number of spare areas to write to

block

Return values	<ul style="list-style-type: none"> HAL status
---------------	--

40.3.18 HAL_NAND_Erase_Block

Function Name	HAL_StatusTypeDef HAL_NAND_Erase_Block (NAND_HandleTypeDef * hndl, NAND_AddressTypeDef * pAddress)
Function Description	NAND memory Block erase.
Parameters	<ul style="list-style-type: none"> hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. pAddress: pointer to NAND address structure
Return values	<ul style="list-style-type: none"> HAL status

40.3.19 HAL_NAND_Read_Status

Function Name	uint32_t HAL_NAND_Read_Status (NAND_HandleTypeDef * hndl)
Function Description	NAND memory read status.
Parameters	<ul style="list-style-type: none"> hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> NAND status

40.3.20 HAL_NAND_Address_Inc

Function Name	uint32_t HAL_NAND_Address_Inc (NAND_HandleTypeDef * hndl, NAND_AddressTypeDef * pAddress)
Function Description	Increment the NAND memory address.
Parameters	<ul style="list-style-type: none"> hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. pAddress: pointer to NAND address structure
Return values	<ul style="list-style-type: none"> The new status of the increment address operation. It can be: NAND_VALID_ADDRESS: When the new address is valid NAND_INVALID_ADDRESS: When the new address is invalid address

40.3.21 HAL_NAND_ECC_Enable

Function Name	HAL_StatusTypeDef HAL_NAND_ECC_Enable (NAND_HandleTypeDef * hndl)
Function Description	Enables dynamically NAND ECC feature.
Parameters	<ul style="list-style-type: none"> hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> HAL status

40.3.22 HAL_NAND_ECC_Disable

Function Name	HAL_StatusTypeDef HAL_NAND_ECC_Disable (NAND_HandleTypeDef * hndl)
Function Description	Disables dynamically FMC_NAND ECC feature.
Parameters	<ul style="list-style-type: none"> • hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • HAL status

40.3.23 HAL_NAND_GetECC

Function Name	HAL_StatusTypeDef HAL_NAND_GetECC (NAND_HandleTypeDef * hndl, uint32_t * ECCval, uint32_t Timeout)
Function Description	Disables dynamically NAND ECC feature.
Parameters	<ul style="list-style-type: none"> • hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module. • ECCval: pointer to ECC value • Timeout: maximum timeout to wait
Return values	<ul style="list-style-type: none"> • HAL status

40.3.24 HAL_NAND_GetState

Function Name	HAL_NAND_StateTypeDef HAL_NAND_GetState (NAND_HandleTypeDef * hndl)
Function Description	return the NAND state
Parameters	<ul style="list-style-type: none"> • hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • HAL state

40.3.25 HAL_NAND_Read_Status

Function Name	uint32_t HAL_NAND_Read_Status (NAND_HandleTypeDef * hndl)
Function Description	NAND memory read status.
Parameters	<ul style="list-style-type: none"> • hndl: pointer to a NAND_HandleTypeDef structure that contains the configuration information for NAND module.
Return values	<ul style="list-style-type: none"> • NAND status

40.4 NAND Firmware driver defines

40.4.1 NAND

NAND Exported Macros

`_HAL_NAND_RESET_HANDLE_STATE` **Description:**

- Reset NAND handle state.

Parameters:

- `_HANDLE_`: specifies the NAND

handle.

Return value:

- None

NAND Private Constants

```
NAND_DEVICE1
NAND_DEVICE2
NAND_WRITE_TIMEOUT
CMD_AREA
ADDR_AREA
NAND_CMD_AREA_A
NAND_CMD_AREA_B
NAND_CMD_AREA_C
NAND_CMD_AREA_TRUE1
NAND_CMD_WRITE0
NAND_CMD_WRITE_TRUE1
NAND_CMD_ERASE0
NAND_CMD_ERASE1
NAND_CMD_READID
NAND_CMD_STATUS
NAND_CMD_LOCK_STATUS
NAND_CMD_RESET
NAND_VALID_ADDRESS
NAND_INVALID_ADDRESS
NAND_TIMEOUT_ERROR
NAND_BUSY
NAND_ERROR
NAND_READY
```

NAND Private Macros

<code>ARRAY_ADDRESS</code>	Description:
	<ul style="list-style-type: none"> • NAND memory address computation.
	Parameters:
	<ul style="list-style-type: none"> • <code>__ADDRESS__</code>: NAND memory address. • <code>__HANDLE__</code>: NAND handle.
	Return value:
	<ul style="list-style-type: none"> • NAND: Raw address value
<code>ADDR_1ST_CYCLE</code>	Description:

- NAND memory address cycling.

Parameters:

- ADDRESS: NAND memory address.

Return value:

- NAND: address cycling value.

ADDR_2ND_CYCLE

ADDR_3RD_CYCLE

ADDR_4TH_CYCLE

41 HAL NOR Generic Driver

41.1 HAL NOR Generic Driver

41.2 NOR Firmware driver registers structures

41.2.1 NOR_IDTypeDef

Data Fields

- *uint16_t Manufacturer_Code*
- *uint16_t Device_Code1*
- *uint16_t Device_Code2*
- *uint16_t Device_Code3*

Field Documentation

- *uint16_t NOR_IDTypeDef::Manufacturer_Code*
Defines the device's manufacturer code used to identify the memory
- *uint16_t NOR_IDTypeDef::Device_Code1*
- *uint16_t NOR_IDTypeDef::Device_Code2*
- *uint16_t NOR_IDTypeDef::Device_Code3*
Defines the device's codes used to identify the memory. These codes can be accessed by performing read operations with specific control signals and addresses set. They can also be accessed by issuing an Auto Select command

41.2.2 NOR_CFITypeDef

Data Fields

- *uint16_t CFI_1*
- *uint16_t CFI_2*
- *uint16_t CFI_3*
- *uint16_t CFI_4*

Field Documentation

- *uint16_t NOR_CFITypeDef::CFI_1*
< Defines the information stored in the memory's Common flash interface which contains a description of various electrical and timing parameters, density information and functions supported by the memory
- *uint16_t NOR_CFITypeDef::CFI_2*
- *uint16_t NOR_CFITypeDef::CFI_3*
- *uint16_t NOR_CFITypeDef::CFI_4*

41.2.3 NOR_HandleTypeDef

Data Fields

- *FMC_NORSRAM_TypeDef * Instance*
- *FMC_NORSRAM_EXTENDED_TypeDef * Extended*
- *FMC_NORSRAM_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_NOR_StateTypeDef State*

Field Documentation

- ***FMC_NORSRAM_TypeDef* NOR_HandleTypeDef::Instance***
Register base address
- ***FMC_NORSRAM_EXTENDED_TypeDef* NOR_HandleTypeDef::Extended***
Extended mode register base address
- ***FMC_NORSRAM_InitTypeDef NOR_HandleTypeDef::Init***
NOR device control configuration parameters
- ***HAL_LockTypeDef NOR_HandleTypeDef::Lock***
NOR locking object
- ***__IO HAL_NOR_StateTypeDef NOR_HandleTypeDef::State***
NOR device access state

41.3 NOR Firmware driver API description

41.3.1 How to use this driver

This driver is a generic layered driver which contains a set of APIs used to control NOR flash memories. It uses the FMC/FSMC layer functions to interface with NOR devices. This driver is used as follows:

- NOR flash memory configuration sequence using the function HAL_NOR_Init() with control and timing parameters for both normal and extended mode.
- Read NOR flash memory manufacturer code and device IDs using the function HAL_NOR_Read_ID(). The read information is stored in the NOR_ID_TypeDef structure declared by the function caller.
- Access NOR flash memory by read/write data unit operations using the functions HAL_NOR_Read(), HAL_NOR_Program().
- Perform NOR flash erase block/chip operations using the functions HAL_NOR_Erase_Block() and HAL_NOR_Erase_Chip().
- Read the NOR flash CFI (common flash interface) IDs using the function HAL_NOR_Read_CFI(). The read information is stored in the NOR_CFI_TypeDef structure declared by the function caller.
- You can also control the NOR device by calling the control APIs HAL_NOR_WriteOperation_Enable() / HAL_NOR_WriteOperation_Disable() to respectively enable/disable the NOR write operation
- You can monitor the NOR device HAL state by calling the function HAL_NOR_GetState()



This driver is a set of generic APIs which handle standard NOR flash operations. If a NOR flash device contains different operations and/or implementations, it should be implemented separately.

NOR HAL driver macros list

Below the list of most used macros in NOR HAL driver.

- NOR_WRITE : NOR memory write data to specified address

41.3.2 NOR Initialization and de_initialization functions

This section provides functions allowing to initialize/de-initialize the NOR memory

This section contains the following APIs:

- [`HAL_NOR_Init\(\)`](#)
- [`HAL_NOR_DeInit\(\)`](#)
- [`HAL_NOR_MspInit\(\)`](#)
- [`HAL_NOR_MspDeInit\(\)`](#)
- [`HAL_NOR_MspWait\(\)`](#)

41.3.3 NOR Input and Output functions

This section provides functions allowing to use and control the NOR memory

This section contains the following APIs:

- [`HAL_NOR_Read_ID\(\)`](#)
- [`HAL_NOR_ReturnToReadMode\(\)`](#)
- [`HAL_NOR_Read\(\)`](#)
- [`HAL_NOR_Program\(\)`](#)
- [`HAL_NOR_ReadBuffer\(\)`](#)
- [`HAL_NOR_ProgramBuffer\(\)`](#)
- [`HAL_NOR_Erase_Block\(\)`](#)
- [`HAL_NOR_Erase_Chip\(\)`](#)
- [`HAL_NOR_Read_CFI\(\)`](#)

41.3.4 NOR Control functions

This subsection provides a set of functions allowing to control dynamically the NOR interface.

This section contains the following APIs:

- [`HAL_NOR_WriteOperation_Enable\(\)`](#)
- [`HAL_NOR_WriteOperation_Disable\(\)`](#)

41.3.5 NOR State functions

This subsection permits to get in run-time the status of the NOR controller and the data flow.

This section contains the following APIs:

- [`HAL_NOR_GetState\(\)`](#)
- [`HAL_NOR_GetStatus\(\)`](#)

41.3.6 HAL_NOR_Init

Function Name	HAL_StatusTypeDef HAL_NOR_Init (NOR_HandleTypeDef * hnор, FMC_NORSRAM_TimingTypeDef * Timing, FMC_NORSRAM_TimingTypeDef * ExtTiming)
Function Description	Perform the NOR memory Initialization sequence.
Parameters	<ul style="list-style-type: none"> • hnор: pointer to the NOR handle • Timing: pointer to NOR control timing structure • ExtTiming: pointer to NOR extended mode timing structure
Return values	<ul style="list-style-type: none"> • HAL status

41.3.7 HAL_NOR_DelInit

Function Name	HAL_StatusTypeDef HAL_NOR_DelInit (NOR_HandleTypeDef * hnор)
Function Description	Perform NOR memory De-Initialization sequence.
Parameters	<ul style="list-style-type: none"> • hnор: pointer to a NOR_HandleTypeDef structure that contains the configuration information for NOR module.
Return values	<ul style="list-style-type: none"> • HAL status

41.3.8 HAL_NOR_MspInit

Function Name	void HAL_NOR_MspInit (NOR_HandleTypeDef * hnор)
Function Description	NOR MSP Init.
Parameters	<ul style="list-style-type: none"> • hnор: pointer to a NOR_HandleTypeDef structure that contains the configuration information for NOR module.
Return values	<ul style="list-style-type: none"> • None

41.3.9 HAL_NOR_MspDelInit

Function Name	void HAL_NOR_MspDelInit (NOR_HandleTypeDef * hnор)
Function Description	NOR MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hnор: pointer to a NOR_HandleTypeDef structure that contains the configuration information for NOR module.
Return values	<ul style="list-style-type: none"> • None

41.3.10 HAL_NOR_MspWait

Function Name	void HAL_NOR_MspWait (NOR_HandleTypeDef * hnор, uint32_t Timeout)
Function Description	NOR BSP Wait for Ready/Busy signal.
Parameters	<ul style="list-style-type: none"> • hnор: pointer to a NOR_HandleTypeDef structure that contains the configuration information for NOR module. • Timeout: Maximum timeout value
Return values	<ul style="list-style-type: none"> • None

41.3.11 HAL_NOR_Read_ID

Function Name	HAL_StatusTypeDef HAL_NOR_Read_ID (NOR_HandleTypeDef * hnor, NOR_IDTypeDef * pNOR_ID)
Function Description	Read NOR flash IDs.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • pNOR_ID: : pointer to NOR ID structure
Return values	<ul style="list-style-type: none"> • HAL status

41.3.12 HAL_NOR_ReturnToReadMode

Function Name	HAL_StatusTypeDef HAL_NOR_ReturnToReadMode (NOR_HandleTypeDef * hnor)
Function Description	Returns the NOR memory to Read mode.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle
Return values	<ul style="list-style-type: none"> • HAL status

41.3.13 HAL_NOR_Read

Function Name	HAL_StatusTypeDef HAL_NOR_Read (NOR_HandleTypeDef * hnor, uint32_t * pAddress, uint16_t * pData)
Function Description	Read data from NOR memory.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • pAddress: pointer to Device address • pData: : pointer to read data
Return values	<ul style="list-style-type: none"> • HAL status

41.3.14 HAL_NOR_Program

Function Name	HAL_StatusTypeDef HAL_NOR_Program (NOR_HandleTypeDef * hnor, uint32_t * pAddress, uint16_t * pData)
Function Description	Program data to NOR memory.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • pAddress: Device address • pData: : pointer to the data to write
Return values	<ul style="list-style-type: none"> • HAL status

41.3.15 HAL_NOR_ReadBuffer

Function Name	HAL_StatusTypeDef HAL_NOR_ReadBuffer (NOR_HandleTypeDef * hnor, uint32_t uwAddress, uint16_t * pData, uint32_t uwBufferSize)
Function Description	Reads a half-word buffer from the NOR memory.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • uwAddress: NOR memory internal address to read from. • pData: pointer to the buffer that receives the data read from the NOR memory.

-
- **uwBufferSize:** : number of Half word to read.

Return values • HAL status

41.3.16 HAL_NOR_ProgramBuffer

Function Name	HAL_StatusTypeDef HAL_NOR_ProgramBuffer (NOR_HandleTypeDef * hnor, uint32_t uwAddress, uint16_t * pData, uint32_t uwBufferSize)
Function Description	Writes a half-word buffer to the NOR memory.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • uwAddress: NOR memory internal start write address • pData: pointer to source data buffer. • uwBufferSize: Size of the buffer to write
Return values	<ul style="list-style-type: none"> • HAL status

41.3.17 HAL_NOR_Erase_Block

Function Name	HAL_StatusTypeDef HAL_NOR_Erase_Block (NOR_HandleTypeDef * hnor, uint32_t BlockAddress, uint32_t Address)
Function Description	Erase the specified block of the NOR memory.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • BlockAddress: : Block to erase address • Address: Device address
Return values	<ul style="list-style-type: none"> • HAL status

41.3.18 HAL_NOR_Erase_Chip

Function Name	HAL_StatusTypeDef HAL_NOR_Erase_Chip (NOR_HandleTypeDef * hnor, uint32_t Address)
Function Description	Erase the entire NOR chip.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • Address: : Device address
Return values	<ul style="list-style-type: none"> • HAL status

41.3.19 HAL_NOR_Read_CFI

Function Name	HAL_StatusTypeDef HAL_NOR_Read_CFI (NOR_HandleTypeDef * hnor, NOR_CFITypeDef * pNOR_CFI)
Function Description	Read NOR flash CFI IDs.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • pNOR_CFI: : pointer to NOR CFI IDs structure
Return values	<ul style="list-style-type: none"> • HAL status

41.3.20 HAL_NOR_WriteOperation_Enable

Function Name **HAL_StatusTypeDef HAL_NOR_WriteOperation_Enable**

(NOR_HandleTypeDef * hnor)

Function Description	Enables dynamically NOR write operation.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle
Return values	<ul style="list-style-type: none"> • HAL status

41.3.21 HAL_NOR_WriteOperation_Disable

Function Name	HAL_StatusTypeDef HAL_NOR_WriteOperation_Disable (NOR_HandleTypeDef * hnor)
Function Description	Disables dynamically NOR write operation.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle
Return values	<ul style="list-style-type: none"> • HAL status

41.3.22 HAL_NOR_GetState

Function Name	HAL_NOR_StateTypeDef HAL_NOR_GetState (NOR_HandleTypeDef * hnor)
Function Description	return the NOR controller state
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle
Return values	<ul style="list-style-type: none"> • NOR controller state

41.3.23 HAL_NOR_GetStatus

Function Name	HAL_NOR_StatusTypeDef HAL_NOR_GetStatus (NOR_HandleTypeDef * hnor, uint32_t Address, uint32_t Timeout)
Function Description	Returns the NOR operation status.
Parameters	<ul style="list-style-type: none"> • hnor: pointer to the NOR handle • Address: Device address • Timeout: NOR programming Timeout
Return values	<ul style="list-style-type: none"> • NOR_Status The returned value can be: HAL_NOR_STATUS_SUCCESS, HAL_NOR_STATUS_ERROR or HAL_NOR_STATUS_TIMEOUT

41.4 NOR Firmware driver defines

41.4.1 NOR

NOR Exported Macros

<u>_HAL_NOR_RESET_HANDLE_STATE</u>	Description:
	<ul style="list-style-type: none"> • Reset NOR handle state.
	Parameters:
	<ul style="list-style-type: none"> • <u>_HANDLE_</u>: specifies the NOR handle.

Return value:

-
- None

NOR Private Constants

MC_ADDRESS
DEVICE_CODE1_ADDR
DEVICE_CODE2_ADDR
DEVICE_CODE3_ADDR
CFI1_ADDRESS
CFI2_ADDRESS
CFI3_ADDRESS
CFI4_ADDRESS
NOR_TMEOUT
NOR_MEMORY_8B
NOR_MEMORY_16B
NOR_MEMORY_ADRESS1
NOR_MEMORY_ADRESS2
NOR_MEMORY_ADRESS3
NOR_MEMORY_ADRESS4

NOR Private Defines

NOR_CMD_ADDRESS_FIRST
NOR_CMD_ADDRESS_FIRST_CFI
NOR_CMD_ADDRESS_SECOND
NOR_CMD_ADDRESS_THIRD
NOR_CMD_ADDRESS_FOURTH
NOR_CMD_ADDRESS_FIFTH
NOR_CMD_ADDRESS_SIXTH
NOR_CMD_DATA_READ_RESET
NOR_CMD_DATA_FIRST
NOR_CMD_DATA_SECOND
NOR_CMD_DATA_AUTO_SELECT
NOR_CMD_DATA_PROGRAM
NOR_CMD_DATA_CHIP_BLOCK_ERASE_THIRD
NOR_CMD_DATA_CHIP_BLOCK_ERASE_FOURTH
NOR_CMD_DATA_CHIP_BLOCK_ERASE_FIFTH
NOR_CMD_DATA_CHIP_ERASE
NOR_CMD_DATA_CFI
NOR_CMD_DATA_BUFFER_AND_PROG

NOR_CMD_DATA_BUFFER_AND_PROG_CONFIRM

NOR_CMD_DATA_BLOCK_ERASE

NOR_MASK_STATUS_DQ5

NOR_MASK_STATUS_DQ6

NOR Private Macros

NOR_ADDR_SHIFT Description:

- NOR memory address shifting.

Parameters:

- __NOR_ADDRESS__: NOR base address
- NOR_MEMORY_WIDTH: NOR memory width
- ADDRESS: NOR memory address

Return value:

- NOR: shifted address value

NOR_WRITE

Description:

- NOR memory write data to specified address.

Parameters:

- ADDRESS: NOR memory address
- DATA: Data to write

Return value:

- None

42 HAL PCCARD Generic Driver

42.1 HAL PCCARD Generic Driver

42.2 PCCARD Firmware driver registers structures

42.2.1 PCCARD_HandleTypeDef

Data Fields

- *FMC_PCCARD_TypeDef * Instance*
- *FMC_PCCARD_InitTypeDef Init*
- *_IO HAL_PCCARD_StateTypeDef State*
- *HAL_LockTypeDef Lock*

Field Documentation

- ***FMC_PCCARD_TypeDef* PCCARD_HandleTypeDef::Instance***
Register base address for PCCARD device
- ***FMC_PCCARD_InitTypeDef PCCARD_HandleTypeDef::Init***
PCCARD device control configuration parameters
- ***_IO HAL_PCCARD_StateTypeDef PCCARD_HandleTypeDef::State***
PCCARD device access state
- ***HAL_LockTypeDef PCCARD_HandleTypeDef::Lock***
PCCARD Lock

42.3 PCCARD Firmware driver API description

42.3.1 How to use this driver

This driver is a generic layered driver which contains a set of APIs used to control PCCARD/compact flash memories. It uses the FMC/FSMC layer functions to interface with PCCARD devices. This driver is used for:

- PCCARD/Compact Flash memory configuration sequence using the function HAL_PCCARD_Init()/HAL_CF_Init() with control and timing parameters for both common and attribute spaces.
- Read PCCARD/Compact Flash memory maker and device IDs using the function HAL_PCCARD_Read_ID()/HAL_CF_Read_ID(). The read information is stored in the CompactFlash_ID structure declared by the function caller.
- Access PCCARD/Compact Flash memory by read/write operations using the functions HAL_PCCARD_Read_Sector()/ HAL_PCCARD_Write_Sector() - HAL_CF_Read_Sector()/HAL_CF_Write_Sector(), to read/write sector.
- Perform PCCARD/Compact Flash Reset chip operation using the function HAL_PCCARD_Reset()/HAL_CF_Reset.
- Perform PCCARD/Compact Flash erase sector operation using the function HAL_PCCARD_Erase_Sector()/HAL_CF_Erase_Sector.
- Read the PCCARD/Compact Flash status operation using the function HAL_PCCARD_ReadStatus()/HAL_CF_ReadStatus().

- You can monitor the PCCARD/Compact Flash device HAL state by calling the function HAL_PCCARD_GetState()/HAL_CF_GetState()



This driver is a set of generic APIs which handle standard PCCARD/compact flash operations. If a PCCARD/Compact Flash device contains different operations and/or implementations, it should be implemented separately.

42.3.2 PCCARD Initialization and de-initialization functions

This section provides functions allowing to initialize/de-initialize the PCCARD memory

This section contains the following APIs:

- [*HAL_PCCARD_Init\(\)*](#)
- [*HAL_PCCARD_DelInit\(\)*](#)
- [*HAL_PCCARD_MspInit\(\)*](#)
- [*HAL_PCCARD_MspDelInit\(\)*](#)

42.3.3 PCCARD Input and Output functions

This section provides functions allowing to use and control the PCCARD memory

This section contains the following APIs:

- [*HAL_PCCARD_Read_ID\(\)*](#)
- [*HAL_PCCARD_Read_Sector\(\)*](#)
- [*HAL_PCCARD_Write_Sector\(\)*](#)
- [*HAL_PCCARD_Erase_Sector\(\)*](#)
- [*HAL_PCCARD_Reset\(\)*](#)
- [*HAL_PCCARD_IRQHandler\(\)*](#)
- [*HAL_PCCARD_ITCallback\(\)*](#)

42.3.4 PCCARD State functions

This subsection permits to get in run-time the status of the PCCARD controller and the data flow.

This section contains the following APIs:

- [*HAL_PCCARD_GetState\(\)*](#)
- [*HAL_PCCARD_GetStatus\(\)*](#)
- [*HAL_PCCARD_ReadStatus\(\)*](#)

42.3.5 HAL_PCCARD_Init

Function Name	<code>HAL_StatusTypeDef HAL_PCCARD_Init (PCCARD_HandleTypeDef * hpccard, FMC_NAND_PCC_TimingTypeDef * ComSpaceTiming, FMC_NAND_PCC_TimingTypeDef * AttSpaceTiming, FMC_NAND_PCC_TimingTypeDef * IOSpaceTiming)</code>
Function Description	Perform the PCCARD memory Initialization sequence.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module. • ComSpaceTiming: Common space timing structure • AttSpaceTiming: Attribute space timing structure

-
- **IOSpaceTiming:** IO space timing structure

Return values

- HAL status

42.3.6 HAL_PCCARD_DelInit

Function Name	HAL_StatusTypeDef HAL_PCCARD_DelInit (PCCARD_HandleTypeDef * hpccard)
Function Description	Perform the PCCARD memory De-initialization sequence.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • HAL status

42.3.7 HAL_PCCARD_MspInit

Function Name	void HAL_PCCARD_MspInit (PCCARD_HandleTypeDef * hpccard)
Function Description	PCCARD MSP Init.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • None

42.3.8 HAL_PCCARD_MspDelInit

Function Name	void HAL_PCCARD_MspDelInit (PCCARD_HandleTypeDef * hpccard)
Function Description	PCCARD MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • None

42.3.9 HAL_PCCARD_Read_ID

Function Name	HAL_StatusTypeDef HAL_PCCARD_Read_ID (PCCARD_HandleTypeDef * hpccard, uint8_t CompactFlash_ID, uint8_t * pStatus)
Function Description	Read Compact Flash's ID.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module. • CompactFlash_ID: Compact flash ID structure. • pStatus: pointer to compact flash status
Return values	<ul style="list-style-type: none"> • HAL status

42.3.10 HAL_PCCARD_Read_Sector

Function Name	HAL_StatusTypeDef HAL_PCCARD_Read_Sector (PCCARD_HandleTypeDef * hpccard, uint16_t * pBuffer, uint16_t SectorAddress, uint8_t * pStatus)
Function Description	Read sector from PCCARD memory.
Parameters	<ul style="list-style-type: none"> hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module. pBuffer: pointer to destination read buffer SectorAddress: Sector address to read pStatus: pointer to PCCARD status
Return values	<ul style="list-style-type: none"> HAL status

42.3.11 HAL_PCCARD_Write_Sector

Function Name	HAL_StatusTypeDef HAL_PCCARD_Write_Sector (PCCARD_HandleTypeDef * hpccard, uint16_t * pBuffer, uint16_t SectorAddress, uint8_t * pStatus)
Function Description	Write sector to PCCARD memory.
Parameters	<ul style="list-style-type: none"> hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module. pBuffer: pointer to source write buffer SectorAddress: Sector address to write pStatus: pointer to PCCARD status
Return values	<ul style="list-style-type: none"> HAL status

42.3.12 HAL_PCCARD_Erase_Sector

Function Name	HAL_StatusTypeDef HAL_PCCARD_Erase_Sector (PCCARD_HandleTypeDef * hpccard, uint16_t SectorAddress, uint8_t * pStatus)
Function Description	Erase sector from PCCARD memory.
Parameters	<ul style="list-style-type: none"> hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module. SectorAddress: Sector address to erase pStatus: pointer to PCCARD status
Return values	<ul style="list-style-type: none"> HAL status

42.3.13 HAL_PCCARD_Reset

Function Name	HAL_StatusTypeDef HAL_PCCARD_Reset (PCCARD_HandleTypeDef * hpccard)
Function Description	Reset the PCCARD memory.
Parameters	<ul style="list-style-type: none"> hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

42.3.14 HAL_PCCARD_IRQHandler

Function Name	void HAL_PCCARD_IRQHandler (PCCARD_HandleTypeDef * hpccard)
Function Description	This function handles PCCARD device interrupt request.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • HAL status

42.3.15 HAL_PCCARD_ITCallback

Function Name	void HAL_PCCARD_ITCallback (PCCARD_HandleTypeDef * hpccard)
Function Description	PCCARD interrupt feature callback.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • None

42.3.16 HAL_PCCARD_GetState

Function Name	HAL_PCCARD_StateTypeDef HAL_PCCARD_GetState (PCCARD_HandleTypeDef * hpccard)
Function Description	return the PCCARD controller state
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • HAL state

42.3.17 HAL_PCCARD_GetStatus

Function Name	HAL_PCCARD_StatusTypeDef HAL_PCCARD_GetStatus (PCCARD_HandleTypeDef * hpccard)
Function Description	Get the compact flash memory status.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • New status of the PCCARD operation. This parameter can be: CompactFlash_TIMEOUT_ERROR: when the previous operation generate a Timeout errorCompactFlash_READY: when memory is ready for the next operation

42.3.18 HAL_PCCARD_ReadStatus

Function Name	HAL_PCCARD_StatusTypeDef HAL_PCCARD_ReadStatus
---------------	---

(PCCARD_HandleTypeDef * hpccard)

Function Description	Reads the Compact Flash memory status using the Read status command.
Parameters	<ul style="list-style-type: none"> • hpccard: pointer to a PCCARD_HandleTypeDef structure that contains the configuration information for PCCARD module.
Return values	<ul style="list-style-type: none"> • The status of the Compact Flash memory. This parameter can be: CompactFlash_BUSY: when memory is busyCompactFlash_READY: when memory is ready for the next operationCompactFlash_ERROR: when the previous operation generates error

42.4 PCCARD Firmware driver defines

42.4.1 PCCARD

PCCARD Exported Macros

`_HAL_PCCARD_RESET_HANDLE_STATE` **Description:**

- Reset PCCARD handle state.

Parameters:

- `_HANDLE_`: specifies the PCCARD handle.

Return value:

- None

PCCARD Private Constants

PCCARD_DEVICE_ADDRESS

PCCARD_ATTRIBUTE_SPACE_ADDRESS

PCCARD_COMMON_SPACE_ADDRESS

PCCARD_IO_SPACE_ADDRESS

PCCARD_IO_SPACE_PRIMARY_ADDR

ATA_DATA

ATA_SECTOR_COUNT

ATA_SECTOR_NUMBER

ATA_CYLINDER_LOW

ATA_CYLINDER_HIGH

ATA_CARD_HEAD

ATA_STATUS_CMD

ATA_STATUS_CMD_ALTERNATE

ATA_COMMON_DATA_AREA

ATA_CARD_CONFIGURATION

ATA_READ_SECTOR_CMD

ATA_WRITE_SECTOR_CMD
ATA_ERASE_SECTOR_CMD
ATA_IDENTIFY_CMD
PCCARD_TIMEOUT_ERROR
PCCARD_BUSY
PCCARD_PROGR
PCCARD_READY
PCCARD_SECTOR_SIZE
PCCARD Private Defines
PCCARD_TIMEOUT_READ_ID
PCCARD_TIMEOUT_READ_WRITE_SECTOR
PCCARD_TIMEOUT_ERASE_SECTOR
PCCARD_TIMEOUT_STATUS
PCCARD_STATUS_OK
PCCARD_STATUS_WRITE_OK

43 HAL PCD Generic Driver

43.1 HAL PCD Generic Driver

43.2 PCD Firmware driver registers structures

43.2.1 PCD_HandleTypeDef

Data Fields

- *PCD_TypeDef * Instance*
- *PCD_InitTypeDef Init*
- *PCD_EPTTypeDef IN_ep*
- *PCD_EPTTypeDef OUT_ep*
- *HAL_LockTypeDef Lock*
- *__IO PCD_StateTypeDef State*
- *uint32_t Setup*
- *void * pData*

Field Documentation

- ***PCD_TypeDef* PCD_HandleTypeDef::Instance***
Register base address
- ***PCD_InitTypeDef PCD_HandleTypeDef::Init***
PCD required parameters
- ***PCD_EPTTypeDef PCD_HandleTypeDef::IN_ep[15]***
IN endpoint parameters
- ***PCD_EPTTypeDef PCD_HandleTypeDef::OUT_ep[15]***
OUT endpoint parameters
- ***HAL_LockTypeDef PCD_HandleTypeDef::Lock***
PCD peripheral status
- ***__IO PCD_StateTypeDef PCD_HandleTypeDef::State***
PCD communication state
- ***uint32_t PCD_HandleTypeDef::Setup[12]***
Setup packet buffer
- ***void* PCD_HandleTypeDef::pData***
Pointer to upper stack Handler

43.3 PCD Firmware driver API description

43.3.1 How to use this driver

The PCD HAL driver can be used as follows:

1. Declare a PCD_HandleTypeDef handle structure, for example: PCD_HandleTypeDef hpcd;
2. Fill parameters of Init structure in HCD handle
3. Call HAL_PCD_Init() API to initialize the PCD peripheral (Core, Device core, ...)
4. Initialize the PCD low level resources through the HAL_PCD_MspInit() API:

-
- a. Enable the PCD/USB Low Level interface clock using
 - `_HAL_RCC_USB_OTG_FS_CLK_ENABLE();`
 - `_HAL_RCC_USB_OTG_HS_CLK_ENABLE();` (For High Speed Mode)
 - b. Initialize the related GPIO clocks
 - c. Configure PCD pin-out
 - d. Configure PCD NVIC interrupt
 - 5. Associate the Upper USB device stack to the HAL PCD Driver:
 - a. `hpcd.pData = pdev;`
 - 6. Enable PCD transmission and reception:
 - a. `HAL_PCD_Start();`

43.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

This section contains the following APIs:

- [`HAL_PCD_Init\(\)`](#)
- [`HAL_PCD_DelInit\(\)`](#)
- [`HAL_PCD_MspInit\(\)`](#)
- [`HAL_PCD_MspDelInit\(\)`](#)

43.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the PCD data transfers.

This section contains the following APIs:

- [`HAL_PCD_Start\(\)`](#)
- [`HAL_PCD_Stop\(\)`](#)
- [`HAL_PCD_IRQHandler\(\)`](#)
- [`HAL_PCD_DataOutStageCallback\(\)`](#)
- [`HAL_PCD_DataInStageCallback\(\)`](#)
- [`HAL_PCD_SetupStageCallback\(\)`](#)
- [`HAL_PCD_SOFCallback\(\)`](#)
- [`HAL_PCD_ResetCallback\(\)`](#)
- [`HAL_PCD_SuspendCallback\(\)`](#)
- [`HAL_PCD_ResumeCallback\(\)`](#)
- [`HAL_PCD_ISOOUTIncompleteCallback\(\)`](#)
- [`HAL_PCD_ISOINIncompleteCallback\(\)`](#)
- [`HAL_PCD_ConnectCallback\(\)`](#)
- [`HAL_PCD_DisconnectCallback\(\)`](#)

43.3.4 Peripheral Control functions

This subsection provides a set of functions allowing to control the PCD data transfers.

This section contains the following APIs:

- [`HAL_PCD_DevConnect\(\)`](#)
- [`HAL_PCD_DevDisconnect\(\)`](#)
- [`HAL_PCD_SetAddress\(\)`](#)
- [`HAL_PCD_EP_Open\(\)`](#)
- [`HAL_PCD_EP_Close\(\)`](#)
- [`HAL_PCD_EP_Receive\(\)`](#)
- [`HAL_PCD_EP_GetRxCount\(\)`](#)
- [`HAL_PCD_EP_Transmit\(\)`](#)
- [`HAL_PCD_EP_SetStall\(\)`](#)

- `HAL_PCD_EP_ClrStall()`
- `HAL_PCD_EP_Flush()`
- `HAL_PCD_ActivateRemoteWakeUp()`
- `HAL_PCD_DeActivateRemoteWakeUp()`

43.3.5 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- `HAL_PCD_GetState()`

43.3.6 HAL_PCD_Init

Function Name	<code>HAL_StatusTypeDef HAL_PCD_Init (PCD_HandleTypeDef * hpcd)</code>
Function Description	Initializes the PCD according to the specified parameters in the PCD_InitTypeDef and initialize the associated handle.
Parameters	<ul style="list-style-type: none"> • <code>hpcd</code>: PCD handle
Return values	<ul style="list-style-type: none"> • HAL status

43.3.7 HAL_PCD_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_PCD_DelInit (PCD_HandleTypeDef * hpcd)</code>
Function Description	Deinitializes the PCD peripheral.
Parameters	<ul style="list-style-type: none"> • <code>hpcd</code>: PCD handle
Return values	<ul style="list-style-type: none"> • HAL status

43.3.8 HAL_PCD_MspInit

Function Name	<code>void HAL_PCD_MspInit (PCD_HandleTypeDef * hpcd)</code>
Function Description	Initializes the PCD MSP.
Parameters	<ul style="list-style-type: none"> • <code>hpcd</code>: PCD handle
Return values	<ul style="list-style-type: none"> • None

43.3.9 HAL_PCD_MspDelInit

Function Name	<code>void HAL_PCD_MspDelInit (PCD_HandleTypeDef * hpcd)</code>
Function Description	Deinitializes PCD MSP.
Parameters	<ul style="list-style-type: none"> • <code>hpcd</code>: PCD handle
Return values	<ul style="list-style-type: none"> • None

43.3.10 HAL_PCD_Start

Function Name	<code>HAL_StatusTypeDef HAL_PCD_Start (PCD_HandleTypeDef * hpcd)</code>
Function Description	Start The USB OTG Device.

Parameters	<ul style="list-style-type: none"> hpcd: PCD handle
Return values	<ul style="list-style-type: none"> HAL status

43.3.11 HAL_PCD_Stop

Function Name	HAL_StatusTypeDef HAL_PCD_Stop (PCD_HandleTypeDef * hpcd)
Function Description	Stop The USB OTG Device.
Parameters	<ul style="list-style-type: none"> hpcd: PCD handle
Return values	<ul style="list-style-type: none"> HAL status

43.3.12 HAL_PCD_IRQHandler

Function Name	void HAL_PCD_IRQHandler (PCD_HandleTypeDef * hpcd)
Function Description	Handles PCD interrupt request.
Parameters	<ul style="list-style-type: none"> hpcd: PCD handle
Return values	<ul style="list-style-type: none"> HAL status

43.3.13 HAL_PCD_DataOutStageCallback

Function Name	void HAL_PCD_DataOutStageCallback (PCD_HandleTypeDef * hpcd, uint8_t epnum)
Function Description	Data OUT stage callback.
Parameters	<ul style="list-style-type: none"> hpcd: PCD handle epnum: endpoint number
Return values	<ul style="list-style-type: none"> None

43.3.14 HAL_PCD_DataInStageCallback

Function Name	void HAL_PCD_DataInStageCallback (PCD_HandleTypeDef * hpcd, uint8_t epnum)
Function Description	Data IN stage callback.
Parameters	<ul style="list-style-type: none"> hpcd: PCD handle epnum: endpoint number
Return values	<ul style="list-style-type: none"> None

43.3.15 HAL_PCD_SetupStageCallback

Function Name	void HAL_PCD_SetupStageCallback (PCD_HandleTypeDef * hpcd)
Function Description	Setup stage callback.
Parameters	<ul style="list-style-type: none"> hpcd: PCD handle
Return values	<ul style="list-style-type: none"> None

43.3.16 HAL_PCD_SOFCallback



Function Name	void HAL_PCD_SOFCallback (PCD_HandleTypeDef * hpcd)
Function Description	USB Start Of Frame callback.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle
Return values	<ul style="list-style-type: none"> • None

43.3.17 HAL_PCD_ResetCallback

Function Name	void HAL_PCD_ResetCallback (PCD_HandleTypeDef * hpcd)
Function Description	USB Reset callback.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle
Return values	<ul style="list-style-type: none"> • None

43.3.18 HAL_PCD_SuspendCallback

Function Name	void HAL_PCD_SuspendCallback (PCD_HandleTypeDef * hpcd)
Function Description	Suspend event callback.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle
Return values	<ul style="list-style-type: none"> • None

43.3.19 HAL_PCD_ResumeCallback

Function Name	void HAL_PCD_ResumeCallback (PCD_HandleTypeDef * hpcd)
Function Description	Resume event callback.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle
Return values	<ul style="list-style-type: none"> • None

43.3.20 HAL_PCD_ISOOUTIncompleteCallback

Function Name	void HAL_PCD_ISOOUTIncompleteCallback (PCD_HandleTypeDef * hpcd, uint8_t epi)
Function Description	Incomplete ISO OUT callback.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • epi: endpoint number
Return values	<ul style="list-style-type: none"> • None

43.3.21 HAL_PCD_ISOINIncompleteCallback

Function Name	void HAL_PCD_ISOINIncompleteCallback (PCD_HandleTypeDef * hpcd, uint8_t epi)
Function Description	Incomplete ISO IN callback.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • epi: endpoint number

Return values	<ul style="list-style-type: none"> None
---------------	--

43.3.22 HAL_PCD_ConnectCallback

Function Name **void HAL_PCD_ConnectCallback (PCD_HandleTypeDef * hpcd)**

Function Description Connection event callback.

Parameters

- hpcd:** PCD handle

Return values

- None

43.3.23 HAL_PCD_DisconnectCallback

Function Name **void HAL_PCD_DisconnectCallback (PCD_HandleTypeDef * hpcd)**

Function Description Disconnection event callback.

Parameters

- hpcd:** PCD handle

Return values

- None

43.3.24 HAL_PCD_DevConnect

Function Name **HAL_StatusTypeDef HAL_PCD_DevConnect (PCD_HandleTypeDef * hpcd)**

Function Description Connect the USB device.

Parameters

- hpcd:** PCD handle

Return values

- HAL status

43.3.25 HAL_PCD_DevDisconnect

Function Name **HAL_StatusTypeDef HAL_PCD_DevDisconnect (PCD_HandleTypeDef * hpcd)**

Function Description Disconnect the USB device.

Parameters

- hpcd:** PCD handle

Return values

- HAL status

43.3.26 HAL_PCD_SetAddress

Function Name **HAL_StatusTypeDef HAL_PCD_SetAddress (PCD_HandleTypeDef * hpcd, uint8_t address)**

Function Description Set the USB Device address.

Parameters

- hpcd:** PCD handle
- address:** new device address

Return values

- HAL status

43.3.27 HAL_PCD_EP_Open

Function Name **HAL_StatusTypeDef HAL_PCD_EP_Open**

(PCD_HandleTypeDef * hpcd, uint8_t ep_addr, uint16_t ep_mps, uint8_t ep_type)

Function Description	Open and configure an endpoint.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address • ep_mps: endpoint max packet size • ep_type: endpoint type
Return values	<ul style="list-style-type: none"> • HAL status

43.3.28 HAL_PCD_EP_Close

Function Name	HAL_StatusTypeDef HAL_PCD_EP_Close (PCD_HandleTypeDef * hpcd, uint8_t ep_addr)
Function Description	Deactivate an endpoint.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address
Return values	<ul style="list-style-type: none"> • HAL status

43.3.29 HAL_PCD_EP_Receive

Function Name	HAL_StatusTypeDef HAL_PCD_EP_Receive (PCD_HandleTypeDef * hpcd, uint8_t ep_addr, uint8_t * pBuf, uint32_t len)
Function Description	Receive an amount of data.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address • pBuf: pointer to the reception buffer • len: amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status

43.3.30 HAL_PCD_EP_GetRxCount

Function Name	uint16_t HAL_PCD_EP_GetRxCount (PCD_HandleTypeDef * hpcd, uint8_t ep_addr)
Function Description	Get Received Data Size.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address

Return values	Data Size
---------------	-----------

43.3.31 HAL_PCD_EP_Transmit

Function Name	HAL_StatusTypeDef HAL_PCD_EP_Transmit (PCD_HandleTypeDef * hpcd, uint8_t ep_addr, uint8_t * pBuf, uint32_t len)
Function Description	Send an amount of data.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address

-
- **pBuf:** pointer to the transmission buffer
 - **len:** amount of data to be sent
- Return values
- HAL status

43.3.32 HAL_PCD_EP_SetStall

Function Name	HAL_StatusTypeDef HAL_PCD_EP_SetStall (PCD_HandleTypeDef * hpcd, uint8_t ep_addr)
Function Description	Set a STALL condition over an endpoint.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address
Return values	<ul style="list-style-type: none"> • HAL status

43.3.33 HAL_PCD_EP_ClrStall

Function Name	HAL_StatusTypeDef HAL_PCD_EP_ClrStall (PCD_HandleTypeDef * hpcd, uint8_t ep_addr)
Function Description	Clear a STALL condition over in an endpoint.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address
Return values	<ul style="list-style-type: none"> • HAL status

43.3.34 HAL_PCD_EP_Flush

Function Name	HAL_StatusTypeDef HAL_PCD_EP_Flush (PCD_HandleTypeDef * hpcd, uint8_t ep_addr)
Function Description	Flush an endpoint.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • ep_addr: endpoint address
Return values	<ul style="list-style-type: none"> • HAL status

43.3.35 HAL_PCD_ActivateRemoteWakeUp

Function Name	HAL_StatusTypeDef HAL_PCD_ActivateRemoteWakeUp (PCD_HandleTypeDef * hpcd)
Function Description	Activate remote wakeup signalling.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle
Return values	<ul style="list-style-type: none"> • HAL status

43.3.36 HAL_PCD_DeActivateRemoteWakeUp

Function Name	HAL_StatusTypeDef HAL_PCD_DeActivateRemoteWakeUp (PCD_HandleTypeDef * hpcd)
Function Description	De-activate remote wakeup signalling.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle

Return values	• HAL status
---------------	--------------

43.3.37 HAL_PCD_GetState

Function Name	PCD_StateTypeDef HAL_PCD_GetState (PCD_HandleTypeDef * hpcd)
Function Description	Return the PCD handle state.
Parameters	• hpcd: PCD handle
Return values	• HAL state

43.4 PCD Firmware driver defines

43.4.1 PCD

PCD Exported Macros

<code>_HAL_PCD_ENABLE</code>	
<code>_HAL_PCD_DISABLE</code>	
<code>_HAL_PCD_GET_FLAG</code>	
<code>_HAL_PCD_CLEAR_FLAG</code>	
<code>_HAL_PCD_IS_INVALID_INTERRUPT</code>	
<code>_HAL_PCD_UNGATE_PHYCLOCK</code>	
<code>_HAL_PCD_GATE_PHYCLOCK</code>	
<code>_HAL_PCD_IS_PHY_SUSPENDED</code>	
<code>USB_OTG_FS_WAKEUP_EXTI_RISING_EDGE</code>	
<code>USB_OTG_FS_WAKEUP_EXTI_FALLING_EDGE</code>	
<code>USB_OTG_FS_WAKEUP_EXTI_RISING_FALLING_EDGE</code>	
<code>USB_OTG_HS_WAKEUP_EXTI_RISING_EDGE</code>	
<code>USB_OTG_HS_WAKEUP_EXTI_FALLING_EDGE</code>	
<code>USB_OTG_HS_WAKEUP_EXTI_RISING_FALLING_EDGE</code>	
<code>USB_OTG_HS_WAKEUP_EXTI_LINE</code>	External interrupt line 20 Connected to the USB HS EXTI Line
<code>USB_OTG_FS_WAKEUP_EXTI_LINE</code>	External interrupt line 18 Connected to the USB FS EXTI Line
<code>_HAL_USB_OTG_HS_WAKEUP_EXTI_ENABLE_IT</code>	

```
_HAL_USB_OTG_HS_WAKEUP_EXTI_DISABLE_IT
__HAL_USB_OTG_HS_WAKEUP_EXTI_GET_FLAG
__HAL_USB_OTG_HS_WAKEUP_EXTI_CLEAR_FLAG
__HAL_USB_OTG_HS_WAKEUP_EXTI_ENABLE_RISING_EDGE
__HAL_USB_OTG_HS_WAKEUP_EXTI_ENABLE_FALLING_EDGE
__HAL_USB_OTG_HS_WAKEUP_EXTI_ENABLE_RISING_FALLING_EDGE
__HAL_USB_OTG_HS_WAKEUP_EXTI_GENERATE_SWIT
__HAL_USB_OTG_FS_WAKEUP_EXTI_ENABLE_IT
__HAL_USB_OTG_FS_WAKEUP_EXTI_DISABLE_IT
__HAL_USB_OTG_FS_WAKEUP_EXTI_GET_FLAG
__HAL_USB_OTG_FS_WAKEUP_EXTI_CLEAR_FLAG
__HAL_USB_OTG_FS_WAKEUP_EXTI_ENABLE_RISING_EDGE
__HAL_USB_OTG_FS_WAKEUP_EXTI_ENABLE_FALLING_EDGE
__HAL_USB_OTG_FS_WAKEUP_EXTI_ENABLE_RISING_FALLING_EDGE
__HAL_USB_OTG_FS_WAKEUP_EXTI_GENERATE_SWIT
```

PCD Instance definition

```
IS_PCD_ALL_INSTANCE
```

PCD PHY Module

```
PCD_PHY_ULPI
```

```
PCD_PHY_EMBEDDED
```

PCD Private Macros

```
PCD_MIN
```

```
PCD_MAX
```

PCD Speed

```
PCD_SPEED_HIGH
```

```
PCD_SPEED_HIGH_IN_FULL
```

```
PCD_SPEED_FULL
```

Turnaround Timeout Value

```
USBD_HS_TRDT_VALUE
```

```
USBD_FS_TRDT_VALUE
```

44 HAL PCD Extension Driver

44.1 HAL PCD Extension Driver

44.2 PCDEEx Firmware driver API description

44.2.1 Extended features functions

This section provides functions allowing to:

- Update FIFO configuration

This section contains the following APIs:

- [*HAL_PCDEEx_SetTxFiFo\(\)*](#)
- [*HAL_PCDEEx_SetRxFiFo\(\)*](#)
- [*HAL_PCDEEx_ActivateLPM\(\)*](#)
- [*HAL_PCDEEx_DeActivateLPM\(\)*](#)
- [*HAL_PCDEEx_LPM_Callback\(\)*](#)

44.2.2 [*HAL_PCDEEx_SetTxFiFo*](#)

Function Name	<code>HAL_StatusTypeDef HAL_PCDEEx_SetTxFiFo (PCD_HandleTypeDef * hpcd, uint8_t fifo, uint16_t size)</code>
Function Description	Set Tx FIFO.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • fifo: The number of Tx fifo • size: Fifo size
Return values	<ul style="list-style-type: none"> • HAL status

44.2.3 [*HAL_PCDEEx_SetRxFiFo*](#)

Function Name	<code>HAL_StatusTypeDef HAL_PCDEEx_SetRxFiFo (PCD_HandleTypeDef * hpcd, uint16_t size)</code>
Function Description	Set Rx FIFO.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle • size: Size of Rx fifo
Return values	<ul style="list-style-type: none"> • HAL status

44.2.4 [*HAL_PCDEEx_ActivateLPM*](#)

Function Name	<code>HAL_StatusTypeDef HAL_PCDEEx_ActivateLPM (PCD_HandleTypeDef * hpcd)</code>
Function Description	Activate LPM feature.
Parameters	<ul style="list-style-type: none"> • hpcd: PCD handle
Return values	<ul style="list-style-type: none"> • HAL status

44.2.5 [*HAL_PCDEEx_DeActivateLPM*](#)

Function Name	HAL_StatusTypeDef HAL_PCDEx_DeActivateLPM (PCD_HandleTypeDef * hpcd)
Function Description	Deactivate LPM feature.
Parameters	<ul style="list-style-type: none">• hpcd: PCD handle
Return values	<ul style="list-style-type: none">• HAL status

44.2.6 HAL_PCDEx_LPM_Callback

Function Name	void HAL_PCDEx_LPM_Callback (PCD_HandleTypeDef * hpcd, PCD_LPM_MsgTypeDef msg)
Function Description	Send LPM message to user layer callback.
Parameters	<ul style="list-style-type: none">• hpcd: PCD handle• msg: LPM message
Return values	<ul style="list-style-type: none">• HAL status

44.3 PCDEEx Firmware driver defines

44.3.1 PCDEEx

45 HAL PWR Generic Driver

45.1 HAL PWR Generic Driver

45.2 PWR Firmware driver registers structures

45.2.1 PWR_PVDTTypeDef

Data Fields

- *uint32_t PVDLevel*
- *uint32_t Mode*

Field Documentation

- *uint32_t PWR_PVDTTypeDef::PVDLevel*
PVDLevel: Specifies the PVD detection level. This parameter can be a value of [PWR_PVD_detection_level](#)
- *uint32_t PWR_PVDTTypeDef::Mode*
Mode: Specifies the operating mode for the selected pins. This parameter can be a value of [PWR_PVD_Mode](#)

45.3 PWR Firmware driver API description

45.3.1 Initialization and de-initialization functions

After reset, the backup domain (RTC registers, RTC backup data registers and backup SRAM) is protected against possible unwanted write accesses. To enable access to the RTC Domain and RTC registers, proceed as follows:

- Enable the Power Controller (PWR) APB1 interface clock using the `_HAL_RCC_PWR_CLK_ENABLE()` macro.
- Enable access to RTC domain using the `HAL_PWR_EnableBkUpAccess()` function.

This section contains the following APIs:

- [`HAL_PWR_DeInit\(\)`](#)
- [`HAL_PWR_EnableBkUpAccess\(\)`](#)
- [`HAL_PWR_DisableBkUpAccess\(\)`](#)

45.3.2 Peripheral Control functions

PVD configuration

- The PVD is used to monitor the VDD power supply by comparing it to a threshold selected by the PVD Level (PLS[2:0] bits in the PWR_CR).
- A PVDO flag is available to indicate if VDD/VDDA is higher or lower than the PVD threshold. This event is internally connected to the EXTI line16 and can generate an

interrupt if enabled. This is done through __HAL_PWR_PVD_EXTI_ENABLE_IT() macro.

- The PVD is stopped in Standby mode.

Wake-up pin configuration

- Wake-up pin is used to wake up the system from Standby mode. This pin is forced in input pull-down configuration and is active on rising edges.
- There is one Wake-up pin: Wake-up Pin 1 on PA.00.
 - For STM32F446xx there are two Wake-Up pins: Pin1 on PA.00 and Pin2 on PC.13
 - For STM32F410xx/STM32F412xG there are three Wake-Up pins: Pin1 on PA.00, Pin2 on PC.00 and Pin3 on PC.01

Low Power modes configuration

The devices feature 3 low-power modes:

- Sleep mode: Cortex-M4 core stopped, peripherals kept running.
- Stop mode: all clocks are stopped, regulator running, regulator in low power mode
- Standby mode: 1.2V domain powered off.

Sleep mode

- Entry: The Sleep mode is entered by using the HAL_PWR_EnterSLEEPMode(PWR_MAINREGULATOR_ON, PWR_SLEEPENTRY_WFI) functions with
 - PWR_SLEEPENTRY_WFI: enter SLEEP mode with WFI instruction
 - PWR_SLEEPENTRY_WFE: enter SLEEP mode with WFE instruction. The Regulator parameter is not used for the STM32F4 family and is kept as parameter just to maintain compatibility with the lower power families (STM32L).
- Exit: Any peripheral interrupt acknowledged by the nested vectored interrupt controller (NVIC) can wake up the device from Sleep mode.

Stop mode

In Stop mode, all clocks in the 1.2V domain are stopped, the PLL, the HSI, and the HSE RC oscillators are disabled. Internal SRAM and register contents are preserved. The voltage regulator can be configured either in normal or low-power mode. To minimize the consumption In Stop mode, FLASH can be powered off before entering the Stop mode using the HAL_PWREx_EnableFlashPowerDown() function. It can be switched on again by software after exiting the Stop mode using the HAL_PWREx_DisableFlashPowerDown() function.

- Entry: The Stop mode is entered using the HAL_PWR_EnterSTOPMode(PWR_MAINREGULATOR_ON) function with:
 - Main regulator ON.
 - Low Power regulator ON.
- Exit: Any EXTI Line (Internal or External) configured in Interrupt/Event mode.

Standby mode

- The Standby mode allows to achieve the lowest power consumption. It is based on the Cortex-M4 deep sleep mode, with the voltage regulator disabled. The 1.2V domain is consequently powered off. The PLL, the HSI oscillator and the HSE oscillator are also switched off. SRAM and register contents are lost except for the RTC registers, RTC backup registers, backup SRAM and Standby circuitry. The voltage regulator is OFF.
 - Entry:
 - The Standby mode is entered using the HAL_PWR_EnterSTANDBYMode() function.
 - Exit:
 - WKUP pin rising edge, RTC alarm (Alarm A and Alarm B), RTC wake-up, tamper event, time-stamp event, external reset in NRST pin, IWDG reset.

Auto-wake-up (AWU) from low-power mode

- The MCU can be woken up from low-power mode by an RTC Alarm event, an RTC Wake-up event, a tamper event or a time-stamp event, without depending on an external interrupt (Auto-wake-up mode).
- RTC auto-wake-up (AWU) from the Stop and Standby modes
 - To wake up from the Stop mode with an RTC alarm event, it is necessary to configure the RTC to generate the RTC alarm using the HAL_RTC_SetAlarm_IT() function.
 - To wake up from the Stop mode with an RTC Tamper or time stamp event, it is necessary to configure the RTC to detect the tamper or time stamp event using the HAL_RTCEEx_SetTimeStamp_IT() or HAL_RTCEEx_SetTamper_IT() functions.
 - To wake up from the Stop mode with an RTC Wake-up event, it is necessary to configure the RTC to generate the RTC Wake-up event using the HAL_RTCEEx_SetWakeUpTimer_IT() function.

This section contains the following APIs:

- [**HAL_PWR_ConfigPVD\(\)**](#)
- [**HAL_PWR_EnablePVD\(\)**](#)
- [**HAL_PWR_DisablePVD\(\)**](#)
- [**HAL_PWR_EnableWakeUpPin\(\)**](#)
- [**HAL_PWR_DisableWakeUpPin\(\)**](#)
- [**HAL_PWR_EnterSLEEPMode\(\)**](#)
- [**HAL_PWR_EnterSTOPMode\(\)**](#)
- [**HAL_PWR_EnterSTANDBYMode\(\)**](#)
- [**HAL_PWR_PVD_IRQHandler\(\)**](#)
- [**HAL_PWR_PVDCallback\(\)**](#)
- [**HAL_PWR_EnableSleepOnExit\(\)**](#)
- [**HAL_PWR_DisableSleepOnExit\(\)**](#)
- [**HAL_PWR_EnableSEVOnPend\(\)**](#)
- [**HAL_PWR_DisableSEVOnPend\(\)**](#)

45.3.3 HAL_PWR_DeInit

Function Name	void HAL_PWR_DeInit (void)
Function Description	Deinitializes the HAL PWR peripheral registers to their default reset values.
Return values	<ul style="list-style-type: none"> • None

45.3.4 HAL_PWR_EnableBkUpAccess

Function Name	void HAL_PWR_EnableBkUpAccess (void)
Function Description	Enables access to the backup domain (RTC registers, RTC backup data registers and backup SRAM).
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • If the HSE divided by 2, 3, ..31 is used as the RTC clock, the Backup Domain Access should be kept enabled.

45.3.5 HAL_PWR_DisableBkUpAccess

Function Name	void HAL_PWR_DisableBkUpAccess (void)
Function Description	Disables access to the backup domain (RTC registers, RTC backup data registers and backup SRAM).
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • If the HSE divided by 2, 3, ..31 is used as the RTC clock, the Backup Domain Access should be kept enabled.

45.3.6 HAL_PWR_ConfigPVD

Function Name	void HAL_PWR_ConfigPVD (PWR_PVDTTypeDef * sConfigPVD)
Function Description	Configures the voltage threshold detected by the Power Voltage Detector(PVD).
Parameters	<ul style="list-style-type: none"> • sConfigPVD: pointer to an PWR_PVDTTypeDef structure that contains the configuration information for the PVD.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • Refer to the electrical characteristics of your device datasheet for more details about the voltage threshold corresponding to each detection level.

45.3.7 HAL_PWR_EnablePVD

Function Name	void HAL_PWR_EnablePVD (void)
Function Description	Enables the Power Voltage Detector(PVD).
Return values	<ul style="list-style-type: none"> • None

45.3.8 HAL_PWR_DisablePVD

Function Name	void HAL_PWR_DisablePVD (void)
Function Description	Disables the Power Voltage Detector(PVD).
Return values	<ul style="list-style-type: none"> • None

45.3.9 HAL_PWR_EnableWakeUpPin

Function Name	void HAL_PWR_EnableWakeUpPin (uint32_t WakeUpPinx)
Function Description	Enables the Wake-up PINx functionality.

Parameters	<ul style="list-style-type: none"> • WakeUpPinx: Specifies the Power Wake-Up pin to enable. This parameter can be one of the following values: PWR_WAKEUP_PIN1/PWR_WAKEUP_PIN2 available only on STM32F410xx/STM32F446xx/STM32F412xG devices PWR_WAKEUP_PIN3 available only on STM32F410xx/STM32F412xG devices
Return values	<ul style="list-style-type: none"> • None

45.3.10 HAL_PWR_DisableWakeUpPin

Function Name	<code>void HAL_PWR_DisableWakeUpPin (uint32_t WakeUpPinx)</code>
Function Description	Disables the Wake-up PINx functionality.
Parameters	<ul style="list-style-type: none"> • WakeUpPinx: Specifies the Power Wake-Up pin to disable. This parameter can be one of the following values: PWR_WAKEUP_PIN1/PWR_WAKEUP_PIN2 available only on STM32F410xx/STM32F446xx/STM32F412xG devices PWR_WAKEUP_PIN3 available only on STM32F410xx/STM32F412xG devices
Return values	<ul style="list-style-type: none"> • None

45.3.11 HAL_PWR_EnterSLEEPMode

Function Name	<code>void HAL_PWR_EnterSLEEPMode (uint32_t Regulator, uint8_t SLEEPEntry)</code>
Function Description	Enters Sleep mode.
Parameters	<ul style="list-style-type: none"> • Regulator: Specifies the regulator state in SLEEP mode. This parameter can be one of the following values: PWR_MAINREGULATOR_ON: SLEEP mode with regulator ON PWR_LOWPOWERREGULATOR_ON: SLEEP mode with low power regulator ON • SLEEPEntry: Specifies if SLEEP mode is entered with WFI or WFE instruction. This parameter can be one of the following values: PWR_SLEEPENTRY_WFI: enter SLEEP mode with WFI instruction PWR_SLEEPENTRY_WFE: enter SLEEP mode with WFE instruction
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • In Sleep mode, all I/O pins keep the same state as in Run mode. • In Sleep mode, the systick is stopped to avoid exit from this mode with systick interrupt when used as time base for Timeout • This parameter is not used for the STM32F4 family and is kept as parameter just to maintain compatibility with the lower power families.

45.3.12 HAL_PWR_EnterSTOPMode

Function Name	<code>void HAL_PWR_EnterSTOPMode (uint32_t Regulator, uint8_t STOPEntry)</code>
---------------	---

Function Description	Enters Stop mode.
Parameters	<ul style="list-style-type: none"> Regulator: Specifies the regulator state in Stop mode. This parameter can be one of the following values: PWR_MAINREGULATOR_ON: Stop mode with regulator ONPWR_LOWPOWERREGULATOR_ON: Stop mode with low power regulator ON STOPEntry: Specifies if Stop mode is entered with WFI or WFE instruction. This parameter can be one of the following values: PWR_STOPENTRY_WFI: Enter Stop mode with WFI instruction PWR_STOPENTRY_WFE: Enter Stop mode with WFE instruction
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> In Stop mode, all I/O pins keep the same state as in Run mode. When exiting Stop mode by issuing an interrupt or a wake-up event, the HSI RC oscillator is selected as system clock. When the voltage regulator operates in low power mode, an additional startup delay is incurred when waking up from Stop mode. By keeping the internal regulator ON during Stop mode, the consumption is higher although the startup time is reduced.

45.3.13 HAL_PWR_EnterSTANDBYMode

Function Name	void HAL_PWR_EnterSTANDBYMode (void)
Function Description	Enters Standby mode.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> In Standby mode, all I/O pins are high impedance except for: Reset pad (still available)RTC_AF1 pin (PC13) if configured for tamper, time-stamp, RTC Alarm out, or RTC clock calibration out.RTC_AF2 pin (PI8) if configured for tamper or time-stamp.WKUP pin 1 (PA0) if enabled.

45.3.14 HAL_PWR_PVD_IRQHandler

Function Name	void HAL_PWR_PVD_IRQHandler (void)
Function Description	This function handles the PWR PVD interrupt request.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This API should be called under the PVD_IRQHandler().

45.3.15 HAL_PWR_PVDCallback

Function Name	void HAL_PWR_PVDCallback (void)
Function Description	PWR PVD interrupt callback.
Return values	<ul style="list-style-type: none"> None

45.3.16 HAL_PWR_EnableSleepOnExit

Function Name	void HAL_PWR_EnableSleepOnExit (void)
Function Description	Indicates Sleep-On-Exit when returning from Handler mode to Thread mode.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> Set SLEEPONEXIT bit of SCR register. When this bit is set, the processor re-enters SLEEP mode when an interruption handling is over. Setting this bit is useful when the processor is expected to run only on interruptions handling.

45.3.17 HAL_PWR_DisableSleepOnExit

Function Name	void HAL_PWR_DisableSleepOnExit (void)
Function Description	Disables Sleep-On-Exit feature when returning from Handler mode to Thread mode.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> Clears SLEEPONEXIT bit of SCR register. When this bit is set, the processor re-enters SLEEP mode when an interruption handling is over.

45.3.18 HAL_PWR_EnableSEVOnPend

Function Name	void HAL_PWR_EnableSEVOnPend (void)
Function Description	Enables CORTEX M4 SEVONPEND bit.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> Sets SEVONPEND bit of SCR register. When this bit is set, this causes WFE to wake up when an interrupt moves from inactive to pended.

45.3.19 HAL_PWR_DisableSEVOnPend

Function Name	void HAL_PWR_DisableSEVOnPend (void)
Function Description	Disables CORTEX M4 SEVONPEND bit.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> Clears SEVONPEND bit of SCR register. When this bit is set, this causes WFE to wake up when an interrupt moves from inactive to pended.

45.4 PWR Firmware driver defines

45.4.1 PWR

PWR CR Register alias address

DBP_BIT_NUMBER

CR_DBP_BB

PVDE_BIT_NUMBER

CR_PVDE_BB
PMODE_BIT_NUMBER
CR_PMODE_BB
PWR CSR Register alias address
EWUP_BIT_NUMBER
CSR_EWUP_BB
PWR Exported Macro
`__HAL_PWR_GET_FLAG`

Description:

- Check PWR flag is set or not.

Parameters:

- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `PWR_FLAG_WU`: Wake Up flag. This flag indicates that a wakeup event was received from the WKUP pin or from the RTC alarm (Alarm A or Alarm B), RTC Tamper event, RTC TimeStamp event or RTC Wakeup. An additional wakeup event is detected if the WKUP pin is enabled (by setting the EWUP bit) when the WKUP pin level is already high.
 - `PWR_FLAG_SB`: StandBy flag. This flag indicates that the system was resumed from StandBy mode.
 - `PWR_FLAG_PVDO`: PVD Output. This flag is valid only if PVD is enabled by the `HAL_PWR_EnablePVD()` function. The PVD is stopped by Standby mode For this reason, this bit is equal to 0 after Standby or reset until the PVDE bit is set.
 - `PWR_FLAG_BRR`:

Backup regulator ready flag. This bit is not reset when the device wakes up from Standby mode or by a system reset or power reset.

- PWR_FLAG_VOSRDY : This flag indicates that the Regulator voltage scaling output selection is ready.

Return value:

- The __FLAG__ (TRUE or FALSE).

_HAL_PWR_CLEAR_FLAG

Description:

- Clear the PWR's pending flags.

Parameters:

- __FLAG__: specifies the flag to clear. This parameter can be one of the following values:
 - PWR_FLAG_WU: Wake Up flag
 - PWR_FLAG_SB: StandBy flag

_HAL_PWR_PVD_EXTI_ENABLE_IT

Description:

- Enable the PVD Exti Line 16.

Return value:

- None.

_HAL_PWR_PVD_EXTI_DISABLE_IT

Description:

- Disable the PVD EXTI Line 16.

Return value:

- None.

_HAL_PWR_PVD_EXTI_ENABLE_EVENT

Description:

- Enable event on PVD Exti Line 16.

Return value:

- None.

_HAL_PWR_PVD_EXTI_DISABLE_EVENT

Description:

- Disable event on PVD Exti

Line 16.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_ENABLE_RISING_EDGE`

Description:

- Enable the PVD Extended Interrupt Rising Trigger.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_DISABLE_RISING_EDGE`

Description:

- Disable the PVD Extended Interrupt Rising Trigger.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_ENABLE_FALLING_EDGE`

Description:

- Enable the PVD Extended Interrupt Falling Trigger.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_DISABLE_FALLING_EDGE`

Description:

- Disable the PVD Extended Interrupt Falling Trigger.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_ENABLE_RISING_FALLING_EDGE`

Description:

- PVD EXTI line configuration: set rising & falling edge trigger.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_DISABLE_RISING_FALLING_EDGE`

Description:

- Disable the PVD Extended Interrupt Rising & Falling Trigger.

Return value:

- None.

`__HAL_PWR_PVD_EXTI_GET_FLAG`

Description:

- checks whether the specified PVD Exti interrupt flag is set or not.

Return value:

- EXTI: PVD Line Status.

Description:

- Clear the PVD Exti flag.

Return value:

- None.

Description:

- Generates a Software interrupt on PVD EXT1 line.

Return value:

- None

PWR Flag

PWR_FLAG_WU
 PWR_FLAG_SB
 PWR_FLAG_PVDO
 PWR_FLAG_BRR
 PWR_FLAG_VOSRDY

PWR Private macros to check input parameters

IS_PWR_PVD_LEVEL
 IS_PWR_PVD_MODE
 IS_PWR_REGULATOR
 IS_PWR_SLEEP_ENTRY
 IS_PWR_STOP_ENTRY

PWR PVD detection level

PWR_PVDLEVEL_0
 PWR_PVDLEVEL_1
 PWR_PVDLEVEL_2
 PWR_PVDLEVEL_3
 PWR_PVDLEVEL_4
 PWR_PVDLEVEL_5
 PWR_PVDLEVEL_6
 PWR_PVDLEVEL_7

PWR PVD EXTI Line

PWR_EXTI_LINE_PVD External interrupt line 16 Connected to the PVD EXTI Line

PWR PVD Mode

PWR_PVD_MODE_NORMAL	basic mode is used
---------------------	--------------------

PWR_PVD_MODE_IT_RISING	External Interrupt Mode with Rising edge trigger detection
PWR_PVD_MODE_IT_FALLING	External Interrupt Mode with Falling edge trigger detection
PWR_PVD_MODE_IT_RISING_FALLING	External Interrupt Mode with Rising/Falling edge trigger detection
PWR_PVD_MODE_EVENT_RISING	Event Mode with Rising edge trigger detection
PWR_PVD_MODE_EVENT_FALLING	Event Mode with Falling edge trigger detection
PWR_PVD_MODE_EVENT_RISING_FALLING	Event Mode with Rising/Falling edge trigger detection

PWR PVD Mode Mask

PVD_MODE_IT

PVD_MODE_EVT

PVD_RISING_EDGE

PVD_FALLING_EDGE

PWR Register alias address

PWR_OFFSET

PWR_CR_OFFSET

PWR_CSR_OFFSET

PWR_CR_OFFSET_BB

PWR_CSR_OFFSET_BB

PWR Regulator state in SLEEP/STOP mode

PWR_MAINREGULATOR_ON

PWR_LOWPOWERREGULATOR_ON

PWR SLEEP mode entry

PWR_SLEEPENTRY_WFI

PWR_SLEEPENTRY_WFE

PWR STOP mode entry

PWR_STOPENTRY_WFI

PWR_STOPENTRY_WFE

PWR WakeUp Pins

PWR_WAKEUP_PIN1

46 HAL PWR Extension Driver

46.1 HAL PWR Extension Driver

46.2 PWREx Firmware driver API description

46.2.1 Peripheral extended features functions

Main and Backup Regulators configuration

- The backup domain includes 4 Kbytes of backup SRAM accessible only from the CPU, and address in 32-bit, 16-bit or 8-bit mode. Its content is retained even in Standby or VBAT mode when the low power backup regulator is enabled. It can be considered as an internal EEPROM when VBAT is always present. You can use the HAL_PWREx_EnableBkUpReg() function to enable the low power backup regulator.
- When the backup domain is supplied by VDD (analog switch connected to VDD) the backup SRAM is powered from VDD which replaces the VBAT power supply to save battery life.
- The backup SRAM is not mass erased by a tamper event. It is read protected to prevent confidential data, such as cryptographic private key, from being accessed. The backup SRAM can be erased only through the Flash interface when a protection level change from level 1 to level 0 is requested. Refer to the description of Read protection (RDP) in the Flash programming manual.
- The main internal regulator can be configured to have a tradeoff between performance and power consumption when the device does not operate at the maximum frequency. This is done through `__HAL_PWR_MAINREGULATORMODE_CONFIG()` macro which configure VOS bit in PWR_CR register Refer to the product datasheets for more details.

FLASH Power Down configuration

- By setting the FPDS bit in the PWR_CR register by using the HAL_PWREx_EnableFlashPowerDown() function, the Flash memory also enters power down mode when the device enters Stop mode. When the Flash memory is in power down mode, an additional startup delay is incurred when waking up from Stop mode.
- For STM32F42xxx/43xxx/446xx/469xx/479xx Devices, the scale can be modified only when the PLL is OFF and the HSI or HSE clock source is selected as system clock. The new value programmed is active only when the PLL is ON. When the PLL is OFF, the voltage scale 3 is automatically selected. Refer to the datasheets for more details.

Over-Drive and Under-Drive configuration

- For STM32F42xxx/43xxx/446xx/469xx/479xx Devices, in Run mode: the main regulator has 2 operating modes available:
 - Normal mode: The CPU and core logic operate at maximum frequency at a given voltage scaling (scale 1, scale 2 or scale 3)

- Over-drive mode: This mode allows the CPU and the core logic to operate at a higher frequency than the normal mode for a given voltage scaling (scale 1, scale 2 or scale 3). This mode is enabled through HAL_PWREx_EnableOverDrive() function and disabled by HAL_PWREx_DisableOverDrive() function, to enter or exit from Over-drive mode please follow the sequence described in Reference manual.
- For STM32F42xxx/43xxx/446xx/469xx/479xx Devices, in Stop mode: the main regulator or low power regulator supplies a low power voltage to the 1.2V domain, thus preserving the content of registers and internal SRAM. 2 operating modes are available:
 - Normal mode: the 1.2V domain is preserved in nominal leakage mode. This mode is only available when the main regulator or the low power regulator is used in Scale 3 or low voltage mode.
 - Under-drive mode: the 1.2V domain is preserved in reduced leakage mode. This mode is only available when the main regulator or the low power regulator is in low voltage mode.

This section contains the following APIs:

- [**HAL_PWREx_EnableBkUpReg\(\)**](#)
- [**HAL_PWREx_DisableBkUpReg\(\)**](#)
- [**HAL_PWREx_EnableFlashPowerDown\(\)**](#)
- [**HAL_PWREx_DisableFlashPowerDown\(\)**](#)
- [**HAL_PWREx_GetVoltageRange\(\)**](#)
- [**HAL_PWREx_ControlVoltageScaling\(\)**](#)
- [**HAL_PWREx_EnableWakeUpPinPolarityRisingEdge\(\)**](#)
- [**HAL_PWREx_EnableWakeUpPinPolarityFallingEdge\(\)**](#)
- [**HAL_PWREx_EnableOverDrive\(\)**](#)
- [**HAL_PWREx_DisableOverDrive\(\)**](#)
- [**HAL_PWREx_EnterUnderDriveSTOPMode\(\)**](#)

46.2.2 HAL_PWREx_EnableBkUpReg

Function Name **HAL_StatusTypeDef HAL_PWREx_EnableBkUpReg (void)**

Function Description Enables the Backup Regulator.

Return values

- HAL status

46.2.3 HAL_PWREx_DisableBkUpReg

Function Name **HAL_StatusTypeDef HAL_PWREx_DisableBkUpReg (void)**

Function Description Disables the Backup Regulator.

Return values

- HAL status

46.2.4 HAL_PWREx_EnableFlashPowerDown

Function Name **void HAL_PWREx_EnableFlashPowerDown (void)**

Function Description Enables the Flash Power Down in Stop mode.

Return values

- None

46.2.5 HAL_PWREx_DisableFlashPowerDown

Function Name **void HAL_PWREx_DisableFlashPowerDown (void)**

Function Description	Disables the Flash Power Down in Stop mode.
Return values	<ul style="list-style-type: none"> None

46.2.6 HAL_PWREx_GetVoltageRange

Function Name	<code>uint32_t HAL_PWREx_GetVoltageRange (void)</code>
Function Description	Return Voltage Scaling Range.
Return values	<ul style="list-style-type: none"> The configured scale for the regulator voltage(VOS bit field). The returned value can be one of the following: PWR_REGULATOR_VOLTAGE_SCALE1: Regulator voltage output Scale 1 mode PWR_REGULATOR_VOLTAGE_SCALE2: Regulator voltage output Scale 2 mode PWR_REGULATOR_VOLTAGE_SCALE3: Regulator voltage output Scale 3 mode

46.2.7 HAL_PWREx_ControlVoltageScaling

Function Name	<code>HAL_StatusTypeDef HAL_PWREx_ControlVoltageScaling (uint32_t VoltageScaling)</code>
Function Description	Configures the main internal regulator output voltage.
Parameters	<ul style="list-style-type: none"> VoltageScaling: specifies the regulator output voltage to achieve a tradeoff between performance and power consumption. This parameter can be one of the following values: PWR_REGULATOR_VOLTAGE_SCALE1: Regulator voltage output range 1 mode, the maximum value of fHCLK is 168 MHz. It can be extended to 180 MHz by activating the over-drive mode.PWR_REGULATOR_VOLTAGE_SCALE2: Regulator voltage output range 2 mode, the maximum value of fHCLK is 144 MHz. It can be extended to, 168 MHz by activating the over-drive mode.PWR_REGULATOR_VOLTAGE_SCALE3: Regulator voltage output range 3 mode, the maximum value of fHCLK is 120 MHz.
Return values	<ul style="list-style-type: none"> HAL Status
Notes	<ul style="list-style-type: none"> To update the system clock frequency(SYSCLK): Set the HSI or HSE as system clock frequency using the <code>HAL_RCC_ClockConfig()</code>.Call the <code>HAL_RCC_OscConfig()</code> to configure the PLL.Call <code>HAL_PWREx_ConfigVoltageScaling()</code> API to adjust the voltage scale.Set the new system clock frequency using the <code>HAL_RCC_ClockConfig()</code>. The scale can be modified only when the HSI or HSE clock source is selected as system clock source, otherwise the API returns <code>HAL_ERROR</code>. When the PLL is OFF, the voltage scale 3 is automatically selected and the VOS bits value in the PWR_CR1 register are not taken in account. This API forces the PLL state ON to allow the possibility to configure the voltage scale 1 or 2. The new voltage scale is active only when the PLL is ON.

46.2.8 HAL_PWREx_EnableWakeUpPinPolarityRisingEdge

Function Name **void HAL_PWREx_EnableWakeUpPinPolarityRisingEdge
(void)**

Function Description Enables Wakeup Pin Detection on high level (rising edge).

Return values • None

46.2.9 HAL_PWREx_EnableWakeUpPinPolarityFallingEdge

Function Name **void HAL_PWREx_EnableWakeUpPinPolarityFallingEdge
(void)**

Function Description Enables Wakeup Pin Detection on low level (falling edge).

Return values • None

46.2.10 HAL_PWREx_EnableOverDrive

Function Name **HAL_StatusTypeDef HAL_PWREx_EnableOverDrive (void)**

Function Description Activates the Over-Drive mode.

Return values • HAL status

Notes • This function can be used only for STM32F42xx/STM32F43xx/STM32F446xx/STM32F469xx/STM32F479xx devices. This mode allows the CPU and the core logic to operate at a higher frequency than the normal mode for a given voltage scaling (scale 1, scale 2 or scale 3).
• It is recommended to enter or exit Over-drive mode when the application is not running critical tasks and when the system clock source is either HSI or HSE. During the Over-drive switch activation, no peripheral clocks should be enabled. The peripheral clocks must be enabled once the Over-drive mode is activated.

46.2.11 HAL_PWREx_DisableOverDrive

Function Name **HAL_StatusTypeDef HAL_PWREx_DisableOverDrive (void)**

Function Description Deactivates the Over-Drive mode.

Return values • HAL status

Notes • This function can be used only for STM32F42xx/STM32F43xx/STM32F446xx/STM32F469xx/STM32F479xx devices. This mode allows the CPU and the core logic to operate at a higher frequency than the normal mode for a given voltage scaling (scale 1, scale 2 or scale 3).
• It is recommended to enter or exit Over-drive mode when the application is not running critical tasks and when the system clock source is either HSI or HSE. During the Over-drive switch activation, no peripheral clocks should be enabled. The peripheral clocks must be enabled once the Over-drive mode is activated.

46.2.12 HAL_PWREx_EnterUnderDriveSTOPMode

Function Name	HAL_StatusTypeDef HAL_PWREx_EnterUnderDriveSTOPMode (uint32_t Regulator, uint8_t STOPEntry)
Function Description	Enters in Under-Drive STOP mode.
Parameters	<ul style="list-style-type: none"> Regulator: specifies the regulator state in STOP mode. This parameter can be one of the following values: PWR_MAINREGULATOR_UNDERDRIVE_ON: Main Regulator in under-drive mode and Flash memory in power-down when the device is in Stop under-drive mode PWR_LOWPOWERREGULATOR_UNDERDRIVE_ON: Low Power Regulator in under-drive mode and Flash memory in power-down when the device is in Stop under-drive mode STOPEntry: specifies if STOP mode is entered with WFI or WFE instruction. This parameter can be one of the following values: PWR_SLEEPENTRY_WFI: enter STOP mode with WFI instruction PWR_SLEEPENTRY_WFE: enter STOP mode with WFE instruction
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This mode is only available for STM32F42xxx/STM324F3xxx/STM32F446xx/STM32F469xx/STM32F479xx devices. This mode can be selected only when the Under-Drive is already active This mode is enabled only with STOP low power mode. In this mode, the 1.2V domain is preserved in reduced leakage mode. This mode is only available when the main regulator or the low power regulator is in low voltage mode If the Under-drive mode was enabled, it is automatically disabled after exiting Stop mode. When the voltage regulator operates in Under-drive mode, an additional startup delay is induced when waking up from Stop mode. In Stop mode, all I/O pins keep the same state as in Run mode. When exiting Stop mode by issuing an interrupt or a wake-up event, the HSI RC oscillator is selected as system clock. When the voltage regulator operates in low power mode, an additional startup delay is incurred when waking up from Stop mode. By keeping the internal regulator ON during Stop mode, the consumption is higher although the startup time is reduced.

46.3 PWREx Firmware driver defines

46.3.1 PWREx

PWRx CSR Register alias address

BRE_BIT_NUMBER

CSR_BRE_BB

WUPP_BIT_NUMBER

CSR_WUPP_BB

PWREx Exported Constants

`__HAL_PWR_VOLTAGESCALING_CONFIG`**Description:**

- macros configure the main internal regulator output voltage.

Parameters:

- `__REGULATOR__`: specifies the regulator output voltage to achieve a tradeoff between performance and power consumption when the device does not operate at the maximum frequency (refer to the datasheets for more details). This parameter can be one of the following values:
 - `PWR_REGULATOR_VOLTAGE_SC_ALE1`: Regulator voltage output Scale 1 mode
 - `PWR_REGULATOR_VOLTAGE_SC_ALE2`: Regulator voltage output Scale 2 mode
 - `PWR_REGULATOR_VOLTAGE_SC_ALE3`: Regulator voltage output Scale 3 mode

Return value:

- None

`__HAL_PWR_OVERDRIVE_ENABLE`**Notes:**

- These macros can be used only for STM32F42xx/STM3243xx devices.

`__HAL_PWR_OVERDRIVE_DISABLE``__HAL_PWR_OVERDRIVESWITCHING_ENABLE`**Notes:**

- These macros can be used only for STM32F42xx/STM3243xx devices.

`__HAL_PWR_OVERDRIVESWITCHING_DISABLE``__HAL_PWR_UNDERDRIVE_ENABLE`**Notes:**

- This mode is enabled only with STOP low power mode. In this mode, the 1.2V domain is preserved in reduced leakage mode. This mode is only available when the main regulator or the low power regulator is in low voltage mode. If the Under-drive mode was enabled, it is automatically disabled after exiting Stop mode. When the voltage regulator operates in Under-drive mode, an additional startup delay is induced when waking up from Stop mode.

`__HAL_PWR_UNDERDRIVE_DISABLE``__HAL_PWR_GET_ODRUDR_FLAG`**Description:**

- Check PWR flag is set or not.

Parameters:

- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `PWR_FLAG_ODRDY`: This flag indicates that the Over-drive mode is ready
 - `PWR_FLAG_ODSWRDY`: This flag indicates that the Over-drive mode switching is ready
 - `PWR_FLAG_UDRDY`: This flag indicates that the Under-drive mode is enabled in Stop mode

Return value:

- The new state of `__FLAG__` (TRUE or FALSE).

Notes:

- These macros can be used only for STM32F42xx/STM3243xx devices.

`_HAL_PWR_CLEAR_ODRUDR_FLAG`

Notes:

- These macros can be used only for STM32F42xx/STM3243xx devices.

PWREx Private macros to check input parameters

`IS_PWR_REGULATOR_UNDERDRIVE`
`IS_PWR_VOLTAGE_SCALING_RANGE`
`IS_PWR_WAKEUP_PIN`

PWREx Over Under Drive Flag

`PWR_FLAG_ODRDY`
`PWR_FLAG_ODSWRDY`
`PWR_FLAG_UDRDY`

PWREx Private Constants

`PWR_OVERDRIVE_TIMEOUT_VALUE`
`PWR_Underdrive_TIMEOUT_VALUE`
`PWR_BKPREG_TIMEOUT_VALUE`
`PWR_VOSRDY_TIMEOUT_VALUE`

PWREx Register alias address

`FPDS_BIT_NUMBER`
`CR_FPDS_BB`
`ODEN_BIT_NUMBER`
`CR_ODEN_BB`

ODSWEN_BIT_NUMBER

CR_ODSWEN_BB

MRLVDS_BIT_NUMBER

CR_MRLVDS_BB

LPLVDS_BIT_NUMBER

CR_LPLVDS_BB

PWREx Regulator state in UnderDrive mode

PWR_MAINREGULATOR_UNDERDRIVE_ON

PWR_LOWPOWERREGULATOR_UNDERDRIVE_ON

PWREx Regulator Voltage Scale

PWR_REGULATOR_VOLTAGE_SCALE1

PWR_REGULATOR_VOLTAGE_SCALE2

PWR_REGULATOR_VOLTAGE_SCALE3

47 HAL QSPI Generic Driver

47.1 HAL QSPI Generic Driver

47.2 QSPI Firmware driver registers structures

47.2.1 QSPI_InitTypeDef

Data Fields

- *uint32_t ClockPrescaler*
- *uint32_t FifoThreshold*
- *uint32_t SampleShifting*
- *uint32_t FlashSize*
- *uint32_t ChipSelectHighTime*
- *uint32_t ClockMode*
- *uint32_t FlashID*
- *uint32_t DualFlash*

Field Documentation

- *uint32_t QSPI_InitTypeDef::ClockPrescaler*
- *uint32_t QSPI_InitTypeDef::FifoThreshold*
- *uint32_t QSPI_InitTypeDef::SampleShifting*
- *uint32_t QSPI_InitTypeDef::FlashSize*
- *uint32_t QSPI_InitTypeDef::ChipSelectHighTime*
- *uint32_t QSPI_InitTypeDef::ClockMode*
- *uint32_t QSPI_InitTypeDef::FlashID*
- *uint32_t QSPI_InitTypeDef::DualFlash*

47.2.2 QSPI_HandleTypeDef

Data Fields

- *QUADSPI_TypeDef * Instance*
- *QSPI_InitTypeDef Init*
- *uint8_t * pTxBuffPtr*
- *__IO uint16_t TxXferSize*
- *__IO uint16_t TxXferCount*
- *uint8_t * pRxBuffPtr*
- *__IO uint16_t RxXferSize*
- *__IO uint16_t RxXferCount*
- *DMA_HandleTypeDef * hdma*
- *__IO HAL_LockTypeDef Lock*
- *__IO HAL_QSPI_StateTypeDef State*
- *__IO uint32_t ErrorCode*
- *uint32_t Timeout*

Field Documentation

- `QUADSPI_TypeDef* QSPI_HandleTypeDef::Instance`
- `QSPI_InitTypeDef QSPI_HandleTypeDef::Init`
- `uint8_t* QSPI_HandleTypeDef::pTxBuffPtr`
- `_IO uint16_t QSPI_HandleTypeDef::TxXferSize`
- `_IO uint16_t QSPI_HandleTypeDef::TxXferCount`
- `uint8_t* QSPI_HandleTypeDef::pRxBuffPtr`
- `_IO uint16_t QSPI_HandleTypeDef::RxXferSize`
- `_IO uint16_t QSPI_HandleTypeDef::RxXferCount`
- `DMA_HandleTypeDef* QSPI_HandleTypeDef::hdma`
- `_IO HAL_LockTypeDef QSPI_HandleTypeDef::Lock`
- `_IO HAL_QSPI_StateTypeDef QSPI_HandleTypeDef::State`
- `_IO uint32_t QSPI_HandleTypeDef::ErrorCode`
- `uint32_t QSPI_HandleTypeDef::Timeout`

47.2.3 QSPI_CommandTypeDef

Data Fields

- `uint32_t Instruction`
- `uint32_t Address`
- `uint32_t AlternateBytes`
- `uint32_t AddressSize`
- `uint32_t AlternateBytesSize`
- `uint32_t DummyCycles`
- `uint32_t InstructionMode`
- `uint32_t AddressMode`
- `uint32_t AlternateByteMode`
- `uint32_t DataMode`
- `uint32_t NbData`
- `uint32_t DdrMode`
- `uint32_t DdrHoldHalfCycle`
- `uint32_t SIOOMode`

Field Documentation

- `uint32_t QSPI_CommandTypeDef::Instruction`
- `uint32_t QSPI_CommandTypeDef::Address`
- `uint32_t QSPI_CommandTypeDef::AlternateBytes`
- `uint32_t QSPI_CommandTypeDef::AddressSize`
- `uint32_t QSPI_CommandTypeDef::AlternateBytesSize`
- `uint32_t QSPI_CommandTypeDef::DummyCycles`
- `uint32_t QSPI_CommandTypeDef::InstructionMode`
- `uint32_t QSPI_CommandTypeDef::AddressMode`
- `uint32_t QSPI_CommandTypeDef::AlternateByteMode`
- `uint32_t QSPI_CommandTypeDef::DataMode`
- `uint32_t QSPI_CommandTypeDef::NbData`
- `uint32_t QSPI_CommandTypeDef::DdrMode`

-
- *uint32_t QSPI_CommandTypeDef::DdrHoldHalfCycle*
 - *uint32_t QSPI_CommandTypeDef::SIOOMode*

47.2.4 QSPI_AutoPollingTypeDef

Data Fields

- *uint32_t Match*
- *uint32_t Mask*
- *uint32_t Interval*
- *uint32_t StatusBytesSize*
- *uint32_t MatchMode*
- *uint32_t AutomaticStop*

Field Documentation

- *uint32_t QSPI_AutoPollingTypeDef::Match*
- *uint32_t QSPI_AutoPollingTypeDef::Mask*
- *uint32_t QSPI_AutoPollingTypeDef::Interval*
- *uint32_t QSPI_AutoPollingTypeDef::StatusBytesSize*
- *uint32_t QSPI_AutoPollingTypeDef::MatchMode*
- *uint32_t QSPI_AutoPollingTypeDef::AutomaticStop*

47.2.5 QSPI_MemoryMappedTypeDef

Data Fields

- *uint32_t TimeOutPeriod*
- *uint32_t TimeOutActivation*

Field Documentation

- *uint32_t QSPI_MemoryMappedTypeDef::TimeOutPeriod*
- *uint32_t QSPI_MemoryMappedTypeDef::TimeOutActivation*

47.3 QSPI Firmware driver API description

47.3.1 How to use this driver

Initialization

1. As prerequisite, fill in the HAL_QSPI_MsplInit() :
 - a. Enable QuadSPI clock interface with __HAL_RCC_QSPI_CLK_ENABLE().

- b. Reset QuadSPI IP with `_HAL_RCC_QSPI_FORCE_RESET()` and `_HAL_RCC_QSPI_RELEASE_RESET()`.
 - c. Enable the clocks for the QuadSPI GPIOs with `_HAL_RCC_GPIOx_CLK_ENABLE()`.
 - d. Configure these QuadSPI pins in alternate mode using `HAL_GPIO_Init()`.
 - e. If interrupt mode is used, enable and configure QuadSPI global interrupt with `HAL_NVIC_SetPriority()` and `HAL_NVIC_EnableIRQ()`.
 - f. If DMA mode is used, enable the clocks for the QuadSPI DMA channel with `_HAL_RCC_DMAX_CLK_ENABLE()`, configure DMA with `HAL_DMA_Init()`, link it with QuadSPI handle using `_HAL_LINKDMA()`, enable and configure DMA channel global interrupt with `HAL_NVIC_SetPriority()` and `HAL_NVIC_EnableIRQ()`.
2. Configure the flash size, the clock prescaler, the fifo threshold, the clock mode, the sample shifting and the CS high time using the `HAL_QSPI_Init()` function.

Indirect functional mode

1. Configure the command sequence using the `HAL_QSPI_Command()` or `HAL_QSPI_Command_IT()` functions :
 - a. Instruction phase : the mode used and if present the instruction opcode.
 - b. Address phase : the mode used and if present the size and the address value.
 - c. Alternate-bytes phase : the mode used and if present the size and the alternate bytes values.
 - d. Dummy-cycles phase : the number of dummy cycles (mode used is same as data phase).
 - e. Data phase : the mode used and if present the number of bytes.
 - f. Double Data Rate (DDR) mode : the activation (or not) of this mode and the delay if activated.
 - g. Sending Instruction Only Once (SIOO) mode : the activation (or not) of this mode.
2. If no data is required for the command, it is sent directly to the memory :
 - a. In polling mode, the output of the function is done when the transfer is complete.
 - b. In interrupt mode, `HAL_QSPI_CmdCpltCallback()` will be called when the transfer is complete.
3. For the indirect write mode, use `HAL_QSPI_Transmit()`, `HAL_QSPI_Transmit_DMA()` or `HAL_QSPI_Transmit_IT()` after the command configuration :
 - a. In polling mode, the output of the function is done when the transfer is complete.
 - b. In interrupt mode, `HAL_QSPI_FifoThresholdCallback()` will be called when the fifo threshold is reached and `HAL_QSPI_TxCpltCallback()` will be called when the transfer is complete.
 - c. In DMA mode, `HAL_QSPI_TxHalfCpltCallback()` will be called at the half transfer and `HAL_QSPI_TxCpltCallback()` will be called when the transfer is complete.
4. For the indirect read mode, use `HAL_QSPI_Receive()`, `HAL_QSPI_Receive_DMA()` or `HAL_QSPI_Receive_IT()` after the command configuration :
 - a. In polling mode, the output of the function is done when the transfer is complete.
 - b. In interrupt mode, `HAL_QSPI_FifoThresholdCallback()` will be called when the fifo threshold is reached and `HAL_QSPI_RxCpltCallback()` will be called when the transfer is complete.
 - c. In DMA mode, `HAL_QSPI_RxHalfCpltCallback()` will be called at the half transfer and `HAL_QSPI_RxCpltCallback()` will be called when the transfer is complete.

Auto-polling functional mode

1. Configure the command sequence and the auto-polling functional mode using the HAL_QSPI_AutoPolling() or HAL_QSPI_AutoPolling_IT() functions :
 - a. Instruction phase : the mode used and if present the instruction opcode.
 - b. Address phase : the mode used and if present the size and the address value.
 - c. Alternate-bytes phase : the mode used and if present the size and the alternate bytes values.
 - d. Dummy-cycles phase : the number of dummy cycles (mode used is same as data phase).
 - e. Data phase : the mode used.
 - f. Double Data Rate (DDR) mode : the activation (or not) of this mode and the delay if activated.
 - g. Sending Instruction Only Once (SIOO) mode : the activation (or not) of this mode.
 - h. The size of the status bytes, the match value, the mask used, the match mode (OR/AND), the polling interval and the automatic stop activation.
2. After the configuration :
 - a. In polling mode, the output of the function is done when the status match is reached. The automatic stop is activated to avoid an infinite loop.
 - b. In interrupt mode, HAL_QSPI_StatusMatchCallback() will be called each time the status match is reached.

Memory-mapped functional mode

1. Configure the command sequence and the memory-mapped functional mode using the HAL_QSPI_MemoryMapped() functions :
 - a. Instruction phase : the mode used and if present the instruction opcode.
 - b. Address phase : the mode used and the size.
 - c. Alternate-bytes phase : the mode used and if present the size and the alternate bytes values.
 - d. Dummy-cycles phase : the number of dummy cycles (mode used is same as data phase).
 - e. Data phase : the mode used.
 - f. Double Data Rate (DDR) mode : the activation (or not) of this mode and the delay if activated.
 - g. Sending Instruction Only Once (SIOO) mode : the activation (or not) of this mode.
 - h. The timeout activation and the timeout period.
2. After the configuration, the QuadSPI will be used as soon as an access on the AHB is done on the address range. HAL_QSPI_TimeOutCallback() will be called when the timeout expires.

Errors management and abort functionality

1. HAL_QSPI_GetError() function gives the error rised during the last operation.
2. HAL_QSPI_Abort() function aborts any on-going operation and flushes the fifo.
3. HAL_QSPI_GetState() function gives the current state of the HAL QuadSPI driver.

Workarounds linked to Silicon Limitation

1. Workarounds Implemented inside HAL Driver
 - Extra data written in the FIFO at the end of a read transfer

47.3.2 Initialization and Configuration functions

This subsection provides a set of functions allowing to :

- Initialize the QuadSPI.
- De-initialize the QuadSPI.

This section contains the following APIs:

- *HAL_QSPI_Init()*
- *HAL_QSPI_DelInit()*
- *HAL_QSPI_MspInit()*
- *HAL_QSPI_MspDelInit()*

47.3.3 IO operation functions

This subsection provides a set of functions allowing to :

- Handle the interrupts.
- Handle the command sequence.
- Transmit data in blocking, interrupt or DMA mode.
- Receive data in blocking, interrupt or DMA mode.
- Manage the auto-polling functional mode.
- Manage the memory-mapped functional mode.

This section contains the following APIs:

- *HAL_QSPI_IRQHandler()*
- *HAL_QSPI_Command()*
- *HAL_QSPI_Command_IT()*
- *HAL_QSPI_Transmit()*
- *HAL_QSPI_Receive()*
- *HAL_QSPI_Transmit_IT()*
- *HAL_QSPI_Receive_IT()*
- *HAL_QSPI_Transmit_DMA()*
- *HAL_QSPI_Receive_DMA()*
- *HAL_QSPI_AutoPolling()*
- *HAL_QSPI_AutoPolling_IT()*
- *HAL_QSPI_MemoryMapped()*
- *HAL_QSPI_ErrorCallback()*
- *HAL_QSPI_CmdCpltCallback()*
- *HAL_QSPI_RxCpltCallback()*
- *HAL_QSPI_TxCpltCallback()*
- *HAL_QSPI_RxHalfCpltCallback()*
- *HAL_QSPI_TxHalfCpltCallback()*
- *HAL_QSPI_FifoThresholdCallback()*
- *HAL_QSPI_StatusMatchCallback()*
- *HAL_QSPI_TimeOutCallback()*

47.3.4 Peripheral Control and State functions

This subsection provides a set of functions allowing to :

- Check in run-time the state of the driver.
- Check the error code set during last operation.
- Abort any operation.

This section contains the following APIs:

- `HAL_QSPI_GetState()`
- `HAL_QSPI_GetError()`
- `HAL_QSPI_Abort()`
- `HAL_QSPI_SetTimeout()`
- `HAL_QSPI_ErrorCallback()`
- `HAL_QSPI_FifoThresholdCallback()`
- `HAL_QSPI_CmdCpltCallback()`
- `HAL_QSPI_RxCpltCallback()`
- `HAL_QSPI_TxCpltCallback()`
- `HAL_QSPI_RxHalfCpltCallback()`
- `HAL_QSPI_TxHalfCpltCallback()`
- `HAL_QSPI_StatusMatchCallback()`
- `HAL_QSPI_TimeOutCallback()`

47.3.5 HAL_QSPI_Init

Function Name	<code>HAL_StatusTypeDef HAL_QSPI_Init (QSPI_HandleTypeDef * hqspi)</code>
Function Description	Initializes the QSPI mode according to the specified parameters in the QSPI_InitTypeDef and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • <code>hqspi</code>: qspi handle
Return values	<ul style="list-style-type: none"> • HAL status

47.3.6 HAL_QSPI_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_QSPI_DelInit (QSPI_HandleTypeDef * hqspi)</code>
Function Description	Delinitializes the QSPI peripheral.
Parameters	<ul style="list-style-type: none"> • <code>hqspi</code>: qspi handle
Return values	<ul style="list-style-type: none"> • HAL status

47.3.7 HAL_QSPI_MsplInit

Function Name	<code>void HAL_QSPI_MsplInit (QSPI_HandleTypeDef * hqspi)</code>
Function Description	QSPI MSP Init.
Parameters	<ul style="list-style-type: none"> • <code>hqspi</code>: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.8 HAL_QSPI_MspDelInit

Function Name	<code>void HAL_QSPI_MspDelInit (QSPI_HandleTypeDef * hqspi)</code>
Function Description	QSPI MSP Delinit.
Parameters	<ul style="list-style-type: none"> • <code>hqspi</code>: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.9 HAL_QSPI_IRQHandler

Function Name	void HAL_QSPI_IRQHandler (QSPI_HandleTypeDef * hspi)
Function Description	This function handles QSPI interrupt request.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None.

47.3.10 HAL_QSPI_Command

Function Name	HAL_StatusTypeDef HAL_QSPI_Command (QSPI_HandleTypeDef * hspi, QSPI_CommandTypeDef * cmd, uint32_t Timeout)
Function Description	Sets the command configuration.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle • cmd: : structure that contains the command configuration information • Timeout: : Time out duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Read or Write Modes

47.3.11 HAL_QSPI_Command_IT

Function Name	HAL_StatusTypeDef HAL_QSPI_Command_IT (QSPI_HandleTypeDef * hspi, QSPI_CommandTypeDef * cmd)
Function Description	Sets the command configuration in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle • cmd: : structure that contains the command configuration information
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Read or Write Modes

47.3.12 HAL_QSPI_Transmit

Function Name	HAL_StatusTypeDef HAL_QSPI_Transmit (QSPI_HandleTypeDef * hspi, uint8_t * pData, uint32_t Timeout)
Function Description	Transmit an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle • pData: pointer to data buffer • Timeout: : Time out duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Write Mode

47.3.13 HAL_QSPI_Receive

Function Name	HAL_StatusTypeDef HAL_QSPI_Receive (QSPI_HandleTypeDef * hspi, uint8_t * pData, uint32_t
---------------	---

Timeout)

Function Description	Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • pData: pointer to data buffer • Timeout: : Time out duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Read Mode

47.3.14 HAL_QSPI_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_QSPI_Transmit_IT (QSPI_HandleTypeDef * hqspi, uint8_t * pData)
Function Description	Send an amount of data in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • pData: pointer to data buffer
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Write Mode

47.3.15 HAL_QSPI_Receive_IT

Function Name	HAL_StatusTypeDef HAL_QSPI_Receive_IT (QSPI_HandleTypeDef * hqspi, uint8_t * pData)
Function Description	Receive an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • pData: pointer to data buffer
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Read Mode

47.3.16 HAL_QSPI_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_QSPI_Transmit_DMA (QSPI_HandleTypeDef * hqspi, uint8_t * pData)
Function Description	Sends an amount of data in non blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • pData: pointer to data buffer
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Indirect Write Mode

47.3.17 HAL_QSPI_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_QSPI_Receive_DMA (QSPI_HandleTypeDef * hqspi, uint8_t * pData)
Function Description	Receives an amount of data in non blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle

- **pData:** pointer to data buffer.
- Return values
- HAL status
- Notes
- This function is used only in Indirect Read Mode

47.3.18 HAL_QSPI_AutoPolling

Function Name	HAL_StatusTypeDef HAL_QSPI_AutoPolling (QSPI_HandleTypeDef * hqspi, QSPI_CommandTypeDef * cmd, QSPI_AutoPollingTypeDef * cfg, uint32_t Timeout)
Function Description	Configure the QSPI Automatic Polling Mode in blocking mode.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • cmd: structure that contains the command configuration information. • cfg: structure that contains the polling configuration information. • Timeout: : Time out duration
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Automatic Polling Mode

47.3.19 HAL_QSPI_AutoPolling_IT

Function Name	HAL_StatusTypeDef HAL_QSPI_AutoPolling_IT (QSPI_HandleTypeDef * hqspi, QSPI_CommandTypeDef * cmd, QSPI_AutoPollingTypeDef * cfg)
Function Description	Configure the QSPI Automatic Polling Mode in non-blocking mode.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • cmd: structure that contains the command configuration information. • cfg: structure that contains the polling configuration information.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Automatic Polling Mode

47.3.20 HAL_QSPI_MemoryMapped

Function Name	HAL_StatusTypeDef HAL_QSPI_MemoryMapped (QSPI_HandleTypeDef * hqspi, QSPI_CommandTypeDef * cmd, QSPI_MemoryMappedTypeDef * cfg)
Function Description	Configure the Memory Mapped mode.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle • cmd: structure that contains the command configuration information. • cfg: structure that contains the memory mapped configuration information.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is used only in Memory mapped Mode

47.3.21 HAL_QSPI_ErrorCallback

Function Name	void HAL_QSPI_ErrorCallback (QSPI_HandleTypeDef * hspi)
Function Description	Transfer Error callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.22 HAL_QSPI_CmdCpltCallback

Function Name	void HAL_QSPI_CmdCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Command completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.23 HAL_QSPI_RxCpltCallback

Function Name	void HAL_QSPI_RxCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.24 HAL_QSPI_TxCpltCallback

Function Name	void HAL_QSPI_TxCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.25 HAL_QSPI_RxHalfCpltCallback

Function Name	void HAL_QSPI_RxHalfCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Rx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.26 HAL_QSPI_TxHalfCpltCallback

Function Name	void HAL_QSPI_TxHalfCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Tx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle

Return values	<ul style="list-style-type: none"> • None
47.3.27 HAL_QSPI_FifoThresholdCallback	
Function Name	void HAL_QSPI_FifoThresholdCallback (QSPI_HandleTypeDefDef * hqspi)
Function Description	FIFO Threshold callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.28 HAL_QSPI_StatusMatchCallback	
Function Name	void HAL_QSPI_StatusMatchCallback (QSPI_HandleTypeDefDef * hqspi)
Function Description	Status Match callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.29 HAL_QSPI_TimeOutCallback	
Function Name	void HAL_QSPI_TimeOutCallback (QSPI_HandleTypeDefDef * hqspi)
Function Description	Timeout callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.30 HAL_QSPI_GetState	
Function Name	HAL_QSPI_StateTypeDef HAL_QSPI_GetState (QSPI_HandleTypeDefDef * hqspi)
Function Description	Return the QSPI state.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • HAL state
47.3.31 HAL_QSPI_GetError	
Function Name	uint32_t HAL_QSPI_GetError (QSPI_HandleTypeDefDef * hqspi)
Function Description	Return the QSPI error code.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • QSPI Error Code
47.3.32 HAL_QSPI_Abort	
Function Name	HAL_StatusTypeDef HAL_QSPI_Abort (QSPI_HandleTypeDefDef * hqspi)

Function Description	Abort the current transmission.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • HAL status
47.3.33 HAL_QSPI_SetTimeout	
Function Name	void HAL_QSPI_SetTimeout (QSPI_HandleTypeDef * hspi, uint32_t Timeout)
Function Description	Set QSPI timeout.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle. • Timeout: Timeout for the QSPI memory access.
Return values	<ul style="list-style-type: none"> • None
47.3.34 HAL_QSPI_ErrorCallback	
Function Name	void HAL_QSPI_ErrorCallback (QSPI_HandleTypeDef * hspi)
Function Description	Transfer Error callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.35 HAL_QSPI_FifoThresholdCallback	
Function Name	void HAL_QSPI_FifoThresholdCallback (QSPI_HandleTypeDef * hspi)
Function Description	FIFO Threshold callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.36 HAL_QSPI_CmdCpltCallback	
Function Name	void HAL_QSPI_CmdCpltCallback (QSPI_HandleTypeDef * hqspi)
Function Description	Command completed callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.37 HAL_QSPI_RxCpltCallback	
Function Name	void HAL_QSPI_RxCpltCallback (QSPI_HandleTypeDef * hqspi)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hqspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None
47.3.38 HAL_QSPI_TxCpltCallback	

Function Name	void HAL_QSPI_TxCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.39 HAL_QSPI_RxHalfCpltCallback

Function Name	void HAL_QSPI_RxHalfCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Rx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.40 HAL_QSPI_TxHalfCpltCallback

Function Name	void HAL_QSPI_TxHalfCpltCallback (QSPI_HandleTypeDef * hspi)
Function Description	Tx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.41 HAL_QSPI_StatusMatchCallback

Function Name	void HAL_QSPI_StatusMatchCallback (QSPI_HandleTypeDef * hspi)
Function Description	Status Match callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.42 HAL_QSPI_TimeOutCallback

Function Name	void HAL_QSPI_TimeOutCallback (QSPI_HandleTypeDef * hspi)
Function Description	Timeout callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle
Return values	<ul style="list-style-type: none"> • None

47.3.43 HAL_QSPI_GetState

Function Name	HAL_QSPI_StateTypeDef HAL_QSPI_GetState (QSPI_HandleTypeDef * hspi)
Function Description	Return the QSPI state.
Parameters	<ul style="list-style-type: none"> • hspi: QSPI handle

Return values	<ul style="list-style-type: none"> • HAL state
---------------	---

47.3.44 HAL_QSPI_GetError

Function Name	<code>uint32_t HAL_QSPI_GetError (QSPI_HandleTypeDef * hspi)</code>
Function Description	Return the QSPI error code.
Parameters	<ul style="list-style-type: none"> • <code>hspi</code>: QSPI handle
Return values	<ul style="list-style-type: none"> • QSPI Error Code

47.3.45 HAL_QSPI_Abort

Function Name	<code>HAL_StatusTypeDef HAL_QSPI_Abort (QSPI_HandleTypeDef * hspi)</code>
Function Description	Abort the current transmission.
Parameters	<ul style="list-style-type: none"> • <code>hspi</code>: QSPI handle
Return values	<ul style="list-style-type: none"> • HAL status

47.3.46 HAL_QSPI_SetTimeout

Function Name	<code>void HAL_QSPI_SetTimeout (QSPI_HandleTypeDef * hspi, uint32_t Timeout)</code>
Function Description	Set QSPI timeout.
Parameters	<ul style="list-style-type: none"> • <code>hspi</code>: QSPI handle. • <code>Timeout</code>: Timeout for the QSPI memory access.
Return values	<ul style="list-style-type: none"> • None

47.4 QSPI Firmware driver defines

47.4.1 QSPI

QSPI Address Mode

<code>QSPI_ADDRESS_NONE</code>	No address
<code>QSPI_ADDRESS_1_LINE</code>	Address on a single line
<code>QSPI_ADDRESS_2_LINES</code>	Address on two lines
<code>QSPI_ADDRESS_4_LINES</code>	Address on four lines

QSPI Address Size

<code>QSPI_ADDRESS_8_BITS</code>	8-bit address
<code>QSPI_ADDRESS_16_BITS</code>	16-bit address
<code>QSPI_ADDRESS_24_BITS</code>	24-bit address
<code>QSPI_ADDRESS_32_BITS</code>	32-bit address

QSPI Alternate Bytes Mode

<code>QSPI_ALTERNATE_BYTES_NONE</code>	No alternate bytes
<code>QSPI_ALTERNATE_BYTES_1_LINE</code>	Alternate bytes on a single line

QSPI_ALTERNATE_BYTES_2_LINES	Alternate bytes on two lines
QSPI_ALTERNATE_BYTES_4_LINES	Alternate bytes on four lines

QSPI Alternate Bytes Size

QSPI_ALTERNATE_BYTES_8_BITS	8-bit alternate bytes
QSPI_ALTERNATE_BYTES_16_BITS	16-bit alternate bytes
QSPI_ALTERNATE_BYTES_24_BITS	24-bit alternate bytes
QSPI_ALTERNATE_BYTES_32_BITS	32-bit alternate bytes

QSPI Automatic Stop

QSPI_AUTOMATIC_STOP_DISABLE	AutoPolling stops only with abort or QSPI disabling
QSPI_AUTOMATIC_STOP_ENABLE	AutoPolling stops as soon as there is a match

QSPI Chip Select High Time

QSPI_CS_HIGH_TIME_1_CYCLE	nCS stay high for at least 1 clock cycle between commands
QSPI_CS_HIGH_TIME_2_CYCLE	nCS stay high for at least 2 clock cycles between commands
QSPI_CS_HIGH_TIME_3_CYCLE	nCS stay high for at least 3 clock cycles between commands
QSPI_CS_HIGH_TIME_4_CYCLE	nCS stay high for at least 4 clock cycles between commands
QSPI_CS_HIGH_TIME_5_CYCLE	nCS stay high for at least 5 clock cycles between commands
QSPI_CS_HIGH_TIME_6_CYCLE	nCS stay high for at least 6 clock cycles between commands
QSPI_CS_HIGH_TIME_7_CYCLE	nCS stay high for at least 7 clock cycles between commands
QSPI_CS_HIGH_TIME_8_CYCLE	nCS stay high for at least 8 clock cycles between commands

QSPI Clock Mode

QSPI_CLOCK_MODE_0	Clk stays low while nCS is released
QSPI_CLOCK_MODE_3	Clk goes high while nCS is released

QSPI Clock Prescaler

IS_QSPI_CLOCK_PRESCALER

QSPI Data Mode

QSPI_DATA_NONE	No data
QSPI_DATA_1_LINE	Data on a single line
QSPI_DATA_2_LINES	Data on two lines
QSPI_DATA_4_LINES	Data on four lines

QSPI Ddr HoldHalfCycle

`QSPI_DDR_HHC_ANALOG_DELAY` Delay the data output using analog delay in DDR mode

`QSPI_DDR_HHC_HALF_CLK_DELAY` Delay the data output by 1/2 clock cycle in DDR mode

QSPI Ddr Mode

`QSPI_DDR_MODE_DISABLE` Double data rate mode disabled

`QSPI_DDR_MODE_ENABLE` Double data rate mode enabled

QSPI Dual Flash Mode

`QSPI_DUALFLASH_ENABLE`

`QSPI_DUALFLASH_DISABLE`

QSPI Dummy Cycles

`IS_QSPI_DUMMY_CYCLES`

QSPI Error Code

`HAL_QSPI_ERROR_NONE` No error

`HAL_QSPI_ERROR_TIMEOUT` Timeout error

`HAL_QSPI_ERROR_TRANSFER` Transfer error

`HAL_QSPI_ERROR_DMA` DMA transfer error

QSPI Exported Macros

`_HAL_QSPI_RESET_HANDLE_STATE` **Description:**

- Reset QSPI handle state.

Parameters:

- `_HANDLE_`: QSPI handle.

Return value:

- None

`_HAL_QSPI_ENABLE`

Description:

- Enable QSPI.

Parameters:

- `_HANDLE_`: specifies the QSPI Handle.

Return value:

- None

`_HAL_QSPI_DISABLE`

Description:

- Disable QSPI.

Parameters:

- `_HANDLE_`: specifies the QSPI Handle.

Return value:

- None

`_HAL_QSPI_ENABLE_IT`

Description:

-
- Enables the specified QSPI interrupt.

Parameters:

- HANDLE: specifies the QSPI Handle.
- INTERRUPT: specifies the QSPI interrupt source to enable. This parameter can be one of the following values:
 - QSPI_IT_TO: QSPI Time out interrupt
 - QSPI_IT_SM: QSPI Status match interrupt
 - QSPI_IT_FT: QSPI FIFO threshold interrupt
 - QSPI_IT_TC: QSPI Transfer complete interrupt
 - QSPI_IT_TE: QSPI Transfer error interrupt

Return value:

- None

_HAL_QSPI_DISABLE_IT

- Description:**
- Disables the specified QSPI interrupt.

Parameters:

- HANDLE: specifies the QSPI Handle.
- INTERRUPT: specifies the QSPI interrupt source to disable. This parameter can be one of the following values:
 - QSPI_IT_TO: QSPI Timeout interrupt
 - QSPI_IT_SM: QSPI Status match interrupt
 - QSPI_IT_FT: QSPI FIFO threshold interrupt
 - QSPI_IT_TC: QSPI Transfer complete interrupt
 - QSPI_IT_TE: QSPI Transfer error interrupt

Return value:

- None

_HAL_QSPI_GET_IT_SOURCE

- Description:**
- Checks whether the specified QSPI interrupt source is enabled.

Parameters:

- HANDLE: specifies the QSPI Handle.
- INTERRUPT: specifies the QSPI interrupt source to check. This parameter can be one of the following values:
 - QSPI_IT_TO: QSPI Time out interrupt
 - QSPI_IT_SM: QSPI Status match

- interrupt
- QSPI_IT_FT: QSPI FIFO threshold interrupt
- QSPI_IT_TC: QSPI Transfer complete interrupt
- QSPI_IT_TE: QSPI Transfer error interrupt

Return value:

- The new state of __INTERRUPT__ (TRUE or FALSE).

[__HAL_QSPI_GET_FLAG](#)**Description:**

- Get the selected QSPI's flag status.

Parameters:

- __HANDLE__: specifies the QSPI Handle.
- __FLAG__: specifies the QSPI flag to check. This parameter can be one of the following values:
 - QSPI_FLAG_BUSY: QSPI Busy flag
 - QSPI_FLAG_TO: QSPI Time out flag
 - QSPI_FLAG_SM: QSPI Status match flag
 - QSPI_FLAG_FT: QSPI FIFO threshold flag
 - QSPI_FLAG_TC: QSPI Transfer complete flag
 - QSPI_FLAG_TE: QSPI Transfer error flag

Return value:

- None

[__HAL_QSPI_CLEAR_FLAG](#)**Description:**

- Clears the specified QSPI's flag status.

Parameters:

- __HANDLE__: specifies the QSPI Handle.
- __FLAG__: specifies the QSPI clear register flag that needs to be set. This parameter can be one of the following values:
 - QSPI_FLAG_TO: QSPI Time out flag
 - QSPI_FLAG_SM: QSPI Status match flag
 - QSPI_FLAG_TC: QSPI Transfer complete flag
 - QSPI_FLAG_TE: QSPI Transfer error flag

Return value:

- None

QSPI Fifo Threshold

IS_QSPI_FIFO_THRESHOLD

QSPI Flags

QSPI_FLAG_BUSY	Busy flag: operation is ongoing
QSPI_FLAG_TO	Timeout flag: timeout occurs in memory-mapped mode
QSPI_FLAG_SM	Status match flag: received data matches in autopolling mode
QSPI_FLAG_FT	Fifo threshold flag: Fifo threshold reached or data left after read from memory is complete
QSPI_FLAG_TC	Transfer complete flag: programmed number of data have been transferred or the transfer has been aborted
QSPI_FLAG_TE	Transfer error flag: invalid address is being accessed

QSPI Flash Size

IS_QSPI_FLASH_SIZE

QSPI Flash Select

QSPI_FLASH_ID_1

QSPI_FLASH_ID_2

QSPI Instruction

IS_QSPI_INSTRUCTION

QSPI Instruction Mode

QSPI_INSTRUCTION_NONE	No instruction
QSPI_INSTRUCTION_1_LINE	Instruction on a single line
QSPI_INSTRUCTION_2_LINES	Instruction on two lines
QSPI_INSTRUCTION_4_LINES	Instruction on four lines

QSPI Interrupts

QSPI_IT_TO	Interrupt on the timeout flag
QSPI_IT_SM	Interrupt on the status match flag
QSPI_IT_FT	Interrupt on the fifo threshold flag
QSPI_IT_TC	Interrupt on the transfer complete flag
QSPI_IT_TE	Interrupt on the transfer error flag

QSPI Interval

IS_QSPI_INTERVAL

QSPI Match Mode

QSPI_MATCH_MODE_AND	AND match mode between unmasked bits
QSPI_MATCH_MODE_OR	OR match mode between unmasked bits

QSPI Private Constants

QSPI_FUNCTIONAL_MODE_INDIRECT_WRITE	Indirect write mode
QSPI_FUNCTIONAL_MODE_INDIRECT_READ	Indirect read mode

QSPI_FUNCTIONAL_MODE_AUTO_POLLING	Automatic polling mode
QSPI_FUNCTIONAL_MODE_MEMORY_MAPPED	Memory-mapped mode

QSPI Private Macros

IS_QSPI_FUNCTIONAL_MODE
 IS_QSPI_SSHIFT
 IS_QSPI_CS_HIGH_TIME
 IS_QSPI_CLOCK_MODE
 IS_QSPI_FLASH_ID
 IS_QSPI_DUAL_FLASH_MODE
 IS_QSPI_ADDRESS_SIZE
 IS_QSPI_ALTERNATE_BYTES_SIZE
 IS_QSPI_INSTRUCTION_MODE
 IS_QSPI_ADDRESS_MODE
 IS_QSPI_ALTERNATE_BYTES_MODE
 IS_QSPI_DATA_MODE
 IS_QSPI_DDR_MODE
 IS_QSPI_DDR_HHC
 IS_QSPI_SIOO_MODE
 IS_QSPI_MATCH_MODE
 IS_QSPI_AUTOMATIC_STOP
 IS_QSPI_TIMEOUT_ACTIVATION
 IS_QSPI_GET_FLAG
 IS_QSPI_IT

QSPI Sample Shifting

QSPI_SAMPLE_SHIFTING_NONE	No clock cycle shift to sample data
QSPI_SAMPLE_SHIFTING_HALFCYCLE	1/2 clock cycle shift to sample data

QSPI SIOO Mode

QSPI_SIOO_INST_EVERY_CMD	Send instruction on every transaction
QSPI_SIOO_INST_ONLY_FIRST_CMD	Send instruction only for the first command

QSPI Status Bytes Size

IS_QSPI_STATUS_BYTES_SIZE

QSPI TimeOut Activation

QSPI_TIMEOUT_COUNTER_DISABLE	Timeout counter disabled, nCS remains active
QSPI_TIMEOUT_COUNTER_ENABLE	Timeout counter enabled, nCS released when timeout expires

QSPI TimeOut Period

IS_QSPI_TIMEOUT_PERIOD

QSPI Timeout definition

HAL_QPSI_TIMEOUT_DEFAULT_VALUE

48 HAL RCC Generic Driver

48.1 HAL RCC Generic Driver

48.2 RCC Firmware driver registers structures

48.2.1 RCC_OsclInitTypeDef

Data Fields

- *uint32_t OscillatorType*
- *uint32_t HSEState*
- *uint32_t LSEState*
- *uint32_t HSISState*
- *uint32_t HSICalibrationValue*
- *uint32_t LSISState*
- *RCC_PLLInitTypeDef PLL*

Field Documentation

- ***uint32_t RCC_OsclInitTypeDef::OscillatorType***
The oscillators to be configured. This parameter can be a value of [*RCC_Oscillator_Type*](#)
- ***uint32_t RCC_OsclInitTypeDef::HSEState***
The new state of the HSE. This parameter can be a value of [*RCC_HSE_Config*](#)
- ***uint32_t RCC_OsclInitTypeDef::LSEState***
The new state of the LSE. This parameter can be a value of [*RCC_LSE_Config*](#)
- ***uint32_t RCC_OsclInitTypeDef::HSISState***
The new state of the HSI. This parameter can be a value of [*RCC_HSI_Config*](#)
- ***uint32_t RCC_OsclInitTypeDef::HSICalibrationValue***
The calibration trimming value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0x1F
- ***uint32_t RCC_OsclInitTypeDef::LSISState***
The new state of the LSI. This parameter can be a value of [*RCC_LSI_Config*](#)
- ***RCC_PLLInitTypeDef RCC_OsclInitTypeDef::PLL***
PLL structure parameters

48.2.2 RCC_ClkInitTypeDef

Data Fields

- *uint32_t ClockType*
- *uint32_t SYSCLKSource*
- *uint32_t AHBCLKDivider*
- *uint32_t APB1CLKDivider*
- *uint32_t APB2CLKDivider*

Field Documentation

- ***uint32_t RCC_ClkInitTypeDef::ClockType***
The clock to be configured. This parameter can be a value of [**RCC_System_Clock_Type**](#)
- ***uint32_t RCC_ClkInitTypeDef::SYSCLKSource***
The clock source (SYSCLKS) used as system clock. This parameter can be a value of [**RCC_System_Clock_Source**](#)
- ***uint32_t RCC_ClkInitTypeDef::AHBCLKDivider***
The AHB clock (HCLK) divider. This clock is derived from the system clock (SYSCLK). This parameter can be a value of [**RCC_AHB_Clock_Source**](#)
- ***uint32_t RCC_ClkInitTypeDef::APB1CLKDivider***
The APB1 clock (PCLK1) divider. This clock is derived from the AHB clock (HCLK). This parameter can be a value of [**RCC_APB1_APB2_Clock_Source**](#)
- ***uint32_t RCC_ClkInitTypeDef::APB2CLKDivider***
The APB2 clock (PCLK2) divider. This clock is derived from the AHB clock (HCLK). This parameter can be a value of [**RCC_APB1_APB2_Clock_Source**](#)

48.3 RCC Firmware driver API description

48.3.1 RCC specific features

After reset the device is running from Internal High Speed oscillator (HSI 16MHz) with Flash 0 wait state, Flash prefetch buffer, D-Cache and I-Cache are disabled, and all peripherals are off except internal SRAM, Flash and JTAG.

- There is no prescaler on High speed (AHB) and Low speed (APB) busses; all peripherals mapped on these busses are running at HSI speed.
- The clock for all peripherals is switched off, except the SRAM and FLASH.
- All GPIOs are in input floating state, except the JTAG pins which are assigned to be used for debug purpose.

Once the device started from reset, the user application has to:

- Configure the clock source to be used to drive the System clock (if the application needs higher frequency/performance)
- Configure the System clock frequency and Flash settings
- Configure the AHB and APB busses prescalers
- Enable the clock for the peripheral(s) to be used
- Configure the clock source(s) for peripherals which clocks are not derived from the System clock (I2S, RTC, ADC, USB OTG FS/SDIO/RNG)

48.3.2 RCC Limitations

A delay between an RCC peripheral clock enable and the effective peripheral enabling should be taken into account in order to manage the peripheral read/write from/to registers.

- This delay depends on the peripheral mapping.
- If peripheral is mapped on AHB: the delay is 2 AHB clock cycle after the clock enable bit is set on the hardware register
- If peripheral is mapped on APB: the delay is 2 APB clock cycle after the clock enable bit is set on the hardware register

Implemented Workaround:

- For AHB & APB peripherals, a dummy read to the peripheral register has been inserted in each `__HAL_RCC_PPP_CLK_ENABLE()` macro.

48.3.3 Initialization and de-initialization functions

This section provides functions allowing to configure the internal/external oscillators (HSE, HSI, LSE, LSI, PLL, CSS and MCO) and the System busses clocks (SYSCLK, AHB, APB1 and APB2).

Internal/external clock and PLL configuration

1. HSI (high-speed internal), 16 MHz factory-trimmed RC used directly or through the PLL as System clock source.
2. LSI (low-speed internal), 32 KHz low consumption RC used as IWDG and/or RTC clock source.
3. HSE (high-speed external), 4 to 26 MHz crystal oscillator used directly or through the PLL as System clock source. Can be used also as RTC clock source.
4. LSE (low-speed external), 32 KHz oscillator used as RTC clock source.
5. PLL (clocked by HSI or HSE), featuring two different output clocks:
 - The first output is used to generate the high speed system clock (up to 168 MHz)
 - The second output is used to generate the clock for the USB OTG FS (48 MHz), the random analog generator (<=48 MHz) and the SDIO (<= 48 MHz).
6. CSS (Clock security system), once enable using the macro `__HAL_RCC_CSS_ENABLE()` and if a HSE clock failure occurs(HSE used directly or through PLL as System clock source), the System clocks automatically switched to HSI and an interrupt is generated if enabled. The interrupt is linked to the Cortex-M4 NMI (Non-Maskable Interrupt) exception vector.
7. MCO1 (microcontroller clock output), used to output HSI, LSE, HSE or PLL clock (through a configurable prescaler) on PA8 pin.
8. MCO2 (microcontroller clock output), used to output HSE, PLL, SYSCLK or PLLI2S clock (through a configurable prescaler) on PC9 pin.

System, AHB and APB busses clocks configuration

1. Several clock sources can be used to drive the System clock (SYSCLK): HSI, HSE and PLL. The AHB clock (HCLK) is derived from System clock through configurable prescaler and used to clock the CPU, memory and peripherals mapped on AHB bus (DMA, GPIO...). APB1 (PCLK1) and APB2 (PCLK2) clocks are derived from AHB clock through configurable prescalers and used to clock the peripherals mapped on these busses. You can use "HAL_RCC_GetSysClockFreq()" function to retrieve the frequencies of these clocks.
2. For the STM32F405xx/07xx and STM32F415xx/17xx devices, the maximum frequency of the SYSCLK and HCLK is 168 MHz, PCLK2 84 MHz and PCLK1 42 MHz. Depending on the device voltage range, the maximum frequency should be adapted accordingly (refer to the product datasheets for more details).
3. For the STM32F42xxx, STM32F43xxx, STM32F446xx, STM32F469xx and STM32F479xx devices, the maximum frequency of the SYSCLK and HCLK is 180 MHz, PCLK2 90 MHz and PCLK1 45 MHz. Depending on the device voltage range, the maximum frequency should be adapted accordingly (refer to the product datasheets for more details).
4. For the STM32F401xx, the maximum frequency of the SYSCLK and HCLK is 84 MHz, PCLK2 84 MHz and PCLK1 42 MHz. Depending on the device voltage range, the maximum frequency should be adapted accordingly (refer to the product datasheets for more details).
5. For the STM32F41xxx, the maximum frequency of the SYSCLK and HCLK is 100 MHz, PCLK2 100 MHz and PCLK1 50 MHz. Depending on the device voltage range, the maximum frequency should be adapted accordingly (refer to the product datasheets for more details).

This section contains the following APIs:

- [***HAL_RCC_DeInit\(\)***](#)

- [*HAL_RCC_OscConfig\(\)*](#)
- [*HAL_RCC_ClockConfig\(\)*](#)

48.3.4 Peripheral Control functions

This subsection provides a set of functions allowing to control the RCC Clocks frequencies.

This section contains the following APIs:

- [*HAL_RCC_MCOConfig\(\)*](#)
- [*HAL_RCC_EnableCSS\(\)*](#)
- [*HAL_RCC_DisableCSS\(\)*](#)
- [*HAL_RCC_GetSysClockFreq\(\)*](#)
- [*HAL_RCC_GetHCLKFreq\(\)*](#)
- [*HAL_RCC_GetPCLK1Freq\(\)*](#)
- [*HAL_RCC_GetPCLK2Freq\(\)*](#)
- [*HAL_RCC_GetOscConfig\(\)*](#)
- [*HAL_RCC_GetClockConfig\(\)*](#)
- [*HAL_RCC_NMI_IRQHandler\(\)*](#)
- [*HAL_RCC_CSSCallback\(\)*](#)

48.3.5 HAL_RCC_DelInit

Function Name	void HAL_RCC_DelInit (void)
Function Description	Resets the RCC clock configuration to the default reset state.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • The default reset state of the clock configuration is given below: HSI ON and used as system clock sourceHSE and PLL OFFAHB, APB1 and APB2 prescaler set to 1.CSS, MCO1 and MCO2 OFFAll interrupts disabled • This function doesn't modify the configuration of the Peripheral clocksLSI, LSE and RTC clocks

48.3.6 HAL_RCC_OscConfig

Function Name	HAL_StatusTypeDef HAL_RCC_OscConfig (RCC_OscInitTypeDef * RCC_OscInitStruct)
Function Description	Initializes the RCC Oscillators according to the specified parameters in the RCC_OscInitTypeDef.
Parameters	<ul style="list-style-type: none"> • RCC_OscInitStruct: pointer to an RCC_OscInitTypeDef structure that contains the configuration information for the RCC Oscillators.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • The PLL is not disabled when used as system clock.

48.3.7 HAL_RCC_ClockConfig

Function Name	HAL_StatusTypeDef HAL_RCC_ClockConfig (RCC_ClkInitTypeDef * RCC_ClkInitStruct, uint32_t FLatency)
Function Description	Initializes the CPU, AHB and APB busses clocks according to the

	specified parameters in the <code>RCC_ClkInitStruct</code> .
Parameters	<ul style="list-style-type: none"> • RCC_ClkInitStruct: pointer to an <code>RCC_OscInitTypeDef</code> structure that contains the configuration information for the RCC peripheral. • FLatency: FLASH Latency, this parameter depend on device selected
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • The <code>SystemCoreClock CMSIS</code> variable is used to store System Clock Frequency and updated by <code>HAL_RCC_GetHCLKFreq()</code> function called within this function • The HSI is used (enabled by hardware) as system clock source after startup from Reset, wake-up from STOP and STANDBY mode, or in case of failure of the HSE used directly or indirectly as system clock (if the Clock Security System CSS is enabled). • A switch from one clock source to another occurs only if the target clock source is ready (clock stable after startup delay or PLL locked). If a clock source which is not yet ready is selected, the switch will occur when the clock source will be ready. • Depending on the device voltage range, the software has to set correctly HPRE[3:0] bits to ensure that HCLK not exceed the maximum allowed frequency (for more details refer to section above "Initialization/de-initialization functions")

48.3.8 HAL_RCC_MCOConfig

Function Name	<code>void HAL_RCC_MCOConfig (uint32_t RCC_MCOx, uint32_t RCC_MCOsource, uint32_t RCC_MCODiv)</code>
Function Description	Selects the clock source to output on MCO1 pin(PA8) or on MCO2 pin(PC9).
Parameters	<ul style="list-style-type: none"> • RCC_MCOx: specifies the output direction for the clock source. This parameter can be one of the following values: <code>RCC_MCO1</code>: Clock source to output on MCO1 pin(PA8). <code>RCC_MCO2</code>: Clock source to output on MCO2 pin(PC9). • RCC_MCOsource: specifies the clock source to output. This parameter can be one of the following values: <code>RCC_MCO1SOURCE_HSI</code>: HSI clock selected as MCO1 source <code>RCC_MCO1SOURCE_LSE</code>: LSE clock selected as MCO1 source <code>RCC_MCO1SOURCE_HSE</code>: HSE clock selected as MCO1 source <code>RCC_MCO1SOURCE_PLLCLK</code>: main PLL clock selected as MCO1 source <code>RCC_MCO2SOURCE_SYSCLK</code>: System clock (SYSCLK) selected as MCO2 source <code>RCC_MCO2SOURCE_PLLI2SCLK</code>: PLLI2S clock selected as MCO2 source, available for all STM32F4 devices except STM32F410xx <code>RCC_MCO2SOURCE_I2SCLK</code>: I2SCLK clock selected as MCO2 source, available only for STM32F410Rx devices <code>RCC_MCO2SOURCE_HSE</code>: HSE clock selected as MCO2 source <code>RCC_MCO2SOURCE_PLLCLK</code>: main PLL clock

	<ul style="list-style-type: none"> selected as MCO2 source
	<ul style="list-style-type: none"> • RCC_MCODiv: specifies the MCOx prescaler. This parameter can be one of the following values: RCC_MCODIV_1: no division applied to MCOx clockRCC_MCODIV_2: division by 2 applied to MCOx clockRCC_MCODIV_3: division by 3 applied to MCOx clockRCC_MCODIV_4: division by 4 applied to MCOx clockRCC_MCODIV_5: division by 5 applied to MCOx clock
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • PA8/PC9 should be configured in alternate function mode. • For STM32F410Rx devices to output I2SCLK clock on MCO2 you should have at least one of the SPI clocks enabled (SPI1, SPI2 or SPI5).

48.3.9 HAL_RCC_EnableCSS

Function Name	void HAL_RCC_EnableCSS (void)
Function Description	Enables the Clock Security System.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • If a failure is detected on the HSE oscillator clock, this oscillator is automatically disabled and an interrupt is generated to inform the software about the failure (Clock Security System Interrupt, CSSI), allowing the MCU to perform rescue operations. The CSSI is linked to the Cortex-M4 NMI (Non-Maskable Interrupt) exception vector.

48.3.10 HAL_RCC_DisableCSS

Function Name	void HAL_RCC_DisableCSS (void)
Function Description	Disables the Clock Security System.
Return values	<ul style="list-style-type: none"> • None

48.3.11 HAL_RCC_GetSysClockFreq

Function Name	uint32_t HAL_RCC_GetSysClockFreq (void)
Function Description	Returns the SYSCLK frequency.
Return values	<ul style="list-style-type: none"> • SYSCLK frequency
Notes	<ul style="list-style-type: none"> • The system frequency computed by this function is not the real frequency in the chip. It is calculated based on the predefined constant and the selected clock source: • If SYSCLK source is HSI, function returns values based on HSI_VALUE(*) • If SYSCLK source is HSE, function returns values based on HSE_VALUE(**) • If SYSCLK source is PLL, function returns values based on HSE_VALUE(**) or HSI_VALUE(*) multiplied/divided by the PLL factors. • (*) HSI_VALUE is a constant defined in stm32f4xx_hal_conf.h file (default value 16 MHz) but the real value may vary

- depending on the variations in voltage and temperature.
- (**) HSE_VALUE is a constant defined in `stm32f4xx_hal_conf.h` file (default value 25 MHz), user has to ensure that HSE_VALUE is same as the real frequency of the crystal used. Otherwise, this function may have wrong result.
- The result of this function could be not correct when using fractional value for HSE crystal.
- This function can be used by the user application to compute the baudrate for the communication peripherals or configure other parameters.
- Each time SYSCLK changes, this function must be called to update the right SYSCLK value. Otherwise, any configuration based on this function will be incorrect.

48.3.12 HAL_RCC_GetHCLKFreq

Function Name	<code>uint32_t HAL_RCC_GetHCLKFreq (void)</code>
Function Description	Returns the HCLK frequency.
Return values	<ul style="list-style-type: none"> HCLK frequency
Notes	<ul style="list-style-type: none"> Each time HCLK changes, this function must be called to update the right HCLK value. Otherwise, any configuration based on this function will be incorrect. The SystemCoreClock CMSIS variable is used to store System Clock Frequency and updated within this function

48.3.13 HAL_RCC_GetPCLK1Freq

Function Name	<code>uint32_t HAL_RCC_GetPCLK1Freq (void)</code>
Function Description	Returns the PCLK1 frequency.
Return values	<ul style="list-style-type: none"> PCLK1 frequency
Notes	<ul style="list-style-type: none"> Each time PCLK1 changes, this function must be called to update the right PCLK1 value. Otherwise, any configuration based on this function will be incorrect.

48.3.14 HAL_RCC_GetPCLK2Freq

Function Name	<code>uint32_t HAL_RCC_GetPCLK2Freq (void)</code>
Function Description	Returns the PCLK2 frequency.
Return values	<ul style="list-style-type: none"> PCLK2 frequency
Notes	<ul style="list-style-type: none"> Each time PCLK2 changes, this function must be called to update the right PCLK2 value. Otherwise, any configuration based on this function will be incorrect.

48.3.15 HAL_RCC_GetOscConfig

Function Name	<code>void HAL_RCC_GetOscConfig (RCC_OscInitTypeDef * RCC_OscInitStruct)</code>
Function Description	Configures the RCC_OscInitStruct according to the internal RCC configuration registers.

Parameters	<ul style="list-style-type: none"> RCC_OscInitStruct: pointer to an RCC_OscInitTypeDef structure that will be configured.
Return values	<ul style="list-style-type: none"> None

48.3.16 HAL_RCC_GetClockConfig

Function Name	void HAL_RCC_GetClockConfig (RCC_ClkInitTypeDef * RCC_ClkInitStruct, uint32_t * pFLatency)
Function Description	Configures the RCC_ClkInitStruct according to the internal RCC configuration registers.
Parameters	<ul style="list-style-type: none"> RCC_ClkInitStruct: pointer to an RCC_ClkInitTypeDef structure that will be configured. pFLatency: Pointer on the Flash Latency.
Return values	<ul style="list-style-type: none"> None

48.3.17 HAL_RCC_NMI_IRQHandler

Function Name	void HAL_RCC_NMI_IRQHandler (void)
Function Description	This function handles the RCC CSS interrupt request.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This API should be called under the NMI_Handler().

48.3.18 HAL_RCC_CSSCallback

Function Name	void HAL_RCC_CSSCallback (void)
Function Description	RCC Clock Security System interrupt callback.
Return values	<ul style="list-style-type: none"> None

48.4 RCC Firmware driver defines

48.4.1 RCC

AHB1 Peripheral Clock Enable Disable

```

__HAL_RCC_GPIOA_CLK_ENABLE
__HAL_RCC_GPIOB_CLK_ENABLE
__HAL_RCC_GPIOC_CLK_ENABLE
__HAL_RCC_GPIOH_CLK_ENABLE
__HAL_RCC_DMA1_CLK_ENABLE
__HAL_RCC_DMA2_CLK_ENABLE
__HAL_RCC_GPIOA_CLK_DISABLE
__HAL_RCC_GPIOB_CLK_DISABLE
__HAL_RCC_GPIOC_CLK_DISABLE
__HAL_RCC_GPIOH_CLK_DISABLE

```

```
_HAL_RCC_DMA1_CLK_DISABLE  
_HAL_RCC_DMA2_CLK_DISABLE
```

AHB1 Force Release Reset

```
_HAL_RCC_AHB1_FORCE_RESET  
_HAL_RCC_GPIOA_FORCE_RESET  
_HAL_RCC_GPIOB_FORCE_RESET  
_HAL_RCC_GPIOC_FORCE_RESET  
_HAL_RCC_GPIOH_FORCE_RESET  
_HAL_RCC_DMA1_FORCE_RESET  
_HAL_RCC_DMA2_FORCE_RESET  
_HAL_RCC_AHB1_RELEASE_RESET  
_HAL_RCC_GPIOA_RELEASE_RESET  
_HAL_RCC_GPIOB_RELEASE_RESET  
_HAL_RCC_GPIOC_RELEASE_RESET  
_HAL_RCC_GPIOH_RELEASE_RESET  
_HAL_RCC_DMA1_RELEASE_RESET  
_HAL_RCC_DMA2_RELEASE_RESET
```

AHB1 Peripheral Low Power Enable Disable

```
_HAL_RCC_GPIOA_CLK_SLEEP_ENABLE  
_HAL_RCC_GPIOB_CLK_SLEEP_ENABLE  
_HAL_RCC_GPIOC_CLK_SLEEP_ENABLE  
_HAL_RCC_GPIOH_CLK_SLEEP_ENABLE  
_HAL_RCC_DMA1_CLK_SLEEP_ENABLE  
_HAL_RCC_DMA2_CLK_SLEEP_ENABLE  
_HAL_RCC_GPIOA_CLK_SLEEP_DISABLE  
_HAL_RCC_GPIOB_CLK_SLEEP_DISABLE  
_HAL_RCC_GPIOC_CLK_SLEEP_DISABLE  
_HAL_RCC_GPIOH_CLK_SLEEP_DISABLE  
_HAL_RCC_DMA1_CLK_SLEEP_DISABLE  
_HAL_RCC_DMA2_CLK_SLEEP_DISABLE
```

AHB Clock Source

```
RCC_SYSCLK_DIV1  
RCC_SYSCLK_DIV2  
RCC_SYSCLK_DIV4  
RCC_SYSCLK_DIV8  
RCC_SYSCLK_DIV16
```

```
RCC_SYSCLK_DIV64
RCC_SYSCLK_DIV128
RCC_SYSCLK_DIV256
RCC_SYSCLK_DIV512

APB1/APB2 Clock Source
RCC_HCLK_DIV1
RCC_HCLK_DIV2
RCC_HCLK_DIV4
RCC_HCLK_DIV8
RCC_HCLK_DIV16

APB1 Peripheral Clock Enable Disable
__HAL_RCC_TIM5_CLK_ENABLE
__HAL_RCC_WWDG_CLK_ENABLE
__HAL_RCC_SPI2_CLK_ENABLE
__HAL_RCC_USART2_CLK_ENABLE
__HAL_RCC_I2C1_CLK_ENABLE
__HAL_RCC_I2C2_CLK_ENABLE
__HAL_RCC_PWR_CLK_ENABLE
__HAL_RCC_TIM5_CLK_DISABLE
__HAL_RCC_WWDG_CLK_DISABLE
__HAL_RCC_SPI2_CLK_DISABLE
__HAL_RCC_USART2_CLK_DISABLE
__HAL_RCC_I2C1_CLK_DISABLE
__HAL_RCC_I2C2_CLK_DISABLE
__HAL_RCC_PWR_CLK_DISABLE

APB1 Force Release Reset
__HAL_RCC_APB1_FORCE_RESET
__HAL_RCC_TIM5_FORCE_RESET
__HAL_RCC_WWDG_FORCE_RESET
__HAL_RCC_SPI2_FORCE_RESET
__HAL_RCC_USART2_FORCE_RESET
__HAL_RCC_I2C1_FORCE_RESET
__HAL_RCC_I2C2_FORCE_RESET
__HAL_RCC_PWR_FORCE_RESET
__HAL_RCC_APB1_RELEASE_RESET
__HAL_RCC_TIM5_RELEASE_RESET
```

```
_HAL_RCC_WWDG_RELEASE_RESET  
_HAL_RCC_SPI2_RELEASE_RESET  
_HAL_RCC_USART2_RELEASE_RESET  
_HAL_RCC_I2C1_RELEASE_RESET  
_HAL_RCC_I2C2_RELEASE_RESET  
_HAL_RCC_PWR_RELEASE_RESET  
APB1 Peripheral Low Power Enable Disable  
_HAL_RCC_TIM5_CLK_SLEEP_ENABLE  
_HAL_RCC_WWDG_CLK_SLEEP_ENABLE  
_HAL_RCC_SPI2_CLK_SLEEP_ENABLE  
_HAL_RCC_USART2_CLK_SLEEP_ENABLE  
_HAL_RCC_I2C1_CLK_SLEEP_ENABLE  
_HAL_RCC_I2C2_CLK_SLEEP_ENABLE  
_HAL_RCC_PWR_CLK_SLEEP_ENABLE  
_HAL_RCC_TIM5_CLK_SLEEP_DISABLE  
_HAL_RCC_WWDG_CLK_SLEEP_DISABLE  
_HAL_RCC_SPI2_CLK_SLEEP_DISABLE  
_HAL_RCC_USART2_CLK_SLEEP_DISABLE  
_HAL_RCC_I2C1_CLK_SLEEP_DISABLE  
_HAL_RCC_I2C2_CLK_SLEEP_DISABLE  
_HAL_RCC_PWR_CLK_SLEEP_DISABLE  
APB2 Peripheral Clock Enable Disable  
_HAL_RCC_TIM1_CLK_ENABLE  
_HAL_RCC_USART1_CLK_ENABLE  
_HAL_RCC_USART6_CLK_ENABLE  
_HAL_RCC_ADC1_CLK_ENABLE  
_HAL_RCC_SPI1_CLK_ENABLE  
_HAL_RCC_SYSCFG_CLK_ENABLE  
_HAL_RCC_TIM9_CLK_ENABLE  
_HAL_RCC_TIM11_CLK_ENABLE  
_HAL_RCC_TIM1_CLK_DISABLE  
_HAL_RCC_USART1_CLK_DISABLE  
_HAL_RCC_USART6_CLK_DISABLE  
_HAL_RCC_ADC1_CLK_DISABLE  
_HAL_RCC_SPI1_CLK_DISABLE  
_HAL_RCC_SYSCFG_CLK_DISABLE
```

```
_HAL_RCC_TIM9_CLK_DISABLE
__HAL_RCC_TIM11_CLK_DISABLE

APB2 Force Release Reset
__HAL_RCC_APB2_FORCE_RESET
__HAL_RCC_TIM1_FORCE_RESET
__HAL_RCC_USART1_FORCE_RESET
__HAL_RCC_USART6_FORCE_RESET
__HAL_RCC_ADC_FORCE_RESET
__HAL_RCC_SPI1_FORCE_RESET
__HAL_RCC_SYSCFG_FORCE_RESET
__HAL_RCC_TIM9_FORCE_RESET
__HAL_RCC_TIM11_FORCE_RESET
__HAL_RCC_APB2_RELEASE_RESET
__HAL_RCC_TIM1_RELEASE_RESET
__HAL_RCC_USART1_RELEASE_RESET
__HAL_RCC_USART6_RELEASE_RESET
__HAL_RCC_ADC_RELEASE_RESET
__HAL_RCC_SPI1_RELEASE_RESET
__HAL_RCC_SYSCFG_RELEASE_RESET
__HAL_RCC_TIM9_RELEASE_RESET
__HAL_RCC_TIM11_RELEASE_RESET

APB2 Peripheral Low Power Enable Disable
__HAL_RCC_TIM1_CLK_SLEEP_ENABLE
__HAL_RCC_USART1_CLK_SLEEP_ENABLE
__HAL_RCC_USART6_CLK_SLEEP_ENABLE
__HAL_RCC_ADC1_CLK_SLEEP_ENABLE
__HAL_RCC_SPI1_CLK_SLEEP_ENABLE
__HAL_RCC_SYSCFG_CLK_SLEEP_ENABLE
__HAL_RCC_TIM9_CLK_SLEEP_ENABLE
__HAL_RCC_TIM11_CLK_SLEEP_ENABLE
__HAL_RCC_TIM1_CLK_SLEEP_DISABLE
__HAL_RCC_USART1_CLK_SLEEP_DISABLE
__HAL_RCC_USART6_CLK_SLEEP_DISABLE
__HAL_RCC_ADC1_CLK_SLEEP_DISABLE
__HAL_RCC_SPI1_CLK_SLEEP_DISABLE
__HAL_RCC_SYSCFG_CLK_SLEEP_DISABLE
```

```
__HAL_RCC_TIM9_CLK_SLEEP_DISABLE
__HAL_RCC_TIM11_CLK_SLEEP_DISABLE
```

RCC BitAddress AliasRegion

```
RCC_OFFSET
RCC_CR_OFFSET
RCC_HSION_BIT_NUMBER
RCC_CR_HSION_BB
RCC_CSSON_BIT_NUMBER
RCC_CR_CSSON_BB
RCC_PLLON_BIT_NUMBER
RCC_CR_PLLON_BB
RCC_BDCR_OFFSET
RCC_RTCEN_BIT_NUMBER
RCC_BDCR_RTCEN_BB
RCC_BDRST_BIT_NUMBER
RCC_BDCR_BDRST_BB
RCC_CSR_OFFSET
RCC_LSION_BIT_NUMBER
RCC_CSR_LSION_BB
RCC_CR_BYTE2_ADDRESS
RCC_CIR_BYTE1_ADDRESS
RCC_CIR_BYTE2_ADDRESS
RCC_BDCR_BYTE0_ADDRESS
RCC_DBP_TIMEOUT_VALUE
RCC_LSE_TIMEOUT_VALUE
HSE_TIMEOUT_VALUE
HSI_TIMEOUT_VALUE
LSI_TIMEOUT_VALUE
```

Flags

```
RCC_FLAG_HSIRDY
RCC_FLAG_HSERDY
RCC_FLAG_PLLRDY
RCC_FLAG_PLLI2SRDY
RCC_FLAG_LSERDY
RCC_FLAG_LSIRDY
RCC_FLAG_BORRST
```

RCC_FLAG_PINRST
RCC_FLAG_PORRST
RCC_FLAG_SFTRST
RCC_FLAG_IWDGRST
RCC_FLAG_WWDGRST
RCC_FLAG_LPWRRST

Flags Interrupts Management

`__HAL_RCC_ENABLE_IT`

Description:

- Enable RCC interrupt (Perform Byte access to RCC_CIR[14:8] bits to enable the selected interrupts).

Parameters:

- `__INTERRUPT__`: specifies the RCC interrupt sources to be enabled. This parameter can be any combination of the following values:
 - `RCC_IT_LSIRDY`: LSI ready interrupt.
 - `RCC_IT_LSERDY`: LSE ready interrupt.
 - `RCC_IT_HSIRDY`: HSI ready interrupt.
 - `RCC_IT_HSERDY`: HSE ready interrupt.
 - `RCC_IT_PLLRDY`: Main PLL ready interrupt.
 - `RCC_IT_PLLI2SRDY`: PLLI2S ready interrupt.

`__HAL_RCC_DISABLE_IT`

Description:

- Disable RCC interrupt (Perform Byte access to RCC_CIR[14:8] bits to disable the selected interrupts).

Parameters:

- `__INTERRUPT__`: specifies the RCC interrupt sources to be disabled. This parameter can be any combination of the following values:
 - `RCC_IT_LSIRDY`: LSI ready interrupt.
 - `RCC_IT_LSERDY`: LSE ready interrupt.
 - `RCC_IT_HSIRDY`: HSI ready interrupt.
 - `RCC_IT_HSERDY`: HSE ready interrupt.
 - `RCC_IT_PLLRDY`: Main PLL ready interrupt.
 - `RCC_IT_PLLI2SRDY`: PLLI2S ready interrupt.

`__HAL_RCC_CLEAR_IT`

Description:

- Clear the RCC's interrupt pending bits (Perform Byte access to RCC_CIR[23:16]

bits to clear the selected interrupt pending bits.

Parameters:

- __INTERRUPT__: specifies the interrupt pending bit to clear. This parameter can be any combination of the following values:
 - RCC_IT_LSIRDY: LSI ready interrupt.
 - RCC_IT_LSERDY: LSE ready interrupt.
 - RCC_IT_HSIRDY: HSI ready interrupt.
 - RCC_IT_HSERDY: HSE ready interrupt.
 - RCC_IT_PLLRDY: Main PLL ready interrupt.
 - RCC_IT_PLLI2SRDY: PLLI2S ready interrupt.
 - RCC_IT_CSS: Clock Security System interrupt

__HAL_RCC_GET_IT

Description:

- Check the RCC's interrupt has occurred or not.

Parameters:

- __INTERRUPT__: specifies the RCC interrupt source to check. This parameter can be one of the following values:
 - RCC_IT_LSIRDY: LSI ready interrupt.
 - RCC_IT_LSERDY: LSE ready interrupt.
 - RCC_IT_HSIRDY: HSI ready interrupt.
 - RCC_IT_HSERDY: HSE ready interrupt.
 - RCC_IT_PLLRDY: Main PLL ready interrupt.
 - RCC_IT_PLLI2SRDY: PLLI2S ready interrupt.
 - RCC_IT_CSS: Clock Security System interrupt

Return value:

- The: new state of __INTERRUPT__ (TRUE or FALSE).

__HAL_RCC_CLEAR_RESET_FLAGS

RCC_FLAG_MASK

Description:

- Check RCC flag is set or not.

Parameters:

- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - RCC_FLAG_HSIRDY: HSI oscillator clock ready.

- RCC_FLAG_HSERDY: HSE oscillator clock ready.
- RCC_FLAG_PLLRDY: Main PLL clock ready.
- RCC_FLAG_PLLI2SRDY: PLLI2S clock ready.
- RCC_FLAG_LSERDY: LSE oscillator clock ready.
- RCC_FLAG_LSIRDY: LSI oscillator clock ready.
- RCC_FLAG_BORRST: POR/PDR or BOR reset.
- RCC_FLAG_PINRST: Pin reset.
- RCC_FLAG_PORRST: POR/PDR reset.
- RCC_FLAG_SFTRST: Software reset.
- RCC_FLAG_IWDGRST: Independent Watchdog reset.
- RCC_FLAG_WWDGRST: Window Watchdog reset.
- RCC_FLAG_LPWRRST: Low Power reset.

Return value:

- The: new state of __FLAG__ (TRUE or FALSE).

`__HAL_RCC_GET_FLAG`**Get Clock source**`__HAL_RCC_SYSCLK_CONFIG`**Description:**

- Macro to configure the system clock source.

Parameters:

- __RCC_SYSCLKSOURCE__: specifies the system clock source. This parameter can be one of the following values:
 - RCC_SYSCLKSOURCE_HSI: HSI oscillator is used as system clock source.
 - RCC_SYSCLKSOURCE_HSE: HSE oscillator is used as system clock source.
 - RCC_SYSCLKSOURCE_PLLCLK: PLL output is used as system clock source.
 - RCC_SYSCLKSOURCE_PLLRCLK: PLLR output is used as system clock source.

`__HAL_RCC_GET_SYSCLK_SOURCE`**Description:**

- Macro to get the clock source used as system clock.

Return value:

- The: clock source used as system clock. The returned value can be one of the following:
 - RCC_SYSCLKSOURCE_STATUS_HSI:

- HSI used as system clock.
- RCC_SYSCLKSOURCE_STATUS_HSE: HSE used as system clock.
- RCC_SYSCLKSOURCE_STATUS_PLLCLK: PLL used as system clock.
- RCC_SYSCLKSOURCE_STATUS_PLLRCLK: PLLR used as system clock.

`_HAL_RCC_GET_PLL_OSCSO
URCE`

Description:

- Macro to get the oscillator used as PLL clock source.

Return value:

- The oscillator used as PLL clock source. The returned value can be one of the following:
 - RCC_PLLSOURCE_HSI: HSI oscillator is used as PLL clock source.
 - RCC_PLLSOURCE_HSE: HSE oscillator is used as PLL clock source.

HSE Config

`RCC_HSE_OFF
RCC_HSE_ON
RCC_HSE_BYPASS`

HSE Configuration

`_HAL_RCC_HSE_CONFIG` **Description:**

- Macro to configure the External High Speed oscillator (HSE).

Parameters:

- `__STATE__`: specifies the new state of the HSE. This parameter can be one of the following values:
 - RCC_HSE_OFF: turn OFF the HSE oscillator, HSERDY flag goes low after 6 HSE oscillator clock cycles.
 - RCC_HSE_ON: turn ON the HSE oscillator.
 - RCC_HSE_BYPASS: HSE oscillator bypassed with external clock.

Notes:

- Transition HSE Bypass to HSE On and HSE On to HSE Bypass are not supported by this macro. User should request a transition to HSE Off first and then HSE On or HSE Bypass. After enabling the HSE (RCC_HSE_ON or RCC_HSE_Bypass), the application software should wait on HSERDY flag to be set indicating that HSE clock is stable and can be used to clock the PLL and/or system clock. HSE state can not be changed if it is used directly or through the PLL as system clock. In this case, you have to select another source of the system clock then change the HSE state (ex. disable it). The HSE is stopped by

hardware when entering STOP and STANDBY modes. This function reset the CSSON bit, so if the clock security system(CSS) was previously enabled you have to enable it again after calling this function.

HSI Config

`RCC_HSI_OFF`

`RCC_HSI_ON`

HSI Configuration

`_HAL_RCC_HSI_ENABLE`

Notes:

- The HSI is stopped by hardware when entering STOP and STANDBY modes. It is used (enabled by hardware) as system clock source after startup from Reset, wake-up from STOP and STANDBY mode, or in case of failure of the HSE used directly or indirectly as system clock (if the Clock Security System CSS is enabled). HSI can not be stopped if it is used as system clock source. In this case, you have to select another source of the system clock then stop the HSI. After enabling the HSI, the application software should wait on HSIRDY flag to be set indicating that HSI clock is stable and can be used as system clock source. This parameter can be: ENABLE or DISABLE. When the HSI is stopped, HSIRDY flag goes low after 6 HSI oscillator clock cycles.

`_HAL_RCC_HSI_DISABLE`

`_HAL_RCC_HSI_CALIBRATIONVALUE_ADJUST`

Description:

- Macro to adjust the Internal High Speed oscillator (HSI) calibration value.

Parameters:

- `_HSICalibrationValue_`: specifies the calibration trimming value. This parameter must be a number between 0 and 0x1F.

Notes:

- The calibration is used to

compensate for the variations in voltage and temperature that influence the frequency of the internal HSI RC.

RTC Clock Configuration

`__HAL_RCC_RTC_ENABLE`

Notes:

- These macros must be used only after the RTC clock source was selected.

`__HAL_RCC_RTC_DISABLE`

Description:

- Macros to configure the RTC clock (RTCCLK).

Parameters:

- `__RTCCLKSource__`: specifies the RTC clock source. This parameter can be one of the following values:
 - `RCC_RTCCLKSOURCE_LSE`: LSE selected as RTC clock.
 - `RCC_RTCCLKSOURCE_LSI`: LSI selected as RTC clock.
 - `RCC_RTCCLKSOURCE_HSE_DIVx`: HSE clock divided by x selected as RTC clock, where x:[2,31]

Notes:

- As the RTC clock configuration bits are in the Backup domain and write access is denied to this domain after reset, you have to enable write access using the Power Backup Access macro before to configure the RTC clock source (to be done once after reset). Once the RTC clock is configured it can't be changed unless the Backup domain is reset using `__HAL_RCC_BackupReset_RELEASE()` macro, or by a Power On Reset (POR).
- If the LSE or LSI is used as RTC clock source, the RTC continues to work in STOP and STANDBY modes, and can be used as wake-up source. However, when the HSE clock is used as RTC clock source, the RTC cannot be used in STOP and STANDBY modes. The maximum input clock frequency for RTC is 1MHz (when using HSE as RTC clock source).

`__HAL_RCC_RTC_CONFIG`

`__HAL_RCC_BACKUPRESET_FORC
E`

Notes:

- This function resets the RTC peripheral (including the backup registers) and the

RTC clock source selection in RCC_CSR register. The BKPSRAM is not affected by this reset.

`__HAL_RCC_BACKUPRESET_RELEASE`
SE

Interrupts

RCC_IT_LSIRDY
RCC_IT_LSERDY
RCC_IT_HSIRDY
RCC_IT_HSERDY
RCC_IT_PLLRDY
RCC_IT_PLLI2SRDY
RCC_IT_CSS

RCC Private macros to check input parameters

IS_RCC_OSCILLATORTYPE
IS_RCC_HSE
IS_RCC_LSE
IS_RCC_HSI
IS_RCC_LSI
IS_RCC_PLL
IS_RCC_PLLSOURCE
IS_RCC_SYSCLKSOURCE
IS_RCC_PLLM_VALUE
IS_RCC_PLLN_VALUE
IS_RCC_PLLP_VALUE
IS_RCC_PLLQ_VALUE
IS_RCC_HCLK
IS_RCC_CLOCKTYPE
IS_RCC_PCLK
IS_RCC_MCO
IS_RCC_MCO1SOURCE
IS_RCC_MCODIV
IS_RCC_CALIBRATION_VALUE

LSE Config

RCC_LSE_OFF
RCC_LSE_ON
RCC_LSE_BYPASS

LSE Configuration

[__HAL_RCC_LSE_CONFIG](#) **Description:**

- Macro to configure the External Low Speed oscillator (LSE).

Parameters:

- [__STATE__](#): specifies the new state of the LSE. This parameter can be one of the following values:
 - [RCC_LSE_OFF](#): turn OFF the LSE oscillator, LSERDY flag goes low after 6 LSE oscillator clock cycles.
 - [RCC_LSE_ON](#): turn ON the LSE oscillator.
 - [RCC_LSE_BYPASS](#): LSE oscillator bypassed with external clock.

Notes:

- Transition LSE Bypass to LSE On and LSE On to LSE Bypass are not supported by this macro. User should request a transition to LSE Off first and then LSE On or LSE Bypass. As the LSE is in the Backup domain and write access is denied to this domain after reset, you have to enable write access using [HAL_PWR_EnableBkUpAccess\(\)](#) function before to configure the LSE (to be done once after reset). After enabling the LSE ([RCC_LSE_ON](#) or [RCC_LSE_BYPASS](#)), the application software should wait on LSERDY flag to be set indicating that LSE clock is stable and can be used to clock the RTC.

LSI Config[RCC_LSI_OFF](#)[RCC_LSI_ON](#)***LSI Configuration***[__HAL_RCC_LSI_ENABLE](#)**Notes:**

- After enabling the LSI, the application software should wait on LSIRDY flag to be set indicating that LSI clock is stable and can be used to clock the IWDG and/or the RTC. LSI can not be disabled if the IWDG is running. When the LSI is stopped, LSIRDY flag goes low after 6 LSI oscillator clock cycles.

[__HAL_RCC_LSI_DISABLE](#)***MCO1 Clock Source***[RCC_MCO1SOURCE_HSI](#)[RCC_MCO1SOURCE_LSE](#)[RCC_MCO1SOURCE_HSE](#)[RCC_MCO1SOURCE_PLLCLK](#)***MCO2 Clock Source***[RCC_MCO2SOURCE_SYSCLK](#)

RCC_MCO2SOURCE_PLLI2SCLK

RCC_MCO2SOURCE_HSE

RCC_MCO2SOURCE_PLLCLK

MCOx Clock Prescaler

RCC_MCODIV_1

RCC_MCODIV_2

RCC_MCODIV_3

RCC_MCODIV_4

RCC_MCODIV_5

MCO Index

RCC_MCO1

RCC_MCO2

Oscillator Type

RCC_OSCILLATORTYPE_NONE

RCC_OSCILLATORTYPE_HSE

RCC_OSCILLATORTYPE_HSI

RCC_OSCILLATORTYPE_LSE

RCC_OSCILLATORTYPE_LSI

PLLP Clock Divider

RCC_PLLP_DIV2

RCC_PLLP_DIV4

RCC_PLLP_DIV6

RCC_PLLP_DIV8

PLL Clock Source

RCC_PLLSOURCE_HSI

RCC_PLLSOURCE_HSE

PLL Config

RCC_PLL_NONE

RCC_PLL_OFF

RCC_PLL_ON

PLL Configuration

`_HAL_RCC_PLL_ENABLE`

Notes:

- After enabling the main PLL, the application software should wait on PLLRDY flag to be set indicating that PLL clock is stable and can be used as system clock source. The main PLL can not be disabled if it is used as system clock source. The main PLL is disabled.

by hardware when entering STOP and STANDBY modes.

`__HAL_RCC_PLL_DISABLE`

`__HAL_RCC_PLL_PLLSOURCE_CONFIG` **Description:**

- Macro to configure the PLL clock source.

Parameters:

- `__PLL SOURCE__`: specifies the PLL entry clock source. This parameter can be one of the following values:
 - `RCC_PLLSOURCE_HSI`: HSI oscillator clock selected as PLL clock entry
 - `RCC_PLLSOURCE_HSE`: HSE oscillator clock selected as PLL clock entry

Notes:

- This function must be used only when the main PLL is disabled.

`__HAL_RCC_PLL_PLLM_CONFIG`

Description:

- Macro to configure the PLL multiplication factor.

Parameters:

- `__PLLM__`: specifies the division factor for PLL VCO input clock. This parameter must be a number between `Min_Data = 2` and `Max_Data = 63`.

Notes:

- This function must be used only when the main PLL is disabled.
- You have to set the PLLM parameter correctly to ensure that the VCO input frequency ranges from 1 to 2 MHz. It is recommended to select a frequency of 2 MHz to limit PLL jitter.

RCC Private Constants

`CLOCKSWITCH_TIMEOUT_VALUE`

`__MCO1_CLK_ENABLE`

`MCO1_GPIO_PORT`

`MCO1_PIN`

`__MCO2_CLK_ENABLE`

`MCO2_GPIO_PORT`

`MCO2_PIN`

RTC Clock Source

RCC_RTCCLKSOURCE_LSE
RCC_RTCCLKSOURCE_LSI
RCC_RTCCLKSOURCE_HSE_DIV2
RCC_RTCCLKSOURCE_HSE_DIV3
RCC_RTCCLKSOURCE_HSE_DIV4
RCC_RTCCLKSOURCE_HSE_DIV5
RCC_RTCCLKSOURCE_HSE_DIV6
RCC_RTCCLKSOURCE_HSE_DIV7
RCC_RTCCLKSOURCE_HSE_DIV8
RCC_RTCCLKSOURCE_HSE_DIV9
RCC_RTCCLKSOURCE_HSE_DIV10
RCC_RTCCLKSOURCE_HSE_DIV11
RCC_RTCCLKSOURCE_HSE_DIV12
RCC_RTCCLKSOURCE_HSE_DIV13
RCC_RTCCLKSOURCE_HSE_DIV14
RCC_RTCCLKSOURCE_HSE_DIV15
RCC_RTCCLKSOURCE_HSE_DIV16
RCC_RTCCLKSOURCE_HSE_DIV17
RCC_RTCCLKSOURCE_HSE_DIV18
RCC_RTCCLKSOURCE_HSE_DIV19
RCC_RTCCLKSOURCE_HSE_DIV20
RCC_RTCCLKSOURCE_HSE_DIV21
RCC_RTCCLKSOURCE_HSE_DIV22
RCC_RTCCLKSOURCE_HSE_DIV23
RCC_RTCCLKSOURCE_HSE_DIV24
RCC_RTCCLKSOURCE_HSE_DIV25
RCC_RTCCLKSOURCE_HSE_DIV26
RCC_RTCCLKSOURCE_HSE_DIV27
RCC_RTCCLKSOURCE_HSE_DIV28
RCC_RTCCLKSOURCE_HSE_DIV29
RCC_RTCCLKSOURCE_HSE_DIV30
RCC_RTCCLKSOURCE_HSE_DIV31

System Clock Source

RCC_SYSCLKSOURCE_HSI
RCC_SYSCLKSOURCE_HSE
RCC_SYSCLKSOURCE_PLLCLK

RCC_SYSCLKSOURCE_PLLRCLK

System Clock Source Status

RCC_SYSCLKSOURCE_STATUS_HSI	HSI used as system clock
RCC_SYSCLKSOURCE_STATUS_HSE	HSE used as system clock
RCC_SYSCLKSOURCE_STATUS_PLLCLK	PLL used as system clock
RCC_SYSCLKSOURCE_STATUS_PLLRCLK	PLLR used as system clock

System Clock Type

RCC_CLOCKTYPE_SYSCLK
RCC_CLOCKTYPE_HCLK
RCC_CLOCKTYPE_PCLK1
RCC_CLOCKTYPE_PCLK2

49 HAL RCC Extension Driver

49.1 HAL RCC Extension Driver

49.2 RCCEEx Firmware driver registers structures

49.2.1 RCC_PLLInitTypeDef

Data Fields

- *uint32_t PLLState*
- *uint32_t PLLSource*
- *uint32_t PLLM*
- *uint32_t PLLN*
- *uint32_t PLLP*
- *uint32_t PLLQ*
- *uint32_t PLLR*

Field Documentation

- ***uint32_t RCC_PLLInitTypeDef::PLLState***
The new state of the PLL. This parameter can be a value of [*RCC_PLL_Config*](#)
- ***uint32_t RCC_PLLInitTypeDef::PLLSource***
RCC_PLLSource: PLL entry clock source. This parameter must be a value of [*RCC_PLL_Clock_Source*](#)
- ***uint32_t RCC_PLLInitTypeDef::PLLM***
PLLM: Division factor for PLL VCO input clock. This parameter must be a number between Min_Data = 0 and Max_Data = 63
- ***uint32_t RCC_PLLInitTypeDef::PLLN***
PLLN: Multiplication factor for PLL VCO output clock. This parameter must be a number between Min_Data = 192 and Max_Data = 432
- ***uint32_t RCC_PLLInitTypeDef::PLLP***
PLLP: Division factor for main system clock (SYSCLK). This parameter must be a value of [*RCC_PLLP_Clock_Divider*](#)
- ***uint32_t RCC_PLLInitTypeDef::PLLQ***
PLLQ: Division factor for OTG FS, SDIO and RNG clocks. This parameter must be a number between Min_Data = 4 and Max_Data = 15
- ***uint32_t RCC_PLLInitTypeDef::PLLR***
PLLR: PLL division factor for I2S, SAI, SYSTEM, SPDIFRX clocks. This parameter is only available in STM32F410xx/STM32F446xx/STM32F469xx/STM32F479xx and STM32F412xG devices. This parameter must be a number between Min_Data = 2 and Max_Data = 7

49.2.2 RCC_PLLI2SInitTypeDef

Data Fields

- *uint32_t PLLI2SN*

-
- *uint32_t PLLI2SR*
 - *uint32_t PLLI2SQ*

Field Documentation

- *uint32_t RCC_PLLI2SInitTypeDef::PLLI2SN*
Specifies the multiplication factor for PLLI2S VCO output clock. This parameter must be a number between Min_Data = 192 and Max_Data = 432. This parameter will be used only when PLLI2S is selected as Clock Source I2S or SAI
- *uint32_t RCC_PLLI2SInitTypeDef::PLLI2SR*
Specifies the division factor for I2S clock. This parameter must be a number between Min_Data = 2 and Max_Data = 7. This parameter will be used only when PLLI2S is selected as Clock Source I2S or SAI
- *uint32_t RCC_PLLI2SInitTypeDef::PLLI2SQ*
Specifies the division factor for SAI1 clock. This parameter must be a number between Min_Data = 2 and Max_Data = 15. This parameter will be used only when PLLI2S is selected as Clock Source SAI

49.2.3 RCC_PLLSAIInitTypeDef

Data Fields

- *uint32_t PLLSAIN*
- *uint32_t PLLSAIP*
- *uint32_t PLLSAIQ*
- *uint32_t PLLSAIR*

Field Documentation

- *uint32_t RCC_PLLSAIInitTypeDef::PLLSAIN*
Specifies the multiplication factor for PLLI2S VCO output clock. This parameter must be a number between Min_Data = 192 and Max_Data = 432. This parameter will be used only when PLLSAI is selected as Clock Source SAI or LTDC
- *uint32_t RCC_PLLSAIInitTypeDef::PLLSAIP*
Specifies division factor for OTG FS and SDIO clocks. This parameter is only available in STM32F469xx/STM32F479xx devices. This parameter must be a value of [*RCCEx_PLLSAIP_Clock_Divider*](#)
- *uint32_t RCC_PLLSAIInitTypeDef::PLLSAIQ*
Specifies the division factor for SAI1 clock. This parameter must be a number between Min_Data = 2 and Max_Data = 15. This parameter will be used only when PLLSAI is selected as Clock Source SAI or LTDC
- *uint32_t RCC_PLLSAIInitTypeDef::PLLSAIR*
Specifies the division factor for LTDC clock. This parameter must be a number between Min_Data = 2 and Max_Data = 7. This parameter will be used only when PLLSAI is selected as Clock Source LTDC

49.2.4 RCC_PeriphCLKInitTypeDef

Data Fields

- *uint32_t PeriphClockSelection*
- *RCC_PLLI2SInitTypeDef PLLI2S*
- *RCC_PLLSAIInitTypeDef PLLSAI*
- *uint32_t PLLI2SDivQ*
- *uint32_t PLLSAIDivQ*
- *uint32_t PLLSAIDivR*
- *uint32_t RTCClockSelection*
- *uint8_t TIMPresSelection*
- *uint32_t Clk48ClockSelection*
- *uint32_t SdioClockSelection*

Field Documentation

- *uint32_t RCC_PeriphCLKInitTypeDef::PeriphClockSelection*
The Extended Clock to be configured. This parameter can be a value of [RCCEEx_Periph_Clock_Selection](#)
- *RCC_PLLI2SInitTypeDef RCC_PeriphCLKInitTypeDef::PLLI2S*
PLL I2S structure parameters. This parameter will be used only when PLLI2S is selected as Clock Source I2S or SAI
- *RCC_PLLSAIInitTypeDef RCC_PeriphCLKInitTypeDef::PLLSAI*
PLL SAI structure parameters. This parameter will be used only when PLLI2S is selected as Clock Source SAI or LTDC
- *uint32_t RCC_PeriphCLKInitTypeDef::PLLI2SDivQ*
Specifies the PLLI2S division factor for SAI1 clock. This parameter must be a number between Min_Data = 1 and Max_Data = 32 This parameter will be used only when PLLI2S is selected as Clock Source SAI
- *uint32_t RCC_PeriphCLKInitTypeDef::PLLSAIDivQ*
Specifies the PLLI2S division factor for SAI1 clock. This parameter must be a number between Min_Data = 1 and Max_Data = 32 This parameter will be used only when PLLSAI is selected as Clock Source SAI
- *uint32_t RCC_PeriphCLKInitTypeDef::PLLSAIDivR*
Specifies the PLLSAI division factor for LTDC clock. This parameter must be one value of [RCCEEx_PLLSAI_DIVR](#)
- *uint32_t RCC_PeriphCLKInitTypeDef::RTCClockSelection*
Specifies RTC Clock Prescalers Selection. This parameter can be a value of [RCC_RTC_Clock_Source](#)
- *uint8_t RCC_PeriphCLKInitTypeDef::TIMPresSelection*
Specifies TIM Clock Prescalers Selection. This parameter can be a value of [RCCEEx_TIM_PRescaler_Selection](#)
- *uint32_t RCC_PeriphCLKInitTypeDef::Clk48ClockSelection*
Specifies CK48 Clock Selection this clock used OTG FS, SDIO and RNG clocks. This parameter can be a value of [RCCEEx_CK48_Clock_Source](#)
- *uint32_t RCC_PeriphCLKInitTypeDef::SdioClockSelection*
Specifies SDIO Clock Source Selection. This parameter can be a value of [RCCEEx_SDIO_Clock_Source](#)

49.3 RCCEEx Firmware driver API description

49.3.1 Extended Peripheral Control functions

This subsection provides a set of functions allowing to control the RCC Clocks frequencies.



Important note: Care must be taken when HAL_RCCEEx_PeriphCLKConfig() is used to select the RTC clock source; in this case the Backup domain will be reset in order to modify the RTC Clock source, as consequence RTC registers (including the backup registers) and RCC_BDCR register are set to their reset values.

This section contains the following APIs:

- [**HAL_RCC_DelInit\(\)**](#)
- [**HAL_RCCEEx_PeriphCLKConfig\(\)**](#)
- [**HAL_RCCEEx_GetPeriphCLKConfig\(\)**](#)
- [**HAL_RCC_OscConfig\(\)**](#)
- [**HAL_RCC_GetOscConfig\(\)**](#)
- [**HAL_RCCEEx_SelectLSEMode\(\)**](#)

49.3.2 HAL_RCC_DelInit

Function Name	void HAL_RCC_DelInit (void)
Function Description	Resets the RCC clock configuration to the default reset state.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • The default reset state of the clock configuration is given below: HSI ON and used as system clock sourceHSE and PLL OFFAHB, APB1 and APB2 prescaler set to 1.CSS, MCO1 and MCO2 OFFAll interrupts disabled • This function doesn't modify the configuration of the Peripheral clocksLSI, LSE and RTC clocks

49.3.3 HAL_RCCEEx_PeriphCLKConfig

Function Name	HAL_StatusTypeDef HAL_RCCEEx_PeriphCLKConfig (RCC_PeriphCLKInitTypeDef * PeriphClkInit)
Function Description	Initializes the RCC extended peripherals clocks according to the specified parameters in the RCC_PeriphCLKInitTypeDef.
Parameters	<ul style="list-style-type: none"> • PeriphClkInit: pointer to an RCC_PeriphCLKInitTypeDef structure that contains the configuration information for the Extended Peripherals clocks(I2S, SAI, LTDC, RTC and TIM).
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • Care must be taken when HAL_RCCEEx_PeriphCLKConfig() is used to select the RTC clock source; in this case the Backup domain will be reset in order to modify the RTC Clock source, as consequence RTC registers (including the backup registers) and RCC_BDCR register are set to their reset values.

49.3.4 HAL_RCCEEx_GetPeriphCLKConfig

Function Name	void HAL_RCCEEx_GetPeriphCLKConfig (RCC_PeriphCLKInitTypeDef * PeriphClkInit)
Function Description	Configures the RCC_PeriphCLKInitTypeDef according to the internal RCC configuration registers.

Parameters	<ul style="list-style-type: none"> PeriphClkInit: pointer to an RCC_PeriphCLKInitTypeDef structure that will be configured.
Return values	<ul style="list-style-type: none"> None

49.3.5 HAL_RCC_OscConfig

Function Name	HAL_StatusTypeDef HAL_RCC_OscConfig (RCC_OscInitTypeDef * RCC_OscInitStruct)
Function Description	Initializes the RCC Oscillators according to the specified parameters in the RCC_OscInitTypeDef.
Parameters	<ul style="list-style-type: none"> RCC_OscInitStruct: pointer to an RCC_OscInitTypeDef structure that contains the configuration information for the RCC Oscillators.
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> The PLL is not disabled when used as system clock.

49.3.6 HAL_RCC_GetOscConfig

Function Name	void HAL_RCC_GetOscConfig (RCC_OscInitTypeDef * RCC_OscInitStruct)
Function Description	Configures the RCC_OscInitStruct according to the internal RCC configuration registers.
Parameters	<ul style="list-style-type: none"> RCC_OscInitStruct: pointer to an RCC_OscInitTypeDef structure that will be configured.
Return values	<ul style="list-style-type: none"> None

49.3.7 HAL_RCCEx_SelectLSEMode

Function Name	void HAL_RCCEx_SelectLSEMode (uint8_t Mode)
Function Description	Select LSE mode.
Parameters	<ul style="list-style-type: none"> Mode: specifies the LSE mode. This parameter can be one of the following values: RCC_LSE_LOWPOWER_MODE: LSE oscillator in low power mode selectionRCC_LSE_HIGHLDRIVE_MODE: LSE oscillator in High Drive mode selection
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> This mode is only available for STM32F410xx/STM32F411xx/STM32F446xx/STM32F469xx/STM32F479xx/STM32F412xG devices.

49.4 RCCEx Firmware driver defines

49.4.1 RCCEx

AHB2 Peripheral Clock Enable Disable

```
__HAL_RCC_USB_OTG_FS_CLK_ENABLE
__HAL_RCC_USB_OTG_FS_CLK_DISABLE
__HAL_RCC_RNG_CLK_ENABLE
__HAL_RCC_RNG_CLK_DISABLE
```

AHB2 Force Release Reset

```
__HAL_RCC_AHB2_FORCE_RESET
__HAL_RCC_USB_OTG_FS_FORCE_RESET
__HAL_RCC_RNG_FORCE_RESET
__HAL_RCC_DCMI_FORCE_RESET
__HAL_RCC_AHB2_RELEASE_RESET
__HAL_RCC_USB_OTG_FS_RELEASE_RESET
__HAL_RCC_RNG_RELEASE_RESET
__HAL_RCC_DCMI_RELEASE_RESET
__HAL_RCC_CRYPT_FORCE_RESET
__HAL_RCC_HASH_FORCE_RESET
__HAL_RCC_CRYPT_RELEASE_RESET
__HAL_RCC_HASH_RELEASE_RESET
```

AHB2 Peripheral Low Power Enable Disable

```
__HAL_RCC_USB_OTG_FS_CLK_SLEEP_ENABLE
__HAL_RCC_USB_OTG_FS_CLK_SLEEP_DISABLE
__HAL_RCC_RNG_CLK_SLEEP_ENABLE
__HAL_RCC_RNG_CLK_SLEEP_DISABLE
__HAL_RCC_DCMI_CLK_SLEEP_ENABLE
__HAL_RCC_DCMI_CLK_SLEEP_DISABLE
__HAL_RCC_CRYPT_CLK_SLEEP_ENABLE
__HAL_RCC_HASH_CLK_SLEEP_ENABLE
__HAL_RCC_CRYPT_CLK_SLEEP_DISABLE
__HAL_RCC_HASH_CLK_SLEEP_DISABLE
```

AHB3 Force Release Reset

```
__HAL_RCC_AHB3_FORCE_RESET
__HAL_RCC_AHB3_RELEASE_RESET
__HAL_RCC_FMC_FORCE_RESET
__HAL_RCC_FMC_RELEASE_RESET
__HAL_RCC_QSPI_FORCE_RESET
__HAL_RCC_QSPI_RELEASE_RESET
```

RCC BitAddress AliasRegion

```
RCC_PLLSAION_BIT_NUMBER
RCC_CR_PLLSAION_BB
PLLSAI_TIMEOUT_VALUE
RCC_PLLI2SON_BIT_NUMBER
RCC_CR_PLLI2SON_BB
RCC_DCKCFGR_OFFSET
RCC_TIMPRE_BIT_NUMBER
RCC_DCKCFGR_TIMPRE_BB
RCC_CFGR_OFFSET
RCC_I2SSRC_BIT_NUMBER
RCC_CFGR_I2SSRC_BB
PLLI2S_TIMEOUT_VALUE
PLL_TIMEOUT_VALUE
RCC CK48 Clock Source
RCC_CK48CLKSOURCE_PLLQ
RCC_CK48CLKSOURCE_PLLSAIP
RCC DSI Clock Source
RCC_DSICLKSOURCE_DSIPHY
RCC_DSICLKSOURCE_PLLR
RCCEx Exported Macros
__HAL_RCC_BKPSRAM_CLK_ENABLE
__HAL_RCC_CCMDATARAMEN_CLK_ENABLE
__HAL_RCC_CRC_CLK_ENABLE
__HAL_RCC_GPIOD_CLK_ENABLE
__HAL_RCC_GPIOE_CLK_ENABLE
__HAL_RCC_GPIOI_CLK_ENABLE
__HAL_RCC_GPIOF_CLK_ENABLE
__HAL_RCC_GPIOG_CLK_ENABLE
__HAL_RCC_GPIOJ_CLK_ENABLE
__HAL_RCC_GPIOK_CLK_ENABLE
__HAL_RCC_DMA2D_CLK_ENABLE
__HAL_RCC_ETHMAC_CLK_ENABLE
__HAL_RCC_ETHMACTX_CLK_ENABLE
__HAL_RCC_ETHMACRX_CLK_ENABLE
__HAL_RCC_ETHMACPTP_CLK_ENABLE
__HAL_RCC_USB_OTG_HS_CLK_ENABLE
```

```

__HAL_RCC_USB_OTG_HS_ULPI_CLK_ENABLE
__HAL_RCC_GPIOD_CLK_DISABLE
__HAL_RCC_GPIOE_CLK_DISABLE
__HAL_RCC_GPIOF_CLK_DISABLE
__HAL_RCC_GPIOG_CLK_DISABLE
__HAL_RCC_GPIOI_CLK_DISABLE
__HAL_RCC_GPIOJ_CLK_DISABLE
__HAL_RCC_GPIOK_CLK_DISABLE
__HAL_RCC_DMA2D_CLK_DISABLE
__HAL_RCC_ETHMAC_CLK_DISABLE
__HAL_RCC_ETHMACTX_CLK_DISABLE
__HAL_RCC_ETHMACRX_CLK_DISABLE
__HAL_RCC_ETHMACPTP_CLK_DISABLE
__HAL_RCC_USB_OTG_HS_CLK_DISABLE
__HAL_RCC_USB_OTG_HS_ULPI_CLK_DISABLE
__HAL_RCC_BKPSRAM_CLK_DISABLE
__HAL_RCC_CCMDATARAMEN_CLK_DISABLE
__HAL_RCC_CRC_CLK_DISABLE
__HAL_RCC_ETH_CLK_ENABLE
__HAL_RCC_ETH_CLK_DISABLE

```

I2S Clock Source

RCC_I2SCLKSOURCE_PLLI2S

RCC_I2SCLKSOURCE_EXT

RCC Private macros to check input parameters

```

IS_RCC_PERIPH_CLOCK
IS_RCC_PLLI2SN_VALUE
IS_RCC_PLLI2SR_VALUE
IS_RCC_PLLI2SQ_VALUE
IS_RCC_PLLSAIN_VALUE
IS_RCC_PLLSAIQ_VALUE
IS_RCC_PLLSAIR_VALUE
IS_RCC_PLLSAI_DIVQ_VALUE
IS_RCC_PLLI2S_DIVQ_VALUE
IS_RCC_PLLSAI_DIVR_VALUE
IS_RCC_PLLR_VALUE
IS_RCC_PLLSAIP_VALUE

```

IS_RCC_CK48CLKSOURCE
 IS_RCC_SDIOCLKSOURCE
 IS_RCC_DSIBYTELANECLKSOURCE
 IS_RCC_LSE_MODE
 IS_RCC_MCO2SOURCE

RCC LSE Dual Mode Selection

RCC_LSE_LOWPOWER_MODE
 RCC_LSE_HIGHDRIVE_MODE

RCC Extended MCOx Clock Config

__HAL_RCC_MCO1_CONFIG **Description:**

- Macro to configure the MCO1 clock.

Parameters:

- __MCOCLKSOURCE__: specifies the MCO clock source. This parameter can be one of the following values:
 - RCC_MCO1SOURCE_HSI: HSI clock selected as MCO1 source
 - RCC_MCO1SOURCE_LSE: LSE clock selected as MCO1 source
 - RCC_MCO1SOURCE_HSE: HSE clock selected as MCO1 source
 - RCC_MCO1SOURCE_PLLCLK: main PLL clock selected as MCO1 source
- __MCODIV__: specifies the MCO clock prescaler. This parameter can be one of the following values:
 - RCC_MCODIV_1: no division applied to MCOx clock
 - RCC_MCODIV_2: division by 2 applied to MCOx clock
 - RCC_MCODIV_3: division by 3 applied to MCOx clock
 - RCC_MCODIV_4: division by 4 applied to MCOx clock
 - RCC_MCODIV_5: division by 5 applied to MCOx clock

__HAL_RCC_MCO2_CONFIG **Description:**

- Macro to configure the MCO2 clock.

Parameters:

- __MCOCLKSOURCE__: specifies the MCO clock source. This parameter can be one of the following values:
 - RCC_MCO2SOURCE_SYSCLK: System clock (SYSCLK) selected as MCO2 source
 - RCC_MCO2SOURCE_PLLI2SCLK: PLLI2S clock selected as MCO2 source, available for all STM32F4 devices except STM32F410xx

- RCC_MCO2SOURCE_I2SCLK: I2SCLK clock selected as MCO2 source, available only for STM32F410Rx devices
- RCC_MCO2SOURCE_HSE: HSE clock selected as MCO2 source
- RCC_MCO2SOURCE_PLLCLK: main PLL clock selected as MCO2 source
- MCODIV: specifies the MCO clock prescaler. This parameter can be one of the following values:
 - RCC_MCODIV_1: no division applied to MCOx clock
 - RCC_MCODIV_2: division by 2 applied to MCOx clock
 - RCC_MCODIV_3: division by 3 applied to MCOx clock
 - RCC_MCODIV_4: division by 4 applied to MCOx clock
 - RCC_MCODIV_5: division by 5 applied to MCOx clock

Notes:

- For STM32F410Rx devices, to output I2SCLK clock on MCO2, you should have at least one of the SPI clocks enabled (SPI1, SPI2 or SPI5).

RCC Periph Clock Selection

RCC_PERIPHCLK_I2S
 RCC_PERIPHCLK_SAI_PLLI2S
 RCC_PERIPHCLK_SAI_PLLSAI
 RCC_PERIPHCLK_LTDC
 RCC_PERIPHCLK_TIM
 RCC_PERIPHCLK_RTC
 RCC_PERIPHCLK_PLLI2S
 RCC_PERIPHCLK_CK48
 RCC_PERIPHCLK_SDIO

RCC PLLSAIP Clock Divider

RCC_PLLSAIP_DIV2
 RCC_PLLSAIP_DIV4
 RCC_PLLSAIP_DIV6
 RCC_PLLSAIP_DIV8

RCC PLLSAI DIVR

RCC_PLLSAIDIVR_2
 RCC_PLLSAIDIVR_4
 RCC_PLLSAIDIVR_8
 RCC_PLLSAIDIVR_16

RCC SAI BlockA Clock Source

RCC_SAIACLKSOURCE_PLLSAI
RCC_SAIACLKSOURCE_PLLI2S
RCC_SAIACLKSOURCE_EXT

RCC SAI BlockB Clock Source

RCC_SAIBCLKSOURCE_PLLSAI
RCC_SAIBCLKSOURCE_PLLI2S
RCC_SAIBCLKSOURCE_EXT

RCC SDIO Clock Source

RCC_SDIOCLKSOURCE_CK48
RCC_SDIOCLKSOURCE_SYSCLK

RCC TIM PRescaler Selection

RCC_TIMPRES_DESACTIVATED
RCC_TIMPRES_ACTIVATED

50 HAL RNG Generic Driver

50.1 HAL RNG Generic Driver

50.2 RNG Firmware driver registers structures

50.2.1 RNG_HandleTypeDef

Data Fields

- *RNG_TypeDef * Instance*
- *HAL_LockTypeDef Lock*
- *_IO HAL_RNG_StateTypeDef State*
- *uint32_t RandomNumber*

Field Documentation

- *RNG_TypeDef* RNG_HandleTypeDef::Instance*
Register base address
- *HAL_LockTypeDef RNG_HandleTypeDef::Lock*
RNG locking object
- *_IO HAL_RNG_StateTypeDef RNG_HandleTypeDef::State*
RNG communication state
- *uint32_t RNG_HandleTypeDef::RandomNumber*
Last Generated RNG Data

50.3 RNG Firmware driver API description

50.3.1 How to use this driver

The RNG HAL driver can be used as follows:

1. Enable the RNG controller clock using `_HAL_RCC_RNG_CLK_ENABLE()` macro in `HAL_RNG_MspInit()`.
2. Activate the RNG peripheral using `HAL_RNG_Init()` function.
3. Wait until the 32 bit Random Number Generator contains a valid random data using (polling/interrupt) mode.
4. Get the 32 bit random number using `HAL_RNG_GenerateRandomNumber()` function.

50.3.2 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the RNG according to the specified parameters in the `RNG_InitTypeDef` and create the associated handle
- Deinitialize the RNG peripheral
- Initialize the RNG MSP
- Deinitialize RNG MSP

This section contains the following APIs:

- [`HAL_RNG_Init\(\)`](#)
- [`HAL_RNG_DelInit\(\)`](#)
- [`HAL_RNG_MsplInit\(\)`](#)
- [`HAL_RNG_MspDelInit\(\)`](#)

50.3.3 Peripheral Control functions

This section provides functions allowing to:

- Get the 32 bit Random number
- Get the 32 bit Random number with interrupt enabled
- Handle RNG interrupt request

This section contains the following APIs:

- [`HAL_RNG_GenerateRandomNumber\(\)`](#)
- [`HAL_RNG_GenerateRandomNumber_IT\(\)`](#)
- [`HAL_RNG_IRQHandler\(\)`](#)
- [`HAL_RNG_GetRandomNumber\(\)`](#)
- [`HAL_RNG_GetRandomNumber_IT\(\)`](#)
- [`HAL_RNG_ReadLastRandomNumber\(\)`](#)
- [`HAL_RNG_ReadyDataCallback\(\)`](#)
- [`HAL_RNG_ErrorCallback\(\)`](#)

50.3.4 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [`HAL_RNG_GetState\(\)`](#)

50.3.5 HAL_RNG_Init

Function Name	<code>HAL_StatusTypeDef HAL_RNG_Init (RNG_HandleTypeDef * hrng)</code>
Function Description	Initializes the RNG peripheral and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> • HAL status

50.3.6 HAL_RNG_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_RNG_DelInit (RNG_HandleTypeDef * hrng)</code>
Function Description	Deinitializes the RNG peripheral.
Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> • HAL status

50.3.7 HAL_RNG_MsplInit

Function Name	<code>void HAL_RNG_MsplInit (RNG_HandleTypeDef * hrng)</code>
Function Description	Initializes the RNG MSP.

Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> • None

50.3.8 HAL_RNG_MspDeInit

Function Name	void HAL_RNG_MspDeInit (RNG_HandleTypeDef * hrng)
Function Description	DeInitializes the RNG MSP.
Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> • None

50.3.9 HAL_RNG_GenerateRandomNumber

Function Name	HAL_StatusTypeDef HAL_RNG_GenerateRandomNumber (RNG_HandleTypeDef * hrng, uint32_t * random32bit)
Function Description	Generates a 32-bit random number.
Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG. • random32bit: pointer to generated random number variable if successful.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • Each time the random number data is read the RNG_FLAG_DRDY flag is automatically cleared.

50.3.10 HAL_RNG_GenerateRandomNumber_IT

Function Name	HAL_StatusTypeDef HAL_RNG_GenerateRandomNumber_IT (RNG_HandleTypeDef * hrng)
Function Description	Generates a 32-bit random number in interrupt mode.
Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> • HAL status

50.3.11 HAL_RNG_IRQHandler

Function Name	void HAL_RNG_IRQHandler (RNG_HandleTypeDef * hrng)
Function Description	Handles RNG interrupt request.
Parameters	<ul style="list-style-type: none"> • hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> • None
Notes	<ul style="list-style-type: none"> • In the case of a clock error, the RNG is no more able to generate random numbers because the PLL48CLK clock is not correct. User has to check that the clock controller is correctly configured to provide the RNG clock and clear the CEIS bit using __HAL_RNG_CLEAR_IT(). The clock error has no impact on the previously generated random numbers,

- and the RNG_DR register contents can be used.
- In the case of a seed error, the generation of random numbers is interrupted as long as the SECS bit is '1'. If a number is available in the RNG_DR register, it must not be used because it may not have enough entropy. In this case, it is recommended to clear the SEIS bit using `__HAL_RNG_CLEAR_IT()`, then disable and enable the RNG peripheral to reinitialize and restart the RNG.
- User-written HAL_RNG_ErrorCallback() API is called once whether SEIS or CEIS are set.

50.3.12 HAL_RNG_GetRandomNumber

Function Name	<code>uint32_t HAL_RNG_GetRandomNumber (RNG_HandleTypeDef * hrng)</code>
Function Description	Returns generated random number in polling mode (Obsolete) Use HAL_RNG_GenerateRandomNumber() API instead.
Parameters	<ul style="list-style-type: none"> hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> Random value

50.3.13 HAL_RNG_GetRandomNumber_IT

Function Name	<code>uint32_t HAL_RNG_GetRandomNumber_IT (RNG_HandleTypeDef * hrng)</code>
Function Description	Returns a 32-bit random number with interrupt enabled (Obsolete), Use HAL_RNG_GenerateRandomNumber_IT() API instead.
Parameters	<ul style="list-style-type: none"> hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> 32-bit random number

50.3.14 HAL_RNG_ReadLastRandomNumber

Function Name	<code>uint32_t HAL_RNG_ReadLastRandomNumber (RNG_HandleTypeDef * hrng)</code>
Function Description	Read latest generated random number.
Parameters	<ul style="list-style-type: none"> hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> random value

50.3.15 HAL_RNG_ReadyDataCallback

Function Name	<code>void HAL_RNG_ReadyDataCallback (RNG_HandleTypeDef * hrng, uint32_t random32bit)</code>
Function Description	Data Ready callback in non-blocking mode.
Parameters	<ul style="list-style-type: none"> hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG. random32bit: generated random number.

Return values	<ul style="list-style-type: none"> None
---------------	--

50.3.16 HAL_RNG_ErrorCallback

Function Name	void HAL_RNG_ErrorCallback (RNG_HandleTypeDef * hrng)
Function Description	RNG error callbacks.
Parameters	<ul style="list-style-type: none"> hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> None

50.3.17 HAL_RNG_GetState

Function Name	HAL_RNG_StateTypeDef HAL_RNG_GetState (RNG_HandleTypeDef * hrng)
Function Description	Returns the RNG state.
Parameters	<ul style="list-style-type: none"> hrng: pointer to a RNG_HandleTypeDef structure that contains the configuration information for RNG.
Return values	<ul style="list-style-type: none"> HAL state

50.4 RNG Firmware driver defines

50.4.1 RNG

RNG Interrupt definition

RNG_IT_DRDY	Data Ready interrupt
RNG_IT_CEI	Clock error interrupt
RNG_IT_SEI	Seed error interrupt

RNG Flag definition

RNG_FLAG_DRDY	Data ready
RNG_FLAG_CECS	Clock error current status
RNG_FLAG_SECS	Seed error current status

RNG Exported Macros

_HAL_RNG_RESET_HANDLE_STATE	Description:
	<ul style="list-style-type: none"> Reset RNG handle state.
	Parameters:
	<ul style="list-style-type: none"> _HANDLE_: RNG Handle
	Return value:
	<ul style="list-style-type: none"> None
_HAL_RNG_ENABLE	Description:
	<ul style="list-style-type: none"> Enables the RNG peripheral.
	Parameters:

- `__HANDLE__`: RNG Handle

Return value:

- None

`__HAL_RNG_DISABLE`**Description:**

- Disables the RNG peripheral.

Parameters:

- `__HANDLE__`: RNG Handle

Return value:

- None

`__HAL_RNG_GET_FLAG`**Description:**

- Check the selected RNG flag status.

Parameters:

- `__HANDLE__`: RNG Handle
- `__FLAG__`: RNG flag This parameter can be one of the following values:
 - `RNG_FLAG_DRDY`: Data ready
 - `RNG_FLAG_CECS`: Clock error current status
 - `RNG_FLAG_SECS`: Seed error current status

Return value:

- The new state of `__FLAG__` (SET or RESET).

`__HAL_RNG_CLEAR_FLAG`**Description:**

- Clears the selected RNG flag status.

Parameters:

- `__HANDLE__`: RNG handle
- `__FLAG__`: RNG flag to clear

Return value:

- None

Notes:

- WARNING: This is a dummy macro for HAL code alignment, flags `RNG_FLAG_DRDY`, `RNG_FLAG_CECS` and `RNG_FLAG_SECS` are read-only.

`__HAL_RNG_ENABLE_IT`**Description:**

- Enables the RNG interrupts.

Parameters:

- `__HANDLE__`: RNG Handle

Return value:

- None

__HAL_RNG_DISABLE_IT**Description:**

- Disables the RNG interrupts.

Parameters:

- __HANDLE__: RNG Handle

Return value:

- None

__HAL_RNG_GET_IT**Description:**

- Checks whether the specified RNG interrupt has occurred or not.

Parameters:

- __HANDLE__: RNG Handle
- __INTERRUPT__: specifies the RNG interrupt status flag to check. This parameter can be one of the following values:
 - RNG_IT_DRDY: Data ready interrupt
 - RNG_IT_CEI: Clock error interrupt
 - RNG_IT_SEI: Seed error interrupt

Return value:

- The new state of __INTERRUPT__ (SET or RESET).

__HAL_RNG_CLEAR_IT**Description:**

- Clear the RNG interrupt status flags.

Parameters:

- __HANDLE__: RNG Handle
- __INTERRUPT__: specifies the RNG interrupt status flag to clear. This parameter can be one of the following values:
 - RNG_IT_CEI: Clock error interrupt
 - RNG_IT_SEI: Seed error interrupt

Return value:

- None

Notes:

- RNG_IT_DRDY flag is read-only, reading RNG_DR register automatically clears RNG_IT_DRDY.

RNG Private Constants**RNG_TIMEOUT_VALUE*****RNG Private Macros***

IS_RNG_IT
IS_RNG_FLAG

51 HAL RTC Generic Driver

51.1 HAL RTC Generic Driver

51.2 RTC Firmware driver registers structures

51.2.1 RTC_InitTypeDef

Data Fields

- *uint32_t HourFormat*
- *uint32_t AsynchPrediv*
- *uint32_t SynchPrediv*
- *uint32_t OutPut*
- *uint32_t OutPutPolarity*
- *uint32_t OutPutType*

Field Documentation

- ***uint32_t RTC_InitTypeDef::HourFormat***
Specifies the RTC Hour Format. This parameter can be a value of [*RTC_Hour_Formats*](#)
- ***uint32_t RTC_InitTypeDef::AsynchPrediv***
Specifies the RTC Asynchronous Predivider value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0x7F
- ***uint32_t RTC_InitTypeDef::SynchPrediv***
Specifies the RTC Synchronous Predivider value. This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFFFF
- ***uint32_t RTC_InitTypeDef::OutPut***
Specifies which signal will be routed to the RTC output. This parameter can be a value of [*RTC_Output_selection_Definitions*](#)
- ***uint32_t RTC_InitTypeDef::OutPutPolarity***
Specifies the polarity of the output signal. This parameter can be a value of [*RTC_Output_Polarity_Definitions*](#)
- ***uint32_t RTC_InitTypeDef::OutPutType***
Specifies the RTC Output Pin mode. This parameter can be a value of [*RTC_Output_Type_ALARM_OUT*](#)

51.2.2 RTC_TimeTypeDef

Data Fields

- *uint8_t Hours*
- *uint8_t Minutes*
- *uint8_t Seconds*
- *uint8_t TimeFormat*
- *uint32_t SubSeconds*
- *uint32_t SecondFraction*

- *uint32_t DayLightSaving*
- *uint32_t StoreOperation*

Field Documentation

- ***uint8_t RTC_TimeTypeDef::Hours***
Specifies the RTC Time Hour. This parameter must be a number between Min_Data = 0 and Max_Data = 12 if the RTC_HourFormat_12 is selected. This parameter must be a number between Min_Data = 0 and Max_Data = 23 if the RTC_HourFormat_24 is selected
- ***uint8_t RTC_TimeTypeDef::Minutes***
Specifies the RTC Time Minutes. This parameter must be a number between Min_Data = 0 and Max_Data = 59
- ***uint8_t RTC_TimeTypeDef::Seconds***
Specifies the RTC Time Seconds. This parameter must be a number between Min_Data = 0 and Max_Data = 59
- ***uint8_t RTC_TimeTypeDef::TimeFormat***
Specifies the RTC AM/PM Time. This parameter can be a value of [RTC_AM_PM_Definitions](#)
- ***uint32_t RTC_TimeTypeDef::SubSeconds***
Specifies the RTC_SSR RTC Sub Second register content. This parameter corresponds to a time unit range between [0-1] Second with [1 Sec / SecondFraction +1] granularity
- ***uint32_t RTC_TimeTypeDef::SecondFraction***
Specifies the range or granularity of Sub Second register content corresponding to Synchronous pre-scaler factor value (PREDIV_S) This parameter corresponds to a time unit range between [0-1] Second with [1 Sec / SecondFraction +1] granularity. This field will be used only by HAL_RTC_GetTime function
- ***uint32_t RTC_TimeTypeDef::DayLightSaving***
Specifies DayLight Save Operation. This parameter can be a value of [RTC_DayLightSaving_Definitions](#)
- ***uint32_t RTC_TimeTypeDef::StoreOperation***
Specifies RTC_StoreOperation value to be written in the BCK bit in CR register to store the operation. This parameter can be a value of [RTC_StoreOperation_Definitions](#)

51.2.3 RTC_DateTypeDef

Data Fields

- *uint8_t WeekDay*
- *uint8_t Month*
- *uint8_t Date*
- *uint8_t Year*

Field Documentation

- ***uint8_t RTC_DateTypeDef::WeekDay***
Specifies the RTC Date WeekDay. This parameter can be a value of [RTC_WeekDay_Definitions](#)

- ***uint8_t RTC_DateTypeDef::Month***
Specifies the RTC Date Month (in BCD format). This parameter can be a value of [*RTC_Month_Date_Definitions*](#)
- ***uint8_t RTC_DateTypeDef::Date***
Specifies the RTC Date. This parameter must be a number between Min_Data = 1 and Max_Data = 31
- ***uint8_t RTC_DateTypeDef::Year***
Specifies the RTC Date Year. This parameter must be a number between Min_Data = 0 and Max_Data = 99

51.2.4 RTC_AlarmTypeDef

Data Fields

- ***RTC_TimeTypeDef AlarmTime***
- ***uint32_t AlarmMask***
- ***uint32_t AlarmSubSecondMask***
- ***uint32_t AlarmDateWeekDaySel***
- ***uint8_t AlarmDateWeekDay***
- ***uint32_t Alarm***

Field Documentation

- ***RTC_TimeTypeDef RTC_AlarmTypeDef::AlarmTime***
Specifies the RTC Alarm Time members
- ***uint32_t RTC_AlarmTypeDef::AlarmMask***
Specifies the RTC Alarm Masks. This parameter can be a value of [*RTC_AlarmMask_Definitions*](#)
- ***uint32_t RTC_AlarmTypeDef::AlarmSubSecondMask***
Specifies the RTC Alarm SubSeconds Masks. This parameter can be a value of [*RTC_Alarm_Sub_Seconds_Masks_Definitions*](#)
- ***uint32_t RTC_AlarmTypeDef::AlarmDateWeekDaySel***
Specifies the RTC Alarm is on Date or WeekDay. This parameter can be a value of [*RTC_AlarmDateWeekDay_Definitions*](#)
- ***uint8_t RTC_AlarmTypeDef::AlarmDateWeekDay***
Specifies the RTC Alarm Date/WeekDay. If the Alarm Date is selected, this parameter must be set to a value in the 1-31 range. If the Alarm WeekDay is selected, this parameter can be a value of [*RTC_WeekDay_Definitions*](#)
- ***uint32_t RTC_AlarmTypeDef::Alarm***
Specifies the alarm . This parameter can be a value of [*RTC_Alarms_Definitions*](#)

51.2.5 RTC_HandleTypeDef

Data Fields

- ***RTC_TypeDef * Instance***
- ***RTC_InitTypeDef Init***
- ***HAL_LockTypeDef Lock***
- ***__IO HAL_RTCStateTypeDef State***

Field Documentation

- ***RTC_TypeDef* RTC_HandleTypeDef::Instance***
Register base address
- ***RTC_InitTypeDef RTC_HandleTypeDef::Init***
RTC required parameters
- ***HAL_LockTypeDef RTC_HandleTypeDef::Lock***
RTC locking object
- ***_IO HAL_RTCStateTypeDef RTC_HandleTypeDef::State***
Time communication state

51.3 RTC Firmware driver API description

51.3.1 Backup Domain Operating Condition

The real-time clock (RTC), the RTC backup registers, and the backup SRAM (BKP SRAM) can be powered from the VBAT voltage when the main VDD supply is powered off. To retain the content of the RTC backup registers, backup SRAM, and supply the RTC when VDD is turned off, VBAT pin can be connected to an optional standby voltage supplied by a battery or by another source.

To allow the RTC operating even when the main digital supply (VDD) is turned off, the VBAT pin powers the following blocks:

1. The RTC
2. The LSE oscillator
3. The backup SRAM when the low power backup regulator is enabled
4. PC13 to PC15 I/Os, plus PI8 I/O (when available)

When the backup domain is supplied by VDD (analog switch connected to VDD), the following pins are available:

1. PC14 and PC15 can be used as either GPIO or LSE pins
2. PC13 can be used as a GPIO or as the RTC_AF1 pin
3. PI8 can be used as a GPIO or as the RTC_AF2 pin

When the backup domain is supplied by VBAT (analog switch connected to VBAT because VDD is not present), the following pins are available:

1. PC14 and PC15 can be used as LSE pins only
2. PC13 can be used as the RTC_AF1 pin
3. PI8 can be used as the RTC_AF2 pin

51.3.2 Backup Domain Reset

The backup domain reset sets all RTC registers and the RCC_BDCR register to their reset values. The BKPSRAM is not affected by this reset. The only way to reset the BKPSRAM is through the Flash interface by requesting a protection level change from 1 to 0.

A backup domain reset is generated when one of the following events occurs:

1. Software reset, triggered by setting the BDRST bit in the RCC Backup domain control register (RCC_BDCR).
2. VDD or VBAT power on, if both supplies have previously been powered off.

51.3.3 Backup Domain Access

After reset, the backup domain (RTC registers, RTC backup data registers and backup SRAM) is protected against possible unwanted write accesses.

To enable access to the RTC Domain and RTC registers, proceed as follows:

- Enable the Power Controller (PWR) APB1 interface clock using the `_HAL_RCC_PWR_CLK_ENABLE()` function.
- Enable access to RTC domain using the `HAL_PWR_EnableBkUpAccess()` function.
- Select the RTC clock source using the `_HAL_RCC_RTC_CONFIG()` function.
- Enable RTC Clock using the `_HAL_RCC_RTC_ENABLE()` function.

51.3.4 How to use this driver

- Enable the RTC domain access (see description in the section above).
- Configure the RTC Prescaler (Asynchronous and Synchronous) and RTC hour format using the `HAL_RTC_Init()` function.

Time and Date configuration

- To configure the RTC Calendar (Time and Date) use the `HAL_RTC_SetTime()` and `HAL_RTC_SetDate()` functions.
- To read the RTC Calendar, use the `HAL_RTC_GetTime()` and `HAL_RTC_GetDate()` functions.

Alarm configuration

- To configure the RTC Alarm use the `HAL_RTC_SetAlarm()` function. You can also configure the RTC Alarm with interrupt mode using the `HAL_RTC_SetAlarm_IT()` function.
- To read the RTC Alarm, use the `HAL_RTC_GetAlarm()` function.

51.3.5 RTC and low power modes

The MCU can be woken up from a low power mode by an RTC alternate function.

The RTC alternate functions are the RTC alarms (Alarm A and Alarm B), RTC wake-up, RTC tamper event detection and RTC time stamp event detection. These RTC alternate functions can wake up the system from the Stop and Standby low power modes.

The system can also wake up from low power modes without depending on an external interrupt (Auto-wake-up mode), by using the RTC alarm or the RTC wake-up events.

The RTC provides a programmable time base for waking up from the Stop or Standby mode at regular intervals. Wake-up from STOP and STANDBY modes is possible only when the RTC clock source is LSE or LSI.

51.3.6 Initialization and de-initialization functions

This section provides functions allowing to initialize and configure the RTC Prescaler (Synchronous and Asynchronous), RTC Hour format, disable RTC registers Write protection, enter and exit the RTC initialization mode, RTC registers synchronization check and reference clock detection enable.

1. The RTC Prescaler is programmed to generate the RTC 1Hz time base. It is split into 2 programmable prescalers to minimize power consumption.
 - A 7-bit asynchronous prescaler and a 13-bit synchronous prescaler.
 - When both prescalers are used, it is recommended to configure the asynchronous prescaler to a high value to minimize power consumption.
2. All RTC registers are Write protected. Writing to the RTC registers is enabled by writing a key into the Write Protection register, RTC_WPR.
3. To configure the RTC Calendar, user application should enter initialization mode. In this mode, the calendar counter is stopped and its value can be updated. When the initialization sequence is complete, the calendar restarts counting after 4 RTCCLK cycles.
4. To read the calendar through the shadow registers after Calendar initialization, calendar update or after wake-up from low power modes the software must first clear the RSF flag. The software must then wait until it is set again before reading the calendar, which means that the calendar registers have been correctly copied into the RTC_TR and RTC_DR shadow registers. The HAL_RTC_WaitForSynchro() function implements the above software sequence (RSF clear and RSF check).

This section contains the following APIs:

- [`HAL_RTC_Init\(\)`](#)
- [`HAL_RTC_DelInit\(\)`](#)
- [`HAL_RTC_MspInit\(\)`](#)
- [`HAL_RTC_MspDeInit\(\)`](#)

51.3.7 RTC Time and Date functions

This section provides functions allowing to configure Time and Date features

This section contains the following APIs:

- [`HAL_RTC_SetTime\(\)`](#)
- [`HAL_RTC_GetTime\(\)`](#)
- [`HAL_RTC_SetDate\(\)`](#)
- [`HAL_RTC_GetDate\(\)`](#)

51.3.8 RTC Alarm functions

This section provides functions allowing to configure Alarm feature

This section contains the following APIs:

- [`HAL_RTC_SetAlarm\(\)`](#)
- [`HAL_RTC_SetAlarm_IT\(\)`](#)
- [`HAL_RTC_DeactivateAlarm\(\)`](#)
- [`HAL_RTC_GetAlarm\(\)`](#)
- [`HAL_RTC_AlarmIRQHandler\(\)`](#)
- [`HAL_RTC_AlarmAEventCallback\(\)`](#)
- [`HAL_RTC_PollForAlarmAEvent\(\)`](#)

51.3.9 Peripheral Control functions

This subsection provides functions allowing to

- Wait for RTC Time and Date Synchronization

This section contains the following APIs:

- [`HAL_RTC_WaitForSynchro\(\)`](#)

51.3.10 Peripheral State functions

This subsection provides functions allowing to

- Get RTC state

This section contains the following APIs:

- [***HAL_RTC_GetState\(\)***](#)

51.3.11 HAL_RTC_Init

Function Name	<code>HAL_StatusTypeDef HAL_RTC_Init (RTC_HandleTypeDef * hrtc)</code>
---------------	---

Function Description	Initializes the RTC peripheral.
----------------------	---------------------------------

Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
------------	--

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

51.3.12 HAL_RTC_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_RTC_DeInit (RTC_HandleTypeDef * hrtc)</code>
---------------	---

Function Description	Deinitializes the RTC peripheral.
----------------------	-----------------------------------

Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
------------	--

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

Notes	<ul style="list-style-type: none"> • This function doesn't reset the RTC Backup Data registers.
-------	--

51.3.13 HAL_RTC_MspInit

Function Name	<code>void HAL_RTC_MspInit (RTC_HandleTypeDef * hrtc)</code>
---------------	---

Function Description	Initializes the RTC MSP.
----------------------	--------------------------

Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
------------	--

Return values	<ul style="list-style-type: none"> • None
---------------	--

51.3.14 HAL_RTC_MspDeInit

Function Name	<code>void HAL_RTC_MspDeInit (RTC_HandleTypeDef * hrtc)</code>
---------------	---

Function Description	Deinitializes the RTC MSP.
----------------------	----------------------------

Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
------------	--

Return values	<ul style="list-style-type: none"> • None
---------------	--

51.3.15 HAL_RTC_SetTime

Function Name	<code>HAL_StatusTypeDef HAL_RTC_SetTime (RTC_HandleTypeDef * hrtc, RTC_TimeTypeDef * sTime, uint32_t Format)</code>
---------------	--

Function Description	Sets RTC current time.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. sTime: Pointer to Time structure Format: Specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> HAL status

51.3.16 HAL_RTC_GetTime

Function Name	HAL_StatusTypeDef HAL_RTC_GetTime (RTC_HandleTypeDef * hrtc, RTC_TimeTypeDef * sTime, uint32_t Format)
Function Description	Gets RTC current time.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. sTime: Pointer to Time structure Format: Specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> You can use SubSeconds and SecondFraction (sTime structure fields returned) to convert SubSeconds value in second fraction ratio with time unit following generic formula: Second fraction ratio * time_unit= [(SecondFraction-SubSeconds)/(SecondFraction+1)] * time_unit This conversion can be performed only if no shift operation is pending (ie. SHFP=0) when PREDIV_S>= SS You must call HAL_RTC_GetDate() after HAL_RTC_GetTime() to unlock the values in the higher-order calendar shadow registers to ensure consistency between the time and date values. Reading RTC current time locks the values in calendar shadow registers until current date is read.

51.3.17 HAL_RTC_SetDate

Function Name	HAL_StatusTypeDef HAL_RTC_SetDate (RTC_HandleTypeDef * hrtc, RTC_DateTypeDef * sDate, uint32_t Format)
Function Description	Sets RTC current date.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. sDate: Pointer to date structure Format: specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> HAL status

51.3.18 HAL_RTC_GetDate

Function Name	<code>HAL_StatusTypeDef HAL_RTC_GetDate (RTC_HandleTypeDef * hrtc, RTC_DateTypeDef * sDate, uint32_t Format)</code>
Function Description	Gets RTC current date.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sDate: Pointer to Date structure • Format: Specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • You must call HAL_RTC_GetDate() after HAL_RTC_GetTime() to unlock the values in the higher-order calendar shadow registers to ensure consistency between the time and date values. Reading RTC current time locks the values in calendar shadow registers until Current date is read.

51.3.19 HAL_RTC_SetAlarm

Function Name	<code>HAL_StatusTypeDef HAL_RTC_SetAlarm (RTC_HandleTypeDef * hrtc, RTC_AlarmTypeDef * sAlarm, uint32_t Format)</code>
Function Description	Sets the specified RTC Alarm.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sAlarm: Pointer to Alarm structure • Format: Specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> • HAL status

51.3.20 HAL_RTC_SetAlarm_IT

Function Name	<code>HAL_StatusTypeDef HAL_RTC_SetAlarm_IT (RTC_HandleTypeDef * hrtc, RTC_AlarmTypeDef * sAlarm, uint32_t Format)</code>
Function Description	Sets the specified RTC Alarm with Interrupt.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sAlarm: Pointer to Alarm structure • Format: Specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> • HAL status

51.3.21 HAL_RTC_DeactivateAlarm

Function Name	HAL_StatusTypeDef HAL_RTC_DeactivateAlarm (RTC_HandleTypeDef * hrtc, uint32_t Alarm)
Function Description	Deactivate the specified RTC Alarm.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • Alarm: Specifies the Alarm. This parameter can be one of the following values: RTC_ALARM_A: AlarmARTC_ALARM_B: AlarmB
Return values	<ul style="list-style-type: none"> • HAL status

51.3.22 HAL_RTC_GetAlarm

Function Name	HAL_StatusTypeDef HAL_RTC_GetAlarm (RTC_HandleTypeDef * hrtc, RTC_AlarmTypeDef * sAlarm, uint32_t Alarm, uint32_t Format)
Function Description	Gets the RTC Alarm value and masks.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sAlarm: Pointer to Date structure • Alarm: Specifies the Alarm. This parameter can be one of the following values: RTC_ALARM_A: AlarmARTC_ALARM_B: AlarmB • Format: Specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data formatRTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> • HAL status

51.3.23 HAL_RTC_AlarmIRQHandler

Function Name	void HAL_RTC_AlarmIRQHandler (RTC_HandleTypeDef * hrtc)
Function Description	This function handles Alarm interrupt request.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

51.3.24 HAL_RTC_AlarmAEventCallback

Function Name	void HAL_RTC_AlarmAEventCallback (RTC_HandleTypeDef * hrtc)
Function Description	Alarm A callback.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

51.3.25 HAL_RTC_PollForAlarmAEvent



Function Name	HAL_StatusTypeDef HAL_RTC_PollForAlarmAEvent (RTC_HandleTypeDef * hrtc, uint32_t Timeout)
Function Description	This function handles AlarmA Polling request.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

51.3.26 HAL_RTC_WaitForSynchro

Function Name	HAL_StatusTypeDef HAL_RTC_WaitForSynchro (RTC_HandleTypeDef * hrtc)
Function Description	Waits until the RTC Time and Date registers (RTC_TR and RTC_DR) are synchronized with RTC APB clock.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> The RTC Resynchronization mode is write protected, use the <code>_HAL_RTC_WRITEPROTECTION_DISABLE()</code> before calling this function. To read the calendar through the shadow registers after Calendar initialization, calendar update or after wake-up from low power modes the software must first clear the RSF flag. The software must then wait until it is set again before reading the calendar, which means that the calendar registers have been correctly copied into the RTC_TR and RTC_DR shadow registers.

51.3.27 HAL_RTC_GetState

Function Name	HAL_RTCStateTypeDef HAL_RTC_GetState (RTC_HandleTypeDef * hrtc)
Function Description	Returns the RTC state.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> HAL state

51.4 RTC Firmware driver defines

51.4.1 RTC

RTC Alarm Date WeekDay Definitions

RTC_ALARMDATEWEEKDAYSEL_DATE

RTC_ALARMDATEWEEKDAYSEL_WEEKDAY

RTC Alarm Mask Definitions

RTC_ALARMMASK_NONE

RTC_ALARMMASK_DATEWEEKDAY
 RTC_ALARMMASK_HOURS
 RTC_ALARMMASK_MINUTES
 RTC_ALARMMASK_SECONDS
 RTC_ALARMMASK_ALL

RTC Alarms Definitions

RTC_ALARM_A
 RTC_ALARM_B

RTC Alarm Sub Seconds Masks Definitions

RTC_ALARMSUBSECONDMASK_ALL	All Alarm SS fields are masked. There is no comparison on sub seconds for Alarm
RTC_ALARMSUBSECONDMASK_SS14_1	SS[14:1] are don't care in Alarm comparison. Only SS[0] is compared.
RTC_ALARMSUBSECONDMASK_SS14_2	SS[14:2] are don't care in Alarm comparison. Only SS[1:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_3	SS[14:3] are don't care in Alarm comparison. Only SS[2:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_4	SS[14:4] are don't care in Alarm comparison. Only SS[3:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_5	SS[14:5] are don't care in Alarm comparison. Only SS[4:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_6	SS[14:6] are don't care in Alarm comparison. Only SS[5:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_7	SS[14:7] are don't care in Alarm comparison. Only SS[6:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_8	SS[14:8] are don't care in Alarm comparison. Only SS[7:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_9	SS[14:9] are don't care in Alarm comparison. Only SS[8:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_10	SS[14:10] are don't care in Alarm comparison. Only SS[9:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_11	SS[14:11] are don't care in Alarm comparison. Only SS[10:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_12	SS[14:12] are don't care in Alarm comparison. Only SS[11:0] are compared
RTC_ALARMSUBSECONDMASK_SS14_13	SS[14:13] are don't care in Alarm comparison. Only SS[12:0] are compared
RTC_ALARMSUBSECONDMASK_SS14	SS[14] is don't care in Alarm comparison. Only SS[13:0] are compared
RTC_ALARMSUBSECONDMASK_NONE	SS[14:0] are compared and must match to activate alarm.

RTC AM PM Definitions

RTC_HOURFORMAT12_AM

RTC_HOURFORMAT12_PM

RTC DayLight Saving Definitions

RTC_DAYLIGHTSAVING_SUB1H

RTC_DAYLIGHTSAVING_ADD1H

RTC_DAYLIGHTSAVING_NONE

RTC Exported Macros

`_HAL_RTC_RESET_HANDLE_STATE`

Description:

- Reset RTC handle state.

Parameters:

- `_HANDLE_`: specifies the RTC handle.

Return value:

- None

`_HAL_RTC_WRITEPROTECTION_DISABLE`

Description:

- Disable the write protection for RTC registers.

Parameters:

- `_HANDLE_`: specifies the RTC handle.

Return value:

- None

`_HAL_RTC_WRITEPROTECTION_ENABLE`

Description:

- Enable the write protection for RTC registers.

Parameters:

- `_HANDLE_`: specifies the RTC handle.

Return value:

- None

`_HAL_RTC_ALARMA_ENABLE`

Description:

- Enable the RTC ALARMA peripheral.

Parameters:

- `_HANDLE_`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_ALARMA_DISABLE`

Description:

- Disable the RTC ALARMA peripheral.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_ALARM_B_ENABLE`

Description:

- Enable the RTC ALARMB peripheral.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_ALARM_B_DISABLE`

Description:

- Disable the RTC ALARMB peripheral.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_ALARM_ENABLE_IT`

Description:

- Enable the RTC Alarm interrupt.

Parameters:

- `__HANDLE__`: specifies the RTC handle.
- `__INTERRUPT__`: specifies the RTC Alarm interrupt sources to be enabled or disabled. This parameter can be any combination of the following values:
 - `RTC_IT_ALRA`: Alarm A interrupt
 - `RTC_IT_ALRB`: Alarm B interrupt

Return value:

- None

_HAL_RTC_ALARM_DISABLE_IT**Description:**

- Disable the RTC Alarm interrupt.

Parameters:

- HANDLE: specifies the RTC handle.
- INTERRUPT: specifies the RTC Alarm interrupt sources to be enabled or disabled. This parameter can be any combination of the following values:
 - RTC_IT_ALRA: Alarm A interrupt
 - RTC_IT_ALRB: Alarm B interrupt

Return value:

- None

_HAL_RTC_ALARM_GET_IT**Description:**

- Check whether the specified RTC Alarm interrupt has occurred or not.

Parameters:

- HANDLE: specifies the RTC handle.
- INTERRUPT: specifies the RTC Alarm interrupt to check. This parameter can be:
 - RTC_IT_ALRA: Alarm A interrupt
 - RTC_IT_ALRB: Alarm B interrupt

Return value:

- None

_HAL_RTC_ALARM_GET_FLAG**Description:**

- Get the selected RTC Alarm's flag status.

Parameters:

- HANDLE: specifies the RTC handle.
- FLAG: specifies the RTC Alarm Flag to check.

This parameter can be:

- RTC_FLAG_ALRAF
- RTC_FLAG_ALRBF
- RTC_FLAG_ALRAW
- F
- RTC_FLAG_ALRBW
- F

Return value:

- None

_HAL_RTC_ALARM_CLEAR_FLAG

- Clear the RTC Alarm's pending flags.

Parameters:

- HANDLE: specifies the RTC handle.
- FLAG: specifies the RTC Alarm Flag sources to be enabled or disabled.
This parameter can be:
 - RTC_FLAG_ALRAF
 - RTC_FLAG_ALRBF

Return value:

- None

_HAL_RTC_ALARM_GET_IT_SOURCE

- Check whether the specified RTC Alarm interrupt has been enabled or not.

Parameters:

- HANDLE: specifies the RTC handle.
- INTERRUPT: specifies the RTC Alarm interrupt sources to check.
This parameter can be:
 - RTC_IT_ALRA: Alarm A interrupt
 - RTC_IT_ALRB: Alarm B interrupt

Return value:

- None

_HAL_RTC_ALARM_EXTI_ENABLE_IT

- Enable interrupt on the RTC Alarm associated Exti line.

Return value:

- None

Description:

- Disable interrupt on the RTC Alarm associated Exti line.

Return value:

- None

Description:

- Enable event on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Disable event on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Enable falling edge trigger on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Disable falling edge trigger on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Enable rising edge trigger on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Disable rising edge trigger on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Enable rising & falling edge trigger on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Disable rising & falling edge trigger on the RTC Alarm associated Exti line.

Return value:

- None.

Description:

- Check whether the RTC Alarm associated Exti line interrupt flag is set or not.

Return value:

- Line: Status.

Description:

- Clear the RTC Alarm associated Exti line flag.

Return value:

- None.

Description:

- Generate a Software interrupt on RTC Alarm associated Exti line.

Return value:

- None.

`__HAL_RTC_ALARM_EXTI_ENABLE_RISING_FALLING_EDGE`

`__HAL_RTC_ALARM_EXTI_DISABLE_RISING_FALLING_EDGE`

`__HAL_RTC_ALARM_EXTI_GET_FLAG`

`__HAL_RTC_ALARM_EXTI_CLEAR_FLAG`

`__HAL_RTC_ALARM_EXTI_GENERATE_SWIT`

RTC Flags Definitions

RTC_FLAG_RECALPF
 RTC_FLAG_TAMP2F
 RTC_FLAG_TAMP1F
 RTC_FLAG_TSOVF
 RTC_FLAG_TSF
 RTC_FLAG_WUTF
 RTC_FLAG_ALRBF

RTC_FLAG_ALRAF
RTC_FLAG_INITF
RTC_FLAG_RSF
RTC_FLAG_INITS
RTC_FLAG_SHPF
RTC_FLAG_WUTWF
RTC_FLAG_ALRBWF
RTC_FLAG_ALRAWF
RTC Hour Formats
RTC_HOURFORMAT_24
RTC_HOURFORMAT_12
RTC Input Parameter Format Definitions
RTC_FORMAT_BIN
RTC_FORMAT_BCD
RTC Interrupts Definitions
RTC_IT_TS
RTC_IT_WUT
RTC_IT_ALRB
RTC_IT_ALRA
RTC_IT_TAMP
RTC_IT_TAMP1
RTC_IT_TAMP2
RTC Private macros to check input parameters
IS_RTC_HOUR_FORMAT
IS_RTC_OUTPUT
IS_RTC_OUTPUT_POL
IS_RTC_OUTPUT_TYPE
IS_RTC_HOUR12
IS_RTC_HOUR24
IS_RTC_ASYNCH_PREDIV
IS_RTC_SYNCH_PREDIV
IS_RTC_MINUTES
IS_RTC_SECONDS
IS_RTC_HOURFORMAT12
IS_RTC_DAYLIGHT_SAVING
IS_RTC_STORE_OPERATION

IS_RTC_FORMAT
IS_RTC_YEAR
IS_RTC_MONTH
IS_RTC_DATE
IS_RTC_WEEKDAY
IS_RTC_ALARM_DATE_WEEKDAY_DATE
IS_RTC_ALARM_DATE_WEEKDAY_WEEKDAY
IS_RTC_ALARM_DATE_WEEKDAY_SEL
IS_RTC_ALARM_MASK
IS_RTC_ALARM
IS_RTC_ALARM_SUB_SECOND_VALUE
IS_RTC_ALARM_SUB_SECOND_MASK

RTC Month Date Definitions

RTC_MONTH_JANUARY
RTC_MONTH_FEBRUARY
RTC_MONTH_MARCH
RTC_MONTH_APRIIL
RTC_MONTH_MAY
RTC_MONTH_JUNE
RTC_MONTH_JULY
RTC_MONTH_AUGUST
RTC_MONTH_SEPTMBER
RTC_MONTH_OCTOBER
RTC_MONTH_NOVEMBER
RTC_MONTH_DECEMBER

RTC Output Polarity Definitions

RTC_OUTPUT_POLARITY_HIGH
RTC_OUTPUT_POLARITY_LOW

RTC Output Selection Definitions

RTC_OUTPUT_DISABLE
RTC_OUTPUT_ALARMA
RTC_OUTPUT_ALARMGB
RTC_OUTPUT_WAKEUP

RTC Output Type ALARM OUT

RTC_OUTPUT_TYPE_OPENDRAIN
RTC_OUTPUT_TYPE_PUSH_PULL

RTC Private Constants

RTC_TR_RESERVED_MASK
RTC_DR_RESERVED_MASK
RTC_INIT_MASK
RTC_RSF_MASK
RTC_FLAGS_MASK
RTC_TIMEOUT_VALUE
RTC EXTI LINE ALARM EVENT External interrupt line 17 Connected to the RTC Alarm event

RTC Store Operation Definitions

RTC_STOREOPERATION_RESET
RTC_STOREOPERATION_SET

RTC WeekDay Definitions

RTC_WEEKDAY_MONDAY
RTC_WEEKDAY_TUESDAY
RTC_WEEKDAY_WEDNESDAY
RTC_WEEKDAY_THURSDAY
RTC_WEEKDAY_FRIDAY
RTC_WEEKDAY_SATURDAY
RTC_WEEKDAY_SUNDAY

52 HAL RTC Extension Driver

52.1 HAL RTC Extension Driver

52.2 RTCEEx Firmware driver registers structures

52.2.1 RTC_TamperTypeDef

Data Fields

- *uint32_t Tamper*
- *uint32_t PinSelection*
- *uint32_t Trigger*
- *uint32_t Filter*
- *uint32_t SamplingFrequency*
- *uint32_t PrechargeDuration*
- *uint32_t TamperPullUp*
- *uint32_t TimeStampOnTamperDetection*

Field Documentation

- *uint32_t RTC_TamperTypeDef::Tamper*
Specifies the Tamper Pin. This parameter can be a value of
[*RTCEEx_Tamper_Pins_Definitions*](#)
- *uint32_t RTC_TamperTypeDef::PinSelection*
Specifies the Tamper Pin. This parameter can be a value of
[*RTCEEx_Tamper_Pins_Selection*](#)
- *uint32_t RTC_TamperTypeDef::Trigger*
Specifies the Tamper Trigger. This parameter can be a value of
[*RTCEEx_Tamper_Trigger_Definitions*](#)
- *uint32_t RTC_TamperTypeDef::Filter*
Specifies the RTC Filter Tamper. This parameter can be a value of
[*RTCEEx_Tamper_Filter_Definitions*](#)
- *uint32_t RTC_TamperTypeDef::SamplingFrequency*
Specifies the sampling frequency. This parameter can be a value of
[*RTCEEx_Tamper_Sampling_Frequencies_Definitions*](#)
- *uint32_t RTC_TamperTypeDef::PrechargeDuration*
Specifies the Precharge Duration . This parameter can be a value of
[*RTCEEx_Tamper_Pin_Precharge_Duration_Definitions*](#)
- *uint32_t RTC_TamperTypeDef::TamperPullUp*
Specifies the Tamper PullUp . This parameter can be a value of
[*RTCEEx_Tamper_Pull_UP_Definitions*](#)
- *uint32_t RTC_TamperTypeDef::TimeStampOnTamperDetection*
Specifies the TimeStampOnTamperDetection. This parameter can be a value of
[*RTCEEx_Tamper_TimeStampOnTamperDetection_Definitions*](#)

52.3 RTCEx Firmware driver API description

52.3.1 How to use this driver

- Enable the RTC domain access.
- Configure the RTC Prescaler (Asynchronous and Synchronous) and RTC hour format using the HAL_RTC_Init() function.

RTC Wake-up configuration

- To configure the RTC Wake-up Clock source and Counter use the HAL_RTC_SetWakeUpTimer() function. You can also configure the RTC Wake-up timer in interrupt mode using the HAL_RTC_SetWakeUpTimer_IT() function.
- To read the RTC Wake-up Counter register, use the HAL_RTC_GetWakeUpTimer() function.

TimeStamp configuration

- Configure the RTC_AFx trigger and enable the RTC TimeStamp using the HAL_RTC_SetTimeStamp() function. You can also configure the RTC TimeStamp with interrupt mode using the HAL_RTC_SetTimeStamp_IT() function.
- To read the RTC TimeStamp Time and Date register, use the HAL_RTC_GetTimeStamp() function.
- The TIMESTAMP alternate function can be mapped either to RTC_AF1 (PC13) or RTC_AF2 (PI8 or PA0 only for STM32F446xx devices) depending on the value of TSINSEL bit in RTC_TAFCR register. The corresponding pin is also selected by HAL_RTC_SetTimeStamp() or HAL_RTC_SetTimeStamp_IT() function.

Tamper configuration

- Enable the RTC Tamper and configure the Tamper filter count, trigger Edge or Level according to the Tamper filter (if equal to 0 Edge else Level) value, sampling frequency, precharge or discharge and Pull-UP using the HAL_RTC_SetTamper() function. You can configure RTC Tamper in interrupt mode using HAL_RTC_SetTamper_IT() function.
- The TAMPER1 alternate function can be mapped either to RTC_AF1 (PC13) or RTC_AF2 (PI8 or PA0 only for STM32F446xx devices) depending on the value of TAMP1INSEL bit in RTC_TAFCR register. The corresponding pin is also selected by HAL_RTC_SetTamper() or HAL_RTC_SetTamper_IT() function.

Backup Data Registers configuration

- To write to the RTC Backup Data registers, use the HAL_RTC_BKUPWrite() function.
- To read the RTC Backup Data registers, use the HAL_RTC_BKUPRead() function.

52.3.2 RTC TimeStamp and Tamper functions

This section provides functions allowing to configure TimeStamp feature

This section contains the following APIs:

- [`HAL_RTCEx_SetTimeStamp\(\)`](#)
- [`HAL_RTCEx_SetTimeStamp_IT\(\)`](#)
- [`HAL_RTCEx_DeactivateTimeStamp\(\)`](#)
- [`HAL_RTCEx_GetTimeStamp\(\)`](#)
- [`HAL_RTCEx_SetTamper\(\)`](#)
- [`HAL_RTCEx_SetTamper_IT\(\)`](#)
- [`HAL_RTCEx_DeactivateTamper\(\)`](#)
- [`HAL_RTCEx_TamperTimeStampIRQHandler\(\)`](#)
- [`HAL_RTCEx_TimeStampEventCallback\(\)`](#)
- [`HAL_RTCEx_Tamper1EventCallback\(\)`](#)
- [`HAL_RTCEx_Tamper2EventCallback\(\)`](#)
- [`HAL_RTCEx_PollForTimeStampEvent\(\)`](#)
- [`HAL_RTCEx_PollForTamper1Event\(\)`](#)
- [`HAL_RTCEx_PollForTamper2Event\(\)`](#)

52.3.3 RTC Wake-up functions

This section provides functions allowing to configure Wake-up feature

This section contains the following APIs:

- [`HAL_RTCEx_SetWakeUpTimer\(\)`](#)
- [`HAL_RTCEx_SetWakeUpTimer_IT\(\)`](#)
- [`HAL_RTCEx_DeactivateWakeUpTimer\(\)`](#)
- [`HAL_RTCEx_GetWakeUpTimer\(\)`](#)
- [`HAL_RTCEx_WakeUpTimerIRQHandler\(\)`](#)
- [`HAL_RTCEx_WakeUpTimerEventCallback\(\)`](#)
- [`HAL_RTCEx_PollForWakeUpTimerEvent\(\)`](#)

52.3.4 Extension Peripheral Control functions

This subsection provides functions allowing to

- Write a data in a specified RTC Backup data register
- Read a data in a specified RTC Backup data register
- Set the Coarse calibration parameters.
- Deactivate the Coarse calibration parameters
- Set the Smooth calibration parameters.
- Configure the Synchronization Shift Control Settings.
- Configure the Calibration Pinout (RTC_CALIB) Selection (1Hz or 512Hz).
- Deactivate the Calibration Pinout (RTC_CALIB) Selection (1Hz or 512Hz).
- Enable the RTC reference clock detection.
- Disable the RTC reference clock detection.
- Enable the Bypass Shadow feature.
- Disable the Bypass Shadow feature.

This section contains the following APIs:

- [`HAL_RTCEx_BKUPWrite\(\)`](#)
- [`HAL_RTCEx_BKUPRead\(\)`](#)
- [`HAL_RTCEx_SetCoarseCalib\(\)`](#)
- [`HAL_RTCEx_DeactivateCoarseCalib\(\)`](#)
- [`HAL_RTCEx_SetSmoothCalib\(\)`](#)
- [`HAL_RTCEx_SetSynchroShift\(\)`](#)
- [`HAL_RTCEx_SetCalibrationOutPut\(\)`](#)
- [`HAL_RTCEx_DeactivateCalibrationOutPut\(\)`](#)

- [*HAL_RTCEx_SetRefClock\(\)*](#)
- [*HAL_RTCEx_DeactivateRefClock\(\)*](#)
- [*HAL_RTCEx_EnableBypassShadow\(\)*](#)
- [*HAL_RTCEx_DisableBypassShadow\(\)*](#)

52.3.5 Extended features functions

This section provides functions allowing to:

- RTC Alarm B callback
- RTC Poll for Alarm B request

This section contains the following APIs:

- [*HAL_RTCEx_AlarmBEventCallback\(\)*](#)
- [*HAL_RTCEx_PollForAlarmBEvent\(\)*](#)

52.3.6 HAL_RTCEx_SetTimeStamp

Function Name	<code>HAL_StatusTypeDef HAL_RTCEx_SetTimeStamp (RTC_HandleTypeDef * hrtc, uint32_t TimeStampEdge, uint32_t RTC_TimeStampPin)</code>
Function Description	Sets TimeStamp.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • TimeStampEdge: Specifies the pin edge on which the TimeStamp is activated. This parameter can be one of the following values: RTC_TIMESTAMPEDGE_RISING: the Time stamp event occurs on the rising edge of the related pin.RTC_TIMESTAMPEDGE_FALLING: the Time stamp event occurs on the falling edge of the related pin. • RTC_TimeStampPin: specifies the RTC TimeStamp Pin. This parameter can be one of the following values: RTC_TIMESTAMPPIN_DEFAULT: PC13 is selected as RTC TimeStamp Pin.RTC_TIMESTAMPPIN_POS1: PI8/PA0 is selected as RTC TimeStamp Pin. (PI8 for all STM32 devices except for STM32F446xx devices the PA0 is used)RTC_TIMESTAMPPIN_PA0: PA0 is selected as RTC TimeStamp Pin only for STM32F446xx devices
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This API must be called before enabling the TimeStamp feature.

52.3.7 HAL_RTCEx_SetTimeStamp_IT

Function Name	<code>HAL_StatusTypeDef HAL_RTCEx_SetTimeStamp_IT (RTC_HandleTypeDef * hrtc, uint32_t TimeStampEdge, uint32_t RTC_TimeStampPin)</code>
Function Description	Sets TimeStamp with Interrupt.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • TimeStampEdge: Specifies the pin edge on which the TimeStamp is activated. This parameter can be one of the following values: RTC_TIMESTAMPEDGE_RISING: the Time

	stamp event occurs on the rising edge of the related pin.RTC_TIMESTAMPEDGE_FALLING: the Time stamp event occurs on the falling edge of the related pin.
	<ul style="list-style-type: none"> • RTC_TimeStampPin: Specifies the RTCTimeStamp Pin. This parameter can be one of the following values: RTC_TIMESTAMPPIN_DEFAULT: PC13 is selected as RTCTimeStamp Pin.RTC_TIMESTAMPPIN_PI8: PI8 is selected as RTCTimeStamp Pin. (not applicable in the case of STM32F446xx devices)RTC_TIMESTAMPPIN_PA0: PA0 is selected as RTCTimeStamp Pin only for STM32F446xx devices
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This API must be called before enabling theTimeStamp feature.

52.3.8 HAL_RTCEx_DeactivateTimeStamp

Function Name	HAL_StatusTypeDef HAL_RTCEx_DeactivateTimeStamp (RTC_HandleTypeDef * hrtc)
Function Description	DeactivatesTimeStamp.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status

52.3.9 HAL_RTCEx_GetTimeStamp

Function Name	HAL_StatusTypeDef HAL_RTCEx_GetTimeStamp (RTC_HandleTypeDef * hrtc, RTC_TimeTypeDef * sTimeStamp, RTC_DateTypeDef * sTimeStampDate, uint32_t Format)
Function Description	Gets the RTCTimeStamp value.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sTimeStamp: Pointer to Time structure • sTimeStampDate: Pointer to Date structure • Format: specifies the format of the entered parameters. This parameter can be one of the following values: RTC_FORMAT_BIN: Binary data format RTC_FORMAT_BCD: BCD data format
Return values	<ul style="list-style-type: none"> • HAL status

52.3.10 HAL_RTCEx_SetTamper

Function Name	HAL_StatusTypeDef HAL_RTCEx_SetTamper (RTC_HandleTypeDef * hrtc, RTC_TamperTypeDef * sTamper)
Function Description	Sets Tamper.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sTamper: Pointer to Tamper Structure.

Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • By calling this API we disable the tamper interrupt for all tampers.

52.3.11 HAL_RTCEx_SetTamper_IT

Function Name	HAL_StatusTypeDef HAL_RTCEx_SetTamper_IT (RTC_HandleTypeDef * hrtc, RTC_TamperTypeDef * sTamper)
Function Description	Sets Tamper with interrupt.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • sTamper: Pointer to RTC Tamper.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • By calling this API we force the tamper interrupt for all tampers.

52.3.12 HAL_RTCEx_DeactivateTamper

Function Name	HAL_StatusTypeDef HAL_RTCEx_DeactivateTamper (RTC_HandleTypeDef * hrtc, uint32_t Tamper)
Function Description	Deactivates Tamper.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • Tamper: Selected tamper pin. This parameter can be RTC_Tamper_1 and/or RTC_TAMPER_2.
Return values	<ul style="list-style-type: none"> • HAL status

52.3.13 HAL_RTCEx_TamperTimeStampIRQHandler

Function Name	void HAL_RTCEx_TamperTimeStampIRQHandler (RTC_HandleTypeDef * hrtc)
Function Description	This function handles TimeStamp interrupt request.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

52.3.14 HAL_RTCEx_TimeStampEventCallback

Function Name	void HAL_RTCEx_TimeStampEventCallback (RTC_HandleTypeDef * hrtc)
Function Description	TimeStamp callback.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

52.3.15 HAL_RTCEx_Tamper1EventCallback

Function Name	void HAL_RTCEx_Tamper1EventCallback (RTC_HandleTypeDef * hrtc)
Function Description	Tamper 1 callback.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

52.3.16 HAL_RTCEx_Tamper2EventCallback

Function Name	void HAL_RTCEx_Tamper2EventCallback (RTC_HandleTypeDef * hrtc)
Function Description	Tamper 2 callback.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

52.3.17 HAL_RTCEx_PollForTimeStampEvent

Function Name	HAL_StatusTypeDef HAL_RTCEx_PollForTimeStampEvent (RTC_HandleTypeDef * hrtc, uint32_t Timeout)
Function Description	This function handles TimeStamp polling request.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

52.3.18 HAL_RTCEx_PollForTamper1Event

Function Name	HAL_StatusTypeDef HAL_RTCEx_PollForTamper1Event (RTC_HandleTypeDef * hrtc, uint32_t Timeout)
Function Description	This function handles Tamper1 Polling.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

52.3.19 HAL_RTCEx_PollForTamper2Event

Function Name	HAL_StatusTypeDef HAL_RTCEx_PollForTamper2Event (RTC_HandleTypeDef * hrtc, uint32_t Timeout)
Function Description	This function handles Tamper2 Polling.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

52.3.20 HAL_RTCEx_SetWakeUpTimer

Function Name	<code>HAL_StatusTypeDef HAL_RTCEx_SetWakeUpTimer (RTC_HandleTypeDef * hrtc, uint32_t WakeUpCounter, uint32_t WakeUpClock)</code>
Function Description	Sets wake up timer.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • WakeUpCounter: Wake up counter • WakeUpClock: Wake up clock
Return values	<ul style="list-style-type: none"> • HAL status

52.3.21 HAL_RTCEx_SetWakeUpTimer_IT

Function Name	<code>HAL_StatusTypeDef HAL_RTCEx_SetWakeUpTimer_IT (RTC_HandleTypeDef * hrtc, uint32_t WakeUpCounter, uint32_t WakeUpClock)</code>
Function Description	Sets wake up timer with interrupt.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • WakeUpCounter: Wake up counter • WakeUpClock: Wake up clock
Return values	<ul style="list-style-type: none"> • HAL status

52.3.22 HAL_RTCEx_DeactivateWakeUpTimer

Function Name	<code>uint32_t HAL_RTCEx_DeactivateWakeUpTimer (RTC_HandleTypeDef * hrtc)</code>
Function Description	Deactivates wake up timer counter.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status

52.3.23 HAL_RTCEx_GetWakeUpTimer

Function Name	<code>uint32_t HAL_RTCEx_GetWakeUpTimer (RTC_HandleTypeDef * hrtc)</code>
Function Description	Gets wake up timer counter.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • Counter value

52.3.24 HAL_RTCEx_WakeUpTimerIRQHandler

Function Name	<code>void HAL_RTCEx_WakeUpTimerIRQHandler (RTC_HandleTypeDef * hrtc)</code>
Function Description	This function handles Wake Up Timer interrupt request.

Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

52.3.25 HAL_RTCEx_WakeUpTimerEventCallback

Function Name	void HAL_RTCEx_WakeUpTimerEventCallback (RTC_HandleTypeDef * hrtc)
Function Description	Wake Up Timer callback.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • None

52.3.26 HAL_RTCEx_PollForWakeUpTimerEvent

Function Name	HAL_StatusTypeDef HAL_RTCEx_PollForWakeUpTimerEvent (RTC_HandleTypeDef * hrtc, uint32_t Timeout)
Function Description	This function handles Wake Up Timer Polling.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

52.3.27 HAL_RTCEx_BKUPWrite

Function Name	void HAL_RTCEx_BKUPWrite (RTC_HandleTypeDef * hrtc, uint32_t BackupRegister, uint32_t Data)
Function Description	Writes a data in a specified RTC Backup data register.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • BackupRegister: RTC Backup data Register number. This parameter can be: RTC_BKP_DRx where x can be from 0 to 19 to specify the register. • Data: Data to be written in the specified RTC Backup data register.
Return values	<ul style="list-style-type: none"> • None

52.3.28 HAL_RTCEx_BKUPRead

Function Name	uint32_t HAL_RTCEx_BKUPRead (RTC_HandleTypeDef * hrtc, uint32_t BackupRegister)
Function Description	Reads data from the specified RTC Backup data Register.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • BackupRegister: RTC Backup data Register number. This parameter can be: RTC_BKP_DRx where x can be from 0 to 19 to specify the register.

Return values	<ul style="list-style-type: none"> • Read value
52.3.29 HAL_RTCEx_SetCoarseCalib	
Function Name	HAL_StatusTypeDef HAL_RTCEx_SetCoarseCalib (RTC_HandleTypeDef * hrtc, uint32_t CalibSign, uint32_t Value)
Function Description	Sets the Coarse calibration parameters.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • CalibSign: Specifies the sign of the coarse calibration value. This parameter can be one of the following values : RTC_CALIBSIGN_POSITIVE: The value sign is positive RTC_CALIBSIGN_NEGATIVE: The value sign is negative • Value: value of coarse calibration expressed in ppm (coded on 5 bits).
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This Calibration value should be between 0 and 63 when using negative sign with a 2-ppm step. • This Calibration value should be between 0 and 126 when using positive sign with a 4-ppm step.
52.3.30 HAL_RTCEx_DeactivateCoarseCalib	
Function Name	HAL_StatusTypeDef HAL_RTCEx_DeactivateCoarseCalib (RTC_HandleTypeDef * hrtc)
Function Description	Deactivates the Coarse calibration parameters.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status
52.3.31 HAL_RTCEx_SetSmoothCalib	
Function Name	HAL_StatusTypeDef HAL_RTCEx_SetSmoothCalib (RTC_HandleTypeDef * hrtc, uint32_t SmoothCalibPeriod, uint32_t SmoothCalibPlusPulses, uint32_t SmoothCalibMinusPulsesValue)
Function Description	Sets the Smooth calibration parameters.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • SmoothCalibPeriod: Select the Smooth Calibration Period. This parameter can be one of the following values : RTC_SMOOTHCALIB_PERIOD_32SEC: The smooth calibration period is 32s. RTC_SMOOTHCALIB_PERIOD_16SEC: The smooth calibration period is 16s. RTC_SMOOTHCALIB_PERIOD_8SEC: The smooth calibration period is 8s. • SmoothCalibPlusPulses: Select to Set or reset the CALP

bit. This parameter can be one of the following values:
RTC_SMOOTHCALIB_PLUSPULSES_SET: Add one RTCCLK pulse every 2^{11} pulses.
RTC_SMOOTHCALIB_PLUSPULSES_RESET: No RTCCLK pulses are added.

- **SmoothCalibMinusPulsesValue**: Select the value of CALM[8:0] bits. This parameter can be one any value from 0 to 0x000001FF.
- | | |
|---------------|---|
| Return values | • HAL status |
| Notes | • To deactivate the smooth calibration, the field SmoothCalibPlusPulses must be equal to SMOOTHCALIB_PLUSPULSES_RESET and the field SmoothCalibMinusPulsesValue must be equal to 0. |

52.3.32 HAL_RTCEx_SetSynchroShift

Function Name	HAL_StatusTypeDef HAL_RTCEx_SetSynchroShift (RTC_HandleTypeDef * hrtc, uint32_t ShiftAdd1S, uint32_t ShiftSubFS)
Function Description	Configures the Synchronization Shift Control Settings.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • ShiftAdd1S: Select to add or not 1 second to the time calendar. This parameter can be one of the following values : RTC_SHIFTADD1S_SET: Add one second to the clock calendar.RTC_SHIFTADD1S_RESET: No effect. • ShiftSubFS: Select the number of Second Fractions to substitute. This parameter can be one any value from 0 to 0x7FFF.
Return values	• HAL status
Notes	• When REFCKON is set, firmware must not write to Shift control register.

52.3.33 HAL_RTCEx_SetCalibrationOutPut

Function Name	HAL_StatusTypeDef HAL_RTCEx_SetCalibrationOutPut (RTC_HandleTypeDef * hrtc, uint32_t CalibOutput)
Function Description	Configures the Calibration Pinout (RTC_CALIB) Selection (1Hz or 512Hz).
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. • CalibOutput: Select the Calibration output Selection . This parameter can be one of the following values: RTC_CALIBOUTPUT_512HZ: A signal has a regular waveform at 512Hz. RTC_CALIBOUTPUT_1HZ: A signal has a regular waveform at 1Hz.
Return values	• HAL status

52.3.34 HAL_RTCEx_DeactivateCalibrationOutPut

Function Name	HAL_StatusTypeDef HAL_RTCEx_DeactivateCalibrationOutPut(RTC_HandleTypeDef * hrtc)
Function Description	Deactivates the Calibration Pinout (RTC_CALIB) Selection (1Hz or 512Hz).
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status

52.3.35 HAL_RTCEx_SetRefClock

Function Name	HAL_StatusTypeDef HAL_RTCEx_SetRefClock(RTC_HandleTypeDef * hrtc)
Function Description	Enables the RTC reference clock detection.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status

52.3.36 HAL_RTCEx_DeactivateRefClock

Function Name	HAL_StatusTypeDef HAL_RTCEx_DeactivateRefClock(RTC_HandleTypeDef * hrtc)
Function Description	Disable the RTC reference clock detection.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status

52.3.37 HAL_RTCEx_EnableBypassShadow

Function Name	HAL_StatusTypeDef HAL_RTCEx_EnableBypassShadow(RTC_HandleTypeDef * hrtc)
Function Description	Enables the Bypass Shadow feature.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When the Bypass Shadow is enabled the calendar value are taken directly from the Calendar counter.

52.3.38 HAL_RTCEx_DisableBypassShadow

Function Name	HAL_StatusTypeDef HAL_RTCEx_DisableBypassShadow(RTC_HandleTypeDef * hrtc)
Function Description	Disables the Bypass Shadow feature.
Parameters	<ul style="list-style-type: none"> • hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> • HAL status

Notes	<ul style="list-style-type: none"> When the Bypass Shadow is enabled the calendar value are taken directly from the Calendar counter.
-------	--

52.3.39 HAL_RTCEx_AlarmBEventCallback

Function Name	void HAL_RTCEx_AlarmBEventCallback (RTC_HandleTypeDef * hrtc)
Function Description	Alarm B callback.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC.
Return values	<ul style="list-style-type: none"> None

52.3.40 HAL_RTCEx_PollForAlarmBEvent

Function Name	HAL_StatusTypeDef HAL_RTCEx_PollForAlarmBEvent (RTC_HandleTypeDef * hrtc, uint32_t Timeout)
Function Description	This function handles AlarmB Polling request.
Parameters	<ul style="list-style-type: none"> hrtc: pointer to a RTC_HandleTypeDef structure that contains the configuration information for RTC. Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

52.4 RTCEx Firmware driver defines

52.4.1 RTCEx

RTC Add 1 Second Parameter Definitions

RTC_SHIFTADD1S_RESET

RTC_SHIFTADD1S_SET

RTC Backup Registers Definitions

RTC_BKP_DR0

RTC_BKP_DR1

RTC_BKP_DR2

RTC_BKP_DR3

RTC_BKP_DR4

RTC_BKP_DR5

RTC_BKP_DR6

RTC_BKP_DR7

RTC_BKP_DR8

RTC_BKP_DR9

RTC_BKP_DR10

RTC_BKP_DR11

RTC_BKP_DR12
RTC_BKP_DR13
RTC_BKP_DR14
RTC_BKP_DR15
RTC_BKP_DR16
RTC_BKP_DR17
RTC_BKP_DR18
RTC_BKP_DR19

RTC Calibration

`__HAL_RTC_COARSE_CALIB_ENABLE`

Description:

- Enable the Coarse calibration process.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_COARSE_CALIB_DISABLE`

Description:

- Disable the Coarse calibration process.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_CALIBRATION_OUTPUT_ENABLE`

Description:

- Enable the RTC calibration output.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_CALIBRATION_OUTPUT_DISABLE`

Description:

- Disable the calibration output.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_CLOCKREF_DETECTION_ENABLE`**Description:**

- Enable the clock reference detection.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_CLOCKREF_DETECTION_DISABLE`**Description:**

- Disable the clock reference detection.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_SHIFT_GET_FLAG`**Description:**

- Get the selected RTC shift operation's flag status.

Parameters:

- `__HANDLE__`: specifies the RTC handle.
- `__FLAG__`: specifies the RTC shift operation Flag is pending or not. This parameter can be:
 - `RTC_FLAG_SHPF`

Return value:

- None

RTC Calib Output Selection Definitions`RTC_CALIBOUTPUT_512HZ``RTC_CALIBOUTPUT_1HZ`***RTC Digital Calib Definitions***`RTC_CALIBSIGN_POSITIVE``RTC_CALIBSIGN_NEGATIVE`***Private macros to check input parameters***`IS_RTC_BKP``IS_TIMESTAMP_EDGE`

IS_RTC_TAMPER
 IS_RTC_TAMPER_PIN
 IS_RTC_TIMESTAMP_PIN
 IS_RTC_TAMPER_TRIGGER
 IS_RTC_TAMPER_FILTER
 IS_RTC_TAMPER_SAMPLING_FREQ
 IS_RTC_TAMPER_PRECHARGE_DURATION
 IS_RTC_TAMPER_TIMESTAMPON TAMPER_DETECTION
 IS_RTC_TAMPER_PULLUP_STATE
 IS_RTC_WAKEUP_CLOCK
 IS_RTC_WAKEUP_COUNTER
 IS_RTC_CALIB_SIGN
 IS_RTC_CALIB_VALUE
 IS_RTC_SMOOTH_CALIB_PERIOD
 IS_RTC_SMOOTH_CALIB_PLUS
 IS_RTC_SMOOTH_CALIB_MINUS
 IS_RTC_SHIFT_ADD1S
 IS_RTC_SHIFT_SUBFS
 IS_RTC_CALIB_OUTPUT

RTCEx Private Constants

RTC EXTI_LINE_TAMPER_TIMESTAMP_EVENT	External interrupt line 21 Connected to the RTC Tamper and Time Stamp events
RTC EXTI_LINE_WAKEUPTIMER_EVENT	External interrupt line 22 Connected to the RTC Wake-up event

RTC Smooth Calib Period Definitions

RTC_SMOOTHCALIB_PERIOD_32SEC	If RTCCLK = 32768 Hz, Smooth calibration period is 32s, else $2^{\text{exp}20}$ RTCCLK seconds
RTC_SMOOTHCALIB_PERIOD_16SEC	If RTCCLK = 32768 Hz, Smooth calibration period is 16s, else $2^{\text{exp}19}$ RTCCLK seconds
RTC_SMOOTHCALIB_PERIOD_8SEC	If RTCCLK = 32768 Hz, Smooth calibration period is 8s, else $2^{\text{exp}18}$ RTCCLK seconds

RTC Smooth Calib Plus Pulses Definitions

RTC_SMOOTHCALIB_PLUSPULSES_SET	The number of RTCCLK pulses added during a X -second window = Y - CALM[8:0] with Y = 512, 256, 128 when X = 32, 16, 8
RTC_SMOOTHCALIB_PLUSPULSES_RESET	The number of RTCCLK pulses substituted during a 32-second window = CALM[8:0]

RTC Tamper`__HAL_RTC_TAMPER1_ENABLE`**Description:**

- Enable the RTC Tamper1 input detection.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_TAMPER1_DISABLE`**Description:**

- Disable the RTC Tamper1 input detection.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_TAMPER2_ENABLE`**Description:**

- Enable the RTC Tamper2 input detection.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_TAMPER2_DISABLE`**Description:**

- Disable the RTC Tamper2 input detection.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_TAMPER_GET_IT`**Description:**

- Check whether the specified RTC Tamper interrupt has occurred or not.

Parameters:

- `__HANDLE__`: specifies the RTC handle.
- `__INTERRUPT__`: specifies the RTC

Tamper interrupt to check. This parameter can be:

- RTC_IT_TAMP1
- RTC_IT_TAMP2

Return value:

- None

[__HAL_RTC_TAMPER_GET_IT_SOURCE](#)

Description:

- Check whether the specified RTC Tamper interrupt has been enabled or not.

Parameters:

- [__HANDLE__](#): specifies the RTC handle.
- [__INTERRUPT__](#): specifies the RTC Tamper interrupt source to check. This parameter can be:
 - RTC_IT_TAMP: Tamper interrupt

Return value:

- None

[__HAL_RTC_TAMPER_GET_FLAG](#)

Description:

- Get the selected RTC Tamper's flag status.

Parameters:

- [__HANDLE__](#): specifies the RTC handle.
- [__FLAG__](#): specifies the RTC Tamper Flag sources to be enabled or disabled. This parameter can be:
 - RTC_FLAG_TAMP1F
 - RTC_FLAG_TAMP2F

Return value:

- None

[__HAL_RTC_TAMPER_CLEAR_FLAG](#)

Description:

- Clear the RTC Tamper's pending flags.

Parameters:

- [__HANDLE__](#): specifies the RTC handle.
- [__FLAG__](#): specifies the RTC Tamper Flag to clear. This parameter can be:
 - RTC_FLAG_TAMP1F
 - RTC_FLAG_TAMP2F

Return value:

- None

RTC Tamper Filter Definitions

RTC_TAMPERFILTER_DISABLE	Tamper filter is disabled
RTC_TAMPERFILTER_2SAMPLE	Tamper is activated after 2 consecutive samples at the active level
RTC_TAMPERFILTER_4SAMPLE	Tamper is activated after 4 consecutive samples at the active level
RTC_TAMPERFILTER_8SAMPLE	Tamper is activated after 8 consecutive samples at the active level.

RTC Tamper Pins Definitions

RTC_TAMPER_1
RTC_TAMPER_2

RTC tamper Pins Selection

RTC_TAMPERPIN_DEFAULT
RTC_TAMPERPIN_POS1

RTC Tamper Pin Precharge Duration Definitions

RTC_TAMPERPRECHARGEDURATION_1RTCCLK	Tamper pins are pre-charged before sampling during 1 RTCCLK cycle
RTC_TAMPERPRECHARGEDURATION_2RTCCLK	Tamper pins are pre-charged before sampling during 2 RTCCLK cycles
RTC_TAMPERPRECHARGEDURATION_4RTCCLK	Tamper pins are pre-charged before sampling during 4 RTCCLK cycles
RTC_TAMPERPRECHARGEDURATION_8RTCCLK	Tamper pins are pre-charged before sampling during 8 RTCCLK cycles

RTC Tamper Pull Up Definitions

RTC_TAMPER_PULLUP_ENABLE	TimeStamp on Tamper Detection event saved
RTC_TAMPER_PULLUP_DISABLE	TimeStamp on Tamper Detection event is not saved

RTC Tamper Sampling Frequencies Definitions

RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV32768	Each of the tamper inputs are sampled with a frequency = RTCCLK / 32768
RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV16384	Each of the tamper inputs are sampled with a frequency = RTCCLK / 16384
RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV8192	Each of the tamper inputs are sampled with a frequency = RTCCLK / 8192
RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV4096	Each of the tamper inputs are sampled with a frequency = RTCCLK / 4096

RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV2048	Each of the tamper inputs are sampled with a frequency = RTCCLK / 2048
RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV1024	Each of the tamper inputs are sampled with a frequency = RTCCLK / 1024
RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV512	Each of the tamper inputs are sampled with a frequency = RTCCLK / 512
RTC_TAMPERSAMPLINGFREQ_RTCCLK_DIV256	Each of the tamper inputs are sampled with a frequency = RTCCLK / 256

EXTI RTC Tamper Timestamp EXTI

<code>_HAL_RTC_TAMPER_TIMESTAMP_EXTI_ENABLE_IT</code>	Description : <ul style="list-style-type: none">Enable interrupt on the RTC Tamper and Timestamp associated Exti line.
<code>_HAL_RTC_TAMPER_TIMESTAMP_EXTI_DISABLE_IT</code>	Description : <ul style="list-style-type: none">Disable interrupt on the RTC Tamper and Timestamp associated Exti line.
<code>_HAL_RTC_TAMPER_TIMESTAMP_EXTI_ENABLE_EVENT</code>	Description : <ul style="list-style-type: none">Enable

event
on the
RTC
Tamper
and
Timesta
mp
associa
ted Exti
line.

**Return
value:**

- None.

`__HAL_RTC_TAMPER_TIMESTAMP_EXTI_DISABLE_EVENT`

Description
:

• Disable
event
on the
RTC
Tamper
and
Timesta
mp
associa
ted Exti
line.

**Return
value:**

- None.

`__HAL_RTC_TAMPER_TIMESTAMP_EXTI_ENABLE_FALLING_EDGE`

Description
:

• Enable
falling
edge
trigger
on the
RTC
Tamper
and
Timesta
mp
associa
ted Exti
line.

**Return
value:**

- None.

`__HAL_RTC_TAMPER_TIMESTAMP_EXTI_DISABLE_FALLING_EDGE`

Description
:

- Disable falling edge trigger on the RTC Tamper and Timestamp associated Exti line.

Return value:

- None.

`__HAL_RTC_TAMPER_TIMESTAMP_EXTI_ENABLE_RISING_EDGE`

Description :

- Enable rising edge trigger on the RTC Tamper and Timestamp associated Exti line.

Return value:

- None.

`__HAL_RTC_TAMPER_TIMESTAMP_EXTI_DISABLE_RISING_EDGE`

Description :

- Disable rising edge trigger on the RTC Tamper and Timestamp associated Exti line.

Return

	value:	
<code>__HAL_RTC_TAMPER_TIMESTAMP_EXTI_ENABLE_RISING_FALLING_EDGE</code>	<ul style="list-style-type: none">• None. <p>Description :</p> <ul style="list-style-type: none">• Enable rising & falling edge trigger on the RTC Tamper and Timestamp associated Exti line.	Return value:
<code>__HAL_RTC_TAMPER_TIMESTAMP_EXTI_DISABLE_RISING_FALLING_EDGE</code>	<ul style="list-style-type: none">• None. <p>Description :</p> <ul style="list-style-type: none">• Disable rising & falling edge trigger on the RTC Tamper and Timestamp associated Exti line.	Return value:
<code>__HAL_RTC_TAMPER_TIMESTAMP_EXTI_GET_FLAG</code>	<ul style="list-style-type: none">• None. <p>Description :</p> <ul style="list-style-type: none">• Check whether the RTC Tamper and Timestamp	

mp
associa
ted Exti
line
interrup
t flag is
set or
not.

**Return
value:**

- Line: Status.

`_HAL_RTC_TAMPER_TIMESTAMP_EXTI_CLEAR_FLAG`

Description

:

- Clear the RTC Tamper and Timesta mp associa ted Exti line flag.

**Return
value:**

- None.

`_HAL_RTC_TAMPER_TIMESTAMP_EXTI_GENERATE_SWIT`

Description

:

- Generat e a Softwar e interrupt on the RTC Tamper and Timesta mp associa ted Exti line.

**Return
value:**

- None.

RTC Tamper TimeStamp On Tamper Detection Definitions

RTC_TIMESTAMPONTAMPERDETECTION_ENABLE	TimeStamp on Tamper Detection event saved
RTC_TIMESTAMPONTAMPERDETECTION_DISABLE	TimeStamp on Tamper Detection event is not saved

RTC Tamper Triggers Definitions

RTC_TAMPERTRIGGER_RISINGEDGE
 RTC_TAMPERTRIGGER_FALLINGEDGE
 RTC_TAMPERTRIGGER_LOWLEVEL
 RTC_TAMPERTRIGGER_HIGHLEVEL

RTC Timestamp_HAL_RTC_TIMESTAMP_ENABLE**Description:**

- Enable the RTC TimeStamp peripheral.

Parameters:

- _HANDLE_: specifies the RTC handle.

Return value:

- None

_HAL_RTC_TIMESTAMP_DISABLE**Description:**

- Disable the RTC TimeStamp peripheral.

Parameters:

- _HANDLE_: specifies the RTC handle.

Return value:

- None

_HAL_RTC_TIMESTAMP_ENABLE_IT**Description:**

- Enable the RTC TimeStamp interrupt.

Parameters:

- _HANDLE_: specifies the RTC handle.
- _INTERRUPT_: specifies the RTC TimeStamp interrupt sources to be enabled or disabled. This parameter can be:
 - RTC_IT_TS: TimeStamp interrupt

Return value:

- None

_HAL_RTC_TIMESTAMP_DISABLE_IT**Description:**

- Disable the RTC TimeStamp interrupt.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC TimeStamp interrupt sources to be enabled or disabled. This parameter can be:
 - RTC_IT_TS: TimeStamp interrupt

Return value:

- None

[__HAL_RTC_TIMESTAMP_GET_IT](#)**Description:**

- Check whether the specified RTC TimeStamp interrupt has occurred or not.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC TimeStamp interrupt to check. This parameter can be:
 - RTC_IT_TS: TimeStamp interrupt

Return value:

- None

[__HAL_RTC_TIMESTAMP_GET_IT_SOURCE](#)**Description:**

- Check whether the specified RTC Time Stamp interrupt has been enabled or not.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC Time Stamp interrupt source to check. This parameter can be:
 - RTC_IT_TS: TimeStamp interrupt

Return value:

- None

[__HAL_RTC_TIMESTAMP_GET_FLAG](#)**Description:**

- Get the selected RTC TimeStamp's flag status.

Parameters:

- `__HANDLE__`: specifies the RTC handle.
- `__FLAG__`: specifies the RTC TimeStamp flag to check. This parameter can be:
 - `RTC_FLAG_TSF`
 - `RTC_FLAG_TSOVF`

Return value:

- None

`__HAL_RTC_TIMESTAMP_CLEAR_FLAG`**Description:**

- Clear the RTC Time Stamp's pending flags.

Parameters:

- `__HANDLE__`: specifies the RTC handle.
- `__FLAG__`: specifies the RTC Alarm Flag sources to be enabled or disabled. This parameter can be:
 - `RTC_FLAG_TSF`

Return value:

- None

RTC TimeStamp Pins Selection`RTC_TIMESTAMPPIN_DEFAULT``RTC_TIMESTAMPPIN_POS1`***RTC TimeStamp Edges Definitions***`RTC_TIMESTAMPEDGE_RISING``RTC_TIMESTAMPEDGE_FALLING`***RTC WakeUp Timer***`__HAL_RTC_WAKEUPTIMER_ENABLE`**Description:**

- Enable the RTC WakeUp Timer peripheral.

Parameters:

- `__HANDLE__`: specifies the RTC handle.

Return value:

- None

`__HAL_RTC_WAKEUPTIMER_DISABLE`**Description:**

- Disable the RTC Wake-up Timer peripheral.

Parameters:

- __HANDLE__: specifies the RTC handle.

Return value:

- None

Description:

- Enable the RTC WakeUpTimer interrupt.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC WakeUpTimer interrupt sources to be enabled or disabled. This parameter can be:
 - RTC_IT_WUT: WakeUpTimer A interrupt

Return value:

- None

Description:

- Disable the RTC WakeUpTimer interrupt.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC WakeUpTimer interrupt sources to be enabled or disabled. This parameter can be:
 - RTC_IT_WUT: WakeUpTimer A interrupt

Return value:

- None

Description:

- Check whether the specified RTC WakeUpTimer interrupt

has occurred or not.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC WakeUpTimer interrupt to check. This parameter can be:
 - RTC_IT_WUT: WakeUpTimer A interrupt

Return value:

- None

Description:

- Check whether the specified RTC Wake Up timer interrupt has been enabled or not.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __INTERRUPT__: specifies the RTC Wake Up timer interrupt sources to check. This parameter can be:
 - RTC_IT_WUT: WakeUpTimer interrupt

Return value:

- None

Description:

- Get the selected RTC WakeUpTimer's flag status.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __FLAG__: specifies the RTC WakeUpTimer Flag to check. This parameter can be:
 - RTC_FLAG_WUT

- F
- RTC_FLAG_WUT
- WF

Return value:

- None

Description:

- Clear the RTC Wake Up timer's pending flags.

Parameters:

- __HANDLE__: specifies the RTC handle.
- __FLAG__: specifies the RTC Tamper Flag sources to be enabled or disabled. This parameter can be:
 - RTC_FLAG_WUT
 - F

Return value:

- None

Description:

- Enable interrupt on the RTC Wake-up Timer associated Exti line.

Return value:

- None

Description:

- Disable interrupt on the RTC Wake-up Timer associated Exti line.

Return value:

- None

Description:

- Enable event on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable event on the RTC Wake-up Timer

associated Exti line.

Return value:

- None.

Description:

- Enable falling edge trigger on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable falling edge trigger on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Enable rising edge trigger on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable rising edge trigger on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Enable rising & falling edge trigger on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

Description:

- Disable rising & falling edge trigger on the RTC Wake-up Timer

associated Exti line.

Return value:

- None.

Description:

- Check whether the RTC Wake-up Timer associated Exti line interrupt flag is set or not.

Return value:

- Line: Status.

Description:

- Clear the RTC Wake-up Timer associated Exti line flag.

Return value:

- None.

Description:

- Generate a Software interrupt on the RTC Wake-up Timer associated Exti line.

Return value:

- None.

`_HAL_RTC_WAKEUPTIMER_EXTI_GET_FLAG``_HAL_RTC_WAKEUPTIMER_EXTI_CLEAR_FLAG``_HAL_RTC_WAKEUPTIMER_EXTI_GENERATE_SWIT`***RTC Wake-up Timer Definitions***

RTC_WAKEUPCLOCK_RTCCLK_DIV16
 RTC_WAKEUPCLOCK_RTCCLK_DIV8
 RTC_WAKEUPCLOCK_RTCCLK_DIV4
 RTC_WAKEUPCLOCK_RTCCLK_DIV2
 RTC_WAKEUPCLOCK_CK_SPRE_16BITS
 RTC_WAKEUPCLOCK_CK_SPRE_17BITS

53 HAL SAI Generic Driver

53.1 HAL SAI Generic Driver

53.2 SAI Firmware driver registers structures

53.2.1 SAI_InitTypeDef

Data Fields

- *uint32_t AudioMode*
- *uint32_t Synchro*
- *uint32_t SynchroExt*
- *uint32_t OutputDrive*
- *uint32_t NoDivider*
- *uint32_t FIFOThreshold*
- *uint32_t ClockSource*
- *uint32_t AudioFrequency*
- *uint32_t Mckdiv*
- *uint32_t MonoStereoMode*
- *uint32_t CompandingMode*
- *uint32_t TriState*
- *uint32_t Protocol*
- *uint32_t DataSize*
- *uint32_t FirstBit*
- *uint32_t ClockStrobing*

Field Documentation

- ***uint32_t SAI_InitTypeDef::AudioMode***
Specifies the SAI Block audio Mode. This parameter can be a value of ***SAI_Block_Mode***
- ***uint32_t SAI_InitTypeDef::Synchro***
Specifies SAI Block synchronization This parameter can be a value of ***SAI_Block_Synchronization***
- ***uint32_t SAI_InitTypeDef::SynchroExt***
Specifies SAI Block synchronization, this setup is common for BLOCKA and BLOCKB
This parameter can be a value of ***SAI_Block_SyncExt***
- ***uint32_t SAI_InitTypeDef::OutputDrive***
Specifies when SAI Block outputs are driven. This parameter can be a value of ***SAI_Block_Output_Drive***
Note:this value has to be set before enabling the audio block but after the audio block configuration.
- ***uint32_t SAI_InitTypeDef::NoDivider***
Specifies whether master clock will be divided or not. This parameter can be a value of ***SAI_Block_NoDivider***
Note:If bit NODIV in the SAI_xCR1 register is cleared, the frame length should be aligned to a number equal to a power of 2, from 8 to 256. If bit NODIV in the SAI_xCR1 register is set, the frame length can take any of the values without

constraint since the input clock of the audio block should be equal to the bit clock.
There is no MCLK_x clock which can be output.

- ***uint32_t SAI_InitTypeDef::FIFOThreshold***
Specifies SAI Block FIFO threshold. This parameter can be a value of ***SAI_Block_Fifo_Threshold***
- ***uint32_t SAI_InitTypeDef::ClockSource***
Specifies the SAI Block x Clock source. This parameter is not used for STM32F446xx devices.
- ***uint32_t SAI_InitTypeDef::AudioFrequency***
Specifies the audio frequency sampling. This parameter can be a value of ***SAI_Audio_Frequency***
- ***uint32_t SAI_InitTypeDef::Mckdiv***
Specifies the master clock divider, the parameter will be used if for AudioFrequency the user choice This parameter must be a number between Min_Data = 0 and Max_Data = 15
- ***uint32_t SAI_InitTypeDef::MonoStereoMode***
Specifies if the mono or stereo mode is selected. This parameter can be a value of ***SAI_Mono_Stereo_Mode***
- ***uint32_t SAI_InitTypeDef::CompandingMode***
Specifies the companding mode type. This parameter can be a value of ***SAI_Block_Companding_Mode***
- ***uint32_t SAI_InitTypeDef::TriState***
Specifies the companding mode type. This parameter can be a value of ***SAI_TRIState_Management***
- ***uint32_t SAI_InitTypeDef::Protocol***
Specifies the SAI Block protocol. This parameter can be a value of ***SAI_Block_Protocol***
- ***uint32_t SAI_InitTypeDef::DataSize***
Specifies the SAI Block data size. This parameter can be a value of ***SAI_Block_Data_Size***
- ***uint32_t SAI_InitTypeDef::FirstBit***
Specifies whether data transfers start from MSB or LSB bit. This parameter can be a value of ***SAI_Block_MSB_LSB_transmission***
- ***uint32_t SAI_InitTypeDef::ClockStrobing***
Specifies the SAI Block clock strobing edge sensitivity. This parameter can be a value of ***SAI_Block_Clock_Strobing***

53.2.2 SAI_FrameInitTypeDef

Data Fields

- ***uint32_t FrameLength***
- ***uint32_t ActiveFrameLength***
- ***uint32_t FSDefinition***
- ***uint32_t FSPolarity***
- ***uint32_t FSOFFset***

Field Documentation

- ***uint32_t SAI_FrameInitTypeDef::FrameLength***
Specifies the Frame length, the number of SCK clocks for each audio frame. This parameter must be a number between Min_Data = 8 and Max_Data = 256.

Note:If master clock MCLK_x pin is declared as an output, the frame length should be aligned to a number equal to power of 2 in order to keep in an audio frame, an integer number of MCLK pulses by bit Clock.

- ***uint32_t SAI_FrameInitTypeDef::ActiveFrameLength***
Specifies the Frame synchronization active level length. This Parameter specifies the length in number of bit clock (SCK + 1) of the active level of FS signal in audio frame. This parameter must be a number between Min_Data = 1 and Max_Data = 128
- ***uint32_t SAI_FrameInitTypeDef::FSDefinition***
Specifies the Frame synchronization definition. This parameter can be a value of [**SAI_Block_FS_Definition**](#)
- ***uint32_t SAI_FrameInitTypeDef::FSPolarity***
Specifies the Frame synchronization Polarity. This parameter can be a value of [**SAI_Block_FS_Polarity**](#)
- ***uint32_t SAI_FrameInitTypeDef::FSOffset***
Specifies the Frame synchronization Offset. This parameter can be a value of [**SAI_Block_FS_Offset**](#)

53.2.3 SAI_SlotInitTypeDef

Data Fields

- ***uint32_t FirstBitOffset***
- ***uint32_t SlotSize***
- ***uint32_t SlotNumber***
- ***uint32_t SlotActive***

Field Documentation

- ***uint32_t SAI_SlotInitTypeDef::FirstBitOffset***
Specifies the position of first data transfer bit in the slot. This parameter must be a number between Min_Data = 0 and Max_Data = 24
- ***uint32_t SAI_SlotInitTypeDef::SlotSize***
Specifies the Slot Size. This parameter can be a value of [**SAI_Block_Slot_Size**](#)
- ***uint32_t SAI_SlotInitTypeDef::SlotNumber***
Specifies the number of slot in the audio frame. This parameter must be a number between Min_Data = 1 and Max_Data = 16
- ***uint32_t SAI_SlotInitTypeDef::SlotActive***
Specifies the slots in audio frame that will be activated. This parameter can be a value of [**SAI_Block_Slot_Active**](#)

53.2.4 __SAI_HandleTypeDefDef

Data Fields

- ***SAI_Block_TypeDef * Instance***
- ***SAI_InitTypeDef Init***
- ***SAI_FrameInitTypeDef FrameInit***
- ***SAI_SlotInitTypeDef SlotInit***
- ***uint8_t * pBuffPtr***
- ***uint16_t XferSize***

-
- *uint16_t XferCount*
 - *DMA_HandleTypeDef * hdmatx*
 - *DMA_HandleTypeDef * hdmarx*
 - *SAIcallback mutecallback*
 - *void(* InterruptServiceRoutine*
 - *HAL_LockTypeDef Lock*
 - *__IO HAL_SAI_StateTypeDef State*
 - *__IO uint32_t ErrorCode*

Field Documentation

- ***SAI_Block_TypeDef* __SAI_HandleTypeDefDef::Instance***
SAI Blockx registers base address
- ***SAI_InitTypeDef __SAI_HandleTypeDefDef::Init***
SAI communication parameters
- ***SAI_FrameInitTypeDef __SAI_HandleTypeDefDef::FrameInit***
SAI Frame configuration parameters
- ***SAI_SlotInitTypeDef __SAI_HandleTypeDefDef::SlotInit***
SAI Slot configuration parameters
- ***uint8_t* __SAI_HandleTypeDefDef::pBuffPtr***
Pointer to SAI transfer Buffer
- ***uint16_t __SAI_HandleTypeDefDef::XferSize***
SAI transfer size
- ***uint16_t __SAI_HandleTypeDefDef::XferCount***
SAI transfer counter
- ***DMA_HandleTypeDef* __SAI_HandleTypeDefDef::hdmatx***
SAI Tx DMA handle parameters
- ***DMA_HandleTypeDef* __SAI_HandleTypeDefDef::hdmarx***
SAI Rx DMA handle parameters
- ***SAIcallback __SAI_HandleTypeDefDef::mutecallback***
SAI mute callback
- ***void(* __SAI_HandleTypeDefDef::InterruptServiceRoutine)(struct __SAI_HandleTypeDefDef *hsai)***
- ***HAL_LockTypeDef __SAI_HandleTypeDefDef::Lock***
SAI locking object
- ***__IO HAL_SAI_StateTypeDef __SAI_HandleTypeDefDef::State***
SAI communication state
- ***__IO uint32_t __SAI_HandleTypeDefDef::ErrorCode***
SAI Error code

53.3 SAI Firmware driver API description

53.3.1 How to use this driver

The SAI HAL driver can be used as follows:

1. Declare a SAI_HandleTypeDef handle structure.
2. Initialize the SAI low level resources by implementing the HAL_SAI_MspInit() API:
 - a. Enable the SAI interface clock.
 - b. SAI pins configuration:
 - Enable the clock for the SAI GPIOs.
 - Configure these SAI pins as alternate function pull-up.

- c. NVIC configuration if you need to use interrupt process (HAL_SAI_Transmit_IT() and HAL_SAI_Receive_IT() APIs):
 - Configure the SAI interrupt priority.
 - Enable the NVIC SAI IRQ handle.
 - d. DMA Configuration if you need to use DMA process (HAL_SAI_Transmit_DMA() and HAL_SAI_Receive_DMA() APIs):
 - Declare a DMA handle structure for the Tx/Rx stream.
 - Enable the DMAx interface clock.
 - Configure the declared DMA handle structure with the required Tx/Rx parameters.
 - Configure the DMA Tx/Rx Stream.
 - Associate the initialized DMA handle to the SAI DMA Tx/Rx handle.
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx/Rx Stream.
3. Program the SAI Mode, Standard, Data Format, MCLK Output, Audio frequency and Polarity using HAL_SAI_Init() function. The specific SAI interrupts (FIFO request and Overrun underrun interrupt) will be managed using the macros __SAI_ENABLE_IT() and __SAI_DISABLE_IT() inside the transmit and receive process.



SAI Clock Source configuration is managed differently depending on the selected STM32F4 devices :

- For STM32F446xx devices, the configuration is managed through RCCEx_PeriphCLKConfig() function in the HAL RCC drivers
- For STM32F439xx/STM32F437xx/STM32F429xx/STM32F427xx devices, the configuration is managed within HAL SAI drivers through HAL_SAI_Init() function using ClockSource field of SAI_InitTypeDef structure.



Make sure that either:

- I2S PLL is configured or
- SAI PLL is configured or
- External clock source is configured after setting correctly the define constant EXTERNAL_CLOCK_VALUE in the stm32f4xx_hal_conf.h file.



In master Tx mode: enabling the audio block immediately generates the bit clock for the external slaves even if there is no data in the FIFO, However FS signal generation is conditioned by the presence of data in the FIFO.



In master Rx mode: enabling the audio block immediately generates the bit clock and FS signal for the external slaves.



It is mandatory to respect the following conditions in order to avoid bad SAI behavior:

- First bit Offset <= (SLOT size - Data size)
- Data size <= SLOT size
- Number of SLOT x SLOT size = Frame length

- The number of slots should be even when SAI_FS_CHANNEL_IDENTIFICATION is selected.

Three operation modes are available within this driver :

Polling mode IO operation

- Send an amount of data in blocking mode using HAL_SAI_Transmit()
- Receive an amount of data in blocking mode using HAL_SAI_Receive()

Interrupt mode IO operation

- Send an amount of data in non blocking mode using HAL_SAI_Transmit_IT()
- At transmission end of transfer HAL_SAI_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_SAI_TxCpltCallback
- Receive an amount of data in non blocking mode using HAL_SAI_Receive_IT()
- At reception end of transfer HAL_SAI_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_SAI_RxCpltCallback
- In case of transfer Error, HAL_SAI_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_SAI_ErrorCallback

DMA mode IO operation

- Send an amount of data in non blocking mode (DMA) using HAL_SAI_Transmit_DMA()
- At transmission end of transfer HAL_SAI_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_SAI_TxCpltCallback
- Receive an amount of data in non blocking mode (DMA) using HAL_SAI_Receive_DMA()
- At reception end of transfer HAL_SAI_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_SAI_RxCpltCallback
- In case of transfer Error, HAL_SAI_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_SAI_ErrorCallback
- Pause the DMA Transfer using HAL_SAI_DMAPause()
- Resume the DMA Transfer using HAL_SAI_DMAResume()
- Stop the DMA Transfer using HAL_SAI_DMASTop()

SAI HAL driver macros list

Below the list of most used macros in USART HAL driver :

- __HAL_SAI_ENABLE: Enable the SAI peripheral
- __HAL_SAI_DISABLE: Disable the SAI peripheral
- __HAL_SAI_ENABLE_IT : Enable the specified SAI interrupts
- __HAL_SAI_DISABLE_IT : Disable the specified SAI interrupts
- __HAL_SAI_GET_IT_SOURCE: Check if the specified SAI interrupt source is enabled or disabled
- __HAL_SAI_GET_FLAG: Check whether the specified SAI flag is set or not

53.3.2 Initialization and de-initialization functions

This subsection provides a set of functions allowing to initialize and de-initialize the SAIx peripheral:

- User must implement HAL_SAI_MspInit() function in which he configures all related peripherals resources (CLOCK, GPIO, DMA, IT and NVIC).
- Call the function HAL_SAI_Init() to configure the selected device with the selected configuration:
 - Mode (Master/slave TX/RX)
 - Protocol
 - Data Size
 - MCLK Output
 - Audio frequency
 - FIFO Threshold
 - Frame Config
 - Slot Config
- Call the function HAL_SAI_DeInit() to restore the default configuration of the selected SAI peripheral.

This section contains the following APIs:

- [***HAL_SAI_InitProtocol\(\)***](#)
- [***HAL_SAI_Init\(\)***](#)
- [***HAL_SAI_DeInit\(\)***](#)
- [***HAL_SAI_MspInit\(\)***](#)
- [***HAL_SAI_MspDeInit\(\)***](#)

53.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the SAI data transfers.

- There are two modes of transfer:
 - Blocking mode : The communication is performed in the polling mode. The status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode : The communication is performed using Interrupts or DMA. These functions return the status of the transfer startup. The end of the data processing will be indicated through the dedicated SAI IRQ when using Interrupt mode or the DMA IRQ when using DMA mode.
- Blocking mode functions are :
 - HAL_SAI_Transmit()
 - HAL_SAI_Receive()
 - HAL_SAI_TransmitReceive()
- Non Blocking mode functions with Interrupt are :
 - HAL_SAI_Transmit_IT()
 - HAL_SAI_Receive_IT()
 - HAL_SAI_TransmitReceive_IT()
- Non Blocking mode functions with DMA are :
 - HAL_SAI_Transmit_DMA()
 - HAL_SAI_Receive_DMA()
 - HAL_SAI_TransmitReceive_DMA()
- A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - HAL_SAI_TxCpltCallback()
 - HAL_SAI_RxCpltCallback()
 - HAL_SAI_ErrorCallback()

This section contains the following APIs:

- [*HAL_SAI_Transmit\(\)*](#)
- [*HAL_SAI_Receive\(\)*](#)
- [*HAL_SAI_Transmit_IT\(\)*](#)
- [*HAL_SAI_Receive_IT\(\)*](#)
- [*HAL_SAI_DMAPause\(\)*](#)
- [*HAL_SAI_DMAResume\(\)*](#)
- [*HAL_SAI_DMAStop\(\)*](#)
- [*HAL_SAI_Abort\(\)*](#)
- [*HAL_SAI_Transmit_DMA\(\)*](#)
- [*HAL_SAI_Receive_DMA\(\)*](#)
- [*HAL_SAI_EnableTxMuteMode\(\)*](#)
- [*HAL_SAI_DisableTxMuteMode\(\)*](#)
- [*HAL_SAI_EnableRxMuteMode\(\)*](#)
- [*HAL_SAI_DisableRxMuteMode\(\)*](#)
- [*HAL_SAI_IRQHandler\(\)*](#)
- [*HAL_SAI_TxCpltCallback\(\)*](#)
- [*HAL_SAI_TxHalfCpltCallback\(\)*](#)
- [*HAL_SAI_RxCpltCallback\(\)*](#)
- [*HAL_SAI_RxHalfCpltCallback\(\)*](#)
- [*HAL_SAI_ErrorCallback\(\)*](#)

53.3.4 Peripheral State and Errors functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_SAI_GetState\(\)*](#)
- [*HAL_SAI_GetError\(\)*](#)

53.3.5 HAL_SAI_InitProtocol

Function Name	HAL_StatusTypeDef HAL_SAI_InitProtocol (SAI_HandleTypeDef * hsai, uint32_t protocol, uint32_t datasize, uint32_t nbslot)
Function Description	Initializes the structure Framelnit, SlotInit and the low part of Init according to the specified parameters and call the function HAL_SAI_Init to initialize the SAI block.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. • protocol: : one of the supported protocol SAI Supported protocol • datasize: : one of the supported datasize SAI protocol data size the configuration information for SAI module. • nbslot: : Number of slot.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.6 HAL_SAI_Init

Function Name	HAL_StatusTypeDef HAL_SAI_Init (SAI_HandleTypeDef * hsai)
Function Description	Initializes the SAI according to the specified parameters in the SAI_InitTypeDef and create the associated handle.

Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status
53.3.7 HAL_SAI_DeInit	
Function Name	HAL_StatusTypeDef HAL_SAI_DeInit (SAI_HandleTypeDef * hsai)
Function Description	DeInitializes the SAI peripheral.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status
53.3.8 HAL_SAI_MspInit	
Function Name	void HAL_SAI_MspInit (SAI_HandleTypeDef * hsai)
Function Description	SAI MSP Init.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • None
53.3.9 HAL_SAI_MspDeInit	
Function Name	void HAL_SAI_MspDeInit (SAI_HandleTypeDef * hsai)
Function Description	SAI MSP DeInit.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • None
53.3.10 HAL_SAI_Transmit	
Function Name	HAL_StatusTypeDef HAL_SAI_Transmit (SAI_HandleTypeDef * hsai, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmits an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. • pData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status
53.3.11 HAL_SAI_Receive	
Function Name	HAL_StatusTypeDef HAL_SAI_Receive (SAI_HandleTypeDef * hsai, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receives an amount of data in blocking mode.

Parameters	<ul style="list-style-type: none"> hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. pData: Pointer to data buffer Size: Amount of data to be received Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

53.3.12 HAL_SAI_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_SAI_Transmit_IT (SAI_HandleTypeDef * hsai, uint8_t * pData, uint16_t Size)
Function Description	Transmits an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. pData: Pointer to data buffer Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status

53.3.13 HAL_SAI_Receive_IT

Function Name	HAL_StatusTypeDef HAL_SAI_Receive_IT (SAI_HandleTypeDef * hsai, uint8_t * pData, uint16_t Size)
Function Description	Receives an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. pData: Pointer to data buffer Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> HAL status

53.3.14 HAL_SAI_DMAPause

Function Name	HAL_StatusTypeDef HAL_SAI_DM_PAUSE (SAI_HandleTypeDef * hsai)
Function Description	Pauses the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> HAL status

53.3.15 HAL_SAI_DMResume

Function Name	HAL_StatusTypeDef HAL_SAI_DMResume (SAI_HandleTypeDef * hsai)
Function Description	Resumes the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> HAL status

53.3.16 HAL_SAI_DMASStop

Function Name	<code>HAL_StatusTypeDef HAL_SAI_DMASStop (SAI_HandleTypeDef * hsai)</code>
Function Description	Stops the audio stream playing from the Media.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.17 HAL_SAI_Abort

Function Name	<code>HAL_StatusTypeDef HAL_SAI_Abort (SAI_HandleTypeDef * hsai)</code>
Function Description	Abort the current transfer and disable the SAI.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.18 HAL_SAI_Transmit_DMA

Function Name	<code>HAL_StatusTypeDef HAL_SAI_Transmit_DMA (SAI_HandleTypeDef * hsai, uint8_t * pData, uint16_t Size)</code>
Function Description	Transmits an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

53.3.19 HAL_SAI_Receive_DMA

Function Name	<code>HAL_StatusTypeDef HAL_SAI_Receive_DMA (SAI_HandleTypeDef * hsai, uint8_t * pData, uint16_t Size)</code>
Function Description	Receives an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. • pData: Pointer to data buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status

53.3.20 HAL_SAI_EnableTxMuteMode

Function Name	<code>HAL_StatusTypeDef HAL_SAI_EnableTxMuteMode (SAI_HandleTypeDef * hsai, uint16_t val)</code>
Function Description	Enable the tx mute mode.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.

- **val:** : value sent during the mute SAI Block Mute Value
- Return values HAL status

53.3.21 HAL_SAI_DisableTxMuteMode

Function Name	HAL_StatusTypeDef HAL_SAI_DisableTxMuteMode (SAI_HandleTypeDef * hsai)
Function Description	Disable the tx mute mode.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.22 HAL_SAI_EnableRxMuteMode

Function Name	HAL_StatusTypeDef HAL_SAI_EnableRxMuteMode (SAI_HandleTypeDef * hsai, SAIcallback callback, uint16_t counter)
Function Description	Enable the rx mute detection.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module. • callback: : function called when the mute is detected • counter: : number a data before mute detection max 63.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.23 HAL_SAI_DisableRxMuteMode

Function Name	HAL_StatusTypeDef HAL_SAI_DisableRxMuteMode (SAI_HandleTypeDef * hsai)
Function Description	Disable the rx mute detection.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.24 HAL_SAI_IRQHandler

Function Name	void HAL_SAI_IRQHandler (SAI_HandleTypeDef * hsai)
Function Description	This function handles SAI interrupt request.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.
Return values	<ul style="list-style-type: none"> • HAL status

53.3.25 HAL_SAI_TxCpltCallback

Function Name	void HAL_SAI_TxCpltCallback (SAI_HandleTypeDef * hsai)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDef structure that contains

the configuration information for SAI module.

Return values

- None

53.3.26 HAL_SAI_TxHalfCpltCallback

Function Name	void HAL_SAI_TxHalfCpltCallback (SAI_HandleTypeDefDef * hsai)
---------------	--

Function Description	Tx Transfer Half completed callbacks.
----------------------	---------------------------------------

Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDefDef structure that contains the configuration information for SAI module.
------------	--

Return values	<ul style="list-style-type: none"> • None
---------------	--

53.3.27 HAL_SAI_RxCpltCallback

Function Name	void HAL_SAI_RxCpltCallback (SAI_HandleTypeDefDef * hsai)
---------------	--

Function Description	Rx Transfer completed callbacks.
----------------------	----------------------------------

Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDefDef structure that contains the configuration information for SAI module.
------------	--

Return values	<ul style="list-style-type: none"> • None
---------------	--

53.3.28 HAL_SAI_RxHalfCpltCallback

Function Name	void HAL_SAI_RxHalfCpltCallback (SAI_HandleTypeDefDef * hsai)
---------------	--

Function Description	Rx Transfer half completed callbacks.
----------------------	---------------------------------------

Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDefDef structure that contains the configuration information for SAI module.
------------	--

Return values	<ul style="list-style-type: none"> • None
---------------	--

53.3.29 HAL_SAI_ErrorCallback

Function Name	void HAL_SAI_ErrorCallback (SAI_HandleTypeDefDef * hsai)
---------------	---

Function Description	SAI error callbacks.
----------------------	----------------------

Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDefDef structure that contains the configuration information for SAI module.
------------	--

Return values	<ul style="list-style-type: none"> • None
---------------	--

53.3.30 HAL_SAI_GetState

Function Name	HAL_SAI_StateTypeDef HAL_SAI_GetState (SAI_HandleTypeDefDef * hsai)
---------------	--

Function Description	Returns the SAI state.
----------------------	------------------------

Parameters	<ul style="list-style-type: none"> • hsai: pointer to a SAI_HandleTypeDefDef structure that contains the configuration information for SAI module.
------------	--

Return values	<ul style="list-style-type: none"> • HAL state
---------------	---

53.3.31 HAL_SAI_GetError

Function Name	<code>uint32_t HAL_SAI_GetError (SAI_HandleTypeDef * hsai)</code>
Function Description	Return the SAI error code.
Parameters	<ul style="list-style-type: none"> • hsai: : pointer to a SAI_HandleTypeDef structure that contains the configuration information for the specified SAI Block.
Return values	<ul style="list-style-type: none"> • SAI Error Code

53.4 SAI Firmware driver defines

53.4.1 SAI

SAI Audio Frequency

`SAI_AUDIO_FREQUENCY_192K`
`SAI_AUDIO_FREQUENCY_96K`
`SAI_AUDIO_FREQUENCY_48K`
`SAI_AUDIO_FREQUENCY_44K`
`SAI_AUDIO_FREQUENCY_32K`
`SAI_AUDIO_FREQUENCY_22K`
`SAI_AUDIO_FREQUENCY_16K`
`SAI_AUDIO_FREQUENCY_11K`
`SAI_AUDIO_FREQUENCY_8K`
`SAI_AUDIO_FREQUENCY_MCKDIV`

SAI Block Clock Strobing

`SAI_CLOCKSTROBING_FALLINGEDGE`
`SAI_CLOCKSTROBING_RISINGEDGE`

SAI Block Companding Mode

`SAI_NOCOMPANDING`
`SAI_ULAW_1CPL_COMPANDING`
`SAI_ALAW_1CPL_COMPANDING`
`SAI_ULAW_2CPL_COMPANDING`
`SAI_ALAW_2CPL_COMPANDING`

SAI Block Data Size

`SAI_DATASIZE_8`
`SAI_DATASIZE_10`
`SAI_DATASIZE_16`
`SAI_DATASIZE_20`
`SAI_DATASIZE_24`
`SAI_DATASIZE_32`

SAI Block Fifo Status Level

SAI_FIFOSTATUS_EMPTY
SAI_FIFOSTATUS_LESS1QUARTERFULL
SAI_FIFOSTATUS_1QUARTERFULL
SAI_FIFOSTATUS_HALFFULL
SAI_FIFOSTATUS_3QUARTERFULL
SAI_FIFOSTATUS_FULL

SAI Block Fifo Threshold

SAI_FIFOTHRESHOLD_EMPTY
SAI_FIFOTHRESHOLD_1QF
SAI_FIFOTHRESHOLD_HF
SAI_FIFOTHRESHOLD_3QF
SAI_FIFOTHRESHOLD_FULL

SAI Block Flags Definition

SAI_FLAG_OVRUDR
SAI_FLAG_MUTEDET
SAI_FLAG_WCKCFG
SAI_FLAG_FREQ
SAI_FLAG_CNRDY
SAI_FLAG_AFSDET
SAI_FLAG_LFSDET

SAI Block FS Definition

SAI_FS_STARTFRAME
SAI_FS_CHANNEL_IDENTIFICATION

SAI Block FS Offset

SAI_FS_FIRSTBIT
SAI_FS_BEFOREFIRSTBIT

SAI Block FS Polarity

SAI_FS_ACTIVE_LOW
SAI_FS_ACTIVE_HIGH

SAI Block Interrupts Definition

SAI_IT_OVRUDR
SAI_IT_MUTEDET
SAI_IT_WCKCFG
SAI_IT_FREQ
SAI_IT_CNRDY

SAI_IT_AFSDET
SAI_IT_LFSDET
SAI Block Mode
SAI_MODEMASTER_TX
SAI_MODEMASTER_RX
SAI_MODESLAVE_TX
SAI_MODESLAVE_RX
SAI Block MSB LSB transmission
SAI_FIRSTBIT_MSB
SAI_FIRSTBIT_LSB
SAI Block Mute Value
SAI_ZERO_VALUE
SAI_LAST_SENT_VALUE
SAI Block NoDivider
SAI_MASTERDIVIDER_ENABLE
SAI_MASTERDIVIDER_DISABLE
SAI Block Output Drive
SAI_OUTPUTDRIVE_DISABLE
SAI_OUTPUTDRIVE_ENABLE
SAI Block Protocol
SAI_FREE_PROTOCOL
SAI_SPDIF_PROTOCOL
SAI_AC97_PROTOCOL
SAI Block Slot Active
SAI_SLOT_NOTACTIVE
SAI_SLOTACTIVE_0
SAI_SLOTACTIVE_1
SAI_SLOTACTIVE_2
SAI_SLOTACTIVE_3
SAI_SLOTACTIVE_4
SAI_SLOTACTIVE_5
SAI_SLOTACTIVE_6
SAI_SLOTACTIVE_7
SAI_SLOTACTIVE_8
SAI_SLOTACTIVE_9
SAI_SLOTACTIVE_10

SAI_SLOTACTIVE_11	
SAI_SLOTACTIVE_12	
SAI_SLOTACTIVE_13	
SAI_SLOTACTIVE_14	
SAI_SLOTACTIVE_15	
SAI_SLOTACTIVE_ALL	
SAI Block Slot Size	
SAI_SLOTSIZE_DATASIZE	
SAI_SLOTSIZE_16B	
SAI_SLOTSIZE_32B	
SAI External synchronisation	
SAI_SYNCEXT_DISABLE	
SAI_SYNCEXT_IN_ENABLE	
SAI_SYNCEXT_OUTBLOCKA_ENABLE	
SAI_SYNCEXT_OUTBLOCKB_ENABLE	
SAI Block Synchronization	
SAI_ASYNCNCHRONOUS	
SAI_SYNCHRONOUS	
SAI_SYNCHRONOUS_EXT	
SAI Clock Source	
SAI_CLKSOURCE_PLLSAI	
SAI_CLKSOURCE_PLLI2S	
SAI_CLKSOURCE_EXT	
SAI_CLKSOURCE_NA	No applicable for STM32F446xx
SAI Error Code	
HAL_SAI_ERROR_NONE	No error
HAL_SAI_ERROR_OVR	Overrun Error
HAL_SAI_ERROR_UDR	Underrun error
HAL_SAI_ERROR_AFSDET	Anticipated Frame synchronisation detection
HAL_SAI_ERROR_LFSDET	Late Frame synchronisation detection
HAL_SAI_ERROR_CNREADY	codec not ready
HAL_SAI_ERROR_WCKCFG	Wrong clock configuration
HAL_SAI_ERROR_TIMEOUT	Timeout error
SAI Exported Macros	
<u>__HAL_SAI_RESET_HANDLE_STATE</u>	Description:
	<ul style="list-style-type: none"> • Reset SAI handle state.

Parameters:

- `__HANDLE__`: specifies the SAI Handle.

Return value:

- None

`__HAL_SAI_ENABLE_IT`**Description:**

- Enable or disable the specified SAI interrupts.

Parameters:

- `__HANDLE__`: specifies the SAI Handle.
- `__INTERRUPT__`: specifies the interrupt source to enable or disable. This parameter can be one of the following values:
 - `SAI_IT_OVRUDR`: Overrun underrun interrupt enable
 - `SAI_IT_MUTEDET`: Mute detection interrupt enable
 - `SAI_IT_WCKCFG`: Wrong Clock Configuration interrupt enable
 - `SAI_IT_FREQ`: FIFO request interrupt enable
 - `SAI_IT_CNRDY`: Codec not ready interrupt enable
 - `SAI_IT_AFSDET`: Anticipated frame synchronization detection interrupt enable
 - `SAI_IT_LFSDET`: Late frame synchronization detection interrupt enable

Return value:

- None

`__HAL_SAI_DISABLE_IT``__HAL_SAI_GET_IT_SOURCE`**Description:**

- Check if the specified SAI interrupt source is enabled or disabled.

Parameters:

- `__HANDLE__`: specifies the SAI Handle. This parameter can be `SAI` where `x`: 1, 2, or 3 to select the SAI peripheral.
- `__INTERRUPT__`: specifies the SAI interrupt source to check. This parameter can be one of the following values:
 - `SAI_IT_TXE`: Tx buffer empty interrupt enable.
 - `SAI_IT_RXNE`: Rx buffer not empty interrupt enable.
 - `SAI_IT_ERR`: Error interrupt enable.

Return value:

- The: new state of __INTERRUPT__ (TRUE or FALSE).

[__HAL_SAI_GET_FLAG](#)**Description:**

- Check whether the specified SAI flag is set or not.

Parameters:

- __HANDLE__: specifies the SAI Handle.
- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - SAI_FLAG_OVRUDR: Overrun underrun flag.
 - SAI_FLAG_MUTEDET: Mute detection flag.
 - SAI_FLAG_WCKCFG: Wrong Clock Configuration flag.
 - SAI_FLAG_FREQ: FIFO request flag.
 - SAI_FLAG_CNRDY: Codec not ready flag.
 - SAI_FLAG_AFSDET: Anticipated frame synchronization detection flag.
 - SAI_FLAG_LFSDET: Late frame synchronization detection flag.

Return value:

- The: new state of __FLAG__ (TRUE or FALSE).

[__HAL_SAI_CLEAR_FLAG](#)**Description:**

- Clears the specified SAI pending flag.

Parameters:

- __HANDLE__: specifies the SAI Handle.
- __FLAG__: specifies the flag to check. This parameter can be any combination of the following values:
 - SAI_FLAG_OVRUDR: Clear Overrun underrun
 - SAI_FLAG_MUTEDET: Clear Mute detection
 - SAI_FLAG_WCKCFG: Clear Wrong Clock Configuration
 - SAI_FLAG_FREQ: Clear FIFO request
 - SAI_FLAG_CNRDY: Clear Codec not ready
 - SAI_FLAG_AFSDET: Clear Anticipated frame synchronization detection
 - SAI_FLAG_LFSDET: Clear Late frame synchronization detection

Return value:

- None

`__HAL_SAI_ENABLE`

`__HAL_SAI_DISABLE`

SAI Mono Stereo Mode

`SAI_STEREOMODE`

`SAI_MONOMODE`

SAI Private Constants

`SAI_FIFO_SIZE`

`SAI_DEFAULT_TIMEOUT`

SAI Private Macros

`IS_SAI_BLOCK_SYNCEXT`

`IS_SAI_SUPPORTED_PROTOCOL`

`IS_SAI_PROTOCOL_DATASIZE`

`IS_SAI_CLK_SOURCE`

`IS_SAI_AUDIO_FREQUENCY`

`IS_SAI_BLOCK_MODE`

`IS_SAI_BLOCK_PROTOCOL`

`IS_SAI_BLOCK_DATASIZE`

`IS_SAI_BLOCK_FIRST_BIT`

`IS_SAI_BLOCK_CLOCK_STROBING`

`IS_SAI_BLOCK_SYNCHRO`

`IS_SAI_BLOCK_OUTPUT_DRIVE`

`IS_SAI_BLOCK_NODIVIDER`

`IS_SAI_BLOCK_FIFO_STATUS`

`IS_SAI_BLOCK_MUTE_COUNTER`

`IS_SAI_BLOCK_MUTE_VALUE`

`IS_SAI_BLOCK_COMPANDING_MODE`

`IS_SAI_BLOCK_FIFO_THRESHOLD`

`IS_SAI_BLOCK_TRISTATE_MANAGEMENT`

`IS_SAI_MONO_STEREO_MODE`

`IS_SAI_SLOT_ACTIVE`

`IS_SAI_BLOCK_SLOT_NUMBER`

`IS_SAI_BLOCK_SLOT_SIZE`

`IS_SAI_BLOCK_FIRSTBIT_OFFSET`

`IS_SAI_BLOCK_FS_OFFSET`

IS_SAI_BLOCK_FS_POLARITY
IS_SAI_BLOCK_FS_DEFINITION
IS_SAI_BLOCK_MASTER_DIVIDER
IS_SAI_BLOCK_FRAME_LENGTH
IS_SAI_BLOCK_ACTIVE_FRAME

SAI Supported protocol

SAI_I2S_STANDARD
SAI_I2S_MSBJUSTIFIED
SAI_I2S_LSBJUSTIFIED
SAI_PCM_LONG
SAI_PCM_SHORT

SAI protocol data size

SAI_PROTOCOL_DATASIZE_16BIT
SAI_PROTOCOL_DATASIZE_16BITEXTENDED
SAI_PROTOCOL_DATASIZE_24BIT
SAI_PROTOCOL_DATASIZE_32BIT

SAI TRIS State Management

SAI_OUTPUT_NOTRELEASED
SAI_OUTPUT_RELEASED

54 HAL SAI Extension Driver

54.1 HAL SAI Extension Driver

54.2 SAIEx Firmware driver API description

54.2.1 SAI peripheral extension features

Comparing to other previous devices, the SAI interface for STM32F446xx devices contains the following additional features :

- Possibility to be clocked from PLLR

54.2.2 How to use this driver

This driver provides functions to manage several sources to clock SAI

54.2.3 Extension features Functions

This subsection provides a set of functions allowing to manage the possible SAI clock sources.

This section contains the following APIs:

- [**SAI_BlockSynchroConfig\(\)**](#)
- [**SAI_GetInputClock\(\)**](#)

54.2.4 SAI_BlockSynchroConfig

Function Name **void SAI_BlockSynchroConfig (SAI_HandleTypeDef * hsai)**

Function Description Configure SAI Block synchronization mode.

Parameters

- **hsai:** pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.

Return values

- SAI Clock Input

54.2.5 SAI_GetInputClock

Function Name **uint32_t SAI_GetInputClock (SAI_HandleTypeDef * hsai)**

Function Description Get SAI Input Clock based on SAI source clock selection.

Parameters

- **hsai:** pointer to a SAI_HandleTypeDef structure that contains the configuration information for SAI module.

Return values

- SAI Clock Input

54.3 SAIEx Firmware driver defines

54.3.1 SAIEx

55 HAL SDRAM Generic Driver

55.1 HAL SDRAM Generic Driver

55.2 SDRAM Firmware driver registers structures

55.2.1 SDRAM_HandleTypeDef

Data Fields

- *FMC_SDRAM_TypeDef * Instance*
- *FMC_SDRAM_InitTypeDef Init*
- *__IO HAL_SDRAM_StateTypeDef State*
- *HAL_LockTypeDef Lock*
- *DMA_HandleTypeDef * hdma*

Field Documentation

- ***FMC_SDRAM_TypeDef* SDRAM_HandleTypeDef::Instance***
Register base address
- ***FMC_SDRAM_InitTypeDef SDRAM_HandleTypeDef::Init***
SDRAM device configuration parameters
- ***__IO HAL_SDRAM_StateTypeDef SDRAM_HandleTypeDef::State***
SDRAM access state
- ***HAL_LockTypeDef SDRAM_HandleTypeDef::Lock***
SDRAM locking object
- ***DMA_HandleTypeDef* SDRAM_HandleTypeDef::hdma***
Pointer DMA handler

55.3 SDRAM Firmware driver API description

55.3.1 How to use this driver

This driver is a generic layered driver which contains a set of APIs used to control SDRAM memories. It uses the FMC layer functions to interface with SDRAM devices. The following sequence should be followed to configure the FMC to interface with SDRAM memories:

1. Declare a SDRAM_HandleTypeDef handle structure, for example:
`SDRAM_HandleTypeDef hdsram`
 - Fill the SDRAM_HandleTypeDef handle "Init" field with the allowed values of the structure member.
 - Fill the SDRAM_HandleTypeDef handle "Instance" field with a predefined base register instance for NOR or SDRAM device
2. Declare a FMC_SDRAM_TimingTypeDef structure; for example:
`FMC_SDRAM_TimingTypeDef Timing;` and fill its fields with the allowed values of the structure member.
3. Initialize the SDRAM Controller by calling the function `HAL_SDRAM_Init()`. This function performs the following sequence:
 - a. MSP hardware layer configuration using the function `HAL_SDRAM_MspInit()`

- b. Control register configuration using the FMC SDRAM interface function `FMC_SDRAM_Init()`
 - c. Timing register configuration using the FMC SDRAM interface function `FMC_SDRAM_Timing_Init()`
 - d. Program the SDRAM external device by applying its initialization sequence according to the device plugged in your hardware. This step is mandatory for accessing the SDRAM device.
4. At this stage you can perform read/write accesses from/to the memory connected to the SDRAM Bank. You can perform either polling or DMA transfer using the following APIs:
- `HAL_SDRAM_Read()`/`HAL_SDRAM_Write()` for polling read/write access
 - `HAL_SDRAM_Read_DMA()`/`HAL_SDRAM_Write_DMA()` for DMA read/write transfer
5. You can also control the SDRAM device by calling the control APIs `HAL_SDRAM_WriteOperation_Enable()`/`HAL_SDRAM_WriteOperation_Disable()` to respectively enable/disable the SDRAM write operation or the function `HAL_SDRAM_SendCommand()` to send a specified command to the SDRAM device. The command to be sent must be configured with the `FMC_SDRAM_CommandTypeDef` structure.
6. You can continuously monitor the SDRAM device HAL state by calling the function `HAL_SDRAM_GetState()`

55.3.2 SDRAM Initialization and de_initialization functions

This section provides functions allowing to initialize/de-initialize the SDRAM memory

This section contains the following APIs:

- [`HAL_SDRAM_Init\(\)`](#)
- [`HAL_SDRAM_DeInit\(\)`](#)
- [`HAL_SDRAM_MspInit\(\)`](#)
- [`HAL_SDRAM_MspDeInit\(\)`](#)
- [`HAL_SDRAM_IRQHandler\(\)`](#)
- [`HAL_SDRAM_RefreshErrorCallback\(\)`](#)
- [`HAL_SDRAM_DMA_XferCpltCallback\(\)`](#)
- [`HAL_SDRAM_DMA_XferErrorCallback\(\)`](#)

55.3.3 SDRAM Input and Output functions

This section provides functions allowing to use and control the SDRAM memory

This section contains the following APIs:

- [`HAL_SDRAM_Read_8b\(\)`](#)
- [`HAL_SDRAM_Write_8b\(\)`](#)
- [`HAL_SDRAM_Read_16b\(\)`](#)
- [`HAL_SDRAM_Write_16b\(\)`](#)
- [`HAL_SDRAM_Read_32b\(\)`](#)
- [`HAL_SDRAM_Write_32b\(\)`](#)
- [`HAL_SDRAM_Read_DMA\(\)`](#)
- [`HAL_SDRAM_Write_DMA\(\)`](#)

55.3.4 SDRAM Control functions

This subsection provides a set of functions allowing to control dynamically the SDRAM interface.

This section contains the following APIs:

- [*HAL_SDRAM_WriteProtection_Enable\(\)*](#)
- [*HAL_SDRAM_WriteProtection_Disable\(\)*](#)
- [*HAL_SDRAM_SendCommand\(\)*](#)
- [*HAL_SDRAM_ProgramRefreshRate\(\)*](#)
- [*HAL_SDRAM_SetAutoRefreshNumber\(\)*](#)
- [*HAL_SDRAM_GetModeStatus\(\)*](#)

55.3.5 SDRAM State functions

This subsection permits to get in run-time the status of the SDRAM controller and the data flow.

This section contains the following APIs:

- [*HAL_SDRAM_GetState\(\)*](#)

55.3.6 HAL_SDRAM_Init

Function Name	<code>HAL_StatusTypeDef HAL_SDRAM_Init (SDRAM_HandleTypeDef * hsdrdram, FMC_SDRAM_TimingTypeDef * Timing)</code>
Function Description	Performs the SDRAM device initialization sequence.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. • Timing: Pointer to SDRAM control timing structure
Return values	<ul style="list-style-type: none"> • HAL status

55.3.7 HAL_SDRAM_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_SDRAM_DeInit (SDRAM_HandleTypeDef * hsdrdram)</code>
Function Description	Perform the SDRAM device initialization sequence.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • HAL status

55.3.8 HAL_SDRAM_MspInit

Function Name	<code>void HAL_SDRAM_MspInit (SDRAM_HandleTypeDef * hsdrdram)</code>
Function Description	SDRAM MSP Init.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • None

55.3.9 HAL_SDRAM_MspDeInit

Function Name	<code>void HAL_SDRAM_MspDeInit (SDRAM_HandleTypeDef * hsdrdram)</code>
Function Description	SDRAM MSP DeInit.

Parameters	<ul style="list-style-type: none"> • hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • None

55.3.10 HAL_SDRAM_IRQHandler

Function Name	void HAL_SDRAM_IRQHandler (SDRAM_HandleTypeDef * hsdram)
Function Description	This function handles SDRAM refresh error interrupt request.
Parameters	<ul style="list-style-type: none"> • hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • HAL status

55.3.11 HAL_SDRAM_RefreshErrorHandler

Function Name	void HAL_SDRAM_RefreshErrorHandler (SDRAM_HandleTypeDef * hsdram)
Function Description	SDRAM Refresh error callback.
Parameters	<ul style="list-style-type: none"> • hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • None

55.3.12 HAL_SDRAM_DMA_XferCpltCallback

Function Name	void HAL_SDRAM_DMA_XferCpltCallback (DMA_HandleTypeDef * hdma)
Function Description	DMA transfer complete callback.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA module.
Return values	<ul style="list-style-type: none"> • None

55.3.13 HAL_SDRAM_DMA_XferErrorHandler

Function Name	void HAL_SDRAM_DMA_XferErrorHandler (DMA_HandleTypeDef * hdma)
Function Description	DMA transfer complete error callback.
Parameters	<ul style="list-style-type: none"> • hdma: DMA handle
Return values	<ul style="list-style-type: none"> • None

55.3.14 HAL_SDRAM_Read_8b

Function Name	HAL_StatusTypeDef HAL_SDRAM_Read_8b (SDRAM_HandleTypeDef * hsdram, uint32_t * pAddress, uint8_t * pDstBuffer, uint32_t BufferSize)
Function Description	Reads 8-bit data buffer from the SDRAM memory.

Parameters	<ul style="list-style-type: none"> hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. pAddress: Pointer to read start address pDstBuffer: Pointer to destination buffer BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> HAL status

55.3.15 HAL_SDRAM_Write_8b

Function Name	HAL_StatusTypeDef HAL_SDRAM_Write_8b (SDRAM_HandleTypeDef * hsdram, uint32_t * pAddress, uint8_t * pSrcBuffer, uint32_t BufferSize)
Function Description	Writes 8-bit data buffer to SDRAM memory.
Parameters	<ul style="list-style-type: none"> hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. pAddress: Pointer to write start address pSrcBuffer: Pointer to source buffer to write BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> HAL status

55.3.16 HAL_SDRAM_Read_16b

Function Name	HAL_StatusTypeDef HAL_SDRAM_Read_16b (SDRAM_HandleTypeDef * hsdram, uint32_t * pAddress, uint16_t * pDstBuffer, uint32_t BufferSize)
Function Description	Reads 16-bit data buffer from the SDRAM memory.
Parameters	<ul style="list-style-type: none"> hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. pAddress: Pointer to read start address pDstBuffer: Pointer to destination buffer BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> HAL status

55.3.17 HAL_SDRAM_Write_16b

Function Name	HAL_StatusTypeDef HAL_SDRAM_Write_16b (SDRAM_HandleTypeDef * hsdram, uint32_t * pAddress, uint16_t * pSrcBuffer, uint32_t BufferSize)
Function Description	Writes 16-bit data buffer to SDRAM memory.
Parameters	<ul style="list-style-type: none"> hsdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. pAddress: Pointer to write start address pSrcBuffer: Pointer to source buffer to write BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> HAL status

55.3.18 HAL_SDRAM_Read_32b

Function Name	HAL_StatusTypeDef HAL_SDRAM_Read_32b (SDRAM_HandleTypeDef * hsdrdram, uint32_t * pAddress, uint32_t * pDstBuffer, uint32_t BufferSize)
Function Description	Reads 32-bit data buffer from the SDRAM memory.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. • pAddress: Pointer to read start address • pDstBuffer: Pointer to destination buffer • BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> • HAL status

55.3.19 HAL_SDRAM_Write_32b

Function Name	HAL_StatusTypeDef HAL_SDRAM_Write_32b (SDRAM_HandleTypeDef * hsdrdram, uint32_t * pAddress, uint32_t * pSrcBuffer, uint32_t BufferSize)
Function Description	Writes 32-bit data buffer to SDRAM memory.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. • pAddress: Pointer to write start address • pSrcBuffer: Pointer to source buffer to write • BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> • HAL status

55.3.20 HAL_SDRAM_Read_DMA

Function Name	HAL_StatusTypeDef HAL_SDRAM_Read_DMA (SDRAM_HandleTypeDef * hsdrdram, uint32_t * pAddress, uint32_t * pDstBuffer, uint32_t BufferSize)
Function Description	Reads a Words data from the SDRAM memory using DMA transfer.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. • pAddress: Pointer to read start address • pDstBuffer: Pointer to destination buffer • BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> • HAL status

55.3.21 HAL_SDRAM_Write_DMA

Function Name	HAL_StatusTypeDef HAL_SDRAM_Write_DMA (SDRAM_HandleTypeDef * hsdrdram, uint32_t * pAddress, uint32_t * pSrcBuffer, uint32_t BufferSize)
Function Description	Writes a Words data buffer to SDRAM memory using DMA transfer.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. • pAddress: Pointer to write start address

-
- **pSrcBuffer:** Pointer to source buffer to write
 - **BufferSize:** Size of the buffer to write to memory
 - HAL status

Return values

55.3.22 HAL_SDRAM_WriteProtection_Enable

Function Name **HAL_StatusTypeDef HAL_SDRAM_WriteProtection_Enable
(SDRAM_HandleTypeDef * hsdr)**

Function Description Enables dynamically SDRAM write protection.

Parameters • **hsdr**: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.

Return values • HAL status

55.3.23 HAL_SDRAM_WriteProtection_Disable

Function Name **HAL_StatusTypeDef HAL_SDRAM_WriteProtection_Disable
(SDRAM_HandleTypeDef * hsdr)**

Function Description Disables dynamically SDRAM write protection.

Parameters • **hsdr**: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.

Return values • HAL status

55.3.24 HAL_SDRAM_SendCommand

Function Name **HAL_StatusTypeDef HAL_SDRAM_SendCommand
(SDRAM_HandleTypeDef * hsdr,
FMC_SDRAM_CommandTypeDef * Command, uint32_t
Timeout)**

Function Description Sends Command to the SDRAM bank.

Parameters • **hsdr**: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
• **Command**: SDRAM command structure
• **Timeout**: Timeout duration

Return values • HAL status

55.3.25 HAL_SDRAM_ProgramRefreshRate

Function Name **HAL_StatusTypeDef HAL_SDRAM_ProgramRefreshRate
(SDRAM_HandleTypeDef * hsdr, uint32_t RefreshRate)**

Function Description Programs the SDRAM Memory Refresh rate.

Parameters • **hsdr**: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
• **RefreshRate**: The SDRAM refresh rate value

Return values • HAL status

55.3.26 HAL_SDRAM_SetAutoRefreshNumber

Function Name	HAL_StatusTypeDef HAL_SDRAM_SetAutoRefreshNumber (SDRAM_HandleTypeDef * hsdrdram, uint32_t AutoRefreshNumber)
Function Description	Sets the Number of consecutive SDRAM Memory auto Refresh commands.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module. • AutoRefreshNumber: The SDRAM auto Refresh number
Return values	<ul style="list-style-type: none"> • HAL status

55.3.27 HAL_SDRAM_GetModeStatus

Function Name	uint32_t HAL_SDRAM_GetModeStatus (SDRAM_HandleTypeDef * hsdrdram)
Function Description	Returns the SDRAM memory current mode.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • The SDRAM memory mode.

55.3.28 HAL_SDRAM_GetState

Function Name	HAL_SDRAM_StateTypeDef HAL_SDRAM_GetState (SDRAM_HandleTypeDef * hsdrdram)
Function Description	Returns the SDRAM state.
Parameters	<ul style="list-style-type: none"> • hsdrdram: pointer to a SDRAM_HandleTypeDef structure that contains the configuration information for SDRAM module.
Return values	<ul style="list-style-type: none"> • HAL state

55.4 SDRAM Firmware driver defines

55.4.1 SDRAM

SDRAM Exported Macros

_HAL_SDRAM_RESET_HANDLE_STATE Description:

- Reset SDRAM handle state.

Parameters:

- **_HANDLE_**: specifies the SDRAM handle.

Return value:

- None

56 HAL SD Generic Driver

56.1 HAL SD Generic Driver

56.2 SD Firmware driver registers structures

56.2.1 SD_HandleTypeDef

Data Fields

- *SD_TypeDef * Instance*
- *SD_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *uint32_t CardType*
- *uint32_t RCA*
- *uint32_t CSD*
- *uint32_t CID*
- *_IO uint32_t SdTransferCplt*
- *_IO uint32_t SdTransferErr*
- *_IO uint32_t DmaTransferCplt*
- *_IO uint32_t SdOperation*
- *DMA_HandleTypeDef * hdmarx*
- *DMA_HandleTypeDef * hdmatx*

Field Documentation

- ***SD_TypeDef* SD_HandleTypeDef::Instance***
SDIO register base address
- ***SD_InitTypeDef SD_HandleTypeDef::Init***
SD required parameters
- ***HAL_LockTypeDef SD_HandleTypeDef::Lock***
SD locking object
- ***uint32_t SD_HandleTypeDef::CardType***
SD card type
- ***uint32_t SD_HandleTypeDef::RCA***
SD relative card address
- ***uint32_t SD_HandleTypeDef::CSD[4]***
SD card specific data table
- ***uint32_t SD_HandleTypeDef::CID[4]***
SD card identification number table
- ***_IO uint32_t SD_HandleTypeDef::SdTransferCplt***
SD transfer complete flag in non blocking mode
- ***_IO uint32_t SD_HandleTypeDef::SdTransferErr***
SD transfer error flag in non blocking mode
- ***_IO uint32_t SD_HandleTypeDef::DmaTransferCplt***
SD DMA transfer complete flag
- ***_IO uint32_t SD_HandleTypeDef::SdOperation***
SD transfer operation (read/write)

-
- **DMA_HandleTypeDef* SD_HandleTypeDef::hdmarx**
SD Rx DMA handle parameters
 - **DMA_HandleTypeDef* SD_HandleTypeDef::hdmatx**
SD Tx DMA handle parameters

56.2.2 HAL_SD_CSDTypedef

Data Fields

- `_IO uint8_t CSDStruct`
- `_IO uint8_t SysSpecVersion`
- `_IO uint8_t Reserved1`
- `_IO uint8_t TAAC`
- `_IO uint8_t NSAC`
- `_IO uint8_t MaxBusClkFrec`
- `_IO uint16_t CardComdClasses`
- `_IO uint8_t RdBlockLen`
- `_IO uint8_t PartBlockRead`
- `_IO uint8_t WrBlockMisalign`
- `_IO uint8_t RdBlockMisalign`
- `_IO uint8_t DSRImpl`
- `_IO uint8_t Reserved2`
- `_IO uint32_t DeviceSize`
- `_IO uint8_t MaxRdCurrentVDDMin`
- `_IO uint8_t MaxRdCurrentVDDMax`
- `_IO uint8_t MaxWrCurrentVDDMin`
- `_IO uint8_t MaxWrCurrentVDDMax`
- `_IO uint8_t DeviceSizeMul`
- `_IO uint8_t EraseGrSize`
- `_IO uint8_t EraseGrMul`
- `_IO uint8_t WrProtectGrSize`
- `_IO uint8_t WrProtectGrEnable`
- `_IO uint8_t ManDeflECC`
- `_IO uint8_t WrSpeedFact`
- `_IO uint8_t MaxWrBlockLen`
- `_IO uint8_t WriteBlockPaPartial`
- `_IO uint8_t Reserved3`
- `_IO uint8_t ContentProtectAppli`
- `_IO uint8_t FileFormatGrouop`
- `_IO uint8_t CopyFlag`
- `_IO uint8_t PermWrProtect`
- `_IO uint8_t TempWrProtect`
- `_IO uint8_t FileFormat`
- `_IO uint8_t ECC`
- `_IO uint8_t CSD_CRC`
- `_IO uint8_t Reserved4`

Field Documentation

- `_IO uint8_t HAL_SD_CSDTypedef::CSDStruct`
CSD structure
- `_IO uint8_t HAL_SD_CSDTypedef::SysSpecVersion`
System specification version
- `_IO uint8_t HAL_SD_CSDTypedef::Reserved1`
Reserved
- `_IO uint8_t HAL_SD_CSDTypedef::TAAC`
Data read access time 1
- `_IO uint8_t HAL_SD_CSDTypedef::NSAC`
Data read access time 2 in CLK cycles
- `_IO uint8_t HAL_SD_CSDTypedef::MaxBusClkFrec`
Max. bus clock frequency
- `_IO uint16_t HAL_SD_CSDTypedef::CardComdClasses`
Card command classes
- `_IO uint8_t HAL_SD_CSDTypedef::RdBlockLen`
Max. read data block length
- `_IO uint8_t HAL_SD_CSDTypedef::PartBlockRead`
Partial blocks for read allowed
- `_IO uint8_t HAL_SD_CSDTypedef::WrBlockMisalign`
Write block misalignment
- `_IO uint8_t HAL_SD_CSDTypedef::RdBlockMisalign`
Read block misalignment
- `_IO uint8_t HAL_SD_CSDTypedef::DSRImpl`
DSR implemented
- `_IO uint8_t HAL_SD_CSDTypedef::Reserved2`
Reserved
- `_IO uint32_t HAL_SD_CSDTypedef::DeviceSize`
Device Size
- `_IO uint8_t HAL_SD_CSDTypedef::MaxRdCurrentVDDMin`
Max. read current @ VDD min
- `_IO uint8_t HAL_SD_CSDTypedef::MaxRdCurrentVDDMax`
Max. read current @ VDD max
- `_IO uint8_t HAL_SD_CSDTypedef::MaxWrCurrentVDDMin`
Max. write current @ VDD min
- `_IO uint8_t HAL_SD_CSDTypedef::MaxWrCurrentVDDMax`
Max. write current @ VDD max
- `_IO uint8_t HAL_SD_CSDTypedef::DeviceSizeMul`
Device size multiplier
- `_IO uint8_t HAL_SD_CSDTypedef::EraseGrSize`
Erase group size
- `_IO uint8_t HAL_SD_CSDTypedef::EraseGrMul`
Erase group size multiplier
- `_IO uint8_t HAL_SD_CSDTypedef::WrProtectGrSize`
Write protect group size
- `_IO uint8_t HAL_SD_CSDTypedef::WrProtectGrEnable`
Write protect group enable
- `_IO uint8_t HAL_SD_CSDTypedef::ManDefIECC`
Manufacturer default ECC
- `_IO uint8_t HAL_SD_CSDTypedef::WrSpeedFact`
Write speed factor
- `_IO uint8_t HAL_SD_CSDTypedef::MaxWrBlockLen`
Max. write data block length
- `_IO uint8_t HAL_SD_CSDTypedef::WriteBlockPaPartial`
Partial blocks for write allowed

- `__IO uint8_t HAL_SD_CSDTypedef::Reserved3`
Reserved
- `__IO uint8_t HAL_SD_CSDTypedef::ContentProtectAppli`
Content protection application
- `__IO uint8_t HAL_SD_CSDTypedef::FileFormatGrouop`
File format group
- `__IO uint8_t HAL_SD_CSDTypedef::CopyFlag`
Copy flag (OTP)
- `__IO uint8_t HAL_SD_CSDTypedef::PermWrProtect`
Permanent write protection
- `__IO uint8_t HAL_SD_CSDTypedef::TempWrProtect`
Temporary write protection
- `__IO uint8_t HAL_SD_CSDTypedef::FileFormat`
File format
- `__IO uint8_t HAL_SD_CSDTypedef::ECC`
ECC code
- `__IO uint8_t HAL_SD_CSDTypedef::CSD_CRC`
CSD CRC
- `__IO uint8_t HAL_SD_CSDTypedef::Reserved4`
Always 1

56.2.3 HAL_SD_CIDTypedef

Data Fields

- `__IO uint8_t ManufacturerID`
- `__IO uint16_t OEM_AppliID`
- `__IO uint32_t ProdName1`
- `__IO uint8_t ProdName2`
- `__IO uint8_t ProdRev`
- `__IO uint32_t ProdSN`
- `__IO uint8_t Reserved1`
- `__IO uint16_t ManufactDate`
- `__IO uint8_t CID_CRC`
- `__IO uint8_t Reserved2`

Field Documentation

- `__IO uint8_t HAL_SD_CIDTypedef::ManufacturerID`
Manufacturer ID
- `__IO uint16_t HAL_SD_CIDTypedef::OEM_AppliID`
OEM/Application ID
- `__IO uint32_t HAL_SD_CIDTypedef::ProdName1`
Product Name part1
- `__IO uint8_t HAL_SD_CIDTypedef::ProdName2`
Product Name part2
- `__IO uint8_t HAL_SD_CIDTypedef::ProdRev`
Product Revision
- `__IO uint32_t HAL_SD_CIDTypedef::ProdSN`
Product Serial Number

- `_IO uint8_t HAL_SD_CIDTypedef::Reserved1`
Reserved1
- `_IO uint16_t HAL_SD_CIDTypedef::ManufactDate`
Manufacturing Date
- `_IO uint8_t HAL_SD_CIDTypedef::CID_CRC`
CID CRC
- `_IO uint8_t HAL_SD_CIDTypedef::Reserved2`
Always 1

56.2.4 HAL_SD_CardStatusTypedef

Data Fields

- `_IO uint8_t DAT_BUS_WIDTH`
- `_IO uint8_t SECURED_MODE`
- `_IO uint16_t SD_CARD_TYPE`
- `_IO uint32_t SIZE_OF_PROTECTED_AREA`
- `_IO uint8_t SPEED_CLASS`
- `_IO uint8_t PERFORMANCE_MOVE`
- `_IO uint8_t AU_SIZE`
- `_IO uint16_t ERASE_SIZE`
- `_IO uint8_t ERASE_TIMEOUT`
- `_IO uint8_t ERASE_OFFSET`

Field Documentation

- `_IO uint8_t HAL_SD_CardStatusTypedef::DAT_BUS_WIDTH`
Shows the currently defined data bus width
- `_IO uint8_t HAL_SD_CardStatusTypedef::SECURED_MODE`
Card is in secured mode of operation
- `_IO uint16_t HAL_SD_CardStatusTypedef::SD_CARD_TYPE`
Carries information about card type
- `_IO uint32_t HAL_SD_CardStatusTypedef::SIZE_OF_PROTECTED_AREA`
Carries information about the capacity of protected area
- `_IO uint8_t HAL_SD_CardStatusTypedef::SPEED_CLASS`
Carries information about the speed class of the card
- `_IO uint8_t HAL_SD_CardStatusTypedef::PERFORMANCE_MOVE`
Carries information about the card's performance move
- `_IO uint8_t HAL_SD_CardStatusTypedef::AU_SIZE`
Carries information about the card's allocation unit size
- `_IO uint16_t HAL_SD_CardStatusTypedef::ERASE_SIZE`
Determines the number of AUs to be erased in one operation
- `_IO uint8_t HAL_SD_CardStatusTypedef::ERASE_TIMEOUT`
Determines the timeout for any number of AU erase
- `_IO uint8_t HAL_SD_CardStatusTypedef::ERASE_OFFSET`
Carries information about the erase offset

56.2.5 HAL_SD_CardInfoTypedef

Data Fields

- ***HAL_SD_CSDTypeDef SD_csd***
- ***HAL_SD_CIDTypeDef SD_cid***
- ***uint64_t CardCapacity***
- ***uint32_t CardBlockSize***
- ***uint16_t RCA***
- ***uint8_t CardType***

Field Documentation

- ***HAL_SD_CSDTypeDef HAL_SD_CardInfoTypedef::SD_csd***
SD card specific data register
- ***HAL_SD_CIDTypeDef HAL_SD_CardInfoTypedef::SD_cid***
SD card identification number register
- ***uint64_t HAL_SD_CardInfoTypedef::CardCapacity***
Card capacity
- ***uint32_t HAL_SD_CardInfoTypedef::CardBlockSize***
Card block size
- ***uint16_t HAL_SD_CardInfoTypedef::RCA***
SD relative card address
- ***uint8_t HAL_SD_CardInfoTypedef::CardType***
SD card type

56.3 SD Firmware driver API description

56.3.1 How to use this driver

This driver implements a high level communication layer for read and write from/to this memory. The needed STM32 hardware resources (SDIO and GPIO) are performed by the user in HAL_SD_MspInit() function (MSP layer). Basically, the MSP layer configuration should be the same as we provide in the examples. You can easily tailor this configuration according to hardware resources.

This driver is a generic layered driver for SDIO memories which uses the HAL SDIO driver functions to interface with SD and uSD cards devices. It is used as follows:

1. Initialize the SDIO low level resources by implement the HAL_SD_MspInit() API:
 - a. Enable the SDIO interface clock using __HAL_RCC_SDIO_CLK_ENABLE();
 - b. SDIO pins configuration for SD card
 - Enable the clock for the SDIO GPIOs using the functions __HAL_RCC_GPIOx_CLK_ENABLE();
 - Configure these SDIO pins as alternate function pull-up using HAL_GPIO_Init() and according to your pin assignment;
 - c. DMA Configuration if you need to use DMA process (HAL_SD_ReadBlocks_DMA() and HAL_SD_WriteBlocks_DMA() APIs).
 - Enable the DMAx interface clock using __HAL_RCC_DMAx_CLK_ENABLE();
 - Configure the DMA using the function HAL_DMA_Init() with predeclared and filled.
 - d. NVIC configuration if you need to use interrupt process when using DMA transfer.
 - Configure the SDIO and DMA interrupt priorities using functions HAL_NVIC_SetPriority(); DMA priority is superior to SDIO's priority

- Enable the NVIC DMA and SDIO IRQs using function HAL_NVIC_EnableIRQ()
 - SDIO interrupts are managed using the macros __HAL_SD_SDIO_ENABLE_IT() and __HAL_SD_SDIO_DISABLE_IT() inside the communication process.
 - SDIO interrupts pending bits are managed using the macros __HAL_SD_SDIO_GET_IT() and __HAL_SD_SDIO_CLEAR_IT()
2. At this stage, you can perform SD read/write/erase operations after SD card initialization

SD Card Initialization and configuration

To initialize the SD Card, use the HAL_SD_Init() function. It initializes the SD Card and put it into Standby State (Ready for data transfer). This function provide the following operations:

1. Apply the SD Card initialization process at 400KHz and check the SD Card type (Standard Capacity or High Capacity). You can change or adapt this frequency by adjusting the "ClockDiv" field. The SD Card frequency (SDIO_CK) is computed as follows: SDIO_CK = SDIOCLK / (ClockDiv + 2) In initialization mode and according to the SD Card standard, make sure that the SDIO_CK frequency doesn't exceed 400KHz.
2. Get the SD CID and CSD data. All these information are managed by the SDCardInfo structure. This structure provide also ready computed SD Card capacity and Block size. These information are stored in SD handle structure in case of future use.
3. Configure the SD Card Data transfer frequency. By Default, the card transfer frequency is set to 24MHz. You can change or adapt this frequency by adjusting the "ClockDiv" field. In transfer mode and according to the SD Card standard, make sure that the SDIO_CK frequency doesn't exceed 25MHz and 50MHz in High-speed mode switch. To be able to use a frequency higher than 24MHz, you should use the SDIO peripheral in bypass mode. Refer to the corresponding reference manual for more details.
4. Select the corresponding SD Card according to the address read with the step 2.
5. Configure the SD Card in wide bus mode: 4-bits data.

SD Card Read operation

- You can read from SD card in polling mode by using function HAL_SD_ReadBlocks(). This function support only 512-bytes block length (the block size should be chosen as 512 bytes). You can choose either one block read operation or multiple block read operation by adjusting the "NumberOfBlocks" parameter.
- You can read from SD card in DMA mode by using function HAL_SD_ReadBlocks_DMA(). This function support only 512-bytes block length (the block size should be chosen as 512 bytes). You can choose either one block read operation or multiple block read operation by adjusting the "NumberOfBlocks" parameter. After this, you have to call the function HAL_SD_CheckReadOperation(), to insure that the read transfer is done correctly in both DMA and SD sides.

SD Card Write operation

- You can write to SD card in polling mode by using function HAL_SD_WriteBlocks(). This function support only 512-bytes block length (the block size should be chosen as 512 bytes). You can choose either one block read operation or multiple block read operation by adjusting the "NumberOfBlocks" parameter.

- You can write to SD card in DMA mode by using function `HAL_SD_WriteBlocks_DMA()`. This function support only 512-bytes block length (the block size should be chosen as 512 byte). You can choose either one block read operation or multiple block read operation by adjusting the "NumberOfBlocks" parameter. After this, you have to call the function `HAL_SD_CheckWriteOperation()`, to insure that the write transfer is done correctly in both DMA and SD sides.

SD card status

- At any time, you can check the SD Card status and get the SD card state by using the `HAL_SD_GetStatus()` function. This function checks first if the SD card is still connected and then get the internal SD Card transfer state.
- You can also get the SD card SD Status register by using the `HAL_SD_SendSDStatus()` function.

SD HAL driver macros list



You can refer to the SD HAL driver header file for more useful macros

56.3.2 Initialization and de-initialization functions

This section provides functions allowing to initialize/de-initialize the SD card device to be ready for use.

This section contains the following APIs:

- `HAL_SD_Init()`
- `HAL_SD_DelInit()`
- `HAL_SD_MspInit()`
- `HAL_SD_MspDelInit()`

56.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the data transfer from/to SD card.

This section contains the following APIs:

- `HAL_SD_ReadBlocks()`
- `HAL_SD_WriteBlocks()`
- `HAL_SD_ReadBlocks_DMA()`
- `HAL_SD_WriteBlocks_DMA()`
- `HAL_SD_CheckReadOperation()`
- `HAL_SD_CheckWriteOperation()`
- `HAL_SD_Erase()`
- `HAL_SD_IRQHandler()`
- `HAL_SD_XferCpltCallback()`
- `HAL_SD_XferErrorCallback()`
- `HAL_SD_DMA_RxCpltCallback()`
- `HAL_SD_DMA_RxErrorCallback()`
- `HAL_SD_DMA_TxCpltCallback()`
- `HAL_SD_DMA_TxErrorCallback()`

56.3.4 Peripheral Control functions

This subsection provides a set of functions allowing to control the SD card operations.

This section contains the following APIs:

- [*HAL_SD_Get_CardInfo\(\)*](#)
- [*HAL_SD_WideBusOperation_Config\(\)*](#)
- [*HAL_SD_StopTransfer\(\)*](#)
- [*HAL_SD_HighSpeed\(\)*](#)

56.3.5 Peripheral State functions

This subsection permits to get in runtime the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_SD_SendSDStatus\(\)*](#)
- [*HAL_SD_GetStatus\(\)*](#)
- [*HAL_SD_GetCardStatus\(\)*](#)

56.3.6 HAL_SD_Init

Function Name	<code>HAL_SD_ErrorTypeDef HAL_SD_Init (SD_HandleTypeDef * hsd, HAL_SD_CardInfoTypeDef * SDCardInfo)</code>
Function Description	Initializes the SD card according to the specified parameters in the <code>SD_HandleTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • SDCardInfo: <code>HAL_SD_CardInfoTypeDef</code> structure for SD card information
Return values	<ul style="list-style-type: none"> • HAL SD error state

56.3.7 HAL_SD_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_SD_DeInit (SD_HandleTypeDef * hsd)</code>
Function Description	De-Initializes the SD card.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • HAL status

56.3.8 HAL_SD_MspInit

Function Name	<code>void HAL_SD_MspInit (SD_HandleTypeDef * hsd)</code>
Function Description	Initializes the SD MSP.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • None

56.3.9 HAL_SD_MspDeInit

Function Name	<code>void HAL_SD_MspDeInit (SD_HandleTypeDef * hsd)</code>
Function Description	De-Initialize SD MSP.

Parameters	<ul style="list-style-type: none"> hsd: SD handle
Return values	<ul style="list-style-type: none"> None

56.3.10 HAL_SD_ReadBlocks

Function Name	HAL_SD_ErrorTypeDef HAL_SD_ReadBlocks (SD_HandleTypeDef * hsd, uint32_t * pReadBuffer, uint64_t ReadAddr, uint32_t BlockSize, uint32_t NumberOfBlocks)
Function Description	Reads block(s) from a specified address in a card.
Parameters	<ul style="list-style-type: none"> hsd: SD handle pReadBuffer: pointer to the buffer that will contain the received data ReadAddr: Address from where data is to be read BlockSize: SD card Data block size NumberOfBlocks: Number of SD blocks to read
Return values	<ul style="list-style-type: none"> SD Card error state
Notes	<ul style="list-style-type: none"> BlockSize must be 512 bytes.

56.3.11 HAL_SD_WriteBlocks

Function Name	HAL_SD_ErrorTypeDef HAL_SD_WriteBlocks (SD_HandleTypeDef * hsd, uint32_t * pWriteBuffer, uint64_t WriteAddr, uint32_t BlockSize, uint32_t NumberOfBlocks)
Function Description	Allows to write block(s) to a specified address in a card.
Parameters	<ul style="list-style-type: none"> hsd: SD handle pWriteBuffer: pointer to the buffer that will contain the data to transmit WriteAddr: Address from where data is to be written BlockSize: SD card Data block size NumberOfBlocks: Number of SD blocks to write
Return values	<ul style="list-style-type: none"> SD Card error state
Notes	<ul style="list-style-type: none"> BlockSize must be 512 bytes.

56.3.12 HAL_SD_ReadBlocks_DMA

Function Name	HAL_SD_ErrorTypeDef HAL_SD_ReadBlocks_DMA (SD_HandleTypeDef * hsd, uint32_t * pReadBuffer, uint64_t ReadAddr, uint32_t BlockSize, uint32_t NumberOfBlocks)
Function Description	Reads block(s) from a specified address in a card.
Parameters	<ul style="list-style-type: none"> hsd: SD handle pReadBuffer: Pointer to the buffer that will contain the received data ReadAddr: Address from where data is to be read BlockSize: SD card Data block size NumberOfBlocks: Number of blocks to read.
Return values	<ul style="list-style-type: none"> SD Card error state
Notes	<ul style="list-style-type: none"> This API should be followed by the function

`HAL_SD_CheckReadOperation()` to check the completion of the read process

- `BlockSize` must be 512 bytes.

56.3.13 HAL_SD_WriteBlocks_DMA

Function Name	<code>HAL_SD_ErrorTypeDef HAL_SD_WriteBlocks_DMA (SD_HandleTypeDef * hsd, uint32_t * pWriteBuffer, uint64_t WriteAddr, uint32_t BlockSize, uint32_t NumberOfBlocks)</code>
Function Description	Writes block(s) to a specified address in a card.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • pWriteBuffer: pointer to the buffer that will contain the data to transmit • WriteAddr: Address from where data is to be read • BlockSize: the SD card Data block size • NumberOfBlocks: Number of blocks to write
Return values	<ul style="list-style-type: none"> • SD Card error state
Notes	<ul style="list-style-type: none"> • This API should be followed by the function <code>HAL_SD_CheckWriteOperation()</code> to check the completion of the write process (by SD current status polling). • <code>BlockSize</code> must be 512 bytes.

56.3.14 HAL_SD_CheckReadOperation

Function Name	<code>HAL_SD_ErrorTypeDef HAL_SD_CheckReadOperation (SD_HandleTypeDef * hsd, uint32_t Timeout)</code>
Function Description	This function waits until the SD DMA data read transfer is finished.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • SD Card error state

56.3.15 HAL_SD_CheckWriteOperation

Function Name	<code>HAL_SD_ErrorTypeDef HAL_SD_CheckWriteOperation (SD_HandleTypeDef * hsd, uint32_t Timeout)</code>
Function Description	This function waits until the SD DMA data write transfer is finished.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • SD Card error state

56.3.16 HAL_SD_Erase

Function Name	<code>HAL_SD_ErrorTypeDef HAL_SD_Erase (SD_HandleTypeDef * hsd, uint64_t startaddr, uint64_t endaddr)</code>
Function Description	Erases the specified memory area of the given SD card.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • startaddr: Start byte address

Return values	<ul style="list-style-type: none"> • endaddr: End byte address • SD Card error state
---------------	---

56.3.17 HAL_SD_IRQHandler

Function Name	void HAL_SD_IRQHandler (SD_HandleTypeDef * hsd)
Function Description	This function handles SD card interrupt request.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • None

56.3.18 HAL_SD_XferCpltCallback

Function Name	void HAL_SD_XferCpltCallback (SD_HandleTypeDef * hsd)
Function Description	SD end of transfer callback.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • None

56.3.19 HAL_SD_XferErrorCallback

Function Name	void HAL_SD_XferErrorCallback (SD_HandleTypeDef * hsd)
Function Description	SD Transfer Error callback.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • None

56.3.20 HAL_SD_DMA_RxCpltCallback

Function Name	void HAL_SD_DMA_RxCpltCallback (DMA_HandleTypeDef * hdma)
Function Description	SD Transfer complete Rx callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA module.
Return values	<ul style="list-style-type: none"> • None

56.3.21 HAL_SD_DMA_RxErrorCallback

Function Name	void HAL_SD_DMA_RxErrorCallback (DMA_HandleTypeDef * hdma)
Function Description	SD DMA transfer complete Rx error callback.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA module.
Return values	<ul style="list-style-type: none"> • None

56.3.22 HAL_SD_DMA_TxCpltCallback

Function Name	void HAL_SD_DMA_TxCpltCallback (DMA_HandleTypeDef * hdma)
Function Description	SD Transfer complete Tx callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA module.
Return values	<ul style="list-style-type: none"> • None
56.3.23 HAL_SD_DMA_TxErrorCallback	
Function Name	void HAL_SD_DMA_TxErrorCallback (DMA_HandleTypeDef * hdma)
Function Description	SD DMA transfer complete error Tx callback.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA module.
Return values	<ul style="list-style-type: none"> • None
56.3.24 HAL_SD_Get_CardInfo	
Function Name	HAL_SD_ErrorTypeDef HAL_SD_Get_CardInfo (SD_HandleTypeDef * hsd, HAL_SD_CardInfoTypeDef * pCardInfo)
Function Description	Returns information about specific card.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • pCardInfo: Pointer to a HAL_SD_CardInfoTypeDef structure that contains all SD card information
Return values	<ul style="list-style-type: none"> • SD Card error state
56.3.25 HAL_SD_WideBusOperation_Config	
Function Name	HAL_SD_ErrorTypeDef HAL_SD_WideBusOperation_Config (SD_HandleTypeDef * hsd, uint32_t WideMode)
Function Description	Enables wide bus operation for the requested card if supported by card.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • WideMode: Specifies the SD card wide bus mode This parameter can be one of the following values: SDIO_BUS_WIDE_8B: 8-bit data transfer (Only for MMC) SDIO_BUS_WIDE_4B: 4-bit data transfer SDIO_BUS_WIDE_1B: 1-bit data transfer
Return values	<ul style="list-style-type: none"> • SD Card error state
56.3.26 HAL_SD_StopTransfer	
Function Name	HAL_SD_ErrorTypeDef HAL_SD_StopTransfer (SD_HandleTypeDef * hsd)

Function Description	Aborts an ongoing data transfer.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • SD Card error state

56.3.27 HAL_SD_HighSpeed

Function Name	HAL_SD_ErrorTypeDef HAL_SD_HighSpeed (SD_HandleTypeDef * hsd)
Function Description	Switches the SD card to High Speed mode.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • SD Card error state
Notes	<ul style="list-style-type: none"> • This operation should be followed by the configuration of PLL to have SDIOCK clock between 67 and 75 MHz

56.3.28 HAL_SD_SendSDStatus

Function Name	HAL_SD_ErrorTypeDef HAL_SD_SendSDStatus (SD_HandleTypeDef * hsd, uint32_t * pSDstatus)
Function Description	Returns the current SD card's status.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • pSDstatus: Pointer to the buffer that will contain the SD card status SD Status register)
Return values	<ul style="list-style-type: none"> • SD Card error state

56.3.29 HAL_SD_GetStatus

Function Name	HAL_SD_TransferStateTypeDef HAL_SD_GetStatus (SD_HandleTypeDef * hsd)
Function Description	Gets the current sd card data status.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle
Return values	<ul style="list-style-type: none"> • Data Transfer state

56.3.30 HAL_SD_GetCardStatus

Function Name	HAL_SD_ErrorTypeDef HAL_SD_GetCardStatus (SD_HandleTypeDef * hsd, HAL_SD_CardStatusTypeDef * pCardStatus)
Function Description	Gets the SD card status.
Parameters	<ul style="list-style-type: none"> • hsd: SD handle • pCardStatus: Pointer to the HAL_SD_CardStatusTypeDef structure that will contain the SD card status information
Return values	<ul style="list-style-type: none"> • SD Card error state

56.4 SD Firmware driver defines

56.4.1 SD

SD Exported Constants

SD_CMD_GO_IDLE_STATE	Resets the SD memory card.
SD_CMD_SEND_OP_COND	Sends host capacity support information and activates the card's initialization process.
SD_CMD_ALL_SEND_CID	Asks any card connected to the host to send the CID numbers on the CMD line.
SD_CMD_SET_REL_ADDR	Asks the card to publish a new relative address (RCA).
SD_CMD_SET_DSR	Programs the DSR of all cards.
SD_CMD_SDIO SEN_OP_COND	Sends host capacity support information (HCS) and asks the accessed card to send its operating condition register (OCR) content in the response on the CMD line.
SD_CMD_HS_SWITCH	Checks switchable function (mode 0) and switch card function (mode 1).
SD_CMD_SEL_DESEL_CARD	Selects the card by its own relative address and gets deselected by any other address
SD_CMD_HS_SEND_EXT_CSD	Sends SD Memory Card interface condition, which includes host supply voltage information and asks the card whether card supports voltage.
SD_CMD_SEND_CSD	Addressed card sends its card specific data (CSD) on the CMD line.
SD_CMD_SEND_CID	Addressed card sends its card identification (CID) on the CMD line.
SD_CMD_READ_DAT_UNTIL_STOP	SD card doesn't support it.
SD_CMD_STOP_TRANSMISSION	Forces the card to stop transmission.
SD_CMD_SEND_STATUS	Addressed card sends its

status register.

SD_CMD_HS_BUSTEST_READ	Sends an addressed card into the inactive state.
SD_CMD_GO_INACTIVE_STATE	
SD_CMD_SET_BLOCKLEN	Sets the block length (in bytes for SDSC) for all following block commands (read, write, lock). Default block length is fixed to 512 Bytes. Not effective for SDHS and SDXC.
SD_CMD_READ_SINGLE_BLOCK	Reads single block of size selected by SET_BLOCKLEN in case of SDSC, and a block of fixed 512 bytes in case of SDHC and SDXC.
SD_CMD_READ_MULT_BLOCK	Continuously transfers data blocks from card to host until interrupted by STOP_TRANSMISSION command.
SD_CMD_HS_BUSTEST_WRITE	64 bytes tuning pattern is sent for SDR50 and SDR104.
SD_CMD_WRITE_DAT_UNTIL_STOP	Speed class control command.
SD_CMD_SET_BLOCK_COUNT	Specify block count for CMD18 and CMD25.
SD_CMD_WRITE_SINGLE_BLOCK	Writes single block of size selected by SET_BLOCKLEN in case of SDSC, and a block of fixed 512 bytes in case of SDHC and SDXC.
SD_CMD_WRITE_MULT_BLOCK	Continuously writes blocks of data until a STOP_TRANSMISSION follows.
SD_CMD_PROG_CID	Reserved for manufacturers.
SD_CMD_PROG_CSD	Programming of the programmable bits of the CSD.
SD_CMD_SET_WRITE_PROT	Sets the write protection bit of the addressed group.
SD_CMD_CLR_WRITE_PROT	Clears the write protection bit of the addressed group.

SD_CMD_SEND_WRITE_PROT	Asks the card to send the status of the write protection bits.
SD_CMD_SD_ERASE_GRP_START	Sets the address of the first write block to be erased. (For SD card only).
SD_CMD_SD_ERASE_GRP_END	Sets the address of the last write block of the continuous range to be erased.
SD_CMD_ERASE_GRP_START	Sets the address of the first write block to be erased. Reserved for each command system set by switch function command (CMD6).
SD_CMD_ERASE_GRP_END	Sets the address of the last write block of the continuous range to be erased. Reserved for each command system set by switch function command (CMD6).
SD_CMD_ERASE	Reserved for SD security applications.
SD_CMD_FAST_IO	SD card doesn't support it (Reserved).
SD_CMD_GO_IRQ_STATE	SD card doesn't support it (Reserved).
SD_CMD_LOCK_UNLOCK	Sets/resets the password or lock/unlock the card. The size of the data block is set by the SET_BLOCK_LEN command.
SD_CMD_APP_CMD	Indicates to the card that the next command is an application specific command rather than a standard command.
SD_CMD_GEN_CMD	Used either to transfer a data block to the card or to get a data block from the card for general purpose/application specific commands.
SD_CMD_NO_CMD	
SD_CMD_APP_SD_SET_BUSWIDTH	SDIO_APP_CMD should be sent before sending these commands. (ACMD6) Defines the data bus width

to be used for data transfer.
The allowed data bus widths
are given in SCR register.

SD_CMD_SD_APP_STATUS	(ACMD13) Sends the SD status.
SD_CMD_SD_APP_SEND_NUM_WRITE_BLOCKS	(ACMD22) Sends the number of the written (without errors) write blocks. Responds with 32bit+CRC data block.
SD_CMD_SD_APP_OP_COND	(ACMD41) Sends host capacity support information (HCS) and asks the accessed card to send its operating condition register (OCR) content in the response on the CMD line.
SD_CMD_SD_APP_SET_CLR_CARD_DETECT	(ACMD42) Connects/Disconnects the 50 KOhm pull-up resistor on CD/DAT3 (pin 1) of the card.
SD_CMD_SD_APP_SEND_SCR	Reads the SD Configuration Register (SCR).
SD_CMD_SDIO_RW_DIRECT	For SD I/O card only, reserved for security specification.
SD_CMD_SDIO_RW_EXTENDED	For SD I/O card only, reserved for security specification.
SD_CMD_SD_APP_GET_MKB	SD_CMD_APP_CMD should be sent before sending these commands. For SD card only
SD_CMD_SD_APP_GET_MID	For SD card only
SD_CMD_SD_APP_SET_CER_RN1	For SD card only
SD_CMD_SD_APP_GET_CER_RN2	For SD card only
SD_CMD_SD_APP_SET_CER_RES2	For SD card only
SD_CMD_SD_APP_GET_CER_RES1	For SD card only
SD_CMD_SD_APP_SECURE_READ_MULTIPLE_BLOCK	For SD card only
SD_CMD_SD_APP_SECURE_WRITE_MULTIPLE_BLOCK	For SD card only
SD_CMD_SD_APP_SECURE_ERASE	For SD card only
SD_CMD_SD_APP_CHANGE_SECURE_AREA	For SD card only
SD_CMD_SD_APP_SECURE_WRITE_MKB	For SD card only
STD_CAPACITY_SD_CARD_V1_1	
STD_CAPACITY_SD_CARD_V2_0	

HIGH_CAPACITY_SD_CARD
MULTIMEDIA_CARD
SECURE_DIGITAL_IO_CARD
HIGH_SPEED_MULTIMEDIA_CARD
SECURE_DIGITAL_IO_COMBO_CARD
HIGH_CAPACITY_MMC_CARD

SD Exported Macros

`_HAL_SD_SDIO_ENABLE`

Description:

- Enable the SD device.

Return value:

- None

`_HAL_SD_SDIO_DISABLE`

Description:

- Disable the SD device.

Return value:

- None

`_HAL_SD_SDIO_DMA_ENABLE`

Description:

- Enable the SDIO DMA transfer.

Return value:

- None

`_HAL_SD_SDIO_DMA_DISABLE`

Description:

- Disable the SDIO DMA transfer.

Return value:

- None

`_HAL_SD_SDIO_ENABLE_IT`

Description:

- Enable the SD device interrupt.

Parameters:

- `_HANDLE_`: SD Handle
- `_INTERRUPT_`: specifies the SDIO interrupt sources to be enabled. This parameter can be one or a combination of the following values:
 - `SDIO_IT_CCRCFAIL`: Command response received (CRC check failed) interrupt
 - `SDIO_IT_DCRCFAIL`: Data block sent/received (CRC check failed) interrupt
 - `SDIO_IT_CTIMEOUT`: Command response timeout interrupt
 - `SDIO_IT_DTIMEOUT`: Data timeout interrupt
 - `SDIO_IT_TXUNDERR`: Transmit FIFO underrun error interrupt
 - `SDIO_IT_RXOVERR`: Received FIFO

- overrun error interrupt
- SDIO_IT_CMDREND: Command response received (CRC check passed) interrupt
- SDIO_IT_CMDSENT: Command sent (no response required) interrupt
- SDIO_IT_DATAEND: Data end (data counter, SDIDCOUNT, is zero) interrupt
- SDIO_IT_STBITERR: Start bit not detected on all data signals in wide bus mode interrupt
- SDIO_IT_DBCKEND: Data block sent/received (CRC check passed) interrupt
- SDIO_IT_CMDACT: Command transfer in progress interrupt
- SDIO_IT_TXACT: Data transmit in progress interrupt
- SDIO_IT_RXACT: Data receive in progress interrupt
- SDIO_IT_TXFIFOHE: Transmit FIFO Half Empty interrupt
- SDIO_IT_RXFIFOHF: Receive FIFO Half Full interrupt
- SDIO_IT_TXFIFOF: Transmit FIFO full interrupt
- SDIO_IT_RXFIFOF: Receive FIFO full interrupt
- SDIO_IT_TXFIFOE: Transmit FIFO empty interrupt
- SDIO_IT_RXFIFOE: Receive FIFO empty interrupt
- SDIO_IT_RXDAVL: Data available in transmit FIFO interrupt
- SDIO_IT_RXDAVL: Data available in receive FIFO interrupt
- SDIO_IT_SDIOIT: SD I/O interrupt received interrupt
- SDIO_IT_CEATAEND: CE-ATA command completion signal received for CMD61 interrupt

Return value:

- None

_HAL_SD_SDIO_DISABLE_IT

- Disable the SD device interrupt.

Parameters:

- _HANDLE_: SD Handle
- _INTERRUPT_: specifies the SDIO interrupt sources to be disabled. This parameter can be one or a combination of the following values:
 - SDIO_IT_CCRCFAIL: Command response received (CRC check failed) interrupt
 - SDIO_IT_DCRCFAIL: Data block

- sent/received (CRC check failed) interrupt
- SDIO_IT_CTIMEOUT: Command response timeout interrupt
- SDIO_IT_DTIMEOUT: Data timeout interrupt
- SDIO_IT_TXUNDERR: Transmit FIFO underrun error interrupt
- SDIO_IT_RXOVERR: Received FIFO overrun error interrupt
- SDIO_IT_CMDREND: Command response received (CRC check passed) interrupt
- SDIO_IT_CMDSENT: Command sent (no response required) interrupt
- SDIO_IT_DATAEND: Data end (data counter, SDIDCOUNT, is zero) interrupt
- SDIO_IT_STBITERR: Start bit not detected on all data signals in wide bus mode interrupt
- SDIO_IT_DBCKEND: Data block sent/received (CRC check passed) interrupt
- SDIO_IT_CMDACT: Command transfer in progress interrupt
- SDIO_IT_TXACT: Data transmit in progress interrupt
- SDIO_IT_RXACT: Data receive in progress interrupt
- SDIO_IT_TXFIFOHE: Transmit FIFO Half Empty interrupt
- SDIO_IT_RXFIFOHF: Receive FIFO Half Full interrupt
- SDIO_IT_TXFIFOF: Transmit FIFO full interrupt
- SDIO_IT_RXFIFOF: Receive FIFO full interrupt
- SDIO_IT_TXFIFOE: Transmit FIFO empty interrupt
- SDIO_IT_RXFIFOE: Receive FIFO empty interrupt
- SDIO_IT_TXDavl: Data available in transmit FIFO interrupt
- SDIO_IT_RXDAVL: Data available in receive FIFO interrupt
- SDIO_IT_SDIOIT: SD I/O interrupt received interrupt
- SDIO_IT_CEATAEND: CE-ATA command completion signal received for CMD61 interrupt

Return value:

- None

_HAL_SD_SDIO_GET_FLAG**Description:**

- Check whether the specified SD flag is set or not.

Parameters:

- `__HANDLE__`: SD Handle
- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `SDIO_FLAG_CCRCFAIL`: Command response received (CRC check failed)
 - `SDIO_FLAG_DCRCFAIL`: Data block sent/received (CRC check failed)
 - `SDIO_FLAG_CTIMEOUT`: Command response timeout
 - `SDIO_FLAG_DTIMEOUT`: Data timeout
 - `SDIO_FLAG_TXUNDERR`: Transmit FIFO underrun error
 - `SDIO_FLAG_RXOVERR`: Received FIFO overrun error
 - `SDIO_FLAG_CMDREND`: Command response received (CRC check passed)
 - `SDIO_FLAG_CMDSENT`: Command sent (no response required)
 - `SDIO_FLAG_DATAEND`: Data end (data counter, `SDIDCOUNT`, is zero)
 - `SDIO_FLAG_STBITERR`: Start bit not detected on all data signals in wide bus mode.
 - `SDIO_FLAG_DBCKEND`: Data block sent/received (CRC check passed)
 - `SDIO_FLAG_CMDACT`: Command transfer in progress
 - `SDIO_FLAG_TXACT`: Data transmit in progress
 - `SDIO_FLAG_RXACT`: Data receive in progress
 - `SDIO_FLAG_TXFIFOHE`: Transmit FIFO Half Empty
 - `SDIO_FLAG_RXFIFOHF`: Receive FIFO Half Full
 - `SDIO_FLAG_TXFIFOF`: Transmit FIFO full
 - `SDIO_FLAG_RXFIFOF`: Receive FIFO full
 - `SDIO_FLAG_TXFIFOE`: Transmit FIFO empty
 - `SDIO_FLAG_RXFIFOE`: Receive FIFO empty
 - `SDIO_FLAG_TXDavl`: Data available in transmit FIFO
 - `SDIO_FLAG_RXDavl`: Data available in receive FIFO
 - `SDIO_FLAG_SDIOIT`: SD I/O interrupt received
 - `SDIO_FLAG_CEATAEND`: CE-ATA command completion signal received for CMD61

Return value:

- The: new state of SD FLAG (SET or RESET).

_HAL_SD_SDIO_CLEAR_FLAG**Description:**

- Clear the SD's pending flags.

Parameters:

- HANDLE: SD Handle
- FLAG: specifies the flag to clear. This parameter can be one or a combination of the following values:
 - SDIO_FLAG_CCRCFAIL: Command response received (CRC check failed)
 - SDIO_FLAG_DCRCFAIL: Data block sent/received (CRC check failed)
 - SDIO_FLAG_CTIMEOUT: Command response timeout
 - SDIO_FLAG_DTIMEOUT: Data timeout
 - SDIO_FLAG_TXUNDERR: Transmit FIFO underrun error
 - SDIO_FLAG_RXOVERR: Received FIFO overrun error
 - SDIO_FLAG_CMDREND: Command response received (CRC check passed)
 - SDIO_FLAG_CMDSENT: Command sent (no response required)
 - SDIO_FLAG_DATAEND: Data end (data counter, SDIDCOUNT, is zero)
 - SDIO_FLAG_STBITERR: Start bit not detected on all data signals in wide bus mode
 - SDIO_FLAG_DBCKEND: Data block sent/received (CRC check passed)
 - SDIO_FLAG_SDIOIT: SD I/O interrupt received
 - SDIO_FLAG_CEATAEND: CE-ATA command completion signal received for CMD61

Return value:

- None

_HAL_SD_SDIO_GET_IT**Description:**

- Check whether the specified SD interrupt has occurred or not.

Parameters:

- HANDLE: SD Handle
- INTERRUPT: specifies the SDIO interrupt source to check. This parameter can be one of the following values:
 - SDIO_IT_CCRCFAIL: Command response received (CRC check failed) interrupt
 - SDIO_IT_DCRCFAIL: Data block sent/received (CRC check failed) interrupt

- SDIO_IT_CTIMEOUT: Command response timeout interrupt
- SDIO_IT_DTIMEOUT: Data timeout interrupt
- SDIO_IT_TXUNDERR: Transmit FIFO underrun error interrupt
- SDIO_IT_RXOVERR: Received FIFO overrun error interrupt
- SDIO_IT_CMDREND: Command response received (CRC check passed) interrupt
- SDIO_IT_CMDSENT: Command sent (no response required) interrupt
- SDIO_IT_DATAEND: Data end (data counter, SDIDCOUNT, is zero) interrupt
- SDIO_IT_STBITERR: Start bit not detected on all data signals in wide bus mode interrupt
- SDIO_IT_DBCKEND: Data block sent/received (CRC check passed) interrupt
- SDIO_IT_CMDACT: Command transfer in progress interrupt
- SDIO_IT_TXACT: Data transmit in progress interrupt
- SDIO_IT_RXACT: Data receive in progress interrupt
- SDIO_IT_TXFIFOHE: Transmit FIFO Half Empty interrupt
- SDIO_IT_RXFIFOHF: Receive FIFO Half Full interrupt
- SDIO_IT_TXFIFOF: Transmit FIFO full interrupt
- SDIO_IT_RXFIFOF: Receive FIFO full interrupt
- SDIO_IT_TXFIFOE: Transmit FIFO empty interrupt
- SDIO_IT_RXFIFOE: Receive FIFO empty interrupt
- SDIO_IT_TXDavl: Data available in transmit FIFO interrupt
- SDIO_IT_RXDAVL: Data available in receive FIFO interrupt
- SDIO_IT_SDIOIT: SD I/O interrupt received interrupt
- SDIO_IT_CEATAEND: CE-ATA command completion signal received for CMD61 interrupt

Return value:

- The: new state of SD IT (SET or RESET).

_HAL_SD_SDIO_CLEAR_IT**Description:**

- Clear the SD's interrupt pending bits.

Parameters:

- `__HANDLE__`: SD Handle
- `__INTERRUPT__`: specifies the interrupt pending bit to clear. This parameter can be one or a combination of the following values:
 - `SDIO_IT_CCRCFAIL`: Command response received (CRC check failed) interrupt
 - `SDIO_IT_DCRCFAIL`: Data block sent/received (CRC check failed) interrupt
 - `SDIO_IT_CTIMEOUT`: Command response timeout interrupt
 - `SDIO_IT_DTIMEOUT`: Data timeout interrupt
 - `SDIO_IT_TXUNDERR`: Transmit FIFO underrun error interrupt
 - `SDIO_IT_RXOVERR`: Received FIFO overrun error interrupt
 - `SDIO_IT_CMDREND`: Command response received (CRC check passed) interrupt
 - `SDIO_IT_CMDSENT`: Command sent (no response required) interrupt
 - `SDIO_IT_DATAEND`: Data end (data counter, `SDIO_DCOUNT`, is zero) interrupt
 - `SDIO_IT_STBITERR`: Start bit not detected on all data signals in wide bus mode interrupt
 - `SDIO_IT_SDIOIT`: SD I/O interrupt received interrupt
 - `SDIO_IT_CEATAEND`: CE-ATA command completion signal received for CMD61

Return value:

- None

SD Handle Structure definition

`SD_InitTypeDef`

`SD_TypeDef`

SD Private Defines

`DATA_BLOCK_SIZE`

`SDIO_STATIC_FLAGS`

`SDIO_CMD0TIMEOUT`

`SD_OCR_ADDR_OUT_OF_RANGE`

`SD_OCR_ADDR_MISALIGNED`

`SD_OCR_BLOCK_LEN_ERR`

`SD_OCR_ERASE_SEQ_ERR`

`SD_OCR_BAD_ERASE_PARAM`

`SD_OCR_WRITE_PROT_VIOLATION`

`SD_OCR_LOCK_UNLOCK_FAILED`

SD_OCR_COM_CRC_FAILED
SD_OCR_ILLEGAL_CMD
SD_OCR_CARD_ECC_FAILED
SD_OCR_CC_ERROR
SD_OCR_GENERAL_UNKNOWN_ERROR
SD_OCR_STREAM_READ_UNDERRUN
SD_OCR_STREAM_WRITE_OVERRUN
SD_OCR_CID_CSD_OVERWRITE
SD_OCR_WP_ERASE_SKIP
SD_OCR_CARD_ECC_DISABLED
SD_OCR_ERASE_RESET
SD_OCR_AKE_SEQ_ERROR
SD_OCR_ERRORBITS
SD_R6_GENERAL_UNKNOWN_ERROR
SD_R6_ILLEGAL_CMD
SD_R6_COM_CRC_FAILED
SD_VOLTAGE_WINDOW_SD
SD_HIGH_CAPACITY
SD_STD_CAPACITY
SD_CHECK_PATTERN
SD_MAX_VOLT_TRIAL
SD_ALLZERO
SD_WIDE_BUS_SUPPORT
SD_SINGLE_BUS_SUPPORT
SD_CARD_LOCKED
SD_DATATIMEOUT
SD_0TO7BITS
SD_8TO15BITS
SD_16TO23BITS
SD_24TO31BITS
SD_MAX_DATA_LENGTH
SD_HALFFIFO
SD_HALFFIFOBYTES
SD_CCCC_LOCK_UNLOCK
SD_CCCC_WRITE_PROT
SD_CCCC_ERASE

SD_SDIO_SEND_IF_COND

SDIO_APP_CMD should be sent before
sending these commands.

57 HAL SMARTCARD Generic Driver

57.1 HAL SMARTCARD Generic Driver

57.2 SMARTCARD Firmware driver registers structures

57.2.1 SMARTCARD_InitTypeDef

Data Fields

- *uint32_t BaudRate*
- *uint32_t WordLength*
- *uint32_t StopBits*
- *uint32_t Parity*
- *uint32_t Mode*
- *uint32_t CLKPolarity*
- *uint32_t CLKPhase*
- *uint32_t CLKLastBit*
- *uint32_t Prescaler*
- *uint32_t GuardTime*
- *uint32_t NACKState*

Field Documentation

- ***uint32_t SMARTCARD_InitTypeDef::BaudRate***
This member configures the SmartCard communication baud rate. The baud rate is computed using the following formula:

$$\text{IntegerDivider} = ((\text{PCLKx}) / (8 * (\text{hirda-} > \text{Init.BaudRate})))$$

$$\text{FractionalDivider} = ((\text{IntegerDivider} - ((\text{uint32_t}) \text{ IntegerDivider})) * 8) + 0.5$$
- ***uint32_t SMARTCARD_InitTypeDef::WordLength***
Specifies the number of data bits transmitted or received in a frame. This parameter can be a value of [**SMARTCARD_Word_Length**](#)
- ***uint32_t SMARTCARD_InitTypeDef::StopBits***
Specifies the number of stop bits transmitted. This parameter can be a value of [**SMARTCARD_Stop_Bits**](#)
- ***uint32_t SMARTCARD_InitTypeDef::Parity***
Specifies the parity mode. This parameter can be a value of [**SMARTCARD_Parity**](#)
Note:When parity is enabled, the computed parity is inserted at the MSB position of the transmitted data (9th bit when the word length is set to 9 data bits; 8th bit when the word length is set to 8 data bits).
- ***uint32_t SMARTCARD_InitTypeDef::Mode***
Specifies whether the Receive or Transmit mode is enabled or disabled. This parameter can be a value of [**SMARTCARD_Mode**](#)
- ***uint32_t SMARTCARD_InitTypeDef::CLKPolarity***
Specifies the steady state of the serial clock. This parameter can be a value of [**SMARTCARD_Clock_Polarity**](#)
- ***uint32_t SMARTCARD_InitTypeDef::CLKPhase***
Specifies the clock transition on which the bit capture is made. This parameter can be a value of [**SMARTCARD_Clock_Phase**](#)

- **`uint32_t SMARTCARD_InitTypeDef::CLKLastBit`**
Specifies whether the clock pulse corresponding to the last transmitted data bit (MSB) has to be output on the SCLK pin in synchronous mode. This parameter can be a value of `SMARTCARD_Last_Bit`
- **`uint32_t SMARTCARD_InitTypeDef::Prescaler`**
Specifies the SmartCard Prescaler value used for dividing the system clock to provide the smartcard clock. This parameter can be a value of `SMARTCARD_Prescaler`
- **`uint32_t SMARTCARD_InitTypeDef::GuardTime`**
Specifies the SmartCard Guard Time value in terms of number of baud clocks. The value given in the register (5 significant bits) is multiplied by 2 to give the division factor of the source clock frequency
- **`uint32_t SMARTCARD_InitTypeDef::NACKState`**
Specifies the SmartCard NACK Transmission state. This parameter can be a value of `SMARTCARD_NACK_State`

57.2.2 SMARTCARD_HandleTypeDef

Data Fields

- `USART_TypeDef * Instance`
- `SMARTCARD_InitTypeDef Init`
- `uint8_t * pTxBuffPtr`
- `uint16_t TxXferSize`
- `uint16_t TxXferCount`
- `uint8_t * pRxBuffPtr`
- `uint16_t RxXferSize`
- `uint16_t RxXferCount`
- `DMA_HandleTypeDef * hdmatx`
- `DMA_HandleTypeDef * hdmarx`
- `HAL_LockTypeDef Lock`
- `__IO HAL_SMARTCARD_StateTypeDef State`
- `__IO uint32_t ErrorCode`

Field Documentation

- `USART_TypeDef* SMARTCARD_HandleTypeDef::Instance`
- `SMARTCARD_InitTypeDef SMARTCARD_HandleTypeDef::Init`
- `uint8_t* SMARTCARD_HandleTypeDef::pTxBuffPtr`
- `uint16_t SMARTCARD_HandleTypeDef::TxXferSize`
- `uint16_t SMARTCARD_HandleTypeDef::TxXferCount`
- `uint8_t* SMARTCARD_HandleTypeDef::pRxBuffPtr`
- `uint16_t SMARTCARD_HandleTypeDef::RxXferSize`
- `uint16_t SMARTCARD_HandleTypeDef::RxXferCount`
- `DMA_HandleTypeDef* SMARTCARD_HandleTypeDef::hdmatx`
- `DMA_HandleTypeDef* SMARTCARD_HandleTypeDef::hdmarx`
- `HAL_LockTypeDef SMARTCARD_HandleTypeDef::Lock`
- `__IO HAL_SMARTCARD_StateTypeDef SMARTCARD_HandleTypeDef::State`
- `__IO uint32_t SMARTCARD_HandleTypeDef::ErrorCode`

57.3 SMARTCARD Firmware driver API description

57.3.1 How to use this driver

The SMARTCARD HAL driver can be used as follows:

1. Declare a SMARTCARD_HandleTypeDef handle structure.
2. Initialize the SMARTCARD low level resources by implementing the HAL_SMARTCARD_MspInit() API:
 - a. Enable the USARTx interface clock.
 - b. SMARTCARD pins configuration:
 - Enable the clock for the SMARTCARD GPIOs.
 - Configure these SMARTCARD pins as alternate function pull-up.
 - c. NVIC configuration if you need to use interrupt process (HAL_SMARTCARD_Transmit_IT() and HAL_SMARTCARD_Receive_IT() APIs):
 - Configure the USARTx interrupt priority.
 - Enable the NVIC USART IRQ handle.
 - d. DMA Configuration if you need to use DMA process (HAL_SMARTCARD_Transmit_DMA() and HAL_SMARTCARD_Receive_DMA() APIs):
 - Declare a DMA handle structure for the Tx/Rx stream.
 - Enable the DMAx interface clock.
 - Configure the declared DMA handle structure with the required Tx/Rx parameters.
 - Configure the DMA Tx/Rx Stream.
 - Associate the initialized DMA handle to the SMARTCARD DMA Tx/Rx handle.
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx/Rx Stream.
3. Program the Baud Rate, Word Length , Stop Bit, Parity, Hardware flow control and Mode(Receiver/Transmitter) in the SMARTCARD Init structure.
4. Initialize the SMARTCARD registers by calling the HAL_SMARTCARD_Init() API:
 - These APIs configure also the low level Hardware GPIO, CLOCK, CORTEX...etc by calling the customized HAL_SMARTCARD_MspInit() API.



The specific SMARTCARD interrupts (Transmission complete interrupt, RXNE interrupt and Error Interrupts) will be managed using the macros __HAL_SMARTCARD_ENABLE_IT() and __HAL_SMARTCARD_DISABLE_IT() inside the transmit and receive process.

Three operation modes are available within this driver :

Polling mode IO operation

- Send an amount of data in blocking mode using HAL_SMARTCARD_Transmit()
- Receive an amount of data in blocking mode using HAL_SMARTCARD_Receive()

Interrupt mode IO operation

- Send an amount of data in non blocking mode using HAL_SMARTCARD_Transmit_IT()

- At transmission end of transfer HAL_SMARTCARD_TxCpltCallback is executed and user can add his own code by customization of function pointer
HAL_SMARTCARD_TxCpltCallback
- Receive an amount of data in non blocking mode using
HAL_SMARTCARD_Receive_IT()
- At reception end of transfer HAL_SMARTCARD_RxCpltCallback is executed and user can add his own code by customization of function pointer
HAL_SMARTCARD_RxCpltCallback
- In case of transfer Error, HAL_SMARTCARD_ErrorCallback() function is executed and user can add his own code by customization of function pointer
HAL_SMARTCARD_ErrorCallback

DMA mode IO operation

- Send an amount of data in non blocking mode (DMA) using
HAL_SMARTCARD_Transmit_DMA()
- At transmission end of transfer HAL_SMARTCARD_TxCpltCallback is executed and user can add his own code by customization of function pointer
HAL_SMARTCARD_TxCpltCallback
- Receive an amount of data in non blocking mode (DMA) using
HAL_SMARTCARD_Receive_DMA()
- At reception end of transfer HAL_SMARTCARD_RxCpltCallback is executed and user can add his own code by customization of function pointer
HAL_SMARTCARD_RxCpltCallback
- In case of transfer Error, HAL_SMARTCARD_ErrorCallback() function is executed and user can add his own code by customization of function pointer
HAL_SMARTCARD_ErrorCallback

SMARTCARD HAL driver macros list

Below the list of most used macros in SMARTCARD HAL driver.

- __HAL_SMARTCARD_ENABLE: Enable the SMARTCARD peripheral
- __HAL_SMARTCARD_DISABLE: Disable the SMARTCARD peripheral
- __HAL_SMARTCARD_GET_FLAG : Check whether the specified SMARTCARD flag is set or not
- __HAL_SMARTCARD_CLEAR_FLAG : Clear the specified SMARTCARD pending flag
- __HAL_SMARTCARD_ENABLE_IT: Enable the specified SMARTCARD interrupt
- __HAL_SMARTCARD_DISABLE_IT: Disable the specified SMARTCARD interrupt



You can refer to the SMARTCARD HAL driver header file for more useful macros

57.3.2

Initialization and Configuration functions

This subsection provides a set of functions allowing to initialize the USART in Smartcard mode.

The Smartcard interface is designed to support asynchronous protocol Smartcards as defined in the ISO 7816-3 standard.

The USART can provide a clock to the smartcard through the SCLK output. In smartcard mode, SCLK is not associated to the communication but is simply derived from the internal peripheral input clock through a 5-bit prescaler.

- For the Smartcard mode only these parameters can be configured:
 - Baud Rate
 - Word Length => Should be 9 bits (8 bits + parity)
 - Stop Bit
 - Parity: => Should be enabled (see table below).
 - USART polarity
 - USART phase
 - USART LastBit
 - Receiver/transmitter modes
 - Prescaler
 - GuardTime
 - NACKState: The Smartcard NACK state
- Recommended SmartCard interface configuration to get the Answer to Reset from the Card:
 - Word Length = 9 Bits
 - 1.5 Stop Bit
 - Even parity
 - BaudRate = 12096 baud
 - Tx and Rx enabled

Table 16: USART frame formats

M1 bit	PCE bit	Smartcard frame
1	1	SB 8 bit data PB STB

Please refer to the ISO 7816-3 specification for more details. -@- It is also possible to choose 0.5 stop bit for receiving but it is recommended to use 1.5 stop bits for both transmitting and receiving to avoid switching between the two configurations.

The HAL_SMARTCARD_Init() function follows the USART SmartCard configuration procedure (details for the procedure are available in reference manual (RM0329)).

This section contains the following APIs:

- [**HAL_SMARTCARD_Init\(\)**](#)
- [**HAL_SMARTCARD_DeInit\(\)**](#)
- [**HAL_SMARTCARD_MspInit\(\)**](#)
- [**HAL_SMARTCARD_MspDeInit\(\)**](#)
- [**HAL_SMARTCARD_Reliit\(\)**](#)

57.3.3 IO operation functions

Smartcard is a single wire half duplex communication protocol. The Smartcard interface is designed to support asynchronous protocol Smartcards as defined in the ISO 7816-3 standard. The USART should be configured as: (+) 8 bits plus parity: where M=1 and PCE=1 in the USART_CR1 register (+) 1.5 stop bits when transmitting and receiving: where STOP=11 in the USART_CR2 register.

1. There are two modes of transfer:

- Blocking mode: The communication is performed in polling mode. The HAL status of all data processing is returned by the same function after finishing transfer.
 - Non Blocking mode: The communication is performed using Interrupts or DMA, These APIs return the HAL status. The end of the data processing will be indicated through the dedicated SMARTCARD IRQ when using Interrupt mode or the DMA IRQ when using DMA mode. The HAL_SMARTCARD_TxCpltCallback(), HAL_SMARTCARD_RxCpltCallback() user callbacks will be executed respectively at the end of the Transmit or Receive process The HAL_SMARTCARD_ErrorCallback() user callback will be executed when a communication error is detected
2. Blocking mode APIs are :
 - HAL_SMARTCARD_Transmit()
 - HAL_SMARTCARD_Receive()
 3. Non Blocking mode APIs with Interrupt are :
 - HAL_SMARTCARD_Transmit_IT()
 - HAL_SMARTCARD_Receive_IT()
 - HAL_SMARTCARD_IRQHandler()
 4. Non Blocking mode functions with DMA are :
 - HAL_SMARTCARD_Transmit_DMA()
 - HAL_SMARTCARD_Receive_DMA()
 5. A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - HAL_SMARTCARD_TxCpltCallback()
 - HAL_SMARTCARD_RxCpltCallback()
 - HAL_SMARTCARD_ErrorCallback()

Smartcard is a single wire half duplex communication protocol. The Smartcard interface is designed to support asynchronous protocol Smartcards as defined in the ISO 7816-3 standard. The USART should be configured as:

- 8 bits plus parity: where M=1 and PCE=1 in the USART_CR1 register
- 1.5 stop bits when transmitting and receiving: where STOP=11 in the USART_CR2 register. (#) There are two modes of transfer:
 - Blocking mode: The communication is performed in polling mode. The HAL status of all data processing is returned by the same function after finishing transfer.
 - Non Blocking mode: The communication is performed using Interrupts or DMA, These APIs return the HAL status. The end of the data processing will be indicated through the dedicated SMARTCARD IRQ when using Interrupt mode or the DMA IRQ when using DMA mode. The HAL_SMARTCARD_TxCpltCallback(), HAL_SMARTCARD_RxCpltCallback() user callbacks will be executed respectively at the end of the Transmit or Receive process The HAL_SMARTCARD_ErrorCallback() user callback will be executed when a communication error is detected (#) Blocking mode APIs are :
 - HAL_SMARTCARD_Transmit()
 - HAL_SMARTCARD_Receive() (#) Non Blocking mode APIs with Interrupt are :
 - HAL_SMARTCARD_Transmit_IT()
 - HAL_SMARTCARD_Receive_IT()
 - HAL_SMARTCARD_IRQHandler() (#) Non Blocking mode functions with DMA are :
 - HAL_SMARTCARD_Transmit_DMA()
 - HAL_SMARTCARD_Receive_DMA() (#) A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - HAL_SMARTCARD_TxCpltCallback()
 - HAL_SMARTCARD_RxCpltCallback()

-
- `HAL_SMARTCARD_ErrorCallback()`

This section contains the following APIs:

- `HAL_SMARTCARD_Transmit()`
- `HAL_SMARTCARD_Receive()`
- `HAL_SMARTCARD_Transmit_IT()`
- `HAL_SMARTCARD_Receive_IT()`
- `HAL_SMARTCARD_Transmit_DMA()`
- `HAL_SMARTCARD_Receive_DMA()`
- `HAL_SMARTCARD_IRQHandler()`
- `HAL_SMARTCARD_TxCpltCallback()`
- `HAL_SMARTCARD_RxCpltCallback()`
- `HAL_SMARTCARD_ErrorCallback()`

57.3.4 Peripheral State and Errors functions

This subsection provides a set of functions allowing to control the SmartCard.

- `HAL_SMARTCARD_GetState()` API can be helpful to check in run-time the state of the SmartCard peripheral.
- `HAL_SMARTCARD_GetError()` check in run-time errors that could be occurred during communication.

This section contains the following APIs:

- `HAL_SMARTCARD_GetState()`
- `HAL_SMARTCARD_GetError()`

57.3.5 HAL_SMARTCARD_Init

Function Name	<code>HAL_StatusTypeDef HAL_SMARTCARD_Init(SMARTCARD_HandleTypeDef * hsc)</code>
Function Description	Initializes the SmartCard mode according to the specified parameters in the SMARTCARD_InitTypeDef and create the associated handle .
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • HAL status

57.3.6 HAL_SMARTCARD_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_SMARTCARD_DelInit(SMARTCARD_HandleTypeDef * hsc)</code>
Function Description	Deinitializes the USART SmartCard peripheral.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • HAL status

57.3.7 HAL_SMARTCARD_MspInit

Function Name	<code>void HAL_SMARTCARD_MspInit</code>
---------------	---

(SMARTCARD_HandleTypeDef * hsc)

Function Description	SMARTCARD MSP Init.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • None

57.3.8 HAL_SMARTCARD_MspDelInit

Function Name	void HAL_SMARTCARD_MspDelInit (SMARTCARD_HandleTypeDef * hsc)
Function Description	SMARTCARD MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • None

57.3.9 HAL_SMARTCARD_RelInit

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_RelInit (SMARTCARD_HandleTypeDef * hsc)
Function Description	

57.3.10 HAL_SMARTCARD_Transmit

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_Transmit (SMARTCARD_HandleTypeDef * hsc, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Send an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module. • pData: pointer to data buffer • Size: amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

57.3.11 HAL_SMARTCARD_Receive

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_Receive (SMARTCARD_HandleTypeDef * hsc, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module. • pData: pointer to data buffer • Size: amount of data to be received

- **Timeout:** Timeout duration

Return values • HAL status

57.3.12 HAL_SMARTCARD_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_Transmit_IT (SMARTCARD_HandleTypeDef * hsc, uint8_t * pData, uint16_t Size)
Function Description	Send an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module. • pData: pointer to data buffer • Size: amount of data to be sent
Return values	• HAL status

57.3.13 HAL_SMARTCARD_Receive_IT

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_Receive_IT (SMARTCARD_HandleTypeDef * hsc, uint8_t * pData, uint16_t Size)
Function Description	Receive an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module. • pData: pointer to data buffer • Size: amount of data to be received
Return values	• HAL status

57.3.14 HAL_SMARTCARD_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_Transmit_DMA (SMARTCARD_HandleTypeDef * hsc, uint8_t * pData, uint16_t Size)
Function Description	Send an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module. • pData: pointer to data buffer • Size: amount of data to be sent
Return values	• HAL status

57.3.15 HAL_SMARTCARD_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_SMARTCARD_Receive_DMA (SMARTCARD_HandleTypeDef * hsc, uint8_t * pData, uint16_t Size)
Function Description	Receive an amount of data in non blocking mode.

Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module. • pData: pointer to data buffer • Size: amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When the SMARTCARD parity is enabled (PCE = 1) the data received contain the parity bits.

57.3.16 HAL_SMARTCARD_IRQHandler

Function Name	void HAL_SMARTCARD_IRQHandler(SMARTCARD_HandleTypeDef * hsc)
Function Description	This function handles SMARTCARD interrupt request.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • None

57.3.17 HAL_SMARTCARD_TxCpltCallback

Function Name	void HAL_SMARTCARD_TxCpltCallback(SMARTCARD_HandleTypeDef * hsc)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • None

57.3.18 HAL_SMARTCARD_RxCpltCallback

Function Name	void HAL_SMARTCARD_RxCpltCallback(SMARTCARD_HandleTypeDef * hsc)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> • None

57.3.19 HAL_SMARTCARD_ErrorCallback

Function Name	void HAL_SMARTCARD_ErrorCallback(SMARTCARD_HandleTypeDef * hsc)
Function Description	SMARTCARD error callbacks.
Parameters	<ul style="list-style-type: none"> • hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.

Return values	<ul style="list-style-type: none"> None
---------------	--

57.3.20 HAL_SMARTCARD_GetState

Function Name	HAL_SMARTCARD_StateTypeDef HAL_SMARTCARD_GetState (SMARTCARD_HandleTypeDef * hsc)
Function Description	return the SMARTCARD state
Parameters	<ul style="list-style-type: none"> hsc: pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for SMARTCARD module.
Return values	<ul style="list-style-type: none"> HAL state

57.3.21 HAL_SMARTCARD_GetError

Function Name	uint32_t HAL_SMARTCARD_GetError (SMARTCARD_HandleTypeDef * hsc)
Function Description	Return the SMARTCARD error code.
Parameters	<ul style="list-style-type: none"> hsc: : pointer to a SMARTCARD_HandleTypeDef structure that contains the configuration information for the specified SMARTCARD.
Return values	<ul style="list-style-type: none"> SMARTCARD Error Code

57.4 SMARTCARD Firmware driver defines

57.4.1 SMARTCARD

SMARTCARD Clock Phase

SMARTCARD_PHASE_1EDGE

SMARTCARD_PHASE_2EDGE

SMARTCARD Clock Polarity

SMARTCARD_POLARITY_LOW

SMARTCARD_POLARITY_HIGH

SMARTCARD DMA requests

SMARTCARD_DMAREQ_TX

SMARTCARD_DMAREQ_RX

SMARTCARD Error Code

HAL_SMARTCARD_ERROR_NONE No error

HAL_SMARTCARD_ERROR_PE Parity error

HAL_SMARTCARD_ERROR_NE Noise error

HAL_SMARTCARD_ERROR_FE Frame error

HAL_SMARTCARD_ERROR_ORE Overrun error

HAL_SMARTCARD_ERROR_DMA DMA transfer error

SMARTCARD Exported Macros**`__HAL_SMARTCARD_RESET_HANDLE_STA
TE`****Description:**

- Reset SMARTCARD handle state.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle.

Return value:

- None

`__HAL_SMARTCARD_FLUSH_DRREGISTER`**Description:**

- Flushes the Smartcard DR register.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle.

`__HAL_SMARTCARD_GET_FLAG`**Description:**

- Checks whether the specified Smartcard flag is set or not.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle.
- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `SMARTCARD_FLAG_TXE`: Transmit data register empty flag
 - `SMARTCARD_FLAG_TC`: Transmission Complete flag
 - `SMARTCARD_FLAG_RXNE`: Receive data register not empty flag
 - `SMARTCARD_FLAG_IDLE`: Idle Line detection flag
 - `SMARTCARD_FLAG_ORE`: Overrun Error flag
 - `SMARTCARD_FLAG_NE`: Noise Error flag
 - `SMARTCARD_FLAG_FE`: Framing Error flag
 - `SMARTCARD_FLAG_PE`: Parity Error flag

Return value:

- The new state of `__FLAG__` (TRUE or FALSE).

`__HAL_SMARTCARD_CLEAR_FLAG`**Description:**

- Clears the specified Smartcard

pending flags.

Parameters:

- HANDLE: specifies the SMARTCARD Handle.
- FLAG: specifies the flag to check. This parameter can be any combination of the following values:
 - SMARTCARD_FLAG_TC: Transmission Complete flag.
 - SMARTCARD_FLAG_RXNE: Receive data register not empty flag.

Notes:

- PE (Parity error), FE (Framing error), NE (Noise error) and ORE (Overrun error) flags are cleared by software sequence: a read operation to USART_SR register followed by a read operation to USART_DR register. RXNE flag can be also cleared by a read to the USART_DR register. TC flag can be also cleared by software sequence: a read operation to USART_SR register followed by a write operation to USART_DR register. TXE flag is cleared only by a write to the USART_DR register.

_HAL_SMARTCARD_CLEAR_PEFLAG

Description:

- Clear the SMARTCARD PE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

_HAL_SMARTCARD_CLEAR_FEFLAG

Description:

- Clear the SMARTCARD FE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3,

4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`__HAL_SMARTCARD_CLEAR_NEFLAG`

Description:

- Clear the SMARTCARD NE pending flag.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`__HAL_SMARTCARD_CLEAR_OREFLAG`

Description:

- Clear the SMARTCARD ORE pending flag.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`__HAL_SMARTCARD_CLEAR_IDLEFLAG`

Description:

- Clear the SMARTCARD IDLE pending flag.

Parameters:

- `__HANDLE__`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`__HAL_SMARTCARD_ENABLE_IT`

Description:

- Enables or disables the specified SmartCard interrupts.

Parameters:

- `__HANDLE__`: specifies the

- SMARTCARD Handle.
- __INTERRUPT__: specifies the SMARTCARD interrupt source to check. This parameter can be one of the following values:
 - SMARTCARD_IT_TXE: Transmit Data Register empty interrupt
 - SMARTCARD_IT_TC: Transmission complete interrupt
 - SMARTCARD_IT_RXNE: Receive Data register not empty interrupt
 - SMARTCARD_IT_IDLE: Idle line detection interrupt
 - SMARTCARD_IT_PE: Parity Error interrupt
 - SMARTCARD_IT_ERR: Error interrupt(Frame error, noise error, overrun error)

__HAL_SMARTCARD_DISABLE_IT

__HAL_SMARTCARD_GET_IT_SOURCE

Description:

- Checks whether the specified SmartCard interrupt has occurred or not.

Parameters:

- __HANDLE__: specifies the SmartCard Handle.
- __IT__: specifies the SMARTCARD interrupt source to check. This parameter can be one of the following values:
 - SMARTCARD_IT_TXE: Transmit Data Register empty interrupt
 - SMARTCARD_IT_TC: Transmission complete interrupt
 - SMARTCARD_IT_RXNE: Receive Data register not empty interrupt
 - SMARTCARD_IT_IDLE: Idle line detection interrupt
 - SMARTCARD_IT_ERR: Error interrupt
 - SMARTCARD_IT_PE: Parity Error interrupt

Return value:

- The: new state of __IT__ (TRUE or

FALSE).

`__HAL_SMARTCARD_ONE_BIT_SAMPLE_ENABLE`

Description:

- Macro to enable the SMARTCARD's one bit sample method.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle.

Return value:

- None

`__HAL_SMARTCARD_ONE_BIT_SAMPLE_DISABLE`

Description:

- Macro to disable the SMARTCARD's one bit sample method.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle.

Return value:

- None

`__HAL_SMARTCARD_ENABLE`

Description:

- Enable the USART associated to the SMARTCARD Handle.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle. SMARTCARD Handle selects the USARTx peripheral (USART availability and x value depending on device).

Return value:

- None

`__HAL_SMARTCARD_DISABLE`

Description:

- Disable the USART associated to the SMARTCARD Handle.

Parameters:

- `__HANDLE__`: specifies the SMARTCARD Handle. SMARTCARD Handle selects the USARTx peripheral (USART availability and x value depending on device).

Return value:

- None

`_HAL_SMARTCARD_DMA_REQUEST_ENAB
LE`

Description:

- Macros to enable or disable the SmartCard DMA request.

Parameters:

- `_HANDLE_`: specifies the SmartCard Handle.
- `_REQUEST_`: specifies the SmartCard DMA request. This parameter can be one of the following values:
 - `SMARTCARD_DMAREQ_TX`: SmartCard DMA transmit request
 - `SMARTCARD_DMAREQ_RX`: SmartCard DMA receive request

`_HAL_SMARTCARD_DMA_REQUEST_DISA
BLE`

SMARTCARD Last Bit

`SMARTCARD_LASTBIT_DISABLE`
`SMARTCARD_LASTBIT_ENABLE`

SMARTCARD Mode

`SMARTCARD_MODE_RX`
`SMARTCARD_MODE_TX`
`SMARTCARD_MODE_TX_RX`

SMARTCARD NACK State

`SMARTCARD_NACK_ENABLE`
`SMARTCARD_NACK_DISABLE`

SMARTCARD Parity

`SMARTCARD_PARITY_EVEN`
`SMARTCARD_PARITY_ODD`

SMARTCARD Prescaler

<code>SMARTCARD_PRESCALER_SYSCLK_DIV2</code>	SYSCLK divided by 2
<code>SMARTCARD_PRESCALER_SYSCLK_DIV4</code>	SYSCLK divided by 4
<code>SMARTCARD_PRESCALER_SYSCLK_DIV6</code>	SYSCLK divided by 6
<code>SMARTCARD_PRESCALER_SYSCLK_DIV8</code>	SYSCLK divided by 8
<code>SMARTCARD_PRESCALER_SYSCLK_DIV10</code>	SYSCLK divided by 10
<code>SMARTCARD_PRESCALER_SYSCLK_DIV12</code>	SYSCLK divided by 12
<code>SMARTCARD_PRESCALER_SYSCLK_DIV14</code>	SYSCLK divided by 14
<code>SMARTCARD_PRESCALER_SYSCLK_DIV16</code>	SYSCLK divided by 16

SMARTCARD_PRESCALER_SYSCLK_DIV18	SYSCLK divided by 18
SMARTCARD_PRESCALER_SYSCLK_DIV20	SYSCLK divided by 20
SMARTCARD_PRESCALER_SYSCLK_DIV22	SYSCLK divided by 22
SMARTCARD_PRESCALER_SYSCLK_DIV24	SYSCLK divided by 24
SMARTCARD_PRESCALER_SYSCLK_DIV26	SYSCLK divided by 26
SMARTCARD_PRESCALER_SYSCLK_DIV28	SYSCLK divided by 28
SMARTCARD_PRESCALER_SYSCLK_DIV30	SYSCLK divided by 30
SMARTCARD_PRESCALER_SYSCLK_DIV32	SYSCLK divided by 32
SMARTCARD_PRESCALER_SYSCLK_DIV34	SYSCLK divided by 34
SMARTCARD_PRESCALER_SYSCLK_DIV36	SYSCLK divided by 36
SMARTCARD_PRESCALER_SYSCLK_DIV38	SYSCLK divided by 38
SMARTCARD_PRESCALER_SYSCLK_DIV40	SYSCLK divided by 40
SMARTCARD_PRESCALER_SYSCLK_DIV42	SYSCLK divided by 42
SMARTCARD_PRESCALER_SYSCLK_DIV44	SYSCLK divided by 44
SMARTCARD_PRESCALER_SYSCLK_DIV46	SYSCLK divided by 46
SMARTCARD_PRESCALER_SYSCLK_DIV48	SYSCLK divided by 48
SMARTCARD_PRESCALER_SYSCLK_DIV50	SYSCLK divided by 50
SMARTCARD_PRESCALER_SYSCLK_DIV52	SYSCLK divided by 52
SMARTCARD_PRESCALER_SYSCLK_DIV54	SYSCLK divided by 54
SMARTCARD_PRESCALER_SYSCLK_DIV56	SYSCLK divided by 56
SMARTCARD_PRESCALER_SYSCLK_DIV58	SYSCLK divided by 58
SMARTCARD_PRESCALER_SYSCLK_DIV60	SYSCLK divided by 60
SMARTCARD_PRESCALER_SYSCLK_DIV62	SYSCLK divided by 62

SMARTCARD Private Constants

SMARTCARD_TIMEOUT_VALUE

SMARTCARD_IT_MASK

SMARTCARD_DIV

SMARTCARD_DIVMANT

SMARTCARD_DIVFRAQ

SMARTCARD_BRR

SMARTCARD_CR1_REG_INDEX

SMARTCARD_CR3_REG_INDEX

SMARTCARD Private Macros

IS_SMARTCARD_WORD_LENGTH

IS_SMARTCARD_STOPBITS

IS_SMARTCARD_PARITY

IS_SMARTCARD_MODE
IS_SMARTCARD_POLARITY
IS_SMARTCARD_PHASE
IS_SMARTCARD_LASTBIT
IS_SMARTCARD_NACK_STATE
IS_SMARTCARD_BAUDRATE
SMARTCARD Number of Stop Bits
SMARTCARD_STOPBITS_0_5
SMARTCARD_STOPBITS_1_5
SMARTCARD Word Length
SMARTCARD_WORDLENGTH_9B

58 HAL SPDIFRX Generic Driver

58.1 HAL SPDIFRX Generic Driver

58.2 SPDIFRX Firmware driver registers structures

58.2.1 SPDIFRX_InitTypeDef

Data Fields

- *uint32_t InputSelection*
- *uint32_t Retries*
- *uint32_t WaitForActivity*
- *uint32_t ChannelSelection*
- *uint32_t DataFormat*
- *uint32_t StereoMode*
- *uint32_t PreambleTypeMask*
- *uint32_t ChannelStatusMask*
- *uint32_t ValidityBitMask*
- *uint32_t ParityErrorMask*

Field Documentation

- ***uint32_t SPDIFRX_InitTypeDef::InputSelection***
Specifies the SPDIF input selection. This parameter can be a value of [*SPDIFRX_Input_Selection*](#)
- ***uint32_t SPDIFRX_InitTypeDef::Retries***
Specifies the Maximum allowed re-tries during synchronization phase. This parameter can be a value of [*SPDIFRX_Max_Retries*](#)
- ***uint32_t SPDIFRX_InitTypeDef::WaitForActivity***
Specifies the wait for activity on SPDIF selected input. This parameter can be a value of [*SPDIFRX_Wait_For_Activity*](#).
- ***uint32_t SPDIFRX_InitTypeDef::ChannelSelection***
Specifies whether the control flow will take the channel status from channel A or B. This parameter can be a value of [*SPDIFRX_Channel_Selection*](#)
- ***uint32_t SPDIFRX_InitTypeDef::DataFormat***
Specifies the Data samples format (LSB, MSB, ...). This parameter can be a value of [*SPDIFRX_Data_Format*](#)
- ***uint32_t SPDIFRX_InitTypeDef::StereoMode***
Specifies whether the peripheral is in stereo or mono mode. This parameter can be a value of [*SPDIFRX_Stereo_Mode*](#)
- ***uint32_t SPDIFRX_InitTypeDef::PreambleTypeMask***
Specifies whether The preamble type bits are copied or not into the received frame. This parameter can be a value of [*SPDIFRX_PT_Mask*](#)
- ***uint32_t SPDIFRX_InitTypeDef::ChannelStatusMask***
Specifies whether the channel status and user bits are copied or not into the received frame. This parameter can be a value of [*SPDIFRX_ChannelStatus_Mask*](#)
- ***uint32_t SPDIFRX_InitTypeDef::ValidityBitMask***
Specifies whether the validity bit is copied or not into the received frame. This parameter can be a value of [*SPDIFRX_V_Mask*](#)

- ***uint32_t SPDIFRX_InitTypeDef::ParityErrorMask***
Specifies whether the parity error bit is copied or not into the received frame. This parameter can be a value of [**SPDIFRX_PE_Mask**](#)

58.2.2 SPDIFRX_SetDataFormatTypeDef

Data Fields

- ***uint32_t DataFormat***
- ***uint32_t StereoMode***
- ***uint32_t PreambleTypeMask***
- ***uint32_t ChannelStatusMask***
- ***uint32_t ValidityBitMask***
- ***uint32_t ParityErrorMask***

Field Documentation

- ***uint32_t SPDIFRX_SetDataFormatTypeDef::DataFormat***
Specifies the Data samples format (LSB, MSB, ...). This parameter can be a value of [**SPDIFRX_Data_Format**](#)
- ***uint32_t SPDIFRX_SetDataFormatTypeDef::StereoMode***
Specifies whether the peripheral is in stereo or mono mode. This parameter can be a value of [**SPDIFRX_Stereo_Mode**](#)
- ***uint32_t SPDIFRX_SetDataFormatTypeDef::PreambleTypeMask***
Specifies whether The preamble type bits are copied or not into the received frame. This parameter can be a value of [**SPDIFRX_PT_Mask**](#)
- ***uint32_t SPDIFRX_SetDataFormatTypeDef::ChannelStatusMask***
Specifies whether the channel status and user bits are copied or not into the received frame. This parameter can be a value of [**SPDIFRX_ChannelStatus_Mask**](#)
- ***uint32_t SPDIFRX_SetDataFormatTypeDef::ValidityBitMask***
Specifies whether the validity bit is copied or not into the received frame. This parameter can be a value of [**SPDIFRX_V_Mask**](#)
- ***uint32_t SPDIFRX_SetDataFormatTypeDef::ParityErrorMask***
Specifies whether the parity error bit is copied or not into the received frame. This parameter can be a value of [**SPDIFRX_PE_Mask**](#)

58.2.3 SPDIFRX_HandleTypeDefDef

Data Fields

- ***SPDIFRX_TypeDef * Instance***
- ***SPDIFRX_InitTypeDef Init***
- ***uint32_t * pRxBuffPtr***
- ***uint32_t * pCsBuffPtr***
- ***__IO uint16_t RxXferSize***
- ***__IO uint16_t RxXferCount***
- ***__IO uint16_t CsXferSize***
- ***__IO uint16_t CsXferCount***
- ***DMA_HandleTypeDef * hdmaCsRx***

- `DMA_HandleTypeDef * hdmaDrRx`
- `_IO HAL_LockTypeDef Lock`
- `_IO HAL_SPDIFRX_StateTypeDef State`
- `_IO uint32_t ErrorCode`

Field Documentation

- `SPDIFRX_TypeDef* SPDIFRX_HandleTypeDef::Instance`
- `SPDIFRX_InitTypeDef SPDIFRX_HandleTypeDef::Init`
- `uint32_t* SPDIFRX_HandleTypeDef::pRxBuffPtr`
- `uint32_t* SPDIFRX_HandleTypeDef::pCsBuffPtr`
- `_IO uint16_t SPDIFRX_HandleTypeDef::RxXferSize`
- `_IO uint16_t SPDIFRX_HandleTypeDef::RxXferCount`
- `_IO uint16_t SPDIFRX_HandleTypeDef::CsXferSize`
- `_IO uint16_t SPDIFRX_HandleTypeDef::CsXferCount`
- `DMA_HandleTypeDef* SPDIFRX_HandleTypeDef::hdmaCsRx`
- `DMA_HandleTypeDef* SPDIFRX_HandleTypeDef::hdmaDrRx`
- `_IO HAL_LockTypeDef SPDIFRX_HandleTypeDef::Lock`
- `_IO HAL_SPDIFRX_StateTypeDef SPDIFRX_HandleTypeDef::State`
- `_IO uint32_t SPDIFRX_HandleTypeDef::ErrorCode`

58.3 SPDIFRX Firmware driver API description

58.3.1 How to use this driver

The SPDIFRX HAL driver can be used as follow:

1. Declare SPDIFRX_HandleTypeDef handle structure.
2. Initialize the SPDIFRX low level resources by implement the HAL_SPDIFRX_MspInit() API:
 - a. Enable the SPDIFRX interface clock.
 - b. SPDIFRX pins configuration:
 - Enable the clock for the SPDIFRX GPIOs.
 - Configure these SPDIFRX pins as alternate function pull-up.
 - c. NVIC configuration if you need to use interrupt process (HAL_SPDIFRX_ReceiveControlFlow_IT() and HAL_SPDIFRX_ReceiveDataFlow_IT() API's).
 - Configure the SPDIFRX interrupt priority.
 - Enable the NVIC SPDIFRX IRQ handle.
 - d. DMA Configuration if you need to use DMA process (HAL_SPDIFRX_ReceiveDataFlow_DMA() and HAL_SPDIFRX_ReceiveControlFlow_DMA() API's).
 - Declare a DMA handle structure for the reception of the Data Flow channel.
 - Declare a DMA handle structure for the reception of the Control Flow channel.
 - Enable the DMAx interface clock.
 - Configure the declared DMA handle structure CtrlRx/DataRx with the required parameters.
 - Configure the DMA Channel.
 - Associate the initialized DMA handle to the SPDIFRX DMA CtrlRx/DataRx handle.

- Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA CtrlRx/DataRx channel.
3. Program the input selection, re-tries number, wait for activity, channel status selection, data format, stereo mode and masking of user bits using HAL_SPDIFRX_Init() function. The specific SPDIFRX interrupts (RXNE/CSRNE and Error Interrupts) will be managed using the macros __SPDIFRX_ENABLE_IT() and __SPDIFRX_DISABLE_IT() inside the receive process. Make sure that ck_spdif clock is configured.
 4. Three operation modes are available within this driver :

Polling mode for reception operation (for debug purpose)

- Receive data flow in blocking mode using HAL_SPDIFRX_ReceiveDataFlow()
- Receive control flow of data in blocking mode using HAL_SPDIFRX_ReceiveControlFlow()

Interrupt mode for reception operation

- Receive an amount of data (Data Flow) in non blocking mode using HAL_SPDIFRX_ReceiveDataFlow_IT()
- Receive an amount of data (Control Flow) in non blocking mode using HAL_SPDIFRX_ReceiveControlFlow_IT()
- At reception end of half transfer HAL_SPDIFRX_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_SPDIFRX_RxHalfCpltCallback
- At reception end of transfer HAL_SPDIFRX_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_SPDIFRX_RxCpltCallback
- In case of transfer Error, HAL_SPDIFRX_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_SPDIFRX_ErrorCallback

DMA mode for reception operation

- Receive an amount of data (Data Flow) in non blocking mode (DMA) using HAL_SPDIFRX_ReceiveDataFlow_DMA()
- Receive an amount of data (Control Flow) in non blocking mode (DMA) using HAL_SPDIFRX_ReceiveControlFlow_DMA()
- At reception end of half transfer HAL_SPDIFRX_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_SPDIFRX_RxHalfCpltCallback
- At reception end of transfer HAL_SPDIFRX_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_SPDIFRX_RxCpltCallback
- In case of transfer Error, HAL_SPDIFRX_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_SPDIFRX_ErrorCallback
- Stop the DMA Transfer using HAL_SPDIFRX_DMAStop()

SPDIFRX HAL driver macros list

Below the list of most used macros in USART HAL driver.

- __HAL_SPDIFRX_IDLE: Disable the specified SPDIFRX peripheral (IDLE State)

- `_HAL_SPDIFRX_SYNC`: Enable the synchronization state of the specified SPDIFRX peripheral (SYNC State)
- `_HAL_SPDIFRX_RCV`: Enable the receive state of the specified SPDIFRX peripheral (RCV State)
- `_HAL_SPDIFRX_ENABLE_IT` : Enable the specified SPDIFRX interrupts
- `_HAL_SPDIFRX_DISABLE_IT` : Disable the specified SPDIFRX interrupts
- `_HAL_SPDIFRX_GET_FLAG`: Check whether the specified SPDIFRX flag is set or not.



You can refer to the SPDIFRX HAL driver header file for more useful macros

58.3.2 Initialization and de-initialization functions

This subsection provides a set of functions allowing to initialize and de-initialize the SPDIFRX peripheral:

- User must Implement `HAL_SPDIFRX_MspInit()` function in which he configures all related peripherals resources (CLOCK, GPIO, DMA, IT and NVIC).
- Call the function `HAL_SPDIFRX_Init()` to configure the SPDIFRX peripheral with the selected configuration:
 - Input Selection (IN0, IN1,...)
 - Maximum allowed re-tries during synchronization phase
 - Wait for activity on SPIDF selected input
 - Channel status selection (from channel A or B)
 - Data format (LSB, MSB, ...)
 - Stereo mode
 - User bits masking (PT,C,U,V,...)
- Call the function `HAL_SPDIFRX_DelInit()` to restore the default configuration of the selected SPDIFRXx peripheral.

This section contains the following APIs:

- `HAL_SPDIFRX_Init\(\)`
- `HAL_SPDIFRX_DelInit\(\)`
- `HAL_SPDIFRX_MspInit\(\)`
- `HAL_SPDIFRX_MspDelInit\(\)`
- `HAL_SPDIFRX_SetDataFormat\(\)`

58.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the SPDIFRX data transfers.

1. There is two mode of transfer:
 - Blocking mode : The communication is performed in the polling mode. The status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode : The communication is performed using Interrupts or DMA. These functions return the status of the transfer start-up. The end of the data processing will be indicated through the dedicated SPDIFRX IRQ when using Interrupt mode or the DMA IRQ when using DMA mode.
2. Blocking mode functions are :
 - `HAL_SPDIFRX_ReceiveDataFlow()`

- `HAL_SPDIFRX_ReceiveControlFlow()` (+@) Do not use blocking mode to receive both control and data flow at the same time.
- 3. No-Blocking mode functions with Interrupt are :
 - `HAL_SPDIFRX_ReceiveControlFlow_IT()`
 - `HAL_SPDIFRX_ReceiveDataFlow_IT()`
- 4. No-Blocking mode functions with DMA are :
 - `HAL_SPDIFRX_ReceiveControlFlow_DMA()`
 - `HAL_SPDIFRX_ReceiveDataFlow_DMA()`
- 5. A set of Transfer Complete Callbacks are provided in No_Blocking mode:
 - `HAL_SPDIFRX_RxCpltCallback()`
 - `HAL_SPDIFRX_ErrorCallback()`

This section contains the following APIs:

- `HAL_SPDIFRX_ReceiveDataFlow()`
- `HAL_SPDIFRX_ReceiveControlFlow()`
- `HAL_SPDIFRX_ReceiveDataFlow_IT()`
- `HAL_SPDIFRX_ReceiveControlFlow_IT()`
- `HAL_SPDIFRX_ReceiveDataFlow_DMA()`
- `HAL_SPDIFRX_ReceiveControlFlow_DMA()`
- `HAL_SPDIFRX_DMAStop()`
- `HAL_SPDIFRX_IRQHandler()`
- `HAL_SPDIFRX_RxHalfCpltCallback()`
- `HAL_SPDIFRX_RxCpltCallback()`
- `HAL_SPDIFRX_CxHalfCpltCallback()`
- `HAL_SPDIFRX_CxCpltCallback()`
- `HAL_SPDIFRX_ErrorCallback()`

58.3.4 Peripheral State and Errors functions

This subsection permit to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- `HAL_SPDIFRX_GetState()`
- `HAL_SPDIFRX_GetError()`

58.3.5 HAL_SPDIFRX_Init

Function Name	<code>HAL_StatusTypeDef HAL_SPDIFRX_Init (SPDIFRX_HandleTypeDef * hspdif)</code>
Function Description	Initializes the SPDIFRX according to the specified parameters in the <code>SPDIFRX_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • <code>hspdif</code>: SPDIFRX handle
Return values	<ul style="list-style-type: none"> • HAL status

58.3.6 HAL_SPDIFRX_DeInit

Function Name	<code>HAL_StatusTypeDef HAL_SPDIFRX_DeInit (SPDIFRX_HandleTypeDef * hspdif)</code>
Function Description	Deinitializes the SPDIFRX peripheral.
Parameters	<ul style="list-style-type: none"> • <code>hspdif</code>: SPDIFRX handle
Return values	<ul style="list-style-type: none"> • HAL status

58.3.7 HAL_SPDIFRX_MspInit

Function Name	void HAL_SPDIFRX_MspInit (SPDIFRX_HandleTypeDef * hspdif)
Function Description	SPDIFRX MSP Init.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle
Return values	<ul style="list-style-type: none"> • None

58.3.8 HAL_SPDIFRX_MspDelInit

Function Name	void HAL_SPDIFRX_MspDelInit (SPDIFRX_HandleTypeDef * hspdif)
Function Description	SPDIFRX MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle
Return values	<ul style="list-style-type: none"> • None

58.3.9 HAL_SPDIFRX_SetDataFormat

Function Name	HAL_StatusTypeDef HAL_SPDIFRX_SetDataFormat (SPDIFRX_HandleTypeDef * hspdif, SPDIFRX_SetDataFormatTypeDef sDataFormat)
Function Description	Sets the SPDIFRX data format according to the specified parameters in the SPDIFRX_InitTypeDef.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle • sDataFormat: SPDIFRX data format
Return values	<ul style="list-style-type: none"> • HAL status

58.3.10 HAL_SPDIFRX_ReceiveDataFlow

Function Name	HAL_StatusTypeDef HAL_SPDIFRX_ReceiveDataFlow (SPDIFRX_HandleTypeDef * hspdif, uint32_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receives an amount of data (Data Flow) in blocking mode.
Parameters	<ul style="list-style-type: none"> • hspdif: pointer to SPDIFRX_HandleTypeDef structure that contains the configuration information for SPDIFRX module. • pData: Pointer to data buffer • Size: Amount of data to be received • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

58.3.11 HAL_SPDIFRX_ReceiveControlFlow

Function Name	HAL_StatusTypeDef HAL_SPDIFRX_ReceiveControlFlow (SPDIFRX_HandleTypeDef * hspdif, uint32_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receives an amount of data (Control Flow) in blocking mode.
Parameters	<ul style="list-style-type: none"> • hspdif: pointer to a SPDIFRX_HandleTypeDef structure that

- contains the configuration information for SPDIFRX module.
- **pData:** Pointer to data buffer
 - **Size:** Amount of data to be received
 - **Timeout:** Timeout duration
- Return values**
- HAL status

58.3.12 HAL_SPDIFRX_ReceiveDataFlow_IT

Function Name	<code>HAL_StatusTypeDef HAL_SPDIFRX_ReceiveDataFlow_IT (SPDIFRX_HandleTypeDef * hspdif, uint32_t * pData, uint16_t Size)</code>
Function Description	Receive an amount of data (Data Flow) in non-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle • pData: a 32-bit pointer to the Receive data buffer. • Size: number of data sample to be received .
Return values	<ul style="list-style-type: none"> • HAL status

58.3.13 HAL_SPDIFRX_ReceiveControlFlow_IT

Function Name	<code>HAL_StatusTypeDef HAL_SPDIFRX_ReceiveControlFlow_IT (SPDIFRX_HandleTypeDef * hspdif, uint32_t * pData, uint16_t Size)</code>
Function Description	Receive an amount of data (Control Flow) with Interrupt.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle • pData: a 32-bit pointer to the Receive data buffer. • Size: number of data sample (Control Flow) to be received :
Return values	<ul style="list-style-type: none"> • HAL status

58.3.14 HAL_SPDIFRX_ReceiveDataFlow_DMA

Function Name	<code>HAL_StatusTypeDef HAL_SPDIFRX_ReceiveDataFlow_DMA (SPDIFRX_HandleTypeDef * hspdif, uint32_t * pData, uint16_t Size)</code>
Function Description	Receive an amount of data (Data Flow) mode with DMA.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle • pData: a 32-bit pointer to the Receive data buffer. • Size: number of data sample to be received :
Return values	<ul style="list-style-type: none"> • HAL status

58.3.15 HAL_SPDIFRX_ReceiveControlFlow_DMA

Function Name	<code>HAL_StatusTypeDef HAL_SPDIFRX_ReceiveControlFlow_DMA (SPDIFRX_HandleTypeDef * hspdif, uint32_t * pData, uint16_t Size)</code>
Function Description	Receive an amount of data (Control Flow) with DMA.

Parameters	<ul style="list-style-type: none"> hspdif: SPDIFRX handle pData: a 32-bit pointer to the Receive data buffer. Size: number of data (Control Flow) sample to be received :
Return values	<ul style="list-style-type: none"> HAL status

58.3.16 HAL_SPDIFRX_DMASStop

Function Name **HAL_StatusTypeDef HAL_SPDIFRX_DMASStop (SPDIFRX_HandleTypeDef * hspdif)**

Function Description stop the audio stream receive from the Media.

Parameters

- hspdif:** SPDIFRX handle

Return values

- None

58.3.17 HAL_SPDIFRX_IRQHandler

Function Name **void HAL_SPDIFRX_IRQHandler (SPDIFRX_HandleTypeDef * hspdif)**

Function Description This function handles SPDIFRX interrupt request.

Parameters

- hspdif:** SPDIFRX handle

Return values

- HAL status

58.3.18 HAL_SPDIFRX_RxHalfCpltCallback

Function Name **void HAL_SPDIFRX_RxHalfCpltCallback (SPDIFRX_HandleTypeDef * hspdif)**

Function Description Rx Transfer (Data flow) half completed callbacks.

Parameters

- hspdif:** SPDIFRX handle

Return values

- None

58.3.19 HAL_SPDIFRX_RxCpltCallback

Function Name **void HAL_SPDIFRX_RxCpltCallback (SPDIFRX_HandleTypeDef * hspdif)**

Function Description Rx Transfer (Data flow) completed callbacks.

Parameters

- hspdif:** SPDIFRX handle

Return values

- None

58.3.20 HAL_SPDIFRX_CxHalfCpltCallback

Function Name **void HAL_SPDIFRX_CxHalfCpltCallback (SPDIFRX_HandleTypeDef * hspdif)**

Function Description Rx (Control flow) Transfer half completed callbacks.

Parameters

- hspdif:** SPDIFRX handle

Return values

- None

58.3.21 HAL_SPDIFRX_CxCpltCallback

Function Name	void HAL_SPDIFRX_CxCpltCallback (SPDIFRX_HandleTypeDef * hspdif)
Function Description	Rx Transfer (Control flow) completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle
Return values	<ul style="list-style-type: none"> • None

58.3.22 HAL_SPDIFRX_ErrorCallback

Function Name	void HAL_SPDIFRX_ErrorCallback (SPDIFRX_HandleTypeDef * hspdif)
Function Description	SPDIFRX error callbacks.
Parameters	<ul style="list-style-type: none"> • hspdif: SPDIFRX handle
Return values	<ul style="list-style-type: none"> • None

58.3.23 HAL_SPDIFRX_GetState

Function Name	HAL_SPDIFRX_StateTypeDef HAL_SPDIFRX_GetState (SPDIFRX_HandleTypeDef * hspdif)
Function Description	Return the SPDIFRX state.
Parameters	<ul style="list-style-type: none"> • hspdif: : SPDIFRX handle
Return values	<ul style="list-style-type: none"> • HAL state

58.3.24 HAL_SPDIFRX_GetError

Function Name	uint32_t HAL_SPDIFRX_GetError (SPDIFRX_HandleTypeDef * hspdif)
Function Description	Return the SPDIFRX error code.
Parameters	<ul style="list-style-type: none"> • hspdif: : SPDIFRX handle
Return values	<ul style="list-style-type: none"> • SPDIFRX Error Code

58.4 SPDIFRX Firmware driver defines**58.4.1 SPDIFRX*****SPDIFRX Channel Status Mask***

SPDIFRX_CHANNELSTATUS_OFF

SPDIFRX_CHANNELSTATUS_ON

SPDIFRX Channel Selection

SPDIFRX_CHANNEL_A

SPDIFRX_CHANNEL_B

SPDIFRX Data Format

SPDIFRX_DATAFORMAT_LSB

SPDIFRX_DATAFORMAT_MSB
SPDIFRX_DATAFORMAT_32BITS

SPDIFRX Error Code

HAL_SPDIFRX_ERROR_NONE	No error
HAL_SPDIFRX_ERROR_TIMEOUT	Timeout error
HAL_SPDIFRX_ERROR_OVR	OVR error
HAL_SPDIFRX_ERROR_PE	Parity error
HAL_SPDIFRX_ERROR_DMA	DMA transfer error
HAL_SPDIFRX_ERROR_UNKNOWN	Unknown Error error

SPDIFRX Exported Macros

<code>_HAL_SPDIFRX_RESET_HANDLE_STATE</code>	Description:
	<ul style="list-style-type: none"> • Reset SPDIFRX handle state. Parameters: <ul style="list-style-type: none"> • <code>_HANDLE_</code>: SPDIFRX handle. Return value: <ul style="list-style-type: none"> • None
<code>_HAL_SPDIFRX_IDLE</code>	Description:
	<ul style="list-style-type: none"> • Disable the specified SPDIFRX peripheral (IDLE State). Parameters: <ul style="list-style-type: none"> • <code>_HANDLE_</code>: specifies the SPDIFRX Handle. Return value: <ul style="list-style-type: none"> • None
<code>_HAL_SPDIFRX_SYNC</code>	Description:
	<ul style="list-style-type: none"> • Enable the specified SPDIFRX peripheral (SYNC State). Parameters: <ul style="list-style-type: none"> • <code>_HANDLE_</code>: specifies the SPDIFRX Handle. Return value: <ul style="list-style-type: none"> • None
<code>_HAL_SPDIFRX_RCV</code>	Description:
	<ul style="list-style-type: none"> • Enable the specified SPDIFRX peripheral (RCV State). Parameters: <ul style="list-style-type: none"> • <code>_HANDLE_</code>: specifies the SPDIFRX Handle.

Return value:

- None

`__HAL_SPDIFRX_ENABLE_IT`

- Description:**
- Enable or disable the specified SPDIFRX interrupts.

Parameters:

- `__HANDLE__`: specifies the SPDIFRX Handle.
- `__INTERRUPT__`: specifies the interrupt source to enable or disable. This parameter can be one of the following values:
 - `SPDIFRX_IT_RXNE`
 - `SPDIFRX_IT_CSRNE`
 - `SPDIFRX_IT_PERRIE`
 - `SPDIFRX_IT_OVRIE`
 - `SPDIFRX_IT_SBLKIE`
 - `SPDIFRX_IT_SYNC DIE`
 - `SPDIFRX_IT_IFEIE`

Return value:

- None

`__HAL_SPDIFRX_DISABLE_IT``__HAL_SPDIFRX_GET_IT_SOURCE`**Description:**

- Checks if the specified SPDIFRX interrupt source is enabled or disabled.

Parameters:

- `__HANDLE__`: specifies the SPDIFRX Handle.
- `__INTERRUPT__`: specifies the SPDIFRX interrupt source to check. This parameter can be one of the following values:
 - `SPDIFRX_IT_RXNE`
 - `SPDIFRX_IT_CSRNE`
 - `SPDIFRX_IT_PERRIE`
 - `SPDIFRX_IT_OVRIE`
 - `SPDIFRX_IT_SBLKIE`
 - `SPDIFRX_IT_SYNC DIE`
 - `SPDIFRX_IT_IFEIE`

Return value:

- The new state of `__IT__` (TRUE or FALSE).

`__HAL_SPDIFRX_GET_FLAG`**Description:**

- Checks whether the specified

SPDIFRX flag is set or not.

Parameters:

- __HANDLE__: specifies the SPDIFRX Handle.
- __FLAG__: specifies the flag to check. This parameter can be one of the following values:
 - SPDIFRX_FLAG_RXNE
 - SPDIFRX_FLAG_CSRNE
 - SPDIFRX_FLAG_PERR
 - SPDIFRX_FLAG_OVR
 - SPDIFRX_FLAG_SBD
 - SPDIFRX_FLAG_SYNCD
 - SPDIFRX_FLAG_FERR
 - SPDIFRX_FLAG_SERR
 - SPDIFRX_FLAG_TERR

Return value:

- The new state of __FLAG__ (TRUE or FALSE).

_HAL_SPDIFRX_CLEAR_IT

Description:

- Clears the specified SPDIFRX SR flag, in setting the proper IFCR register bit.

Parameters:

- __HANDLE__: specifies the USART Handle.
- __IT_CLEAR__: specifies the interrupt clear register flag that needs to be set to clear the corresponding interrupt. This parameter can be one of the following values:
 - SPDIFRX_FLAG_PERR
 - SPDIFRX_FLAG_OVR
 - SPDIFRX_SR_SBD
 - SPDIFRX_SR_SYNCD

Return value:

- None

SPDIFRX Flags Definition

SPDIFRX_FLAG_RXNE
 SPDIFRX_FLAG_CSRNE
 SPDIFRX_FLAG_PERR
 SPDIFRX_FLAG_OVR
 SPDIFRX_FLAG_SBD
 SPDIFRX_FLAG_SYNCD

SPDIFRX_FLAG_FERR
SPDIFRX_FLAG_SERR
SPDIFRX_FLAG_TERR
SPDIFRX Input Selection
SPDIFRX_INPUT_IN0
SPDIFRX_INPUT_IN1
SPDIFRX_INPUT_IN2
SPDIFRX_INPUT_IN3
SPDIFRX Interrupts Definition
SPDIFRX_IT_RXNE
SPDIFRX_IT_CSRNE
SPDIFRX_IT_PERRIE
SPDIFRX_IT_OVRIE
SPDIFRX_IT_SBLKIE
SPDIFRX_IT_SYNC DIE
SPDIFRX_IT_IFEIE
SPDIFRX Maximum Retries
SPDIFRX_MAXRETRIES_NONE
SPDIFRX_MAXRETRIES_3
SPDIFRX_MAXRETRIES_15
SPDIFRX_MAXRETRIES_63
SPDIFRX Parity Error Mask
SPDIFRX_PARITYERRORMASK_OFF
SPDIFRX_PARITYERRORMASK_ON
SPDIFRX Private Macros
IS_SPDIFRX_INPUT_SELECT
IS_SPDIFRX_MAX_RETRIES
IS_SPDIFRX_WAIT_FOR_ACTIVITY
IS_PREAMBLE_TYPE_MASK
IS_VALIDITY_MASK
IS_PARITY_ERROR_MASK
IS_SPDIFRX_CHANNEL
IS_SPDIFRX_DATA_FORMAT
IS_STEREO_MODE
IS_CHANNEL_STATUS_MASK
SPDIFRX Preamble Type Mask

SPDIFRX_PREAMBLETYPEMASK_OFF

SPDIFRX_PREAMBLETYPEMASK_ON

SPDIFRX State

SPDIFRX_STATE_IDLE

SPDIFRX_STATE_SYNC

SPDIFRX_STATE_RCV

SPDIFRX Stereo Mode

SPDIFRX_STEREOMODE_DISABLE

SPDIFRX_STEREOMODE_ENABLE

SPDIFRX Validity Mask

SPDIFRX_VALIDITYMASK_OFF

SPDIFRX_VALIDITYMASK_ON

SPDIFRX Wait For Activity

SPDIFRX_WAITFORACTIVITY_OFF

SPDIFRX_WAITFORACTIVITY_ON

59 HAL SPI Generic Driver

59.1 HAL SPI Generic Driver

59.2 SPI Firmware driver registers structures

59.2.1 SPI_InitTypeDef

Data Fields

- *uint32_t Mode*
- *uint32_t Direction*
- *uint32_t DataSize*
- *uint32_t CLKPolarity*
- *uint32_t CLKPhase*
- *uint32_t NSS*
- *uint32_t BaudRatePrescaler*
- *uint32_t FirstBit*
- *uint32_t TIMode*
- *uint32_t CRCCalculation*
- *uint32_t CRCPolynomial*

Field Documentation

- ***uint32_t SPI_InitTypeDef::Mode***
Specifies the SPI operating mode. This parameter can be a value of [**SPI_mode**](#)
- ***uint32_t SPI_InitTypeDef::Direction***
Specifies the SPI Directional mode state. This parameter can be a value of [**SPI_Direction_mode**](#)
- ***uint32_t SPI_InitTypeDef::DataSize***
Specifies the SPI data size. This parameter can be a value of [**SPI_data_size**](#)
- ***uint32_t SPI_InitTypeDef::CLKPolarity***
Specifies the serial clock steady state. This parameter can be a value of [**SPI_Clock_Polarity**](#)
- ***uint32_t SPI_InitTypeDef::CLKPhase***
Specifies the clock active edge for the bit capture. This parameter can be a value of [**SPI_Clock_Phase**](#)
- ***uint32_t SPI_InitTypeDef::NSS***
Specifies whether the NSS signal is managed by hardware (NSS pin) or by software using the SSI bit. This parameter can be a value of [**SPI_Slave_Select_management**](#)
- ***uint32_t SPI_InitTypeDef::BaudRatePrescaler***
Specifies the Baud Rate prescaler value which will be used to configure the transmit and receive SCK clock. This parameter can be a value of [**SPI_BaudRate_Prescaler**](#)
Note:The communication clock is derived from the master clock. The slave clock does not need to be set
- ***uint32_t SPI_InitTypeDef::FirstBit***
Specifies whether data transfers start from MSB or LSB bit. This parameter can be a value of [**SPI_MSB_LSB_transmission**](#)

- ***uint32_t SPI_InitTypeDef::TIMode***
Specifies if the TI mode is enabled or not. This parameter can be a value of ***SPI_TIMode***
- ***uint32_t SPI_InitTypeDef::CRCCalculation***
Specifies if the CRC calculation is enabled or not. This parameter can be a value of ***SPI_CRC_Calculation***
- ***uint32_t SPI_InitTypeDef::CRCPolynomial***
Specifies the polynomial used for the CRC calculation. This parameter must be a number between Min_Data = 0 and Max_Data = 65535

59.2.2 __SPI_HandleTypeDef

Data Fields

- ***SPI_TypeDef * Instance***
- ***SPI_InitTypeDef Init***
- ***uint8_t * pTxBuffPtr***
- ***uint16_t TxXferSize***
- ***uint16_t TxXferCount***
- ***uint8_t * pRxBuffPtr***
- ***uint16_t RxXferSize***
- ***uint16_t RxXferCount***
- ***DMA_HandleTypeDef * hdmatx***
- ***DMA_HandleTypeDef * hdmarx***
- ***void(* RxISR***
- ***void(* TxISR***
- ***HAL_LockTypeDef Lock***
- ***__IO HAL_SPI_StateTypeDef State***
- ***__IO uint32_t ErrorCode***

Field Documentation

- ***SPI_TypeDef* __SPI_HandleTypeDef::Instance***
- ***SPI_InitTypeDef __SPI_HandleTypeDef::Init***
- ***uint8_t* __SPI_HandleTypeDef::pTxBuffPtr***
- ***uint16_t __SPI_HandleTypeDef::TxXferSize***
- ***uint16_t __SPI_HandleTypeDef::TxXferCount***
- ***uint8_t* __SPI_HandleTypeDef::pRxBuffPtr***
- ***uint16_t __SPI_HandleTypeDef::RxXferSize***
- ***uint16_t __SPI_HandleTypeDef::RxXferCount***
- ***DMA_HandleTypeDef* __SPI_HandleTypeDef::hdmatx***
- ***DMA_HandleTypeDef* __SPI_HandleTypeDef::hdmarx***
- ***void(* __SPI_HandleTypeDef::RxISR)(struct __SPI_HandleTypeDef *hspi)***
- ***void(* __SPI_HandleTypeDef::TxISR)(struct __SPI_HandleTypeDef *hspi)***
- ***HAL_LockTypeDef __SPI_HandleTypeDef::Lock***
- ***__IO HAL_SPI_StateTypeDef __SPI_HandleTypeDef::State***
- ***__IO uint32_t __SPI_HandleTypeDef::ErrorCode***

59.3 SPI Firmware driver API description

59.3.1 How to use this driver

The SPI HAL driver can be used as follows:

1. Declare a SPI_HandleTypeDef handle structure, for example: SPI_HandleTypeDef hspi;
2. Initialize the SPI low level resources by implementing the HAL_SPI_MspInit ()API:
 - a. Enable the SPIx interface clock
 - b. SPI pins configuration
 - Enable the clock for the SPI GPIOs
 - Configure these SPI pins as alternate function push-pull
 - c. NVIC configuration if you need to use interrupt process
 - Configure the SPIx interrupt priority
 - Enable the NVIC SPI IRQ handle
 - d. DMA Configuration if you need to use DMA process
 - Declare a DMA_HandleTypeDef handle structure for the transmit or receive stream
 - Enable the DMAx interface clock using
 - Configure the DMA handle parameters
 - Configure the DMA Tx or Rx Stream
 - Associate the initialized hdma_tx handle to the hspi DMA Tx or Rx handle
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx or Rx Stream
3. Program the Mode, Direction , Data size, Baudrate Prescaler, NSS management, Clock polarity and phase, FirstBit and CRC configuration in the hspi Init structure.
4. Initialize the SPI registers by calling the HAL_SPI_Init() API:
 - This API configures also the low level Hardware GPIO, CLOCK, CORTEX...etc by calling the customized HAL_SPI_MspInit() API.

Circular mode restriction:

1. The DMA circular mode cannot be used when the SPI is configured in these modes:
 - a. Master 2Lines RxOnly
 - b. Master 1Line Rx
2. The CRC feature is not managed when the DMA circular mode is enabled
3. When the SPI DMA Pause/Stop features are used, we must use the following APIs the HAL_SPI_DMAPause()/ HAL_SPI_DMAStop() only under the SPI callbacks

59.3.2 Initialization and de-initialization functions

This subsection provides a set of functions allowing to initialize and de-initialize the SPIx peripheral:

- User must implement HAL_SPI_MspInit() function in which he configures all related peripherals resources (CLOCK, GPIO, DMA, IT and NVIC).
- Call the function HAL_SPI_Init() to configure the selected device with the selected configuration:
 - Mode
 - Direction
 - Data Size
 - Clock Polarity and Phase
 - NSS Management
 - BaudRate Prescaler
 - FirstBit
 - TIMode

- CRC Calculation
- CRC Polynomial if CRC enabled
- Call the function HAL_SPI_DeInit() to restore the default configuration of the selected SPIx peripheral.

This section contains the following APIs:

- [*HAL_SPI_Init\(\)*](#)
- [*HAL_SPI_DeInit\(\)*](#)
- [*HAL_SPI_MspInit\(\)*](#)
- [*HAL_SPI_MspDeInit\(\)*](#)

59.3.3 IO operation functions

The SPI supports master and slave mode :

1. There are two modes of transfer:
 - Blocking mode: The communication is performed in polling mode. The HAL status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode: The communication is performed using Interrupts or DMA, These APIs return the HAL status. The end of the data processing will be indicated through the dedicated SPI IRQ when using Interrupt mode or the DMA IRQ when using DMA mode. The HAL_SPI_TxCpltCallback(), HAL_SPI_RxCpltCallback() and HAL_SPI_TxRx_CpltCallback() user callbacks will be executed respectively at the end of the transmit or Receive process The HAL_SPI_ErrorCallback() user callback will be executed when a communication error is detected
2. APIs provided for these 2 transfer modes (Blocking mode or Non blocking mode using either Interrupt or DMA) exist for 1Line (simplex) and 2Lines (full duplex) modes.

This section contains the following APIs:

- [*HAL_SPI_Transmit\(\)*](#)
- [*HAL_SPI_Receive\(\)*](#)
- [*HAL_SPI_TransmitReceive\(\)*](#)
- [*HAL_SPI_Transmit_IT\(\)*](#)
- [*HAL_SPI_Receive_IT\(\)*](#)
- [*HAL_SPI_TransmitReceive_IT\(\)*](#)
- [*HAL_SPI_Transmit_DMA\(\)*](#)
- [*HAL_SPI_Receive_DMA\(\)*](#)
- [*HAL_SPI_TransmitReceive_DMA\(\)*](#)
- [*HAL_SPI_DMAPause\(\)*](#)
- [*HAL_SPI_DMAResume\(\)*](#)
- [*HAL_SPI_DMAStop\(\)*](#)
- [*HAL_SPI_IRQHandler\(\)*](#)
- [*HAL_SPI_TxCpltCallback\(\)*](#)
- [*HAL_SPI_RxCpltCallback\(\)*](#)
- [*HAL_SPI_TxRx_CpltCallback\(\)*](#)
- [*HAL_SPI_TxHalfCpltCallback\(\)*](#)
- [*HAL_SPI_RxHalfCpltCallback\(\)*](#)
- [*HAL_SPI_TxRxHalfCpltCallback\(\)*](#)
- [*HAL_SPI_ErrorCallback\(\)*](#)

59.3.4 Peripheral State and Errors functions

This subsection provides a set of functions allowing to control the SPI.

- HAL_SPI_GetState() API can be helpful to check in run-time the state of the SPI peripheral
- HAL_SPI_GetError() check in run-time Errors occurring during communication

This section contains the following APIs:

- [**HAL_SPI_GetState\(\)**](#)
- [**HAL_SPI_GetError\(\)**](#)

59.3.5 HAL_SPI_Init

Function Name	HAL_StatusTypeDef HAL_SPI_Init (SPI_HandleTypeDef * hspi)
Function Description	Initializes the SPI according to the specified parameters in the SPI_InitTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • HAL status

59.3.6 HAL_SPI_DeInit

Function Name	HAL_StatusTypeDef HAL_SPI_DeInit (SPI_HandleTypeDef * hspi)
Function Description	DeInitializes the SPI peripheral.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • HAL status

59.3.7 HAL_SPI_MspInit

Function Name	void HAL_SPI_MspInit (SPI_HandleTypeDef * hspi)
Function Description	SPI MSP Init.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.8 HAL_SPI_MspDeInit

Function Name	void HAL_SPI_MspDeInit (SPI_HandleTypeDef * hspi)
Function Description	SPI MSP DeInit.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.9 HAL_SPI_Transmit

Function Name	HAL_StatusTypeDef HAL_SPI_Transmit (SPI_HandleTypeDef * hspi, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Transmit an amount of data in blocking mode.

Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. pData: pointer to data buffer Size: amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

59.3.10 HAL_SPI_Receive

Function Name	HAL_StatusTypeDef HAL_SPI_Receive (SPI_HandleTypeDef * hspi, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. pData: pointer to data buffer Size: amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

59.3.11 HAL_SPI_TransmitReceive

Function Name	HAL_StatusTypeDef HAL_SPI_TransmitReceive (SPI_HandleTypeDef * hspi, uint8_t * pTxData, uint8_t * pRxData, uint16_t Size, uint32_t Timeout)
Function Description	Transmit and Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. pTxData: pointer to transmission data buffer pRxData: pointer to reception data buffer to be Size: amount of data to be sent Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> HAL status

59.3.12 HAL_SPI_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_SPI_Transmit_IT (SPI_HandleTypeDef * hspi, uint8_t * pData, uint16_t Size)
Function Description	Transmit an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. pData: pointer to data buffer Size: amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status

59.3.13 HAL_SPI_Receive_IT

Function Name	HAL_StatusTypeDef HAL_SPI_Receive_IT (SPI_HandleTypeDef * hspi, uint8_t * pData, uint16_t Size)
---------------	--

Function Description	Receive an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. • pData: pointer to data buffer • Size: amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

59.3.14 HAL_SPI_TransmitReceive_IT

Function Name	HAL_StatusTypeDef HAL_SPI_TransmitReceive_IT(SPI_HandleTypeDef * hspi, uint8_t * pTxData, uint8_t * pRxData, uint16_t Size)
Function Description	Transmit and Receive an amount of data in no-blocking mode with Interrupt.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. • pTxData: pointer to transmission data buffer • pRxData: pointer to reception data buffer to be • Size: amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

59.3.15 HAL_SPI_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_SPI_Transmit_DMA(SPI_HandleTypeDef * hspi, uint8_t * pData, uint16_t Size)
Function Description	Transmit an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. • pData: pointer to data buffer • Size: amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

59.3.16 HAL_SPI_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_SPI_Receive_DMA(SPI_HandleTypeDef * hspi, uint8_t * pData, uint16_t Size)
Function Description	Receive an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. • pData: pointer to data buffer • Size: amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When the CRC feature is enabled the pData Length must be Size + 1.

59.3.17 HAL_SPI_TransmitReceive_DMA

Function Name	HAL_StatusTypeDef HAL_SPI_TransmitReceive_DMA (SPI_HandleTypeDef * hspi, uint8_t * pTxData, uint8_t * pRxData, uint16_t Size)
Function Description	Transmit and Receive an amount of data in no-blocking mode with DMA.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module. pTxData: pointer to transmission data buffer pRxData: pointer to reception data buffer Size: amount of data to be sent
Return values	<ul style="list-style-type: none"> HAL status
Notes	<ul style="list-style-type: none"> When the CRC feature is enabled the pRxData Length must be Size + 1

59.3.18 HAL_SPI_DMAPause

Function Name	HAL_StatusTypeDef HAL_SPI_DMAPause (SPI_HandleTypeDef * hspi)
Function Description	Pauses the DMA Transfer.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for the specified SPI module.
Return values	<ul style="list-style-type: none"> HAL status

59.3.19 HAL_SPI_DMAResume

Function Name	HAL_StatusTypeDef HAL_SPI_DMAResume (SPI_HandleTypeDef * hspi)
Function Description	Resumes the DMA Transfer.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for the specified SPI module.
Return values	<ul style="list-style-type: none"> HAL status

59.3.20 HAL_SPI_DMAStop

Function Name	HAL_StatusTypeDef HAL_SPI_DMAStop (SPI_HandleTypeDef * hspi)
Function Description	Stops the DMA Transfer.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for the specified SPI module.
Return values	<ul style="list-style-type: none"> HAL status

59.3.21 HAL_SPI_IRQHandler

Function Name	void HAL_SPI_IRQHandler (SPI_HandleTypeDef * hspi)
Function Description	This function handles SPI interrupt request.
Parameters	<ul style="list-style-type: none"> hspi: pointer to a SPI_HandleTypeDef structure that contains

the configuration information for SPI module.

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

59.3.22 HAL_SPI_TxCpltCallback

Function Name	void HAL_SPI_TxCpltCallback (SPI_HandleTypeDef * hspi)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.23 HAL_SPI_RxCpltCallback

Function Name	void HAL_SPI_RxCpltCallback (SPI_HandleTypeDef * hspi)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.24 HAL_SPI_TxRxCpltCallback

Function Name	void HAL_SPI_TxRxCpltCallback (SPI_HandleTypeDef * hspi)
Function Description	Tx and Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.25 HAL_SPI_TxHalfCpltCallback

Function Name	void HAL_SPI_TxHalfCpltCallback (SPI_HandleTypeDef * hspi)
Function Description	Tx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.26 HAL_SPI_RxHalfCpltCallback

Function Name	void HAL_SPI_RxHalfCpltCallback (SPI_HandleTypeDef * hspi)
Function Description	Rx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.27 HAL_SPI_TxRxHalfCpltCallback

Function Name	void HAL_SPI_TxRxHalfCpltCallback (SPI_HandleTypeDef * hspi)
Function Description	Tx and Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.28 HAL_SPI_ErrorCallback

Function Name	void HAL_SPI_ErrorCallback (SPI_HandleTypeDef * hspi)
Function Description	SPI error callbacks.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • None

59.3.29 HAL_SPI_GetState

Function Name	HAL_SPI_StateTypeDef HAL_SPI_GetState (SPI_HandleTypeDef * hspi)
Function Description	Return the SPI state.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • HAL state

59.3.30 HAL_SPI_GetError

Function Name	uint32_t HAL_SPI_GetError (SPI_HandleTypeDef * hspi)
Function Description	Return the SPI error code.
Parameters	<ul style="list-style-type: none"> • hspi: pointer to a SPI_HandleTypeDef structure that contains the configuration information for SPI module.
Return values	<ul style="list-style-type: none"> • SPI Error Code

59.4 SPI Firmware driver defines

59.4.1 SPI

SPI BaudRate Prescaler

SPI_BAUDRATEPRESCALER_2
 SPI_BAUDRATEPRESCALER_4
 SPI_BAUDRATEPRESCALER_8
 SPI_BAUDRATEPRESCALER_16
 SPI_BAUDRATEPRESCALER_32
 SPI_BAUDRATEPRESCALER_64
 SPI_BAUDRATEPRESCALER_128

SPI_BAUDRATEPRESCALER_256

SPI Clock Phase

SPI_PHASE_1EDGE

SPI_PHASE_2EDGE

SPI Clock Polarity

SPI_POLARITY_LOW

SPI_POLARITY_HIGH

SPI CRC Calculation

SPI_CRCCALCULATION_DISABLE

SPI_CRCCALCULATION_ENABLE

SPI Data Size

SPI_DATASIZE_8BIT

SPI_DATASIZE_16BIT

SPI Direction Mode

SPI_DIRECTION_2LINES

SPI_DIRECTION_2LINES_RXONLY

SPI_DIRECTION_1LINE

SPI Error Code

HAL_SPI_ERROR_NONE No error

HAL_SPI_ERROR_MODF MODF error

HAL_SPI_ERROR_CRC CRC error

HAL_SPI_ERROR_OVR OVR error

HAL_SPI_ERROR_FRE FRE error

HAL_SPI_ERROR_DMA DMA transfer error

HAL_SPI_ERROR_FLAG Flag: RXNE,TXE, BSY

SPI Exported Macros

`_HAL_SPI_RESET_HANDLE_STATE` **Description:**

- Reset SPI handle state.

Parameters:

- `_HANDLE_`: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.

Return value:

- None

`_HAL_SPI_ENABLE_IT`

Description:

- Enable or disable the specified SPI interrupts.

Parameters:

- HANDLE: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.
- INTERRUPT: specifies the interrupt source to enable or disable. This parameter can be one of the following values:
 - SPI_IT_TXE: Tx buffer empty interrupt enable
 - SPI_IT_RXNE: RX buffer not empty interrupt enable
 - SPI_IT_ERR: Error interrupt enable

Return value:

- None

_HAL_SPI_DISABLE_IT
_HAL_SPI_GET_IT_SOURCE

Description:

- Check if the specified SPI interrupt source is enabled or disabled.

Parameters:

- HANDLE: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.
- INTERRUPT: specifies the SPI interrupt source to check. This parameter can be one of the following values:
 - SPI_IT_TXE: Tx buffer empty interrupt enable
 - SPI_IT_RXNE: RX buffer not empty interrupt enable
 - SPI_IT_ERR: Error interrupt enable

Return value:

- The: new state of IT (TRUE or FALSE).

_HAL_SPI_GET_FLAG

Description:

- Check whether the specified SPI flag is set or not.

Parameters:

- HANDLE: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.
- FLAG: specifies the flag to check. This parameter can be one of the following values:
 - SPI_FLAG_RXNE: Receive buffer not empty flag
 - SPI_FLAG_TXE: Transmit buffer empty flag
 - SPI_FLAG_CRCERR: CRC error flag

- SPI_FLAG_MODF: Mode fault flag
- SPI_FLAG_OVR: Overrun flag
- SPI_FLAG_BSY: Busy flag
- SPI_FLAG_FRE: Frame format error flag

Return value:

- The: new state of __FLAG__ (TRUE or FALSE).

[__HAL_SPI_CLEAR_CRCERRFLAG](#)**Description:**

- Clear the SPI CRCERR pending flag.

Parameters:

- __HANDLE__: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.

Return value:

- None

[__HAL_SPI_CLEAR_MODFFLAG](#)**Description:**

- Clear the SPI MODF pending flag.

Parameters:

- __HANDLE__: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.

Return value:

- None

[__HAL_SPI_CLEAR_OVRFAG](#)**Description:**

- Clear the SPI OVR pending flag.

Parameters:

- __HANDLE__: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.

Return value:

- None

[__HAL_SPI_CLEAR_FREFLAG](#)**Description:**

- Clear the SPI FRE pending flag.

Parameters:

- __HANDLE__: specifies the SPI handle. This parameter can be SPI where x: 1, 2, or 3 to select the SPI peripheral.

Return value:

- None

<code>_HAL_SPI_ENABLE</code>	Description: <ul style="list-style-type: none">• Enable SPI. Parameters: <ul style="list-style-type: none">• <code>_HANDLE_</code>: specifies the SPI Handle. Return value: <ul style="list-style-type: none">• None
<code>_HAL_SPI_DISABLE</code>	Description: <ul style="list-style-type: none">• Disable SPI. Parameters: <ul style="list-style-type: none">• <code>_HANDLE_</code>: specifies the SPI Handle. Return value: <ul style="list-style-type: none">• None

SPI Flags Definition

`SPI_FLAG_RXNE`
`SPI_FLAG_TXE`
`SPI_FLAG_CRCERR`
`SPI_FLAG_MODF`
`SPI_FLAG_OVR`
`SPI_FLAG_BSY`
`SPI_FLAG_FRE`

SPI Interrupt Definition

`SPI_IT_TXE`
`SPI_IT_RXNE`
`SPI_IT_ERR`

SPI Mode

`SPI_MODE_SLAVE`
`SPI_MODE_MASTER`

SPI MSB LSB Transssmission

`SPI_FIRSTBIT_MSB`
`SPI_FIRSTBIT_LSB`

SPI Private Macros

`IS_SPI_MODE`
`IS_SPI_DIRECTION_MODE`
`IS_SPI_DIRECTION_2LINES_OR_1LINE`
`IS_SPI_DIRECTION_2LINES`
`IS_SPI_DATASIZE`

IS_SPI_CPOL
IS_SPI_CPHA
IS_SPI_NSS
IS_SPI_BAUDRATE_PRESCALER
IS_SPI_FIRST_BIT
IS_SPI_TIMODE
IS_SPI_CRC_CALCULATION
IS_SPI_CRC_POLYNOMIAL
SPI_1LINE_TX
SPI_1LINE_RX
SPI_RESET_CRC
SPI Slave Select Management
SPI_NSS_SOFT
SPI_NSS_HARD_INPUT
SPI_NSS_HARD_OUTPUT
SPI TI Mode
SPI_TIMODE_DISABLE
SPI_TIMODE_ENABLE

60 HAL SRAM Generic Driver

60.1 HAL SRAM Generic Driver

60.2 SRAM Firmware driver registers structures

60.2.1 SRAM_HandleTypeDef

Data Fields

- *FMC_NORSRAM_TypeDef * Instance*
- *FMC_NORSRAM_EXTENDED_TypeDef * Extended*
- *FMC_NORSRAM_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *_IO HAL_SRAM_StateTypeDef State*
- *DMA_HandleTypeDef * hdma*

Field Documentation

- ***FMC_NORSRAM_TypeDef* SRAM_HandleTypeDef::Instance***
Register base address
- ***FMC_NORSRAM_EXTENDED_TypeDef* SRAM_HandleTypeDef::Extended***
Extended mode register base address
- ***FMC_NORSRAM_InitTypeDef SRAM_HandleTypeDef::Init***
SRAM device control configuration parameters
- ***HAL_LockTypeDef SRAM_HandleTypeDef::Lock***
SRAM locking object
- ***_IO HAL_SRAM_StateTypeDef SRAM_HandleTypeDef::State***
SRAM device access state
- ***DMA_HandleTypeDef* SRAM_HandleTypeDef::hdma***
Pointer DMA handler

60.3 SRAM Firmware driver API description

60.3.1 How to use this driver

This driver is a generic layered driver which contains a set of APIs used to control SRAM memories. It uses the FMC layer functions to interface with SRAM devices. The following sequence should be followed to configure the FMC/FSMC to interface with SRAM/PSRAM memories:

1. Declare a SRAM_HandleTypeDef handle structure, for example:

```
SRAM_HandleTypeDef hsrام; and:
```

 - Fill the SRAM_HandleTypeDef handle "Init" field with the allowed values of the structure member.
 - Fill the SRAM_HandleTypeDef handle "Instance" field with a predefined base register instance for NOR or SRAM device
 - Fill the SRAM_HandleTypeDef handle "Extended" field with a predefined base register instance for NOR or SRAM extended mode

2. Declare two FMC_NORSRAM_TimingTypeDef structures, for both normal and extended mode timings; for example: FMC_NORSRAM_TimingTypeDef Timing and FMC_NORSRAM_TimingTypeDef ExTiming; and fill its fields with the allowed values of the structure member.
3. Initialize the SRAM Controller by calling the function HAL_SRAM_Init(). This function performs the following sequence:
 - a. MSP hardware layer configuration using the function HAL_SRAM_MspInit()
 - b. Control register configuration using the FMC NORSRAM interface function FMC_NORSRAM_Init()
 - c. Timing register configuration using the FMC NORSRAM interface function FMC_NORSRAM_Timing_Init()
 - d. Extended mode Timing register configuration using the FMC NORSRAM interface function FMC_NORSRAM_Extended_Timing_Init()
 - e. Enable the SRAM device using the macro __FMC_NORSRAM_ENABLE()
4. At this stage you can perform read/write accesses from/to the memory connected to the NOR/SRAM Bank. You can perform either polling or DMA transfer using the following APIs:
 - HAL_SRAM_Read()/HAL_SRAM_Write() for polling read/write access
 - HAL_SRAM_Read_DMA()/HAL_SRAM_Write_DMA() for DMA read/write transfer
5. You can also control the SRAM device by calling the control APIs HAL_SRAM_WriteOperation_Enable() / HAL_SRAM_WriteOperation_Disable() to respectively enable/disable the SRAM write operation
6. You can continuously monitor the SRAM device HAL state by calling the function HAL_SRAM_GetState()

60.3.2 SRAM Initialization and de_initialization functions

This section provides functions allowing to initialize/de-initialize the SRAM memory

This section contains the following APIs:

- [*HAL_SRAM_Init\(\)*](#)
- [*HAL_SRAM_DelInit\(\)*](#)
- [*HAL_SRAM_MspInit\(\)*](#)
- [*HAL_SRAM_MspDelInit\(\)*](#)
- [*HAL_SRAM_DMA_XferCpltCallback\(\)*](#)
- [*HAL_SRAM_DMA_XferErrorCallback\(\)*](#)

60.3.3 SRAM Input and Output functions

This section provides functions allowing to use and control the SRAM memory

This section contains the following APIs:

- [*HAL_SRAM_Read_8b\(\)*](#)
- [*HAL_SRAM_Write_8b\(\)*](#)
- [*HAL_SRAM_Read_16b\(\)*](#)
- [*HAL_SRAM_Write_16b\(\)*](#)
- [*HAL_SRAM_Read_32b\(\)*](#)
- [*HAL_SRAM_Write_32b\(\)*](#)
- [*HAL_SRAM_Read_DMA\(\)*](#)
- [*HAL_SRAM_Write_DMA\(\)*](#)

60.3.4 SRAM Control functions

This subsection provides a set of functions allowing to control dynamically the SRAM interface.

This section contains the following APIs:

- [*HAL_SRAM_WriteOperation_Enable\(\)*](#)
- [*HAL_SRAM_WriteOperation_Disable\(\)*](#)

60.3.5 SRAM State functions

This subsection permits to get in run-time the status of the SRAM controller and the data flow.

This section contains the following APIs:

- [*HAL_SRAM_GetState\(\)*](#)

60.3.6 HAL_SRAM_Init

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_Init (SRAM_HandleTypeDef * hsram, FMC_NORSRAM_TimingTypeDef * Timing, FMC_NORSRAM_TimingTypeDef * ExtTiming)</code>
Function Description	Performs the SRAM device initialization sequence.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • Timing: Pointer to SRAM control timing structure • ExtTiming: Pointer to SRAM extended mode timing structure
Return values	<ul style="list-style-type: none"> • HAL status

60.3.7 HAL_SRAM_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_DelInit (SRAM_HandleTypeDef * hsram)</code>
Function Description	Performs the SRAM device De-initialization sequence.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • HAL status

60.3.8 HAL_SRAM_MspInit

Function Name	<code>void HAL_SRAM_MspInit (SRAM_HandleTypeDef * hsram)</code>
Function Description	SRAM MSP Init.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • None

60.3.9 HAL_SRAM_MspDelInit

Function Name	<code>void HAL_SRAM_MspDelInit (SRAM_HandleTypeDef * hsram)</code>
Function Description	SRAM MSP DelInit.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • None

60.3.10 HAL_SRAM_DMA_XferCpltCallback

Function Name	<code>void HAL_SRAM_DMA_XferCpltCallback (DMA_HandleTypeDef * hdma)</code>
Function Description	DMA transfer complete callback.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • None

60.3.11 HAL_SRAM_DMA_XferErrorCallback

Function Name	<code>void HAL_SRAM_DMA_XferErrorCallback (DMA_HandleTypeDef * hdma)</code>
Function Description	DMA transfer complete error callback.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • None

60.3.12 HAL_SRAM_Read_8b

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_Read_8b (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint8_t * pDstBuffer, uint32_t BufferSize)</code>
Function Description	Reads 8-bit buffer from SRAM memory.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to read start address • pDstBuffer: Pointer to destination buffer • BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.13 HAL_SRAM_Write_8b

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_Write_8b (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint8_t * pSrcBuffer, uint32_t BufferSize)</code>
Function Description	Writes 8-bit buffer to SRAM memory.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to write start address • pSrcBuffer: Pointer to source buffer to write • BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.14 HAL_SRAM_Read_16b

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_Read_16b (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint16_t</code>
---------------	---

*** pDstBuffer, uint32_t BufferSize)**

Function Description	Reads 16-bit buffer from SRAM memory.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to read start address • pDstBuffer: Pointer to destination buffer • BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.15 HAL_SRAM_Write_16b

Function Name	HAL_StatusTypeDef HAL_SRAM_Write_16b (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint16_t * pSrcBuffer, uint32_t BufferSize)
Function Description	Writes 16-bit buffer to SRAM memory.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to write start address • pSrcBuffer: Pointer to source buffer to write • BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.16 HAL_SRAM_Read_32b

Function Name	HAL_StatusTypeDef HAL_SRAM_Read_32b (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint32_t * pDstBuffer, uint32_t BufferSize)
Function Description	Reads 32-bit buffer from SRAM memory.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to read start address • pDstBuffer: Pointer to destination buffer • BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.17 HAL_SRAM_Write_32b

Function Name	HAL_StatusTypeDef HAL_SRAM_Write_32b (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint32_t * pSrcBuffer, uint32_t BufferSize)
Function Description	Writes 32-bit buffer to SRAM memory.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to write start address • pSrcBuffer: Pointer to source buffer to write • BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.18 HAL_SRAM_Read_DMA

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_Read_DMA (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint32_t * pDstBuffer, uint32_t BufferSize)</code>
Function Description	Reads a Words data from the SRAM memory using DMA transfer.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to read start address • pDstBuffer: Pointer to destination buffer • BufferSize: Size of the buffer to read from memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.19 HAL_SRAM_Write_DMA

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_Write_DMA (SRAM_HandleTypeDef * hsram, uint32_t * pAddress, uint32_t * pSrcBuffer, uint32_t BufferSize)</code>
Function Description	Writes a Words data buffer to SRAM memory using DMA transfer.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module. • pAddress: Pointer to write start address • pSrcBuffer: Pointer to source buffer to write • BufferSize: Size of the buffer to write to memory
Return values	<ul style="list-style-type: none"> • HAL status

60.3.20 HAL_SRAM_WriteOperation_Enable

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_WriteOperation_Enable (SRAM_HandleTypeDef * hsram)</code>
Function Description	Enables dynamically SRAM write operation.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • HAL status

60.3.21 HAL_SRAM_WriteOperation_Disable

Function Name	<code>HAL_StatusTypeDef HAL_SRAM_WriteOperation_Disable (SRAM_HandleTypeDef * hsram)</code>
Function Description	Disables dynamically SRAM write operation.
Parameters	<ul style="list-style-type: none"> • hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none"> • HAL status

60.3.22 HAL_SRAM_GetState

Function Name	<code>HAL_SRAM_StateTypeDef HAL_SRAM_GetState (SRAM_HandleTypeDef * hsram)</code>
---------------	---

Function Description	Returns the SRAM controller state.
Parameters	<ul style="list-style-type: none">• hsram: pointer to a SRAM_HandleTypeDef structure that contains the configuration information for SRAM module.
Return values	<ul style="list-style-type: none">• HAL state

60.4 SRAM Firmware driver defines

60.4.1 SRAM

SRAM Exported Macros

`_HAL_SRAM_RESET_HANDLE_STATE` **Description:**

- Reset SRAM handle state.

Parameters:

- `_HANDLE_`: SRAM handle

Return value:

- None

61 HAL TIM Generic Driver

61.1 HAL TIM Generic Driver

61.2 TIM Firmware driver registers structures

61.2.1 TIM_Base_InitTypeDef

Data Fields

- *uint32_t Prescaler*
- *uint32_t CounterMode*
- *uint32_t Period*
- *uint32_t ClockDivision*
- *uint32_t RepetitionCounter*

Field Documentation

- ***uint32_t TIM_Base_InitTypeDef::Prescaler***
Specifies the prescaler value used to divide the TIM clock. This parameter can be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF
- ***uint32_t TIM_Base_InitTypeDef::CounterMode***
Specifies the counter mode. This parameter can be a value of [**TIM_Counter_Mode**](#)
- ***uint32_t TIM_Base_InitTypeDef::Period***
Specifies the period value to be loaded into the active Auto-Reload Register at the next update event. This parameter can be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF.
- ***uint32_t TIM_Base_InitTypeDef::ClockDivision***
Specifies the clock division. This parameter can be a value of [**TIM_ClockDivision**](#)
- ***uint32_t TIM_Base_InitTypeDef::RepetitionCounter***
Specifies the repetition counter value. Each time the RCR downcounter reaches zero, an update event is generated and counting restarts from the RCR value (N). This means in PWM mode that (N+1) corresponds to:the number of PWM periods in edge-aligned mode the number of half PWM period in center-aligned mode This parameter must be a number between Min_Data = 0x00 and Max_Data = 0xFF.
Note:This parameter is valid only for TIM1 and TIM8.

61.2.2 TIM_OC_InitTypeDef

Data Fields

- *uint32_t OCMode*
- *uint32_t Pulse*
- *uint32_t OCPolarity*
- *uint32_t OCNPolarity*
- *uint32_t OCFastMode*
- *uint32_t OCIdleState*
- *uint32_t OCNIdleState*

Field Documentation

- ***uint32_t TIM_OC_InitTypeDef::OCMode***
Specifies the TIM mode. This parameter can be a value of
TIM_Output_Compare_and_PWM_modes
- ***uint32_t TIM_OC_InitTypeDef::Pulse***
Specifies the pulse value to be loaded into the Capture Compare Register. This parameter can be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF
- ***uint32_t TIM_OC_InitTypeDef::OCPolarity***
Specifies the output polarity. This parameter can be a value of
TIM_Output_Compare_Polarity
- ***uint32_t TIM_OC_InitTypeDef::OCNPolarity***
Specifies the complementary output polarity. This parameter can be a value of
TIM_Output_Compare_N_Polarity
Note:This parameter is valid only for TIM1 and TIM8.
- ***uint32_t TIM_OC_InitTypeDef::OCFastMode***
Specifies the Fast mode state. This parameter can be a value of
TIM_Output_Fast_State
Note:This parameter is valid only in PWM1 and PWM2 mode.
- ***uint32_t TIM_OC_InitTypeDef::OCIdleState***
Specifies the TIM Output Compare pin state during Idle state. This parameter can be a value of
TIM_Output_Compare_Idle_State
Note:This parameter is valid only for TIM1 and TIM8.
- ***uint32_t TIM_OC_InitTypeDef::OCNIdleState***
Specifies the TIM Output Compare pin state during Idle state. This parameter can be a value of
TIM_Output_Compare_N_Idle_State
Note:This parameter is valid only for TIM1 and TIM8.

61.2.3 TIM_OnePulse_InitTypeDef

Data Fields

- ***uint32_t OCMode***
- ***uint32_t Pulse***
- ***uint32_t OCPolarity***
- ***uint32_t OCNPolarity***
- ***uint32_t OCIdleState***
- ***uint32_t OCNIdleState***
- ***uint32_t IC_Polarity***
- ***uint32_t IC_Selection***
- ***uint32_t IC_Filter***

Field Documentation

- ***uint32_t TIM_OnePulse_InitTypeDef::OCMode***
Specifies the TIM mode. This parameter can be a value of
TIM_Output_Compare_and_PWM_modes
- ***uint32_t TIM_OnePulse_InitTypeDef::Pulse***
Specifies the pulse value to be loaded into the Capture Compare Register. This parameter can be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF

- ***uint32_t TIM_OnePulse_InitTypeDef::OCPolarity***
Specifies the output polarity. This parameter can be a value of [**TIM_Output_Compare_Polarity**](#)
- ***uint32_t TIM_OnePulse_InitTypeDef::OCNPolarity***
Specifies the complementary output polarity. This parameter can be a value of [**TIM_Output_Compare_N_Polarity**](#)
Note:This parameter is valid only for TIM1 and TIM8.
- ***uint32_t TIM_OnePulse_InitTypeDef::OCIdleState***
Specifies the TIM Output Compare pin state during Idle state. This parameter can be a value of [**TIM_Output_Compare_Idle_State**](#)
Note:This parameter is valid only for TIM1 and TIM8.
- ***uint32_t TIM_OnePulse_InitTypeDef::OCNIdleState***
Specifies the TIM Output Compare pin state during Idle state. This parameter can be a value of [**TIM_Output_Compare_N_Idle_State**](#)
Note:This parameter is valid only for TIM1 and TIM8.
- ***uint32_t TIM_OnePulse_InitTypeDef::ICPolarity***
Specifies the active edge of the input signal. This parameter can be a value of [**TIM_Input_Capture_Polarity**](#)
- ***uint32_t TIM_OnePulse_InitTypeDef::ICSelection***
Specifies the input. This parameter can be a value of [**TIM_Input_Capture_Selection**](#)
- ***uint32_t TIM_OnePulse_InitTypeDef::ICFilter***
Specifies the input capture filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF

61.2.4 TIM_IC_InitTypeDef

Data Fields

- ***uint32_t ICPolarity***
- ***uint32_t ICSelection***
- ***uint32_t ICPrescaler***
- ***uint32_t ICFilter***

Field Documentation

- ***uint32_t TIM_IC_InitTypeDef::ICPolarity***
Specifies the active edge of the input signal. This parameter can be a value of [**TIM_Input_Capture_Polarity**](#)
- ***uint32_t TIM_IC_InitTypeDef::ICSelection***
Specifies the input. This parameter can be a value of [**TIM_Input_Capture_Selection**](#)
- ***uint32_t TIM_IC_InitTypeDef::ICPrescaler***
Specifies the Input Capture Prescaler. This parameter can be a value of [**TIM_Input_Capture_Prescaler**](#)
- ***uint32_t TIM_IC_InitTypeDef::ICFilter***
Specifies the input capture filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF

61.2.5 TIM_Encoder_InitTypeDef

Data Fields

- *uint32_t EncoderMode*
- *uint32_t IC1Polarity*
- *uint32_t IC1Selection*
- *uint32_t IC1Prescaler*
- *uint32_t IC1Filter*
- *uint32_t IC2Polarity*
- *uint32_t IC2Selection*
- *uint32_t IC2Prescaler*
- *uint32_t IC2Filter*

Field Documentation

- *uint32_t TIM_Encoder_InitTypeDef::EncoderMode*
Specifies the active edge of the input signal. This parameter can be a value of [**TIM_Encoder_Mode**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC1Polarity*
Specifies the active edge of the input signal. This parameter can be a value of [**TIM_Input_Capture_Polarity**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC1Selection*
Specifies the input. This parameter can be a value of [**TIM_Input_Capture_Selection**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC1Prescaler*
Specifies the Input Capture Prescaler. This parameter can be a value of [**TIM_Input_Capture_Prescaler**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC1Filter*
Specifies the input capture filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF
- *uint32_t TIM_Encoder_InitTypeDef::IC2Polarity*
Specifies the active edge of the input signal. This parameter can be a value of [**TIM_Input_Capture_Polarity**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC2Selection*
Specifies the input. This parameter can be a value of [**TIM_Input_Capture_Selection**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC2Prescaler*
Specifies the Input Capture Prescaler. This parameter can be a value of [**TIM_Input_Capture_Prescaler**](#)
- *uint32_t TIM_Encoder_InitTypeDef::IC2Filter*
Specifies the input capture filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF

61.2.6 TIM_ClockConfigTypeDef**Data Fields**

- *uint32_t ClockSource*
- *uint32_t ClockPolarity*
- *uint32_t ClockPrescaler*
- *uint32_t ClockFilter*

Field Documentation

- ***uint32_t TIM_ClockConfigTypeDef::ClockSource***
TIM clock sources. This parameter can be a value of [**TIM_Clock_Source**](#)
- ***uint32_t TIM_ClockConfigTypeDef::ClockPolarity***
TIM clock polarity. This parameter can be a value of [**TIM_Clock_Polarity**](#)
- ***uint32_t TIM_ClockConfigTypeDef::ClockPrescaler***
TIM clock prescaler. This parameter can be a value of [**TIM_Clock_Prescaler**](#)
- ***uint32_t TIM_ClockConfigTypeDef::ClockFilter***
TIM clock filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF

61.2.7 TIM_ClearInputConfigTypeDef

Data Fields

- ***uint32_t ClearInputState***
- ***uint32_t ClearInputSource***
- ***uint32_t ClearInputPolarity***
- ***uint32_t ClearInputPrescaler***
- ***uint32_t ClearInputFilter***

Field Documentation

- ***uint32_t TIM_ClearInputConfigTypeDef::ClearInputState***
TIM clear Input state. This parameter can be ENABLE or DISABLE
- ***uint32_t TIM_ClearInputConfigTypeDef::ClearInputSource***
TIM clear Input sources. This parameter can be a value of [**TIM_ClearInput_Source**](#)
- ***uint32_t TIM_ClearInputConfigTypeDef::ClearInputPolarity***
TIM Clear Input polarity. This parameter can be a value of [**TIM_ClearInput_Polarity**](#)
- ***uint32_t TIM_ClearInputConfigTypeDef::ClearInputPrescaler***
TIM Clear Input prescaler. This parameter can be a value of [**TIM_ClearInput_Prescaler**](#)
- ***uint32_t TIM_ClearInputConfigTypeDef::ClearInputFilter***
TIM Clear Input filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF

61.2.8 TIM_SlaveConfigTypeDef

Data Fields

- ***uint32_t SlaveMode***
- ***uint32_t InputTrigger***
- ***uint32_t TriggerPolarity***
- ***uint32_t TriggerPrescaler***
- ***uint32_t TriggerFilter***

Field Documentation

- ***uint32_t TIM_SlaveConfigTypeDef::SlaveMode***
Slave mode selection This parameter can be a value of [**TIM_Slave_Mode**](#)

- ***uint32_t TIM_SlaveConfigTypeDef::InputTrigger***
Input Trigger source This parameter can be a value of [**TIM_Trigger_Selection**](#)
- ***uint32_t TIM_SlaveConfigTypeDef::TriggerPolarity***
Input Trigger polarity This parameter can be a value of [**TIM_Trigger_Polarity**](#)
- ***uint32_t TIM_SlaveConfigTypeDef::TriggerPrescaler***
Input trigger prescaler This parameter can be a value of [**TIM_Trigger_Prescaler**](#)
- ***uint32_t TIM_SlaveConfigTypeDef::TriggerFilter***
Input trigger filter This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF

61.2.9 TIM_HandleTypeDef

Data Fields

- ***TIM_TypeDef * Instance***
- ***TIM_Base_InitTypeDef Init***
- ***HAL_TIM_ActiveChannel Channel***
- ***DMA_HandleTypeDef * hdma***
- ***HAL_LockTypeDef Lock***
- ***__IO HAL_TIM_StateTypeDef State***

Field Documentation

- ***TIM_TypeDef* TIM_HandleTypeDef::Instance***
Register base address
- ***TIM_Base_InitTypeDef TIM_HandleTypeDef::Init***
TIM Time Base required parameters
- ***HAL_TIM_ActiveChannel TIM_HandleTypeDef::Channel***
Active channel
- ***DMA_HandleTypeDef* TIM_HandleTypeDef::hdma[7]***
DMA Handlers array This array is accessed by a [**DMA_Handle_index**](#)
- ***HAL_LockTypeDef TIM_HandleTypeDef::Lock***
Locking object
- ***__IO HAL_TIM_StateTypeDef TIM_HandleTypeDef::State***
TIM operation state

61.3 TIM Firmware driver API description

61.3.1 TIMER Generic features

The Timer features include:

1. 16-bit up, down, up/down auto-reload counter.
2. 16-bit programmable prescaler allowing dividing (also on the fly) the counter clock frequency either by any factor between 1 and 65536.
3. Up to 4 independent channels for:
 - Input Capture
 - Output Compare
 - PWM generation (Edge and Center-aligned Mode)
 - One-pulse mode output

61.3.2 How to use this driver

1. Initialize the TIM low level resources by implementing the following functions depending from feature used :
 - Time Base : HAL_TIM_Base_MspInit()
 - Input Capture : HAL_TIM_IC_MspInit()
 - Output Compare : HAL_TIM_OC_MspInit()
 - PWM generation : HAL_TIM_PWM_MspInit()
 - One-pulse mode output : HAL_TIM_OnePulse_MspInit()
 - Encoder mode output : HAL_TIM_Encoder_MspInit()
2. Initialize the TIM low level resources :
 - a. Enable the TIM interface clock using __TIMx_CLK_ENABLE();
 - b. TIM pins configuration
 - Enable the clock for the TIM GPIOs using the following function: __GPIOx_CLK_ENABLE();
 - Configure these TIM pins in Alternate function mode using HAL_GPIO_Init();
3. The external Clock can be configured, if needed (the default clock is the internal clock from the APBx), using the following function: HAL_TIM_ConfigClockSource, the clock configuration should be done before any start function.
4. Configure the TIM in the desired functioning mode using one of the initialization function of this driver:
 - HAL_TIM_Base_Init: to use the Timer to generate a simple time base
 - HAL_TIM_OC_Init and HAL_TIM_OC_ConfigChannel: to use the Timer to generate an Output Compare signal.
 - HAL_TIM_PWM_Init and HAL_TIM_PWM_ConfigChannel: to use the Timer to generate a PWM signal.
 - HAL_TIM_IC_Init and HAL_TIM_IC_ConfigChannel: to use the Timer to measure an external signal.
 - HAL_TIM_OnePulse_Init and HAL_TIM_OnePulse_ConfigChannel: to use the Timer in One Pulse Mode.
 - HAL_TIM_Encoder_Init: to use the Timer Encoder Interface.
5. Activate the TIM peripheral using one of the start functions depending from the feature used:
 - Time Base : HAL_TIM_Base_Start(), HAL_TIM_Base_Start_DMA(), HAL_TIM_Base_Start_IT()
 - Input Capture : HAL_TIM_IC_Start(), HAL_TIM_IC_Start_DMA(), HAL_TIM_IC_Start_IT()
 - Output Compare : HAL_TIM_OC_Start(), HAL_TIM_OC_Start_DMA(), HAL_TIM_OC_Start_IT()
 - PWM generation : HAL_TIM_PWM_Start(), HAL_TIM_PWM_Start_DMA(), HAL_TIM_PWM_Start_IT()
 - One-pulse mode output : HAL_TIM_OnePulse_Start(), HAL_TIM_OnePulse_Start_IT()
 - Encoder mode output : HAL_TIM_Encoder_Start(), HAL_TIM_Encoder_Start_DMA(), HAL_TIM_Encoder_Start_IT().
6. The DMA Burst is managed with the two following functions:
HAL_TIM_DMABurst_WriteStart() HAL_TIM_DMABurst_ReadStart()

61.3.3 Time Base functions

This section provides functions allowing to:

- Initialize and configure the TIM base.

-
- De-initialize the TIM base.
 - Start the Time Base.
 - Stop the Time Base.
 - Start the Time Base and enable interrupt.
 - Stop the Time Base and disable interrupt.
 - Start the Time Base and enable DMA transfer.
 - Stop the Time Base and disable DMA transfer.

This section contains the following APIs:

- [*HAL_TIM_Base_Init\(\)*](#)
- [*HAL_TIM_Base_DeInit\(\)*](#)
- [*HAL_TIM_Base_MspInit\(\)*](#)
- [*HAL_TIM_Base_MspDeInit\(\)*](#)
- [*HAL_TIM_Base_Start\(\)*](#)
- [*HAL_TIM_Base_Stop\(\)*](#)
- [*HAL_TIM_Base_Start_IT\(\)*](#)
- [*HAL_TIM_Base_Stop_IT\(\)*](#)
- [*HAL_TIM_Base_Start_DMA\(\)*](#)
- [*HAL_TIM_Base_Stop_DMA\(\)*](#)

61.3.4 Time Output Compare functions

This section provides functions allowing to:

- Initialize and configure the TIM Output Compare.
- De-initialize the TIM Output Compare.
- Start the Time Output Compare.
- Stop the Time Output Compare.
- Start the Time Output Compare and enable interrupt.
- Stop the Time Output Compare and disable interrupt.
- Start the Time Output Compare and enable DMA transfer.
- Stop the Time Output Compare and disable DMA transfer.

This section contains the following APIs:

- [*HAL_TIM_OC_Init\(\)*](#)
- [*HAL_TIM_OC_DeInit\(\)*](#)
- [*HAL_TIM_OC_MspInit\(\)*](#)
- [*HAL_TIM_OC_MspDeInit\(\)*](#)
- [*HAL_TIM_OC_Start\(\)*](#)
- [*HAL_TIM_OC_Stop\(\)*](#)
- [*HAL_TIM_OC_Start_IT\(\)*](#)
- [*HAL_TIM_OC_Stop_IT\(\)*](#)
- [*HAL_TIM_OC_Start_DMA\(\)*](#)
- [*HAL_TIM_OC_Stop_DMA\(\)*](#)

61.3.5 Time PWM functions

This section provides functions allowing to:

- Initialize and configure the TIM OPWM.
- De-initialize the TIM PWM.
- Start the Time PWM.
- Stop the Time PWM.
- Start the Time PWM and enable interrupt.
- Stop the Time PWM and disable interrupt.

-
- Start the Time PWM and enable DMA transfer.
 - Stop the Time PWM and disable DMA transfer.

This section contains the following APIs:

- [*HAL_TIM_PWM_Init\(\)*](#)
- [*HAL_TIM_PWM_DeInit\(\)*](#)
- [*HAL_TIM_PWM_MspInit\(\)*](#)
- [*HAL_TIM_PWM_MspDeInit\(\)*](#)
- [*HAL_TIM_PWM_Start\(\)*](#)
- [*HAL_TIM_PWM_Stop\(\)*](#)
- [*HAL_TIM_PWM_Start_IT\(\)*](#)
- [*HAL_TIM_PWM_Stop_IT\(\)*](#)
- [*HAL_TIM_PWM_Start_DMA\(\)*](#)
- [*HAL_TIM_PWM_Stop_DMA\(\)*](#)

61.3.6 Time Input Capture functions

This section provides functions allowing to:

- Initialize and configure the TIM Input Capture.
- De-initialize the TIM Input Capture.
- Start the Time Input Capture.
- Stop the Time Input Capture.
- Start the Time Input Capture and enable interrupt.
- Stop the Time Input Capture and disable interrupt.
- Start the Time Input Capture and enable DMA transfer.
- Stop the Time Input Capture and disable DMA transfer.

This section contains the following APIs:

- [*HAL_TIM_IC_Init\(\)*](#)
- [*HAL_TIM_IC_DeInit\(\)*](#)
- [*HAL_TIM_IC_MspInit\(\)*](#)
- [*HAL_TIM_IC_MspDeInit\(\)*](#)
- [*HAL_TIM_IC_Start\(\)*](#)
- [*HAL_TIM_IC_Stop\(\)*](#)
- [*HAL_TIM_IC_Start_IT\(\)*](#)
- [*HAL_TIM_IC_Stop_IT\(\)*](#)
- [*HAL_TIM_IC_Start_DMA\(\)*](#)
- [*HAL_TIM_IC_Stop_DMA\(\)*](#)

61.3.7 Time One Pulse functions

This section provides functions allowing to:

- Initialize and configure the TIM One Pulse.
- De-initialize the TIM One Pulse.
- Start the Time One Pulse.
- Stop the Time One Pulse.
- Start the Time One Pulse and enable interrupt.
- Stop the Time One Pulse and disable interrupt.
- Start the Time One Pulse and enable DMA transfer.
- Stop the Time One Pulse and disable DMA transfer.

This section contains the following APIs:

- [*HAL_TIM_OnePulse_Init\(\)*](#)

- [*HAL_TIM_OnePulse_DelInit\(\)*](#)
- [*HAL_TIM_OnePulse_MspInit\(\)*](#)
- [*HAL_TIM_OnePulse_MspDelInit\(\)*](#)
- [*HAL_TIM_OnePulse_Start\(\)*](#)
- [*HAL_TIM_OnePulse_Stop\(\)*](#)
- [*HAL_TIM_OnePulse_Start_IT\(\)*](#)
- [*HAL_TIM_OnePulse_Stop_IT\(\)*](#)

61.3.8 Time Encoder functions

This section provides functions allowing to:

- Initialize and configure the TIM Encoder.
- De-initialize the TIM Encoder.
- Start the Time Encoder.
- Stop the Time Encoder.
- Start the Time Encoder and enable interrupt.
- Stop the Time Encoder and disable interrupt.
- Start the Time Encoder and enable DMA transfer.
- Stop the Time Encoder and disable DMA transfer.

This section contains the following APIs:

- [*HAL_TIM_Encoder_Init\(\)*](#)
- [*HAL_TIM_Encoder_DelInit\(\)*](#)
- [*HAL_TIM_Encoder_MspInit\(\)*](#)
- [*HAL_TIM_Encoder_MspDelInit\(\)*](#)
- [*HAL_TIM_Encoder_Start\(\)*](#)
- [*HAL_TIM_Encoder_Stop\(\)*](#)
- [*HAL_TIM_Encoder_Start_IT\(\)*](#)
- [*HAL_TIM_Encoder_Stop_IT\(\)*](#)
- [*HAL_TIM_Encoder_Start_DMA\(\)*](#)
- [*HAL_TIM_Encoder_Stop_DMA\(\)*](#)

61.3.9 IRQ handler management

This section provides Timer IRQ handler function.

This section contains the following APIs:

- [*HAL_TIM_IRQHandler\(\)*](#)

61.3.10 Peripheral Control functions

This section provides functions allowing to:

- Configure The Input Output channels for OC, PWM, IC or One Pulse mode.
- Configure External Clock source.
- Configure Complementary channels, break features and dead time.
- Configure Master and the Slave synchronization.
- Configure the DMA Burst Mode.

This section contains the following APIs:

- [*HAL_TIM_OC_ConfigChannel\(\)*](#)
- [*HAL_TIM_IC_ConfigChannel\(\)*](#)
- [*HAL_TIM_PWM_ConfigChannel\(\)*](#)
- [*HAL_TIM_OnePulse_ConfigChannel\(\)*](#)

- [*HAL_TIM_DMABurst_WriteStart\(\)*](#)
- [*HAL_TIM_DMABurst_WriteStop\(\)*](#)
- [*HAL_TIM_DMABurst_ReadStart\(\)*](#)
- [*HAL_TIM_DMABurst_ReadStop\(\)*](#)
- [*HAL_TIM_GenerateEvent\(\)*](#)
- [*HAL_TIM_ConfigOCrefClear\(\)*](#)
- [*HAL_TIM_ConfigClockSource\(\)*](#)
- [*HAL_TIM_ConfigT1Input\(\)*](#)
- [*HAL_TIM_SlaveConfigSynchronization\(\)*](#)
- [*HAL_TIM_SlaveConfigSynchronization_IT\(\)*](#)
- [*HAL_TIM_ReadCapturedValue\(\)*](#)

61.3.11 TIM Callbacks functions

This section provides TIM callback functions:

- Timer Period elapsed callback
- Timer Output Compare callback
- Timer Input capture callback
- Timer Trigger callback
- Timer Error callback

This section contains the following APIs:

- [*HAL_TIM_PeriodElapsedCallback\(\)*](#)
- [*HAL_TIM_OC_DelayElapsedCallback\(\)*](#)
- [*HAL_TIM_IC_CaptureCallback\(\)*](#)
- [*HAL_TIM_PWM_PulseFinishedCallback\(\)*](#)
- [*HAL_TIM_TriggerCallback\(\)*](#)
- [*HAL_TIM_ErrorCallback\(\)*](#)

61.3.12 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_TIM_Base_GetState\(\)*](#)
- [*HAL_TIM_OC_GetState\(\)*](#)
- [*HAL_TIM_PWM_GetState\(\)*](#)
- [*HAL_TIM_IC_GetState\(\)*](#)
- [*HAL_TIM_OnePulse_GetState\(\)*](#)
- [*HAL_TIM_Encoder_GetState\(\)*](#)

61.3.13 HAL_TIM_Base_Init

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Init (TIM_HandleTypeDef * htim)
Function Description	Initializes the TIM Time base Unit according to the specified parameters in the TIM_HandleTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.14 HAL_TIM_Base_DeInit

Function Name	HAL_StatusTypeDef HAL_TIM_Base_DeInit (TIM_HandleTypeDef * htim)
Function Description	DeInitializes the TIM Base peripheral.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.15 HAL_TIM_Base_MspInit

Function Name	void HAL_TIM_Base_MspInit (TIM_HandleTypeDef * htim)
Function Description	Initializes the TIM Base MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.16 HAL_TIM_Base_MspDeInit

Function Name	void HAL_TIM_Base_MspDeInit (TIM_HandleTypeDef * htim)
Function Description	DeInitializes TIM Base MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.17 HAL_TIM_Base_Start

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Start (TIM_HandleTypeDef * htim)
Function Description	Starts the TIM Base generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.18 HAL_TIM_Base_Stop

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Stop (TIM_HandleTypeDef * htim)
Function Description	Stops the TIM Base generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.19 HAL_TIM_Base_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Start_IT
---------------	--

(TIM_HandleTypeDef * htim)

Function Description	Starts the TIM Base generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.20 HAL_TIM_Base_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Stop_IT (TIM_HandleTypeDef * htim)
Function Description	Stops the TIM Base generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.21 HAL_TIM_Base_Start_DMA

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Start_DMA (TIM_HandleTypeDef * htim, uint32_t * pData, uint16_t Length)
Function Description	Starts the TIM Base generation in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • pData: The source Buffer address. • Length: The length of data to be transferred from memory to peripheral.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.22 HAL_TIM_Base_Stop_DMA

Function Name	HAL_StatusTypeDef HAL_TIM_Base_Stop_DMA (TIM_HandleTypeDef * htim)
Function Description	Stops the TIM Base generation in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.23 HAL_TIM_OC_Init

Function Name	HAL_StatusTypeDef HAL_TIM_OC_Init (TIM_HandleTypeDef * htim)
Function Description	Initializes the TIM Output Compare according to the specified parameters in the TIM_HandleTypeDef and create the associated handle.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.24 HAL_TIM_OC_DeInit

Function Name	HAL_StatusTypeDef HAL_TIM_OC_DeInit (TIM_HandleTypeDef * htim)
Function Description	DeInitializes the TIM peripheral.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.25 HAL_TIM_OC_MspInit

Function Name	void HAL_TIM_OC_MspInit (TIM_HandleTypeDef * htim)
Function Description	Initializes the TIM Output Compare MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.26 HAL_TIM_OC_MspDeInit

Function Name	void HAL_TIM_OC_MspDeInit (TIM_HandleTypeDef * htim)
Function Description	DeInitializes TIM Output Compare MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.27 HAL_TIM_OC_Start

Function Name	HAL_StatusTypeDef HAL_TIM_OC_Start (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Output Compare signal generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.28 HAL_TIM_OC_Stop

Function Name	HAL_StatusTypeDef HAL_TIM_OC_Stop (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Output Compare signal generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can

be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

61.3.29 HAL_TIM_OC_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIM_OC_Start_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Output Compare signal generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.30 HAL_TIM_OC_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIM_OC_Stop_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Output Compare signal generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.31 HAL_TIM_OC_Start_DMA

Function Name	HAL_StatusTypeDef HAL_TIM_OC_Start_DMA (TIM_HandleTypeDef * htim, uint32_t Channel, uint32_t * pData, uint16_t Length)
Function Description	Starts the TIM Output Compare signal generation in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected • pData: The source Buffer address.

- **Length:** The length of data to be transferred from memory to TIM peripheral

Return values • HAL status

61.3.32 HAL_TIM_OC_Stop_DMA

Function Name **HAL_StatusTypeDef HAL_TIM_OC_Stop_DMA (TIM_HandleTypeDef * htim, uint32_t Channel)**

Function Description Stops the TIM Output Compare signal generation in DMA mode.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
- **Channel:** TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected

Return values • HAL status

61.3.33 HAL_TIM_PWM_Init

Function Name **HAL_StatusTypeDef HAL_TIM_PWM_Init (TIM_HandleTypeDef * htim)**

Function Description Initializes the TIM PWM Time Base according to the specified parameters in the TIM_HandleTypeDef and create the associated handle.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

Return values • HAL status

61.3.34 HAL_TIM_PWM_DeInit

Function Name **HAL_StatusTypeDef HAL_TIM_PWM_DeInit (TIM_HandleTypeDef * htim)**

Function Description DeInitializes the TIM peripheral.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

Return values • HAL status

61.3.35 HAL_TIM_PWM_MspInit

Function Name **void HAL_TIM_PWM_MspInit (TIM_HandleTypeDef * htim)**

Function Description Initializes the TIM PWM MSP.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

Return values • None

61.3.36 HAL_TIM_PWM_MspDeInit



Function Name	void HAL_TIM_PWM_MspDeInit (TIM_HandleTypeDef * htim)
Function Description	Deinitializes TIM PWM MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.37 HAL_TIM_PWM_Start

Function Name	HAL_StatusTypeDef HAL_TIM_PWM_Start (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the PWM signal generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.38 HAL_TIM_PWM_Stop

Function Name	HAL_StatusTypeDef HAL_TIM_PWM_Stop (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the PWM signal generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.39 HAL_TIM_PWM_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIM_PWM_Start_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the PWM signal generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.40 HAL_TIM_PWM_Stop_IT

Function Name	<code>HAL_StatusTypeDef HAL_TIM_PWM_Stop_IT (TIM_HandleTypeDef * htim, uint32_t Channel)</code>
Function Description	Stops the PWM signal generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.41 HAL_TIM_PWM_Start_DMA

Function Name	<code>HAL_StatusTypeDef HAL_TIM_PWM_Start_DMA (TIM_HandleTypeDef * htim, uint32_t Channel, uint32_t * pData, uint16_t Length)</code>
Function Description	Starts the TIM PWM signal generation in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected • pData: The source Buffer address. • Length: The length of data to be transferred from memory to TIM peripheral
Return values	<ul style="list-style-type: none"> • HAL status

61.3.42 HAL_TIM_PWM_Stop_DMA

Function Name	<code>HAL_StatusTypeDef HAL_TIM_PWM_Stop_DMA (TIM_HandleTypeDef * htim, uint32_t Channel)</code>
Function Description	Stops the TIM PWM signal generation in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.43 HAL_TIM_IC_Init

Function Name	<code>HAL_StatusTypeDef HAL_TIM_IC_Init (TIM_HandleTypeDef * htim)</code>
---------------	---

Function Description Initializes the TIM Input Capture Time base according to the specified parameters in the **TIM_HandleTypeDef** and create the associated handle.

Parameters

- **htim:** pointer to a **TIM_HandleTypeDef** structure that contains the configuration information for TIM module.

Return values

- HAL status

61.3.44 **HAL_TIM_IC_DeInit**

Function Name **HAL_StatusTypeDef HAL_TIM_IC_DeInit (TIM_HandleTypeDef * htim)**

Function Description DeInitializes the TIM peripheral.

Parameters

- **htim:** pointer to a **TIM_HandleTypeDef** structure that contains the configuration information for TIM module.

Return values

- HAL status

61.3.45 **HAL_TIM_IC_MspInit**

Function Name **void HAL_TIM_IC_MspInit (TIM_HandleTypeDef * htim)**

Function Description Initializes the TIM Input Capture MSP.

Parameters

- **htim:** pointer to a **TIM_HandleTypeDef** structure that contains the configuration information for TIM module.

Return values

- None

61.3.46 **HAL_TIM_IC_MspDeInit**

Function Name **void HAL_TIM_IC_MspDeInit (TIM_HandleTypeDef * htim)**

Function Description DeInitializes TIM Input Capture MSP.

Parameters

- **htim:** pointer to a **TIM_HandleTypeDef** structure that contains the configuration information for TIM module.

Return values

- None

61.3.47 **HAL_TIM_IC_Start**

Function Name **HAL_StatusTypeDef HAL_TIM_IC_Start (TIM_HandleTypeDef * htim, uint32_t Channel)**

Function Description Starts the TIM Input Capture measurement.

Parameters

- **htim:** pointer to a **TIM_HandleTypeDef** structure that contains the configuration information for TIM module.
- **Channel:** TIM Channels to be enabled. This parameter can be one of the following values: **TIM_CHANNEL_1:** TIM Channel 1 selected**TIM_CHANNEL_2:** TIM Channel 2 selected**TIM_CHANNEL_3:** TIM Channel 3 selected**TIM_CHANNEL_4:** TIM Channel 4 selected

Return values

- HAL status

61.3.48 **HAL_TIM_IC_Stop**

Function Name	HAL_StatusTypeDef HAL_TIM_IC_Stop (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Input Capture measurement.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> HAL status
61.3.49 HAL_TIM_IC_Start_IT	
Function Name	HAL_StatusTypeDef HAL_TIM_IC_Start_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Input Capture measurement in interrupt mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> HAL status
61.3.50 HAL_TIM_IC_Stop_IT	
Function Name	HAL_StatusTypeDef HAL_TIM_IC_Stop_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Input Capture measurement in interrupt mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> HAL status
61.3.51 HAL_TIM_IC_Start_DMA	
Function Name	HAL_StatusTypeDef HAL_TIM_IC_Start_DMA (TIM_HandleTypeDef * htim, uint32_t Channel, uint32_t * pData, uint16_t Length)
Function Description	Starts the TIM Input Capture measurement on in DMA mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be enabled. This parameter can

be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected

- **pData:** The destination Buffer address.
- **Length:** The length of data to be transferred from TIM peripheral to memory.

Return values

- HAL status

61.3.52 HAL_TIM_IC_Stop_DMA

Function Name

**HAL_StatusTypeDef HAL_TIM_IC_Stop_DMA
(TIM_HandleTypeDef * htim, uint32_t Channel)**

Function Description

Stops the TIM Input Capture measurement on in DMA mode.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
- **Channel:** TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected

Return values

- HAL status

61.3.53 HAL_TIM_OnePulse_Init

Function Name

**HAL_StatusTypeDef HAL_TIM_OnePulse_Init
(TIM_HandleTypeDef * htim, uint32_t OnePulseMode)**

Function Description

Initializes the TIM One Pulse Time Base according to the specified parameters in the TIM_HandleTypeDef and create the associated handle.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
- **OnePulseMode:** Select the One pulse mode. This parameter can be one of the following values: TIM_OPMODE_SINGLE: Only one pulse will be generated.TIM_OPMODE_REPEATITIVE: Repetitive pulses will be generated.

Return values

- HAL status

61.3.54 HAL_TIM_OnePulse_DelInit

Function Name

**HAL_StatusTypeDef HAL_TIM_OnePulse_DelInit
(TIM_HandleTypeDef * htim)**

Function Description

Deinitializes the TIM One Pulse.

Parameters

- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

Return values

- HAL status

61.3.55 HAL_TIM_OnePulse_MspInit

Function Name	void HAL_TIM_OnePulse_MspInit (TIM_HandleTypeDef * htim)
Function Description	Initializes the TIM One Pulse MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.56 HAL_TIM_OnePulse_MspDeInit

Function Name	void HAL_TIM_OnePulse_MspDeInit (TIM_HandleTypeDef * htim)
Function Description	DeInitializes TIM One Pulse MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.57 HAL_TIM_OnePulse_Start

Function Name	HAL_StatusTypeDef HAL_TIM_OnePulse_Start (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Starts the TIM One Pulse signal generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: : TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.58 HAL_TIM_OnePulse_Stop

Function Name	HAL_StatusTypeDef HAL_TIM_OnePulse_Stop (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Stops the TIM One Pulse signal generation.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: : TIM Channels to be disable. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.59 HAL_TIM_OnePulse_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIM_OnePulse_Start_IT (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Starts the TIM One Pulse signal generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that

- contains the configuration information for TIM module.
- **OutputChannel:** : TIM Channels to be enabled. This parameter can be one of the following values:
TIM_CHANNEL_1: TIM Channel 1
selectedTIM_CHANNEL_2: TIM Channel 2 selected

Return values • HAL status

61.3.60 HAL_TIM_OnePulse_Stop_IT

Function Name	<code>HAL_StatusTypeDef HAL_TIM_OnePulse_Stop_IT (TIM_HandleTypeDef * htim, uint32_t OutputChannel)</code>
Function Description	Stops the TIM One Pulse signal generation in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: : TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selected
Return values	• HAL status

61.3.61 HAL_TIM_Encoder_Init

Function Name	<code>HAL_StatusTypeDef HAL_TIM_Encoder_Init (TIM_HandleTypeDef * htim, TIM_Encoder_InitTypeDef * sConfig)</code>
Function Description	Initializes the TIM Encoder Interface and create the associated handle.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sConfig: TIM Encoder Interface configuration structure
Return values	• HAL status

61.3.62 HAL_TIM_Encoder_DelInit

Function Name	<code>HAL_StatusTypeDef HAL_TIM_Encoder_DelInit (TIM_HandleTypeDef * htim)</code>
Function Description	Deinitializes the TIM Encoder interface.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	• HAL status

61.3.63 HAL_TIM_Encoder_MspInit

Function Name	<code>void HAL_TIM_Encoder_MspInit (TIM_HandleTypeDef * htim)</code>
Function Description	Initializes the TIM Encoder Interface MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

Return values	<ul style="list-style-type: none"> None
61.3.64 HAL_TIM_Encoder_MspDeInit	
Function Name	void HAL_TIM_Encoder_MspDeInit (TIM_HandleTypeDef * htim)
Function Description	DeInitializes TIM Encoder Interface MSP.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> None
61.3.65 HAL_TIM_Encoder_Start	
Function Name	HAL_StatusTypeDef HAL_TIM_Encoder_Start (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Encoder Interface.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_ALL: TIM Channel 1 and TIM Channel 2 are selected
Return values	<ul style="list-style-type: none"> HAL status
61.3.66 HAL_TIM_Encoder_Stop	
Function Name	HAL_StatusTypeDef HAL_TIM_Encoder_Stop (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Encoder Interface.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_ALL: TIM Channel 1 and TIM Channel 2 are selected
Return values	<ul style="list-style-type: none"> HAL status
61.3.67 HAL_TIM_Encoder_Start_IT	
Function Name	HAL_StatusTypeDef HAL_TIM_Encoder_Start_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Encoder Interface in interrupt mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2

selectedTIM_CHANNEL_ALL: TIM Channel 1 and TIM Channel 2 are selected

Return values	<ul style="list-style-type: none"> HAL status
---------------	--

61.3.68 HAL_TIM_Encoder_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIM_Encoder_Stop_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Encoder Interface in interrupt mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_ALL: TIM Channel 1 and TIM Channel 2 are selected
Return values	<ul style="list-style-type: none"> HAL status

61.3.69 HAL_TIM_Encoder_Start_DMA

Function Name	HAL_StatusTypeDef HAL_TIM_Encoder_Start_DMA (TIM_HandleTypeDef * htim, uint32_t Channel, uint32_t * pData1, uint32_t * pData2, uint16_t Length)
Function Description	Starts the TIM Encoder Interface in DMA mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_ALL: TIM Channel 1 and TIM Channel 2 are selected pData1: The destination Buffer address for IC1. pData2: The destination Buffer address for IC2. Length: The length of data to be transferred from TIM peripheral to memory.
Return values	<ul style="list-style-type: none"> HAL status

61.3.70 HAL_TIM_Encoder_Stop_DMA

Function Name	HAL_StatusTypeDef HAL_TIM_Encoder_Stop_DMA (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Encoder Interface in DMA mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_ALL: TIM Channel 1 and TIM Channel 2 are selected

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

61.3.71 HAL_TIM_IRQHandler

Function Name	void HAL_TIM_IRQHandler (TIM_HandleTypeDef * htim)
Function Description	This function handles TIM interrupts requests.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.72 HAL_TIM_OC_ConfigChannel

Function Name	HAL_StatusTypeDef HAL_TIM_OC_ConfigChannel (TIM_HandleTypeDef * htim, TIM_OC_InitTypeDef * sConfig, uint32_t Channel)
Function Description	Initializes the TIM Output Compare Channels according to the specified parameters in the TIM_OC_InitTypeDef.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sConfig: TIM Output Compare configuration structure • Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.73 HAL_TIM_IC_ConfigChannel

Function Name	HAL_StatusTypeDef HAL_TIM_IC_ConfigChannel (TIM_HandleTypeDef * htim, TIM_IC_InitTypeDef * sConfig, uint32_t Channel)
Function Description	Initializes the TIM Input Capture Channels according to the specified parameters in the TIM_IC_InitTypeDef.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sConfig: TIM Input Capture configuration structure • Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.74 HAL_TIM_PWM_ConfigChannel

Function Name	HAL_StatusTypeDef HAL_TIM_PWM_ConfigChannel (TIM_HandleTypeDef * htim, TIM_OC_InitTypeDef * sConfig, uint32_t Channel)
---------------	---

Function Description	Initializes the TIM PWM channels according to the specified parameters in the TIM_OC_InitTypeDef.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sConfig: TIM PWM configuration structure • Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.75 HAL_TIM_OnePulse_ConfigChannel

Function Name	HAL_StatusTypeDef HAL_TIM_OnePulse_ConfigChannel (TIM_HandleTypeDef * htim, TIM_OnePulse_InitTypeDef * sConfig, uint32_t OutputChannel, uint32_t InputChannel)
Function Description	Initializes the TIM One Pulse Channels according to the specified parameters in the TIM_OnePulse_InitTypeDef.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sConfig: TIM One Pulse configuration structure • OutputChannel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selected • InputChannel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selected
Return values	<ul style="list-style-type: none"> • HAL status

61.3.76 HAL_TIM_DMABurst_WriteStart

Function Name	HAL_StatusTypeDef HAL_TIM_DMABurst_WriteStart (TIM_HandleTypeDef * htim, uint32_t BurstBaseAddress, uint32_t BurstRequestSrc, uint32_t * BurstBuffer, uint32_t BurstLength)
Function Description	Configure the DMA Burst to transfer Data from the memory to the TIM peripheral.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • BurstBaseAddress: TIM Base address from when the DMA will starts the Data write. This parameters can be on of the following values: TIM_DMABASE_CR1TIM_DMABASE_CR2TIM_DMABASE_SMCRTIM_DMABASE_DIERTIM_DMABASE_SRTIM_DMABASE_EGRTIM_DMABASE_CCMR1TIM_DMABASE_CCMR2TIM_DMABASE_CCERTIM_DMABASE_CNTTIM_DMABASE_PSCTIM_DMABASE_ARRTIM_DMABASE_RCRTIM_DMABASE_CCR1TIM_DMABASE_CCR2TIM_DMABASE_CCR3TIM_DMABASE_CCR4TIM_DMABASE_BDRTIM_DMABASE_DCR

- **BurstRequestSrc:** TIM DMA Request sources. This parameters can be on of the following values: TIM_DMA_UPDATE: TIM update Interrupt sourceTIM_DMA_CC1: TIM Capture Compare 1 DMA sourceTIM_DMA_CC2: TIM Capture Compare 2 DMA sourceTIM_DMA_CC3: TIM Capture Compare 3 DMA sourceTIM_DMA_CC4: TIM Capture Compare 4 DMA sourceTIM_DMA_COM: TIM Commutation DMA sourceTIM_DMA_TRIGGER: TIM Trigger DMA source
 - **BurstBuffer:** The Buffer address.
 - **BurstLength:** DMA Burst length. This parameter can be one value between TIM_DMABURSTLENGTH_1TRANSFER and TIM_DMABURSTLENGTH_18TRANSFERS.
- Return values**
- HAL status

61.3.77 HAL_TIM_DMABurst_WriteStop

Function Name	<code>HAL_StatusTypeDef HAL_TIM_DMABurst_WriteStop (TIM_HandleTypeDef * htim, uint32_t BurstRequestSrc)</code>
Function Description	Stops the TIM DMA Burst mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • BurstRequestSrc: TIM DMA Request sources to disable
Return values	<ul style="list-style-type: none"> • HAL status

61.3.78 HAL_TIM_DMABurst_ReadStart

Function Name	<code>HAL_StatusTypeDef HAL_TIM_DMABurst_ReadStart (TIM_HandleTypeDef * htim, uint32_t BurstBaseAddress, uint32_t BurstRequestSrc, uint32_t * BurstBuffer, uint32_t BurstLength)</code>
Function Description	Configure the DMA Burst to transfer Data from the TIM peripheral to the memory.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • BurstBaseAddress: TIM Base address from when the DMA will starts the Data read. This parameters can be on of the following values: TIM_DMABASE_CR1TIM_DMABASE_CR2TIM_DMABASE_SMCR TIM_DMABASE_DIERTIM_DMABASE_SRTIM_DMABASE_EGRTI M_DMABASE_CCMR1TIM_DMABASE_CCMR2TIM_DMABASE_C CERTIM_DMABASE_CNTTIM_DMABASE_PSCTIM_DMABASE_A RRTIM_DMABASE_RCRTIM_DMABASE_CCR1TIM_DMABASE_C CR2TIM_DMABASE_CCR3TIM_DMABASE_CCR4TIM_DMABASE_BDTRTIM_DMABASE_DCR • BurstRequestSrc: TIM DMA Request sources. This parameters can be on of the following values: TIM_DMA_UPDATE: TIM update Interrupt sourceTIM_DMA_CC1: TIM Capture Compare 1 DMA sourceTIM_DMA_CC2: TIM Capture Compare 2 DMA sourceTIM_DMA_CC3: TIM Capture Compare 3 DMA sourceTIM_DMA_CC4: TIM Capture Compare 4 DMA sourceTIM_DMA_COM: TIM Commutation DMA sourceTIM_DMA_TRIGGER: TIM Trigger DMA source

- **BurstBuffer:** The Buffer address.
- **BurstLength:** DMA Burst length. This parameter can be one value between TIM_DMABURSTLENGTH_1TRANSFER and TIM_DMABURSTLENGTH_18TRANSFERS.

Return values • HAL status

61.3.79 HAL_TIM_DMABurst_ReadStop

Function Name **HAL_StatusTypeDef HAL_TIM_DMABurst_ReadStop
(TIM_HandleTypeDef *htim, uint32_t BurstRequestSrc)**

Function Description Stop the DMA burst reading.

- Parameters
- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
 - **BurstRequestSrc:** TIM DMA Request sources to disable.

Return values • HAL status

61.3.80 HAL_TIM_GenerateEvent

Function Name **HAL_StatusTypeDef HAL_TIM_GenerateEvent
(TIM_HandleTypeDef *htim, uint32_t EventSource)**

Function Description Generate a software event.

- Parameters
- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
 - **EventSource:** specifies the event source. This parameter can be one of the following values:
TIM_EVENTSOURCE_UPDATE: Timer update Event
sourceTIM_EVENTSOURCE_CC1: Timer Capture Compare 1 Event sourceTIM_EVENTSOURCE_CC2: Timer Capture Compare 2 Event sourceTIM_EVENTSOURCE_CC3: Timer Capture Compare 3 Event
sourceTIM_EVENTSOURCE_CC4: Timer Capture Compare 4 Event sourceTIM_EVENTSOURCE_COM: Timer COM event sourceTIM_EVENTSOURCE_TRIGGER: Timer Trigger Event sourceTIM_EVENTSOURCE_BREAK: Timer Break event source

Return values • HAL status

- Notes
- TIM6 and TIM7 can only generate an update event.
 - TIM_EVENTSOURCE_COM and TIM_EVENTSOURCE_BREAK are used only with TIM1 and TIM8.

61.3.81 HAL_TIM_ConfigOCrefClear

Function Name **HAL_StatusTypeDef HAL_TIM_ConfigOCrefClear
(TIM_HandleTypeDef *htim, TIM_ClearInputConfigTypeDef *sClearInputConfig, uint32_t Channel)**

Function Description Configures the OCRef clear feature.

- Parameters
- **htim:** pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

- **sClearInputConfig:** pointer to a TIM_ClearInputConfigTypeDef structure that contains the OCREF clear feature and parameters for the TIM peripheral.
 - **Channel:** specifies the TIM Channel. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
- Return values**
- HAL status

61.3.82 HAL_TIM_ConfigClockSource

Function Name	HAL_StatusTypeDef HAL_TIM_ConfigClockSource (TIM_HandleTypeDef * htim, TIM_ClockConfigTypeDef * sClockSourceConfig)
Function Description	Configures the clock source to be used.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sClockSourceConfig: pointer to a TIM_ClockConfigTypeDef structure that contains the clock source information for the TIM peripheral.
Return values	<ul style="list-style-type: none"> • HAL status

61.3.83 HAL_TIM_ConfigTI1Input

Function Name	HAL_StatusTypeDef HAL_TIM_ConfigTI1Input (TIM_HandleTypeDef * htim, uint32_t TI1_Selection)
Function Description	Selects the signal connected to the TI1 input: direct from CH1_input or a XOR combination between CH1_input, CH2_input & CH3_input.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • TI1_Selection: Indicate whether or not channel 1 is connected to the output of a XOR gate. This parameter can be one of the following values: TIM_TI1SELECTION_CH1: The TIMx_CH1 pin is connected to TI1 inputTIM_TI1SELECTION_XORCOMBINATION: The TIMx_CH1, CH2 and CH3 pins are connected to the TI1 input (XOR combination)
Return values	<ul style="list-style-type: none"> • HAL status

61.3.84 HAL_TIM_SlaveConfigSynchronization

Function Name	HAL_StatusTypeDef HAL_TIM_SlaveConfigSynchronization (TIM_HandleTypeDef * htim, TIM_SlaveConfigTypeDef * sSlaveConfig)
Function Description	Configures the TIM in Slave mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sSlaveConfig: pointer to a TIM_SlaveConfigTypeDef structure that contains the slave configuration information for the TIM peripheral.

structure that contains the selected trigger (internal trigger input, filtered timer input or external trigger input) and the) and the Slave mode (Disable, Reset, Gated, Trigger, External clock mode 1).

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

61.3.85 HAL_TIM_SlaveConfigSynchronization_IT

Function Name	HAL_StatusTypeDef HAL_TIM_SlaveConfigSynchronization_IT (TIM_HandleTypeDef * htim, TIM_SlaveConfigTypeDef * sSlaveConfig)
Function Description	Configures the TIM in Slave mode in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: TIM handle. • sSlaveConfig: pointer to a TIM_SlaveConfigTypeDef structure that contains the selected trigger (internal trigger input, filtered timer input or external trigger input) and the) and the Slave mode (Disable, Reset, Gated, Trigger, External clock mode 1).
Return values	<ul style="list-style-type: none"> • HAL status

61.3.86 HAL_TIM_ReadCapturedValue

Function Name	uint32_t HAL_TIM_ReadCapturedValue (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Read the captured value from Capture Compare unit.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channels to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • Captured value

61.3.87 HAL_TIM_PeriodElapsedCallback

Function Name	void HAL_TIM_PeriodElapsedCallback (TIM_HandleTypeDef * htim)
Function Description	Period elapsed callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.88 HAL_TIM_OC_DelayElapsedCallback

Function Name	void HAL_TIM_OC_DelayElapsedCallback (TIM_HandleTypeDef * htim)
---------------	--

Function Description	Output Compare callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.89 HAL_TIM_IC_CaptureCallback

Function Name	void HAL_TIM_IC_CaptureCallback (TIM_HandleTypeDef * htim)
Function Description	Input Capture callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.90 HAL_TIM_PWM_PulseFinishedCallback

Function Name	void HAL_TIM_PWM_PulseFinishedCallback (TIM_HandleTypeDef * htim)
Function Description	PWM Pulse finished callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.91 HAL_TIM_TriggerCallback

Function Name	void HAL_TIM_TriggerCallback (TIM_HandleTypeDef * htim)
Function Description	Hall Trigger detection callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.92 HAL_TIM_ErrorCallback

Function Name	void HAL_TIM_ErrorCallback (TIM_HandleTypeDef * htim)
Function Description	Timer error callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

61.3.93 HAL_TIM_Base_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIM_Base_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM Base state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that

contains the configuration information for TIM module.

Return values	<ul style="list-style-type: none"> • HAL state
---------------	---

61.3.94 HAL_TIM_OC_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIM_OC_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM OC state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL state

61.3.95 HAL_TIM_PWM_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIM_PWM_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM PWM state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL state

61.3.96 HAL_TIM_IC_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIM_IC_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM Input Capture state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL state

61.3.97 HAL_TIM_OnePulse_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIM_OnePulse_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM One Pulse Mode state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL state

61.3.98 HAL_TIM_Encoder_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIM_Encoder_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM Encoder Mode state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

61.4 TIM Firmware driver defines

61.4.1 TIM

TIM AOE Bit State

TIM_AUTOMATICOUTPUT_ENABLE
TIM_AUTOMATICOUTPUT_DISABLE

TIM Break Input State

TIM_BREAK_ENABLE
TIM_BREAK_DISABLE

TIM Break Polarity

TIM_BREAKPOLARITY_LOW
TIM_BREAKPOLARITY_HIGH

TIM Channel

TIM_CHANNEL_1
TIM_CHANNEL_2
TIM_CHANNEL_3
TIM_CHANNEL_4
TIM_CHANNEL_ALL

TIM Clear Input Polarity

TIM_CLEARINPUTPOLARITY_INVERTED Polarity for ETRx pin
TIM_CLEARINPUTPOLARITY_NONINVERTED Polarity for ETRx pin

TIM Clear Input Prescaler

TIM_CLEARINPUTPRESCALER_DIV1	No prescaler is used
TIM_CLEARINPUTPRESCALER_DIV2	Prescaler for External ETR pin: Capture performed once every 2 events.
TIM_CLEARINPUTPRESCALER_DIV4	Prescaler for External ETR pin: Capture performed once every 4 events.
TIM_CLEARINPUTPRESCALER_DIV8	Prescaler for External ETR pin: Capture performed once every 8 events.

TIM Clear Input Source

TIM_CLEARINPUTSOURCE_ETR
TIM_CLEARINPUTSOURCE_NONE

TIM Clock Division

TIM_CLOCKDIVISION_DIV1
TIM_CLOCKDIVISION_DIV2
TIM_CLOCKDIVISION_DIV4

TIM Clock Polarity

TIM_CLOCKPOLARITY_INVERTED	Polarity for ETRx clock sources
TIM_CLOCKPOLARITY_NONINVERTED	Polarity for ETRx clock sources
TIM_CLOCKPOLARITY_RISING	Polarity for TIx clock sources
TIM_CLOCKPOLARITY_FALLING	Polarity for TIx clock sources
TIM_CLOCKPOLARITY_BOTHEDGE	Polarity for TIx clock sources

TIM Clock Prescaler

TIM_CLOCKPRESCALER_DIV1	No prescaler is used
TIM_CLOCKPRESCALER_DIV2	Prescaler for External ETR Clock: Capture performed once every 2 events.
TIM_CLOCKPRESCALER_DIV4	Prescaler for External ETR Clock: Capture performed once every 4 events.
TIM_CLOCKPRESCALER_DIV8	Prescaler for External ETR Clock: Capture performed once every 8 events.

TIM Clock Source

TIM_CLOCKSOURCE_ETRMODE2
TIM_CLOCKSOURCE_INTERNAL
TIM_CLOCKSOURCE_ITR0
TIM_CLOCKSOURCE_ITR1
TIM_CLOCKSOURCE_ITR2
TIM_CLOCKSOURCE_ITR3
TIM_CLOCKSOURCE_TI1ED
TIM_CLOCKSOURCE_TI1
TIM_CLOCKSOURCE_TI2
TIM_CLOCKSOURCE_ETRMODE1

TIM Commutation Source

TIM_COMMUTATION_TRGI
TIM_COMMUTATION_SOFTWARE

TIM Counter Mode

TIM_COUNTERMODE_UP
TIM_COUNTERMODE_DOWN
TIM_COUNTERMODE_CENTERALIGNED1
TIM_COUNTERMODE_CENTERALIGNED2
TIM_COUNTERMODE_CENTERALIGNED3

TIM DMA Base address

TIM_DMABASE_CR1
TIM_DMABASE_CR2

TIM_DMABASE_SMCR
TIM_DMABASE_DIER
TIM_DMABASE_SR
TIM_DMABASE_EGR
TIM_DMABASE_CCMR1
TIM_DMABASE_CCMR2
TIM_DMABASE_CCER
TIM_DMABASE_CNT
TIM_DMABASE_PSC
TIM_DMABASE_ARR
TIM_DMABASE_RCR
TIM_DMABASE_CCR1
TIM_DMABASE_CCR2
TIM_DMABASE_CCR3
TIM_DMABASE_CCR4
TIM_DMABASE_BDTR
TIM_DMABASE_DCR
TIM_DMABASE_OR
TIM DMA Burst Length
TIM_DMABURSTLENGTH_1TRANSFER
TIM_DMABURSTLENGTH_2TRANSFERS
TIM_DMABURSTLENGTH_3TRANSFERS
TIM_DMABURSTLENGTH_4TRANSFERS
TIM_DMABURSTLENGTH_5TRANSFERS
TIM_DMABURSTLENGTH_6TRANSFERS
TIM_DMABURSTLENGTH_7TRANSFERS
TIM_DMABURSTLENGTH_8TRANSFERS
TIM_DMABURSTLENGTH_9TRANSFERS
TIM_DMABURSTLENGTH_10TRANSFERS
TIM_DMABURSTLENGTH_11TRANSFERS
TIM_DMABURSTLENGTH_12TRANSFERS
TIM_DMABURSTLENGTH_13TRANSFERS
TIM_DMABURSTLENGTH_14TRANSFERS
TIM_DMABURSTLENGTH_15TRANSFERS
TIM_DMABURSTLENGTH_16TRANSFERS
TIM_DMABURSTLENGTH_17TRANSFERS

TIM_DMABURSTLENGTH_18TRANSFERS

TIM DMA sources

TIM_DMA_UPDATE
TIM_DMA_CC1
TIM_DMA_CC2
TIM_DMA_CC3
TIM_DMA_CC4
TIM_DMA_COM
TIM_DMA_TRIGGER

TIM Encoder Mode

TIM_ENCODERMODE_TI1
TIM_ENCODERMODE_TI2
TIM_ENCODERMODE_TI12

TIM ETR Polarity

TIM_ETRPOLARITY_INVERTED Polarity for ETR source
TIM_ETRPOLARITY_NONINVERTED Polarity for ETR source

TIM ETR Prescaler

TIM_ETRPRESCALER_DIV1 No prescaler is used
TIM_ETRPRESCALER_DIV2 ETR input source is divided by 2
TIM_ETRPRESCALER_DIV4 ETR input source is divided by 4
TIM_ETRPRESCALER_DIV8 ETR input source is divided by 8

TIM Event Source

TIM_EVENTSOURCE_UPDATE
TIM_EVENTSOURCE_CC1
TIM_EVENTSOURCE_CC2
TIM_EVENTSOURCE_CC3
TIM_EVENTSOURCE_CC4
TIM_EVENTSOURCE_COM
TIM_EVENTSOURCE_TRIGGER
TIM_EVENTSOURCE_BREAK

TIM Exported Macros

`__HAL_TIM_RESET_HANDLE_ST
ATE` **Description:**
 • Reset TIM handle state.
Parameters:
 • `__HANDLE__`: TIM handle
Return value:

- None

`__HAL_TIM_ENABLE`

Description:

- Enable the TIM peripheral.

Parameters:

- `__HANDLE__`: TIM handle

Return value:

- None

`__HAL_TIM_MOE_ENABLE`

Description:

- Enable the TIM main Output.

Parameters:

- `__HANDLE__`: TIM handle

Return value:

- None

`__HAL_TIM_DISABLE`

Description:

- Disable the TIM peripheral.

Parameters:

- `__HANDLE__`: TIM handle

Return value:

- None

`__HAL_TIM_MOE_DISABLE`

Description:

- Disable the TIM main Output.

Parameters:

- `__HANDLE__`: TIM handle

Return value:

- None

`__HAL_TIM_ENABLE_IT`

`__HAL_TIM_ENABLE_DMA`

`__HAL_TIM_DISABLE_IT`

`__HAL_TIM_DISABLE_DMA`

`__HAL_TIM_GET_FLAG`

`__HAL_TIM_CLEAR_FLAG`

`__HAL_TIM_GET_IT_SOURCE`

`__HAL_TIM_CLEAR_IT`

`__HAL_TIM_IS_TIM_COUNTING_DOWN`

`__HAL_TIM_SET_PRESCALER`

TIM_SET_ICPRESCALERVALUE
 TIM_RESET_ICPRESCALERVAL
 UE
 TIM_SET_CAPTUREPOLARITY
 TIM_RESET_CAPTUREPOLARIT
 Y
 __HAL_TIM_SET_COMPARE

Description:

- Sets the TIM Capture Compare Register value on runtime without calling another time ConfigChannel function.

Parameters:

- __HANDLE__: TIM handle.
- __CHANNEL__: : TIM Channels to be configured. This parameter can be one of the following values:
 - TIM_CHANNEL_1: TIM Channel 1 selected
 - TIM_CHANNEL_2: TIM Channel 2 selected
 - TIM_CHANNEL_3: TIM Channel 3 selected
 - TIM_CHANNEL_4: TIM Channel 4 selected
- __COMPARE__: specifies the Capture Compare register new value.

Return value:

- None

__HAL_TIM_GET_COMPARE

Description:

- Gets the TIM Capture Compare Register value on runtime.

Parameters:

- __HANDLE__: TIM handle.
- __CHANNEL__: : TIM Channel associated with the capture compare register This parameter can be one of the following values:
 - TIM_CHANNEL_1: get capture/compare 1 register value
 - TIM_CHANNEL_2: get capture/compare 2 register value
 - TIM_CHANNEL_3: get capture/compare 3 register value
 - TIM_CHANNEL_4: get capture/compare 4 register value

Return value:

- None

__HAL_TIM_SET_COUNTER

Description:

- Sets the TIM Counter Register value on runtime.

Parameters:

- `__HANDLE__`: TIM handle.
- `__COUNTER__`: specifies the Counter register new value.

Return value:

- None

`__HAL_TIM_GET_COUNTER`

- Gets the TIM Counter Register value on runtime.

Parameters:

- `__HANDLE__`: TIM handle.

Return value:

- None

`__HAL_TIM_SET_AUTORELOAD`

- Sets the TIM Autoreload Register value on runtime without calling another time any Init function.

Parameters:

- `__HANDLE__`: TIM handle.
- `__AUTORELOAD__`: specifies the Counter register new value.

Return value:

- None

`__HAL_TIM_GET_AUTORELOAD`

Description:

- Gets the TIM Autoreload Register value on runtime.

Parameters:

- `__HANDLE__`: TIM handle.

Return value:

- None

`__HAL_TIM_SET_CLOCKDIVISION`
N

Description:

- Sets the TIM Clock Division value on runtime without calling another time any Init function.

Parameters:

- `__HANDLE__`: TIM handle.
- `__CKD__`: specifies the clock division value.
This parameter can be one of the following value:
 - `TIM_CLOCKDIVISION_DIV1`

- TIM_CLOCKDIVISION_DIV2
- TIM_CLOCKDIVISION_DIV4

Return value:

- None

`__HAL_TIM_GET_CLOCKDIVISION`

Description:

- Gets the TIM Clock Division value on runtime.

Parameters:

- `__HANDLE__`: TIM handle.

Return value:

- None

`__HAL_TIM_SET_ICPRESCALER`

Description:

- Sets the TIM Input Capture prescaler on runtime without calling another time

Parameters:

- `__HANDLE__`: TIM handle.
- `__CHANNEL__`: : TIM Channels to be configured. This parameter can be one of the following values:
 - `TIM_CHANNEL_1`: TIM Channel 1 selected
 - `TIM_CHANNEL_2`: TIM Channel 2 selected
 - `TIM_CHANNEL_3`: TIM Channel 3 selected
 - `TIM_CHANNEL_4`: TIM Channel 4 selected
- `__ICPSC__`: specifies the Input Capture4 prescaler new value. This parameter can be one of the following values:
 - `TIM_ICPSC_DIV1`: no prescaler
 - `TIM_ICPSC_DIV2`: capture is done once every 2 events
 - `TIM_ICPSC_DIV4`: capture is done once every 4 events
 - `TIM_ICPSC_DIV8`: capture is done once every 8 events

Return value:

- None

`__HAL_TIM_GET_ICPRESCALER`

Description:

- Gets the TIM Input Capture prescaler on runtime.

Parameters:

- `__HANDLE__`: TIM handle.
- `__CHANNEL__`: : TIM Channels to be configured. This parameter can be one of the

following values:

- TIM_CHANNEL_1: get input capture 1 prescaler value
- TIM_CHANNEL_2: get input capture 2 prescaler value
- TIM_CHANNEL_3: get input capture 3 prescaler value
- TIM_CHANNEL_4: get input capture 4 prescaler value

Return value:

- None

[__HAL_TIM_URS_ENABLE](#)

Description:

- Set the Update Request Source (URS) bit of the TIMx_CR1 register.

Parameters:

- [__HANDLE__](#): TIM handle.

Return value:

- None

Notes:

- When the USR bit of the TIMx_CR1 register is set, only counter overflow/underflow generates an update interrupt or DMA request (if enabled)

[__HAL_TIM_URS_DISABLE](#)

Description:

- Reset the Update Request Source (URS) bit of the TIMx_CR1 register.

Parameters:

- [__HANDLE__](#): TIM handle.

Return value:

- None

Notes:

- When the USR bit of the TIMx_CR1 register is reset, any of the following events generate an update interrupt or DMA request (if enabled):
 - _ Counter overflow/underflow _ Setting the UG bit _ Update generation through the slave mode controller

[__HAL_TIM_SET_CAPTUREPOLARITY](#)

Description:

- Sets the TIM Capture x input polarity on runtime.

Parameters:

- [__HANDLE__](#): TIM handle.
- [__CHANNEL__](#): TIM Channels to be configured. This parameter can be one of the

following values:

- TIM_CHANNEL_1: TIM Channel 1 selected
- TIM_CHANNEL_2: TIM Channel 2 selected
- TIM_CHANNEL_3: TIM Channel 3 selected
- TIM_CHANNEL_4: TIM Channel 4 selected
- __POLARITY__: Polarity for TIx source
 - TIM_INPUTCHANNELPOLARITY_RISING : Rising Edge
 - TIM_INPUTCHANNELPOLARITY_FALLING : Falling Edge
 - TIM_INPUTCHANNELPOLARITY_BOTHEDGE: Rising and Falling Edge

Return value:

- None

Notes:

- The polarity
TIM_INPUTCHANNELPOLARITY_BOTHEDGE is not authorized for TIM Channel 4.

TIM Flag definition

TIM_FLAG_UPDATE
 TIM_FLAG_CC1
 TIM_FLAG_CC2
 TIM_FLAG_CC3
 TIM_FLAG_CC4
 TIM_FLAG_COM
 TIM_FLAG_TRIGGER
 TIM_FLAG_BREAK
 TIM_FLAG_CC1OF
 TIM_FLAG_CC2OF
 TIM_FLAG_CC3OF
 TIM_FLAG_CC4OF

TIM Input Capture Polarity

TIM_ICPOLARITY_RISING
 TIM_ICPOLARITY_FALLING
 TIM_ICPOLARITY_BOTHEDGE

TIM Input Capture Prescaler

TIM_ICPSC_DIV1	Capture performed each time an edge is detected on the capture input
----------------	--

TIM_ICPSC_DIV2	Capture performed once every 2 events
TIM_ICPSC_DIV4	Capture performed once every 4 events
TIM_ICPSC_DIV8	Capture performed once every 8 events

TIM Input Capture Selection

TIM_ICSELECTION_DIRECTTI	TIM Input 1, 2, 3 or 4 is selected to be connected to IC1, IC2, IC3 or IC4, respectively
TIM_ICSELECTION_INDIRECTTI	TIM Input 1, 2, 3 or 4 is selected to be connected to IC2, IC1, IC4 or IC3, respectively
TIM_ICSELECTION_TRC	TIM Input 1, 2, 3 or 4 is selected to be connected to TRC

TIM Input Channel Polarity

TIM_INPUTCHANNELPOLARITY_RISING	Polarity for TIx source
TIM_INPUTCHANNELPOLARITY_FALLING	Polarity for TIx source
TIM_INPUTCHANNELPOLARITY_BOTHEDGE	Polarity for TIx source

TIM Interrupt definition

TIM_IT_UPDATE
 TIM_IT_CC1
 TIM_IT_CC2
 TIM_IT_CC3
 TIM_IT_CC4
 TIM_IT_COM
 TIM_IT_TRIGGER
 TIM_IT_BREAK

TIM Private macros to check input parameters

IS_TIM_COUNTER_MODE
 IS_TIM_CLOCKDIVISION_DIV
 IS_TIM_PWM_MODE
 IS_TIM_OC_MODE
 IS_TIM_FAST_STATE
 IS_TIM_OC_POLARITY
 IS_TIM_OCN_POLARITY
 IS_TIM_OCIDLE_STATE
 IS_TIM_OCNIDLE_STATE
 IS_TIM_CHANNELS
 IS_TIM_OPM_CHANNELS
 IS_TIM_COMPLEMENTARY_CHANNELS
 IS_TIM_IC_POLARITY

IS_TIM_IC_SELECTION
IS_TIM_IC_PRESCALER
IS_TIM_OPM_MODE
IS_TIM_DMA_SOURCE
IS_TIM_ENCODER_MODE
IS_TIM_EVENT_SOURCE
IS_TIM_CLOCKSOURCE
IS_TIM_CLOCKPOLARITY
IS_TIM_CLOCKPRESCALER
IS_TIM_CLOCKFILTER
IS_TIM_CLEARINPUT_SOURCE
IS_TIM_CLEARINPUT_POLARITY
IS_TIM_CLEARINPUT_PRESCALER
IS_TIM_CLEARINPUT_FILTER
IS_TIM_OSSR_STATE
IS_TIM_OSSI_STATE
IS_TIM_LOCK_LEVEL
IS_TIM_BREAK_STATE
IS_TIM_BREAK_POLARITY
IS_TIM_AUTOMATIC_OUTPUT_STATE
IS_TIM_TRGO_SOURCE
IS_TIM_SLAVE_MODE
IS_TIM_MSM_STATE
IS_TIM_TRIGGER_SELECTION
IS_TIM_INTERNAL_TRIGGEREVENT_SELECTION
IS_TIM_TRIGGERPOLARITY
IS_TIM_TRIGGERPRESCALER
IS_TIM_TRIGGERFILTER
IS_TIM_TI1SELECTION
IS_TIM_DMA_BASE
IS_TIM_DMA_LENGTH
IS_TIM_IC_FILTER
TIM Lock level
TIM_LOCKLEVEL_OFF
TIM_LOCKLEVEL_1
TIM_LOCKLEVEL_2

TIM_LOCKLEVEL_3

TIM Mask Definition

TIM_CCER_CCxE_MASK

TIM_CCER_CCxNE_MASK

TIM Master Mode Selection

TIM_TRGO_RESET

TIM_TRGO_ENABLE

TIM_TRGO_UPDATE

TIM_TRGO_OC1

TIM_TRGO_OC1REF

TIM_TRGO_OC2REF

TIM_TRGO_OC3REF

TIM_TRGO_OC4REF

TIM Master Slave Mode

TIM_MASTERSLAVEMODE_ENABLE

TIM_MASTERSLAVEMODE_DISABLE

TIM One Pulse Mode

TIM_OPMODE_SINGLE

TIM_OPMODE_REPETITIVE

TIM OSSI OffState Selection for Idle mode state

TIM_OSSI_ENABLE

TIM_OSSI_DISABLE

TIM OSSR OffState Selection for Run mode state

TIM_OSSR_ENABLE

TIM_OSSR_DISABLE

TIM Output Compare and PWM modes

TIM_OCMODE_TIMING

TIM_OCMODE_ACTIVE

TIM_OCMODE_INACTIVE

TIM_OCMODE_TOGGLE

TIM_OCMODE_PWM1

TIM_OCMODE_PWM2

TIM_OCMODE_FORCED_ACTIVE

TIM_OCMODE_FORCED_INACTIVE

TIM Output Compare Idle State

TIM_OCIDLESTATE_SET

TIM_OCIDLESTATE_RESET	
<i>TIM Output Compare N Idle State</i>	
TIM_OCNIDLESTATE_SET	
TIM_OCNIDLESTATE_RESET	
<i>TIM Output CompareN Polarity</i>	
TIM_OCPOLARITY_HIGH	
TIM_OCPOLARITY_LOW	
<i>TIM Output Compare Polarity</i>	
TIM_OCPOLARITY_HIGH	
TIM_OCPOLARITY_LOW	
<i>TIM Output Fast State</i>	
TIM_OCFAST_DISABLE	
TIM_OCFAST_ENABLE	
<i>TIM Slave Mode</i>	
TIM_SLAVEMODE_DISABLE	
TIM_SLAVEMODE_RESET	
TIM_SLAVEMODE_GATED	
TIM_SLAVEMODE_TRIGGER	
TIM_SLAVEMODE_EXTERNAL1	
<i>TIM TI1 Selection</i>	
TIM_TI1SELECTION_CH1	
TIM_TI1SELECTION_XORCOMBINATION	
<i>TIM Trigger Polarity</i>	
TIM_TRIGGERPOLARITY_INVERTED	Polarity for ETRx trigger sources
TIM_TRIGGERPOLARITY_NONINVERTED	Polarity for ETRx trigger sources
TIM_TRIGGERPOLARITY_RISING	Polarity for TIxFPx or TI1_ED trigger sources
TIM_TRIGGERPOLARITY_FALLING	Polarity for TIxFPx or TI1_ED trigger sources
TIM_TRIGGERPOLARITY_BOTHEDGE	Polarity for TIxFPx or TI1_ED trigger sources
<i>TIM Trigger Prescaler</i>	
TIM_TRIGGERPRESCALER_DIV1	No prescaler is used
TIM_TRIGGERPRESCALER_DIV2	Prescaler for External ETR Trigger: Capture performed once every 2 events.
TIM_TRIGGERPRESCALER_DIV4	Prescaler for External ETR Trigger: Capture performed once every 4 events.
TIM_TRIGGERPRESCALER_DIV8	Prescaler for External ETR Trigger: Capture

TIM Trigger Selection

TIM_TS_ITR0
TIM_TS_ITR1
TIM_TS_ITR2
TIM_TS_ITR3
TIM_TS_TI1F_ED
TIM_TS_TI1FP1
TIM_TS_TI2FP2
TIM_TS_ETRF
TIM_TS_NONE

62 HAL TIM Extension Driver

62.1 HAL TIM Extension Driver

62.2 TIMEx Firmware driver registers structures

62.2.1 TIM_HallSensor_InitTypeDef

Data Fields

- *uint32_t IC1Polarity*
- *uint32_t IC1Prescaler*
- *uint32_t IC1Filter*
- *uint32_t Commutation_Delay*

Field Documentation

- *uint32_t TIM_HallSensor_InitTypeDef::IC1Polarity*
Specifies the active edge of the input signal. This parameter can be a value of [*TIM_Input_Capture_Polarity*](#)
- *uint32_t TIM_HallSensor_InitTypeDef::IC1Prescaler*
Specifies the Input Capture Prescaler. This parameter can be a value of [*TIM_Input_Capture_Prescaler*](#)
- *uint32_t TIM_HallSensor_InitTypeDef::IC1Filter*
Specifies the input capture filter. This parameter can be a number between Min_Data = 0x0 and Max_Data = 0xF
- *uint32_t TIM_HallSensor_InitTypeDef::Commutation_Delay*
Specifies the pulse value to be loaded into the Capture Compare Register. This parameter can be a number between Min_Data = 0x0000 and Max_Data = 0xFFFF

62.2.2 TIM_MasterConfigTypeDef

Data Fields

- *uint32_t MasterOutputTrigger*
- *uint32_t MasterSlaveMode*

Field Documentation

- *uint32_t TIM_MasterConfigTypeDef::MasterOutputTrigger*
Trigger output (TRGO) selection. This parameter can be a value of [*TIM_Master_Mode_Selection*](#)
- *uint32_t TIM_MasterConfigTypeDef::MasterSlaveMode*
Master/slave mode selection. This parameter can be a value of [*TIM_Master_Slave_Mode*](#)

62.2.3 TIM_BreakDeadTimeConfigTypeDef

Data Fields

- *uint32_t OffStateRunMode*
- *uint32_t OffStateIDLEMode*
- *uint32_t LockLevel*
- *uint32_t DeadTime*
- *uint32_t BreakState*
- *uint32_t BreakPolarity*
- *uint32_t AutomaticOutput*

Field Documentation

- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::OffStateRunMode***
TIM off state in run mode. This parameter can be a value of
[*TIM_OSSR_Off_State_Selection_for_Run_mode_state*](#)
- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::OffStateIDLEMode***
TIM off state in IDLE mode. This parameter can be a value of
[*TIM_OSSI_Off_State_Selection_for_Idle_mode_state*](#)
- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::LockLevel***
TIM Lock level. This parameter can be a value of [*TIM_Lock_level*](#)
- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::DeadTime***
TIM dead Time. This parameter can be a number between Min_Data = 0x00 and Max_Data = 0xFF
- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::BreakState***
TIM Break State. This parameter can be a value of
[*TIM_Break_Input_enable_disable*](#)
- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::BreakPolarity***
TIM Break input polarity. This parameter can be a value of [*TIM_Break_Polarity*](#)
- ***uint32_t TIM_BreakDeadTimeConfigTypeDef::AutomaticOutput***
TIM Automatic Output Enable state. This parameter can be a value of
[*TIM_AOE_Bit_Set_Reset*](#)

62.3 TIMEx Firmware driver API description

62.3.1 TIMER Extended features

The Timer Extension features include:

1. Complementary outputs with programmable dead-time for :
 - Input Capture
 - Output Compare
 - PWM generation (Edge and Center-aligned Mode)
 - One-pulse mode output
2. Synchronization circuit to control the timer with external signals and to interconnect several timers together.
3. Break input to put the timer output signals in reset state or in a known state.
4. Supports incremental (quadrature) encoder and hall-sensor circuitry for positioning purposes

62.3.2 How to use this driver

1. Initialize the TIM low level resources by implementing the following functions depending from feature used :
 - Complementary Output Compare : HAL_TIM_OC_MspInit()
 - Complementary PWM generation : HAL_TIM_PWM_MspInit()
 - Complementary One-pulse mode output : HAL_TIM_OnePulse_MspInit()
 - Hall Sensor output : HAL_TIM_HallSensor_MspInit()
2. Initialize the TIM low level resources :
 - a. Enable the TIM interface clock using __TIMx_CLK_ENABLE();
 - b. TIM pins configuration
 - Enable the clock for the TIM GPIOs using the following function:
__GPIOx_CLK_ENABLE();
 - Configure these TIM pins in Alternate function mode using
HAL_GPIO_Init();
3. The external Clock can be configured, if needed (the default clock is the internal clock from the APBx), using the following function: HAL_TIM_ConfigClockSource, the clock configuration should be done before any start function.
4. Configure the TIM in the desired functioning mode using one of the initialization function of this driver:
 - HAL_TIMEx_HallSensor_Init and HAL_TIMEx_ConfigCommutationEvent: to use the Timer Hall Sensor Interface and the commutation event with the corresponding Interrupt and DMA request if needed (Note that One Timer is used to interface with the Hall sensor Interface and another Timer should be used to use the commutation event).
5. Activate the TIM peripheral using one of the start functions:
 - Complementary Output Compare : HAL_TIMEx_OCN_Start(),
HAL_TIMEx_OCN_Start_DMA(), HAL_TIMEx_OC_Start_IT()
 - Complementary PWM generation : HAL_TIMEx_PWMN_Start(),
HAL_TIMEx_PWMN_Start_DMA(), HAL_TIMEx_PWMN_Start_IT()
 - Complementary One-pulse mode output : HAL_TIMEx_OnePulseN_Start(),
HAL_TIMEx_OnePulseN_Start_IT()
 - Hall Sensor output : HAL_TIMEx_HallSensor_Start(),
HAL_TIMEx_HallSensor_Start_DMA(), HAL_TIMEx_HallSensor_Start_IT().

62.3.3 Timer Hall Sensor functions

This section provides functions allowing to:

- Initialize and configure TIM HAL Sensor.
- De-initialize TIM HAL Sensor.
- Start the Hall Sensor Interface.
- Stop the Hall Sensor Interface.
- Start the Hall Sensor Interface and enable interrupts.
- Stop the Hall Sensor Interface and disable interrupts.
- Start the Hall Sensor Interface and enable DMA transfers.
- Stop the Hall Sensor Interface and disable DMA transfers.

This section contains the following APIs:

- [**HAL_TIMEx_HallSensor_Init\(\)**](#)
- [**HAL_TIMEx_HallSensor_DeInit\(\)**](#)
- [**HAL_TIMEx_HallSensor_MspInit\(\)**](#)
- [**HAL_TIMEx_HallSensor_MspDeInit\(\)**](#)
- [**HAL_TIMEx_HallSensor_Start\(\)**](#)

- [*HAL_TIMEx_HallSensor_Stop\(\)*](#)
- [*HAL_TIMEx_HallSensor_Start_IT\(\)*](#)
- [*HAL_TIMEx_HallSensor_Stop_IT\(\)*](#)
- [*HAL_TIMEx_HallSensor_Start_DMA\(\)*](#)
- [*HAL_TIMEx_HallSensor_Stop_DMA\(\)*](#)

62.3.4 Timer Complementary Output Compare functions

This section provides functions allowing to:

- Start the Complementary Output Compare/PWM.
- Stop the Complementary Output Compare/PWM.
- Start the Complementary Output Compare/PWM and enable interrupts.
- Stop the Complementary Output Compare/PWM and disable interrupts.
- Start the Complementary Output Compare/PWM and enable DMA transfers.
- Stop the Complementary Output Compare/PWM and disable DMA transfers.

This section contains the following APIs:

- [*HAL_TIMEx_OCN_Start\(\)*](#)
- [*HAL_TIMEx_OCN_Stop\(\)*](#)
- [*HAL_TIMEx_OCN_Start_IT\(\)*](#)
- [*HAL_TIMEx_OCN_Stop_IT\(\)*](#)
- [*HAL_TIMEx_OCN_Start_DMA\(\)*](#)
- [*HAL_TIMEx_OCN_Stop_DMA\(\)*](#)

62.3.5 Timer Complementary PWM functions

This section provides functions allowing to:

- Start the Complementary PWM.
- Stop the Complementary PWM.
- Start the Complementary PWM and enable interrupts.
- Stop the Complementary PWM and disable interrupts.
- Start the Complementary PWM and enable DMA transfers.
- Stop the Complementary PWM and disable DMA transfers.
- Start the Complementary Input Capture measurement.
- Stop the Complementary Input Capture.
- Start the Complementary Input Capture and enable interrupts.
- Stop the Complementary Input Capture and disable interrupts.
- Start the Complementary Input Capture and enable DMA transfers.
- Stop the Complementary Input Capture and disable DMA transfers.
- Start the Complementary One Pulse generation.
- Stop the Complementary One Pulse.
- Start the Complementary One Pulse and enable interrupts.
- Stop the Complementary One Pulse and disable interrupts.

This section contains the following APIs:

- [*HAL_TIMEx_PWMN_Start\(\)*](#)
- [*HAL_TIMEx_PWMN_Stop\(\)*](#)
- [*HAL_TIMEx_PWMN_Start_IT\(\)*](#)
- [*HAL_TIMEx_PWMN_Stop_IT\(\)*](#)
- [*HAL_TIMEx_PWMN_Start_DMA\(\)*](#)
- [*HAL_TIMEx_PWMN_Stop_DMA\(\)*](#)

62.3.6 Timer Complementary One Pulse functions

This section provides functions allowing to:

- Start the Complementary One Pulse generation.
- Stop the Complementary One Pulse.
- Start the Complementary One Pulse and enable interrupts.
- Stop the Complementary One Pulse and disable interrupts.

This section contains the following APIs:

- [*HAL_TIMEx_OnePulseN_Start\(\)*](#)
- [*HAL_TIMEx_OnePulseN_Stop\(\)*](#)
- [*HAL_TIMEx_OnePulseN_Start_IT\(\)*](#)
- [*HAL_TIMEx_OnePulseN_Stop_IT\(\)*](#)

62.3.7 Peripheral Control functions

This section provides functions allowing to:

- Configure The Input Output channels for OC, PWM, IC or One Pulse mode.
- Configure External Clock source.
- Configure Complementary channels, break features and dead time.
- Configure Master and the Slave synchronization.
- Configure the commutation event in case of use of the Hall sensor interface.
- Configure the DMA Burst Mode.

This section contains the following APIs:

- [*HAL_TIMEx_ConfigCommutationEvent\(\)*](#)
- [*HAL_TIMEx_ConfigCommutationEvent_IT\(\)*](#)
- [*HAL_TIMEx_ConfigCommutationEvent_DMA\(\)*](#)
- [*HAL_TIMEx_MasterConfigSynchronization\(\)*](#)
- [*HAL_TIMEx_ConfigBreakDeadTime\(\)*](#)
- [*HAL_TIMEx_RemapConfig\(\)*](#)

62.3.8 Extension Callbacks functions

This section provides Extension TIM callback functions:

- Timer Commutation callback
- Timer Break callback

This section contains the following APIs:

- [*HAL_TIMEx_CommutationCallback\(\)*](#)
- [*HAL_TIMEx_BreakCallback\(\)*](#)
- [*TIMEx_DMACommuationCplt\(\)*](#)

62.3.9 Extension Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_TIMEx_HallSensor_GetState\(\)*](#)

62.3.10 HAL_TIMEx_HallSensor_Init

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Init (TIM_HandleTypeDef * htim, TIM_HallSensor_InitTypeDef *
---------------	--

sConfig)

Function Description	Initializes the TIM Hall Sensor Interface and create the associated handle.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sConfig: TIM Hall Sensor configuration structure
Return values	<ul style="list-style-type: none"> • HAL status

62.3.11 HAL_TIMEx_HallSensor_DelInit

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_DelInit (TIM_HandleTypeDef * htim)
Function Description	Deinitializes the TIM Hall Sensor interface.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.12 HAL_TIMEx_HallSensor_MspInit

Function Name	void HAL_TIMEx_HallSensor_MspInit (TIM_HandleTypeDef * htim)
Function Description	Initializes the TIM Hall Sensor MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

62.3.13 HAL_TIMEx_HallSensor_MspDelInit

Function Name	void HAL_TIMEx_HallSensor_MspDelInit (TIM_HandleTypeDef * htim)
Function Description	Deinitializes TIM Hall Sensor MSP.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

62.3.14 HAL_TIMEx_HallSensor_Start

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Start (TIM_HandleTypeDef * htim)
Function Description	Starts the TIM Hall Sensor Interface.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.15 HAL_TIMEx_HallSensor_Stop

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Stop (TIM_HandleTypeDef * htim)
Function Description	Stops the TIM Hall sensor Interface.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.16 HAL_TIMEx_HallSensor_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Start_IT (TIM_HandleTypeDef * htim)
Function Description	Starts the TIM Hall Sensor Interface in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.17 HAL_TIMEx_HallSensor_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Stop_IT (TIM_HandleTypeDef * htim)
Function Description	Stops the TIM Hall Sensor Interface in interrupt mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.18 HAL_TIMEx_HallSensor_Start_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Start_DMA (TIM_HandleTypeDef * htim, uint32_t * pData, uint16_t Length)
Function Description	Starts the TIM Hall Sensor Interface in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • pData: The destination Buffer address. • Length: The length of data to be transferred from TIM peripheral to memory.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.19 HAL_TIMEx_HallSensor_Stop_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_HallSensor_Stop_DMA (TIM_HandleTypeDef * htim)
Function Description	Stops the TIM Hall Sensor Interface in DMA mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.20 HAL_TIMEx_OCN_Start

Function Name	HAL_StatusTypeDef HAL_TIMEx_OCN_Start (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Output Compare signal generation on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.21 HAL_TIMEx_OCN_Stop

Function Name	HAL_StatusTypeDef HAL_TIMEx_OCN_Stop (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Output Compare signal generation on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.22 HAL_TIMEx_OCN_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_OCN_Start_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the TIM Output Compare signal generation in interrupt mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.23 HAL_TIMEx_OCN_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_OCN_Stop_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
---------------	---

Function Description	Stops the TIM Output Compare signal generation in interrupt mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.24 HAL_TIMEx_OCN_Start_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_OCN_Start_DMA (TIM_HandleTypeDef * htim, uint32_t Channel, uint32_t * pData, uint16_t Length)
Function Description	Starts the TIM Output Compare signal generation in DMA mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected • pData: The source Buffer address. • Length: The length of data to be transferred from memory to TIM peripheral
Return values	<ul style="list-style-type: none"> • HAL status

62.3.25 HAL_TIMEx_OCN_Stop_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_OCN_Stop_DMA (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM Output Compare signal generation in DMA mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.26 HAL_TIMEx_PWMN_Start

Function Name	HAL_StatusTypeDef HAL_TIMEx_PWMN_Start (TIM_HandleTypeDef * htim, uint32_t Channel)
---------------	--

Function Description	Starts the PWM signal generation on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.27 HAL_TIMEx_PWMN_Stop

Function Name	HAL_StatusTypeDef HAL_TIMEx_PWMN_Stop (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the PWM signal generation on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.28 HAL_TIMEx_PWMN_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_PWMN_Start_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Starts the PWM signal generation in interrupt mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.29 HAL_TIMEx_PWMN_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_PWMN_Stop_IT (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the PWM signal generation in interrupt mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM

Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2
 selectedTIM_CHANNEL_3: TIM Channel 3
 selectedTIM_CHANNEL_4: TIM Channel 4 selected

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

62.3.30 HAL_TIMEx_PWMN_Start_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_PWMN_Start_DMA (TIM_HandleTypeDef * htim, uint32_t Channel, uint32_t * pData, uint16_t Length)
Function Description	Starts the TIM PWM signal generation in DMA mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected • pData: The source Buffer address. • Length: The length of data to be transferred from memory to TIM peripheral
Return values	<ul style="list-style-type: none"> • HAL status

62.3.31 HAL_TIMEx_PWMN_Stop_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_PWMN_Stop_DMA (TIM_HandleTypeDef * htim, uint32_t Channel)
Function Description	Stops the TIM PWM signal generation in DMA mode on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Channel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2 selectedTIM_CHANNEL_3: TIM Channel 3 selectedTIM_CHANNEL_4: TIM Channel 4 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.32 HAL_TIMEx_OnePulseN_Start

Function Name	HAL_StatusTypeDef HAL_TIMEx_OnePulseN_Start (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Starts the TIM One Pulse signal generation on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selectedTIM_CHANNEL_2: TIM Channel 2

selected

Return values	<ul style="list-style-type: none"> • HAL status
---------------	--

62.3.33 HAL_TIMEx_OnePulseN_Stop

Function Name	HAL_StatusTypeDef HAL_TIMEx_OnePulseN_Stop (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Stops the TIM One Pulse signal generation on the complementary output.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selected TIM_CHANNEL_2: TIM Channel 2 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.34 HAL_TIMEx_OnePulseN_Start_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_OnePulseN_Start_IT (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Starts the TIM One Pulse signal generation in interrupt mode on the complementary channel.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: TIM Channel to be enabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selected TIM_CHANNEL_2: TIM Channel 2 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.35 HAL_TIMEx_OnePulseN_Stop_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_OnePulseN_Stop_IT (TIM_HandleTypeDef * htim, uint32_t OutputChannel)
Function Description	Stops the TIM One Pulse signal generation in interrupt mode on the complementary channel.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • OutputChannel: TIM Channel to be disabled. This parameter can be one of the following values: TIM_CHANNEL_1: TIM Channel 1 selected TIM_CHANNEL_2: TIM Channel 2 selected
Return values	<ul style="list-style-type: none"> • HAL status

62.3.36 HAL_TIMEx_ConfigCommutationEvent

Function Name	HAL_StatusTypeDef HAL_TIMEx_ConfigCommutationEvent (TIM_HandleTypeDef * htim, uint32_t InputTrigger, uint32_t
---------------	--

CommutationSource)

Function Description	Configure the TIM commutation event sequence.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • InputTrigger: the Internal trigger corresponding to the Timer Interfacing with the Hall sensor. This parameter can be one of the following values: TIM_TS_ITR0: Internal trigger 0 selectedTIM_TS_ITR1: Internal trigger 1 selectedTIM_TS_ITR2: Internal trigger 2 selectedTIM_TS_ITR3: Internal trigger 3 selectedTIM_TS_NONE: No trigger is needed • CommutationSource: the Commutation Event source. This parameter can be one of the following values: TIM_COMMUTATION_TRGI: Commutation source is the TRGI of the Interface TimerTIM_COMMUTATION_SOFTWARE: Commutation source is set by software using the COMG bit
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • This function is mandatory to use the commutation event in order to update the configuration at each commutation detection on the TRGI input of the Timer, the typical use of this feature is with the use of another Timer(interface Timer) configured in Hall sensor interface, this interface Timer will generate the commutation at its TRGO output (connected to Timer used in this function) each time the TI1 of the Interface Timer detect a commutation at its input TI1.

62.3.37 HAL_TIMEx_ConfigCommuteEvent_IT

Function Name	HAL_StatusTypeDef HAL_TIMEx_ConfigCommuteEvent_IT (TIM_HandleTypeDef * htim, uint32_t InputTrigger, uint32_t CommutationSource)
Function Description	Configure the TIM commutation event sequence with interrupt.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • InputTrigger: the Internal trigger corresponding to the Timer Interfacing with the Hall sensor. This parameter can be one of the following values: TIM_TS_ITR0: Internal trigger 0 selectedTIM_TS_ITR1: Internal trigger 1 selectedTIM_TS_ITR2: Internal trigger 2 selectedTIM_TS_ITR3: Internal trigger 3 selectedTIM_TS_NONE: No trigger is needed • CommutationSource: the Commutation Event source. This parameter can be one of the following values: TIM_COMMUTATION_TRGI: Commutation source is the TRGI of the Interface TimerTIM_COMMUTATION_SOFTWARE: Commutation source is set by software using the COMG bit
Return values	<ul style="list-style-type: none"> • HAL status

- Notes**
- This function is mandatory to use the commutation event in order to update the configuration at each commutation detection on the TRGI input of the Timer, the typical use of this feature is with the use of another Timer(interface Timer) configured in Hall sensor interface, this interface Timer will generate the commutation at its TRGO output (connected to Timer used in this function) each time the TI1 of the Interface Timer detect a commutation at its input TI1.

62.3.38 HAL_TIMEx_ConfigCommutationEvent_DMA

Function Name	HAL_StatusTypeDef HAL_TIMEx_ConfigCommutationEvent_DMA (TIM_HandleTypeDef * htim, uint32_t InputTrigger, uint32_t CommutationSource)
Function Description	Configure the TIM commutation event sequence with DMA.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. InputTrigger: the Internal trigger corresponding to the Timer Interfacing with the Hall sensor. This parameter can be one of the following values: TIM_TS_ITR0: Internal trigger 0 selectedTIM_TS_ITR1: Internal trigger 1 selectedTIM_TS_ITR2: Internal trigger 2 selectedTIM_TS_ITR3: Internal trigger 3 selectedTIM_TS_NONE: No trigger is needed CommutationSource: the Commutation Event source. This parameter can be one of the following values: TIM_COMMUTATION_TRGI: Commutation source is the TRGI of the Interface TimerTIM_COMMUTATION_SOFTWARE: Commutation source is set by software using the COMG bit
Return values	• HAL status
Notes	<ul style="list-style-type: none"> This function is mandatory to use the commutation event in order to update the configuration at each commutation detection on the TRGI input of the Timer, the typical use of this feature is with the use of another Timer(interface Timer) configured in Hall sensor interface, this interface Timer will generate the commutation at its TRGO output (connected to Timer used in this function) each time the TI1 of the Interface Timer detect a commutation at its input TI1. The user should configure the DMA in his own software, in This function only the COMDE bit is set

62.3.39 HAL_TIMEx_MasterConfigSynchronization

Function Name	HAL_StatusTypeDef HAL_TIMEx_MasterConfigSynchronization (TIM_HandleTypeDef * htim, TIM_MasterConfigTypeDef * sMasterConfig)
Function Description	Configures the TIM in master mode.
Parameters	<ul style="list-style-type: none"> htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.

- **sMasterConfig:** pointer to a TIM_MasterConfigTypeDef structure that contains the selected trigger output (TRGO) and the Master/Slave mode.

Return values

- HAL status

62.3.40 HAL_TIMEx_ConfigBreakDeadTime

Function Name	<code>HAL_StatusTypeDef HAL_TIMEx_ConfigBreakDeadTime (TIM_HandleTypeDef * htim, TIM_BreakDeadTimeConfigTypeDef * sBreakDeadTimeConfig)</code>
Function Description	Configures the Break feature, dead time, Lock level, OSSI/OSSR State and the AOE(automatic output enable).
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • sBreakDeadTimeConfig: pointer to a TIM_ConfigBreakDeadConfig_TypeDef structure that contains the BDTR Register configuration information for the TIM peripheral.
Return values	<ul style="list-style-type: none"> • HAL status

62.3.41 HAL_TIMEx_RemapConfig

Function Name	<code>HAL_StatusTypeDef HAL_TIMEx_RemapConfig (TIM_HandleTypeDef * htim, uint32_t Remap)</code>
Function Description	Configures the TIM2, TIM5 and TIM11 Remapping input capabilities.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module. • Remap: specifies the TIM input remapping source. This parameter can be one of the following values: TIM_TIM2_TIM8_TRGO: TIM2 ITR1 input is connected to TIM8 Trigger output(default) TIM_TIM2_ETH_PTP: TIM2 ITR1 input is connected to ETH PTP trigger output. TIM_TIM2_USBFS_SOF: TIM2 ITR1 input is connected to USB FS SOF. TIM_TIM2_USBHS_SOF: TIM2 ITR1 input is connected to USB HS SOF. TIM_TIM5_GPIO: TIM5 CH4 input is connected to dedicated Timer pin(default) TIM_TIM5_LSI: TIM5 CH4 input is connected to LSI clock. TIM_TIM5_LSE: TIM5 CH4 input is connected to LSE clock. TIM_TIM5_RTC: TIM5 CH4 input is connected to RTC Output event. TIM_TIM11_GPIO: TIM11 CH4 input is connected to dedicated Timer pin (default) TIM_TIM11_HSE: TIM11 CH4 input is connected to HSE_RTC clock (HSE divided by a programmable prescaler)
Return values	<ul style="list-style-type: none"> • HAL status

62.3.42 HAL_TIMEx_CommmutationCallback

Function Name	<code>void HAL_TIMEx_CommmutationCallback (TIM_HandleTypeDef * htim)</code>
---------------	---

Function Description	Hall commutation changed callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

62.3.43 HAL_TIMEx_BreakCallback

Function Name	void HAL_TIMEx_BreakCallback (TIM_HandleTypeDef * htim)
Function Description	Hall Break detection callback in non blocking mode.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • None

62.3.44 TIMEx_DMACommutationCplt

Function Name	void TIMEx_DMACommutationCplt (DMA_HandleTypeDef * hdma)
Function Description	TIM DMA Commutation callback.
Parameters	<ul style="list-style-type: none"> • hdma: pointer to a DMA_HandleTypeDef structure that contains the configuration information for the specified DMA module.
Return values	<ul style="list-style-type: none"> • None

62.3.45 HAL_TIMEx_HallSensor_GetState

Function Name	HAL_TIM_StateTypeDef HAL_TIMEx_HallSensor_GetState (TIM_HandleTypeDef * htim)
Function Description	Return the TIM Hall Sensor interface state.
Parameters	<ul style="list-style-type: none"> • htim: pointer to a TIM_HandleTypeDef structure that contains the configuration information for TIM module.
Return values	<ul style="list-style-type: none"> • HAL state

62.4 TIMEx Firmware driver defines

62.4.1 TIMEx

TIM Private Macros

IS_TIM_REMAP

IS_TIM_DEADTIME

TIM Remap

TIM_TIM2_TIM8_TRGO

TIM_TIM2_ETH_PTP

TIM_TIM2_USBFS_SOF

TIM_TIM2_USBHS_SOF

TIM_TIM5_GPIO
TIM_TIM5_LSI
TIM_TIM5_LSE
TIM_TIM5_RTC
TIM_TIM11_GPIO
TIM_TIM11_HSE

63 HAL UART Generic Driver

63.1 HAL UART Generic Driver

63.2 UART Firmware driver registers structures

63.2.1 `UART_InitTypeDef`

Data Fields

- `uint32_t BaudRate`
- `uint32_t WordLength`
- `uint32_t StopBits`
- `uint32_t Parity`
- `uint32_t Mode`
- `uint32_t HwFlowCtl`
- `uint32_t OverSampling`

Field Documentation

- `uint32_t UART_InitTypeDef::BaudRate`

This member configures the UART communication baud rate. The baud rate is computed using the following formula:
 $\text{IntegerDivider} = ((\text{PCLKx}) / (8 * (\text{OVR8}+1) * (\text{uart->Init.BaudRate})))$
 $\text{FractionalDivider} = ((\text{IntegerDivider} - ((\text{uint32_t}) \text{ IntegerDivider})) * 8 * (\text{OVR8}+1)) + 0.5$ Where OVR8 is the "oversampling by 8 mode" configuration bit in the CR1 register.

- `uint32_t UART_InitTypeDef::WordLength`

Specifies the number of data bits transmitted or received in a frame. This parameter can be a value of [`UART_Word_Length`](#)

- `uint32_t UART_InitTypeDef::StopBits`

Specifies the number of stop bits transmitted. This parameter can be a value of [`UART_Stop_Bits`](#)

- `uint32_t UART_InitTypeDef::Parity`

Specifies the parity mode. This parameter can be a value of [`UART_Parity`](#)
Note:When parity is enabled, the computed parity is inserted at the MSB position of the transmitted data (9th bit when the word length is set to 9 data bits; 8th bit when the word length is set to 8 data bits).

- `uint32_t UART_InitTypeDef::Mode`

Specifies whether the Receive or Transmit mode is enabled or disabled. This parameter can be a value of [`UART_Mode`](#)

- `uint32_t UART_InitTypeDef::HwFlowCtl`

Specifies whether the hardware flow control mode is enabled or disabled. This parameter can be a value of [`UART_Hardware_Flow_Control`](#)

- `uint32_t UART_InitTypeDef::OverSampling`

Specifies whether the Over sampling 8 is enabled or disabled, to achieve higher speed (up to fPCLK/8). This parameter can be a value of [`UART_Over_Sampling`](#)

63.2.2 UART_HandleTypeDef

Data Fields

- ***USART_TypeDef * Instance***
- ***UART_InitTypeDef Init***
- ***uint8_t * pTxBuffPtr***
- ***uint16_t TxXferSize***
- ***uint16_t TxXferCount***
- ***uint8_t * pRxBuffPtr***
- ***uint16_t RxXferSize***
- ***uint16_t RxXferCount***
- ***DMA_HandleTypeDef * hdmatx***
- ***DMA_HandleTypeDef * hdmarx***
- ***HAL_LockTypeDef Lock***
- ***__IO HAL_UART_StateTypeDef State***
- ***__IO uint32_t ErrorCode***

Field Documentation

- ***USART_TypeDef* UART_HandleTypeDef::Instance***
UART registers base address
- ***UART_InitTypeDef UART_HandleTypeDef::Init***
UART communication parameters
- ***uint8_t* UART_HandleTypeDef::pTxBuffPtr***
Pointer to UART Tx transfer Buffer
- ***uint16_t UART_HandleTypeDef::TxXferSize***
UART Tx Transfer size
- ***uint16_t UART_HandleTypeDef::TxXferCount***
UART Tx Transfer Counter
- ***uint8_t* UART_HandleTypeDef::pRxBuffPtr***
Pointer to UART Rx transfer Buffer
- ***uint16_t UART_HandleTypeDef::RxXferSize***
UART Rx Transfer size
- ***uint16_t UART_HandleTypeDef::RxXferCount***
UART Rx Transfer Counter
- ***DMA_HandleTypeDef* UART_HandleTypeDef::hdmatx***
UART Tx DMA Handle parameters
- ***DMA_HandleTypeDef* UART_HandleTypeDef::hdmarx***
UART Rx DMA Handle parameters
- ***HAL_LockTypeDef UART_HandleTypeDef::Lock***
Locking object
- ***__IO HAL_UART_StateTypeDef UART_HandleTypeDef::State***
UART communication state
- ***__IO uint32_t UART_HandleTypeDef::ErrorCode***
UART Error code

63.3 UART Firmware driver API description

63.3.1 How to use this driver

The UART HAL driver can be used as follows:

1. Declare a `UART_HandleTypeDef` handle structure.
2. Initialize the UART low level resources by implementing the `HAL_UART_MspInit()` API:
 - a. Enable the USARTx interface clock.
 - b. UART pins configuration:
 - Enable the clock for the UART GPIOs.
 - Configure these UART pins as alternate function pull-up.
 - c. NVIC configuration if you need to use interrupt process (`HAL_UART_Transmit_IT()` and `HAL_UART_Receive_IT()` APIs):
 - Configure the USARTx interrupt priority.
 - Enable the NVIC USART IRQ handle.
 - d. DMA Configuration if you need to use DMA process (`HAL_UART_Transmit_DMA()` and `HAL_UART_Receive_DMA()` APIs):
 - Declare a DMA handle structure for the Tx/Rx stream.
 - Enable the DMAx interface clock.
 - Configure the declared DMA handle structure with the required Tx/Rx parameters.
 - Configure the DMA Tx/Rx Stream.
 - Associate the initialized DMA handle to the UART DMA Tx/Rx handle.
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx/Rx Stream.
3. Program the Baud Rate, Word Length, Stop Bit, Parity, Hardware flow control and Mode(Receiver/Transmitter) in the Init structure.
4. For the UART asynchronous mode, initialize the UART registers by calling the `HAL_UART_Init()` API.
5. For the UART Half duplex mode, initialize the UART registers by calling the `HAL_HalfDuplex_Init()` API.
6. For the LIN mode, initialize the UART registers by calling the `HAL_LIN_Init()` API.
7. For the Multi-Processor mode, initialize the UART registers by calling the `HAL_MultiProcessor_Init()` API.



The specific UART interrupts (Transmission complete interrupt, RXNE interrupt and Error Interrupts) will be managed using the macros `__HAL_UART_ENABLE_IT()` and `__HAL_UART_DISABLE_IT()` inside the transmit and receive process.



These APIs (`HAL_UART_Init()` and `HAL_HalfDuplex_Init()`) configure also the low level Hardware GPIO, CLOCK, CORTEX...etc) by calling the customized `HAL_UART_MspInit()` API.

Three operation modes are available within this driver :

Polling mode IO operation

- Send an amount of data in blocking mode using `HAL_UART_Transmit()`
- Receive an amount of data in blocking mode using `HAL_UART_Receive()`

Interrupt mode IO operation

- Send an amount of data in non blocking mode using HAL_UART_Transmit_IT()
- At transmission end of transfer HAL_UART_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_UART_TxCpltCallback
- Receive an amount of data in non blocking mode using HAL_UART_Receive_IT()
- At reception end of transfer HAL_UART_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_UART_RxCpltCallback
- In case of transfer Error, HAL_UART_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_UART_ErrorCallback

DMA mode IO operation

- Send an amount of data in non blocking mode (DMA) using HAL_UART_Transmit_DMA()
- At transmission end of half transfer HAL_UART_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_UART_TxHalfCpltCallback
- At transmission end of transfer HAL_UART_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_UART_TxCpltCallback
- Receive an amount of data in non blocking mode (DMA) using HAL_UART_Receive_DMA()
- At reception end of half transfer HAL_UART_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_UART_RxHalfCpltCallback
- At reception end of transfer HAL_UART_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_UART_RxCpltCallback
- In case of transfer Error, HAL_UART_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_UART_ErrorCallback
- Pause the DMA Transfer using HAL_UART_DMAPause()
- Resume the DMA Transfer using HAL_UART_DMAResume()
- Stop the DMA Transfer using HAL_UART_DMAStop()

UART HAL driver macros list

Below the list of most used macros in UART HAL driver.

- __HAL_UART_ENABLE: Enable the UART peripheral
- __HAL_UART_DISABLE: Disable the UART peripheral
- __HAL_UART_GET_FLAG : Check whether the specified UART flag is set or not
- __HAL_UART_CLEAR_FLAG : Clear the specified UART pending flag
- __HAL_UART_ENABLE_IT: Enable the specified UART interrupt
- __HAL_UART_DISABLE_IT: Disable the specified UART interrupt
- __HAL_UART_GET_IT_SOURCE: Check whether the specified UART interrupt has occurred or not



You can refer to the UART HAL driver header file for more useful macros

63.3.2 Initialization and Configuration functions

This subsection provides a set of functions allowing to initialize the USARTx or the UARTy in asynchronous mode.

- For the asynchronous mode only these parameters can be configured:
 - Baud Rate
 - Word Length
 - Stop Bit
 - Parity: If the parity is enabled, then the MSB bit of the data written in the data register is transmitted but is changed by the parity bit. Depending on the frame length defined by the M bit (8-bits or 9-bits), please refer to Reference manual for possible UART frame formats.
 - Hardware flow control
 - Receiver/transmitter modes
 - Over Sampling Method

The HAL_UART_Init(), HAL_HalfDuplex_Init(), HAL_LIN_Init() and HAL_MultiProcessor_Init() APIs follow respectively the UART asynchronous, UART Half duplex, LIN and Multi-Processor configuration procedures (details for the procedures are available in reference manual (RM0329)).

This section contains the following APIs:

- [**HAL_UART_Init\(\)**](#)
- [**HAL_HalfDuplex_Init\(\)**](#)
- [**HAL_LIN_Init\(\)**](#)
- [**HAL_MultiProcessor_Init\(\)**](#)
- [**HAL_UART_DeInit\(\)**](#)
- [**HAL_UART_MspInit\(\)**](#)
- [**HAL_UART_MspDeInit\(\)**](#)

63.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the UART asynchronous and Half duplex data transfers.

1. There are two modes of transfer:
 - Blocking mode: The communication is performed in polling mode. The HAL status of all data processing is returned by the same function after finishing transfer.
 - Non blocking mode: The communication is performed using Interrupts or DMA, these APIs return the HAL status. The end of the data processing will be indicated through the dedicated UART IRQ when using Interrupt mode or the DMA IRQ when using DMA mode. The HAL_UART_TxCpltCallback(), HAL_UART_RxCpltCallback() user callbacks will be executed respectively at the end of the transmit or receive process. The HAL_UART_ErrorCallback() user callback will be executed when a communication error is detected.
2. Blocking mode APIs are:
 - HAL_UART_Transmit()
 - HAL_UART_Receive()
3. Non Blocking mode APIs with Interrupt are:
 - HAL_UART_Transmit_IT()
 - HAL_UART_Receive_IT()
 - HAL_UART_IRQHandler()
4. Non Blocking mode functions with DMA are:
 - HAL_UART_Transmit_DMA()

- `HAL_UART_Receive_DMA()`
- 5. A set of Transfer Complete Callbacks are provided in non blocking mode:
 - `HAL_UART_TxCpltCallback()`
 - `HAL_UART_RxCpltCallback()`
 - `HAL_UART_ErrorCallback()`



In the Half duplex communication, it is forbidden to run the transmit and receive process in parallel, the UART state `HAL_UART_STATE_BUSY_TX_RX` can't be useful.

This section contains the following APIs:

- `HAL_UART_Transmit()`
- `HAL_UART_Receive()`
- `HAL_UART_Transmit_IT()`
- `HAL_UART_Receive_IT()`
- `HAL_UART_Transmit_DMA()`
- `HAL_UART_Receive_DMA()`
- `HAL_UART_DMAPause()`
- `HAL_UART_DMAResume()`
- `HAL_UART_DMAStop()`
- `HAL_UART_IRQHandler()`
- `HAL_UART_TxCpltCallback()`
- `HAL_UART_TxHalfCpltCallback()`
- `HAL_UART_RxCpltCallback()`
- `HAL_UART_RxHalfCpltCallback()`
- `HAL_UART_ErrorCallback()`

63.3.4 Peripheral Control functions

This subsection provides a set of functions allowing to control the UART:

- `HAL_LIN_SendBreak()` API can be helpful to transmit the break character.
- `HAL_MultiProcessor_EnterMuteMode()` API can be helpful to enter the UART in mute mode.
- `HAL_MultiProcessor_ExitMuteMode()` API can be helpful to exit the UART mute mode by software.

This section contains the following APIs:

- `HAL_LIN_SendBreak()`
- `HAL_MultiProcessor_EnterMuteMode()`
- `HAL_MultiProcessor_ExitMuteMode()`
- `HAL_HalfDuplex_EnableTransmitter()`
- `HAL_HalfDuplex_EnableReceiver()`

63.3.5 Peripheral State and Errors functions

This subsection provides a set of functions allowing to return the State of UART communication process, return Peripheral Errors occurred during communication process

- `HAL_UART_GetState()` API can be helpful to check in run-time the state of the UART peripheral.
- `HAL_UART_GetError()` check in run-time errors that could be occurred during communication.

This section contains the following APIs:

- `HAL_UART_GetState()`
- `HAL_UART_GetError()`

63.3.6 HAL_UART_Init

Function Name	<code>HAL_StatusTypeDef HAL_UART_Init (UART_HandleTypeDef * huart)</code>
Function Description	Initializes the UART mode according to the specified parameters in the <code>UART_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a <code>UART_HandleTypeDef</code> structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.7 HAL_HalfDuplex_Init

Function Name	<code>HAL_StatusTypeDef HAL_HalfDuplex_Init (UART_HandleTypeDef * huart)</code>
Function Description	Initializes the half-duplex mode according to the specified parameters in the <code>UART_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a <code>UART_HandleTypeDef</code> structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.8 HAL_LIN_Init

Function Name	<code>HAL_StatusTypeDef HAL_LIN_Init (UART_HandleTypeDef * huart, uint32_t BreakDetectLength)</code>
Function Description	Initializes the LIN mode according to the specified parameters in the <code>UART_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a <code>UART_HandleTypeDef</code> structure that contains the configuration information for the specified UART module. • BreakDetectLength: Specifies the LIN break detection length. This parameter can be one of the following values: <code>UART_LINBREAKDETECTLENGTH_10B</code>: 10-bit break detection <code>UART_LINBREAKDETECTLENGTH_11B</code>: 11-bit break detection
Return values	<ul style="list-style-type: none"> • HAL status

63.3.9 HAL_MultiProcessor_Init

Function Name	<code>HAL_StatusTypeDef HAL_MultiProcessor_Init (UART_HandleTypeDef * huart, uint8_t Address, uint32_t WakeUpMethod)</code>
Function Description	Initializes the Multi-Processor mode according to the specified parameters in the <code>UART_InitTypeDef</code> and create the associated

handle.

Parameters	<ul style="list-style-type: none"> huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module. Address: USART address WakeUpMethod: specifies the USART wake-up method. This parameter can be one of the following values: UART_WAKEUPMETHOD_IDLELINE: Wake-up by an idle line detection UART_WAKEUPMETHOD_ADDRESSMARK: Wake-up by an address mark
Return values	<ul style="list-style-type: none"> HAL status

63.3.10 HAL_UART_DelInit

Function Name	HAL_StatusTypeDef HAL_UART_DelInit (UART_HandleTypeDef * huart)
Function Description	Deinitializes the USART peripheral.
Parameters	<ul style="list-style-type: none"> huart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> HAL status

63.3.11 HAL_UART_MspInit

Function Name	void HAL_UART_MspInit (UART_HandleTypeDef * huart)
Function Description	USART MSP Init.
Parameters	<ul style="list-style-type: none"> huart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> None

63.3.12 HAL_UART_MspDeInit

Function Name	void HAL_UART_MspDeInit (UART_HandleTypeDef * huart)
Function Description	USART MSP DeInit.
Parameters	<ul style="list-style-type: none"> huart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> None

63.3.13 HAL_UART_Transmit

Function Name	HAL_StatusTypeDef HAL_UART_Transmit (UART_HandleTypeDef * huart, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Sends an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> huart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.

- module.
- **pData:** Pointer to data buffer
 - **Size:** Amount of data to be sent
 - **Timeout:** Timeout duration
- | | |
|---------------|--------------|
| Return values | • HAL status |
|---------------|--------------|

63.3.14 HAL_UART_Receive

Function Name	HAL_StatusTypeDef HAL_UART_Receive (UART_HandleTypeDef * huart, uint8_t * pData, uint16_t Size, uint32_t Timeout)
Function Description	Receives an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module. • pData: Pointer to data buffer • Size: Amount of data to be received • Timeout: Timeout duration
Return values	• HAL status

63.3.15 HAL_UART_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_UART_Transmit_IT (UART_HandleTypeDef * huart, uint8_t * pData, uint16_t Size)
Function Description	Sends an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	• HAL status

63.3.16 HAL_UART_Receive_IT

Function Name	HAL_StatusTypeDef HAL_UART_Receive_IT (UART_HandleTypeDef * huart, uint8_t * pData, uint16_t Size)
Function Description	Receives an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module. • pData: Pointer to data buffer • Size: Amount of data to be received
Return values	• HAL status

63.3.17 HAL_UART_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_UART_Transmit_DMA (UART_HandleTypeDef * huart, uint8_t * pData, uint16_t Size)
---------------	---

Function Description	Sends an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module. • pData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

63.3.18 HAL_UART_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_UART_Receive_DMA (UART_HandleTypeDef * huart, uint8_t * pData, uint16_t Size)
Function Description	Receives an amount of data in non blocking mode.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module. • pData: Pointer to data buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • When the UART parity is enabled (PCE = 1) the data received contain the parity bit.

63.3.19 HAL_UART_DMAPause

Function Name	HAL_StatusTypeDef HAL_UART_DMAPause (UART_HandleTypeDef * huart)
Function Description	Pauses the DMA Transfer.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.20 HAL_UART_DMAResume

Function Name	HAL_StatusTypeDef HAL_UART_DMAResume (UART_HandleTypeDef * huart)
Function Description	Resumes the DMA Transfer.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.21 HAL_UART_DMAStop

Function Name	HAL_StatusTypeDef HAL_UART_DMAStop (UART_HandleTypeDef * huart)
Function Description	Stops the DMA Transfer.

Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.22 HAL_UART_IRQHandler

Function Name	void HAL_UART_IRQHandler (UART_HandleTypeDef * huart)
Function Description	This function handles UART interrupt request.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • None

63.3.23 HAL_UART_TxCpltCallback

Function Name	void HAL_UART_TxCpltCallback (UART_HandleTypeDef * huart)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • None

63.3.24 HAL_UART_TxHalfCpltCallback

Function Name	void HAL_UART_TxHalfCpltCallback (UART_HandleTypeDef * huart)
Function Description	Tx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • None

63.3.25 HAL_UART_RxCpltCallback

Function Name	void HAL_UART_RxCpltCallback (UART_HandleTypeDef * huart)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • None

63.3.26 HAL_UART_RxHalfCpltCallback

Function Name	void HAL_UART_RxHalfCpltCallback (UART_HandleTypeDef * huart)
---------------	--

huart)

Function Description	Rx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • None

63.3.27 HAL_UART_ErrorCallback

Function Name	void HAL_UART_ErrorCallback (UART_HandleTypeDef * huart)
Function Description	UART error callbacks.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • None

63.3.28 HAL_LIN_SendBreak

Function Name	HAL_StatusTypeDef HAL_LIN_SendBreak (UART_HandleTypeDef * huart)
Function Description	Transmits break characters.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.29 HAL_MultiProcessor_EnterMuteMode

Function Name	HAL_StatusTypeDef HAL_MultiProcessor_EnterMuteMode (UART_HandleTypeDef * huart)
Function Description	Enters the UART in mute mode.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.30 HAL_MultiProcessor_ExitMuteMode

Function Name	HAL_StatusTypeDef HAL_MultiProcessor_ExitMuteMode (UART_HandleTypeDef * huart)
Function Description	Exits the UART mute mode: wake up software.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.31 HAL_HalfDuplex_EnableTransmitter

Function Name	HAL_StatusTypeDef HAL_HalfDuplex_EnableTransmitter (UART_HandleTypeDef * huart)
Function Description	Enables the UART transmitter and disables the UART receiver.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.32 HAL_HalfDuplex_EnableReceiver

Function Name	HAL_StatusTypeDef HAL_HalfDuplex_EnableReceiver (UART_HandleTypeDef * huart)
Function Description	Enables the UART receiver and disables the UART transmitter.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL status

63.3.33 HAL_UART_GetState

Function Name	HAL_UART_StateTypeDef HAL_UART_GetState (UART_HandleTypeDef * huart)
Function Description	Returns the UART state.
Parameters	<ul style="list-style-type: none"> • huart: pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART module.
Return values	<ul style="list-style-type: none"> • HAL state

63.3.34 HAL_UART_GetError

Function Name	uint32_t HAL_UART_GetError (UART_HandleTypeDef * huart)
Function Description	Return the UART error code.
Parameters	<ul style="list-style-type: none"> • huart: : pointer to a UART_HandleTypeDef structure that contains the configuration information for the specified UART.
Return values	<ul style="list-style-type: none"> • UART Error Code

63.4 UART Firmware driver defines

63.4.1 UART

UART Error Code

HAL_UART_ERROR_NONE	No error
HAL_UART_ERROR_PE	Parity error
HAL_UART_ERROR_NE	Noise error

HAL_UART_ERROR_FE	Frame error
HAL_UART_ERROR_ORE	Overrun error
HAL_UART_ERROR_DMA	DMA transfer error

UART Exported Macros`_HAL_UART_RESET_HANDLE_STATE`**Description:**

- Reset UART handle state.

Parameters:

- `_HANDLE_`: specifies the UART Handle. This parameter can be `UARTx` where `x`: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`_HAL_UART_FLUSH_DRREGISTER`**Description:**

- Flushes the UART DR register.

Parameters:

- `_HANDLE_`: specifies the UART Handle.

Description:

- Checks whether the specified UART flag is set or not.

Parameters:

- `_HANDLE_`: specifies the UART Handle. This parameter can be `UARTx` where `x`: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- `_FLAG_`: specifies the flag to check. This parameter can be one of the following values:
 - `UART_FLAG_CTS`: CTS Change flag (not available for `UART4` and `UART5`)
 - `UART_FLAG_LBD`: LIN Break detection flag
 - `UART_FLAG_TXE`: Transmit data register empty flag
 - `UART_FLAG_TC`: Transmission Complete flag
 - `UART_FLAG_RXNE`: Receive data register not empty flag
 - `UART_FLAG_IDLE`: Idle Line detection flag
 - `UART_FLAG_ORE`: Overrun Error flag

- UART_FLAG_NE: Noise Error flag
- UART_FLAG_FE: Framing Error flag
- UART_FLAG_PE: Parity Error flag

Return value:

- The new state of __FLAG__ (TRUE or FALSE).

_HAL_UART_CLEAR_FLAG**Description:**

- Clears the specified UART pending flag.

Parameters:

- __HANDLE__: specifies the UART Handle. This parameter can be UARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- __FLAG__: specifies the flag to check. This parameter can be any combination of the following values:
 - UART_FLAG_CTS: CTS Change flag (not available for UART4 and UART5).
 - UART_FLAG_LBD: LIN Break detection flag.
 - UART_FLAG_TC: Transmission Complete flag.
 - UART_FLAG_RXNE: Receive data register not empty flag.

Return value:

- None

Notes:

- PE (Parity error), FE (Framing error), NE (Noise error), ORE (Overrun error) and IDLE (Idle line detected) flags are cleared by software sequence: a read operation to USART_SR register followed by a read operation to USART_DR register. RXNE flag can be also cleared by a read to the USART_DR register. TC flag can be also cleared by software sequence: a read operation to USART_SR register followed by a write operation to USART_DR register. TXE flag is cleared only by a write to the USART_DR register.

[__HAL_UART_CLEAR_PEFLAG](#)**Description:**

- Clear the UART PE pending flag.

Parameters:

- [__HANDLE__](#): specifies the UART Handle. This parameter can be [UARTx](#) where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

[__HAL_UART_CLEAR_FEFLAG](#)**Description:**

- Clear the UART FE pending flag.

Parameters:

- [__HANDLE__](#): specifies the UART Handle. This parameter can be [UARTx](#) where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

[__HAL_UART_CLEAR_NEFLAG](#)**Description:**

- Clear the UART NE pending flag.

Parameters:

- [__HANDLE__](#): specifies the UART Handle. This parameter can be [UARTx](#) where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

[__HAL_UART_CLEAR_OREFLAG](#)**Description:**

- Clear the UART ORE pending flag.

Parameters:

- [__HANDLE__](#): specifies the UART Handle. This parameter can be [UARTx](#) where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

[__HAL_UART_CLEAR_IDLEFLAG](#)**Description:**

- Clear the UART IDLE pending flag.

Parameters:

- `__HANDLE__`: specifies the UART Handle. This parameter can be `UARTx` where `x`: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

Return value:

- None

`UART_IT_MASK`

Description:

- Enable the specified UART interrupt.

Parameters:

- `__HANDLE__`: specifies the UART Handle. This parameter can be `UARTx` where `x`: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- `__INTERRUPT__`: specifies the UART interrupt source to enable. This parameter can be one of the following values:
 - `UART_IT_CTS`: CTS change interrupt
 - `UART_IT_LBD`: LIN Break detection interrupt
 - `UART_IT_TXE`: Transmit Data Register empty interrupt
 - `UART_IT_TC`: Transmission complete interrupt
 - `UART_IT_RXNE`: Receive Data register not empty interrupt
 - `UART_IT_IDLE`: Idle line detection interrupt
 - `UART_IT_PE`: Parity Error interrupt
 - `UART_IT_ERR`: Error interrupt(Frame error, noise error, overrun error)

Return value:

- None

`__HAL_UART_ENABLE_IT`
`__HAL_UART_DISABLE_IT`

Description:

- Disable the specified UART interrupt.

Parameters:

- `__HANDLE__`: specifies the UART Handle. This parameter can be

UARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.

- __INTERRUPT__: specifies the UART interrupt source to disable. This parameter can be one of the following values:
 - UART_IT_CTS: CTS change interrupt
 - UART_IT_LBD: LIN Break detection interrupt
 - UART_IT_TXE: Transmit Data Register empty interrupt
 - UART_IT_TC: Transmission complete interrupt
 - UART_IT_RXNE: Receive Data register not empty interrupt
 - UART_IT_IDLE: Idle line detection interrupt
 - UART_IT_PE: Parity Error interrupt
 - UART_IT_ERR: Error interrupt(Frame error, noise error, overrun error)

Return value:

- None

[__HAL_UART_GET_IT_SOURCE](#)

- Checks whether the specified UART interrupt has occurred or not.

Parameters:

- __HANDLE__: specifies the UART Handle. This parameter can be UARTx where x: 1, 2, 3, 4, 5, 6, 7 or 8 to select the USART or UART peripheral.
- __IT__: specifies the UART interrupt source to check. This parameter can be one of the following values:
 - UART_IT_CTS: CTS change interrupt (not available for UART4 and UART5)
 - UART_IT_LBD: LIN Break detection interrupt
 - UART_IT_TXE: Transmit Data Register empty interrupt
 - UART_IT_TC: Transmission complete interrupt
 - UART_IT_RXNE: Receive Data register not empty interrupt
 - UART_IT_IDLE: Idle line detection interrupt

-
- USART_IT_ERR: Error interrupt

Return value:

- The: new state of __IT__ (TRUE or FALSE).

_HAL_UART_HWCONTROL_CTS_ENABLE

Description:

- Enable CTS flow control This macro allows to enable CTS hardware flow control for a given UART instance, without need to call

Parameters:

- __HANDLE__: specifies the UART Handle. The Handle Instance can be USART1, USART2 or LPUART.

Return value:

- None

Notes:

- As macro is expected to be used for modifying CTS Hw flow control feature activation, without need for USART instance Deinit/Init, following conditions for macro call should be fulfilled : UART instance should have already been initialised (through call of HAL_UART_Init())macro could only be called when corresponding UART instance is disabled (i.e __HAL_UART_DISABLE(__HANDLE__)) and should be followed by an Enable macro (i.e __HAL_UART_ENABLE(__HANDLE__)).

_HAL_UART_HWCONTROL_CTS_DISABLE

Description:

- Disable CTS flow control This macro allows to disable CTS hardware flow control for a given UART instance, without need to call

Parameters:

- __HANDLE__: specifies the UART Handle. The Handle Instance can be USART1, USART2 or LPUART.

Return value:

- None

Notes:

- As macro is expected to be used for modifying CTS Hw flow control feature activation, without need for

USART instance Deinit/Init, following conditions for macro call should be fulfilled : USART instance should have already been initialised (through call of HAL_UART_Init())macro could only be called when corresponding USART instance is disabled (i.e __HAL_UART_DISABLE(__HANDLE__)) and should be followed by an Enable macro (i.e __HAL_UART_ENABLE(__HANDLE__)).

[__HAL_UART_HWCONTROL_RTS_ENABLE](#)

Description:

- Enable RTS flow control This macro allows to enable RTS hardware flow control for a given USART instance, without need to call

Parameters:

- __HANDLE__: specifies the USART Handle. The Handle Instance can be USART1, USART2 or LPUART.

Return value:

- None

Notes:

- As macro is expected to be used for modifying RTS Hw flow control feature activation, without need for USART instance Deinit/Init, following conditions for macro call should be fulfilled : USART instance should have already been initialised (through call of HAL_UART_Init())macro could only be called when corresponding USART instance is disabled (i.e __HAL_UART_DISABLE(__HANDLE__)) and should be followed by an Enable macro (i.e __HAL_UART_ENABLE(__HANDLE__)).

[__HAL_UART_HWCONTROL_RTS_DISABLE](#)

Description:

- Disable RTS flow control This macro allows to disable RTS hardware flow control for a given USART instance, without need to call

Parameters:

- __HANDLE__: specifies the USART Handle. The Handle Instance can be USART1, USART2 or LPUART.

Return value:

- None

Notes:

- As macro is expected to be used for modifying RTS Hw flow control feature activation, without need for USART instance Deinit/Init, following conditions for macro call should be fulfilled : USART instance should have already been initialised (through call of HAL_UART_Init())macro could only be called when corresponding USART instance is disabled (i.e __HAL_UART_DISABLE(__HANDLE__)) and should be followed by an Enable macro (i.e __HAL_UART_ENABLE(__HANDLE__)).

`__HAL_UART_ONE_BIT_SAMPLE_ENABLE`

Description:

- macros to enables the UART's one bit sample method

Parameters:

- `__HANDLE__`: specifies the UART Handle.

Return value:

- None

`__HAL_UART_ONE_BIT_SAMPLE_DISABLE`

Description:

- macros to disables the UART's one bit sample method

Parameters:

- `__HANDLE__`: specifies the UART Handle.

Return value:

- None

`__HAL_UART_ENABLE`

Description:

- Enable USART.

Parameters:

- `__HANDLE__`: specifies the USART Handle.

Return value:

- None

`__HAL_UART_DISABLE`

Description:

- Disable UART.

Parameters:

- `__HANDLE__`: specifies the UART Handle.

Return value:

- None

UART Flags

`UART_FLAG_CTS`
`UART_FLAG_LBD`
`UART_FLAG_TXE`
`UART_FLAG_TC`
`UART_FLAG_RXNE`
`UART_FLAG_IDLE`
`UART_FLAG_ORE`
`UART_FLAG_NE`
`UART_FLAG_FE`
`UART_FLAG_PE`

UART Hardware Flow Control

`UART_HWCONTROL_NONE`
`UART_HWCONTROL_RTS`
`UART_HWCONTROL_CTS`
`UART_HWCONTROL_RTS_CTS`

UART Interrupt Definitions

`UART_IT_PE`
`UART_IT_TXE`
`UART_IT_TC`
`UART_IT_RXNE`
`UART_IT_IDLE`
`UART_IT_LBD`
`UART_IT_CTS`
`UART_IT_ERR`

UART LIN Break Detection Length

`UART_LINBREAKDETECTLENGTH_10B`
`UART_LINBREAKDETECTLENGTH_11B`

UART Transfer Mode

`UART_MODE_RX`
`UART_MODE_TX`

UART_MODE_TX_RX
UART Over Sampling
UART_OVERSAMPLING_16
UART_OVERSAMPLING_8
UART Parity
UART_PARITY_NONE
UART_PARITY_EVEN
UART_PARITY_ODD
UART Private Constants
UART_TIMEOUT_VALUE
UART_CR1_REG_INDEX
UART_CR2_REG_INDEX
UART_CR3_REG_INDEX
UART Private Macros
IS_UART_WORD_LENGTH
IS_UART_LIN_WORD_LENGTH
IS_UART_STOPBITS
IS_UART_PARITY
IS_UART_HARDWARE_FLOW_CONTROL
IS_UART_MODE
IS_UART_STATE
IS_UART_OVERSAMPLING
IS_UART_LIN_OVERSAMPLING
IS_UART_LIN_BREAK_DETECT_LENGTH
IS_UART_WAKEUPMETHOD
IS_UART_BAUDRATE
IS_UART_ADDRESS
UART_DIV_SAMPLING16
UART_DIVMANT_SAMPLING16
UART_DIVFRAQ_SAMPLING16
UART_BRR_SAMPLING16
UART_DIV_SAMPLING8
UART_DIVMANT_SAMPLING8
UART_DIVFRAQ_SAMPLING8
UART_BRR_SAMPLING8
UART State

UART_STATE_DISABLE

UART_STATE_ENABLE

UART Number of Stop Bits

UART_STOPBITS_1

UART_STOPBITS_2

UART Wakeup Functions

UART_WAKEUPMETHOD_IDLELINE

UART_WAKEUPMETHOD_ADDRESSMARK

UART Word Length

UART_WORDLENGTH_8B

UART_WORDLENGTH_9B

64 HAL USART Generic Driver

64.1 HAL USART Generic Driver

64.2 USART Firmware driver registers structures

64.2.1 USART_InitTypeDef

Data Fields

- *uint32_t BaudRate*
- *uint32_t WordLength*
- *uint32_t StopBits*
- *uint32_t Parity*
- *uint32_t Mode*
- *uint32_t CLKPolarity*
- *uint32_t CLKPhase*
- *uint32_t CLKLastBit*

Field Documentation

- ***uint32_t USART_InitTypeDef::BaudRate***
This member configures the Usart communication baud rate. The baud rate is computed using the following formula:

$$\text{IntegerDivider} = ((\text{PCLKx}) / (8 * (\text{husart-} > \text{Init.BaudRate})))$$

$$\text{FractionalDivider} = ((\text{IntegerDivider} - ((\text{uint32_t}) \text{ IntegerDivider})) * 8) + 0.5$$
- ***uint32_t USART_InitTypeDef::WordLength***
Specifies the number of data bits transmitted or received in a frame. This parameter can be a value of [**USART_Word_Length**](#)
- ***uint32_t USART_InitTypeDef::StopBits***
Specifies the number of stop bits transmitted. This parameter can be a value of [**USART_Stop_Bits**](#)
- ***uint32_t USART_InitTypeDef::Parity***
Specifies the parity mode. This parameter can be a value of [**USART_Parity**](#)
Note:When parity is enabled, the computed parity is inserted at the MSB position of the transmitted data (9th bit when the word length is set to 9 data bits; 8th bit when the word length is set to 8 data bits).
- ***uint32_t USART_InitTypeDef::Mode***
Specifies whether the Receive or Transmit mode is enabled or disabled. This parameter can be a value of [**USART_Mode**](#)
- ***uint32_t USART_InitTypeDef::CLKPolarity***
Specifies the steady state of the serial clock. This parameter can be a value of [**USART_Clock_Polarity**](#)
- ***uint32_t USART_InitTypeDef::CLKPhase***
Specifies the clock transition on which the bit capture is made. This parameter can be a value of [**USART_Clock_Phase**](#)
- ***uint32_t USART_InitTypeDef::CLKLastBit***
Specifies whether the clock pulse corresponding to the last transmitted data bit (MSB) has to be output on the SCLK pin in synchronous mode. This parameter can be a value of [**USART_Last_Bit**](#)

64.2.2 USART_HandleTypeDef

Data Fields

- *USART_TypeDef * Instance*
- *USART_InitTypeDef Init*
- *uint8_t * pTxBuffPtr*
- *uint16_t TxXferSize*
- *_IO uint16_t TxXferCount*
- *uint8_t * pRxBuffPtr*
- *uint16_t RxXferSize*
- *_IO uint16_t RxXferCount*
- *DMA_HandleTypeDef * hdmatx*
- *DMA_HandleTypeDef * hdmarx*
- *HAL_LockTypeDef Lock*
- *_IO HAL_USART_StateTypeDef State*
- *_IO uint32_t ErrorCode*

Field Documentation

- *USART_TypeDef* USART_HandleTypeDef::Instance*
- *USART_InitTypeDef USART_HandleTypeDef::Init*
- *uint8_t* USART_HandleTypeDef::pTxBuffPtr*
- *uint16_t USART_HandleTypeDef::TxXferSize*
- *_IO uint16_t USART_HandleTypeDef::TxXferCount*
- *uint8_t* USART_HandleTypeDef::pRxBuffPtr*
- *uint16_t USART_HandleTypeDef::RxXferSize*
- *_IO uint16_t USART_HandleTypeDef::RxXferCount*
- *DMA_HandleTypeDef* USART_HandleTypeDef::hdmatx*
- *DMA_HandleTypeDef* USART_HandleTypeDef::hdmarx*
- *HAL_LockTypeDef USART_HandleTypeDef::Lock*
- *_IO HAL_USART_StateTypeDef USART_HandleTypeDef::State*
- *_IO uint32_t USART_HandleTypeDef::ErrorCode*

64.3 USART Firmware driver API description

64.3.1 How to use this driver

The USART HAL driver can be used as follows:

1. Declare a USART_HandleTypeDef handle structure.
2. Initialize the USART low level resources by implementing the HAL_USART_MspInit () API:
 - a. Enable the USARTx interface clock.
 - b. USART pins configuration:
 - Enable the clock for the USART GPIOs.
 - Configure these USART pins as alternate function pull-up.
 - c. NVIC configuration if you need to use interrupt process
(HAL_USART_Transmit_IT(), HAL_USART_Receive_IT() and
HAL_USART_TransmitReceive_IT() APIs):

- Configure the USARTx interrupt priority.
- Enable the NVIC USART IRQ handle.
- d. DMA Configuration if you need to use DMA process
(HAL_USART_Transmit_DMA() HAL_USART_Receive_IT() and
HAL_USART_TransmitReceive_IT() APIs):
 - Declare a DMA handle structure for the Tx/Rx stream.
 - Enable the DMA interface clock.
 - Configure the declared DMA handle structure with the required Tx/Rx parameters.
 - Configure the DMA Tx/Rx Stream.
 - Associate the initialized DMA handle to the USART DMA Tx/Rx handle.
 - Configure the priority and enable the NVIC for the transfer complete interrupt on the DMA Tx/Rx Stream.
- 3. Program the Baud Rate, Word Length, Stop Bit, Parity, Hardware flow control and Mode(Receiver/Transmitter) in the husart Init structure.
- 4. Initialize the USART registers by calling the HAL_USART_Init() API:
 - These APIs configures also the low level Hardware GPIO, CLOCK, CORTEX...etc) by calling the customized HAL_USART_MspInit(&husart) API. The specific USART interrupts (Transmission complete interrupt, RXNE interrupt and Error Interrupts) will be managed using the macros __HAL_USART_ENABLE_IT() and __HAL_USART_DISABLE_IT() inside the transmit and receive process.
- 5. Three operation modes are available within this driver :

Polling mode IO operation

- Send an amount of data in blocking mode using HAL_USART_Transmit()
- Receive an amount of data in blocking mode using HAL_USART_Receive()

Interrupt mode IO operation

- Send an amount of data in non blocking mode using HAL_USART_Transmit_IT()
- At transmission end of transfer HAL_USART_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_USART_TxCpltCallback
- Receive an amount of data in non blocking mode using HAL_USART_Receive_IT()
- At reception end of transfer HAL_USART_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_USART_RxCpltCallback
- In case of transfer Error, HAL_USART_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_USART_ErrorCallback

DMA mode IO operation

- Send an amount of data in non blocking mode (DMA) using HAL_USART_Transmit_DMA()
- At transmission end of half transfer HAL_USART_TxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_USART_TxHalfCpltCallback

- At transmission end of transfer HAL_USART_TxCpltCallback is executed and user can add his own code by customization of function pointer HAL_USART_TxCpltCallback
- Receive an amount of data in non blocking mode (DMA) using HAL_USART_Receive_DMA()
- At reception end of half transfer HAL_USART_RxHalfCpltCallback is executed and user can add his own code by customization of function pointer HAL_USART_RxHalfCpltCallback
- At reception end of transfer HAL_USART_RxCpltCallback is executed and user can add his own code by customization of function pointer HAL_USART_RxCpltCallback
- In case of transfer Error, HAL_USART_ErrorCallback() function is executed and user can add his own code by customization of function pointer HAL_USART_ErrorCallback
- Pause the DMA Transfer using HAL_USART_DMAPause()
- Resume the DMA Transfer using HAL_USART_DMAResume()
- Stop the DMA Transfer using HAL_USART_DMAStop()

USART HAL driver macros list

Below the list of most used macros in USART HAL driver.

- __HAL_USART_ENABLE: Enable the USART peripheral
- __HAL_USART_DISABLE: Disable the USART peripheral
- __HAL_USART_GET_FLAG : Check whether the specified USART flag is set or not
- __HAL_USART_CLEAR_FLAG : Clear the specified USART pending flag
- __HAL_USART_ENABLE_IT: Enable the specified USART interrupt
- __HAL_USART_DISABLE_IT: Disable the specified USART interrupt



You can refer to the USART HAL driver header file for more useful macros

64.3.2

Initialization and Configuration functions

This subsection provides a set of functions allowing to initialize the USART in asynchronous and in synchronous modes.

- For the asynchronous mode only these parameters can be configured:
 - Baud Rate
 - Word Length
 - Stop Bit
 - Parity: If the parity is enabled, then the MSB bit of the data written in the data register is transmitted but is changed by the parity bit. Depending on the frame length defined by the M bit (8-bits or 9-bits), please refer to Reference manual for possible USART frame formats.
 - USART polarity
 - USART phase
 - USART LastBit
 - Receiver/transmitter modes

The HAL_USART_Init() function follows the USART synchronous configuration procedure (details for the procedure are available in reference manual (RM0329)).

This section contains the following APIs:

- [HAL_USART_Init\(\)](#)

- [`HAL_USART_DeInit\(\)`](#)
- [`HAL_USART_MspInit\(\)`](#)
- [`HAL_USART_MspDelInit\(\)`](#)

64.3.3 IO operation functions

This subsection provides a set of functions allowing to manage the USART synchronous data transfers.

The USART supports master mode only: it cannot receive or send data related to an input clock (SCLK is always an output).

1. There are two modes of transfer:
 - Blocking mode: The communication is performed in polling mode. The HAL status of all data processing is returned by the same function after finishing transfer.
 - No-Blocking mode: The communication is performed using Interrupts or DMA, These API's return the HAL status. The end of the data processing will be indicated through the dedicated USART IRQ when using Interrupt mode or the DMA IRQ when using DMA mode. The `HAL_USART_TxCpltCallback()`, `HAL_USART_RxCpltCallback()` and `HAL_USART_TxRxCpltCallback()` user callbacks will be executed respectively at the end of the transmit or Receive process. The `HAL_USART_ErrorCallback()` user callback will be executed when a communication error is detected
2. Blocking mode APIs are :
 - `HAL_USART_Transmit()` in simplex mode
 - `HAL_USART_Receive()` in full duplex receive only
 - `HAL_USART_TransmitReceive()` in full duplex mode
3. Non Blocking mode APIs with Interrupt are :
 - `HAL_USART_Transmit_IT()`in simplex mode
 - `HAL_USART_Receive_IT()` in full duplex receive only
 - `HAL_USART_TransmitReceive_IT()` in full duplex mode
 - `HAL_USART_IRQHandler()`
4. Non Blocking mode functions with DMA are :
 - `HAL_USART_Transmit_DMA()`in simplex mode
 - `HAL_USART_Receive_DMA()` in full duplex receive only
 - `HAL_USART_TransmitReceie_DMA()` in full duplex mode
 - `HAL_USART_DMAPause()`
 - `HAL_USART_DMAResume()`
 - `HAL_USART_DMAStop()`
5. A set of Transfer Complete Callbacks are provided in non Blocking mode:
 - `HAL_USART_TxHalfCpltCallback()`
 - `HAL_USART_TxCpltCallback()`
 - `HAL_USART_RxHalfCpltCallback()`
 - `HAL_USART_RxCpltCallback()`
 - `HAL_USART_ErrorCallback()`
 - `HAL_USART_TxRxCpltCallback()`

This section contains the following APIs:

- [`HAL_USART_Transmit\(\)`](#)
- [`HAL_USART_Receive\(\)`](#)
- [`HAL_USART_TransmitReceive\(\)`](#)
- [`HAL_USART_Transmit_IT\(\)`](#)
- [`HAL_USART_Receive_IT\(\)`](#)
- [`HAL_USART_TransmitReceive_IT\(\)`](#)

- [*HAL_USART_Transmit_DMA\(\)*](#)
- [*HAL_USART_Receive_DMA\(\)*](#)
- [*HAL_USART_TransmitReceive_DMA\(\)*](#)
- [*HAL_USART_DMAPause\(\)*](#)
- [*HAL_USART_DMAResume\(\)*](#)
- [*HAL_USART_DMAStop\(\)*](#)
- [*HAL_USART_IRQHandler\(\)*](#)
- [*HAL_USART_TxCpltCallback\(\)*](#)
- [*HAL_USART_TxHalfCpltCallback\(\)*](#)
- [*HAL_USART_RxCpltCallback\(\)*](#)
- [*HAL_USART_RxHalfCpltCallback\(\)*](#)
- [*HAL_USART_TxRxCpltCallback\(\)*](#)
- [*HAL_USART_ErrorCallback\(\)*](#)

64.3.4 Peripheral State and Errors functions

This subsection provides a set of functions allowing to return the State of USART communication process, return Peripheral Errors occurred during communication process

- [*HAL_USART_GetState\(\)*](#) API can be helpful to check in run-time the state of the USART peripheral.
- [*HAL_USART_GetError\(\)*](#) check in run-time errors that could be occurred during communication.

This section contains the following APIs:

- [*HAL_USART_GetState\(\)*](#)
- [*HAL_USART_GetError\(\)*](#)

64.3.5 HAL_USART_Init

Function Name	HAL_StatusTypeDef HAL_USART_Init (USART_HandleTypeDef * huart)
Function Description	Initializes the USART mode according to the specified parameters in the <code>USART_InitTypeDef</code> and create the associated handle.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a <code>USART_HandleTypeDef</code> structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • HAL status

64.3.6 HAL_USART_DeInit

Function Name	HAL_StatusTypeDef HAL_USART_DeInit (USART_HandleTypeDef * huart)
Function Description	Deinitializes the USART peripheral.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a <code>USART_HandleTypeDef</code> structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • HAL status

64.3.7 HAL_USART_MspInit

Function Name	void HAL_USART_MspInit (USART_HandleTypeDef * huart)
---------------	---

Function Description	USART MSP Init.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.8 HAL_USART_MspDeInit

Function Name	void HAL_USART_MspDeInit (USART_HandleTypeDef * husart)
Function Description	USART MSP DeInit.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.9 HAL_USART_Transmit

Function Name	HAL_StatusTypeDef HAL_USART_Transmit (USART_HandleTypeDef * husart, uint8_t * pTxData, uint16_t Size, uint32_t Timeout)
Function Description	Simplex Send an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pTxData: Pointer to data buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

64.3.10 HAL_USART_Receive

Function Name	HAL_StatusTypeDef HAL_USART_Receive (USART_HandleTypeDef * husart, uint8_t * pRxData, uint16_t Size, uint32_t Timeout)
Function Description	Full-Duplex Receive an amount of data in blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pRxData: Pointer to data buffer • Size: Amount of data to be received • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

64.3.11 HAL_USART_TransmitReceive

Function Name	HAL_StatusTypeDef HAL_USART_TransmitReceive (USART_HandleTypeDef * husart, uint8_t * pTxData, uint8_t *
---------------	--

pRxData, uint16_t Size, uint32_t Timeout)

Function Description	Full-Duplex Send receive an amount of data in full-duplex mode (blocking mode).
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pTxData: Pointer to data transmitted buffer • pRxData: Pointer to data received buffer • Size: Amount of data to be sent • Timeout: Timeout duration
Return values	<ul style="list-style-type: none"> • HAL status

64.3.12 HAL_USART_Transmit_IT

Function Name	HAL_StatusTypeDef HAL_USART_Transmit_IT (USART_HandleTypeDef * husart, uint8_t * pTxData, uint16_t Size)
Function Description	Simplex Send an amount of data in non-blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pTxData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • The USART errors are not managed to avoid the overrun error.

64.3.13 HAL_USART_Receive_IT

Function Name	HAL_StatusTypeDef HAL_USART_Receive_IT (USART_HandleTypeDef * husart, uint8_t * pRxData, uint16_t Size)
Function Description	Simplex Receive an amount of data in non-blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pRxData: Pointer to data buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status

64.3.14 HAL_USART_TransmitReceive_IT

Function Name	HAL_StatusTypeDef HAL_USART_TransmitReceive_IT (USART_HandleTypeDef * husart, uint8_t * pTxData, uint8_t * pRxData, uint16_t Size)
Function Description	Full-Duplex Send receive an amount of data in full-duplex mode (non-blocking).
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that

	contains the configuration information for the specified USART module.
	<ul style="list-style-type: none"> • pTxData: Pointer to data transmitted buffer • pRxData: Pointer to data received buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status

64.3.15 HAL_USART_Transmit_DMA

Function Name	HAL_StatusTypeDef HAL_USART_Transmit_DMA (USART_HandleTypeDef * huart, uint8_t * pTxData, uint16_t Size)
Function Description	Simplex Send an amount of data in non-blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pTxData: Pointer to data buffer • Size: Amount of data to be sent
Return values	<ul style="list-style-type: none"> • HAL status

64.3.16 HAL_USART_Receive_DMA

Function Name	HAL_StatusTypeDef HAL_USART_Receive_DMA (USART_HandleTypeDef * huart, uint8_t * pRxData, uint16_t Size)
Function Description	Full-Duplex Receive an amount of data in non-blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pRxData: Pointer to data buffer • Size: Amount of data to be received
Return values	<ul style="list-style-type: none"> • HAL status
Notes	<ul style="list-style-type: none"> • The USART DMA transmit stream must be configured in order to generate the clock for the slave. • When the USART parity is enabled (PCE = 1) the data received contain the parity bit.

64.3.17 HAL_USART_TransmitReceive_DMA

Function Name	HAL_StatusTypeDef HAL_USART_TransmitReceive_DMA (USART_HandleTypeDef * huart, uint8_t * pTxData, uint8_t * pRxData, uint16_t Size)
Function Description	Full-Duplex Transmit Receive an amount of data in non-blocking mode.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module. • pTxData: Pointer to data transmitted buffer • pRxData: Pointer to data received buffer

- **Size:** Amount of data to be received
- | | |
|---------------|--|
| Return values | • HAL status |
| Notes | • When the USART parity is enabled (PCE = 1) the data received contain the parity bit. |

64.3.18 HAL_USART_DMAPause

Function Name	HAL_StatusTypeDef HAL_USART_DMAPause (USART_HandleTypeDef * husart)
Function Description	Pauses the DMA Transfer.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • HAL status

64.3.19 HAL_USART_DMAResume

Function Name	HAL_StatusTypeDef HAL_USART_DMAResume (USART_HandleTypeDef * husart)
Function Description	Resumes the DMA Transfer.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • HAL status

64.3.20 HAL_USART_DMAStop

Function Name	HAL_StatusTypeDef HAL_USART_DMAStop (USART_HandleTypeDef * husart)
Function Description	Stops the DMA Transfer.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • HAL status

64.3.21 HAL_USART_IRQHandler

Function Name	void HAL_USART_IRQHandler (USART_HandleTypeDef * husart)
Function Description	This function handles USART interrupt request.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.22 HAL_USART_TxCpltCallback

Function Name	void HAL_USART_TxCpltCallback (USART_HandleTypeDef * husart)
Function Description	Tx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.23 HAL_USART_TxHalfCpltCallback

Function Name	void HAL_USART_TxHalfCpltCallback (USART_HandleTypeDef * husart)
Function Description	Tx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.24 HAL_USART_RxCpltCallback

Function Name	void HAL_USART_RxCpltCallback (USART_HandleTypeDef * husart)
Function Description	Rx Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.25 HAL_USART_RxHalfCpltCallback

Function Name	void HAL_USART_RxHalfCpltCallback (USART_HandleTypeDef * husart)
Function Description	Rx Half Transfer completed callbacks.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> • None

64.3.26 HAL_USART_TxRxCpltCallback

Function Name	void HAL_USART_TxRxCpltCallback (USART_HandleTypeDef * husart)
Function Description	Tx/Rx Transfers completed callback for the non-blocking process.
Parameters	<ul style="list-style-type: none"> • husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.

Return values	<ul style="list-style-type: none"> None
---------------	--

64.3.27 HAL_USART_ErrorCallback

Function Name	<code>void HAL_USART_ErrorCallback (USART_HandleTypeDef * husart)</code>
Function Description	USART error callbacks.
Parameters	<ul style="list-style-type: none"> husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> None

64.3.28 HAL_USART_GetState

Function Name	<code>HAL_USART_StateTypeDef HAL_USART_GetState (USART_HandleTypeDef * husart)</code>
Function Description	Returns the USART state.
Parameters	<ul style="list-style-type: none"> husart: pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART module.
Return values	<ul style="list-style-type: none"> HAL state

64.3.29 HAL_USART_GetError

Function Name	<code>uint32_t HAL_USART_GetError (USART_HandleTypeDef * husart)</code>
Function Description	Return the USART error code.
Parameters	<ul style="list-style-type: none"> husart: : pointer to a USART_HandleTypeDef structure that contains the configuration information for the specified USART.
Return values	<ul style="list-style-type: none"> USART Error Code

64.4 USART Firmware driver defines

64.4.1 USART

USART Clock

`USART_CLOCK_DISABLE`

`USART_CLOCK_ENABLE`

USART Clock Phase

`USART_PHASE_1EDGE`

`USART_PHASE_2EDGE`

USART Clock Polarity

`USART_POLARITY_LOW`

`USART_POLARITY_HIGH`

USART Error Code

HAL_USART_ERROR_NONE	No error
HAL_USART_ERROR_PE	Parity error
HAL_USART_ERROR_NE	Noise error
HAL_USART_ERROR_FE	Frame error
HAL_USART_ERROR_ORE	Overrun error
HAL_USART_ERROR_DMA	DMA transfer error

USART Exported Macros

<code>_HAL_USART_RESET_HANDLE_STATE</code>	Description: • Reset USART handle state.
Parameters:	
<code>_HAL_USART_GET_FLAG</code>	Description: • Checks whether the specified Smartcard flag is set or not.
Parameters:	<ul style="list-style-type: none"> • <code>_HANDLE_</code>: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral. • <code>_FLAG_</code>: specifies the flag to check. This parameter can be one of the following values: <ul style="list-style-type: none"> – USART_FLAG_TXE: Transmit data register empty flag – USART_FLAG_TC: Transmission Complete flag – USART_FLAG_RXNE: Receive data register not empty flag – USART_FLAG_IDLE: Idle Line detection flag – USART_FLAG_ORE: Overrun Error flag – USART_FLAG_NE: Noise Error flag – USART_FLAG_FE: Framing Error flag – USART_FLAG_PE: Parity Error flag

Return value:

- The new state of FLAG (TRUE or FALSE).

_HAL_USART_CLEAR_FLAG**Description:**

- Clears the specified Smartcard pending flags.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.
- FLAG: specifies the flag to check. This parameter can be any combination of the following values:
 - USART_FLAG_TC: Transmission Complete flag.
 - USART_FLAG_RXNE: Receive data register not empty flag.

Return value:

- None

Notes:

- PE (Parity error), FE (Framing error), NE (Noise error), ORE (Overrun error) and IDLE (Idle line detected) flags are cleared by software sequence: a read operation to USART_SR register followed by a read operation to USART_DR register. RXNE flag can be also cleared by a read to the USART_DR register. TC flag can be also cleared by software sequence: a read operation to USART_SR register followed by a write operation to USART_DR register. TXE flag is cleared only by a write to the USART_DR register.

_HAL_USART_CLEAR_PEFLAG**Description:**

- Clear the USART PE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.

Return value:

- None

[__HAL_USART_CLEAR_FEFLAG](#)**Description:**

- Clear the USART FE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.

Return value:

- None

[__HAL_USART_CLEAR_NEFLAG](#)**Description:**

- Clear the USART NE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.

Return value:

- None

[__HAL_USART_CLEAR_OREFLAG](#)**Description:**

- Clear the UART ORE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.

Return value:

- None

[__HAL_USART_CLEAR_IDLEFLAG](#)**Description:**

- Clear the USART IDLE pending flag.

Parameters:

- HANDLE: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.

Return value:

- None

[__HAL_USART_ENABLE_IT](#)**Description:**

- Enables or disables the specified USART interrupts.

Parameters:

- `HANDLE`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.
- `INTERRUPT`: specifies the USART interrupt source to check. This parameter can be one of the following values:
 - USART_IT_TXE: Transmit Data Register empty interrupt
 - USART_IT_TC: Transmission complete interrupt
 - USART_IT_RXNE: Receive Data register not empty interrupt
 - USART_IT_IDLE: Idle line detection interrupt
 - USART_IT_PE: Parity Error interrupt
 - USART_IT_ERR: Error interrupt(Frame error, noise error, overrun error) This parameter can be: ENABLE or DISABLE.

Return value:

- None

`_HAL_USART_DISABLE_IT`
`_HAL_USART_GET_IT_SOURCE`

Description:

- Checks whether the specified USART interrupt has occurred or not.

Parameters:

- `HANDLE`: specifies the USART Handle. This parameter can be USARTx where x: 1, 2, 3 or 6 to select the USART peripheral.
- `IT`: specifies the USART interrupt source to check. This parameter can be one of the following values:
 - USART_IT_TXE: Transmit Data Register empty interrupt
 - USART_IT_TC: Transmission complete interrupt
 - USART_IT_RXNE: Receive Data register not empty interrupt
 - USART_IT_IDLE: Idle line detection interrupt
 - USART_IT_ERR: Error interrupt

- USART_IT_PE: Parity Error interrupt

Return value:

- The new state of __IT__ (TRUE or FALSE).

`__HAL_USART_ONE_BIT_SAMPLE_ENABLE`

Description:

- Macro to enable the USART's one bit sample method.

Parameters:

- `__HANDLE__`: specifies the USART Handle.

Return value:

- None

`__HAL_USART_ONE_BIT_SAMPLE_DISABLE`

Description:

- Macro to disable the USART's one bit sample method.

Parameters:

- `__HANDLE__`: specifies the USART Handle.

Return value:

- None

`__HAL_USART_ENABLE`

Description:

- Enable USART.

Parameters:

- `__HANDLE__`: specifies the USART Handle. USART Handle selects the USARTx peripheral (USART availability and x value depending on device).

Return value:

- None

`__HAL_USART_DISABLE`

Description:

- Disable USART.

Parameters:

- `__HANDLE__`: specifies the USART Handle. USART Handle selects the USARTx peripheral (USART availability and x value depending on device).

Return value:

- None

USART Flags

USART_FLAG_TXE
USART_FLAG_TC
USART_FLAG_RXNE
USART_FLAG_IDLE
USART_FLAG_ORE
USART_FLAG_NE
USART_FLAG_FE
USART_FLAG_PE

USART Interrupts Definition

USART_IT_PE
USART_IT_TXE
USART_IT_TC
USART_IT_RXNE
USART_IT_IDLE
USART_IT_LBD
USART_IT_CTS
USART_IT_ERR

USART Last Bit

USART_LASTBIT_DISABLE
USART_LASTBIT_ENABLE

USART Mode

USART_MODE_RX
USART_MODE_TX
USART_MODE_TX_RX

USART NACK State

USART_NACK_ENABLE
USART_NACK_DISABLE

USART Parity

USART_PARITY_NONE
USART_PARITY_EVEN
USART_PARITY_ODD

USART Private Constants

DUMMY_DATA
USART_TIMEOUT_VALUE
USART_IT_MASK

USART_CR1_REG_INDEX
USART_CR2_REG_INDEX
USART_CR3_REG_INDEX
USART Private Macros
IS_USART_NACK_STATE
IS_USART_LASTBIT
IS_USART_PHASE
IS_USART_POLARITY
IS_USART_CLOCK
IS_USART_WORD_LENGTH
IS_USART_STOPBITS
IS_USART_PARITY
IS_USART_MODE
IS_USART_BAUDRATE
USART_DIV
USART_DIVMANT
USART_DIVFRAQ
USART_BRR
USART Number of Stop Bits
USART_STOPBITS_1
USART_STOPBITS_0_5
USART_STOPBITS_2
USART_STOPBITS_1_5
USART Word Length
USART_WORDLENGTH_8B
USART_WORDLENGTH_9B

65 HAL WWDG Generic Driver

65.1 HAL WWDG Generic Driver

65.2 WWDG Firmware driver registers structures

65.2.1 WWDG_InitTypeDef

Data Fields

- *uint32_t Prescaler*
- *uint32_t Window*
- *uint32_t Counter*

Field Documentation

- ***uint32_t WWDG_InitTypeDef::Prescaler***
Specifies the prescaler value of the WWDG. This parameter can be a value of **WWDG_Prescaler**
- ***uint32_t WWDG_InitTypeDef::Window***
Specifies the WWDG window value to be compared to the downcounter. This parameter must be a number lower than Max_Data = 0x80
- ***uint32_t WWDG_InitTypeDef::Counter***
Specifies the WWDG free-running downcounter value. This parameter must be a number between Min_Data = 0x40 and Max_Data = 0x7F

65.2.2 WWDG_HandleTypeDefDef

Data Fields

- *WWDG_TypeDef * Instance*
- *WWDG_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_WWDG_StateTypeDef State*

Field Documentation

- ***WWDG_TypeDef* WWDG_HandleTypeDefDef::Instance***
Register base address
- ***WWDG_InitTypeDef WWDG_HandleTypeDefDef::Init***
WWDG required parameters
- ***HAL_LockTypeDef WWDG_HandleTypeDefDef::Lock***
WWDG locking object
- ***__IO HAL_WWDG_StateTypeDef WWDG_HandleTypeDefDef::State***
WWDG communication state

65.3 WWDG Firmware driver API description

65.3.1 WWDG specific features

Once enabled the WWDG generates a system reset on expiry of a programmed time period, unless the program refreshes the counter (downcounter) before reaching 0x3F value (i.e. a reset is generated when the counter value rolls over from 0x40 to 0x3F).

- An MCU reset is also generated if the counter value is refreshed before the counter has reached the refresh window value. This implies that the counter must be refreshed in a limited window.
- Once enabled the WWDG cannot be disabled except by a system reset.
- WWDRST flag in RCC_CSR register can be used to inform when a WWDG reset occurs.
- The WWDG counter input clock is derived from the APB clock divided by a programmable prescaler.
- WWDG clock (Hz) = PCLK1 / (4096 * Prescaler)
- WWDG timeout (mS) = 1000 * Counter / WWDG clock
- WWDG Counter refresh is allowed between the following limits :
 - min time (mS) = 1000 * (Counter _ Window) / WWDG clock
 - max time (mS) = 1000 * (Counter _ 0x40) / WWDG clock
- Min-max timeout value at 50 MHz(PCLK1): 81.9 us / 41.9 ms

65.3.2 How to use this driver

- Enable WWDG APB1 clock using __HAL_RCC_WWDG_CLK_ENABLE().
- Set the WWDG prescaler, refresh window and counter value using HAL_WWDG_Init() function.
- Start the WWDG using HAL_WWDG_Start() function. When the WWDG is enabled the counter value should be configured to a value greater than 0x40 to prevent generating an immediate reset.
- Optionally you can enable the Early Wakeup Interrupt (EWI) which is generated when the counter reaches 0x40, and then start the WWDG using HAL_WWDG_Start_IT(). At EWI HAL_WWDG_WakeupCallback is executed and user can add his own code by customization of function pointer HAL_WWDG_WakeupCallback Once enabled, EWI interrupt cannot be disabled except by a system reset.
- Then the application program must refresh the WWDG counter at regular intervals during normal operation to prevent an MCU reset, using HAL_WWDG_Refresh() function. This operation must occur only when the counter is lower than the refresh window value already programmed.

WWDG HAL driver macros list

Below the list of most used macros in WWDG HAL driver.

- __HAL_WWDG_ENABLE: Enable the WWDG peripheral
- __HAL_WWDG_GET_FLAG: Get the selected WWDG's flag status
- __HAL_WWDG_CLEAR_FLAG: Clear the WWDG's pending flags
- __HAL_WWDG_ENABLE_IT: Enables the WWDG early wake-up interrupt

65.3.3 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the WWDG according to the specified parameters in the WWDG_InitTypeDef and create the associated handle
- DeInitialize the WWDG peripheral
- Initialize the WWDG MSP
- DeInitialize the WWDG MSP

This section contains the following APIs:

- [*HAL_WWDG_Init\(\)*](#)
- [*HAL_WWDG_DeInit\(\)*](#)
- [*HAL_WWDG_MspInit\(\)*](#)
- [*HAL_WWDG_MspDeInit\(\)*](#)
- [*HAL_WWDG_WakeupCallback\(\)*](#)

65.3.4 IO operation functions

This section provides functions allowing to:

- Start the WWDG.
- Refresh the WWDG.
- Handle WWDG interrupt request.

This section contains the following APIs:

- [*HAL_WWDG_Start\(\)*](#)
- [*HAL_WWDG_Start_IT\(\)*](#)
- [*HAL_WWDG_Refresh\(\)*](#)
- [*HAL_WWDG_IRQHandler\(\)*](#)
- [*HAL_WWDG_WakeupCallback\(\)*](#)

65.3.5 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [*HAL_WWDG_GetState\(\)*](#)

65.3.6 HAL_WWDG_Init

Function Name	HAL_StatusTypeDef HAL_WWDG_Init (WWDG_HandleTypeDef * hwdg)
Function Description	Initializes the WWDG according to the specified parameters in the WWDG_InitTypeDef and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> • HAL status

65.3.7 HAL_WWDG_DeInit

Function Name	HAL_StatusTypeDef HAL_WWDG_DeInit (WWDG_HandleTypeDef * hwdg)
Function Description	DeInitializes the WWDG peripheral.
Parameters	<ul style="list-style-type: none"> • hwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified

WWDG module.

Return values	<ul style="list-style-type: none"> HAL status
---------------	--

65.3.8 HAL_WWDG_MspInit

Function Name	void HAL_WWDG_MspInit (WWDG_HandleTypeDefDef * hwdg)
Function Description	Initializes the WWDG MSP.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

65.3.9 HAL_WWDG_MspDelInit

Function Name	void HAL_WWDG_MspDelInit (WWDG_HandleTypeDefDef * hwdg)
Function Description	Deinitializes the WWDG MSP.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

65.3.10 HAL_WWDG_WakeupCallback

Function Name	void HAL_WWDG_WakeupCallback (WWDG_HandleTypeDefDef * hwdg)
Function Description	Early Wakeup WWDG callback.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

65.3.11 HAL_WWDG_Start

Function Name	HAL_StatusTypeDef HAL_WWDG_Start (WWDG_HandleTypeDefDef * hwdg)
Function Description	Starts the WWDG.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> HAL status

65.3.12 HAL_WWDG_Start_IT

Function Name	HAL_StatusTypeDef HAL_WWDG_Start_IT (WWDG_HandleTypeDefDef * hwdg)
Function Description	Starts the WWDG with interrupt enabled.

Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> HAL status

65.3.13 HAL_WWDG_Refresh

Function Name	HAL_StatusTypeDef HAL_WWDG_Refresh (WWDG_HandleTypeDef * hwwdg, uint32_t Counter)
Function Description	Refreshes the WWDG.
Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module. Counter: value of counter to put in WWDG counter
Return values	<ul style="list-style-type: none"> HAL status

65.3.14 HAL_WWDG_IRQHandler

Function Name	void HAL_WWDG_IRQHandler (WWDG_HandleTypeDef * hwwdg)
Function Description	Handles WWDG interrupt request.
Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> The Early Wakeup Interrupt (EWI) can be used if specific safety operations or data logging must be performed before the actual reset is generated. The EWI interrupt is enabled using __HAL_WWDG_ENABLE_IT() macro. When the downcounter reaches the value 0x40, and EWI interrupt is generated and the corresponding Interrupt Service Routine (ISR) can be used to trigger specific actions (such as communications or data logging), before resetting the device.

65.3.15 HAL_WWDG_WakeupCallback

Function Name	void HAL_WWDG_WakeupCallback (WWDG_HandleTypeDef * hwwdg)
Function Description	Early Wakeup WWDG callback.
Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

65.3.16 HAL_WWDG_GetState

Function Name	HAL_WWDG_StateTypeDef HAL_WWDG_GetState (WWDG_HandleTypeDef * hwwdg)
---------------	---

Function Description	Returns the WWDG state.
Parameters	<ul style="list-style-type: none"> • hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> • HAL state

65.4 WWDG Firmware driver defines

65.4.1 WWDG

WWDG BitAddress

`WWDG_CFR_BASE`

WWDG Exported Macros

`_HAL_WWDG_RESET_HANDLE_STATE` **Description:**

- Reset WWDG handle state.

Parameters:

- `_HANDLE_`: WWDG handle

Return value:

- None

Description:

- Enables the WWDG peripheral.

Parameters:

- `_HANDLE_`: WWDG handle

Return value:

- None

Description:

- Disables the WWDG peripheral.

Parameters:

- `_HANDLE_`: WWDG handle

Return value:

- None

Notes:

- WARNING: This is a dummy macro for HAL code alignment. Once enable, WWDG Peripheral cannot be disabled except by a system reset.

Description:

- Gets the selected WWDG's it status.

Parameters:

- `_HANDLE_`: WWDG handle

- `__INTERRUPT__`: specifies the interrupt to check. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt IT

Return value:

- The new state of `WWDG_FLAG` (SET or RESET).

`__HAL_WWDG_CLEAR_IT`**Description:**

- Clear the WWDG's interrupt pending bits to clear the selected interrupt pending bits.

Parameters:

- `__HANDLE__`: WWDG handle
- `__INTERRUPT__`: specifies the interrupt pending bit to clear. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt flag

`__HAL_WWDG_ENABLE_IT`**Description:**

- Enables the WWDG early wakeup interrupt.

Parameters:

- `__HANDLE__`: WWDG handle
- `__INTERRUPT__`: specifies the interrupt to enable. This parameter can be one of the following values:
 - `WWDG_IT_EWI`: Early wakeup interrupt

Return value:

- None

Notes:

- Once enabled this interrupt cannot be disabled except by a system reset.

`__HAL_WWDG_DISABLE_IT`**Description:**

- Disables the WWDG early wakeup interrupt.

Parameters:

- `__HANDLE__`: WWDG handle
- `__INTERRUPT__`: specifies the interrupt to disable. This parameter can be one of the following values:
 - `WWDG_IT_EWI`: Early wakeup interrupt

Return value:

- None

Notes:

- WARNING: This is a dummy macro for HAL code alignment. Once enabled this interrupt cannot be disabled except by a system reset.

`__HAL_WWDG_GET_FLAG`**Description:**

- Gets the selected WWDG's flag status.

Parameters:

- `__HANDLE__`: WWDG handle
- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt flag

Return value:

- The: new state of `WWDG_FLAG` (SET or RESET).

`__HAL_WWDG_CLEAR_FLAG`**Description:**

- Clears the WWDG's pending flags.

Parameters:

- `__HANDLE__`: WWDG handle
- `__FLAG__`: specifies the flag to clear. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt flag

Return value:

- None

`__HAL_WWDG_GET_IT_SOURCE`**Description:**

- Checks if the specified WWDG interrupt source is enabled or disabled.

Parameters:

- `__HANDLE__`: WWDG Handle.
- `__INTERRUPT__`: specifies the WWDG interrupt source to check. This parameter can be one of the following values:
 - `WWDG_IT_EWI`: Early Wakeup Interrupt

Return value:

- state: of `__INTERRUPT__` (TRUE or

FALSE).

WWDG Flag definition

WWDG_FLAG_EWIF Early wakeup interrupt flag

WWDG Interrupt definition

WWDG_IT_EWI Early wakeup interrupt

WWDG Prescaler

WWDG_PRESCALER_1 WWDG counter clock = (PCLK1/4096)/1

WWDG_PRESCALER_2 WWDG counter clock = (PCLK1/4096)/2

WWDG_PRESCALER_4 WWDG counter clock = (PCLK1/4096)/4

WWDG_PRESCALER_8 WWDG counter clock = (PCLK1/4096)/8

WWDG Private Macros

IS_WWDG_PRESCALER

IS_WWDG_WINDOW

IS_WWDG_COUNTER

66 HAL WWDG Generic Driver

66.1 HAL WWDG Generic Driver

66.2 WWDG Firmware driver registers structures

66.2.1 WWDG_InitTypeDef

Data Fields

- *uint32_t Prescaler*
- *uint32_t Window*
- *uint32_t Counter*

Field Documentation

- ***uint32_t WWDG_InitTypeDef::Prescaler***
Specifies the prescaler value of the WWDG. This parameter can be a value of **WWDG_Prescaler**
- ***uint32_t WWDG_InitTypeDef::Window***
Specifies the WWDG window value to be compared to the downcounter. This parameter must be a number lower than Max_Data = 0x80
- ***uint32_t WWDG_InitTypeDef::Counter***
Specifies the WWDG free-running downcounter value. This parameter must be a number between Min_Data = 0x40 and Max_Data = 0x7F

66.2.2 WWDG_HandleTypeDefDef

Data Fields

- *WWDG_TypeDef * Instance*
- *WWDG_InitTypeDef Init*
- *HAL_LockTypeDef Lock*
- *__IO HAL_WWDG_StateTypeDef State*

Field Documentation

- ***WWDG_TypeDef* WWDG_HandleTypeDefDef::Instance***
Register base address
- ***WWDG_InitTypeDef WWDG_HandleTypeDefDef::Init***
WWDG required parameters
- ***HAL_LockTypeDef WWDG_HandleTypeDefDef::Lock***
WWDG locking object
- ***__IO HAL_WWDG_StateTypeDef WWDG_HandleTypeDefDef::State***
WWDG communication state

66.3 WWDG Firmware driver API description

66.3.1 WWDG specific features

Once enabled the WWDG generates a system reset on expiry of a programmed time period, unless the program refreshes the counter (downcounter) before reaching 0x3F value (i.e. a reset is generated when the counter value rolls over from 0x40 to 0x3F).

- An MCU reset is also generated if the counter value is refreshed before the counter has reached the refresh window value. This implies that the counter must be refreshed in a limited window.
- Once enabled the WWDG cannot be disabled except by a system reset.
- WWDRST flag in RCC_CSR register can be used to inform when a WWDG reset occurs.
- The WWDG counter input clock is derived from the APB clock divided by a programmable prescaler.
- WWDG clock (Hz) = PCLK1 / (4096 * Prescaler)
- WWDG timeout (mS) = 1000 * Counter / WWDG clock
- WWDG Counter refresh is allowed between the following limits :
 - min time (mS) = 1000 * (Counter _ Window) / WWDG clock
 - max time (mS) = 1000 * (Counter _ 0x40) / WWDG clock
- Min-max timeout value at 50 MHz(PCLK1): 81.9 us / 41.9 ms

66.3.2 How to use this driver

- Enable WWDG APB1 clock using __HAL_RCC_WWDG_CLK_ENABLE().
- Set the WWDG prescaler, refresh window and counter value using HAL_WWDG_Init() function.
- Start the WWDG using HAL_WWDG_Start() function. When the WWDG is enabled the counter value should be configured to a value greater than 0x40 to prevent generating an immediate reset.
- Optionally you can enable the Early Wakeup Interrupt (EWI) which is generated when the counter reaches 0x40, and then start the WWDG using HAL_WWDG_Start_IT(). At EWI HAL_WWDG_WakeupCallback is executed and user can add his own code by customization of function pointer HAL_WWDG_WakeupCallback Once enabled, EWI interrupt cannot be disabled except by a system reset.
- Then the application program must refresh the WWDG counter at regular intervals during normal operation to prevent an MCU reset, using HAL_WWDG_Refresh() function. This operation must occur only when the counter is lower than the refresh window value already programmed.

WWDG HAL driver macros list

Below the list of most used macros in WWDG HAL driver.

- __HAL_WWDG_ENABLE: Enable the WWDG peripheral
- __HAL_WWDG_GET_FLAG: Get the selected WWDG's flag status
- __HAL_WWDG_CLEAR_FLAG: Clear the WWDG's pending flags
- __HAL_WWDG_ENABLE_IT: Enables the WWDG early wake-up interrupt

66.3.3 Initialization and de-initialization functions

This section provides functions allowing to:

- Initialize the WWDG according to the specified parameters in the WWDG_InitTypeDef and create the associated handle
- DeInitialize the WWDG peripheral
- Initialize the WWDG MSP
- DeInitialize the WWDG MSP

This section contains the following APIs:

- [***HAL_WWDG_Init\(\)***](#)
- [***HAL_WWDG_DeInit\(\)***](#)
- [***HAL_WWDG_MspInit\(\)***](#)
- [***HAL_WWDG_MspDeInit\(\)***](#)
- [***HAL_WWDG_WakeupCallback\(\)***](#)

66.3.4 IO operation functions

This section provides functions allowing to:

- Start the WWDG.
- Refresh the WWDG.
- Handle WWDG interrupt request.

This section contains the following APIs:

- [***HAL_WWDG_Start\(\)***](#)
- [***HAL_WWDG_Start_IT\(\)***](#)
- [***HAL_WWDG_Refresh\(\)***](#)
- [***HAL_WWDG_IRQHandler\(\)***](#)
- [***HAL_WWDG_WakeupCallback\(\)***](#)

66.3.5 Peripheral State functions

This subsection permits to get in run-time the status of the peripheral and the data flow.

This section contains the following APIs:

- [***HAL_WWDG_GetState\(\)***](#)

66.3.6 HAL_WWDG_Init

Function Name	HAL_StatusTypeDef HAL_WWDG_Init (WWDG_HandleTypeDef * hwdg)
Function Description	Initializes the WWDG according to the specified parameters in the WWDG_InitTypeDef and creates the associated handle.
Parameters	<ul style="list-style-type: none"> • hwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> • HAL status

66.3.7 HAL_WWDG_DeInit

Function Name	HAL_StatusTypeDef HAL_WWDG_DeInit (WWDG_HandleTypeDef * hwdg)
Function Description	DeInitializes the WWDG peripheral.
Parameters	<ul style="list-style-type: none"> • hwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified

WWDG module.

Return values	<ul style="list-style-type: none"> HAL status
---------------	--

66.3.8 HAL_WWDG_MspInit

Function Name	void HAL_WWDG_MspInit (WWDG_HandleTypeDefDef * hwdg)
Function Description	Initializes the WWDG MSP.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

66.3.9 HAL_WWDG_MspDelInit

Function Name	void HAL_WWDG_MspDelInit (WWDG_HandleTypeDefDef * hwdg)
Function Description	Deinitializes the WWDG MSP.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

66.3.10 HAL_WWDG_WakeupCallback

Function Name	void HAL_WWDG_WakeupCallback (WWDG_HandleTypeDefDef * hwdg)
Function Description	Early Wakeup WWDG callback.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

66.3.11 HAL_WWDG_Start

Function Name	HAL_StatusTypeDef HAL_WWDG_Start (WWDG_HandleTypeDefDef * hwdg)
Function Description	Starts the WWDG.
Parameters	<ul style="list-style-type: none"> hwdg: pointer to a WWDG_HandleTypeDefDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> HAL status

66.3.12 HAL_WWDG_Start_IT

Function Name	HAL_StatusTypeDef HAL_WWDG_Start_IT (WWDG_HandleTypeDefDef * hwdg)
Function Description	Starts the WWDG with interrupt enabled.

Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> HAL status

66.3.13 HAL_WWDG_Refresh

Function Name	HAL_StatusTypeDef HAL_WWDG_Refresh (WWDG_HandleTypeDef * hwwdg, uint32_t Counter)
Function Description	Refreshes the WWDG.
Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module. Counter: value of counter to put in WWDG counter
Return values	<ul style="list-style-type: none"> HAL status

66.3.14 HAL_WWDG_IRQHandler

Function Name	void HAL_WWDG_IRQHandler (WWDG_HandleTypeDef * hwwdg)
Function Description	Handles WWDG interrupt request.
Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None
Notes	<ul style="list-style-type: none"> The Early Wakeup Interrupt (EWI) can be used if specific safety operations or data logging must be performed before the actual reset is generated. The EWI interrupt is enabled using __HAL_WWDG_ENABLE_IT() macro. When the downcounter reaches the value 0x40, and EWI interrupt is generated and the corresponding Interrupt Service Routine (ISR) can be used to trigger specific actions (such as communications or data logging), before resetting the device.

66.3.15 HAL_WWDG_WakeupCallback

Function Name	void HAL_WWDG_WakeupCallback (WWDG_HandleTypeDef * hwwdg)
Function Description	Early Wakeup WWDG callback.
Parameters	<ul style="list-style-type: none"> hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> None

66.3.16 HAL_WWDG_GetState

Function Name	HAL_WWDG_StateTypeDef HAL_WWDG_GetState (WWDG_HandleTypeDef * hwwdg)
---------------	---

Function Description	Returns the WWDG state.
Parameters	<ul style="list-style-type: none"> • hwwdg: pointer to a WWDG_HandleTypeDef structure that contains the configuration information for the specified WWDG module.
Return values	<ul style="list-style-type: none"> • HAL state

66.4 WWDG Firmware driver defines

66.4.1 WWDG

WWDG BitAddress

`WWDG_CFR_BASE`

WWDG Exported Macros

`_HAL_WWDG_RESET_HANDLE_STATE` **Description:**

- Reset WWDG handle state.

Parameters:

- `_HANDLE_`: WWDG handle

Return value:

- None

Description:

- Enables the WWDG peripheral.

Parameters:

- `_HANDLE_`: WWDG handle

Return value:

- None

Description:

- Disables the WWDG peripheral.

Parameters:

- `_HANDLE_`: WWDG handle

Return value:

- None

Notes:

- WARNING: This is a dummy macro for HAL code alignment. Once enable, WWDG Peripheral cannot be disabled except by a system reset.

Description:

- Gets the selected WWDG's it status.

Parameters:

- `_HANDLE_`: WWDG handle

- `__INTERRUPT__`: specifies the interrupt to check. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt IT

Return value:

- The new state of `WWDG_FLAG` (SET or RESET).

`__HAL_WWDG_CLEAR_IT`**Description:**

- Clear the WWDG's interrupt pending bits to clear the selected interrupt pending bits.

Parameters:

- `__HANDLE__`: WWDG handle
- `__INTERRUPT__`: specifies the interrupt pending bit to clear. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt flag

`__HAL_WWDG_ENABLE_IT`**Description:**

- Enables the WWDG early wakeup interrupt.

Parameters:

- `__HANDLE__`: WWDG handle
- `__INTERRUPT__`: specifies the interrupt to enable. This parameter can be one of the following values:
 - `WWDG_IT_EWI`: Early wakeup interrupt

Return value:

- None

Notes:

- Once enabled this interrupt cannot be disabled except by a system reset.

`__HAL_WWDG_DISABLE_IT`**Description:**

- Disables the WWDG early wakeup interrupt.

Parameters:

- `__HANDLE__`: WWDG handle
- `__INTERRUPT__`: specifies the interrupt to disable. This parameter can be one of the following values:
 - `WWDG_IT_EWI`: Early wakeup interrupt

Return value:

- None

Notes:

- WARNING: This is a dummy macro for HAL code alignment. Once enabled this interrupt cannot be disabled except by a system reset.

`__HAL_WWDG_GET_FLAG`**Description:**

- Gets the selected WWDG's flag status.

Parameters:

- `__HANDLE__`: WWDG handle
- `__FLAG__`: specifies the flag to check. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt flag

Return value:

- The: new state of `WWDG_FLAG` (SET or RESET).

`__HAL_WWDG_CLEAR_FLAG`**Description:**

- Clears the WWDG's pending flags.

Parameters:

- `__HANDLE__`: WWDG handle
- `__FLAG__`: specifies the flag to clear. This parameter can be one of the following values:
 - `WWDG_FLAG_EWIF`: Early wakeup interrupt flag

Return value:

- None

`__HAL_WWDG_GET_IT_SOURCE`**Description:**

- Checks if the specified WWDG interrupt source is enabled or disabled.

Parameters:

- `__HANDLE__`: WWDG Handle.
- `__INTERRUPT__`: specifies the WWDG interrupt source to check. This parameter can be one of the following values:
 - `WWDG_IT_EWI`: Early Wakeup Interrupt

Return value:

- state: of `__INTERRUPT__` (TRUE or

FALSE).

WWDG Flag definition

WWDG_FLAG_EWIF Early wakeup interrupt flag

WWDG Interrupt definition

WWDG_IT_EWI Early wakeup interrupt

WWDG Prescaler

WWDG_PRESCALER_1 WWDG counter clock = (PCLK1/4096)/1

WWDG_PRESCALER_2 WWDG counter clock = (PCLK1/4096)/2

WWDG_PRESCALER_4 WWDG counter clock = (PCLK1/4096)/4

WWDG_PRESCALER_8 WWDG counter clock = (PCLK1/4096)/8

WWDG Private Macros

IS_WWDG_PRESCALER

IS_WWDG_WINDOW

IS_WWDG_COUNTER

67 FAQs

General subjects

Why should I use the HAL drivers?

There are many advantages in using the HAL drivers:

- Ease of use: you can use the HAL drivers to configure and control any peripheral embedded within your STM32 MCU without prior in-depth knowledge of the product.
- HAL drivers provide intuitive and ready-to-use APIs to configure the peripherals and support polling, interrupt and DMA programming model to accommodate all application requirements, thus allowing the end-user to build a complete application by calling a few APIs.
- Higher level of abstraction than a standard peripheral library allowing to transparently manage:
 - Data transfers and processing using blocking mode (polling) or non-blocking mode (interrupt or DMA)
 - Error management through peripheral error detection and timeout mechanism.
- Generic architecture speeding up initialization and porting, thus allowing customers to focus on innovation.
- Generic set of APIs with full compatibility across the STM32 series/lines, to ease the porting task between STM32 MCUs.
- The APIs provided within the HAL drivers are feature-oriented and do not require in-depth knowledge of peripheral operation.
- The APIs provided are modular. They include initialization, IO operation and control functions. The end-user has to call init function, then start the process by calling one IO operation functions (write, read, transmit, receive, ...). Most of the peripherals have the same architecture.
- The number of functions required to build a complete and useful application is very reduced. As an example, to build a UART communication process, the user only has to call HAL_UART_Init() then HAL_UART_Transmit() or HAL_UART_Receive().

Which STM32F4 devices are supported by the HAL drivers?

The HAL drivers are developed to support all STM32F4 devices. To ensure compatibility between all devices and portability with other series and lines, the API is split into the generic and the extension APIs. For more details, please refer to [Section 4.4: "Devices supported by HAL drivers"](#).

What is the cost of using HAL drivers in term of code size and performance?

Like generic architecture drivers, the HAL drivers may induce firmware overhead.

This is due to the high abstraction level and ready-to-use APIs which allow data transfers, errors management and offloads the user application from implementation details.

Architecture

How many files should I modify to configure the HAL drivers?

Only one file needs to be modified: `stm32f4xx_hal_conf.h`. You can modify this file by disabling unused modules, or adjusting some parameters (i.e. HSE value, System configuration, Ethernet parameters configuration...)

A template is provided in the HAL drivers folders (stm32f4xx_hal_conf_template.c).

Which header files should I include in my application to use the HAL drivers?

Only stm32f4xx_hal.h file has to be included.

What is the difference between stm32f4xx_hal_ppp.c/h and stm32f4xx_hal_ppp_ex.c/h?

The HAL driver architecture supports common features across STM32 series/lines. To support specific features, the drivers are split into two groups.

- The generic APIs (stm32f4xx_hal_ppp.c): It includes the common set of APIs across all the STM32 product lines
- The extension APIs (stm32f4xx_hal_ppp_ex.c): It includes the specific APIs for specific device part number or family.

Is it possible to use the APIs available in stm32f4xx_ll_ppp.c?

These APIs cannot be used directly because they are internal and offer services to upper layer drivers. As an example stm32f4xx_ll_fmc.c/h driver is used by stm32f4xx_hal_sram.c, stm32f4xx_hal_nor.c, stm32f4xx_hal_nand.c and stm32f4xx_hal_sdram.c drivers.

Initialization and I/O operation functions

How do I configure the system clock?

Unlike the standard library, the system clock configuration is not performed in CMSIS drivers file (system_stm32f4xx.c) but in the main user application by calling the two main functions, HAL_RCC_OscConfig() and HAL_RCC_ClockConfig(). It can be modified in any user application section.

What is the purpose of the *PPP_HandleTypeDef *pHandle* structure located in each driver in addition to the Initialization structure

*PPP_HandleTypeDef *pHandle* is the main structure implemented in the HAL drivers. It handles the peripheral configuration and registers, and embeds all the structures and variables required to follow the peripheral device flow (pointer to buffer, Error code, State,...)

However, this structure is not required to service peripherals such as GPIO, SYSTICK, PWR, and RCC.

What is the purpose of HAL_PPP_MspInit() and HAL_PPP_MspDeInit() functions?

These function are called within HAL_PPP_Init() and HAL_PPP_DeInit(), respectively. They are used to perform the low level Initialization/de-initialization related to the additional hardware resources (RCC, GPIO, NVIC and DMA).

These functions are declared in stm32f4xx_hal_msp.c. A template is provided in the HAL driver folders (stm32f4xx_hal_msp_template.c).

When and how should I use callbacks functions (functions declared with the attribute `__weak`)?

Use callback functions for the I/O operations used in DMA or interrupt mode. The PPP process complete callbacks are called to inform the user about process completion in real-time event mode (interrupts).

The Errors callbacks are called when a processing error occurs in DMA or interrupt mode. These callbacks are customized by the user to add user proprietary code. They can be declared in the application. Note that the same process completion callbacks are used for DMA and interrupt mode.

Is it mandatory to use `HAL_Init()` function at the beginning of the user application?

It is mandatory to use `HAL_Init()` function to enable the system configuration (Prefetch, Data instruction cache,...), configure the systTick and the NVIC priority grouping and the hardware low level initialization.

The sysTick configuration shall be adjusted by calling `HAL_RCC_ClockConfig()` function, to obtain 1 ms whatever the system clock.

Why do I need to configure the SysTick timer to use the HAL drivers?

The SysTick timer is configured to be used to generate variable increments by calling `HAL_IncTick()` function in Systick ISR and retrieve the value of this variable by calling `HAL_GetTick()` function.

The call `HAL_GetTick()` function is mandatory when using HAL drivers with Polling Process or when using `HAL_Delay()`.

Why is the SysTick timer configured to have 1 ms?

This is mandatory to ensure correct IO operation in particular for polling mode operation where the 1 ms is required as timebase.

Could `HAL_Delay()` function block my application under certain conditions?

Care must be taken when using `HAL_Delay()` since this function provides accurate delay based on a variable incremented in SysTick ISR. This implies that if `HAL_Delay()` is called from a peripheral ISR process, then the SysTick interrupt must have higher priority (numerically lower) than the peripheral interrupt, otherwise the caller ISR process will be blocked. Use `HAL_NVIC_SetPriority()` function to change the SysTick interrupt priority.

What programming model sequence should I follow to use HAL drivers ?

Follow the sequence below to use the APIs provided in the HAL drivers:

1. Call `HAL_Init()` function to initialize the system (data cache, NVIC priority,...).
2. Initialize the system clock by calling `HAL_RCC_OscConfig()` followed by `HAL_RCC_ClockConfig()`.
3. Add `HAL_IncTick()` function under `SysTick_Handler()` ISR function to enable polling process when using `HAL_Delay()` function
4. Start initializing your peripheral by calling `HAL_PPP_Init()`.
5. Implement the hardware low level initialization (Peripheral clock, GPIO, DMA,..) by calling `HAL_PPP_MspInit()` in `stm32f4xx_hal_msp.c`
6. Start your process operation by calling IO operation functions.

What is the purpose of HAL_PPP_IRQHandler() function and when should I use it?

HAL_PPP_IRQHandler() is used to handle interrupt process. It is called under PPP_IRQHandler() function in stm32f4xx_it.c. In this case, the end-user has to implement only the callbacks functions (prefixed by __weak) to perform the appropriate action when an interrupt is detected. Advanced users can implement their own code in PPP_IRQHandler() without calling HAL_PPP_IRQHandler().

Can I use directly the macros defined in stm32f4xx_hal_ppp.h ?

Yes, you can: a set of macros is provided with the APIs. They allow accessing directly some specific features using peripheral flags.

Where must PPP_HandleTypeDef structure peripheral handler be declared?

PPP_HandleTypeDef structure peripheral handler must be declared as a global variable, so that all the structure fields are set to 0 by default. In this way, the peripheral handler default state are set to HAL_PPP_STATE_RESET, which is the default state for each peripheral after a system reset.

68 Revision history

Table 17: Document revision history

Date	Revision	Changes
05-May-2014	1	Initial release.
03-Apr-2015	2	<p>Added CEC, FMPI2C, QSPI and SPDIFRX in Table 1: "Acronyms and definitions".</p> <p>Added STM32F446xx, cec, dcmi, fmpi2c, fmpi2c_ex, spdifrx and qspi in Table 5: "List of devices supported by HAL drivers".</p> <p>Updated Common macros section in Section 4.9: "HAL common resources".</p> <p>Added Section 9: "HAL CEC Generic Driver", Section 25: "HAL FLASH_RAMFUNC Generic Driver", Section 26: "HAL FMPI2C Generic Driver", Section 27: "HAL FMPI2C Extension Driver", Section 49: "HAL QSPI Generic Driver" and Section 60: "HAL SPDIFRX Generic Driver".</p>
17-Sep-2015	3	<p>Added DSI and LPTIM in Table 1: "Acronyms and definitions".</p> <p>Added STM32F469xx, STM32F479xx, STM32F410xx, dsi, ltdc_ex and lptim in Table 5: "List of devices supported by HAL drivers".</p> <p>Added Section 21: "HAL DSI Generic Driver", Section 41: "HAL LTDC Extension Driver" and Section 39: "HAL LPTIM Generic Driver".</p>

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2015 STMicroelectronics – All rights reserved

