

Reset

DS1307

VCC

Reset button outside the controller

for resetting the Arduino.

匸

Temp

RESET

SCL

SDA

Data DS18B20