

# **Zulay Double Whisk Milk Frother Handheld Mixer**

(Model: Twin Whisk - 12,500 RPM)

**QUICK START USER GUIDE** 

## Introduction

This Quick Start User Guide for the **Zulay Double Whisk Milk Frother Handheld Mixer** (Model: Twin Whisk - 12,500 RPM) by Zulay Kitchen explains how to start using your **Zulay Double Whisk Milk Frother** quickly, operate it safely, and get your rich milk foam in mere seconds.

The **Zulay Double Whisk Milk Frother** is a high-performance and ergonomic device designed for those with a preference for coffee and more. This milk frother is well-suited for making professional-level lattes, cappuccinos, macchiatos, hot chocolate, and protein shakes at home.

Please note that it is not recommended for whisking whipped cream or eggs.

## **Product overview**

The **Zulay Double Whisk Milk Frother** is a versatile, powerful, and durable addition to your kitchen or coffee station. It works with all types of milk, including half and half, creamer, soy, almond, cashew, hazelnut, whole milk, and other dairy options.



The **Zulay Double Whisk Milk Frother** features an easy-to-use push button and an ergonomic handle, providing a user-friendly and secure experience. Its double whisk head is engineered to produce ample froth very quickly and save you time and effort. The whisk head is made of high-quality stainless steel, to ensure durability and resistance to rust.

To clean the whisk, put it in running hot water, push the button on top of the handle, and release it in a second to switch the device off. Do not clean it in a dishwasher.

The **Zulay Double Whisk Milk Frother** comes with a sleek and unobtrusive metal stand for device storage or comfortable everyday usage. The frother's compact design is optimized for space-saving storage and is travel-friendly.

#### **Key Features:**

- **High-Powered Motor:** operates at 12,500 RPM, ensuring quick and efficient frothing.
- **Versatility:** excellent for frothing latte, cappuccino, macchiato, hot chocolate, whisking matcha, or mixing protein powder drinks.
- **Battery powered**: powered by two AA batteries (not included) making it portable and easy to use anytime.
- **No hassle guarantee:** backed by a lifetime guarantee from the Zulay Kitchen company.
- **Color and style:** comes in different colors and styles to fit your choice.
- **Package dimensions & item weight:** package parameters 247 x 72 x 72 mm, device weight 141,7 g.

## **Package contents**

The **Zulay Double Whisk Milk Frother Handheld Mixer** package contains:

- One **Zulay Double Whisk Milk Frother Handheld Mixer** (two AA-type batteries not included).
- One metal stand for device storage.
- Quick Start User Guide explaining how to use the mixer.
- Warranty Card that details the terms and conditions of the product warranty.
- Recipe Booklet to help you get started with making professional-level beverages using this device.

# **Configuration and customization options**

This product comes with a single on/off push button for simplicity and ease of use. It is ready to use after unpacking and does not require any special configuration. Follow the **"How to use the frother mixer"** section of this Quick Start User Guide to find out how to utilize the hand mixer.

This mixer comes as a pre-assembled kitchen unit and is not authorized for any additional customization. User-made customization of the product immediately voids the manufacturer's liability.

# Safety instructions and warnings

To prevent potential injuries or **Zulay Double Whisk Milk Frother** malfunction:

- Keep it away from children.
- Do not immerse the motor unit in water or any other liquid.
- Clean the frothing aid immediately after each use.
- Don't customize the product, change its parameters, or use it with the power source not listed in this Quick Start User Guide (always use two AA-type batteries).
- Remove batteries when not in use for an extended period.

## **Product setup instructions**

The **Zulay Double Whisk Milk Frother** features ultimate simplicity and ergonomics. To start frothing milk you just need to insert 2 AA-type batteries (not included in the package) and push the power button.



Open the battery compartment on the back part of the motor unit

#### **Before you start:**

- Open the battery compartment on the back part of the motor unit, and insert 2 standard AA batteries (not included).
- Close the battery compartment, and ensure it is securely closed.
- Now you are ready to use the **Zulay Double Whisk Milk Frother** for milk frothing.
- (Optionally) If you don't need your **Zulay Double Whisk Milk Frother** to froth milk right now, you can put it on a storage stand.

## How to use the frother mixer

To froth any type of milk, whisk matcha tea, or mix protein powder shake, and get the best possible result, follow these simple steps:

1. Hold the container with the liquid at a 45-degree angle. Place the whisk head into the liquid you wish to froth, ensuring that the head is submerged before turning it on.



Hold the container at a 45-degree angle

2. Push the on/off button to start the frother. Move the frother up and down until the foam reaches the desired consistency (about 20-45 seconds).



Push the button, move the frother up and down

3. Once finished, release the on/off button to switch off the frother.

4. To clean, place the whisk in hot running water, push the on/off button and hold it for a second, then release. Ensure to also clean the frothing aid with a damp cloth immediately after each use.



Place the whisk in the water, press and release the on/off button

5. Dry and place the frother on the metal stand for easy storage.

# **Troubleshooting**

- If the frother is not turning on, check if the batteries are inserted correctly or if they need replacing.
- If the frother is not working properly, ensure the frothing aid is clean.
- If the milk is not frothing properly, make sure that the whisk head is fully attached. Try moving the frother more slowly or quickly.
- Avoid lifting the whisk head out of the liquid while in use as this can cause splattering.

# Frequently asked questions (FAQ)

#### Q: Does Zulay Double Whisk Milk Frother come with batteries?

A: No, you will need 2 AA batteries, which are not included.

## Q: How do I insert batteries?

A: Open the battery compartment in the back part of the motor unit, and insert 2 standard AA batteries in accordance with their polarity. The positive (+) end of each battery must align with the positive marking inside the battery compartment, and the negative (-) end with the negative marking. Close the battery compartment, and check if it is closed tightly.

### Q: Do I need to hold the on/off button while frothing?

A: Yes. The device starts working when you push and hold the on/off button and immediately stops when you release the on/off button.

#### Q: How do I clean my Milk Frother?

A: Simply place the whisk in hot running water and briefly turn it on by holding the button.

#### Q: Can I use the Milk Frother with non-dairy milk?

A: Yes, it works great with almond, soy, cashew, and other non-dairy milk.

Q: Can I use the Milk Frother for whisking whipped cream, egg yolks, or egg whites?
A: We do not recommend doing this using **Zulay Double Whisk Milk Frother**. You can use other Zulay Kitchen products to do this.