

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Collaboration Systems
Manufacturer: Kramer
Firmware Version: N/A
Model(s): VIA GO, VIA GO2

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.17.0000-b002	2.19.0.48

Version History

Module Version	Date	Notes
1_0_1_0	7/13/2023	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly. devicePassword and deviceUsername default values are 'supass' and 'su' respectively.
Example: `InterfaceName.devicePassword = 'supass'`

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 9982, Model='VIA GO')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	
CloudClean	None	
# CloudClean example InterfaceName.Set('CloudClean', None)		
Command	Value	Value
DoNotDisturb	'On'	'Off'
Qualifier Key	Qualifier Value	
'User'	'String'	
# DoNotDisturb example InterfaceName.Set('DoNotDisturb', 'On', {'User': 'String'})		
Command	Value	
Kickoff	None	
Qualifier Key	Qualifier Value	
'User'	'String'	
# Kickoff example InterfaceName.Set('Kickoff', None, {'User': 'String'})		
Command	Value	Value
PresentationMode	'On'	'Off'
# PresentationMode example InterfaceName.Set('PresentationMode', 'On')		
Command	Value	
Reboot	None	
# Reboot example InterfaceName.Set('Reboot', None)		
Command	Value	
RestartApacheServer	None	
# RestartApacheServer example InterfaceName.Set('RestartApacheServer', None)		
Command	Value	Value
Screenshare	'On'	'Off'
# Screenshare example InterfaceName.Set('Screenshare', 'On')		
Command	Value	
Volume	0 to 100 in steps of 1 %	
# Volume example InterfaceName.Set('Volume', 100)		
Command	Value	Value
WakeUp	'On'	'Off'
# WakeUp example InterfaceName.Set('WakeUp', 'On')		
Command	Value	Value
WifiGuestMode	'Start'	'Stop'
# WifiGuestMode example InterfaceName.Set('WifiGuestMode', 'Start')		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value		
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value		Value
DisplayStatus	'Not Presenting'	'Presenting'	'Waiting'
	'User Does Not Exist'		
Qualifier Key	Qualifier Value		
'User'	'String'		
# DisplayStatus example InterfaceName.Update('DisplayStatus', {'User': 'String'}) Value = InterfaceName.ReadStatus('DisplayStatus', {'User': 'String'}) InterfaceName.SubscribeStatus('DisplayStatus', None, FeedbackHandler)			
Command	Value		
IPAddress	'String'		
# IPAddress example InterfaceName.Update('IPAddress') Value = InterfaceName.ReadStatus('IPAddress') InterfaceName.SubscribeStatus('IPAddress', None, FeedbackHandler)			
Command	Value		Value
PresentationMode	'On'	'Off'	
# PresentationMode example InterfaceName.Update('PresentationMode') Value = InterfaceName.ReadStatus('PresentationMode') InterfaceName.SubscribeStatus('PresentationMode', None, FeedbackHandler)			
Command	Value		
RoomCode	'String'		
# RoomCode example InterfaceName.Update('RoomCode') Value = InterfaceName.ReadStatus('RoomCode') InterfaceName.SubscribeStatus('RoomCode', None, FeedbackHandler)			
Command	Value		
Volume	0 to 100 in steps of 1 %		
# Volume example InterfaceName.Update('Volume') Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)			
Command	Value		Value

Global Scripter Module Communication Sheet

WifiGuestMode	'Start'	'Stop'
<pre># WifiGuestMode example InterfaceName.Update('WifiGuestMode') Value = InterfaceName.ReadStatus('WifiGuestMode') InterfaceName.SubscribeStatus('WifiGuestMode', None, FeedbackHandler)</pre>		

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type: Ethernet (TCP)

Default Port: 9982

Logon Credentials Supported: Yes

Default Username: su

Default Password: supass

Multi-Connection: Undetermined

Capabilities:

Port Changeability: No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Cloud Clean None	<P><UN>su</UN><PwD>supass</PwD><Cmd>CloudClean</Cmd><P1></P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Presentation Mode Off	<P><UN>su</UN><PwD>supass</PwD><Cmd>PrsMode</Cmd><P1>Set</P1><P2>0</P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Presentation Mode On	<P><UN>su</UN><PwD>supass</PwD><Cmd>PrsMode</Cmd><P1>Set</P1><P2>1</P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Reboot None	<P><UN>su</UN><PwD>supass</PwD><Cmd>Reboot</Cmd><P1></P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Restart Apache Server None	<P><UN>su</UN><PwD>supass</PwD><Cmd>RestartApache</Cmd><P1></P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Screenshare Off	<P><UN>su</UN><PwD>supass</PwD><Cmd>ScreenShare</Cmd><P1>Off</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Screenshare On	<P><UN>su</UN><PwD>supass</PwD><Cmd>ScreenShare</Cmd><P1>On</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Volume 0	<P><UN>su</UN><PwD>supass</PwD><Cmd>Vol</Cmd><P1>Set</P1><P2>0</P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Volume 100	<P><UN>su</UN><PwD>supass</PwD><Cmd>Vol</Cmd><P1>Set</P1><P2>100</P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Wake Up Off	<P><UN>su</UN><PwD>supass</PwD><Cmd>WakeUp</Cmd><P1>1</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Wake Up On	<P><UN>su</UN><PwD>supass</PwD><Cmd>WakeUp</Cmd><P1>0</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Wifi Guest Mode Start	<P><UN>su</UN><PwD>supass</PwD><Cmd>WifiGuestMode</Cmd><P1>1</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Wifi Guest Mode Stop	<P><UN>su</UN><PwD>supass</PwD><Cmd>WifiGuestMode</Cmd><P1>0</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>

Appendix B. Update Commands

IP Address	<P><UN>su</UN><Pwd>supass</Pwd><Cmd>IpInfo</Cmd><P1></P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Presentation Mode	<P><UN>su</UN><Pwd>supass</Pwd><Cmd>PrsMode</Cmd><P1>Get</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Room Code	<P><UN>su</UN><Pwd>supass</Pwd><Cmd>RCode</Cmd><P1>Get</P1><P2>Code</P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Volume	<P><UN>su</UN><Pwd>supass</Pwd><Cmd>Vol</Cmd><P1>Get</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>
Wifi Guest Mode	<P><UN>su</UN><Pwd>supass</Pwd><Cmd>WifiGuestMode</Cmd><P1>Status</P1><P2></P2><P3></P3><P4></P4><P5></P5><P6></P6><P7></P7><P8></P8><P9></P9><P10></P10></P>