

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scripter Modules, refer to the "[Guide to Using Scripter Modules](#)" document.

Device Specifications

Device Type: Controller
Manufacturer: Extron
Firmware Version: 1.6
Model(s): IPL T PCS4, IPL T PCS4i

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scripter Version
3.01.0000-b010	2.1.0

Version History

Module Version	Date	Notes
1_2_2_0	12/17/2018	Updated error message.
1_2_0_1	10/2/2017	Updated module to Rev. B
1_2_0_0	12/09/2016	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword must be set accordingly.
Example: `InterfaceName.devicePassword = 'extron'`

Supported Classes and Examples

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='IPL T PCS4')</code>

Set Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command ExecutiveMode	Value 'On'	Value 'Off'	
# ExecutiveMode example InterfaceName.Set('ExecutiveMode', 'On')			
Command OutputReferenceThreshold	Value 'Full'	Value 'Standby'	Value None
Qualifier Key 'Output'	Qualifier Value '1' – '4'		
# OutputReferenceThreshold example InterfaceName.Set('OutputReferenceThreshold', 'Full', {'Output': '1'})			
Command PowerControl	Value 'On'	Value 'Off'	
Qualifier Key 'Output'	Qualifier Value '1' – '4'		
# PowerControl example InterfaceName.Set('PowerControl', 'On', {'Output': '1'})			

Status Available

For all commands, Update should be called only once since the command's status will be updated automatically as the device's status changes.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'}, FeedbackHandler)
FeedbackHandler will be called only when the specified qualifier gets a new status.
```

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus examples Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	
ExecutiveMode	'On'	'Off'	
# ExecutiveMode examples InterfaceName.Update('ExecutiveMode') Value = InterfaceName.ReadStatus('ExecutiveMode') InterfaceName.SubscribeStatus('ExecutiveMode', None, FeedbackHandler)			
Command	Value	Value	Value
OutputReferenceThreshold	'Full'	'Standby'	None
Qualifier Key	Qualifier Value		
'Output'	'1' – '4'		
# OutputReferenceThreshold examples InterfaceName.Update('OutputReferenceThreshold', {'Output': '1'}) Value = InterfaceName.ReadStatus('OutputReferenceThreshold', {'Output': '1'}) InterfaceName.SubscribeStatus('OutputReferenceThreshold', None, FeedbackHandler)			
Command	Value	Value	
PowerControl	'On'	'Off'	
Qualifier Key	Qualifier Value		
'Output'	'1' – '4'		
# PowerControl examples InterfaceName.Update('PowerControl', {'Output': '1'}) Value = InterfaceName.ReadStatus('PowerControl', {'Output': '1'}) InterfaceName.SubscribeStatus('PowerControl', None, FeedbackHandler)			

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type:	Ethernet
Default Port:	23
Logon Credentials Supported:	Yes
Multi-Connection Capabilities:	Undetermined
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Please refer to user manual for settings and changes to the network communication.
If User password is used for Authentication, then control of the device may be limited.

Appendix A. Set Commands

ExecutiveMode Off	0X\r\n
ExecutiveMode On	1X\r\n
OutputReference Output 1 Clear	W1*0TH\r\n
OutputReference Output 1 Full	W1*2TH\r\n
OutputReference Output 1 Standby	W1*1TH\r\n
OutputReference Output 2 Clear	W2*0TH\r\n
OutputReference Output 2 Full	W2*2TH\r\n
OutputReference Output 2 Standby	W2*1TH\r\n
OutputReference Output 3 Clear	W3*0TH\r\n
OutputReference Output 3 Full	W3*2TH\r\n
OutputReference Output 3 Standby	W3*1TH\r\n
OutputReference Output 4 Clear	W4*0TH\r\n
OutputReference Output 4 Full	W4*2TH\r\n
OutputReference Output 4 Standby	W4*1TH\r\n
PowerControl Output 1 Off	W1*0PC\r\n
PowerControl Output 1 On	W1*1PC\r\n
PowerControl Output 2 Off	W2*0PC\r\n
PowerControl Output 2 On	W2*1PC\r\n
PowerControl Output 3 Off	W3*0PC\r\n
PowerControl Output 3 On	W3*1PC\r\n
PowerControl Output 4 Off	W4*0PC\r\n
PowerControl Output 4 On	W4*1PC\r\n

Appendix B. Query Commands

ExecutiveMode	X\r\n
OutputReference Output 1	WTH\r\n
OutputReference Output 2	WTH\r\n
OutputReference Output 3	WTH\r\n
OutputReference Output 4	WTH\r\n
PowerControl Output 1	W1PC\r\n
PowerControl Output 2	W2PC\r\n
PowerControl Output 3	W3PC\r\n
PowerControl Output 4	W4PC\r\n