

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Video Conference
Manufacturer: Poly
Firmware Version: 4.6.2-460046
Model(s): Poly Studio X50, Poly Studio X30, Poly Studio X70, Poly Studio X52

Tested on the Following Software and Firmware Versions

ControlScript Deployment Utility	1.12.0-b.73
IP Link Pro Control Processor Firmware	3.18.0001-b002
IP Link Pro Control Processor xi Firmware	1.12.0000-b019
IP Link Pro Control Processor Q xi Firmware	1.12.0000-b019

Version History

Module Version	Date	Notes
1_3_3_0	3/20/2026	Renamed module from: poly_vtc_Poly_Studio_Series → poly_vtc_Poly_Studio_X_Series. Updated module authentication to support device firmware 4.6.2. Added Ready and Disconnecting to Collaboration Session Status. Added dot to DTMF. Added Some Up to System Status. Updated Reboot command string.
1_3_1_0	8/20/2025	Added commands: System State, Call Info Heartbeat, Call Info Name, Call Info Number, Call Info State, Hook, Zoom Rooms Meeting Status, Microsoft Teams Meeting Status, Camera Near Tracking. Added model: Poly Studio X52.
1_1_0_0	6/1/2022	Added Poly Studio X70 model. Added System Status. Renamed Mic Volume to Volume and changed range from soft to absolute. Removed Collaboration Session Content Save command. Updated Collaboration Content Save All command logic. Added Number of Camera Far, Camera Near, and Phonebook Results module parameters. Updated module authentication logic.
1_0_2_0	12/8/2020	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- SSLVerifyMode variable must be set accordingly. Default value is 'On'.
Example: `InterfaceName = ModuleName.HTTPClass('192.168.254.254', 443, 'admin', 'password', Model='Poly Studio X50', SSLVerifyMode='On')`
- NumberOfCameraNearResults variable must be set accordingly. Default value is '5'.
NumberOfCameraNearResults ranges from 1 to 10.
Example: `InterfaceName.NumberOfCameraNearResults = '5'`
- NumberOfCameraFarResults variable must be set accordingly. Default value is '5'.
NumberOfCameraFarResults ranges from 1 to 10.
Example: `InterfaceName.NumberOfCameraFarResults = '5'`
- NumberOfPhonebookResults variable must be set accordingly. Default value is '5'.
NumberOfPhonebookResults ranges from 1 to 10.
Example: `InterfaceName.NumberOfPhonebookResults = '5'`
- The following applies when authentication is enabled on the device.
 - The module will make one attempt to authenticate using the credentials supplied to the module. If this attempt fails, all subsequent login attempts, commands, and queries will be blocked from being sent to the device. Please verify the credentials, then rebuild the configuration to reattempt authentication.
 - **NOTE:** Login attempts are shared by both the module and Web UI. The number of attempts may be adjusted under Web UI → Security → Local Accounts → Account Lockout → **Lock Admin Account After Failed Logins**.
 - The module may be required to reauthenticate at the interval specified by **Max Session Timeout in Minutes** within Web UI → Security → Access. The device will reject control commands and queries between each interval until the module reauthenticates. Therefore, it is recommended to set **Max Session Timeout in Minutes** to a large interval or Off.
 - If the module is authenticated when password is changed on the device, the device will immediately require the module to reauthenticate.
- Regardless of authentication requirements, the device creates a session for the module to allow communication. If the **Maximum Number of Active Sessions** set within Web UI → Security → Access is reached, the device will not create a session for the module, resulting in no control or status.
 - The module will reattempt to obtain a session, given the login credentials supplied are correct.
 - Each module initialization from rebuilding or program restart requests the device to create a new session.
 - Existing sessions individually expire as specified by Web UI → Security → Access → **Idle Session Timeout in Minutes** and **Max Session Timeout in Minutes**, whichever comes first.
 - Existing sessions may be viewed in Web UI → Diagnostics → **Sessions**.

-
- The following commands are updated by CallInfoHeartbeat: CallInfoName, CallInfoNumber, CallInfoState

Supported Class and Example

HTTPClass

```
InterfaceName = ModuleName.HTTPClass('192.168.254.254', 443, 'admin', 'password', Model='Poly  
Studio X50', SSLVerifyMode='On')
```

Camera Far and Near Commands

- **Camera Far/Near List**
 - This is where the results will be saved to when Camera Far/Near List is updated. The number of results to display is specified by the Number of Camera Far/Near Results driver parameter that is set to 5 by default.
- **Camera Far/Near List Navigation**
 - This command is used for navigating through the results for Camera Far/Near List.
- **Camera Far/Near List Update**
 - This command is used to query the Camera Far/Near List, in which the device will respond with a list of results, which will be populated in Camera Far/Near List.
- **Camera Far/Near Pan Tilt**
 - This command will execute pan and tilt control for entry selected from Camera Far/Near List.
- **Camera Far/Near Zoom**
 - This command will execute zoom control for entry selected from Camera Far/Near List.
- **Camera Near Focus**
 - This command will execute focus control for entry selected from Camera Near List.
- **Camera Near Tracking**
 - This command will execute tracking control for entry selected from Camera Near List.

Phonebook Commands

- **Phonebook Dial**
 - This command dials entry selected from Phonebook Results.
- **Phonebook Navigation**
 - This command is used for navigating through the results for Phonebook Results.
- **Phonebook Results**
 - This is where the results will be saved to when Phonebook is updated. The number of results to display is specified by the Number of Phonebook Results driver parameter that is set to 5 by default.
- **Phonebook Update**
 - This command is used to query the Phonebook, in which the device will respond with a list of results, which will be populated in Phonebook Results.

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command CameraFarListNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# CameraFarListNavigation example InterfaceName.Set('CameraFarListNavigation', 'Up')			
Command CameraFarListUpdate	Value None		
# CameraFarListUpdate example InterfaceName.Set('CameraFarListUpdate', None)			
Command CameraFarPanTilt ¹	Value 'Up' 'Right'	Value 'Down' 'Stop'	Value 'Left'
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# CameraFarPanTilt example InterfaceName.Set('CameraFarPanTilt', 'Up', {'Position': '1'})			
Command CameraFarZoom ¹	Value 'In'	Value 'Out'	Value 'Stop'
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# CameraFarZoom example InterfaceName.Set('CameraFarZoom', 'In', {'Position': '1'})			
Command CameraNearFocus	Value 'Near'	Value 'Far'	Value 'Stop'
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# CameraNearFocus example InterfaceName.Set('CameraNearFocus', 'Near', {'Position': '1'})			
Command CameraNearListNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# CameraNearListNavigation example InterfaceName.Set('CameraNearListNavigation', 'Up')			
Command CameraNearListUpdate	Value None		
# CameraNearListUpdate example InterfaceName.Set('CameraNearListUpdate', None)			
Command CameraNearPanTilt ¹	Value 'Up' 'Right'	Value 'Down' 'Stop'	Value 'Left'
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# CameraNearPanTilt example InterfaceName.Set('CameraNearPanTilt', 'Up', {'Position': '1'})			

Command CameraNearPreset	Value '1' – '10'		
Qualifier Key 'Action'	Qualifier Value 'Clear' 'Save without Image'	Qualifier Value 'Recall'	Qualifier Value 'Save with Image'
# CameraNearPreset example InterfaceName.Set('CameraNearPreset', '1', {'Action': 'Clear'})			
Command CameraNearTracking ¹	Value 'On' 'Off'		
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# CameraNearTracking example InterfaceName.Set('CameraNearTracking', 'On', {'Position': '1'})			
Command CameraNearZoom ¹	Value 'In' 'Out' 'Stop'		
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# CameraNearZoom example InterfaceName.Set('CameraNearZoom', 'In', {'Position': '1'})			
Command CollaborationSessionContentSave	Value None		
Qualifier Key 'PIN'	Qualifier Value String		
# CollaborationSessionContentSave example InterfaceName.Set('CollaborationSessionContentSave', None, {'PIN': 'String'})			
Command CollaborationSessionContentSaveStatus	Value 'Enable' 'Disable'		
Qualifier Key 'PIN'	Qualifier Value String		
# CollaborationSessionContentSaveStatus example InterfaceName.Set('CollaborationSessionContentSaveStatus', 'Enable', {'PIN': 'String'})			
Command CollaborationSessionEnd	Value None		
# CollaborationSessionEnd example InterfaceName.Set('CollaborationSessionEnd', None)			
Command DeviceMode	Value 'On' 'Off'		
# DeviceMode example InterfaceName.Set('DeviceMode', 'On')			
Command DTMF	Value '0' – '9' '*' '#'		
# DTMF example InterfaceName.Set('DTMF', '0')			

Command Hook	Value 'Dial Auto' 'Hangup 1' 'Hangup 4' 'Dial Audio'	Value 'Answer' 'Hangup 2' 'Hangup 5'	Value 'Ignore' 'Hangup 3' 'Dial Video'
Qualifier Key 'Dial String' ²	Qualifier Value String		
# Hook example InterfaceName.Set('Hook', 'Dial Auto', {'Dial String': 'String'}) InterfaceName.Set('Hook', 'Answer')			
Command MicMute	Value 'On'	Value 'Off'	
# MicMute example InterfaceName.Set('MicMute', 'On')			
Command PhonebookDial	Value None		
Qualifier Key 'Position'	Qualifier Value '1' – '10'		
# PhonebookDial example InterfaceName.Set('PhonebookDial', None, {'Position': '1'})			
Command PhonebookNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# PhonebookNavigation example InterfaceName.Set('PhonebookNavigation', 'Up')			
Command PhonebookUpdate	Value None		
# PhonebookUpdate example InterfaceName.Set('PhonebookUpdate', None)			
Command Reboot	Value None		
# Reboot example InterfaceName.Set('Reboot', None)			
Command VideoMute	Value 'On'	Value 'Off'	
# VideoMute example InterfaceName.Set('VideoMute', 'On')			
Command Volume	Value 0 to 100 in steps of 1		
# Volume example InterfaceName.Set('Volume', 100)			

¹ Requires at least one prior use of Camera Far/Near List Update.² Only needed for 'Dial' commands.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, CallInfoName, CallInfoNumber, CallInfoState, CameraFarList, CameraNearList, and PhonebookResults do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value		
CallInfoHeartbeat	None		
# CallInfoName example Value = InterfaceName.Update('CallInfoHeartbeat')			
Command	Value		
CallInfoName ¹	'String'		
Qualifier Key	Qualifier Value		
'Call'	1 – 5		
# CallInfoName example Value = InterfaceName.ReadStatus('CallInfoName', {'Call': 5}) InterfaceName.SubscribeStatus('CallInfoName', None, FeedbackHandler)			
Command	Value		
CallInfoNumber ¹	'String'		
Qualifier Key	Qualifier Value		
'Call'	1 – 5		
# CallInfoNumber example Value = InterfaceName.ReadStatus('CallInfoNumber', {'Call': 5}) InterfaceName.SubscribeStatus('CallInfoNumber', None, FeedbackHandler)			
Command	Value	Value	Value
CallInfoState ¹	'Inactive'	'Allocated'	'Dialing'
	'Incoming'	'Ringing'	'Connecting'
	'Connected'	'Aborted'	'Failed'
	'Holding'	'Transferring'	'Disconnecting'
	'Disconnected'	'Idle'	
Qualifier Key	Qualifier Value		
'Call'	1 – 5		
# CallInfoState example Value = InterfaceName.ReadStatus('CallInfoState', {'Call': 5}) InterfaceName.SubscribeStatus('CallInfoState', None, FeedbackHandler)			
Command	Value		
CameraFarList	'String'		
Qualifier Key	Qualifier Value		
'Position'	'1' – '10'		
# CameraFarList example Value = InterfaceName.ReadStatus('CameraFarList', {'Position': '1'}) InterfaceName.SubscribeStatus('CameraFarList', None, FeedbackHandler)			

Command	Value		
CameraNearList	'String'		
Qualifier Key	Qualifier Value		
'Position'	'1' – '10'		
# CameraNearList example Value = InterfaceName.ReadStatus('CameraNearList', {'Position': '1'}) InterfaceName.SubscribeStatus('CameraNearList', None, FeedbackHandler)			
Command	Value	Value	Value
CollaborationSessionStatus	'Active'	'Not Active'	'Ready'
	'Disconnecting'		
# CollaborationSessionStatus example InterfaceName.Update('CollaborationSessionStatus') Value = InterfaceName.ReadStatus('CollaborationSessionStatus') InterfaceName.SubscribeStatus('CollaborationSessionStatus', None, FeedbackHandler)			
Command	Value	Value	
ConnectionStatus	'Connected'	'Disconnected'	
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			
Command	Value	Value	
DeviceMode	'On'	'Off'	
# DeviceMode example InterfaceName.Update('DeviceMode') Value = InterfaceName.ReadStatus('DeviceMode') InterfaceName.SubscribeStatus('DeviceMode', None, FeedbackHandler)			
Command	Value	Value	
MicMute	'On'	'Off'	
# MicMute example InterfaceName.Update('MicMute') Value = InterfaceName.ReadStatus('MicMute') InterfaceName.SubscribeStatus('MicMute', None, FeedbackHandler)			
Command	Value	Value	
MicrosoftTeamsMeetingStatus	'Connected'	'Idle'	
# MicrosoftTeamsMeetingStatus example InterfaceName.Update('MicrosoftTeamsMeetingStatus') Value = InterfaceName.ReadStatus('MicrosoftTeamsMeetingStatus') InterfaceName.SubscribeStatus('MicrosoftTeamsMeetingStatus', None, FeedbackHandler)			
Command	Value		
PhonebookResults	'String'		
Qualifier Key	Qualifier Value		
'Position'	'1' – '10'		
# PhonebookResults example Value = InterfaceName.ReadStatus('PhonebookResults', {'Position': '1'}) InterfaceName.SubscribeStatus('PhonebookResults', None, FeedbackHandler)			
Command	Value	Value	Value
SystemState	'Initializing'	'Ready'	'Shutting Down'
	'Down'	'Updating'	'Sleep'
# SystemState example InterfaceName.Update('SystemState') Value = InterfaceName.ReadStatus('SystemState') InterfaceName.SubscribeStatus('SystemState', None, FeedbackHandler)			

**Global Scripter Module
Communication Sheet**

Command SystemStatus	Value 'Up' 'Down'	Value 'All Up' 'Off'	Value 'None Up' 'Some Up'
Qualifier Key 'Status'	Qualifier Value 'LAN Network' 'Provisioning Service' 'Log Threshold' 'Gatekeeper'	Qualifier Value 'Built-In Camera' 'Microphones' 'Auto Answer Point-to-Point Video' 'Global Directory Server'	Qualifier Value 'Cameras' 'Remote Control' 'SIP Registrar Server' 'Calendaring Service'
# SystemStatus example InterfaceName.Update('SystemStatus', {'Status': 'LAN Network'}) Value = InterfaceName.ReadStatus('SystemStatus', {'Status': 'LAN Network'}) InterfaceName.SubscribeStatus('SystemStatus', None, FeedbackHandler)			
Command VideoMute	Value 'On'	Value 'Off'	
# VideoMute example InterfaceName.Update('VideoMute') Value = InterfaceName.ReadStatus('VideoMute') InterfaceName.SubscribeStatus('VideoMute', None, FeedbackHandler)			
Command Volume	Value 0 to 100 in steps of 1		
# Volume example InterfaceName.Update('Volume') Value = InterfaceName.ReadStatus('Volume') InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)			
Command ZoomRoomsMeetingStatus	Value 'Connected'	Value 'Idle'	
# ZoomRoomsMeetingStatus example InterfaceName.Update('ZoomRoomsMeetingStatus') Value = InterfaceName.ReadStatus('ZoomRoomsMeetingStatus') InterfaceName.SubscribeStatus('ZoomRoomsMeetingStatus', None, FeedbackHandler)			

¹ Updated by CallInfoHeartbeat.

Network Communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type: Ethernet (HTTPS)

Default Port: 443

Logon Credentials Supported: Yes

Default Username: admin

Multi-Connection Yes

Capabilities:

Port Changeability: No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device