#### Pi1541 - Switch Rev. 1

## Module description

## Description

The Pi1541-Switch is a detachable switch board for the Pi1541 HAT (project number 111). The connector to the Pi1541 HAT is placed on the solder side of the PCB.

### **Switches**

The switches have functions according to the firmware and configuration, which can be found at this website: <a href="https://cbm-pi1541.firebaseapp.com/">https://cbm-pi1541.firebaseapp.com/</a>

The default configuration is:

Switch	Function	
SW1 (left)	Select/Reset	
SW2	Move Up/Previous Disk	
SW3	Move Down/Next Disk	
SW4	Exit Folder	
SW5 (right)	Insert Disk	

#### **LEDs**

LED	Color	Function
LD2	Green	Power Indicator
LD1	Red	Busy Indicator

## Connector

X3: 8p Micro Match, female, THT (Tyco or alternative)

The ribbon cable can also be soldered in directly.

Pin	Signal
1	/SW1
2	/SW2
3	/SW3
4	/SW4
5	/SW5
6	LED_OUT (LD1)
7	+3V3
8	GND

#### Measures

Can be found in the board print out

# Revision History

Rev. 0: Prototype

Rev. 1: Moved the connector X3 to the solder side

17.03.2019 12:15

Doc.-No.: 112-6-01-01