

RRC-Raptor-V4H

I2C

- User's Manual: Software

V0.0.3

Contents

i.	VERSION LIST	4
ii.	HASHTAG	5
1.	Overview.....	6
2.	Directory Configuration.....	7
3.	Kernel configuration	7
4.	Connect.....	8
5.	Option Setting.....	10
6.	I2C Tool.....	11
7.	APPENDIX	12

LIST OF FIGURES

FIGURE 1. DIRECTORY CONFIGURATION	7
FIGURE 2 KERNEL CONFIGURATION.....	7
FIGURE 3 CONNECT	8
FIGURE 4 EXAMPLE OF I2CTransfer METHOD.....	11

i. VERSION LIST

Description	Version	Date	Author
RTX_I2C	V0.0.1	2024/07/17	Jerry
RTX_I2C	V0.0.2	2024/10/29	Jerry
Translate the content into English.	V0.0.3	2024/11/20	Jerry

ii. HASHTAG

#V4H

#I2C

#BSP

1. Overview

Target : Introduce kernel configuration and how to use I2C tools to read and write to I2C devices.

2. Directory Configuration

The directory configuration is shown below.

—— drivers/i2c/busses/ —— i2c-rcar.c : I2C Driver source file

Figure 1. Directory Configuration

3. Kernel configuration

To enable the function of this module, make the following setting with Kernel Configuration. The changes affect after re-building the kernel.

```
Device Drivers --->
  *- I2C support --->
    <*> I2C device interface
    I2C Hardware Bus support --->
      <*> Renesas R-Car I2C Controller
```

Figure 2 Kernel configuration

4. Connect

Provide an I2C interface so that users can add their own I2C devices.

CN32 CAN BOARD CONNECTOR




Figure 3 Connect

CN32 : CAN/I2C/GPIO CONNECTOR

CAN H / CAN L signals after passing through the internal transceiver.

PIN	SYMBOL	System bus ID
1	I2C2_SDA_CNA	I2C19
2	I2C2_SCL_CNA	I2C19
3	I2C2_SDA_CNB	I2C19
4	I2C2_SCL_CNB	I2C19
5	I2C2_SDA_CNC	I2C20
6	I2C2_SCL_CNC	I2C20
7	I2C2_SDA_CND	I2C20
8	I2C2_SCL_CND	I2C20
9	I2C2_SDA_CNE	I2C21
10	I2C2_SCL_CNE	I2C21

11	I2C2_SDA_CNF	I2C21
12	I2C2_SCL_CNF	I2C21
13	D3.3V_I2C	
14	SG	
17	D5.0V1	
18	D5.0V1	

CN25 : I2C CN

I2C0~I2C4 are signals directly from the SoC.

PIN	SYMBOL	System bus ID
1	D3.3V_I2C	
2	GND	
3	D3.3V_I2C	
4	GND	
5	I2C0_SCL	I2C0
6	I2C0_SDA	I2C0
7	I2C1_SCL	I2C1
8	I2C1_SDA	I2C1
9	I2C2_SCL	I2C2
10	I2C2_SDA	I2C2
11	I2C3_SCL	I2C3
12	I2C3_SDA	I2C3
13	I2C4_SCL	I2C4
14	I2C4_SDA	I2C4

5. Option Setting

Please set I2C transfer speed 1000000 or 400000 or 100000 to "clock-frequency" of device tree file in arch/arm64/boot/dts/renesas directory. No setting means 100000 Hz.

```
&i2c0 {  
    status = "okay";  
    clock-frequency = <100000>;  
    ...  
}  
  
&i2c1 {  
    status = "okay";  
    clock-frequency = <400000>;  
    ...  
}
```

I2C0, I2C1, I2C2, I2C3, I2C4, and I2C5 have Open drain buffer.

Their IntDelay are set 110ns in arch/arm64/boot/dts/renesas/ r8a779g0.dtsi

For fast mode plus, please set "i2c-scl-rising-time-ns" to 120 or lower (according to I2C specification).

6. I2C Tool

Users can connect through CN32 (I2C2_CNA to I2C2_CNF) or CN25 (I2C0 to I2C4).

Use i2ctransfer can read / write i2c device.

- I. **Here is an example of Raptor connecting to I2C AT24C256 EEPROM (address 0x50) through CN25 的 I2C1.**

The process for the following example is as follows:

1. Read 4 bytes of data from address 0x00 on the I2C1 device at 0x50.
2. Write 0x23 to address 0x01 on the I2C1 device at 0x50.
3. Then read 4 bytes of data from address 0x00 on the I2C1 device at 0x50 and observe that the value at address 0x01 has changed to 0x23..

```
root@v4x:~# i2ctransfer -f -y 1 w2@0x50 0x00 0x0 r4
0xff 0xff 0xff 0xff
root@v4x:~# i2ctransfer -f -y 1 w3@0x50 0x00 0x01 0x23
root@v4x:~# i2ctransfer -f -y 1 w2@0x50 0x00 0x0 r4
0xff 0x23 0xff 0xff
```

Figure 4 example of i2ctransfer method

- II. **If you want to connect an EEPROM (address 0x50) via CN32's I2CA.**

Replace the 1 (bus 1) in the transfer command of the above example with 19 (bus 19).

I2ctransfer -f -y 19 w2@0x50 0x00 0x0 r4

I2ctransfer -f -y 19 w3@0x50 0x00 0x1 0x23

I2ctransfer -f -y 19 w2@0x50 0x00 0x0 r4

7. APPENDIX