

### Impossible to set the TZEN option bit

Issue: The user cannot set the TZEN option bit through Bootloader interfaces.

Workaround: Instead of the bootloader interface, the user can use JTAG to set the TZEN option bit.

### Go command on USB-DFU interface

Issue: The user cannot use the Go command through the bootloader on the USB-DFU interface.

Workaround: Instead of the USB-DFU interface, the user can use JTAG or any other communication ports supported by Bootloader to run the Go command, like USART, I<sup>2</sup>C, SPI, or CAN FD.

**Caution:** Only SFI through JTAG is fully supported on bootloader V9.0. SFI through bootloader interfaces is partially supported because some option bytes cannot be managed by the bootloader and they must be set through JTAG.

## 6.11.2 Boot from RSS

On the NUCLEO-L552ZE-Q, PH3-BOOT0 is fixed to a LOW level allowing the boot from the memory address defined by the SECBOOTADD0 option byte. To change the boot from RSS, it is necessary to set PH3-BOOT0 to the HIGH level just by applying 3V3 on the PH3-BOOT0 signal. The easiest solution is to make a direct connection between CN11 pin 5 (VDD) and 7 (PH3\_BOOT0).

## 6.12 Virtual COM port: LPUART or USART

An LPUART or a USART interface of the STM32 microcontroller on the NUCLEO board can be connected to ST-LINK/V2-1 MCU or on shields on ST morpho connectors and ARDUINO<sup>®</sup> Uno V3 connectors.

The selection between LPUART and USART is performed by setting related solder bridges.

Refer to Table 10 and Table 11 below for the UART or LPUART connection to VCP interfaces or ARDUINO<sup>®</sup> UART.

**Table 10. LPUART1 connection**

| Solder bridge configuration <sup>(1)</sup>                      | Feature                                                                                                                                                                        |
|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SB127, SB129 ON</b><br><b>SB124, SB126, SB128, SB130 OFF</b> | <b>LPUART1 (PG7/PG8) connected to ST-LINK VCP.</b><br><b>Must be the interface for 1V8 MCU mode because PG [2-15] stay at 3V3 IO interface link to the VDDIO power supply.</b> |
| SB128, SB130 ON<br>SB123, SB125, SB127, SB129 OFF               | LPUART1 (PG7/PG8) connected to Zio, ARDUINO <sup>®</sup> D0/D1                                                                                                                 |

1. The default configuration is in bold.

**Table 11. USART3 connection**

| Solder bridge configuration <sup>(1)</sup>                      | Feature                                                              |
|-----------------------------------------------------------------|----------------------------------------------------------------------|
| SB124, SB126 ON<br>SB123, SB125, SB127, SB129 OFF               | USART3 (PD8/PD9) connected to ST-LINK VCP<br>Only 3V3 mode supported |
| <b>SB123, SB125 ON</b><br><b>SB124, SB126, SB128, SB130 OFF</b> | <b>USART3 (PD8/PD9) connected to Zio, ARDUINO<sup>®</sup> D0/D1</b>  |

By default:

- Communication between target MCU and ST-LINK MCU is enabled on LPUART1.
- Communication between target MCU, ARDUINO<sup>®</sup>, and ST morpho connectors, is enabled on USART3, not to interfere with the VCP interface.

The Virtual COM port settings are 115200 bps, 8-bit data, no parity, 1 stop bit, and no flow control.