



KEY_POWER c0030

KEY_AUDIO c01b7

KEY_INFO c0060

KEY_FIND c021f

KEY_RECORD c00b2

KEY_FINANCE c0191

KEY_TASKMANAGER c018f

KEY_F16 c008e

KEY_F17 c00b0

KEY_VOICECOMMAND c00cf

KEY_F18 c0188

KEY_F19 c0199

KEY_UP c0042

KEY_LEFT c0044

KEY_ENTER c0041

KEY_RIGHT c0045

KEY_DOWN c0043

KEY_WWW c0196

KEY_BACK c0224

KEY_HOMEPAGE c0223

KEY_VOLUMEUP c00e9

KEY_EXIT c0094

KEY_PAGEUP c009c

KEY_VOLUMEDOWN c00ea

KEY_MUTE c00e2

KEY_PAGEDOWN c009d

KEY_STOPCD c00b7

KEY_EJECTCD c00b8

KEY_SHUFFLE c00b9

KEY_SEARCH c0221

Xiaomi A3 Bluetooth Remote Control Keycode names and Scancodes

/dev/input/event18: Xiaomi RC Consumer Control ← Scancodes shown in this page.

/dev/input/event19: Xiaomi RC Keyboard ← Applies to numberpad 1 through 0; typical keyboard events.

This is a self-made reverse-engineering effort in attempt to register its buttons for further remapping within Linux. Scancodes were obtained by reading evtest output. Numberpad outputs keyboard-like input events. Image of remote is self-taken AI has been involved in removing the background to adapt the image.

For informational and/or educational purposes only. Neither this page nor Me are affiliated by Xiaomi