MAINTENANCE BODY GENERAL MAINTENANCE

PROCEDURE

■ 1.TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

- a. If necessary, tighten the bolts and nuts on the chassis parts listed below.
 - Front axle and suspension
 - Drivetrain
 - · Rear axle and suspension
 - Brake system
 - Engine mounts
 - Other chassis parts
- **b.** If necessary, tighten the bolts and nuts on the body parts listed below.
 - · Seat belt system
 - Seats
 - Doors and hood
 - Body mounts
 - Fuel tank
 - Exhaust system
 - · Other body parts

2.INSPECT TIRE AND INFLATION PRESSURE

- a. Check the tires for wear and proper inflation pressure.
 Click hereSuspension>TIRE / WHEEL>TIRE AND WHEEL SYSTEM>INSPECTION
- **■** 3.INSPECT LIGHTS, HORN, WIPERS AND WASHERS

■ 4.CLEAN OR REPLACE AIR CONDITIONING FILTER

- Remove the air conditioning filter.
 Click hereVehicle Interior>HEATING / AIR CONDITIONING>AIR CONDITIONING UNIT>DISASSEMBLY
- **b.** Visually inspect the surface of the air conditioning filter.
- c. If the air conditioning filter is contaminated with foreign matter, clean or replace it according to the maintenance schedule.

NOTICE:

Some filters are not able to be cleaned.

5.INSPECT REFRIGERANT AMOUNT FOR AIR CONDITIONER

a. Inspect the refrigerant pressure with manifold gauge.

Туре	See procedure
HFC-134a (R134a)	(
)

■ 6. ROAD TEST

a. Check the engine and chassis for abnormal noises.

- **b.** Check that the vehicle does not wander or pull to one side.
- c. Check that the brakes work properly and do not drag.
- **d.** Bed-in the parking brake shoes to the drums.

■ 7. CORROSION INSPECTION

■ 8. BODY INSPECTION

- a. Check the body exterior for dents, scratches and rust.
- **b.** Check the underbody for rust and damage. If necessary, replace the damaged part or repair the damaged area.

■ 9. FINAL INSPECTION

- a. Check the operation of the body parts.
 - i. Hood
 - · Auxiliary catch operates properly.
 - · Hood locks securely when closed.
 - ii. Front and rear doors
 - · Door locks operate properly.
 - · Doors close properly.
 - iii. Back doors
 - · Doors lock operate properly.
 - · Doors close properly.
 - iv. Tail gate
 - · Door closes properly.
 - v. Seats
 - · Seats adjust easily and lock securely in any position.
 - · Front seatbacks lock securely in any position.
 - · Fold-down rear seatbacks lock securely.
 - vi. Be sure to deliver a clean car. Make sure to check the following:
 - Steering wheel
 - · Shift lever knob
 - All switches and knobs
 - Door handles
 - Seats

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.