Print Exit

FRONT SUSPENSION FRONT SHOCK ABSORBER INSPECTION

CAUTION / NOTICE / HINT

HINT:

- · Use the same procedure for the RH and LH sides.
- · The procedure listed below is for the LH side.

PROCEDURE

■ 1.INSPECT FRONT SHOCK ABSORBER ASSEMBLY LH

48520

a. Compress and extend the shock absorber rod 4 or more times and check the operating sound and resistance. **Standard:**

The operating sound and resistance are normal.

If there is any abnormality, replace the front shock absorber with a new one.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.