MAINTENANCE BRAKE GENERAL MAINTENANCE

PROCEDURE

■ 1.INSPECT BRAKE PEDAL AND PARKING BRAKE

a. Inspect the brake pedal and parking brake.

Туре	See procedure
Brake pedal	(
)
Parking brake	(
)

■ 2.INSPECT BRAKE LININGS AND DRUMS

a. Inspect the rear brake linings and drums.

Туре	See procedure
Rear brake (for Rear Drum Brake)	(
)
Rear brake (for Rear Disk Brake)	(
)

■ 3.INSPECT BRAKE PADS AND DISCS

a. Inspect the brake pads and discs.

Туре	See procedure
Front brake	(
Rear brake (for Rear Disk Brake)	(

HINT:


- \cdot $\;$ If a squealing or scraping noise is heard from the brake while driving, check the pad wear indicator.
- \cdot If there are traces of the indicator contacting the disc rotor, the disc pad should be replaced.

■ 4,INSPECT BRAKE LINE PIPES AND HOSES

HINT:

Work in a well-lighted area. Turn the front wheels fully to the right or left before beginning the inspection.

a.



Using a mirror, check the entire circumference and length of the brake lines and hoses for:

- Damage
- Wear
- Deformation
- · Cracks
- · Corrosion
- Leaks
- Bends
- Twists
- **b.** Check all the clamps for tightness and the connections for leakage.
- c. Check that the hoses and lines are not near sharp edges, moving parts or the exhaust system.
- **d.** Check that the lines are installed properly and pass through the center of the grommets.

■ 5.INSPECT BRAKE FLUID

a. Inspect the brake fluid.

Туре	See procedure
w/ ABS	(
)
w/o ABS	(
)

■ 6.REPLACE BRAKE FLUID

a. Replace the brake fluid.

Туре	See procedure
w/ ABS	(
w/o ABS	(

■ 7.REPLACE VACUUM PUMP (for 1VD-FTV)

a. Replace the vacuum pump.

Туре	See procedure
1VD-FTV	(
)

■ 8.INSPECT VACUUM PUMP (for 1HZ)

a. Inspect the vacuum pump.

Туре	See procedure
1HZ	(

■ 9.INSPECT CLUTCH FLUID

- **a.** Inspect the clutch fluid (See page Drivetrain>CLUTCH>CLUTCH SYSTEM>BLEEDING).
- © 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.