PREPARATION HF1A TRANSFER / 4WD / AWD SST

			T
	09308-00010	Oil Seal Puller	-
	09309-60010	Extension Pipe	_
	03303 00010	Extension ripe	
	09316-20011	Transfer Bearing Replacer	_
		<u> </u>	
	09316-60011	Transmission & Transfer Bearing Replacer	-
	(09316-00011)	Replacer Pipe	_
	(09310-00011)	Replacel Fipe	-
	(09316-00031)	Replacer B	_
\$9,5352900			
	(09316-00041)	Replacer C	_
	(03310-00041)	Tropiacei C	
	(09316-00051)	Replacer D	-
	(00316 00061)	Donloor 5	
	(09316-00061)	Replacer E	-
	(09316-00071)	Replacer F	-

	09319-60020	Output Shaft Needle Roller Bearing Remover	-
	09330-00021	Companion Flange Holding Tool	-
	09502-12010	Differential Bearing Replacer	-
	09513-36040	Rear Axle Bearing Replacer	-
	09527-20011	Rear Axle Shaft Bearing Remover	-
D 000			
	09570-22011	Differential Mounting Cushion Remover & Replacer	-
	09817-16011	Back-up Light Switch Tool	-
	09950-00020	Bearing Remover	-

	-	+	
Ħ.	09950-00030	Bearing Remover Attachment	-
	09950-40011	Puller B Set	-
	(09951-04010)	Hanger 150	-
	(09951-04020)	Hanger 200	-
	(09952-04010)	Slide Arm	-
	(09953-04020)	Center Bolt 150 Arm 25	-
	(09955-04031)	Claw No.3	_
	(09955-04061)	Claw No. 6	_
9	(09957-04010)	Attachment	-

0011			
	09950-70010	Handle Set	-
١	(09951-07100)	Handle 100	-
	(09951-07200)	Handle 200	-

^{© 2012} TOYOTA MOTOR CORPORATION. All Rights Reserved.