DRIVE SHAFT / PROPELLER SHAFT FRONT PROPELLER SHAFT ASSEMBLY REMOVAL


PROCEDURE

1.REMOVE FRONT PROPELLER SHAFT ASSEMBLY

37140


Exit

a.



Place matchmarks on the propeller shaft flange and transfer flange.

b. Remove the 4 nuts and 4 washers.



Place matchmarks on the propeller shaft flange and differential flange.

- **d.** Remove the 4 nuts, 4 bolts and 4 washers.
- e. Remove the front propeller shaft assembly.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.