Illustrated Parts List

The Illustrated Part List (IPL) contains the illustrations and the parts lists for the different assemblies in the printer. The parts lists give the part numbers, description, and quantity of all the items and the modules in the printer. You can order the items and the modules for which the part numbers are given.

How to Read the IPL

This section describes how the higher assemblies are broken down to their related sub assemblies and other separate parts.

Illustrations

Table 10-1 on page 10-2 shows the symbols used to indicate the different levels of main assemblies in a printer, and the sub assemblies under the main assembly.

Rev AA How to Read the IPL 10-1




Table 10-1: Symbols Representation - Assemblies

► Indicates further explosion.

Alphabets

- An alphabet is assigned to the main assemblies of a printer and each sub assembly under the main assembly. See Figure 10-1 on page 10-3.
 - For example: If A, B, C and D identify the main assemblies of a printer, then the alphabets E, F, and so on identify the sub assemblies below each main assembly in a sequence.
- The alphabets assigned to main assemblies are used only for one time.
- The alphabets "I" and "O" are not used because they look like the numbers 1 and 0.

10-2 How to Read the IPL Rev AA

Numbers

A natural number (1,2,3.....) is assigned to the stand alone parts (in ascending order) through out the breakdown of main assemblies. See Figure 10-1.

Note: The numbers assigned to main assemblies can be used only for one time.




Figure 10-1: Graphical Representation of the Different Subassemblies and Parts

Rev AA How to Read the IPL 10-3

Tables

Figure 10-2 describes the styles used to show the explosion of the main assemblies in parts lists.




Figure 10-2: Representation of the different Sub-assemblies and parts in the Table

Notes

Notes provide useful information. Some examples for note are as follows:

Note: To order this item, use part number of item 9 in this table.

Note: This screw is a part of Core Module.

Note: This item can be ordered separately.

10-4 How to Read the IPL Rev AA

Willett 620 Printer



Figure 10-3: Main Parts of the Printer

Table 10-2 shows the sub assemblies of the printer.

| Item | Descriptions |
|------|-------------------------|
| Α | Electronics Compartment |
| В | Ink Compartment |
| С | Printhead |
| D | Cabinet |
| E | Umbilical |

Table 10-2: Willett 620 Printer Assembly

Rev AA Willett 620 Printer 10-5

Electronics Compartment




Figure 10-4: Electronics Compartment

Main Control Board (MCB)



Figure 10-5: Main Control Board

LCD




Figure 10-6: LCD

Electronics Fan Assembly




Figure 10-7: Electronics Fan Assembly

Power Supply Unit Assembly




Figure 10-8: Power Supply Unit Assembly

EHT Module




Figure 10-9: EHT Module

Connector Panel




Figure 10-10: Connector Panel

| Item Num | ber | P/N | Description | Qty |
|----------|-----|----------|---|-----|
| Α | | | Electronics Compartment | |
| | 1 | SP383356 | Main Control Board | 1 |
| | 2 | SP383353 | LCD with Touch Panel (Cable included) | 1 |
| | 3* | SP389494 | Fuse | 1 |
| F | | SP383352 | Electronics Fan Assembly | |
| | 4 | | Fan Bracket | 1 |
| | 5 | | Fan, 60 mm | 1 |
| | 6 | | Washer | 4 |
| | 7 | | Screw | 4 |
| | 8 | | Finger guard, 60 mm | 1 |
| G | | | Power Supply Unit (PSU) Assembly with Mount | |
| | 9 | SP389497 | PSU RT-50 | 1 |
| | 10 | SP389496 | PSU RS-75 | 1 |
| Н | | | EHT Module Assembly | |
| | 11 | | M4 Nyloc Nut | 2 |
| | 12 | 383124 | EHT Module | 1 |
| J | | | Connector Panel | |
| | 13 | | Print Trigger | 1 |
| | 14 | 383096 | USB Connector | 1 |

Table 10-3: Electronics Compartment

Ink Compartment






Figure 10-11: Ink System

Ink Cartridge




Figure 10-12: Ink Cartridge

Rev AA Ink Compartment 10-11

Make-up Cartridge




Figure 10-13: Make-up Cartridge

Septum Assembly






Figure 10-14: Septum Assembly

10-12 Ink Compartment Rev AA

Ink Core Module Assembly




Figure 10-15: Ink Core with Pump

Ink Core Pump




Figure 10-16: Ink Core Pump Assembly

Rev AA Ink Compartment 10-13

Ink Core Without Pump




Figure 10-17: Ink Core Module Without Pump

Ink System Fan




Figure 10-18: Ink System Fan Assembly

10-14 Ink Compartment Rev AA

| Item Number | P/N | Description | Qty |
|-------------|----------|--------------------------------------|-----|
| В | | Ink Compartment | |
| 1 | | Ink Cartridge | 1 |
| 2 | | Make-up Cartridge | 1 |
| F | 383107 | Septum Assembly | 1 |
| 3 | | K30 x 12 Pan-head Torx Screw | 2 |
| 4 | | M3 ET Washer | 2 |
| 5 | | Tube and Ribbon Cable Clamp | 1 |
| 6 | | K30 x 8 Pan-head Torx Screw | 6 |
| 7 | | Black Stripe Tube (Ink System) | 1 |
| 8 | | Septum | 1 |
| 9 | | Green Stripe Tube (Make-up System) | 1 |
| G | SP383345 | Ink Core with Pump | |
| 10 | SP383351 | One piece Ink System Cover | 1 |
| 11* | SP383348 | Valve Base Assembly | |
| 12* | SP383349 | Flush Valve | |
| 13* | SP383347 | 5 Micron Filter | 1 |
| 14* | SP383350 | Valve Connector Board (VCB) Assembly | 1 |
| J | 383119 | Micro Pump | |
| 15 | | M4 x 35 Cap-head Screw | 2 |
| 16 | | Saddle Clamp | 1 |
| 17 | | Micro Pump | 1 |
| K | SP383346 | Ink Core without Pump | |
| 18* | | M3 x 7 Manifold Screw | 2 |
| 19* | | Ink Core Manifold (Male) | 1 |
| 20 | | Ink Core Manifold Gasket | 1 |

Table 10-4: Ink Compartment

Rev AA Ink Compartment 10-15

| Item Number | P/N | Description | Qty |
|-------------|----------|----------------------------|-----|
| 21 | | Ink Core Manifold (Female) | 1 |
| Н | | Ink System Fan Assembly | |
| 22 | SP383352 | Fan | 1 |
| 23 | | M4 ET Washer | 4 |
| 24 | | M4 x 10 Cap-head Screw | 4 |
| 25 | | Fan Guard | 1 |
| 26* | SP231116 | Fan Inside Filter | 1 |


Table 10-4: Ink Compartment (Continued)

10-16 Ink Compartment Rev AA

^{*-} Items are not shown in the figure.

Printhead





Printhead Valve Module






Figure 10-20: Printhead Valve Module

Rev AA Printhead 10-17

Printhead Engine






Figure 10-21: Printhead Engine

| Item Number | P/N | Description | Qty |
|-------------|----------|--|-----|
| С | | Printhead | |
| F | SP383339 | Printhead Valve Module | |
| 1 | | M2 x 6 Cap-head Screw | 8 |
| 2 | | Printhead Valve Module Deck | 1 |
| 3 | | Printhead Valve Module Gasket | 1 |
| 4 | | Feed Valve | 1 |
| 5 | | Rear Manifold Gasket | 1 |
| 6 | | 3-Way Manifold Assembly (Rear Tubing Manifold) | 1 |
| G | SP383340 | Printhead Engine (60 micron) | |
| 7 | | M2 x 6 Cap-head Screw | 7 |
| 8 | | Nozzle Assembly | 1 |

Table 10-5: Printhead Assembly

10-18 Printhead Rev AA

| Item Number | P/N | Description | Qty |
|-------------|--------|---|-----|
| 9 | | Charge Electrode | 1 |
| 10 | | Deflector Plate | 1 |
| 11 | | Printhead Engine Deck | 1 |
| 12 | | Printhead Engine Gasket | 1 |
| 13 | | Front Tubing Manifold Gasket | 1 |
| 14 | | 1-Way Manifold Assembly (Front Tubing Manifold) | 1 |
| 15* | 383099 | Printhead Gasket Kit* | |
| | | Gasket, Printhead | 10 |
| | | Gasket, 3-way Manifold | 10 |
| | | Gasket, 1-way Manifold | 10 |
| | | Connection Manifold Gasket | 10 |
| | | 4.47 x 1.78 O-ring | 10 |

Table 10-5: Printhead Assembly (Continued)

Cabinet



Left Handle



Figure 10-22: Left Handle

Rev AA Cabinet 10-19

^{*-} Item is not shown in the figure.

Right Handle



Figure 10-23: Right Handle

Cabinet Foot




Figure 10-24: Cabinet Foot

| Item Number | P/N | Description | Qty |
|-------------|----------|--------------|-----|
| D | | Cabinet | |
| 1 | SP383554 | Left Handle | 1 |
| 2 | SP383555 | Right Handle | 1 |
| 3 | 392004 | Cabinet Foot | 4 |

Table 10-6: Cabinet

10-20 Cabinet Rev AA

Cables

| P/N | Description | Qty |
|----------|--|-----|
| SP383101 | Ribbon Cable and Heatshrink Assembly Smart Chip and Pump 14 Way | 1 |
| 383252 | 20 way Ink System Ribbon Cable Assembly | 1 |
| 383251 | 16 way Ink System Ribbon Cable Assembly | 1 |
| SP383889 | Mains Cable | 1 |
| SP383893 | IO 3 Way Photocell Cable | 1 |
| 388090 | 3 Way Cable MTG Plug | 1 |

Table 10-7: Cables

Rev AA Cables 10-21

Optional Accessories

Printhead Stand




Figure 10-25: Printhead Stand

Din Plugs



Figure 10-26: 3 Way DIN Plug

Accessories

| Item Number | P/N | Description | Qty |
|-------------|--------------|--|-----|
| | 383131 | Printhead Stand | |
| 1 | | Clamp Assembly | 1 |
| 2 | | Vertical Tube | 1 |
| 3 | | Printhead Cross Tube | 1 |
| 4 | | Printhead Mount Assembly | 1 |
| 5 | | M6 x 8 Grub Screw | 2 |
| 6 | | M10 Nut | 8 |
| 7 | | M10 Washer | 8 |
| 8 | | Stand Base Plate | 1 |
| 9 | | M16 x 40 Hex Bolt | 1 |
| 10 | | Adjustable Foot | 4 |
| 11 | | Anti-vibration Mounting | 1 |
| 12 | | Umbilical Clamp Assembly | |
| 13 | 500-0036-578 | 3-Way DIN Plug (Photo Cell) for Product Detector and Reverse Printing Input | 1 |

Rev AA Accessories 10-23

Miscellaneous Accessories

Bottle Holder

| Part Number | Description |
|-------------|------------------------|
| SP383357 | Bottle Holder Assembly |

Table 10-8: Connectivity

Hydraulics

| Part Number | Description |
|-------------|------------------|
| 399072 | Tubing Kit Spare |

Table 10-9: Printhead and Umbilical

Printhead and Umbilical

| Part Number | Description |
|-------------|--|
| SP383343 | Printhead and Umbilical Complete (2 m) 60 micron |
| SP383344 | Printhead Chassis and Umbilical (2 m) |
| SP383342 | Printhead Cover Assembly |
| 223277 | Printhead Screw (Only) |

Table 10-10: Printhead and Umbilical