OCPP App Configuration

For RIOD POWERPOD Chargers

Step-by-step guide to configure OCPP on your POWERPOD charger

CONFIGURATION GUIDE

Document No.	**RD035**
Date	**December 2025**
Drafted by	**RIOD India**
Website	**riod.energy**

Overview

This guide provides step-by-step instructions for configuring OCPP settings on RIOD POWERPOD Go and City chargers. OCPP configuration enables your charger to communicate with a Central Management System for remote monitoring, session management, billing, and fleet operations.

Prerequisites

- POWERPOD Go or City model (Lite does not support OCPP)
- Charger installed and powered on
- Smartphone or laptop with Wi-Fi capability
- CMS server details (URL, port, path)
- Device admin credentials (provided by RIOD with the device)

Accessing the Configuration Interface

1. Locate the Configuration button on your POWERPOD (bottom panel)
2. Press and hold the Configuration button for 3 seconds
3. LED indicator begins blinking yellow (configuration mode active)
4. On your device, open Wi-Fi settings and connect to: RIOD-[MAC_ID]
5. Password: 123123123
6. Open browser and navigate to: 192.168.1.1
7. Enter admin username and password (unique per device, provided by RIOD)

Configuring OCPP Settings

Navigate to EVSE Configuration > View Configuration > OCPP Configuration section. Fill in each field:

OCPP Configuration Fields	
OCPP Host	CMS server hostname or IP (e.g., cms.company.com)
OCPP Port	CMS server port (common: 5555, 8080, 443)
OCPP URL	WebSocket path (e.g., /ws/ or /ocpp/)
ChargeBox ID	Unique ID for this charger (must match CMS registration)
Vendor Name	Leave as RIOD unless CMS requires different
Charge Point Serial	Pre-filled with hardware serial (do not change)
Charge Point Model	Pre-filled as POWERPOD (do not change)

Network Configuration

Option A: Wi-Fi

1. Locate Wi-Fi settings section in the configuration page
2. Select your router's SSID or enter manually
3. Enter Wi-Fi password
4. Click "Set" to save

Option B: 4G LTE

1. Locate 4G settings section
2. Enter APN for your network provider

APN Reference	
Jio	jionet

BSNL	bsnlnet
Airtel	airtelgprs.com
Airtel IoT/M2M	airteliot.com
Vi	www

3. Click "Set" to save

Setting Up Payment Application

For commercial installations, configure the payment application:

1. Download the Community Charging Suite application
2. Login using your mobile number via OTP
3. Click the "+" button on the dashboard to add funds to your wallet
4. Scan the QR code on the charger to start charging
5. Select the charging mode

Saving and Testing

1. Click "Set" to save OCPP configuration
2. Click "Set" to save network configuration
3. Release the Configuration button on the charger
4. Charger restarts automatically
5. Wait for LED to stabilise: Yellow (stable) = Connected and ready

Verification: Check your CMS dashboard for the newly connected charge point. The charger sends a BootNotification upon connection. Status should show as Available.

Common Issues and Solutions

Issue	Cause	Resolution
Cannot connect to RIOD Wi-Fi	Config mode not active	Press config button, ensure LED blinks yellow
192.168.1.1 not loading	Wrong network connected	Verify connected to RIOD-MAC Wi-Fi
OCPP connection failing	Incorrect server details	Double-check host, port, URL format
Charger offline after config	Network credentials wrong	Re-enter config mode, verify credentials
ChargeBox ID rejected	ID not registered on CMS	Register the ChargeBox ID on your CMS first

Contact Information	
Website	riod.energy
Email	hello@riod.in
Support	support@riodlogic.com
Phone	+91 974 600 6455

riod.energy | hello@riod.in | +91 974 600 6455