



Time	Set the current time of HMI.
Date	Set the current date of HMI.
Daylight saving time	Set summer time start time and end time. NOTE Timer could be skipped when the wired controller switches summer time.
Language	Set the language of HMI.
Backlight	Set the backlight brightness.
Buzzer	Indicates the status of Buzzer.
Screen Lock	Reminds user how to lock and unlock the screen.
Screen Lock Time	Set the automatic screen lock timer.
Decimal separator	Switch decimal separator type.