

# **CONTENTS**

---

<b>1 SAFETY PRECAUTIONS .....</b>	<b>07</b>
<b>2 GENERAL INTRODUCTION .....</b>	<b>10</b>
<b>3 ACCESSORIES .....</b>	<b>11</b>
• 3.1 Accessories supplied with the unit .....	11
• 3.2 Accessories available from supplier.....	11
<b>4 BEFORE INSTALLATION.....</b>	<b>11</b>
<b>5 IMPORTANT INFORMATION FOR THE REFRIGERANT .....</b>	<b>12</b>
<b>6 INSTALLATION SITE .....</b>	<b>13</b>
• 6.1 Selecting a location in cold climates .....	14
• 6.2 Selecting a location in hot climates .....	14
<b>7 INSTALLATION PRECAUTIONS .....</b>	<b>15</b>
• 7.1 Dimensions .....	15
• 7.2 Installation requirements .....	15
• 7.3 Drain hole position .....	16
• 7.4 Servicing space requirements .....	16
<b>8 TYPICAL APPLICATIONS .....</b>	<b>18</b>
• 8.1 Application 1.....	18
• 8.2 Application 2.....	20
• 8.3 Cascade system.....	23
• 8.4 Balance tank volume requirement .....	25
<b>9 OVERVIEW OF THE UNIT .....</b>	<b>25</b>
• 9.1 Disassembling the unit.....	25
• 9.2 Main components.....	26
• 9.3 Electronic control box .....	27
• 9.4 Water piping .....	36
• 9.5 Filling water .....	39
• 9.6 Water piping insulation.....	40
• 9.7 Field wiring.....	40
<b>10 START-UP AND CONFIGURATION.....</b>	<b>54</b>
• 10.1 DIP switch settings overview .....	54